


HP LaserJet P2015 Series

Service Manual



TONER  invent

www.tonerplus.com.ua

HP LaserJet P2015 Series

Service Manual



Copyright information

© 2006 Copyright Hewlett-Packard Development Company, L.P.

Reproduction, adaptation, or translation without prior written permission is prohibited, except as allowed under the copyright laws.

The information contained herein is subject to change without notice.

The only warranties for HP products and services are set forth in the express warranty statements accompanying such products and services. Nothing herein should be construed as constituting an additional warranty. HP shall not be liable for technical or editorial errors or omissions contained herein.

Part number CB366-90905

Edition 1, 10/2006

Safety information

WARNING!

Potential Shock Hazard

Always follow basic safety precautions when using this product to reduce risk of injury from fire or electric shock.

Read and understand all instructions in the user guide.

Observe all warnings and instructions marked on the product.

Use only a grounded electrical outlet when connecting the printer to a power source. If you do not know whether the outlet is grounded, check with a qualified electrician.

Do not touch the contacts on the end of any of the sockets on the printer. Replace damaged cords immediately.

Unplug this product from wall outlets before cleaning.

Do not install or use this product near water or when you are wet.

Install the product securely on a stable surface.

Install the product in a protected location where no one can step on or trip over the power cord and where the power cord will not be damaged.

If the product does not operate normally, see the online user guide.

Refer all servicing questions to qualified personnel.

Information regarding FCC Class B, Parts 15 and 68 requirements can be found in the user guide.

Trademark credits

PostScript® 3™ is a trademark of Adobe Systems Incorporated.

Microsoft®, Windows®, and Windows XP® are U.S. registered trademarks of Microsoft Corporation.

Energy Star® and the Energy Star logo® are U.S. registered marks of the United States Environmental Protection Agency.



Table of contents

1 Product information

Product features	2
HP LaserJet P2015 printer	2
HP LaserJet P2015d printer	2
HP LaserJet P2015n printer	3
HP LaserJet P2015dn printer	3
HP LaserJet P2015x printer	3
Identify product parts	4
Control panel	6
Supported paper and other media	7
Optimize print quality for media types	7
Guidelines for using media	8
HP media	8
Media to avoid	8
Media that can damage the printer	8
Paper	9
Labels	9
Label construction	9
Transparencies	9
Envelopes	9
Envelope construction	10
Envelopes with double-side seams	10
Envelopes with adhesive strips or flaps	10
Envelope storage	10
Card stock and heavy media	11
Card stock construction	11
Card stock guidelines	11
Letterhead and preprinted forms	11
Load media	13
Tray 1	13
Tray 2 and optional tray 3	14
Straight-through output path	14
Manual feed	15
Media type and tray loading	15

2 Installation

Site preparation	18
Package contents	19
Install tray 3	20

Install printer software	21
Supported operating systems	21
Drivers	21
Windows printer drivers	21
Macintosh printer driver	21
Driver downloads	21
Installing software on Microsoft® Windows	22
Installing software on Macintosh OS X V10.2.8, V10.3.9, and V10.4.3	23
Uninstaller	23
Printer information pages	25
Demo page	25
Configuration page	25
Supplies Status page	25
Network Configuration page	25

3 Manage the printer

HP ToolboxFX	28
To view HP ToolboxFX	28
Status	29
Alerts	30
Set up status alerts	30
Set up e-mail alerts	30
Help	30
Device settings	31
Device information	31
Paper handling	32
Print quality	32
Paper types	32
System setup	33
Service	33
Print settings	33
Printing	33
PCL 5e	33
PCL 6	33
PostScript®	34
Network settings	34
Embedded Web server	35
Open the embedded Web server	35
Status tab	36
Settings tab	36
Networking tab	36
Links	37

4 Maintenance

Replace the print cartridge	40
Redistribute toner	42
Clean the printer	43
Clean the print-cartridge area	43
Clean the printer media path	44
Clean the pickup roller (tray 1)	46

Replace the pickup roller (tray 1)	51
Clean the pickup roller (tray 2)	55
Replace the pickup roller (tray 2)	62

5 Theory of operation

Introduction	70
Internal components	71
Timing	73
Engine control system	74
Laser/scanner system	76
Pickup/feed/delivery system	77
Image-formation system	79

6 Removal and replacement

Introduction	84
Removal and replacement strategy	84
Electrostatic discharge	84
Required tools	84
Before performing service	85
Pre-service procedures	85
Parts removal order	85
Covers	86
Left-side cover	86
Right-side cover	86
Back cover	87
Duplexer tray (HP LaserJet P2015d, P2015dn, and P2015x printers only)	89
Top cover	90
Control panel	95
Formatter	97
Laser/scanner	98
Memory-tag-reader assembly	99
Duplex-drive PCA (HP LaserJet P2015d, P2015dn, and P2015x printers only)	101
Fuser	103
Fan	103
Duplex-drive gears (HP LaserJet P2015d, P2015dn, and P2015x printers only)	104
Duplex solenoid (HP LaserJet P2015d, P2015dn, and P2015x printers only)	106
Fuser	107
Interlock assembly	118
ECU	119
Main motor	126
Pickup and feed assemblies	128
Transfer roller	128
Registration assembly	129
Main gear assembly/tray 2 pickup solenoid	130
Print-cartridge door	134

7 Problem solving

Basic problem solving	138
Status-light patterns	140

Fatal error secondary messages	147
Accessory error secondary messages	150
Media problemsolving	151
Printed page is different from what appeared on screen	153
Garbled, incorrect, or incomplete text	153
Missing graphics or text, or blank pages	153
Page format is different from another HP LaserJet printer	154
Graphics quality	154
Image problem solving	155
Light print or faded	155
Toner specks	155
Dropouts	155
Vertical lines	156
Gray background	156
Toner smear	156
Loose toner	157
Vertical repetitive defects	157
Misformed characters	157
Page skew	158
Curl or wave	158
Wrinkles or creases	158
Toner scatter outline	159
Clear jams	160
Print-cartridge area	160
Input trays	162
Output bin	165
Straight-through output path	166
Automatic two-sided printing path	167
Diagnostic resources	172
Engine test	172
Continuous self-test	172
Half self-test functional check	173
Drum rotation functional check	173
Heating element check	173
High-voltage contacts check	174
Checking the print cartridge contacts	174
Checking the high-voltage connector assembly	175
Network-setup problemsolving	176
Reset the printer	177
NVRAM initialization	177
Super NVRAM initialization	177
Network reset	178
Cold reset	178
Troubleshooting tools and reference diagrams	179
Repetitive image defects	179
General timing chart	180
Circuit diagram	181
Solenoids	183
Switches and sensors	184
Rollers and pads	185

8 Parts and diagrams

Order parts and supplies	188
Parts	188
Related documentation and software	188
Supplies	188
Assembly locations	190
Covers	194
Internal assemblies	198
Alphabetical parts list	228
Numerical parts list	239

Appendix A Accessory/Consumable addendum

Consumables and accessories	252
10/100 networking print servers	252
HP print cartridges	253
HP policy on non-HP print cartridges	253
Storing print cartridges	253
Print cartridge life expectancy	253
Saving toner	253
DIMMs (memory or font)	254
Install a DIMM	254
Test the DIMM installation	256
Remove a DIMM	256

Appendix B Service and support

Hardware service	260
Extended warranty	260
Guidelines for repacking the printer	261
How to contact HP	261

Appendix C Printer specifications

Environmental specifications	264
Acoustic emissions	264
Electrical specifications	265
Physical specifications	267
Printer capacities and ratings	268
Memory specifications	268
Port availability	268

Appendix D Regulatory information

FCC compliance	270
Declaration of Conformity statements	271
Regulatory statements	272
Laser safety statement	272
Canadian DOC regulations	272
Korean EMI statement	272
Laser statement for Finland	273

Appendix E Warranty and licensing

Hewlett-Packard limited warranty statement276

Hewlett-Packard software license agreement277

Limited warranty for print cartridge278

Index279

1 Product information

This chapter provides information on the following topics:

- [Product features](#)
- [Identify product parts](#)
- [Control panel](#)
- [Supported paper and other media](#)
- [Load media](#)

Product features

The following are the standard configurations for the HP LaserJet P2015 Series printers.

HP LaserJet P2015 printer

- 27 ppm (Letter-size), 26 ppm (A4-size)
- First page out in as few as 8.5 seconds
- ProRes 1200 (provides fine-line detail at 1200 x 1200 dpi)
- FastRes 1200 600x600x2
- 600 dpi (provides 600 x 600 dpi output with Resolution Enhancement Technology [REt] for improved text)
- 50-sheet multipurpose tray (tray 1)
- 250-sheet enclosed input tray (tray 2)
- Optional additional 250-sheet input tray (tray 3)
- EconoMode
- Print watermarks, booklets, multiple pages per sheet (N-up), and first page on different media than the rest of the document
- 32 MB RAM
- Memory can be upgraded to 288 MB
- 3,000-page or 7,000-page print cartridge
- PCL 6, PCL 5e, and HP postscript level 3 emulation (printer automatically determines and switches to the appropriate language)
- Compatible with USB 2.0 specifications
- Supported by Windows® 98 (printer driver only), Me (printer driver only), 2000, Server 2003 (printer driver only), XP 32-bit, XP 64-bit (printer driver only)
- Supported by Macintosh OS X V10.2.8, V10.3.9, V10.4.3
- On/off switch
- HP ToolboxFX (provides printer status information, troubleshooting information, and printer configuration information)
- Embedded Web server (EWS) with internal pages that are localized in 16 languages
- 45 HP fonts
- 35 HP postscript emulation level 3 fonts

HP LaserJet P2015d printer

The HP LaserJet P2015d printer includes all of the features of the HP LaserJet P2015 plus automatic two-sided (duplex) printing.

HP LaserJet P2015n printer

The HP LaserJet P2015n printer includes all of the features of the HP LaserJet P2015 plus an HP internal network port.

HP LaserJet P2015dn printer

The HP LaserJet P2015dn printer includes all of the features of the HP LaserJet P2015d plus an HP internal network port.

HP LaserJet P2015x printer

The HP LaserJet P2015x printer includes all of the features of the HP LaserJet P2015dn plus an additional 250-sheet input tray (tray 3).

Identify product parts

The following illustrations identify the components of the HP LaserJet P2015 Series printers. The HP LaserJet P2015dn model is shown.




Figure 1-1 HP LaserJet P2015dn, front view

1	Output bin
2	Print-cartridge door
3	Tray 1 (50-sheet multipurpose tray)
4	Model number
5	Tray 2 (250-sheet enclosed input tray)
6	On/off switch
7	Print-cartridge-door button
8	Control panel





Figure 1-2 HP LaserJet P2015dn, back view

1	Straight-through output door
2	Power receptacle

3	Automatic two-sided-printing media-size selector (duplex models only)
4	HP internal network port (network-ready models only)
5	USB port
6	Rear automatic two-sided path door (duplex models only)
7	Jam-clearing levers
8	Serial number

Control panel

The printer control panel is comprised of six lights and two buttons. The lights produce patterns that identify the printer status.



1	Jam light: Indicates that there is a jam in the printer.
2	Toner light: When the print cartridge is low, the Toner light illuminates. When the print cartridge is out of the printer, the Toner light blinks.
3	Paper out light: Indicates that the printer is out of paper.
4	Attention light: Indicates that the print-cartridge door is open or other errors exist.
5	Ready light: Indicates that the printer is ready to print.
6	Go button and light: Initiates action or indicates status.
7	Cancel button: To cancel the print job that is currently printing, press the Cancel button.

Supported paper and other media

The HP LaserJet P2015 Series printer can use a variety of paper and other print media in accordance with the guidelines in this user guide. Media that does not meet these guidelines might cause the following problems:

- Poor print quality
- Increased jams
- Premature wear on the printer, requiring repair

For best results, use only HP brand paper and print media. Hewlett-Packard Company cannot recommend the use of other brands. Because they are not HP products, HP cannot influence or control their quality.

It is possible for media to meet all of the guidelines in this user guide and still not produce satisfactory results. This might be the result of improper handling, unacceptable temperature and humidity levels, or other variables over which Hewlett-Packard has no control.

Before you purchase a large quantity of media, test the media and make sure that it meets the requirements specified in this user guide and in *HP LaserJet printer family media guide*. Download the guidelines from <http://www.hp.com/support/ljpaperguide/>.



CAUTION Using media that does not meet Hewlett-Packard's specifications might cause problems for the printer, requiring repair. This repair is not covered by the Hewlett-Packard warranty or service agreements.

Optimize print quality for media types

The HP LaserJet P2015 Series printers provide a number of print modes that allow the unit to adapt to various media. You can change the print modes on the **Paper** tab in the printer driver, in HP ToolboxFX, or in the embedded Web server.



NOTE When using the CARDSTOCK, ENVELOPE, LABEL, and ROUGH modes, the printer pauses between pages and the number of pages per minute decreases.

Table 1-1 Driver print modes

Mode	Media type
PLAIN	75 to 104 g/m ² (20 to 27 lb)
LIGHT	Less than 75 g/m ² (20 lb)
HEAVY	90 to 105 g/m ² (24 to 28 lb)
CARDSTOCK	Card stock or thick media
TRANSPARENCY	4-mil, 0.1 Monochrome Overhead Transparencies (OHTs)
ENVELOPE	Standard HP LaserJet envelopes
LABEL	Standard HP LaserJet labels
BOND	Bond paper
ROUGH	Rough paper

Guidelines for using media

You can print on a variety of media, such as paper (including up to 100% recycled-fiber-content paper), envelopes, labels, transparencies, and custom-size media. The following are the supported media sizes:

- Minimum: 76 by 127 mm (3 x 5 inches)
- Maximum: 216 by 356 mm (8.5 x 14 inches)

Properties such as weight, grain, and moisture content are important factors that affect printer performance and quality. To achieve the best possible print quality, only use high-quality media that is designed for laser printers.

HP media

HP recommends a variety of media. See the *HP LaserJet Printer Family Print Media Guide* (<http://www.hp.com/support/ljpaperguide/>) for a full list.

Media to avoid

- Do not use paper that is too rough.
- Do not use paper with cutouts or perforations other than standard 3-hole punched paper.
- Do not use multipart or multipage forms.
- Do not use paper that contains a watermark if you are printing solid patterns.

Media that can damage the printer

- Do not use media with staples attached.
- Do not use transparencies designed for inkjet printers or other low-temperature printers. Use only transparencies that are specified for use with HP LaserJet printers.
- Do not use photo paper intended for inkjet printers.

- Do not use paper that is embossed or coated and is not designed for the temperatures of the printer's image fuser. Select media that can tolerate temperatures of 200°C (392°F) for 0.1 second. HP produces a selection of media that is designed for the HP LaserJet P2015 Series printers.
- Do not use letterhead paper that uses low temperature dyes or thermography. Preprinted forms or letterhead must use inks that can tolerate temperatures of 200°C (392°F) for 0.1 second.
- Do not use any media that produces hazardous emissions, or that melts, offsets, or discolors when exposed to temperatures of 200°C (392°F) for 0.1 second.

To order HP LaserJet printing supplies, go to <http://www.hp.com/go/ljsupplies/> in the U.S. or to <http://www.hp.com/ghp/buyonline.html/> worldwide.

Paper

For best results, use conventional 75 g/m² (20 lb) paper. Make sure that the paper is of good quality and free of cuts, nicks, tears, spots, loose particles, dust, wrinkles, voids, and curled or bent edges.

Labels

Print labels from tray 1 by using the straight-through output path.



CAUTION Do not feed a sheet of labels through the printer more than once. The adhesive degrades during the heat of printing and might damage the printer.

Label construction

When selecting labels, consider the quality of the following components:

- **Adhesives:** The adhesive material should be stable at 200°C (392°F), the printer's maximum temperature.
- **Arrangement:** Only use labels with no exposed backing between them. Labels can peel off sheets that have spaces between the labels, causing serious jams.
- **Curl:** Prior to printing, labels must lie flat with no more than 13 mm (0.5 inch) of curl in any direction.
- **Condition:** Do not use labels that have wrinkles, bubbles, or other indications of separation.

Transparencies

Transparencies must be able to withstand 200°C (392°F), the printer's maximum temperature.

Envelopes

Print envelopes from tray 1 by using the straight-through paper path.


Envelope construction

Envelope construction is critical. Envelope fold lines can vary considerably, not only between manufacturers but also within a box from the same manufacturer. When selecting envelopes, consider the following components:

- **Weight:** The weight of the envelope paper should not exceed 90 g/m² (24 lb), or jamming might result.
- **Construction:** Prior to printing, envelopes should lie flat with less than 6 mm (0.25 in.) curl and should not contain air. Envelopes that trap air may cause problems. Do not use envelopes that contain clasps, snaps, tie strings, transparent windows, holes, perforations, cut outs, synthetic materials, stamping, or embossing. Do not use envelopes with adhesives that do not require moistening, but rely instead on pressure to seal them.
- **Condition:** Make sure that the envelopes are not wrinkled, nicked, or otherwise damaged. Make sure that the envelopes do not have any exposed adhesive.
- **Sizes:** From 90 x 160 mm (3.5 x 6.3 inches) to 178 x 254 mm (7 x 10 inches).

Envelopes with double-side seams

An envelope with double-side-seam construction has vertical seams at both ends of the envelope rather than diagonal seams. This style might be more likely to wrinkle. Make sure that the seam extends all the way to the corner of the envelope as shown in the following illustration.



- | | |
|---|------------------------------------|
| 1 | Acceptable envelope construction |
| 2 | Unacceptable envelope construction |

Envelopes with adhesive strips or flaps

Envelopes with a peel-off adhesive strip or with more than one flap that folds over to seal must use adhesives compatible with the heat and pressure in the printer: 200°C (392°F). The extra flaps and strips might cause wrinkling, creasing, or jams.

Envelope storage

Proper storage of envelopes contributes to good print quality. You should store envelopes flat. If air is trapped in an envelope, creating an air bubble, the envelope might wrinkle during printing.

Card stock and heavy media

You can print many types of card stock from the paper input tray, including index cards and postcards. Some card stock performs better than others because its construction is better suited for feeding through a laser printer.

For optimum printer performance, do not use paper heavier than 157 g/m² (42 lb). Paper that is too heavy might cause misfeeds, stacking problems, paper jams, poor toner fusing, poor print quality, or excessive mechanical wear.



NOTE You might be able to print on heavier paper if you do not fill the input tray to capacity and if you use paper with a smoothness rating of 100-180 Sheffield.

Card stock construction

- **Smoothness:** 135-157 g/m² (36-42 lb) card stock should have a smoothness rating of 100-180 Sheffield. 60-135 g/m² (16-36 lb) card stock should have a smoothness rating of 100-250 Sheffield.
- **Construction:** Card stock should lie flat with less than 5 mm (0.2 inch) of curl.
- **Condition:** Make sure that the card stock is not wrinkled, nicked, or otherwise damaged.
- **Sizes:** Only use card stock within the following size ranges:
 - **Minimum:** 76 x 127 mm (3 x 5 inches)
 - **Maximum:** 216 x 356 mm (8.5 x 14.0 inches)

Card stock guidelines

Set margins at least 2 mm (0.08 inch) away from the edges.

Letterhead and preprinted forms

Many manufacturers now offer premium paper advertised as laser-compatible or laser-guaranteed. Some of the rougher surface finishes, such as cockle, laid, or linen, might require the special fuser modes that are available on some printer models in order to achieve adequate toner adhesion.



NOTE Some page-to-page variation is normal when printing with laser printers. This variation cannot be observed when printing on plain paper. However, this variation is obvious when printing on preprinted forms because the lines and boxes are already placed on the page.

To avoid problems when using preprinted forms, embossed paper, and letterhead, observe the following guidelines:

- Avoid using low-temperature inks (the kind used with some types of thermography).
- Use preprinted forms and letterhead paper that have been printed by offset lithography or engraving.
- Use forms that have been created with heat-resistant inks that will not melt, vaporize, or release undesirable emissions when heated to 200°C (392°F) for 0.1 second. Typically, oxidation-set or oil-based inks meet this requirement.

- When the form is preprinted, be careful not to change the moisture content of the paper, and do not use materials that change the paper's electrical or handling properties. Seal the forms in moisture-proof wrap to prevent moisture changes during storage.
- Avoid processing preprinted forms that have a finish or coating.
- Avoid using heavily embossed or raised-letterhead papers.
- Avoid papers that have heavily textured surfaces.
- Avoid using offset powders or other materials that prevent printed forms from sticking together.

Load media


The following sections describe how to load media into the different input trays.



CAUTION If you try to print on media that is wrinkled, folded, or damaged in any way, a jam might occur.


Tray 1

Tray 1 is accessed from the front of the printer. The printer prints from tray 1 before attempting to print from other trays.



Tray 1 holds up to fifty sheets of 75 g/m² (20 lb) media or ten envelopes, ten transparencies, or ten cards. You can use tray 1 to print the first page on media different from the remainder of the document.


Media guides ensure that the media is correctly fed into the printer and that the print is not skewed (crooked on the media). When loading media, adjust the media guides to match the width of the media that you are using.



Tray 2 and optional tray 3

Tray 2 and optional tray 3 hold up to 250 pages of 75 g/m² (20 lb) paper, or fewer pages of heavier media (25 mm (0.9 inch) or less stack height). Load media with the top forward and the side to be printed on facing down.


Media guides ensure that the media feeds correctly into the printer and that the print is not skewed. Tray 2 has side and rear media guides. When loading media, adjust the media guides to match the length and width of the media that you are using.



NOTE When you add new media, make sure that you remove all of the media from the input tray and straighten the stack of new media. This reduces jams by preventing multiple sheets of media from feeding through the printer at one time.

Straight-through output path

Use the straight-through output path when printing envelopes, transparencies, heavy media, or any media that tends to curl when printed. If you open the straight-through output door before printing media from tray 1, tray 2, or optional tray 3, the media exits the printer through the straight-through output path.



NOTE Printed media does not stack when you use the straight-through output path. The media drops to the surface below unless you remove each sheet as it exits the printer.

Manual feed

You can use manual feed when printing mixed media. For example, you can use manual feed to print an envelope, then a letter, then an envelope, and so on. Load envelopes in tray 1 and load letterhead into tray 2.

To print using manual feed, open the printer Properties or Printer Setup, and then select **Manual Feed (tray 1)** from the **Source Tray** drop-down list. After you have enabled manual feed, press the **Go** button to print.

Media type and tray loading

The HP LaserJet P2015 Series has the following tray priority:

1. Tray 1 (if open)
2. Tray 3 (if attached)
3. Tray 2

Minimum media dimensions are 76 x 127 mm (3 x 5 inches).

Maximum media dimensions are 216 x 356 mm (8.5 x 11 inches).

Table 1-2 Tray 1 media information

Media type	Media specifications	Media quantity	Driver settings	Paper orientation	Output
Normal	75 to 104 g/m ² (20 to 27 lb)	Up to 50 sheets	Plain or unspecified	N/A	Output bin
Envelopes	Less than 90 g/m ² (24 lb)	Up to 10 envelopes	Envelope	Short edge leading, flap on right side facing up	Straight-through output door
Labels	Standard	Up to 10 sheets	Labels	Side to be printed facing up	Straight-through output door
Shipping labels	Heavy	Up to 10 sheets	Cardstock	Side to be printed facing up	Straight-through output door
Transparencies	4-mil, 0.1 Monochrome Overhead	Up to 10 sheets	Transparencies	Side to be printed facing up	Straight-through output door
Heavy	90 to 105 g/m ² (24 to 28 lb)	Up to 10 sheets	Light glossy, glossy, or heavy glossy	Side to be printed facing up	Straight-through output door
Glossy	75 to 105 g/m ² (20 to 28 lb)	Up to 10 sheets	Light glossy, glossy, or heavy glossy	Side to be printed facing up	Straight-through output door
Letterhead	75 to 104 g/m ² (20 to 27 lb)	Up to 10 sheets	Letterhead	Side to be printed facing up, top of page in first	Output bin
Cardstock	Up to 10	Up to 10	Cardstock	Side to be printed facing up	Straight-through output door

Table 1-3 Tray 2 and optional tray 3 media information

Media type	Media specifications	Media quantity	Driver settings	Paper orientation	Output
Normal	75 to 104 g/m ² (20 to 27 lb)	Up to 250 sheets	Plain or unspecified	N/A	Output bin
Heavy	90 to 105 g/m ² (24 to 28 lb)	Up to 250 sheets	Cardstock	N/A	Straight-through output door
Transparencies	4-mil, 0.1 Monochrome Overhead	Up to 10 sheets	Transparencies	Side to be printed face down	Straight-through output door
Letterhead	75 to 104 g/m ² (20 to 27 lb)	Up to 250 sheets	Letterhead	Side to be printed face down	Normal: output bin Heavy: straight-through output door

2 Installation

- [Site preparation](#)
- [Package contents](#)
- [Install tray 3](#)
- [Install printer software](#)
- [Printer information pages](#)

Site preparation

Place the printer on a sturdy, level surface that meets the following environmental requirements:

- Temperature: 15°C to 32.5°C (59°F to 90.5°F)
- Humidity: 10% to 80% relative humidity (no condensation)
- Exposure: Place away from direct sunlight, open flames, ammonia fumes, and air vents.
- Clearance: Allow sufficient space around the printer for access.
- Ventilation: Ensure that the printer is located in a well-ventilated area.

Package contents

Figure 2-1 Package contents on page 19 shows the package contents for the HP LaserJet P2015 Series printer.




Figure 2-1 Package contents

1	HP LaserJet P2015 Series printer
2	Software and user documentation CD-ROM
3	Power cable

Install tray 3

If you have tray 3, install tray 3 as shown.




Figure 2-2 Installing tray 3

After installing tray 3, configure the printer driver to allow printing from tray 3.

1. On the Windows task bar, click **Start**, click **Settings**, and then click **Printers**.
2. Right-click the **HP LaserJet P2015** icon.
3. Click **Properties**.
4. Click the **Device Settings** tab.
5. Windows 2000/XP: Under **Installable Options**, change **Tray 3** to **Installed**.

Windows 98/Me: Click **Configure**, and then select **Tray 3** under **Optional Paper Sources**.

Install printer software

Supported operating systems

The printer software runs on the following operating systems:

- Windows 98 (printer driver only)
- Windows Me (printer driver only)
- Windows 2000
- Windows Server 2003 (printer driver only)
- Windows XP (32-bit)
- Windows XP (64-bit) (printer driver only)
- Macintosh OS X V10.2.8, V10.3.9, and V10.4.3

Drivers

Windows printer drivers

The software CD-ROM that came with the printer includes three Windows printer drivers: PCL 5e, PCL 6, and HP postscript level 3 emulation. Choose a printer driver based on the way you use the printer.

- Use the **PCL 5e** printer driver if you need print results to look consistent with those from older HP LaserJet printers. Certain features are not available in this printer driver.
- Use the **PCL 6** printer driver to take full advantage of all printer features. Unless complete backward compatibility with previous PCL drivers or older printers is necessary, the PCL 6 driver is recommended.
- Use the **HP postscript level 3 emulation** printer driver for HP postscript level 3 emulation. Certain printer features are not available in this printer driver.

Macintosh printer driver

The software CD-ROM that came with the printer includes an HP LaserJet P2015 Series driver for Macintosh OS X V10.2.8, V10.3.9, and V10.4.3

Driver downloads

The latest printer drivers and printing software for your HP LaserJet printer are available on the Web at <http://www.hp.com/support/ljp2015>.

Installing software on Microsoft® Windows

Two methods are available for installing printer drivers and software components for the printer.

Full (Recommended). Installs everything that your device needs to work plus HP ToolboxFX:

- **HP LaserJet P2015 Series PCL 6 driver.**
- **HP ToolboxFX.** Allows you to change printer settings and contains documentation and self-help tools.
- **Screen Fonts.** Printer-matching TrueType fonts help ensure WYSIWYG printing.
- **HP LaserJet P2015 Series printer documentation.** A list of documentation, which includes information about product operation, troubleshooting, warranty and specifications, supplies, and support.
- **HP Software Update.** Use this software to check for software updates for your HP products.

Minimum. Installs only the software required to print. The following is a list of available components:

- **HP LaserJet P2015 Series PCL 6 driver**
- **Screen Fonts.** Printer-matching TrueType fonts help ensure WYSIWYG printing.
- **HP Software Update.** Use this software to check for software updates for your HP products.



NOTE To install additional printer drivers (PCL 5e or HP postscript level 3 emulation), utilize the Windows Add Printer utility.

NOTE Administrator privileges are required to install the printing system onto a Windows 2000 or Windows XP operating system.

USB Connection

1. Insert the software installation CD into the computer CD-ROM drive.
2. If the installation program does not start automatically, browse the CD contents and run the SETUP.EXE file.
3. Follow the onscreen instructions.

Network Connection

If a computer on the network already has the HP LaserJet P2015 software installed, no additional software installation is necessary when adding a new HP LaserJet P2015 printer to the network. Otherwise, install the printer software on one of the networked computers as directed below.

1. Insert the software installation CD into the computer CD-ROM drive.
2. If the installation program does not start automatically, browse the CD contents and run the SETUP.EXE file.
3. Follow the onscreen instructions.
4. At the printer control panel, print a Network Configuration page to verify the installation was successful.

Installing software on Macintosh OS X V10.2.8, V10.3.9, and V10.4.3

USB connection

1. Insert the CD-ROM.
2. Run the installation utility.
3. After the software installation is complete, attach the USB cable to the printer and the computer and then restart the computer.
4. After the computer has restarted, open the Print Center or Printer Setup Utility to see if the printer name appears in the Printer List.
5. If the printer name appears in the Printer List, the setup is complete. If the printer name does not appear in the Printer List, go to the next step.
6. Click the **Add** button, and then select **USB** from the drop-down list.
7. Select **HP LaserJet P2015 Series** and then click **Add**. The printer name appears in the Printer List. Setup is complete.

Network connection

1. Connect the local area network (LAN) cable to the printer.
2. Print the Network configuration report from the printer control panel. Find the "mDNS printer name" located under the TCP/IP heading. The mDNS name will be needed in step 7.
3. Insert the CD-ROM.
4. Run the installation utility.
5. After the installation utility has completed, open the Print Center or Printer Setup Utility.
6. Click **Add**, and then select **Bonjour/Rendezvous** from the drop-down list.
7. Select the **HP LaserJet P2015 Series printer** name that matches the mDNS printer name found on the Network configuration report printed in step 2.
8. Click **Add**. The printer name appears in the Printer List. Setup is complete.
9. At the printer control panel, print a Network Configuration page to verify the installation was successful.

Uninstaller

Use the Uninstall icon in the HP LaserJet P2015 Series printer program group to select and remove the HP printing system components from a Windows machine.

1. From the **Start** menu, in the **HP LaserJet P2015 Series** program group, click the **Uninstall** icon.
2. The printing system guides you through removing all of the printing system components.
3. If you have performed a **Full** install and you do not have any other HP devices installed, follow steps 4 and 5. Following these steps might disable the functionality of other HP devices that are installed because they share the software.

4. Open the Microsoft Windows Control Panel. Double-click **Add/Remove Programs**.
5. You will see entries for HP Extended Capabilities, HP Software Update, HP Imaging Device Functions, and HP Solution Center and Imaging Support Tools. For each item, click **Change/Remove** and follow the prompts.



NOTE For driver-only (Add Printer) installations, delete the printer icon from the Printers folder (Windows 98 Second Edition, Windows Me, Windows 2003 Server , and Windows XP 64-bit).

Printer information pages

You can print the following information pages.

Demo page

The Demo page contains examples of text and graphics. To print the Demo page, press the **Go** button when the printer **Ready** light is on and no other jobs are printing.

Configuration page

The Configuration page lists current settings and properties of the printer. It also contains a status log report. You can print a Configuration page from the following locations:

- Printer control panel. Press the **Go** button until the **Ready** and **Error** lights start blinking, and then release the **Go** button.
- Embedded Web server
- HP ToolboxFX



NOTE You can also get the information contained in the Event log and the Configuration page through the HP ToolboxFX without printing the pages.

Supplies Status page

The Supplies Status page automatically prints when you print a Configuration page from the control panel. The Supplies Status page provides the following information:

- The estimated percentage of toner remaining in the print cartridge
- The number of pages and print jobs that have been processed
- Ordering and recycling information

Network Configuration page



NOTE The Network Configuration page is only available on printers with an HP internal network port.

The Network Configuration page automatically prints when you print a Configuration page from the control panel. The Network Configuration page provides the following information about the printer network configuration:

- IP address
- firmware version
- network statistics
- protocol information

3 Manage the printer

This chapter provides information on the following topics:

- [HP ToolboxFX](#)
- [Embedded Web server](#)

HP ToolboxFX

HP ToolboxFX is software that you can use to complete the following tasks:

- Check the printer status.
- Configure the printer settings.
- View troubleshooting information.
- View online documentation.

You can view HP ToolboxFX when the printer is directly connected to your computer or when it is connected to the network. You must perform a typical software installation to install HP ToolboxFX.



NOTE HP ToolboxFX is not supported for Windows 98 SE, Windows Me, Windows Server 2003, or Macintosh operating systems.

NOTE You do not need Internet access to open and use HP ToolboxFX.

To view HP ToolboxFX

Open HP ToolboxFX in one of these ways:

- In the Windows system tray or on your desktop, double-click the HP ToolboxFX icon.
- On the Windows **Start** menu, click **Programs** (or **All Programs** in Windows XP), click **HP**, click **HP LaserJet 2015 Series**, and then click **HP ToolboxFX**.

Status

The HP ToolboxFX **Status** folder contains links to the following main pages:

- **Device Status.** View printer status information. This page indicates printer conditions such as a jam or an empty tray. After you correct a problem with the printer, click **Refresh** to update the printer status.
- **Supplies Status.** View detailed supplies status such as the estimated percentage of toner remaining in the print cartridge and the number of pages that have been printed with the current print cartridge. This page also has links to order supplies and to find recycling information.
- **Device Configuration.** View a detailed description of the current printer configuration, including the amount of memory installed and whether optional trays are installed.
- **Network Configuration.** View a detailed description of the current network configuration, including the IP address and network status.
- **Print Info Pages.** Print the Configuration page and various other information pages that are available for the printer, such as the Supplies Status page and the Demo page.
- **Event Log.** View a four-column table where printer events and error codes are logged for your reference. The number in the Page Count column specifies the total number of pages that the printer had printed when the error occurred. The Event log also contains a brief description of the error.

Alerts

The HP ToolboxFX **Alerts** folder contains links to the following main pages:

- **Set up Status Alerts.** Set up HP ToolboxFX to send you pop-up alerts for certain events, such as low toner levels.
- **Set up E-mail Alerts.** Set up HP ToolboxFX to send you e-mail alert messages for certain events, such as low toner levels.

Set up status alerts

HP ToolboxFX can open pop-up alerts on your computer when certain events occur. Events that trigger alerts include jams, low levels of toner in HP print cartridges, non-HP print cartridge in use, empty input trays, and error messages.

Alerts only appear when the printer is printing from the computer on which you set up the alerts.



NOTE You must click **Apply** to save your changes.

Set up e-mail alerts

Use HP ToolboxFX to configure up to two e-mail addresses to receive alerts when certain events occur. You can specify different events for each e-mail address. Enter the information for the e-mail server that will send out the e-mail alert messages for the printer.



NOTE You must click **Apply** to save your changes.

Help

The HP ToolboxFX **Help** folder contains links to the following main pages:

- **Troubleshooting.** Print troubleshooting pages and clean the printer.
- **How Do I?** View the How Do I? Help for help with specific tasks.
- **Animated demonstrations**
- **User Guide.** View information about the printer usage, warranty, specifications, and support. The user guide is available in both HTML and PDF formats.
- **Readme.** View important information about the printer that is not available in the user guide.

Device settings

The HP ToolboxFX **Device Settings** folder contains links to the following main pages:

- **Device Information.** View information about the printer, such as the printer description and a contact person.
- **Paper Handling.** Change the printer paper-handling settings, such as default paper size and default paper type.
- **Print Quality.** Change the printer print-quality settings.
- **Paper Types.** Change the printer mode settings for a each media type, such as letterhead, prepunched, or glossy paper.
- **System Setup.** Change the printer system settings, such as printer language and jam recovery.
- **Service.** Gain access to various procedures required to maintain the printer.

Device information

The information that you type in these fields appears on the Configuration page.



NOTE You must click **Apply** to save your changes.

Paper handling

Use the HP ToolboxFX paper-handling options to configure your default settings.

Three options are available for handling print jobs when the product is out of media:

- Select **Wait For Paper To Be Loaded**.
- Select **Cancel** from the **Paper out action** drop-down list to cancel the print job.
- Select **Override** from the **Paper out time** drop-down list to send the print job to another paper tray.

The **Paper out time** field specifies how long the printer waits before acting on your selections. You can specify from 0 to 3600 seconds.



NOTE You must click **Apply** to save your changes.

Print quality

Use the HP ToolboxFX print-quality options to improve the appearance of your print jobs.

- **Resolution.** Select 600 resolution for quality print jobs and Fast Res 1200 for higher-quality print jobs. Select ProRes 1200 for the highest-quality print job (printing time increases).
- **REt.** Activate REt to improve print quality.
- **Print density.** For increased print density, select a higher number. For decreased print density, select a lower number.
- **EconoMode.** EconoMode is a feature that allows the printer to use less toner per page. Selecting this option may extend the life of the print cartridge and reduce cost per page. However, it will also reduce print quality. The printed image is lighter, but it is adequate for printing drafts or proofs. HP does not recommend full-time use of EconoMode. If EconoMode is used full-time, it is possible that the toner supply will outlast the mechanical parts in the toner cartridge. If print quality begins to degrade under these circumstances, you will need to install a new toner cartridge, even if there is toner supply remaining in the cartridge.



NOTE You must click **Apply** to save your changes.

Paper types

Use these HP ToolboxFX **Paper Types** options to configure print modes that correspond to the various media types. When you select **Restore Modes**, all of the modes are reset to the factory settings.



NOTE You must click **Apply** to save your changes.

System setup

Use the HP ToolboxFX system settings options to configure miscellaneous print settings.



NOTE You must click **Apply** to save your changes.

Service

During the printing process, paper, toner, and dust particles can accumulate inside the printer. Over time, this buildup can cause print-quality problems such as toner specks or smearing. HP ToolboxFX provides an easy method for cleaning the paper path.

Print settings

The HP ToolboxFX Print Settings tab contains links to the following main pages:

- **Printing.** Change the default print settings, such as number of copies and paper orientation.
- **PCL 5e.** View and change the PCL 5e settings.
- **PCL 6.** View and change the PCL 6 settings.
- **Postscript.** View and change the HP postscript level 3 emulation settings.

Printing

Use the HP ToolboxFX printing settings options to configure the settings for all print functions.



NOTE You must click **Apply** to save your changes.

PCL 5e

Use the PCL 5e options to configure the settings when you are using the PCL 5e print personality.



NOTE Initial font support for PCL 5e is limited to the following fonts: Courier, Letter Gothic, Naskh, Koufi, and Lina Printer. Additional fonts can be used if you install a font DIMM.

NOTE You must click **Apply** to save your changes.

PCL 6

Use the PCL 6 printer driver to take full advantage of all printer features. Unless complete backward compatibility with previous PCL drivers or older printers is necessary, the PCL 6 driver is recommended.



NOTE You must click **Apply** to save your changes.

PostScript®

Use the PostScript option when you are using the HP postscript level 3 emulation print personality. When the **Print PostScript Errors** option is turned on, the HP postscript level 3 emulation error page automatically prints when HP postscript level 3 emulation errors occur.



NOTE You must click **Apply** to save your changes.

Network settings

The network administrator can use the HP ToolboxFX **Network Settings** folder to control the network-related settings for the printer when it is connected to a TCP/IP-based network.

The following options are available:

- **IP Configuration**
- **Advanced**
- **SNMP**
- **Network Summary**

Embedded Web server

The embedded Web server allows you to view printer and network status and to manage printing functions from your computer instead of from the printer control panel. Below are examples of what you can do using the embedded Web server:

- View printer status information
- View and print internal pages
- Determine the remaining life on all supplies and order new ones
- Set the size and type of media loaded in each tray
- View and change tray configurations
- View and change the printer default configuration settings
- View and change network configuration

The embedded Web server provides the same functions as the Advanced Printer Settings section of the HP ToolboxFX. The main differences between using the embedded Web server and using the HP ToolboxFX are the following:

- You do not need to install any software on the computer. You only need to use one of these supported Web browsers:
 - Internet Explorer 6.0 (and later)
 - Netscape Navigator 7.0 (and later)
 - Firefox 1.0 (and later)
 - Mozilla 1.6 (and later)
 - Opera 7.0 (and later)
 - Safari 1.2 (and later)
 - Konqueror 3.2 (and later)
- The embedded Web server is available in sixteen languages.
- The embedded Web server does not provide e-mail or status alerts.

The embedded Web server works when the printer is connected to an TCP/IP-based network. The embedded Web server does not support IPX-based printer connections.



NOTE You do not have to have Internet access to open and use the embedded Web server. However, if you click a link on any of the pages, you must have Internet access in order to go to the site associated with the link.

Open the embedded Web server

To open the embedded Web server, type the IP address or hostname of the printer in the address field of a supported Web browser. To find the IP address, print a Configuration page at the printer by pressing and holding the **Go** button.



Tip After you open the URL, bookmark it so that you can return to it quickly in the future.

The embedded Web server has three tabs that contain settings and information about the printer: the **Status** tab, the **Settings** tab, and the **Networking** tab.

Status tab

The Status pages group consists of the following pages.

- **Device Status.** This page displays the status of the printer and HP supplies.
- **Device Configuration.** This page shows the information found on the printer Configuration page.
- **Supplies Status.** This page shows the status of HP supplies and provides supplies part numbers. To order new supplies, click **Order Supplies** in the upper-right part of the window.
- **Event log.** This page shows a list of all printer events and errors.
- **Print Info Pages.** This page has links that allow you to print the various information pages that reside within the memory of the printer.
- **Network Summary.** This page shows the information found on the printer Network Summary page.

Settings tab

This tab allows you to configure the printer from your computer. If this printer is networked, always consult with the printer administrator before changing settings on this tab.

The **Settings** tab contains the following pages:

- **Device Information.** View and change basic information about the printer.
- **Paper Handling.** View and change the settings for the printer's input tray.
- **Printing.** View and change the default printer job settings.
- **PCL 5e.** View and change the PCL font information.



NOTE Initial font support for PCL 5e is limited to the following fonts: Courier, Letter Gothic, Naskh, Koufi, and Lina Printer. Additional fonts can be used if you install a font DIMM.

- **Postscript.** View and change the settings for HP postscript level 3 emulation errors.
- **Print Quality.** View and change the print-quality settings.
- **Paper Types.** View and change the print modes for various media types.
- **System Setup.** View and change system information.
- **Service.** Initiate the cleaning mode.

Networking tab

This tab allows the network administrator to control network-related settings for the printer when it is connected to an IP-based network.

Links

Links are located in the upper-right part of the Status pages. You must have Internet access in order to use any of these links. If you use a dial-up connection and did not connect when you first opened the embedded Web server, you must connect before you can visit these Web sites. Connecting might require that you close the embedded Web server and reopen it.


- **Order Supplies.** Click this link to connect to the Sure Supply Web site and order genuine HP supplies from HP or a reseller of your choice.
- **Product Support.** Connects to the support site for the HP LaserJet P2015 Series printer. You can search for help regarding general topics.

4 Maintenance

- [Replace the print cartridge](#)
- [Redistribute toner](#)
- [Clean the printer](#)
- [Clean the pickup roller \(tray 1\)](#)
- [Replace the pickup roller \(tray 1\)](#)
- [Clean the pickup roller \(tray 2\)](#)
- [Replace the pickup roller \(tray 2\)](#)

Replace the print cartridge


1. Press the print-cartridge-door button, and then remove the print cartridge from the printer. For recycling information, see the inside of the print-cartridge box.




CAUTION To prevent damage, do not expose the print cartridge to light. Cover it with a piece of paper.

CAUTION After removing the print cartridge, only handle it on the ends.


2. Remove the new print cartridge from the packaging.
3. Bend the tab on the left side of the cartridge to break it loose.




4. Pull the tab until all the tape is removed from the cartridge. Put the tab in the print-cartridge box to return for recycling.



5. Gently rock the toner cartridge from front to back to distribute the toner evenly inside the cartridge.



6. Insert the print cartridge in the printer and close the print-cartridge door.




CAUTION If toner gets on your clothing, wipe it off with a dry cloth and wash the clothing in cold water. *Hot water sets toner into the fabric.*

Redistribute toner

When toner is low, faded or light areas appear on the printed page. You might be able to temporarily improve print quality by redistributing the toner.


1. Open the print-cartridge-door button, and then remove the print cartridge from the printer.



CAUTION To prevent damage, do not expose the print cartridge to light. Cover it with a sheet of paper.


CAUTION After removing the print cartridge, only handle it on the ends.

2. To redistribute the toner, gently rock the print cartridge from front to back.



CAUTION If toner gets on your clothing, wipe it off with a dry cloth and wash the clothing in cold water. *Hot water sets toner into the fabric.*

3. Reinsert the print cartridge into the printer, and close the print cartridge door.



If the print is still light, install a new print cartridge.

Clean the printer

Clean the outside of the printer with a clean, damp cloth when necessary.



CAUTION Do not use ammonia-based cleaners on or around the printer.

During the printing process, paper, toner, and dust particles can accumulate inside the printer. Over time, this buildup can cause print quality problems, such as toner specks or smearing, and paper jams. To correct and prevent these types of problems, you can clean the print cartridge area and the printer media path.


Clean the print-cartridge area

You do not need to clean the print-cartridge area often. However, cleaning this area can improve the quality of your printed sheets.



WARNING! Before cleaning the printer, turn the printer off by unplugging the power cord, and wait for the printer to cool.

1. Press the print-cartridge-door button, and then remove the print cartridge from the printer.




CAUTION Do not touch the black sponge-transfer roller inside the printer. Doing so can damage the printer.


CAUTION To prevent damage, do not expose the print cartridge to light. Cover it with a piece of paper.

CAUTION After removing the print cartridge, only handle it on the ends.


2. With a dry, lint-free cloth, wipe any residue from the media-path area and the print-cartridge cavity.



3. Replace the print cartridge, and close the print-cartridge door.




4. Plug the power cord into the printer.



Clean the printer media path

If you are seeing toner specks or dots on the printouts, clean the printer media path. This process uses a transparency to remove dust and toner from the media path. Do not use bond or rough paper.



NOTE For best results use a sheet of transparency. If you do not have any transparencies, you can use copier-grade media (70 to 90 g/m² (18 to 24 lb.)) with a smooth surface.


1. Make sure that the printer is idle and the Ready light is on.
2. Load the transparency in tray 1.
3. Print a cleaning page using one of the following methods:
 - Open HP ToolboxFX. Click the **Troubleshooting** tab, and then click **Print Quality Tools**. Select the cleaning page.
 - On the printer control panel, press and hold the **Go** button until the **Attention**, **Ready**, and **Go** lights come on. When all three lights come on, release the **Go** button.
 - Press **Go** again. The printer picks up the transparency and begins the cleaning process.




NOTE The cleaning process takes approximately 2 minutes. The cleaning page will stop periodically during the cleaning process. Do not turn the printer off until the cleaning process has finished. You might need to repeat the cleaning process several times to thoroughly clean the printer.

Clean the pickup roller (tray 1)

1. Unplug the power cord from the printer, and allow the printer to cool.



2. Press the print-cartridge-door button to open the print-cartridge door.



3. Remove the print cartridge.





CAUTION After removing the print cartridge, only handle it on the ends.


4. Grasping the pickup-roller cover with thumb and forefinger, squeeze the left side of the pickup-roller cover to release the left retaining tab, and then slide the cover to the left and up.



CAUTION Failure to slide the cover to the left when removing it can cause the right retaining tab to break.




5. Press the two black retaining tabs outward until the pickup roller is released from its seat.




6. Remove the pickup roller from the printer.




CAUTION Do not touch the pickup-roller pad.




7. Dab a lint-free cloth in water, and scrub the roller.




8. Using a dry, lint-free cloth, wipe the pickup roller to remove loosened dirt.




9. Allow the pickup roller to dry completely.




10. Line up the black retaining tabs in the printer with the grooves in the pickup roller, and then press the pickup roller into the pickup-roller seat until the retaining tabs click.



11. Grasping the pickup-roller cover with thumb and forefinger, insert the pickup-roller cover's right retaining tab into the retaining slot.




- 12.** Squeeze the left side of the pickup-roller cover and insert the left retaining tab in the retaining slot.




- 13.** Close the print-cartridge door.
- 14.** Plug the printer in.

Replace the pickup roller (tray 1)

1. Unplug the power cord from the printer, and allow the printer to cool.



2. Press the print-cartridge-door button to open the print-cartridge door.



3. Remove the print cartridge.





CAUTION After removing the print cartridge, only handle it on the ends.


4. Grasping the pickup-roller cover with thumb and forefinger, squeeze the left side of the pickup-roller cover to release the left retaining tab, and then slide the cover to the left and up.




CAUTION Failure to slide the cover to the left when removing it can cause the right retaining tab to break.



5. Press the two black retaining tabs outward until the pickup roller is released from its seat.




6. Remove the old pickup roller from the printer.




7. Line up the black retaining tabs in the printer with the grooves in the new pickup roller, and then press the pickup roller into the pickup-roller seat until the retaining tabs click.




CAUTION Do not touch the pickup-roller pad.



8. Grasping the pickup-roller cover with thumb and forefinger, insert the pickup-roller cover's right retaining tab into the retaining slot.



9. Squeeze the left side of the pickup-roller cover and insert the left retaining tab in the retaining slot.




10. Close the print-cartridge door.

11. Plug the printer in.

Clean the pickup roller (tray 2)


1. Unplug the power cord from the printer, and allow the printer to cool.




2. Press the print-cartridge-door button, and then remove the print cartridge from the printer.




CAUTION After removing the print cartridge, only handle it on the ends.




3. Remove tray 2.




4. Open the automatic two-sided path door on the front of the printer (HP LaserJet P2015d, HP LaserJet P2015dn, and HP LaserJet P2015x printers only).




5. Place the printer on the work surface with the front of the printer facing up.




6. Pull the white tabs outward, and rotate the tabs up.



7. Slide the right tab to the right, and leave the tab in this position throughout the procedure.




8. Slide the pickup roller assembly to the right, and remove the left end cap.




9. Remove the pickup roller.




CAUTION Do not touch the pickup-roller pad.




- 10.** Dab a lint-free cloth in water, and scrub the roller.




- 11.** Using a dry, lint-free cloth, wipe the pickup roller to remove loosened dirt.




- 12.** Allow the pickup roller to dry completely.




- 13.** Insert the left side of the pickup roller into the left slot (1), and insert the right side (the side that has the notches in the shaft) into the right slot (2).




14. Place the end cap over the shaft on the left side, push the end cap to the right, and rotate the tab downward into position.




15. Rotate the shaft until the notches engage and the shaft clicks into place.
16. Push the right tab to the left, and rotate the tab downward into position.
17. Place the printer on the work surface with the top of the printer facing up.
18. Close the automatic two-sided path door.



19. Reinstall the print cartridge, and close the print-cartridge door.




20. Plug the printer in.



Replace the pickup roller (tray 2)


1. Unplug the power cord from the printer, and allow the printer to cool.




2. Press the print-cartridge-door button, and then remove the print cartridge from the printer.




CAUTION After removing the print cartridge, only handle it on the ends.




3. Remove tray 2.




4. Open the automatic two-sided path door on the front of the printer (HP LaserJet P2015d, HP LaserJet P2015dn, and HP LaserJet P2015x printers only).




5. Place the printer on the work surface with the front of the printer facing up.




6. Pull the white tabs outward, and rotate the tabs up.



7. Slide the right tab to the right, and leave the tab in this position throughout the procedure.




8. Slide the pickup roller assembly to the right, and remove the left end cap.




9. Remove the old pickup roller.




CAUTION Do not touch the pickup-roller pad.



- 10.** Insert the left side of the new pickup roller into the left slot (1), and insert the right side (the side that has the notches in the shaft) into the right slot (2).




- 11.** Place the end cap over the shaft on the left side, push the end cap to the right, and rotate the tab downward into position.




- 12.** Rotate the shaft until the notches engage and the shaft clicks into place.
- 13.** Push the right tab to the left, and rotate the tab downward into position.
- 14.** Place the printer on the work surface with the top of the printer facing up.


15. Close the automatic two-sided path door.



16. Reinstall the print cartridge, and close the print-cartridge door.



17. Plug the printer in to turn it back on.



5 Theory of operation

- [Introduction](#)
- [Internal components](#)
- [Timing](#)
- [Engine control system](#)
- [Laser/scanner system](#)
- [Pickup/feed/delivery system](#)
- [Image-formation system](#)

Introduction

This chapter presents an overview of the relationships between major components in the printer, and includes a detailed discussion of the image-formation system. The following systems are discussed:

- Engine control system
- Laser/scanner system
- Pickup/feed/delivery system
- Image-formation system

Figure 5-1 Block diagram on page 70 illustrates the relationships among the four systems.




Figure 5-1 Block diagram

Internal components

Figure 5-2 Cross-section of printer on page 71 highlights the major internal components.




Figure 5-2 Cross-section of printer

1	Top output bin delivery roller
2	Fuser film
3	Laser/scanner
4	Primary charging roller
5	Developer roller
6	Print cartridge
7	Feed roller
8	Multipurpose pickup roller
9	Multipurpose separation pad
10	Separation pad

11	Pickup roller
12	Registration roller
13	Duplexer pickup roller
14	Registration shutter
15	Transfer roller
16	Photosensitive drum
17	Duplexer feed roller
18	Pressure roller
19	Rear output bin delivery roller

Timing

Sequence of operation

Operation sequences are controlled by the microprocessor on the DC controller. [Table 5-1 Sequence of operation on page 73](#) describes engine operations for each period of a print operation.

Table 5-1 Sequence of operation

Name	Timing	Purpose
WAIT	From power-on until the end of the main motor initial drive	Detects presence of a print cartridge. Clears potential from the drum surface and cleans the transfer roller.
STBY (standby)	From the end of the WAIT or LSTR period until either a print command is sent from the formatter or the power is turned off.	Prepares the printer to receive print commands
INTR (initial rotation)	From the time of the print command until the pickup solenoid is turned on.	Prepares the photosensitive drum for printing.
PRINT	From the end of the INTR period until the primary high-voltage is turned off.	Forms the image on the photosensitive drum and transfers the toner image to the media.
LSTR (last rotation)	From the end of the PRINT period (when high-voltage is turned off) until the main motor stops rotating.	Delivers the last page of a print job. After LSTR, the printer either returns to STBY or, if another print command was sent from the formatter, enters INTR.

Power-on sequence

Table 5-2 Power-on sequence

Step	Action
1	Power-on
2	CPU initialization
3	Video interface communication start
4	Check sensors for residual media
5	Main motor initial drive
6	Fuser heater initial drive. The fuser heater reaches a surface temperature of 100°C.
7	Laser/scanner motor initial drive
8	High-voltage control Detect presence of a print cartridge Clean the transfer roller after the primary charging ac bias is turned on
9	Failure/abnormality check: detect laser/scanner failure, fuser failure, and open covers
10	Communication with the memory tag

Engine control system

The engine control system coordinates all printer functions, according to commands sent from the formatter. It drives the laser/scanner system, the image-formation system, and the pickup/feed/delivery system.

The engine control system contains the following components:

- DC controller
- High-voltage PCA




Figure 5-3 Engine control system




Figure 5-4 Engine control system circuit diagram

Laser/scanner system

The laser/scanner system receives video signals from the dc controller and the formatter and converts the signals into latent images on the photosensitive drum.




Figure 5-5 Laser/scanner system

Pickup/feed/delivery system

The pickup/feed/delivery system consists of several types of feed rollers and sensors. The dc controller uses two motors and two solenoids to drive the rollers. Three media-detection sensors detect media as it passes through the printer. If media does not reach or pass each sensor within a specified time period, the dc controller determines that a jam has occurred and alerts the formatter.

The following components are identified in [Figure 5-6 Pickup/feed/delivery system on page 78](#):

- M1, main motor
- SL1, tray 2 pickup solenoid
- SL2, tray 1 pickup solenoid
- SL3, duplex solenoid (HP LJ P2015d, P2015dn, and P2015x only)
- PS911, width-detection sensor
- PS912, top-of-page sensor
- PS913, width-detection sensor
- PS914, tray 2 media sensor
- PS915, fuser delivery sensor
- PS915, duplex sensor (HP LJ P2015d, P2015dn, and P2015x only)




Figure 5-6 Pickup/feed/delivery system

Image-formation system

Laser printing requires the interaction of several different technologies, including electronics, optics, and electrophotographics, to provide a printed page. Each process functions independently and must be coordinated with the other printer processes. Image formation consists of the following five processes:

- electrostatic latent-image formation
- developing
- transfer
- fusing
- drum cleaning

The five processes contain eight steps.




Figure 5-7 Image-formation system

Step 1: Primary charging

DC and AC biases are applied to the primary charging roller, which transfers a uniform negative potential to the photosensitive drum.




Figure 5-8 Primary charging

Step 2: Laser beam exposure

The laser beam scans the photosensitive drum to neutralize negative charges on parts of the drum. An electrostatic latent image is formed on the drum where negative charges were neutralized.

Step 3: Developing

The developing cylinder comes in contact with the photosensitive drum to deposit toner onto the electrostatic latent image.



NOTE The charges on the exposed area of the drum are shown as positive in [Figure 5-9 Developing on page 80](#). The charges are actually negative, but they are more positive than the charges on the developing cylinder.




Figure 5-9 Developing

Toner acquires a negative charge through friction from the developing cylinder and the blade. When the negatively charged toner comes in contact with the drum, the toner adheres to the electrostatic latent image. The image on the drum becomes visible because of the toner.

Step 4: Transfer

The transfer charging roller, to which a dc positive bias is applied, imparts a positive charge on the print media. When the print media comes in contact with the photosensitive drum, the toner is transferred to the print media.




Figure 5-10 Transfer

Step 5: Separation

The elasticity of the print media causes its separation from the photosensitive drum. A static charge eliminator aids separation by weakening any electrostatic adhesion.




Figure 5-11 Separation

Step 6: Fusing

The dc negative bias applied to the fusing film strengthens the holding force of the toner on the print media and prevents the toner from scattering.




Figure 5-12 Fusing

Step 7: Drum cleaning

The cleaning blade scrapes the residual toner off the photosensitive drum and deposits it into the waste toner case.




Figure 5-13 Drum cleaning

6 Removal and replacement

- [Introduction](#)
- [Before performing service](#)
- [Covers](#)
- [Control panel](#)
- [Formatter](#)
- [Laser/scanner](#)
- [Memory-tag-reader assembly](#)
- [Duplex-drive PCA \(HP LaserJet P2015d, P2015dn, and P2015x printers only\)](#)
- [Fuser](#)
- [Interlock assembly](#)
- [ECU](#)
- [Main motor](#)
- [Pickup and feed assemblies](#)
- [Main gear assembly/tray 2 pickup solenoid](#)
- [Print-cartridge door](#)

Introduction

This chapter documents removal and replacement of field replaceable units (FRUs) only.

Removal and replacement strategy

Replace parts in the reverse order of their removal. Directions for difficult or critical replacement procedures are included.



WARNING! The sheet-metal edges of the product can be sharp. Use caution when working on the product.



NOTE Note the length, diameter, color, type, and location of each screw. Be sure to return each screw to its original location during reassembly.

Incorrectly routed or loose wire harnesses can interfere with other internal components and can become damaged or broken. Frayed or pinched harness wires can be difficult to locate. When replacing wire harnesses, always use the provided wire loops, lance points, or wire-harness guides.

Electrostatic discharge



CAUTION The product contains parts that are sensitive to electrostatic discharge (ESD). Always service the product at an ESD-protected workstation, or use an ESD mat.

Watch for the ESD symbol to identify the parts that are sensitive to ESD. Protect these parts by using an ESD wrist strap and by placing ESD-sensitive parts into protective ESD pouches.



Required tools

The following tools are needed to service this product:

- #2 Phillips screwdriver with magnetic tip
- Small flat-blade screwdriver
- Small needle-nose pliers
- ESD mat
- Penlight



CAUTION A pozidrive screwdriver can damage the screw heads on the product. Use a #2 Phillips screwdriver.

If you use a multispeed screwdriver, use a torque limiter.

Before performing service


Follow the pre-service procedures before you perform service.

Pre-service procedures

1. Remove all media from the product.
2. Place the product on an ESD mat. If an ESD mat or an ESD-protected workstation is not available, discharge body static and ground the product chassis before servicing the product.
3. Remove the print cartridge.
4. Unplug the power cord and the interface cable.
5. Lift the printer off optional tray 3 (if tray 3 is installed).

Parts removal order

Use the following diagram to determine which parts must be removed before removing other parts.



Covers

Left-side cover

1. Open the print-cartridge door.
2. At the back of the printer, use a flat-blade screwdriver to release two tabs (1).




Figure 6-1 Removing the left-side cover (1 of 2)

3. Lift the cover away from the printer.

Right-side cover

1. Open the print-cartridge door.
2. Remove tray 2.

3. At the front of the printer, pop the front edge of the right-side cover over the two retaining tabs.



Figure 6-2 Removing the right-side cover

4. Lift the cover away from the printer.

Back cover

1. Remove tray 2.
2. Remove the left-side cover and the right-side cover.

3. Remove four screws (1).




Figure 6-3 Removing the back cover (1 of 2)

4. Tip the printer so that it rests on its front.
5. Release the tab (2) at the back of the printer on the right side.
6. Open the duplex access door (3).

7. Slide the cover toward the right side of the printer to clear the tab (1) on the duplexer tray (duplex models only).




Figure 6-4 Removing the back cover (2 of 2)

8. Lift the cover straight up and away from the printer.

Duplexer tray (HP LaserJet P2015d, P2015dn, and P2015x printers only)

1. Remove the left-side cover, the right-side cover, and the back cover.

2. Pull the duplexer tray release-tab (1) to release the duplexer tray magnets.




Figure 6-5 Removing the duplexer tray

3. Pull out the duplexer tray.

Top cover

1. Remove the left-side cover, the right-side cover, the back cover, and the duplexer tray.

2. Remove two screws (1) at the back of the printer.




Figure 6-6 Removing the top cover (1 of 4)

3. Remove one screw (1) on the left side of the printer, and remove one screw (2) on the right side of the printer.




Figure 6-7 Removing the top cover (2 of 4)

4. Release the control-panel cable (1) on the left side of the printer.




Figure 6-8 Removing the top cover (3 of 4)

5. Lift the top cover off the printer.




Figure 6-9 Removing the top cover (4 of 4)

Control panel

1. Remove all covers.
2. On the bottom of the top cover, remove two screws (1).




Figure 6-10 Removing the control panel (1 of 2)

3. Remove the control-panel wires from the wire guides.




Figure 6-11 Removing the control panel (2 of 2)

Formatter



1. Remove the left-side cover.
2. Disconnect one cable (1) at the top of the formatter.
3. Disconnect one flat, flexible cable (2) at the top of the formatter.



CAUTION Do not fold flat, flexible cables. Also, do not straighten pre-folds in flat, flexible cables.

4. Disconnect one flat, flexible cable (3) at the bottom of the formatter.
5. Disconnect one cable (4) at the bottom of the formatter.
6. Remove four screws (5).




Figure 6-12 Removing the formatter

7. Remove the formatter.

Laser/scanner

1. Remove all covers.
2. Disconnect one flat, flexible cable (1) from the laser/scanner PCA.
3. Disconnect one cable (2) from the top of the laser/scanner.
4. Unthread all cables (3) from the laser/scanner cable guides.



NOTE Examine the cable routing as you unthread the cables.

5. Remove four screws (4).




Figure 6-13 Removing the laser/scanner

6. Lift the laser/scanner out of the printer.



NOTE Examine the shutter switch as you lift the laser/scanner out of the printer.

Memory-tag-reader assembly

1. Remove all covers.
2. Remove the fan from the printer chassis.
3. Remove one cable (1) from the top of the memory-tag-reader cover.
4. Disconnect one cable (2) from the formatter.




Figure 6-14 Removing the memory-tag-reader assembly (1 of 2)

5. Remove one screw (1).




Figure 6-15 Removing the memory-tag-reader assembly (2 of 2)

6. Lift the back of the memory-tag-reader assembly slightly, and then slide the assembly toward the back of the printer to release it from the laser/scanner plate.

Duplex-drive PCA (HP LaserJet P2015d, P2015dn, and P2015x printers only)



1. Remove all covers.
2. Disconnect the duplex-drive cable (1) at the ECU, and then route the cable through the hole in the chassis.




Figure 6-16 Removing the duplex-drive PCA (1 of 2)

3. Disconnect one cable (1) from the duplex-drive PCA.

4. Remove one screw (2), and then lift the duplex-drive PCA off the printer.




Figure 6-17 Removing the duplex-drive PCA (2 of 2)

Fuser

Several parts must be removed before you can remove the fuser. The following parts are included in this section about removing the fuser:

- Fan
- Duplex-drive gears/face-down gears
- Duplex solenoid
- Fuser

Fan

1. Remove all covers.
2. Disconnect the fan cable (1) at the ECU.




Figure 6-18 Removing the fan (1 of 2)

3. Unthread the fan wires from the retaining clips.
4. Remove two screws (1).

5. Unhook the fan clip (2) and then lift the fan off the printer.




Figure 6-19 Removing the fan (2 of 2)

Duplex-drive gears (HP LaserJet P2015d, P2015dn, and P2015x printers only)

1. Remove all covers.
2. Remove the fan.

3. Remove three screws (1).




Figure 6-20 Removing the duplex-drive gears (1 of 2)

4. Lift the assembly away from the printer.




Figure 6-21 Removing the duplex-drive gears (2 of 2)



NOTE The gears are not attached to the gear plate. Carefully remove the gear plate and the gears together to prevent them from falling out of the assembly.

Duplex solenoid (HP LaserJet P2015d, P2015dn, and P2015x printers only)

1. Remove all covers.
2. Remove the fan.
3. Remove the duplex-drive gears.
4. Disconnect one cable (1) at the duplex-drive PCA.

5. Remove one screw (2), and then lift the solenoid off the printer chassis.




Figure 6-22 Removing the duplex solenoid

Fuser

1. Remove all covers.
2. Remove the fan.
3. Remove the duplex-drive gears or face-down gears.
4. Remove the formatter.
5. On the right side of the printer, press the tabs on two gears (1) to release the gears, and then slide the gears off the shafts.

6. Disconnect one cable (2) on the right side of the printer.




Figure 6-23 Removing the fuser (1 of 10)

7. Disconnect four cables (1) from the ECU, and then disconnect two more cables (2) that were behind the first set.




Figure 6-24 Removing the fuser (2 of 10)

8. Pull the tab on the cable holder (1) at the left side of the printer and slide it toward the center to release it from the frame, and then unroute the cables.

9. Pull the tab on the cable holder (2) and slide it toward the center to release it from the frame, and then unroute the cables.




Figure 6-25 Removing the fuser (3 of 10)

10. Remove one screw (1) from the fuser cover, and then slide the fuser cover to the right and remove it.




Figure 6-26 Removing the fuser (4 of 10)

11. Disconnect three cables (1).




Figure 6-27 Removing the fuser (5 of 10)

12. Disconnect one cable (1), and then unroute the cable from the cable guide.




Figure 6-28 Removing the fuser (6 of 10)



NOTE Before you proceed to step 13, make sure that all cables disconnected in previous steps are free from any cable guides and cable holders.

13. Remove three screws (1) on the right side of the printer.




Figure 6-29 Removing the fuser (7 of 10)

14. Remove three screws (1) from the left side of the printer.




Figure 6-30 Removing the fuser (8 of 10)

15. At the left side of the printer, pull the printer chassis from the top to spread the printer frame and release the fuser from the frame.




Figure 6-31 Removing the fuser (9 of 10)

16. Pull the fuser out of the printer at an angle so that the delivery roller shaft clears the hole (1) in the chassis.




Figure 6-32 Removing the fuser (10 of 10)

Interlock assembly

1. Remove all covers.
2. Open the print-cartridge door.
3. Remove two screws (1) that secure the interlock assembly to the left side of the printer chassis.
4. Remove two cables (2).




Figure 6-33 Removing the interlock assembly (1 of 2)

5. Lift the interlock assembly away from the printer.

ECU



1. Remove all covers.
2. Remove the fan.
3. Remove the duplex-drive gears.
4. Remove the formatter.
5. Remove the fuser.
6. Remove the interlock assembly.
7. Remove cables from the cable clip under the feed plate (1), and then remove the feed plate by lifting it and pulling it straight back.




Figure 6-34 Removing the ECU (1 of 7)

8. Disconnect three cables (1).




Figure 6-35 Removing the ECU (2 of 7)

9. Remove one screw (4) from the right side of the printer.




Figure 6-36 Removing the ECU (3 of 7)

10. Remove two screws (1) from the left side of the printer, and then push the interlock cables and the formatter cable (2) through the hole in the chassis.




Figure 6-37 Removing the ECU (4 of 7)

11. Spread the printer frame at the right side of the printer to release the internal tabs that secure the ECU to the chassis.




Figure 6-38 Removing the ECU (5 of 7)

12. Spread the printer frame at the left side of the printer to release the internal tabs, and then lower the ECU slightly and pull it straight back to remove it.



NOTE Make sure that cables do not become caught on the contact springs as you remove the ECU.




Figure 6-39 Removing the ECU (6 of 7)



Reinstallation tip When replacing the ECU, you might find it easier to find the correct placement of the ECU pan in the printer if you tip the printer so that it rests on its front.

13. Remove four screws (1) and then lift the ECU off the ECU plate.




Figure 6-40 Removing the ECU (7 of 7)

Main motor

1. Remove all covers.
2. Remove the fan.
3. Remove the duplex-drive gears.
4. Remove the formatter.
5. Remove the fuser.
6. Remove the interlock assembly.
7. Remove the ECU.
8. Remove three screws (1).




Figure 6-41 Removing the main motor (1 of 2)

9. Hold the motor while releasing the tabs (1) on the cable guide, and then lift the motor and the cable guide out of the printer together.




Figure 6-42 Removing the main motor (2 of 2)

Pickup and feed assemblies

This section covers the major assemblies of the pickup and feed system: the transfer roller and the registration assembly.

Transfer roller



NOTE It is important to make sure that the transfer roller needs to be replaced before removing it. Excess handling can cause additional damage.

1. Open the print-cartridge door and remove the print cartridge.
2. Use needle-nose pliers to release the transfer roller tabs at the end of the roller, near the right side of the printer.



CAUTION Do not break the tabs, and do not touch the rollers.




Figure 6-43 Removing the transfer roller

3. Lift up the end of the roller near the right side of the printer, and then slide it toward the right side of the printer while pulling it out of the printer.

Registration assembly

1. Remove five screws (1).




Figure 6-44 Removing the registration assembly

2. Lift the entire assembly out of the printer.

Main gear assembly/tray 2 pickup solenoid

1. Remove all covers.
2. Remove the fan from the printer chassis.
3. Disconnect one cable (1) at the ECU.




Figure 6-45 Removing the main gear assembly (1 of 2)

4. Remove the duplex-drive PCA from the printer chassis.
5. Release the tab on the gear (1) and slide the gear off the shaft.
6. Remove the cables from the cable guide (2).

7. Remove four screws (3).




Figure 6-46 Removing the main gear assembly (2 of 2)

8. Pull the main gear assembly straight away from the printer.

9. To remove the tray 2 pickup solenoid, disconnect one cable (1).




Figure 6-47 Removing the tray 2 pickup solenoid (1 of 2)

10. Remove one screw (1), and then lift the solenoid off the printer.




Figure 6-48 Removing the tray 2 pickup solenoid (2 of 2)

Print-cartridge door

1. Use a flat-blade screwdriver to gently pry the cartridge-door arm (1) off the print-cartridge door.



CAUTION Be careful not to break the tabs.




Figure 6-49 Removing the print-cartridge door (1 of 2)

2. Remove two screws (2).




Figure 6-50 Removing the print-cartridge door (2 of 2)

3. Lift the cartridge-door assembly straight away from the printer.

7 Problem solving

- [Basic problem solving](#)
- [Status-light patterns](#)
- [Fatal error secondary messages](#)
- [Accessory error secondary messages](#)
- [Media problemsolving](#)
- [Printed page is different from what appeared on screen](#)
- [Image problem solving](#)
- [Clear jams](#)
- [Diagnostic resources](#)
- [Network-setup problemsolving](#)
- [Reset the printer](#)
- [Troubleshooting tools and reference diagrams](#)

Basic problem solving

Table 7-1 Basic problem solving

When the product is connected to a correctly grounded power source, the LEDs on the control panel do not illuminate and the main motor does not rotate.

The printer does not turn on.

Cause	Solution
No power to the printer.	<ol style="list-style-type: none">1. Verify that the power switch is turned on.2. Verify that the power cable is correctly plugged into the outlet and the printer.3. Verify that the power outlet has the correct voltage.
The power inlet/switch cable assembly is defective.	Replace the power inlet/switch cable assembly.
The ECU is defective.	Replace the ECU.

When turned on, the LEDs on the control panel light up, but the main motor does not rotate.

The printer turns on, but the motor does not rotate.

Cause	Solution
The print cartridge door is open.	Close the print cartridge door.
Media is jammed in the paper path.	Clear all media from the paper path and make sure that all sensors are working correctly.
The motor cable is not connected correctly.	Reconnect the motor cable.
The motor is not mounted correctly in the printer chassis.	Verify that the motor is connected correctly and that it rotates freely.
A gear is damaged or jammed.	Replace the gear assembly.
The ECU is defective.	Replace the ECU.
The main motor is defective.	Replace the motor.

The printer turns on and the motor rotates, but none of the control panel lights turn on, and pressing the control panel buttons has no effect.

The printer is unresponsive.

Cause	Solution
The control panel cable is not connected correctly.	Reconnect the control panel cable.
The control panel is defective.	Replace the control panel.
The formatter is defective.	Replace the formatter.

Table 7-1 Basic problem solving (continued)

The printer is on, but the control panel lights indicate that the printer is not in the "ready" state.

The printer is not "ready."

Cause	Solution
The printer has an internal error that was detected during the power-on self-test sequence.	Consult the list of control panel light patterns to identify and correct the error.

The printer turns on, the motor rotates, and the control panel indicates the "ready" state, but the printer does not print.

The printer does not print.

Cause	Solution
A printer component is defective.	Perform an engine test to verify print-engine components. <ol style="list-style-type: none">1. Press the engine test switch to print an engine test.2. If the engine test page does not print, check all of the connectors on the ECU and reconnect any cables that are connected incorrectly.3. If, after checking the connectors, the error persists, replace the ECU.
The formatter is defective.	Press the Go button to print a Demo page. If the Demo page does not print, replace the formatter.

The printer prints the engine test and the Demo page, but does not print jobs sent from a computer.

The printer does not print from a computer.

Cause	Solution
The cable is not connected correctly.	Reconnect the cable.
An incorrect printer driver is selected.	Select the correct printer driver.
The printer driver is not installed correctly.	Uninstall and then reinstall the printer software. Make sure that you use the correct procedure and port setting.
Other devices are connected to the printer (for example, through a switch or hub) that are interfering with the computer-printer communications.	Disconnect the other devices, switches, or hubs.
There is a computer-port communications problem.	Reset the computer port settings (see the computer user guide for more information).
The formatter is defective.	Replace the formatter.

Status-light patterns




Table 7-2 Status-light legend

	Symbol for "light off"
	Symbol for "light on"
	Symbol for "light blinking"

Table 7-3 Control-panel status light patterns

Error code	Pattern	Description	Action
10007		<p>Initialization/Startup</p> <p>While in the Startup state, the Go, Ready, and Attention lights cycle (at the rate of 500 ms) one after another.</p> <p>Reconfiguration Initialization</p> <p>During the printer start up, you can request special initialization sequences that reconfigure the printer. When one of the sequences is requested, such as cold reset, the lights cycle as in the Initialization/Startup state.</p> <p>Job Cancel</p> <p>After the cancellation process has been completed, the printer returns to the Ready state.</p>	<p>During the Initialization, Reconfiguration, and Job Cancel processes, pressing buttons has no effect.</p>

Table 7-3 Control-panel status light patterns (continued)



Error code	Pattern	Description	Action
10001		Ready The printer is ready with no job activity.	To print a Configuration page, press and hold the Go button for 5 seconds. To print a Demo page, press and release the Go button.
10023		Processing Data The printer is processing or receiving data.	To cancel the current job, press the Cancel button.

Table 7-3 Control-panel status light patterns (continued)



Error code	Pattern	Description	Action
41000		<p>Manual Feed or Continuable Error</p> <p>This state can be reached in the following circumstances:</p> <ul style="list-style-type: none">• Manual feed• General continuable error• Memory configuration error• Personality/Job-related error	<p>To recover from the error and print whatever data is possible, press the Go button.</p> <p>If the recovery is successful, the printer goes to the Processing Data state and completes the job.</p> <p>If the recovery is unsuccessful, the printer returns to the Continuable Error state.</p>
40021		<p>Attention</p> <p>The print-cartridge door is open.</p>	<p>Close the print-cartridge door.</p>

Table 7-3 Control-panel status light patterns (continued)



Error code	Pattern	Description	Action
50003 50005 50006 50007 5000X		Fatal Error	<ul style="list-style-type: none">• Turn off the printer, wait 10 seconds, and turn on the printer.• Unplug the printer for five minutes. Then plug it back in and turn the power on.• If you are unable to resolve the problem, contact HP.
		Accessory Error	To display additional error information, press the Go button. The light pattern changes. When you release the Go button, the printer returns to the initial Accessory Error state.

Table 7-3 Control-panel status light patterns (continued)



Error code	Pattern	Description	Action
		Toner Low The Go, Ready, and Attention lights act independently of the Toner Low state.	Order a new print cartridge and have it ready.
		Toner Missing The print cartridge has been removed from the printer.	Reinsert the print cartridge in the printer.

Table 7-3 Control-panel status light patterns (continued)




Error code	Pattern	Description	Action
40022		Jam	Clear the jam.

Table 7-3 Control-panel status light patterns (continued)

Error code	Pattern	Description	Action
41900		Paper Out	Load paper or other media.
		Paper Mount The loaded paper or other media is not supported.	Load acceptable paper or other media. Press the Go button to override the condition.

Fatal error secondary messages

If the printer has a fatal error, press and hold the Go button to see a secondary error message.

Table 7-4 Fatal error secondary messages



Error code	Pattern	Description	Action
79XXX		General fatal error	<ol style="list-style-type: none">1. Turn the printer off, and then turn the printer on again.2. If the error persists, disconnect the I/O cable and print an engine test. If the self-test is successful, reconnect the I/O cable.3. If the error persists, replace the formatter.
55 50007		Engine error. The formatter and engine are not communicating.	<ol style="list-style-type: none">1. Unplug the printer, and then plug it in again.2. Reseat the formatter cable in the ECU.3. If the error persists, replace the formatter.4. If, after replacing the formatter, the error persists, replace the ECU.

Table 7-4 Fatal error secondary messages (continued)






Error code	Pattern	Description	Action
52 50005		Laser/scanner error. The laser/scanner has a malfunction.	<ol style="list-style-type: none">1. Check the laser/scanner cable connections.2. If the error persists, replace the laser/scanner.

Table 7-4 Fatal error secondary messages (continued)

Error code	Pattern	Description	Action
57		Fan motor error	<ol style="list-style-type: none">1. Check the fan cable connections.2. If the error persists, replace the fan.
50XXX		Fuser error. The fuser has a malfunction.	<ol style="list-style-type: none">1. Unplug the printer for at least ten minutes, and then plug it in again.2. Verify that the fuser connector and thermistor connector are both firmly seated in the ECU3. Perform a heating element resistance check.4. If the resistance readings are correct, but the error persists, replace the fuser.

Accessory error secondary messages

Table 7-5 Accessory error secondary messages

Error code	Pattern	Description	Action
		Accessory error	If the printer has an accessory error, press and hold the Go button to see the secondary error message. Release the Go button to return to the initial accessory error state.
53XXXX 79XXX		DIMM slot error	<ol style="list-style-type: none">1. Verify that the DIMM is correctly seated.2. If the error persists, replace the DIMM.

Media problemsolving

The following problems with media cause print-quality deviations, jamming, or damage to the printer.

Problem	Cause	Solution
Poor print quality or toner adhesion	The paper is too moist, too rough, too heavy or too smooth, or it is embossed or from a faulty paper lot.	Try another kind of paper, between 100 and 250 Sheffield, with 4 to 6% moisture content.
Dropouts, jamming, or curl	The paper has been stored incorrectly.	Store paper flat in its moisture-proof wrapping.
	The paper has variability from one side to the other.	Turn the paper over.
Excessive curl	The paper is too moist, has the wrong grain direction, or is of short-grain construction	Open the rear output bin, or use long-grain paper.
	The paper varies from side-to-side.	Turn the paper over.
Jamming, damage to printer	The paper has cutouts or perforations.	Use paper that is free of cutouts or perforations.
Problems with feeding	The paper has ragged edges.	Use high-quality paper that is made for laser printers.
	The paper varies from side-to-side.	Turn the paper over.
	The paper is too moist, too rough, too heavy or too smooth, has the wrong grain direction, or is of short-grain construction or it is embossed or from a faulty paper lot.	Try another kind of paper, between 100 and 250 Sheffield, 4 to 6% moisture content. Open the rear output bin, or use long-grain paper.
Print is skewed (crooked).	The media guides might be incorrectly adjusted.	Remove all media from the input tray, straighten the stack, and then load the media in the input tray again. Adjust the media guides to the width and length of the media that you are using and try printing again.
More than one sheet feeds at one time.	The media tray might be overloaded.	Remove some of the media from the tray.
	The media might be wrinkled, folded, or damaged.	Verify that the media is not wrinkled, folded, or damaged. Try printing on media from a new or different package.
The printer does not pull media from the media input tray.	The printer might be in manual-feed mode.	Verify that the printer is not in manual feed mode and print your job again.
	The pickup roller might be dirty or damaged.	Contact HP Customer Care.
	The paper-length adjustment control in tray 2 or optional tray 3 is set at a length that is greater than the media size.	Adjust the paper-length adjustment control to the correct length.
The printer does not pull media from media input tray when using the automatic two-sided printing feature.	The automatic two-sided printing media-size selector is not set to the correct page size.	Push in the media selector for letter/legal-size media. Pull out the media-size selector for A4-size media.

Printed page is different from what appeared on screen

Choose the item that best describes the problem:

- [Garbled, incorrect, or incomplete text on page 153](#)
- [Missing graphics or text, or blank pages on page 153](#)
- [Page format is different from another HP LaserJet printer on page 154](#)
- [Graphics quality on page 154](#)

Garbled, incorrect, or incomplete text

- The wrong printer driver might have been selected when the software was installed. Make sure that the HP LaserJet P2015 printer driver is selected in the printer Properties.
- If a specific file prints garbled text, there might be a problem with that specific file. If a specific application prints garbled text, there might be a problem with that application. Make sure that the appropriate printer driver is selected.
- There might be a problem with your software application. Try printing from another software application.
- The USB cable might be loose or defective. Try the following remedies:
 - Disconnect the cable and reconnect it at both ends.
 - Try printing a job that you know works.
 - If possible, attach the cable and printer to another computer, and try printing a job that you know works.
 - Try using a new USB 2.0 cable that is 3 m (10 ft) or less in length.
 - Turn off the printer and the computer. Remove the USB cable, and inspect both ends of the cable for damage. Reconnect the cable, making sure that the connections are tight. Make sure that the printer is directly connected to the computer. Remove any switchboxes, tape backup drives, security keys, or any other devices that are attached between the USB port on the computer and the printer. These devices can sometimes interfere with communication between the computer and the printer. Restart the printer and the computer.

Missing graphics or text, or blank pages

- Make sure that your file does not contain blank pages.
- The sealing tape might still be in the print cartridge. Remove the print cartridge, and pull the tab on the end of the cartridge until the entire length of the tape is removed. Reinstall the print cartridge. To check the printer, print a Demo page by pressing the **Go** button.
- The graphic settings in the printer Properties might not be correct for the type of job that you are printing. Try a different graphic setting in the printer Properties.
- Clean the printer, particularly the contacts between the print cartridge and the power supply.

Page format is different from another HP LaserJet printer

If you used an older or different HP LaserJet printer driver (printer software) to create the document, or if the printer Properties settings in the software are different, the page format might change when you try to print using your new printer driver or settings. To help eliminate this problem, try the following remedies:

- Create documents and print them using the same printer driver (printer software) and printer Properties settings regardless of which HP LaserJet printer you use to print them.
- Change the resolution, paper size, font settings, and other settings.

Graphics quality

The graphics settings might be unsuitable for your print job. Check the graphic settings, such as resolution, in the printer Properties and adjust them as necessary.




NOTE You might lose some resolution when converting from one graphics format to another.

Image problem solving


This section provides information about identifying and correcting print defects.

Light print or faded




- The print cartridge is nearing end of life.
- The media might not meet Hewlett-Packard's media specifications (for example, the media is too moist or too rough).
- If the whole page is light, the print density adjustment is too light or EconoMode might be turned on. Adjust the print density, and disable EconoMode in the printer Properties.

Toner specks




- The media might not meet Hewlett-Packard's media specifications (for example, the media is too moist or too rough).
- The printer might need to be cleaned.

Dropouts




- A single sheet of media might be defective. Try reprinting the job.
- The media's moisture content is uneven or the media has moist spots on its surface. Try printing with new media.
- The media lot is bad. The manufacturing processes can cause some areas to reject toner. Try a different type or brand of media.
- The print cartridge might be defective.

Vertical lines



The photosensitive drum inside the print cartridge has probably been scratched. Install a new HP print cartridge.

Gray background




- Make sure that tray 1 is in place.
 - Decrease the print density setting through HP ToolboxFX or the embedded Web server. This decreases the amount of background shading.
 - Change the media to a lighter basis weight.
 - Check the printer's environment. Very dry (low humidity) conditions can increase the amount of background shading.
 - Install a new HP print cartridge.
-

Toner smear



- If toner smears appear on the leading edge of the media, the media guides might be dirty. Wipe the media guides with a dry, lint-free cloth.
 - Check the media type and quality.
 - Try installing a new HP print cartridge.
 - The fuser temperature might be too low. In your printer driver, make sure the appropriate media type is selected.
-

Loose toner




- Clean the inside of the printer.
- Check the media type and quality.
- Try installing a new HP print cartridge.
- In your printer driver, make sure the appropriate media type is selected.
- Plug the printer directly into an AC outlet instead of into a power strip.

Vertical repetitive defects




- The print cartridge might be damaged. If a repetitive mark occurs at the same spot on the page, install a new HP print cartridge.
- The internal parts might have toner on them. If the defects occur on the back of the page, the problem will probably correct itself after a few more printed pages.
- In your printer driver, make sure the appropriate media type is selected.

Misformed characters




- If characters are improperly formed, producing hollow images, the media stock might be too slick. Try a different media.
- If characters are improperly formed, producing a wavy effect, the printer might need service. Print a configuration page. If the characters are improperly formed, contact an HP-authorized dealer or service representative.

Page skew




- Make sure that the media is loaded correctly and the media guides are not too tight or too loose against the media stack.
- The input bin might be too full.
- Check the media type and quality.

Curl or wave




- Check the media type and quality. Both high temperature and humidity cause media to curl.
- The media might have been in the input tray too long. Turn over the stack of media in the tray. Also, try rotating the media 180° in the input tray.
- Open the straight-through output door and try printing straight through.
- The fuser temperature might be too high. In your printer driver, make sure the appropriate media type is selected. If the problem persists, select a media type that uses a lower fuser temperature, such as transparencies or light media.

Wrinkles or creases



- Make sure that media is loaded properly.
- Check the media type and quality.
- Open the straight-through output door and try printing straight through.
- Turn over the stack of media in the tray. Also, try rotating the media 180° in the input tray.
- For envelopes, this can be caused by air pockets inside the envelope. Remove the envelope, flatten the envelope, and try printing again.

Toner scatter outline



- If large amounts of toner have scattered around the characters, the media might be resisting the toner. (A small amount of toner scatter is normal for laser printing.) Try a different media type.
- Turn over the stack of media in the tray.
- Use media designed for laser printers.

Clear jams

Occasionally, media becomes jammed during a print job. You are notified of a media jam by an error in the software and the printer control-panel lights.

The following are some of the causes of media jams:

- The input trays are loaded improperly or too full.



NOTE When you add new media, always remove all of the media from the input tray and straighten the stack of new media. This helps prevent multiple sheets of media from feeding through the printer at one time, reducing media jams.

- The media does not meet HP specifications.
- The printer might need to be cleaned to remove paper dust and other particles from the paper path.

There might be loose toner in the printer after a media jam. This toner clears up after a few sheets print.



CAUTION Media jams might result in loose toner on the page. If you get any toner on your clothes, wash them in cold water. *Hot water will permanently set the toner into the fabric.*


Print-cartridge area

To clear a jam in the print-cartridge area, perform the following steps:



CAUTION Do not use sharp objects, such as tweezers or needle-nose pliers, to remove jams. Damage caused by sharp objects will not be covered by the warranty.


1. Press the print-cartridge-door button, and then remove the print cartridge from the printer.




CAUTION To prevent damage to the print cartridge, minimize its exposure to direct light.

CAUTION After removing the print cartridge, handle it only on the ends.


2. Open the straight-through output door.




3. Pull down the green pressure-release levers.



4. With both hands, grasp the side of the media that is most visible (this includes the middle), and carefully pull it free from the printer.



5. Replace the print cartridge, and close the print-cartridge door.




Input trays


To clear a jam in the input trays, perform the following steps:

CAUTION Do not use sharp objects, such as tweezers or needle-nose pliers, to remove jams. Damage caused by sharp objects will not be covered by the warranty.


1. Open the straight-through output door.



2. Pull down the green pressure-release levers.




3. Press the print-cartridge-door button, and then remove the print cartridge from the printer.




CAUTION After removing the print cartridge, handle it only on the ends.


4. With both hands, grasp the side of the media that is most visible (this includes the middle), and carefully pull it free from the printer.




5. Insert the print cartridge in the printer and close the print-cartridge door.




6. Open tray 2.




7. With both hands, grasp the side of the media that is most visible (this includes the middle), and carefully pull it free from the printer.



8. If no media is visible, open the print-cartridge door, remove the print cartridge, and pull down the upper media guide. Carefully pull the media up and out of the printer.



9. Close tray 2.




Output bin



CAUTION Do not use sharp objects, such as tweezers or needle-nose pliers, to remove jams. Damage caused by sharp objects will not be covered by the warranty.

With both hands, grasp the side of the media that is most visible (this includes the middle), and carefully pull it free from the printer.




Straight-through output path


To clear a jam in the straight-through output path, perform the following steps:

CAUTION Do not use sharp objects, such as tweezers or needle-nose pliers, to remove jams. Damage caused by sharp objects will not be covered by the warranty.


1. Open the straight-through output door.



2. Pull down the green pressure-release levers.




3. With both hands, grasp the side of the media that is most visible (this includes the middle), and carefully pull it free from the printer.



NOTE If you cannot grasp the media with your hands, perform the procedure in [Print-cartridge area on page 160](#).

4. Close the straight-through output door.




Automatic two-sided printing path

To clear a jam in the automatic two-sided printing path, perform the following steps:




CAUTION Do not use sharp objects, such as tweezers or needlenose pliers, to remove jams. Damage caused by sharp objects will not be covered by the warranty.


1. Open the straight-through output door.




2. Pull down the green pressure-release levers.




3. Remove tray 2.




4. Push down on the green lever on the automatic two-sided printing path door on the front of the printer.




5. With both hands, grasp the side of the media that is most visible (this includes the middle), and carefully pull it free from the printer.




6. Close the automatic two-sided printing path door by firmly pushing it up.




7. Reinsert tray 2.




8. Open the automatic two-sided printing path door on the back of the printer.



9. With both hands, grasp the side of the media that is most visible (this includes the middle), and carefully pull it free from the printer.



10. Close the automatic two-sided printing path door.



Diagnostic resources

Engine test

The engine test verifies that the print engine is functioning correctly. During the test, the printer prints horizontal lines down the entire printable area of a page. The formatter is bypassed during the engine test.



NOTE The formatter must be connected to the ECU to perform an engine test.

1. Remove the left side cover.
2. Press the engine-test switch. A single test page prints.




Figure 7-1 Location of engine-test switch

Continuous self-test

The continuous self-test puts the device into a continuous printing mode without having to send jobs to it.

1. Turn off the printer.
2. Press and hold the **Go** button.
3. Turn on the printer and continue to hold the **Go** button for approximately 20 seconds, but no longer than 30 seconds, until the **Attention** and **Ready** lights illuminate.
4. Release the **Go** button.



NOTE If the **Attention**, **Ready**, and **Go** lights illuminate before you release the **Go** button, start again at step 1.

5. The **Ready** light starts blinking, indicating that the device is performing a continuous self-test.

To terminate the continuous self-test, press the **Cancel** button.

Half self-test functional check

The half self-test check determines which printing process is malfunctioning.

1. Print a Configuration page.
2. Press the print-cartridge-door button after the paper advances halfway through the printer (approximately five seconds after the motor begins rotating). The leading edge of the paper should have advanced past the print cartridge.
3. Remove the print cartridge.
4. Open the print cartridge drum shield to view the drum surface. If a dark and distinct toner image is present on the drum surface, assume that the first two functions of the electrophotographic process are functioning (image formation and development). Troubleshoot the failure as a transfer or fusing problem.

If there is no image on the photosensitive drum, perform these checks:

1. Make sure you removed the entire length of the sealing tape from the print cartridge before you installed the cartridge.
2. Perform a drum rotation functional check to ensure that the drum is rotating.
3. Perform a high-voltage contacts check.

Drum rotation functional check

The photosensitive drum, located in the print cartridge, must rotate for the print process to work. The photosensitive drum receives its drive from the main drive assembly.



NOTE This test is especially important if refilled print cartridges have been used.

1. Open the print-cartridge door.
2. Remove the print cartridge.
3. Mark the drive gear on the cartridge with a felt-tipped marker. Note the position of the mark.
4. Install the print cartridge and close the print-cartridge door. The startup sequence should rotate the drum enough to move the mark.
5. Open the print-cartridge door and inspect the gear that was marked in step 3. Verify that the mark moved.

If the mark did not move, inspect the main drive assembly to make sure that it is meshing with the print cartridge gears. If the drive gears appear functional and the drum does not move, replace the print cartridge.

Heating element check

Paper passes between the heating element and a soft pressure roller to fuse toner to the paper.

1. Unplug the printer for at least ten minutes.
2. Verify that the thermistor connector is seated into both the printer chassis and the ECU.

3. Remove the heating element connector from the ECU. To measure the continuity of the heating element, measure the resistance between the two pins at the end of the cable.



NOTE Normal resistance is 25 ohms +/- 10 ohms for the 110 V printer and 80 ohms +/- 20 ohms for the 220 V printer.

If no resistance is measured, replace the fuser.

4. Remove the thermistor connector, and then measure the resistance between J206 pins one and two and between J206 pins three and four.



NOTE Normal resistance between both pairs of pins is 370K ohms +/- 50K ohms at 20° C (68°F).

5. If no resistance is measured, replace the fuser.

High-voltage contacts check

The high-voltage contacts in the printer must have a good connection with the contacts on the print cartridge to provide the necessary voltages for the electrophotographic processes.

Checking the print cartridge contacts

Remove the print cartridge and visually inspect the three connection points on the ends of the print cartridge: drum ground (1), charging (2), and developing roller (3). If one is dirty or corroded, clean the connection with isopropyl alcohol. If one is damaged, replace the print cartridge.




Figure 7-2 Print cartridge high-voltage connection points (right side)




Figure 7-3 Print cartridge high-voltage connection points (left side)



CAUTION After removing the print cartridge, handle it only on the ends.

Checking the high-voltage connector assembly

Visually inspect the cartridge connection points inside the printer to make sure that they are not dirty or corroded. If the pins are dirty, clean them with isopropyl alcohol.

Network-setup problemsolving

If the computer cannot discover the networked HP LaserJet 2015 Series printer, perform the following steps:

1. Check the cables to ensure that they are properly connected. Check all of the following connections:
 - Power cables
 - Cables between the printer and the hub or switch
 - Cables between the hub or switch and the computer
 - Cables to and from the modem or Internet connection, if applicable
2. Verify that the computer network connections are working correctly (Windows only):
 - On the Windows desktop, double-click **My Network Places** or **Network Neighborhood**.
 - Click the **Entire Network** link.
 - Click the **Entire Contents** link.
 - Double-click one of the network icons, and make sure that some devices are listed.
3. Verify that the network connection is active:
 - Check the network light on the network (RJ-45) connector on the back of the printer.
 - If one of the lights is on solid, the printer is connected to the network.
 - If both network lights are off, check the cable connections from the printer to the gateway, switch, or hub to ensure that the connections are secure.
 - If the connections are secure, turn off the power to the printer for at least 10 seconds, and then turn on the power to the printer.
4. Print a Network Configuration page.
 - On the Network Configuration page, see if a non-zero IP address is assigned to the printer.
 - If the Network Configuration page does not have a valid, non-zero IP address, reset the HP internal network port to the factory defaults by pressing the **Go** and **Cancel** buttons at the same time.

After the Attention, Ready, and Go lights finish cycling, the printer returns to a Ready state and the reset is complete.
 - Two minutes after the printer reaches the Ready state, print another Network Configuration page, and check to see if a valid IP address is assigned to the printer.
 - If the IP address is still zeros, contact the network administrator.

Reset the printer

NVRAM initialization



CAUTION Only perform the following procedure if absolutely necessary. Performing an NVRAM initialization resets some parameters that cannot be restored later.

NVRAM initialization sets all default variables stored in NVRAM back to factory default values or to a default ROM value, depending on the variable. It also performs a system reset.

NVRAM initialization resets the following:

- All menu settings to factory default values
- Factory settings such as formatter number, page counts, and factory paper settings

Use the following procedure to perform an NVRAM initialization.

1. Turn the printer off.
2. Press and hold down the **Go** button.
3. Turn the printer on, and continue to hold the **Go** button for at least 20 seconds. During this process, the **Go** button, Attention, and Ready LEDs each turn on.
4. Release the **Go** button.

The printer lights begin cycling. After the NVRAM initialization is complete, the printer returns to the ready state.

Super NVRAM initialization

This feature is similar to NVRAM initialization, except all of NVRAM is re-initialized (including the configuration parameters not reset by an NVRAM initialization).

Use the following procedure to perform an NVRAM initialization.

1. Turn off the printer.
2. Press and hold the **Go** button.
3. Turn on the printer and continue to hold the **Go** button for at least 50 seconds. During this process, the **Attention**, **Ready**, **Go** lights turn on. Then the **Attention** and **Ready** lights turn off, leaving only the **Go** light illuminated.
4. Release the **Go** button. The **Go**, **Ready** and **Attention** lights turn on.
5. Press and hold the **Go** button. All lights turn off. During the next three seconds, the **Go**, **Ready** and **Attention** lights turn on in that order, one per second.
6. Release the **Go** button to perform the initialization. The control panel lights begin cycling from front to back. After the Super NVRAM initialization process is complete, the printer returns to the ready state.

Network reset

A network reset changes all network system parameters in NVRAM to the factory defaults. During the network-reset process, all button presses are ignored.

Use the following procedure to perform a network reset.

1. Turn off the printer.
2. Press and hold the **Job Cancel** button.
3. Turn on the printer and continue to hold the **Job Cancel** button for approximately 10 seconds, but no longer than 20 seconds. During this process, the **Attention** light turns on.
4. Release the **Job Cancel** button. The **Attention**, **Ready**, and **Go** lights begin cycling from front to back. After the network-reset process is complete, the device returns to the ready state.



NOTE If the **Attention** and **Ready** lights illuminate before you release the **Job Cancel** button, start again at step 1.

Cold reset

A cold reset changes most system parameters in NVRAM to the factory defaults. However, unlike NVRAM initialization, a cold reset does not reset the page count, the paper tray sizes, language, or formatter number.



NOTE A cold reset also resets all the HP Jetdirect settings as well as the printer settings.

Use the following procedure to perform a cold reset.

1. Turn off the printer.
2. Press and hold the **Go** button.
3. Turn the printer on, and continue to hold the **Go** button for at least 5 seconds, but not longer than 15 seconds. During this process, the **Attention** LED turns on.
4. Release the **Go** button.



NOTE If both the **Attention** and the **Ready** LEDs turn on before you release the **Go** button, you must start the procedure again with step 1.

The printer's LEDs begin cycling. The cold-reset process runs until completion, and the printer returns to the ready state.

Troubleshooting tools and reference diagrams

Repetitive image defects

If the printer output has a consistent, repetitive defect, then use [Table 7-6 Repetitive image defects on page 179](#) to determine which part needs to be replaced based on the measured distance between the repetitions of the defect.

Table 7-6 Repetitive image defects

Distance between identical defects	Dirty or damaged roller	Solution
37.7 mm (1.48 inches)	Primary charging roller	Replace the print cartridge.
43.0 mm (1.69 inches)	Registration roller	Replace the registration assembly.
44.0 mm (1.73 inches)	Developing cylinder	Replace the print cartridge.
46.2 mm (1.82 inches)	Transfer roller	Replace the transfer roller.
56.5 mm (2.22 inches)	Fuser film	Replace the fuser.
69.0 mm (2.72 inches)	Pressure roller	Replace the fuser.
75.4 mm (2.97 inches)	Photosensitive drum	Replace the print cartridge.

General timing chart




Figure 7-4 General timing chart

Circuit diagram




Figure 7-5 Circuit diagram (1 of 2)




Figure 7-6 Circuit diagram (2 of 2)

Solenoids




Figure 7-7 Solenoids

1	Duplex solenoid
2	Tray 1 pickup solenoid
3	Tray 2 pickup solenoid

Switches and sensors




Figure 7-8 Switches and sensors

1	Interlock switch
2	Delivery sensor
3	Top-of-page sensor

Rollers and pads




Figure 7-9 Rollers and pads

1	Transfer roller
2	Pressure roller
3	Pickup roller
4	Separation pad

8 Parts and diagrams

- [Order parts and supplies](#)
- [Assembly locations](#)
- [Covers](#)
- [Internal assemblies](#)
- [Alphabetical parts list](#)
- [Numerical parts list](#)

Order parts and supplies

Parts

Order replacement parts from the following Web sites:

<http://h30074.www3.hp.com/csn-aux/srvcdlvry/epdo/default/ePDOLogin.asp> (technicians)

<http://h20141.www2.hp.com/hpparts> (customers)

Related documentation and software

Order documentation and software from the companies listed in the following table; some documentation and software is available at the following Web sites.

Table 8-1 Technical support Web sites

HP Customer Care Online	http://www.hp.com/support
Software drivers, support documentation, and answers to frequently asked questions	
HP Technical Training	http://education.itrc.hp.com/TrainerII/en-US/index.jsp
(North America)	
Classes and schedules	

Supplies

Printer supplies are listed in this chapter. Consumables are available directly from HP at the following numbers.

- US: 800-538-8787
- Canada: 800-387-3154 (in Toronto: 416-671-8383)
- United Kingdom: 0734-441212
- Germany: 0130-3322

Contact your local HP Parts Coordinator for other local phone numbers.

ENWW

Assembly locations




Figure 8-1 Assembly locations (1 of 2)

Table 8-2 Assembly locations (1 of 2)

Ref	Description	Part number	Qty
	Face-down gear assembly	RM1-1305-000	
	Main drive assembly	RM1-4253-000	
	Cassette	RM1-4251-000	
	Registration assembly	RM1-4244-000	1




Figure 8-2 Assembly locations (2 of 2)

Table 8-3 Assembly locations (2 of 2)

Ref	Description	Part number	Qty
	Fuser assembly (110 V)	RM1-4247-000	1
	Fuser assembly (220 V)	RM1-4248-000	
	Duplex-drive assembly	RM1-4255-000	
	Duplexing assembly (HP LJ P2015d, P2015dn, and P2015x)	RM1-4258-000	
	ECU assembly (110 V)	RM1-4273-000	
	ECU assembly (220 V)	RM1-4273-000	

Covers




Figure 8-3 Covers

Table 8-4 Covers

Ref	Description	Part number	Qty
1	Top cover assembly	RM1-4272-000	1
1A	Holder, panel PCB	RC2-0316-000	1
1B	Screw, tap, binding head, M3x8	XB4-7300-809	2
2	Left cover assembly	RL1-1529-000	1
3	Cover, connector	RC2-0332-000	1
4	Right cover assembly	RL1-1530-000	1
5	Rear cover assembly (HP LJ P2015)	RM1-4277-000	1
6	Rear cover assembly (HP LJ P2015d, P2015dn, and P2015x)	RM1-4270-000	1
7	Label, stapler prohibition	RC1-3794-000	1
8	Cover, front	RC2-0330-000	1
9	Sheet, noise absorb	RC2-0312-000	1
10	Sheet, noise absorb	RC2-0311-000	2
11	Sheet, insulator	RC2-0314-000	1




Figure 8-4 Cartridge-door assembly

Table 8-5 Cartridge-door assembly

Ref	Description	Part number	Qty
	Cartridge-door assembly	RM1-4266-000	1
1	Cover, multipurpose	RM2-0407-000	1
2	Inner cover assembly	RM1-4267-000	1
3	Spring, tension	RU5-2895-000	2
4	M.P. lifting-plate assembly	RM1-4268-000	1
5	Expansion-tray assembly	RM1-4269-000	1
6	Hinge, multipurpose, right	RC2-0422-000	1
7	Hinge, multipurpose, left	RC2-0421-000	1

Internal assemblies




Figure 8-5 Internal components (1 of 4)

Table 8-6 Internal components (1 of 4)

Ref	Description	Part number	Qty
1	Roller, face-down	RL1-0527-000	1
2	Paper pick-up gear assembly	RM1-1301-000	1
3	Paper-feed guide assembly	RM1-4263-000	1
4	Bushing, right	RB2-2895-000	1
5	Bushing, left	RB2-2896-000	1
6	Bushing	RB2-2897-000	1
7	Shaft, paper pick-up drive	RC1-3471-000	1
8	Flag, paper-sensing	RC1-3472-000	1
9	Roller, idler	RC1-3481-000	2
10	Arm, idler roller	RC1-3482-000	2
11	Flag, M.P. sensor	RC2-0415-000	1
12	Base, separation pad	RC2-0419-000	1
13	Spring, compression	RU5-2323-000	2
14	Spring compression	RU5-2894-000	1
15	Spring, tension	RU5-2898-000	1
16	M.P. sensor PCB assembly	RM1-4162-000	1
17	Holder, M.P. sensor	RC2-0414-000	1
18	Screw, tap, binding head, M3x8	XB4-7300-809	1
19	Roller, paper pickup idler	RC1-3470-000	2
20	Roller, paper pick-up	RL1-0540-000	1
21	Pad, M.P. separation	RL1-1524-000	1
22	Paper-retaining assembly (HP LJ P2015d, P2015dn, and P2015x)	RM1-4265-000	1
23	Paper retaining assembly (HP LJ P2015)	RM1-4276-000	1
24	Bushing	RC1-3665-000	2
25	Link, gear release	RC1-3668-000	1
26	Gear, 29T	RU5-0331-000	1
27	Gear, 19T	RU5-0332-000	1
28	Guide, cable	RC2-1569-000	1
29	Guide, reverse	RC2-0323-000	1
30	Screw, RS, M3x6	XA9-1495-000	7
31	Screw, tap, M3x6	XA9-1503-000	6
32	Screw, RS, M3x8	XA9-1504-000	1
33	Screw, tapping, truss head, M4x10	XB4-7401-005	1




Figure 8-6 Internal components (2 of 4)

Table 8-7 Internal components (2 of 4)

Ref	Description	Part number	Qty
1	Guide, cartridge, right lower	RC2-0346-000	1
2	Duct	RC2-0351-000	1
3	Guide, cable	RC2-0397-000	1
4	Cam	RC2-0410-000	1
5	Guide, cassette, right rear	RC2-0416-000	1
6	Guide, cartridge, right upper	RC2-0426-000	1
7	Guide, shutter, front	RC2-0428-000	1
8	Guide, cassette, right center 1	RC1-3456-000	1
9	Guide, cassette, right center 2	RC1-3457-000	1
10	Guide, shutter, rear	RC1-3535-000	1
11	Holder, switch	RC1-3727-000	1
12	Screw, RS, M3x8	XA9-1504-000	8
13	Screw, RS, M3x6 (HP LJ P2015d, P2015dn, and P2015x)	XA9-1495-000	10
13	Screw, RS, M3x6 (HP LJ P2015)	XA9-1495-000	7
14	Screw, RS, M3x6	XA9-1561-000	1
15	Screw, toothed washer, M4x6	XB2-7400-606	1
16	Motor, DC	RK2-1567-000	1
17	Guide, cassette, right front	RL1-0517-000	1
18	Inlet/switch cable assembly	RM1-4169-000	1
19	Scanner assembly	RM1-4262-000	1
20	Plate, solenoid holder	RC1-3459-000	1
21	Cam, right	RC1-3546-000	1
22	Stopper	RC1-3580-000	1
23	Duplex driver PCB assembly (HP LJ P2015d, P2015dn, and P2015x)	RM1-1262-000	1
24	Spring, compression	RU5-2335-000	1
25	Shield, duplexing solenoid (HP LJ P2015d, P2015dn, and P2015x)	RC2-0347-000	1
26	Plate, grounding	RC2-1568-000	1
27	Arm, cam	RC2-0405-000	1
28	Arm, link	RC2-0406-000	1
29	Holder, fan	RC2-0349-000	1
30	Arm, tag	RC2-0392-000	1
31	Duct	RC2-0354-000	1
32	Holder, drawer connector	RC2-0396-000	1

Ref	Description	Part number	Qty
33	Connector, drawer	VS1-7258-007	1
34	Fan	RK2-1589-000	1
35	Screw, tap, M3x6	XA9-1503-000	3
36	Screw, tap, M3x8	XA9-1648-000	4
37	Screw, tap, binding head, M3x8	XB4-7300-809	1
38	Rod, grounding	RC2-0350-000	1
39	Cable, memory tag	RM1-4163-000	1
40	Solenoid (HP LJ P2015d, P2015dn, and P2015x)	RK2-0420-000	1
41	Solenoid (HP LJ P2015)	RK2-0424-000	1




Figure 8-7 Internal components (3 of 4)

Table 8-8 Internal components (3 of 4)

Ref	Description	Part number	Qty
1	Cover, drum	RC1-3563-000	1
2	Plate, drum grounding	RC1-3565-000	1
3	Plate, transfer grounding	RC1-3698-000	1
4	Spring, grounding	RC1-3700-000	1
5	Spring, transfer, right	RC1-3702-000	1
6	Cover, registration gear	RC1-3708-000	1
7	Screw, tapping, truss head, M4x10	XB4-7401-005	7
8	Spring, compression	RC1-3736-000	1
9	Spring, contact	RC2-0344-000	1
10	Bushing	RC2-0356-000	1
11	Bushing	RC2-0357-000	1
12	Eliminator, static charge	RC2-0358-000	1
13	Guide, transfer front	RC2-0359-000	1
14	Roller, transfer	RM1-4279-000	1
15	Plate, registration grounding	RC2-0384-000	1
16	Gear, 33T	RU5-0320-000	1
17	Spring, compression	RU5-2144-000	1
18	Spring, compression	RU5-2338-000	1
19	Screw, with washer, M3x8	XA9-1420-000	1
20	Screw, with washer, M4x12	XA9-1422-000	1
21	Screw, tap, binding head, M3x8	XB4-7300-809	2
22	Sheet, registration damper	RC1-3695-000	1
23	Top sensor assembly	RM1-1283-000	1
24	Paper-width sensor assembly	RM1-4245-000	1
25	Registration assembly	RM1-4244-000	1
26	Screw, RS, M3x8	XA9-1504-000	1
27	Shutter link assembly	RM1-1321-000	1
28	Label, transfer guide open	RC1-3796-000	1
29	Paper-sensor PCB assembly	RM1-4159-000	1




Figure 8-8 Internal components (4 of 4)

Table 8-9 Internal components (4 of 4)

Ref	Description	Part number	Qty
1	Roller, M.P. paper pick-up	RL1-1525-000	1
2	Side plate, M.P. drive	RL1-1531-000	1
3	Guide, cassette, left center 1	RC1-3461-000	1
4	Guide, cassette, left center 2	RC1-3462-000	1
5	Guide, cassette, left rear	RC1-3463-000	1
6	Lever, cartridge contact	RC1-3542-000	1
7	Spring, torsion	RC1-3543-000	1
8	Spring, contact	RC1-3719-000	1
9	Guide, cartridge, left lower	RC2-0339-000	1
10	Holder contact	RC2-0342-000	1
11	Guide, F.F.C	RC2-0423-000	1
12	Sheet, plate bottom	RC2-1578-000	1
13	Guide, cassette, left front	RL1-0518-000	1
14	Paper pick-up gear assembly	RM1-4275-000	1
15	Plate, drum grounding	RC1-3541-000	1
16	Arm lock	RC1-3561-000	1
17	Bushing	RC1-3562-000	1
18	Roller	RC1-0950-000	2
19	Spring, compression	RU5-2337-000	1
20	Gear, 19T	RU5-0927-000	1
21	Gear, 26T	RU5-0928-000	1
22	Gear, 14T	RU5-0929-000	1
23	Holder, M.P. solenoid	RC2-0334-000	1
24	Guide, cartridge font	RC2-0340-000	1
25	Guide, M.P. cable	RC2-0335-000	1
26	Guide, cartridge, left upper	RC2-0425-000	1
27	Spring, torsion	RC2-0427-000	1
28	Guide, F.F.C	RC2-0424-000	1
29	Spring, grounding	RC1-0944-000	1
30	Holder, paper pick-up roller	RC2-0386-000	1
31	Cam, M.P., left	RC2-0387-000	1
32	Cam, M.P., right	RC2-0388-000	1
33	Cover, paper pick-up roller	RC2-0420-000	1
34	Microswitch	RK2-0534-000	1

Ref	Description	Part number	Qty
35	Screw, RS, M3x6	XA9-1495-000	6
36	Screw, RS, M3x8	XA9-1504-000	6
37	Cap, continuity	RA0-1068-000	1
38	Solenoid	RK2-1587-000	1




Figure 8-9 ECU assembly

Table 8-10 ECU assembly

Ref	Description	Part number	Qty
	ECU assembly (110 V)	RM1-4273-000	1
	ECU assembly (220 V)	RM1-4274-000	1




Figure 8-10 Main drive assembly

Table 8-11 Main drive assembly

Ref	Description	Part number	Qty
	Main drive assembly	RM1-4253-000	1




Figure 8-11 Fuser assembly

Table 8-12 Fuser assembly

Ref	Description	Part number	Qty
	Fuser assembly (110 V)	RM1-4247-000	1
	Fuser assembly (220 V)	RM1-4248-000	1
1	Spring, tension	RA0-1090-000	2
2	Retainer, spring	RA0-1189-000	1
3	Side plate, fixing, right	RC1-3604-000	1
4	Side plate, fixing, left	RC1-3605-000	1
5	Plate, fixing reinforcement	RC1-3606-000	1
6	Guide, fixing, upper	RC1-3607-000	1
7	Guide, paper separate, lower	RC1-3611-000	1
8	Flag, paper delivery sensor	RC1-3613-000	1
9	Spring, torsion	RC1-3614-000	1
10	Bushing	RC1-3615-000	1
11	Lever, pressure release, right	RC1-3616-000	1
12	Lever, pressure release, left	RC1-3617-000	1
13	Lever, pressure-release sensor, right	RC1-3618-000	1
14	Lever, pressure release sensor, left	RC1-3619-000	1
15	Flag, intertwine prevention	RC1-3622-000	1
16	Plate, pressure, right	RC1-3623-000	1
17	Plate, pressure, left	RC1-3624-000	1
18	Spring, compression	RC1-3625-000	1
19	Holder, leaf spring	RC1-3627-000	1
20	Ring, conductive rubber	RC1-3628-000	1
21	Roller, face-up	RC1-3633-000	1
22	Delivery sensor PCB assembly	RM1-1251-000	1
23	Gear, 17T	RU5-0330-000	1
24	Frame, fixing	RC2-0295-000	1
25	Guide, fixing entrance	RC2-0296-000	1
26	Bushing	RC2-0297-000	1
27	Bushing	RC2-0298-000	1
28	Needle, fixing static charge	RC2-0299-000	1
29	Holder, separate lower guide	RC2-0429-000	1
30	Cover, fixing	RC2-0300-000	1
31	Sheet, fixing bottom	RC2-0431-000	1
32	Spring, compression	RU5-2901-000	2

Ref	Description	Part number	Qty
33	Screw, with washer, M4x12	XA9-1422-000	1
34	Screw, tap, M3x6	XA9-1503-000	10
35	Screw, tap, binding head, M3x8	XB4-7300-809	1
36	Delivery frame assembly	RM1-1291-000	1
37	Roller, pressure	RC2-0303-000	1
38	Film guide assembly (110 V)	RM1-4249-000	1
39	Film guide assembly (220 V)	RM1-4250-000	1




Figure 8-12 Duplexing drive assembly

Table 8-13 Duplexing drive assembly

Ref	Description	Part number	Qty
	Duplexing drive assembly (HP LJ P2015d, P2015dn, and P2015x)	RM1-4255-000	1
1	Normal-rotation drive assembly (HP LJ P2015d, P2015dn, and P2015x)	RM1-4256-000	1
2	Reverse-rotation drive assembly (HP LJ P2015d, P2015dn, and P2015x)	RM1-4257-000	1




Figure 8-13 Face-down gear assembly

Table 8-14 Face-down gear assembly

Ref	Description	Part number	Qty
	Face-down gear assembly	RM1-1305-000	1




Figure 8-14 Cassette assembly

Table 8-15 Cassette assembly

Ref	Description	Part number	Qty
	Cassette	RM1-4251-000	1
1	Cassette body assembly	RC1-3483-000	1
2	Cassette cover assembly	RM1-4252-000	1
3	Back end limit assembly	RM1-1295-000	1
4	Plate, lifter	RL1-0522-000	1
5	Left paper side-end assembly	RM1-1296-000	1
6	Right paper side-end assembly	RM1-1297-020	1
7	Separation pad assembly	RM1-1298-000	1
8	Screw, M4x10	XB4-7401-005	2
9	Spring, compression	RC1-3489-000	2
10	Gear, 10T	RU5-0328-000	1
11	Spring, grounding	RC1-3492-000	1
12	Spring, tension	RU5-2324-000	1
13	Lock, lifter plate	RC1-3490-000	1
14	Stopper, claw	RC1-4198-000	2
15	Stopper, cassette left	RC1-3508-000	1
16	Spring, compression	RU5-2327-000	2
17	Stopper, cassette right	RC1-3507-000	1




Figure 8-15 Duplexing assembly

Table 8-16 Duplexing assembly

Ref	Description	Part number	Qty
	Duplexing assembly (HP LJ P2015d, P2015dn, and P2015x)	RM1-4258-000	1




Figure 8-16 PCB assembly locations

Table 8-17 PCB assembly locations

Ref	Description	Part number	Qty
1	ECU assembly (110 V)	RM1-4273-000	1
1	ECU assembly (220 V)	RM1-4274-000	1
2	Duplex driver PCB assembly (HP LJ P2015d, P2015dn, and P2015x)	RM1-1262-000	1

Alphabetical parts list

Table 8-18 Alphabetical parts list

Description	Part number	Table and page
Arm lock	RC1-3561-000	Internal components (4 of 4) on page 207
Arm, cam	RC2-0405-000	Internal components (2 of 4) on page 201
Arm, idler roller	RC1-3482-000	Internal components (1 of 4) on page 199
Arm, link	RC2-0406-000	Internal components (2 of 4) on page 201
Arm, tag	RC2-0392-000	Internal components (2 of 4) on page 201
Back end limit assembly	RM1-1295-000	Cassette assembly on page 223
Base, separation pad	RC2-0419-000	Internal components (1 of 4) on page 199
Bushing	RB2-2897-000	Internal components (1 of 4) on page 199
Bushing	RC1-3665-000	Internal components (1 of 4) on page 199
Bushing	RC2-0356-000	Internal components (3 of 4) on page 205
Bushing	RC2-0357-000	Internal components (3 of 4) on page 205
Bushing	RC1-3562-000	Internal components (4 of 4) on page 207
Bushing	RC1-3615-000	Fuser assembly on page 215
Bushing	RC2-0297-000	Fuser assembly on page 215
Bushing	RC2-0298-000	Fuser assembly on page 215
Bushing, left	RB2-2896-000	Internal components (1 of 4) on page 199
Bushing, right	RB2-2895-000	Internal components (1 of 4) on page 199
Cable, memory tag	RM1-4163-000	Internal components (2 of 4) on page 201
Cam	RC2-0410-000	Internal components (2 of 4) on page 201
Cam, M.P., left	RC2-0387-000	Internal components (4 of 4) on page 207
Cam, M.P., right	RC2-0388-000	Internal components (4 of 4) on page 207

Table 8-18 Alphabetical parts list (continued)

Description	Part number	Table and page
Cam, right	RC1-3546-000	Internal components (2 of 4) on page 201
Cap, continuity	RA0-1068-000	Internal components (4 of 4) on page 207
Cartridge-door assembly	RM1-4266-000	Cartridge-door assembly on page 197
Cassette	RM1-4251-000	Assembly locations (1 of 2) on page 191
Cassette	RM1-4251-000	Cassette assembly on page 223
Cassette body assembly	RC1-3483-000	Cassette assembly on page 223
Cassette cover assembly	RM1-4252-000	Cassette assembly on page 223
Connector, drawer	VS1-7258-007	Internal components (2 of 4) on page 201
Cover, connector	RC2-0332-000	Covers on page 195
Cover, drum	RC1-3563-000	Internal components (3 of 4) on page 205
Cover, fixing	RC2-0300-000	Fuser assembly on page 215
Cover, front	RC2-0330-000	Covers on page 195
Cover, multipurpose	RM2-0407-000	Cartridge-door assembly on page 197
Cover, paper pick-up roller	RC2-0420-000	Internal components (4 of 4) on page 207
Cover, registration gear	RC1-3708-000	Internal components (3 of 4) on page 205
Delivery frame assembly	RM1-1291-000	Fuser assembly on page 215
Delivery sensor PCB assembly	RM1-1251-000	Fuser assembly on page 215
Duct	RC2-0351-000	Internal components (2 of 4) on page 201
Duct	RC2-0354-000	Internal components (2 of 4) on page 201
Duplex driver PCB assembly (HP LJ P2015d, P2015dn, and P2015x)	RM1-1262-000	Internal components (2 of 4) on page 201
Duplex driver PCB assembly (HP LJ P2015d, P2015dn, and P2015x)	RM1-1262-000	PCB assembly locations on page 227
Duplex-drive assembly	RM1-4255-000	Assembly locations (2 of 2) on page 193
Duplexing assembly (HP LJ P2015d, P2015dn, and P2015x)	RM1-4258-000	Duplexing assembly on page 225
Duplexing assembly (HP LJ P2015d, P2015dn, and P2015x)	RM1-4258-000	Assembly locations (2 of 2) on page 193

Table 8-18 Alphabetical parts list (continued)

Description	Part number	Table and page
Duplexing drive assembly (HP LJ P2015d, P2015dn, and P2015x)	RM1-4255-000	Duplexing drive assembly on page 219
ECU assembly (110 V)	RM1-4273-000	Assembly locations (2 of 2) on page 193
ECU assembly (110 V)	RM1-4273-000	ECU assembly on page 211
ECU assembly (110 V)	RM1-4273-000	PCB assembly locations on page 227
ECU assembly (220 V)	RM1-4273-000	Assembly locations (2 of 2) on page 193
ECU assembly (220 V)	RM1-4274-000	ECU assembly on page 211
ECU assembly (220 V)	RM1-4274-000	PCB assembly locations on page 227
Eliminator, static charge	RC2-0358-000	Internal components (3 of 4) on page 205
Expansion-tray assembly	RM1-4269-000	Cartridge-door assembly on page 197
Face-down gear assembly	RM1-1305-000	Assembly locations (1 of 2) on page 191
Face-down gear assembly	RM1-1305-000	Face-down gear assembly on page 221
Fan	RK2-1589-000	Internal components (2 of 4) on page 201
Film guide assembly (110 V)	RM1-4249-000	Fuser assembly on page 215
Film guide assembly (220 V)	RM1-4250-000	Fuser assembly on page 215
Flag, intertwine prevention	RC1-3622-000	Fuser assembly on page 215
Flag, M.P. sensor	RC2-0415-000	Internal components (1 of 4) on page 199
Flag, paper delivery sensor	RC1-3613-000	Fuser assembly on page 215
Flag, paper-sensing	RC1-3472-000	Internal components (1 of 4) on page 199
Frame, fixing	RC2-0295-000	Fuser assembly on page 215
Fuser assembly (110 V)	RM1-4247-000	Assembly locations (2 of 2) on page 193
Fuser assembly (110 V)	RM1-4247-000	Fuser assembly on page 215
Fuser assembly (220 V)	RM1-4248-000	Assembly locations (2 of 2) on page 193
Fuser assembly (220 V)	RM1-4248-000	Fuser assembly on page 215
Gear, 10T	RU5-0328-000	Cassette assembly on page 223
Gear, 14T	RU5-0929-000	Internal components (4 of 4) on page 207

Table 8-18 Alphabetical parts list (continued)

Description	Part number	Table and page
Gear, 17T	RU5-0330-000	Fuser assembly on page 215
Gear, 19T	RU5-0332-000	Internal components (1 of 4) on page 199
Gear, 19T	RU5-0927-000	Internal components (4 of 4) on page 207
Gear, 26T	RU5-0928-000	Internal components (4 of 4) on page 207
Gear, 29T	RU5-0331-000	Internal components (1 of 4) on page 199
Gear, 33T	RU5-0320-000	Internal components (3 of 4) on page 205
Guide, cable	RC2-1569-000	Internal components (1 of 4) on page 199
Guide, cable	RC2-0397-000	Internal components (2 of 4) on page 201
Guide, cartridge font	RC2-0340-000	Internal components (4 of 4) on page 207
Guide, cartridge, left lower	RC2-0339-000	Internal components (4 of 4) on page 207
Guide, cartridge, left upper	RC2-0425-000	Internal components (4 of 4) on page 207
Guide, cartridge, right lower	RC2-0346-000	Internal components (2 of 4) on page 201
Guide, cartridge, right upper	RC2-0426-000	Internal components (2 of 4) on page 201
Guide, cassette, left center 1	RC1-3461-000	Internal components (4 of 4) on page 207
Guide, cassette, left center 2	RC1-3462-000	Internal components (4 of 4) on page 207
Guide, cassette, left front	RL1-0518-000	Internal components (4 of 4) on page 207
Guide, cassette, left rear	RC1-3463-000	Internal components (4 of 4) on page 207
Guide, cassette, right center 1	RC1-3456-000	Internal components (2 of 4) on page 201
Guide, cassette, right center 2	RC1-3457-000	Internal components (2 of 4) on page 201
Guide, cassette, right front	RL1-0517-000	Internal components (2 of 4) on page 201
Guide, cassette, right rear	RC2-0416-000	Internal components (2 of 4) on page 201
Guide, F.F.C	RC2-0423-000	Internal components (4 of 4) on page 207

Table 8-18 Alphabetical parts list (continued)

Description	Part number	Table and page
Guide, F.F.C	RC2-0424-000	Internal components (4 of 4) on page 207
Guide, fixing entrance	RC2-0296-000	Fuser assembly on page 215
Guide, fixing, upper	RC1-3607-000	Fuser assembly on page 215
Guide, M.P. cable	RC2-0335-000	Internal components (4 of 4) on page 207
Guide, paper separate, lower	RC1-3611-000	Fuser assembly on page 215
Guide, reverse	RC2-0323-000	Internal components (1 of 4) on page 199
Guide, shutter, front	RC2-0428-000	Internal components (2 of 4) on page 201
Guide, shutter, rear	RC1-3535-000	Internal components (2 of 4) on page 201
Guide, transfer front	RC2-0359-000	Internal components (3 of 4) on page 205
Hinge, multipurpose, left	RC2-0421-000	Cartridge-door assembly on page 197
Hinge, multipurpose, right	RC2-0422-000	Cartridge-door assembly on page 197
Holder contact	RC2-0342-000	Internal components (4 of 4) on page 207
Holder, drawer connector	RC2-0396-000	Internal components (2 of 4) on page 201
Holder, fan	RC2-0349-000	Internal components (2 of 4) on page 201
Holder, leaf spring	RC1-3627-000	Fuser assembly on page 215
Holder, M.P. sensor	RC2-0414-000	Internal components (1 of 4) on page 199
Holder, M.P. solenoid	RC2-0334-000	Internal components (4 of 4) on page 207
Holder, panel PCB	RC2-0316-000	Covers on page 195
Holder, paper pick-up roller	RC2-0386-000	Internal components (4 of 4) on page 207
Holder, separate lower guide	RC2-0429-000	Fuser assembly on page 215
Holder, switch	RC1-3727-000	Internal components (2 of 4) on page 201
Inlet/switch cable assembly	RM1-4169-000	Internal components (2 of 4) on page 201
Inner cover assembly	RM1-4267-000	Cartridge-door assembly on page 197
Label, stapler prohibition	RC1-3794-000	Covers on page 195

Table 8-18 Alphabetical parts list (continued)

Description	Part number	Table and page
Label, transfer guide open	RC1-3796-000	Internal components (3 of 4) on page 205
Left cover assembly	RL1-1529-000	Covers on page 195
Left paper side-end assembly	RM1-1296-000	Cassette assembly on page 223
Lever, cartridge contact	RC1-3542-000	Internal components (4 of 4) on page 207
Lever, pressure release sensor, left	RC1-3619-000	Fuser assembly on page 215
Lever, pressure release, left	RC1-3617-000	Fuser assembly on page 215
Lever, pressure release, right	RC1-3616-000	Fuser assembly on page 215
Lever, pressure-release sensor, right	RC1-3618-000	Fuser assembly on page 215
Link, gear release	RC1-3668-000	Internal components (1 of 4) on page 199
Lock, lifter plate	RC1-3490-000	Cassette assembly on page 223
M.P. lifting-plate assembly	RM1-4268-000	Cartridge-door assembly on page 197
M.P. sensor PCB assembly	RM1-4162-000	Internal components (1 of 4) on page 199
Main drive assembly	RM1-4253-000	Assembly locations (1 of 2) on page 191
Main drive assembly	RM1-4253-000	Main drive assembly on page 213
Microswitch	RK2-0534-000	Internal components (4 of 4) on page 207
Motor, DC	RK2-1567-000	Internal components (2 of 4) on page 201
Needle, fixing static charge	RC2-0299-000	Fuser assembly on page 215
Normal-rotation drive assembly (HP LJ P2015d, P2015dn, and P2015x)	RM1-4256-000	Duplexing drive assembly on page 219
Pad, M.P. separation	RL1-1524-000	Internal components (1 of 4) on page 199
Paper pick-up gear assembly	RM1-1301-000	Internal components (1 of 4) on page 199
Paper pick-up gear assembly	RM1-4275-000	Internal components (4 of 4) on page 207
Paper retaining assembly (HP LJ P2015)	RM1-4276-000	Internal components (1 of 4) on page 199
Paper-feed guide assembly	RM1-4263-000	Internal components (1 of 4) on page 199
Paper-retaining assembly (HP LJ P2015d, P2015dn, and P2015x)	RM1-4265-000	Internal components (1 of 4) on page 199

Table 8-18 Alphabetical parts list (continued)

Description	Part number	Table and page
Paper-sensor PCB assembly	RM1-4159-000	Internal components (3 of 4) on page 205
Paper-width sensor assembly	RM1-4245-000	Internal components (3 of 4) on page 205
Plate, drum grounding	RC1-3565-000	Internal components (3 of 4) on page 205
Plate, drum grounding	RC1-3541-000	Internal components (4 of 4) on page 207
Plate, fixing reinforcement	RC1-3606-000	Fuser assembly on page 215
Plate, grounding	RC2-1568-000	Internal components (2 of 4) on page 201
Plate, lifter	RL1-0522-000	Cassette assembly on page 223
Plate, pressure, left	RC1-3624-000	Fuser assembly on page 215
Plate, pressure, right	RC1-3623-000	Fuser assembly on page 215
Plate, registration grounding	RC2-0384-000	Internal components (3 of 4) on page 205
Plate, solenoid holder	RC1-3459-000	Internal components (2 of 4) on page 201
Plate, transfer grounding	RC1-3698-000	Internal components (3 of 4) on page 205
Rear cover assembly (HP LJ P2015)	RM1-4277-000	Covers on page 195
Rear cover assembly (HP LJ P2015d, P2015dn, and P2015x)	RM1-4270-000	Covers on page 195
Registration assembly	RM1-4244-000	Assembly locations (1 of 2) on page 191
Registration assembly	RM1-4244-000	Internal components (3 of 4) on page 205
Retainer, spring	RA0-1189-000	Fuser assembly on page 215
Reverse-rotation drive assembly (HP LJ P2015d, P2015dn, and P2015x)	RM1-4257-000	Duplexing drive assembly on page 219
Right cover assembly	RL1-1530-000	Covers on page 195
Right paper side-end assembly	RM1-1297-020	Cassette assembly on page 223
Ring, conductive rubber	RC1-3628-000	Fuser assembly on page 215
Rod, grounding	RC2-0350-000	Internal components (2 of 4) on page 201
Roller	RC1-0950-000	Internal components (4 of 4) on page 207
Roller, face-down	RL1-0527-000	Internal components (1 of 4) on page 199
Roller, face-up	RC1-3633-000	Fuser assembly on page 215

Table 8-18 Alphabetical parts list (continued)

Description	Part number	Table and page
Roller, idler	RC1-3481-000	Internal components (1 of 4) on page 199
Roller, M.P. paper pick-up	RL1-1525-000	Internal components (4 of 4) on page 207
Roller, paper pick-up	RL1-0540-000	Internal components (1 of 4) on page 199
Roller, paper pickup idler	RC1-3470-000	Internal components (1 of 4) on page 199
Roller, pressure	RC2-0303-000	Fuser assembly on page 215
Roller, transfer	RM1-4279-000	Internal components (3 of 4) on page 205
Scanner assembly	RM1-4262-000	Internal components (2 of 4) on page 201
Screw, M4x10	XB4-7401-005	Cassette assembly on page 223
Screw, RS, M3x6	XA9-1495-000	Internal components (1 of 4) on page 199
Screw, RS, M3x6	XA9-1561-000	Internal components (2 of 4) on page 201
Screw, RS, M3x6	XA9-1495-000	Internal components (4 of 4) on page 207
Screw, RS, M3x6 (HP LJ P2015)	XA9-1495-000	Internal components (2 of 4) on page 201
Screw, RS, M3x6 (HP LJ P2015d, P2015dn, and P2015x)	XA9-1495-000	Internal components (2 of 4) on page 201
Screw, RS, M3x8	XA9-1504-000	Internal components (1 of 4) on page 199
Screw, RS, M3x8	XA9-1504-000	Internal components (2 of 4) on page 201
Screw, RS, M3x8	XA9-1504-000	Internal components (3 of 4) on page 205
Screw, RS, M3x8	XA9-1504-000	Internal components (4 of 4) on page 207
Screw, tap, binding head, M3x8	XB4-7300-809	Covers on page 195
Screw, tap, binding head, M3x8	XB4-7300-809	Internal components (1 of 4) on page 199
Screw, tap, binding head, M3x8	XB4-7300-809	Internal components (2 of 4) on page 201
Screw, tap, binding head, M3x8	XB4-7300-809	Internal components (3 of 4) on page 205
Screw, tap, binding head, M3x8	XB4-7300-809	Fuser assembly on page 215
Screw, tap, M3x6	XA9-1503-000	Internal components (1 of 4) on page 199

Table 8-18 Alphabetical parts list (continued)

Description	Part number	Table and page
Screw, tap, M3x6	XA9-1503-000	Internal components (2 of 4) on page 201
Screw, tap, M3x6	XA9-1503-000	Fuser assembly on page 215
Screw, tap, M3x8	XA9-1648-000	Internal components (2 of 4) on page 201
Screw, tapping, truss head, M4x10	XB4-7401-005	Internal components (1 of 4) on page 199
Screw, tapping, truss head, M4x10	XB4-7401-005	Internal components (3 of 4) on page 205
Screw, toothed washer, M4x6	XB2-7400-606	Internal components (2 of 4) on page 201
Screw, with washer, M3x8	XA9-1420-000	Internal components (3 of 4) on page 205
Screw, with washer, M4x12	XA9-1422-000	Internal components (3 of 4) on page 205
Screw, with washer, M4x12	XA9-1422-000	Fuser assembly on page 215
Separation pad assembly	RM1-1298-000	Cassette assembly on page 223
Shaft, paper pick-up drive	RC1-3471-000	Internal components (1 of 4) on page 199
Sheet, fixing bottom	RC2-0431-000	Fuser assembly on page 215
Sheet, insulator	RC2-0314-000	Covers on page 195
Sheet, noise absorb	RC2-0312-000	Covers on page 195
Sheet, noise absorb	RC2-0311-000	Covers on page 195
Sheet, plate bottom	RC2-1578-000	Internal components (4 of 4) on page 207
Sheet, registration damper	RC1-3695-000	Internal components (3 of 4) on page 205
Shield, duplexing solenoid (HP LJ P2015d, P2015dn, and P2015x)	RC2-0347-000	Internal components (2 of 4) on page 201
Shutter link assembly	RM1-1321-000	Internal components (3 of 4) on page 205
Side plate, fixing, left	RC1-3605-000	Fuser assembly on page 215
Side plate, fixing, right	RC1-3604-000	Fuser assembly on page 215
Side plate, M.P. drive	RL1-1531-000	Internal components (4 of 4) on page 207
Solenoid	RK2-1587-000	Internal components (4 of 4) on page 207
Solenoid (HP LJ P2015)	RK2-0424-000	Internal components (2 of 4) on page 201
Solenoid (HP LJ P2015d, P2015dn, and P2015x)	RK2-0420-000	Internal components (2 of 4) on page 201

Table 8-18 Alphabetical parts list (continued)

Description	Part number	Table and page
Spring compression	RU5-2894-000	Internal components (1 of 4) on page 199
Spring, compression	RU5-2323-000	Internal components (1 of 4) on page 199
Spring, compression	RU5-2335-000	Internal components (2 of 4) on page 201
Spring, compression	RC1-3736-000	Internal components (3 of 4) on page 205
Spring, compression	RU5-2144-000	Internal components (3 of 4) on page 205
Spring, compression	RU5-2338-000	Internal components (3 of 4) on page 205
Spring, compression	RU5-2337-000	Internal components (4 of 4) on page 207
Spring, compression	RC1-3625-000	Fuser assembly on page 215
Spring, compression	RU5-2901-000	Fuser assembly on page 215
Spring, compression	RC1-3489-000	Cassette assembly on page 223
Spring, compression	RU5-2327-000	Cassette assembly on page 223
Spring, contact	RC2-0344-000	Internal components (3 of 4) on page 205
Spring, contact	RC1-3719-000	Internal components (4 of 4) on page 207
Spring, grounding	RC1-3700-000	Internal components (3 of 4) on page 205
Spring, grounding	RC1-0944-000	Internal components (4 of 4) on page 207
Spring, grounding	RC1-3492-000	Cassette assembly on page 223
Spring, tension	RU5-2895-000	Cartridge-door assembly on page 197
Spring, tension	RU5-2898-000	Internal components (1 of 4) on page 199
Spring, tension	RA0-1090-000	Fuser assembly on page 215
Spring, tension	RU5-2324-000	Cassette assembly on page 223
Spring, torsion	RC1-3543-000	Internal components (4 of 4) on page 207
Spring, torsion	RC2-0427-000	Internal components (4 of 4) on page 207
Spring, torsion	RC1-3614-000	Fuser assembly on page 215

Table 8-18 Alphabetical parts list (continued)

Description	Part number	Table and page
Spring, transfer, right	RC1-3702-000	Internal components (3 of 4) on page 205
Stopper	RC1-3580-000	Internal components (2 of 4) on page 201
Stopper, cassette left	RC1-3508-000	Cassette assembly on page 223
Stopper, cassette right	RC1-3507-000	Cassette assembly on page 223
Stopper, claw	RC1-4198-000	Cassette assembly on page 223
Top cover assembly	RM1-4272-000	Covers on page 195
Top sensor assembly	RM1-1283-000	Internal components (3 of 4) on page 205

Numerical parts list

Table 8-19 Numerical parts list

Part number	Description	Table and page
RA0-1068-000	Cap, continuity	Internal components (4 of 4) on page 207
RA0-1090-000	Spring, tension	Fuser assembly on page 215
RA0-1189-000	Retainer, spring	Fuser assembly on page 215
RB2-2895-000	Bushing, right	Internal components (1 of 4) on page 199
RB2-2896-000	Bushing, left	Internal components (1 of 4) on page 199
RB2-2897-000	Bushing	Internal components (1 of 4) on page 199
RC1-0944-000	Spring, grounding	Internal components (4 of 4) on page 207
RC1-0950-000	Roller	Internal components (4 of 4) on page 207
RC1-3456-000	Guide, cassette, right center 1	Internal components (2 of 4) on page 201
RC1-3457-000	Guide, cassette, right center 2	Internal components (2 of 4) on page 201
RC1-3459-000	Plate, solenoid holder	Internal components (2 of 4) on page 201
RC1-3461-000	Guide, cassette, left center 1	Internal components (4 of 4) on page 207
RC1-3462-000	Guide, cassette, left center 2	Internal components (4 of 4) on page 207
RC1-3463-000	Guide, cassette, left rear	Internal components (4 of 4) on page 207
RC1-3470-000	Roller, paper pickup idler	Internal components (1 of 4) on page 199
RC1-3471-000	Shaft, paper pick-up drive	Internal components (1 of 4) on page 199
RC1-3472-000	Flag, paper-sensing	Internal components (1 of 4) on page 199
RC1-3481-000	Roller, idler	Internal components (1 of 4) on page 199
RC1-3482-000	Arm, idler roller	Internal components (1 of 4) on page 199
RC1-3483-000	Cassette body assembly	Cassette assembly on page 223
RC1-3489-000	Spring, compression	Cassette assembly on page 223

Table 8-19 Numerical parts list (continued)

Part number	Description	Table and page
RC1-3490-000	Lock, lifter plate	Cassette assembly on page 223
RC1-3492-000	Spring, grounding	Cassette assembly on page 223
RC1-3507-000	Stopper, cassette right	Cassette assembly on page 223
RC1-3508-000	Stopper, cassette left	Cassette assembly on page 223
RC1-3535-000	Guide, shutter, rear	Internal components (2 of 4) on page 201
RC1-3541-000	Plate, drum grounding	Internal components (4 of 4) on page 207
RC1-3542-000	Lever, cartridge contact	Internal components (4 of 4) on page 207
RC1-3543-000	Spring, torsion	Internal components (4 of 4) on page 207
RC1-3546-000	Cam, right	Internal components (2 of 4) on page 201
RC1-3561-000	Arm lock	Internal components (4 of 4) on page 207
RC1-3562-000	Bushing	Internal components (4 of 4) on page 207
RC1-3563-000	Cover, drum	Internal components (3 of 4) on page 205
RC1-3565-000	Plate, drum grounding	Internal components (3 of 4) on page 205
RC1-3580-000	Stopper	Internal components (2 of 4) on page 201
RC1-3604-000	Side plate, fixing, right	Fuser assembly on page 215
RC1-3605-000	Side plate, fixing, left	Fuser assembly on page 215
RC1-3606-000	Plate, fixing reinforcement	Fuser assembly on page 215
RC1-3607-000	Guide, fixing, upper	Fuser assembly on page 215
RC1-3611-000	Guide, paper separate, lower	Fuser assembly on page 215
RC1-3613-000	Flag, paper delivery sensor	Fuser assembly on page 215
RC1-3614-000	Spring, torsion	Fuser assembly on page 215
RC1-3615-000	Bushing	Fuser assembly on page 215
RC1-3616-000	Lever, pressure release, right	Fuser assembly on page 215
RC1-3617-000	Lever, pressure release, left	Fuser assembly on page 215
RC1-3618-000	Lever, pressure-release sensor, right	Fuser assembly on page 215
RC1-3619-000	Lever, pressure release sensor, left	Fuser assembly on page 215

Table 8-19 Numerical parts list (continued)

Part number	Description	Table and page
RC1-3622-000	Flag, intertwine prevention	Fuser assembly on page 215
RC1-3623-000	Plate, pressure, right	Fuser assembly on page 215
RC1-3624-000	Plate, pressure, left	Fuser assembly on page 215
RC1-3625-000	Spring, compression	Fuser assembly on page 215
RC1-3627-000	Holder, leaf spring	Fuser assembly on page 215
RC1-3628-000	Ring, conductive rubber	Fuser assembly on page 215
RC1-3633-000	Roller, face-up	Fuser assembly on page 215
RC1-3665-000	Bushing	Internal components (1 of 4) on page 199
RC1-3668-000	Link, gear release	Internal components (1 of 4) on page 199
RC1-3695-000	Sheet, registration damper	Internal components (3 of 4) on page 205
RC1-3698-000	Plate, transfer grounding	Internal components (3 of 4) on page 205
RC1-3700-000	Spring, grounding	Internal components (3 of 4) on page 205
RC1-3702-000	Spring, transfer, right	Internal components (3 of 4) on page 205
RC1-3708-000	Cover, registration gear	Internal components (3 of 4) on page 205
RC1-3719-000	Spring, contact	Internal components (4 of 4) on page 207
RC1-3727-000	Holder, switch	Internal components (2 of 4) on page 201
RC1-3736-000	Spring, compression	Internal components (3 of 4) on page 205
RC1-3794-000	Label, stapler prohibition	Covers on page 195
RC1-3796-000	Label, transfer guide open	Internal components (3 of 4) on page 205
RC1-4198-000	Stopper, claw	Cassette assembly on page 223
RC2-0295-000	Frame, fixing	Fuser assembly on page 215
RC2-0296-000	Guide, fixing entrance	Fuser assembly on page 215
RC2-0297-000	Bushing	Fuser assembly on page 215
RC2-0298-000	Bushing	Fuser assembly on page 215
RC2-0299-000	Needle, fixing static charge	Fuser assembly on page 215
RC2-0300-000	Cover, fixing	Fuser assembly on page 215
RC2-0303-000	Roller, pressure	Fuser assembly on page 215

Table 8-19 Numerical parts list (continued)

Part number	Description	Table and page
RC2-0311-000	Sheet, noise absorb	Covers on page 195
RC2-0312-000	Sheet, noise absorb	Covers on page 195
RC2-0314-000	Sheet, insulator	Covers on page 195
RC2-0316-000	Holder, panel PCB	Covers on page 195
RC2-0323-000	Guide, reverse	Internal components (1 of 4) on page 199
RC2-0330-000	Cover, front	Covers on page 195
RC2-0332-000	Cover, connector	Covers on page 195
RC2-0334-000	Holder, M.P. solenoid	Internal components (4 of 4) on page 207
RC2-0335-000	Guide, M.P. cable	Internal components (4 of 4) on page 207
RC2-0339-000	Guide, cartridge, left lower	Internal components (4 of 4) on page 207
RC2-0340-000	Guide, cartridge font	Internal components (4 of 4) on page 207
RC2-0342-000	Holder contact	Internal components (4 of 4) on page 207
RC2-0344-000	Spring, contact	Internal components (3 of 4) on page 205
RC2-0346-000	Guide, cartridge, right lower	Internal components (2 of 4) on page 201
RC2-0347-000	Shield, duplexing solenoid (HP LJ P2015d, P2015dn, and P2015x)	Internal components (2 of 4) on page 201
RC2-0349-000	Holder, fan	Internal components (2 of 4) on page 201
RC2-0350-000	Rod, grounding	Internal components (2 of 4) on page 201
RC2-0351-000	Duct	Internal components (2 of 4) on page 201
RC2-0354-000	Duct	Internal components (2 of 4) on page 201
RC2-0356-000	Bushing	Internal components (3 of 4) on page 205
RC2-0357-000	Bushing	Internal components (3 of 4) on page 205
RC2-0358-000	Eliminator, static charge	Internal components (3 of 4) on page 205
RC2-0359-000	Guide, transfer front	Internal components (3 of 4) on page 205
RC2-0384-000	Plate, registration grounding	Internal components (3 of 4) on page 205

Table 8-19 Numerical parts list (continued)

Part number	Description	Table and page
RC2-0386-000	Holder, paper pick-up roller	Internal components (4 of 4) on page 207
RC2-0387-000	Cam, M.P., left	Internal components (4 of 4) on page 207
RC2-0388-000	Cam, M.P., right	Internal components (4 of 4) on page 207
RC2-0392-000	Arm, tag	Internal components (2 of 4) on page 201
RC2-0396-000	Holder, drawer connector	Internal components (2 of 4) on page 201
RC2-0397-000	Guide, cable	Internal components (2 of 4) on page 201
RC2-0405-000	Arm, cam	Internal components (2 of 4) on page 201
RC2-0406-000	Arm, link	Internal components (2 of 4) on page 201
RC2-0410-000	Cam	Internal components (2 of 4) on page 201
RC2-0414-000	Holder, M.P. sensor	Internal components (1 of 4) on page 199
RC2-0415-000	Flag, M.P. sensor	Internal components (1 of 4) on page 199
RC2-0416-000	Guide, cassette, right rear	Internal components (2 of 4) on page 201
RC2-0419-000	Base, separation pad	Internal components (1 of 4) on page 199
RC2-0420-000	Cover, paper pick-up roller	Internal components (4 of 4) on page 207
RC2-0421-000	Hinge, multipurpose, left	Cartridge-door assembly on page 197
RC2-0422-000	Hinge, multipurpose, right	Cartridge-door assembly on page 197
RC2-0423-000	Guide, F.F.C	Internal components (4 of 4) on page 207
RC2-0424-000	Guide, F.F.C	Internal components (4 of 4) on page 207
RC2-0425-000	Guide, cartridge, left upper	Internal components (4 of 4) on page 207
RC2-0426-000	Guide, cartridge, right upper	Internal components (2 of 4) on page 201
RC2-0427-000	Spring, torsion	Internal components (4 of 4) on page 207
RC2-0428-000	Guide, shutter, front	Internal components (2 of 4) on page 201

Table 8-19 Numerical parts list (continued)

Part number	Description	Table and page
RC2-0429-000	Holder, separate lower guide	Fuser assembly on page 215
RC2-0431-000	Sheet, fixing bottom	Fuser assembly on page 215
RC2-1568-000	Plate, grounding	Internal components (2 of 4) on page 201
RC2-1569-000	Guide, cable	Internal components (1 of 4) on page 199
RC2-1578-000	Sheet, plate bottom	Internal components (4 of 4) on page 207
RK2-0420-000	Solenoid (HP LJ P2015d, P2015dn, and P2015x)	Internal components (2 of 4) on page 201
RK2-0424-000	Solenoid (HP LJ P2015)	Internal components (2 of 4) on page 201
RK2-0534-000	Microswitch	Internal components (4 of 4) on page 207
RK2-1567-000	Motor, DC	Internal components (2 of 4) on page 201
RK2-1587-000	Solenoid	Internal components (4 of 4) on page 207
RK2-1589-000	Fan	Internal components (2 of 4) on page 201
RL1-0517-000	Guide, cassette, right front	Internal components (2 of 4) on page 201
RL1-0518-000	Guide, cassette, left front	Internal components (4 of 4) on page 207
RL1-0522-000	Plate, lifter	Cassette assembly on page 223
RL1-0527-000	Roller, face-down	Internal components (1 of 4) on page 199
RL1-0540-000	Roller, paper pick-up	Internal components (1 of 4) on page 199
RL1-1524-000	Pad, M.P. separation	Internal components (1 of 4) on page 199
RL1-1525-000	Roller, M.P. paper pick-up	Internal components (4 of 4) on page 207
RL1-1529-000	Left cover assembly	Covers on page 195
RL1-1530-000	Right cover assembly	Covers on page 195
RL1-1531-000	Side plate, M.P. drive	Internal components (4 of 4) on page 207
RM1-1251-000	Delivery sensor PCB assembly	Fuser assembly on page 215
RM1-1262-000	Duplex driver PCB assembly (HP LJ P2015d, P2015dn, and P2015x)	Internal components (2 of 4) on page 201
RM1-1262-000	Duplex driver PCB assembly (HP LJ P2015d, P2015dn, and P2015x)	PCB assembly locations on page 227

Table 8-19 Numerical parts list (continued)

Part number	Description	Table and page
RM1-1283-000	Top sensor assembly	Internal components (3 of 4) on page 205
RM1-1291-000	Delivery frame assembly	Fuser assembly on page 215
RM1-1295-000	Back end limit assembly	Cassette assembly on page 223
RM1-1296-000	Left paper side-end assembly	Cassette assembly on page 223
RM1-1297-020	Right paper side-end assembly	Cassette assembly on page 223
RM1-1298-000	Separation pad assembly	Cassette assembly on page 223
RM1-1301-000	Paper pick-up gear assembly	Internal components (1 of 4) on page 199
RM1-1305-000	Face-down gear assembly	Assembly locations (1 of 2) on page 191
RM1-1305-000	Face-down gear assembly	Face-down gear assembly on page 221
RM1-1321-000	Shutter link assembly	Internal components (3 of 4) on page 205
RM1-4159-000	Paper-sensor PCB assembly	Internal components (3 of 4) on page 205
RM1-4162-000	M.P. sensor PCB assembly	Internal components (1 of 4) on page 199
RM1-4163-000	Cable, memory tag	Internal components (2 of 4) on page 201
RM1-4169-000	Inlet/switch cable assembly	Internal components (2 of 4) on page 201
RM1-4244-000	Registration assembly	Assembly locations (1 of 2) on page 191
RM1-4244-000	Registration assembly	Internal components (3 of 4) on page 205
RM1-4245-000	Paper-width sensor assembly	Internal components (3 of 4) on page 205
RM1-4247-000	Fuser assembly (110 V)	Assembly locations (2 of 2) on page 193
RM1-4247-000	Fuser assembly (110 V)	Fuser assembly on page 215
RM1-4248-000	Fuser assembly (220 V)	Assembly locations (2 of 2) on page 193
RM1-4248-000	Fuser assembly (220 V)	Fuser assembly on page 215
RM1-4249-000	Film guide assembly (110 V)	Fuser assembly on page 215
RM1-4250-000	Film guide assembly (220 V)	Fuser assembly on page 215
RM1-4251-000	Cassette	Assembly locations (1 of 2) on page 191

Table 8-19 Numerical parts list (continued)

Part number	Description	Table and page
RM1-4251-000	Cassette	Cassette assembly on page 223
RM1-4252-000	Cassette cover assembly	Cassette assembly on page 223
RM1-4253-000	Main drive assembly	Assembly locations (1 of 2) on page 191
RM1-4253-000	Main drive assembly	Main drive assembly on page 213
RM1-4255-000	Duplex-drive assembly	Assembly locations (2 of 2) on page 193
RM1-4255-000	Duplexing drive assembly (HP LJ P2015d, P2015dn, and P2015x)	Duplexing drive assembly on page 219
RM1-4256-000	Normal-rotation drive assembly (HP LJ P2015d, P2015dn, and P2015x)	Duplexing drive assembly on page 219
RM1-4257-000	Reverse-rotation drive assembly (HP LJ P2015d, P2015dn, and P2015x)	Duplexing drive assembly on page 219
RM1-4258-000	Duplexing assembly (HP LJ P2015d, P2015dn, and P2015x)	Assembly locations (2 of 2) on page 193
RM1-4258-000	Duplexing assembly (HP LJ P2015d, P2015dn, and P2015x)	Duplexing assembly on page 225
RM1-4262-000	Scanner assembly	Internal components (2 of 4) on page 201
RM1-4263-000	Paper-feed guide assembly	Internal components (1 of 4) on page 199
RM1-4265-000	Paper-retaining assembly (HP LJ P2015d, P2015dn, and P2015x)	Internal components (1 of 4) on page 199
RM1-4266-000	Cartridge-door assembly	Cartridge-door assembly on page 197
RM1-4267-000	Inner cover assembly	Cartridge-door assembly on page 197
RM1-4268-000	M.P. lifting-plate assembly	Cartridge-door assembly on page 197
RM1-4269-000	Expansion-tray assembly	Cartridge-door assembly on page 197
RM1-4270-000	Rear cover assembly (HP LJ P2015d, P2015dn, and P2015x)	Covers on page 195
RM1-4272-000	Top cover assembly	Covers on page 195
RM1-4273-000	ECU assembly (110 V)	Assembly locations (2 of 2) on page 193
RM1-4273-000	ECU assembly (220 V)	Assembly locations (2 of 2) on page 193
RM1-4273-000	ECU assembly (110 V)	ECU assembly on page 211
RM1-4273-000	ECU assembly (110 V)	PCB assembly locations on page 227

Table 8-19 Numerical parts list (continued)

Part number	Description	Table and page
RM1-4274-000	ECU assembly (220 V)	ECU assembly on page 211
RM1-4274-000	ECU assembly (220 V)	PCB assembly locations on page 227
RM1-4275-000	Paper pick-up gear assembly	Internal components (4 of 4) on page 207
RM1-4276-000	Paper retaining assembly (HP LJ P2015)	Internal components (1 of 4) on page 199
RM1-4277-000	Rear cover assembly (HP LJ P2015)	Covers on page 195
RM1-4279-000	Roller, transfer	Internal components (3 of 4) on page 205
RM2-0407-000	Cover, multipurpose	Cartridge-door assembly on page 197
RU5-0320-000	Gear, 33T	Internal components (3 of 4) on page 205
RU5-0328-000	Gear, 10T	Cassette assembly on page 223
RU5-0330-000	Gear, 17T	Fuser assembly on page 215
RU5-0331-000	Gear, 29T	Internal components (1 of 4) on page 199
RU5-0332-000	Gear, 19T	Internal components (1 of 4) on page 199
RU5-0927-000	Gear, 19T	Internal components (4 of 4) on page 207
RU5-0928-000	Gear, 26T	Internal components (4 of 4) on page 207
RU5-0929-000	Gear, 14T	Internal components (4 of 4) on page 207
RU5-2144-000	Spring, compression	Internal components (3 of 4) on page 205
RU5-2323-000	Spring, compression	Internal components (1 of 4) on page 199
RU5-2324-000	Spring, tension	Cassette assembly on page 223
RU5-2327-000	Spring, compression	Cassette assembly on page 223
RU5-2335-000	Spring, compression	Internal components (2 of 4) on page 201
RU5-2337-000	Spring, compression	Internal components (4 of 4) on page 207
RU5-2338-000	Spring, compression	Internal components (3 of 4) on page 205
RU5-2894-000	Spring compression	Internal components (1 of 4) on page 199

Table 8-19 Numerical parts list (continued)

Part number	Description	Table and page
RU5-2895-000	Spring, tension	Cartridge-door assembly on page 197
RU5-2898-000	Spring, tension	Internal components (1 of 4) on page 199
RU5-2901-000	Spring, compression	Fuser assembly on page 215
VS1-7258-007	Connector, drawer	Internal components (2 of 4) on page 201
XA9-1420-000	Screw, with washer, M3x8	Internal components (3 of 4) on page 205
XA9-1422-000	Screw, with washer, M4x12	Internal components (3 of 4) on page 205
XA9-1422-000	Screw, with washer, M4x12	Fuser assembly on page 215
XA9-1495-000	Screw, RS, M3x6	Internal components (1 of 4) on page 199
XA9-1495-000	Screw, RS, M3x6 (HP LJ P2015d, P2015dn, and P2015x)	Internal components (2 of 4) on page 201
XA9-1495-000	Screw, RS, M3x6 (HP LJ P2015)	Internal components (2 of 4) on page 201
XA9-1495-000	Screw, RS, M3x6	Internal components (4 of 4) on page 207
XA9-1503-000	Screw, tap, M3x6	Internal components (1 of 4) on page 199
XA9-1503-000	Screw, tap, M3x6	Internal components (2 of 4) on page 201
XA9-1503-000	Screw, tap, M3x6	Fuser assembly on page 215
XA9-1504-000	Screw, RS, M3x8	Internal components (1 of 4) on page 199
XA9-1504-000	Screw, RS, M3x8	Internal components (2 of 4) on page 201
XA9-1504-000	Screw, RS, M3x8	Internal components (3 of 4) on page 205
XA9-1504-000	Screw, RS, M3x8	Internal components (4 of 4) on page 207
XA9-1561-000	Screw, RS, M3x6	Internal components (2 of 4) on page 201
XA9-1648-000	Screw, tap, M3x8	Internal components (2 of 4) on page 201
XB2-7400-606	Screw, toothed washer, M4x6	Internal components (2 of 4) on page 201
XB4-7300-809	Screw, tap, binding head, M3x8	Covers on page 195
XB4-7300-809	Screw, tap, binding head, M3x8	Internal components (1 of 4) on page 199

Table 8-19 Numerical parts list (continued)

Part number	Description	Table and page
XB4-7300-809	Screw, tap, binding head, M3x8	Internal components (2 of 4) on page 201
XB4-7300-809	Screw, tap, binding head, M3x8	Internal components (3 of 4) on page 205
XB4-7300-809	Screw, tap, binding head, M3x8	Fuser assembly on page 215
XB4-7401-005	Screw, tapping, truss head, M4x10	Internal components (1 of 4) on page 199
XB4-7401-005	Screw, tapping, truss head, M4x10	Internal components (3 of 4) on page 205
XB4-7401-005	Screw, M4x10	Cassette assembly on page 223

A Accessory/Consumable addendum

This appendix provides information on the following topics:

- [Consumables and accessories](#)
- [10/100 networking print servers](#)
- [HP print cartridges](#)
- [DIMMs \(memory or font\)](#)

Consumables and accessories

Product name	Description	Part number
Print cartridge	3,000-page print cartridge	Q7553A
Print cartridge	7,000-page print cartridge	Q7553X
Pickup roller	Tray 1 pickup roller	CB366-67901
Pickup roller	Tray 2 pickup roller	CB366-67902
Separation pad	Separation pad for 250-sheet feeder	RM1-1298-000CN
250-sheet paper tray	Optional tray 3	Q5931A
<i>HP LaserJet Family Print Media Guide</i>		http://www.hp.com/support/ljpaperguide

10/100 networking print servers

Table A-1 HP LaserJet P2015 Series printer

Item and description	Order number
HP Jetdirect en3700 fast Ethernet print server	J7942A
HP Jetdirect en2400 802.11g wireless external print server (full featured, USB port)	J7951A

HP print cartridges

HP policy on non-HP print cartridges

Hewlett-Packard Company cannot recommend the use of non-HP print cartridges, either new, refilled, or remanufactured. Since they are not HP products, Hewlett-Packard cannot influence their design or control their quality. Service or repair that is required as a result of using non-HP print cartridges will not be covered under the printer warranty.



NOTE The warranty does not apply to defects resulting from software, interfacing, or parts not supplied by Hewlett-Packard.

Storing print cartridges

Do not remove the print cartridge from its package until you are ready to use it, and minimize exposure to light.

Print cartridge life expectancy

The average cartridge yield is 3000 pages in accordance with ISO/IEC 19752. A replacement cartridge that has an average yield of 7000 pages in accordance with ISO/IEC 19752 is also available. Actual cartridge yield depends on specific use.

Saving toner

EconoMode is a feature that allows the printer to use less toner per page. Selecting this option may extend the life of the print cartridge and reduce cost per page. However, it will also reduce print quality. The printed image is lighter, but it is adequate for printing drafts or proofs. HP does not recommend full-time use of EconoMode. If EconoMode is used full-time, it is possible that the toner supply will outlast the mechanical parts in the toner cartridge. If print quality begins to degrade under these circumstances, you will need to install a new toner cartridge, even if there is toner supply remaining in the cartridge.

DIMMs (memory or font)


The following sections provide instructions for installing, testing, and removing DIMMs.

Install a DIMM


To install a DIMM, follow the instructions below:

CAUTION Handling a DIMM (memory) without wearing a grounded, antistatic device might damage the DIMM. Touch any metal part of the printer or other grounded metal before touching the DIMM.


1. Use the power switch to turn off the printer, and then unplug all of the cables and cords connected to the printer.





2. Open the DIMM door.




3. Remove the DIMM from the antistatic bag it came in, grasping the DIMM on the top edge.



4. With the gold contacts facing upward, insert the DIMM in the DIMM seat and press the DIMM body in until the metal retaining pins click.



5. Close the DIMM door.



6. Reconnect all printer cables and cords, and then use the power switch to turn on the printer.

Test the DIMM installation

To test the DIMM installation, print a configuration page, and check the Total Memory specified on the page.

If all lights on the control panel are blinking, the DIMM installation was unsuccessful. Remove the DIMM and reinstall it.


Remove a DIMM

To remove a DIMM, follow the instructions below:




CAUTION Handling a DIMM (memory) without wearing a grounded, antistatic device might damage the DIMM. Touch any metal part of the printer or other grounded metal before touching the DIMM.


1. Use the power switch to turn off the printer, and then unplug all of the cables and cords connected to the printer.




2. Open the DIMM door.



3. Unlock the DIMM retaining pins by pressing them outward.




4. Grasp the DIMM on the bottom edge, and then remove the DIMM from the printer.



NOTE Store the DIMM in an antistatic bag.

5. Close the DIMM door.



6. Reconnect all printer cables and cords, and then use the power switch to turn on the printer.

B Service and support

This appendix provides information on the following topics:

- [Hardware service](#)
- [Extended warranty](#)
- [Guidelines for repacking the printer](#)
- [How to contact HP](#)

Hardware service

If your hardware fails during the warranty period, Hewlett-Packard offers the following support options:

- **Hewlett-Packard repair services:** Hewlett-Packard will arrange to pick up the unit, repair it, and return it to you within 5 to 10 business days, depending on your location.
- **Hewlett-Packard authorized service provider:** You can return the unit to a local authorized service dealer.

Extended warranty

HP Care Pack provides coverage for the HP product and all HP-supplied internal components. The hardware maintenance covers a three-year period from the date of the HP product purchase. The customer may purchase an HP Care Pack up to one year from the date of purchase of the HP product. For more information, contact the HP Customer Care Service and Support group.

HP Care Pack options might be available after the standard warranty period has expired. Go to <http://www.hpexpress-services.com/10467a/> and enter the product number to identify the HP Care Pack options that are available for your product.

Guidelines for repacking the printer

Use the following guidelines when repacking the printer:

- If possible, include print samples and 5 to 10 sheets of paper or other media that did not print correctly.
- Remove and keep any DIMMs (memory) installed in the printer.



CAUTION Static electricity can damage DIMMs. When handling DIMMs, wear a grounded, antistatic wrist strap.

- Remove and keep any cables, trays, and optional accessories installed in the printer.
- Remove and keep the print cartridge.



CAUTION To prevent damage to the print cartridge, store the print cartridge in its original packing material, or store it so that it is not exposed to light.

- If possible, use the original shipping container and packing material. *Shipping damage as a result of inadequate packing is your responsibility.* If you have already disposed of the printer's packing material, contact a local mailing service for information on repacking the printer.
- Hewlett-Packard recommends that you insure the equipment for shipment.

How to contact HP

If you need to contact HP for service or support, use one of the following links:

- In the United States, go to <http://www.hp.com/support/ljP2015/>.
- Worldwide, go to <http://www.hp.com/>.

C Printer specifications

This appendix provides information on the following topics:

- [Environmental specifications](#)
- [Acoustic emissions](#)
- [Electrical specifications](#)
- [Physical specifications](#)
- [Printer capacities and ratings](#)
- [Memory specifications](#)
- [Port availability](#)

Environmental specifications

Operating environment	Printer plugged into an AC outlet: <ul style="list-style-type: none">• Temperature: 10° C to 32.5° C (50° F to 90.5° F)• Humidity: 20 to 80 percent (no condensation)
Storage environment	Printer unplugged from an AC outlet: <ul style="list-style-type: none">• Temperature: 0° C to 40° C (32° F to 104° F)• Humidity: 10 to 80 percent (no condensation)



NOTE Values are based on preliminary data. See <http://www.hp.com/support/ljP2015> for current information.

Acoustic emissions

Declared per ISO 9296

Table C-1 HP LaserJet P2015 printer

Sound power level	Printing (27 ppm): $L_{WA,d} = 6.4$ Bels A and 62 dB (A) Ready (Sleep): Inaudible
Sound pressure level bystander position	Printing (27 ppm): $L_{pA,m} = 50$ dB (A) Ready (Sleep): Inaudible



NOTE Values are based on preliminary data. See <http://www.hp.com/support/ljP2015> for current information.

NOTE Configuration tested: HP LaserJet P2015 base base unit, 26 ppm, standard tray, A4 paper, and simplex continuous print.

Electrical specifications



WARNING! Power requirements are based on the country/region where the printer is sold. Do not convert operating voltages. Doing so might damage the printer and void the product warranty.

Table C-2 HP LaserJet P2015 printer

Power requirements (110)	110-127 V (+/-10%), 50/60 Hz (+/-2)
Power requirements (220)	220 V - 240 V (+/-10%), 50/60 Hz (+/-2 Hz)
Power consumption	<ul style="list-style-type: none">• During printing (27 ppm): 350 watts (average)• During Ready (Standby) and Sleep*: 7 Watts• * Instant-on fuser technology• Off: <0.1 watts
Rated current	<ul style="list-style-type: none">• 4.9 amps at 115 volts• 2.9 amps at 230 volts

Table C-3 HP LaserJet P2015d printer, HP LaserJet P2015n printer, HP LaserJet P2015x printer

Power requirements (110)	110-127 V (+/-10%), 50/60 Hz (+/-2)
Power requirements (220)	220 V - 240 V (+/-10%), 50/60 Hz (+/-2 Hz)
Power consumption	<ul style="list-style-type: none">• During printing (27 ppm): 350 watts (average)• During Ready (Standby) and Sleep*: 7 Watts• * Instant-on fuser technology• Off: <0.1 watts
Rated current	<ul style="list-style-type: none">• 4.9 amps at 115 volts• 2.9 amps at 230 volts

Table C-4 HP LaserJet P2015dn printer

Power requirements (110)	110-127 V (+/-10%), 50/60 Hz (+/-2)
Power requirements (220)	220 V - 240 V (+/-10%), 50/60 Hz (+/-2 Hz)
Power consumption	<ul style="list-style-type: none">• During printing (27 ppm): 350 watts (average)• During Ready (Standby) and Sleep*: 7 Watts <p>* Instant-on fuser technology</p> <ul style="list-style-type: none">• Off: <0.1 watts
Rated current	<ul style="list-style-type: none">• 4.9 amps at 115 volts• 2.9 amps at 230 volts



NOTE Values are based on preliminary data. See <http://www.hp.com/support/ljP2015> for current information.

NOTE The power reported is the highest value measured for monochrome printing using all standard voltages.

NOTE The default time from Ready mode to Sleep mode and the recovery time from Sleep mode to the start of printing is less than 10 seconds because of the instant-on fusing.

NOTE The heat dissipation in Ready mode is 25 BTU/hour.

Physical specifications

Dimensions

- Width: 350 mm (16.8 inches)
- Depth: 361 mm (14.2 inches)
- Height: 256 mm (10.0 inches)

Weight (3,000-page cartridge installed)

HP LaserJet P2015 printer: 10.7 kg (23.6 lb)



NOTE Values are based on preliminary data. See <http://www.hp.com/support/ljP2015> for current information.

Printer capacities and ratings

Print speed	HP LaserJet P2015 printer: <ul style="list-style-type: none">• 27 ppm (letter), 26 ppm (A4)• First page out in as few as 8.5 seconds
Tray 2 capacity	250 sheets of regular weight 75 g/m ² (20 lb) paper
Tray 1 capacity	50 sheets of regular weight 75 g/m ² ((20 lb)) paper
Optional input tray (tray 3) capacity	250 sheets of regular weight 75 g/m ² (20 lb) paper
Top (face down) output bin capacity	125 sheets of regular weight 75 g/m ² (20 lb) paper
Minimum paper size	76 by 127 mm (3 by 5 inches)
Maximum paper size	216 by 356 mm (8.5 by 14 inches)
Media weight	Output bin: 60 to 105 g/m ² (16 to 28 lbs) Straight through media path: 60 to 163 g/m ² (16 to 43 lbs)
Base memory	32 MB RAM
Upgrade memory expansion	One DIMM slot available for a 32, 64, 128, or 256 MB RAM DIMM
Print resolution	<ul style="list-style-type: none">• 1200 dpi: This setting uses ProRes 1200 to provide fine-line detail at 1200 x 1200 dpi.• 1200 effective dpi: This setting provides 1200 dpi effective output quality using FastRes 1200.• 600 dpi: This setting provides 600 x 600 dpi output with Resolution Enhancement technology (REt) for improved text.
Duty cycle	<ul style="list-style-type: none">• 10,000 single-sided pages per month (maximum)• 1,000 single-sided pages per month (average)
PCL	PCL 5e, PCL 6
Postscript emulation	HP postscript level 3 emulation

Memory specifications

Base memory	32 MB RAM
Upgrade memory expansion	100-pin, 66 MHz minimum speed

Port availability

USB	Compatible with High-speed USB 2.0 specifications
Network	RJ-45, Ethernet 10/100
(networking-equipped models only)	

D Regulatory information

FCC compliance

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy. If it is not installed and used in accordance with the instructions, it may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase separation between equipment and receiver.
- Connect equipment to an outlet on a circuit different from that to which the receiver is located.
- Consult your dealer or an experienced radio/TV technician.



NOTE Any changes or modifications to the printer that are not expressly approved by Hewlett-Packard could void the user's authority to operate this equipment.

Use of a shielded interface cable is required to comply with the Class B limits of Part 15 of FCC rules.

Declaration of Conformity statements

Declaration of Conformity

according to ISO/IEC Guide 22 and EN 45014

Manufacturer's Name: Hewlett-Packard Company
Manufacturer's Address: 11311 Chinden Boulevard,
Boise, Idaho 83714-1021, USA

declares that the product

Product Name: HP LaserJet P2015 Series
Regulatory Model ³⁾: BOISB-0602-00

Product Options: Including: Q5931A — Optional 250-Sheet Input Tray
ALL

Toner Cartridges: Q7553A / Q7553X

conforms to the following Product Specifications:

Safety: IEC 60950-1:2001 / EN 60950-1:2001 +A11
IEC 60825-1:1993 +A1 +A2/EN 60825-1:1994 +A1 +A2 Class 1 Laser/LED Product)
GB4943-2001

EMC: CISPR 22:1993 +A1 +A2/ EN 55022:1994 Class B¹⁾
EN 61000-3-2:2000
EN 61000-3-3:1995 / A1
EN 55024:1998 +A1 +A2
FCC Title 47 CFR, Part 15 Class B²⁾ / ICES-003, Issue 4
GB9254-1998, GB17625.1-2003

Supplementary Information:

The product herewith complies with the requirements of the EMC Directive 89/336/EEC and the Low Voltage Directive 73/23/EEC, and carries the CE-marking accordingly.

1) The product was tested in a typical configuration with Hewlett-Packard Personal Computer Systems.

2) This Device complies with Part 15 of the FCC Rules. Operation is subject to the following two Conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

3) For regulatory purposes, this product is assigned a Regulatory model number. This number should not be confused with the product name or the product number(s).

Boise, Idaho 83714, USA

September 1, 2006

For Regulatory Topics ONLY, contact:

Australia Contact: Product Regulations Manager, Hewlett-Packard Australia Ltd., 31-41 Joseph Street, Blackburn, Victoria 3130, Australia

European Contact: Your Local Hewlett-Packard Sales and Service Office or Hewlett-Packard GmbH, Department HQ-TRE / Standards Europe, Herrenberger Straße 140, Böblingen, D-71034, Germany, (FAX: +49-7031-14-3143)

USA Contact: Product Regulations Manager, Hewlett-Packard Company, PO Box 15, Mail Stop 160, Boise, Idaho 83707-0015, USA, (Phone: 208-396-6000)

Regulatory statements

Laser safety statement

The Center for Devices and Radiological Health (CDRH) of the U.S. Food and Drug Administration has implemented regulations for laser products manufactured since August 1, 1976. Compliance is mandatory for products marketed in the United States. The printer is certified as a "Class 1" laser product under the U.S. Department of Health and Human Services (DHHS) Radiation Performance Standard according to the Radiation Control for Health and Safety Act of 1968.

Since radiation emitted inside the printer is completely confined within protective housings and external covers, the laser beam cannot escape during any phase of normal user operation.



WARNING! Using controls, making adjustments, or performing procedures other than those specified in this user guide could result in exposure to hazardous radiation.

Canadian DOC regulations

Complies with Canadian EMC Class B requirements.

« Conforme à la classe B des normes canadiennes de compatibilité électromagnétiques (CEM). »

Korean EMI statement

사용자 안내문 (A급 기기)

이 기기는 업무용으로 전자파장애감정을 받은
기기이오니, 만약 잘못 구입하셨을 때에는 구입
한 곳에서 비업무용으로 교환하시기 바랍니다.

Laser statement for Finland

LASERTURVALLISUUS

LUOKAN 1 LASERLAITE

KLASS 1 LASER APPARAT

HP LaserJet P2015, HP LaserJet P2015d, HP LaserJet P2015n, HP LaserJet P2015x, HP LaserJet P2015dn -laserkirjoitin on käyttäjän kannalta turvallinen luokan 1 laserlaite. Normaalisissa käytössä kirjoittimen suojakotelointi estää lasersäteen pääsyn laitteen ulkopuolelle.

Laitteen turvallisuusluokka on määritetty standardin EN 60825-1 (1994) mukaisesti.

VAROITUS!

Laitteen käyttäminen muulla kuin käyttöohjeessa mainitulla tavalla saattaa altistaa käyttäjän turvallisuusluokan 1 ylittävälle näkymättömälle lasersäteilylle.

VARNING!

Om apparaten används på annat sätt än i bruksanvisning specificerats, kan användaren utsättas för osynlig laserstrålning, som överskrider gränsen för laserklass 1.

HUOLTO

HP LaserJet P2015, HP LaserJet P2015d, HP LaserJet P2015n, HP LaserJet P2015x, HP LaserJet P2015dn -kirjoittimen sisällä ei ole käyttäjän huollettavissa olevia kohteita. Laitteen saa avata ja huoltaa ainoastaan sen huoltamiseen koulutettu henkilö. Tällaiseksi huoltotoimenpiteeksi ei katsota väriainekasetin vaihtamista, paperiradan puhdistusta tai muita käyttäjän käsikirjassa lueteltuja, käyttäjän tehtäväksi tarkoitettuja ylläpitotoimia, jotka voidaan suorittaa ilman erikoistyökaluja.

VARO!

Mikäli kirjoittimen suojakotelo avataan, olet alttiina näkymättömälle lasersäteilylle laitteen ollessa toiminnassa. Älä katso säteeseen.

VARNING!

Om laserprinterns skyddshölje öppnas då apparaten är i funktion, utsätts användaren för osynlig laserstrålning. Betrakta ej strålen.

Tiedot laitteessa käytettävän laserdiodin säteilyominaisuuksista:

Aallonpituus 785-800 nm

Teho 5 mW

Luokan 3B laser

E Warranty and licensing

Hewlett-Packard limited warranty statement

HP PRODUCT

HP LaserJet P2015 Series printers

DURATION OF LIMITED WARRANTY

One year from date of purchase

HP warrants to you, the end-user customer, that HP hardware and accessories will be free from defects in materials and workmanship after the date of purchase, for the period specified above. If HP receives notice of such defects during the warranty period, HP will, at its option, either repair or replace products which prove to be defective. Replacement products may be either new or equivalent in performance to new.

HP warrants to you that HP software will not fail to execute its programming instructions after the date of purchase, for the period specified above, due to defects in material and workmanship when properly installed and used. If HP receives notice of such defects during the warranty period, HP will replace software which does not execute its programming instructions due to such defects.

HP does not warrant that the operation of HP products will be uninterrupted or error free. If HP is unable, within a reasonable time, to repair or replace any product to a condition as warranted, you will be entitled to a refund of the purchase price upon prompt return of the product.

HP products may contain remanufactured parts equivalent to new in performance or may have been subject to incidental use.

Warranty does not apply to defects resulting from (a) improper or inadequate maintenance or calibration, (b) software, interfacing, parts or supplies not supplied by HP, (c) unauthorized modification or misuse, (d) operation outside of the published environmental specifications for the product, or (e) improper site preparation or maintenance.

HP's limited warranty is valid in any country/region or locality where HP has a support presence for this product and where HP has marketed this product. The level of warranty service you receive may vary according to local standards. HP will not alter form, fit or function of the product to make it operate in a country/region for which it was never intended to function for legal or regulatory reasons. TO THE EXTENT ALLOWED BY LOCAL LAW, THE ABOVE WARRANTIES ARE EXCLUSIVE AND NO OTHER WARRANTY OR CONDITION, WHETHER WRITTEN OR ORAL, IS EXPRESSED OR IMPLIED AND HP SPECIFICALLY DISCLAIMS ANY IMPLIED WARRANTIES OR CONDITIONS OF MERCHANTABILITY, SATISFACTORY QUALITY, AND FITNESS FOR A PARTICULAR PURPOSE. Some countries/regions, states or provinces do not allow limitations on the duration of an implied warranty, so the above limitation or exclusion might not apply to you. This warranty gives you specific legal rights and you might also have other rights that vary from country/region to country/region, state to state, or province to province.

TO THE EXTENT ALLOWED BY LOCAL LAW, THE REMEDIES IN THIS WARRANTY STATEMENT ARE YOUR SOLE AND EXCLUSIVE REMEDIES. EXCEPT AS INDICATED ABOVE, IN NO EVENT WILL HP OR ITS SUPPLIERS BE LIABLE FOR LOSS OF DATA OR FOR DIRECT, SPECIAL, INCIDENTAL, CONSEQUENTIAL (INCLUDING LOST PROFIT OR DATA), OR OTHER DAMAGE, WHETHER BASED IN CONTRACT, TORT, OR OTHERWISE. Some countries/regions, states or provinces do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you.

THE WARRANTY TERMS CONTAINED IN THIS STATEMENT, EXCEPT TO THE EXTENT LAWFULLY PERMITTED, DO NOT EXCLUDE, RESTRICT OR MODIFY AND ARE IN ADDITION TO THE MANDATORY STATUTORY RIGHTS APPLICABLE TO THE SALE OF THIS PRODUCT TO YOU.

Hewlett-Packard software license agreement

ATTENTION: USE OF THE SOFTWARE IS SUBJECT TO THE HP SOFTWARE LICENSE TERMS SET FORTH BELOW. USING THE SOFTWARE INDICATES YOUR ACCEPTANCE OF THESE LICENSE TERMS.

HP SOFTWARE LICENSE TERMS

The following License Terms govern your use of the accompanying Software unless you have a separate signed agreement with Hewlett-Packard.

License Grant. Hewlett-Packard grants you a license to use one copy of the Software. "Use" means storing, loading, installing, executing, or displaying the Software. You may not modify the Software or disable any licensing or control features of the Software. If the Software is licensed for "concurrent use," you may not allow more than the maximum number of authorized users to Use the Software concurrently.

Ownership. The Software is owned and copyrighted by Hewlett-Packard or its third-party suppliers. Your license confers no title to, or ownership in, the Software and is not a sale of any rights in the Software. Hewlett-Packard's third-party suppliers may protect their rights in the event of any violation of these License Terms.

Copies and Adaptations. You may only make copies or adaptations of the Software for archival purposes or when copying or adaptation is an essential step in the authorized Use of the Software. You must reproduce all copyright notices in the original Software on all copies or adaptations. You may not copy the Software onto any public network.

No Disassembly or Decryption. You may not disassemble or decompile the Software unless HP's prior written consent is obtained. In some jurisdictions, HP's consent may not be required for limited disassembly or decompilation. Upon request, you will provide HP with reasonably detailed information regarding any disassembly or decompilation. You may not decrypt the Software unless decryption is a necessary part of the operation of the Software.

Transfer. Your license will automatically terminate upon any transfer of the Software. Upon transfer, you must deliver the Software, including any copies and related documentation, to the transferee. The transferee must accept these License Terms as a condition to the transfer.

Termination. HP may terminate your license upon notice for failure to comply with any of these License Terms. Upon termination, you must immediately destroy the Software, together with all copies, adaptations, and merged portions in any form.

Export Requirements. You may not export or re-export the Software or any copy or adaptation in violation of any applicable laws or regulations.

U.S. Government Restricted Rights. The Software and any accompanying documentation have been developed entirely at private expense. They are delivered and licensed as "commercial computer software" as defined in DFARS 252.227-7013 (Oct 1988), DFARS 252.211-7015 (May 1991), or DFARS 252.227-7014 (Jun 1995), as a "commercial item" as defined in FAR 2.101(a) (Jun 1987), or as "Restricted computer software" as defined in FAR 52.227-19 (Jun 1987) (or any equivalent agency regulation or contract clause), whichever is applicable. You have only those rights provided for such Software and any accompanying documentation by the applicable DFARS or FAR clause or the HP standard software agreement for the product involved.



Limited warranty for print cartridge



NOTE The following warranty applies to the print cartridge that came with this printer.

This HP product is warranted to be free from defects in materials and workmanship. This warranty does not apply to products that (a) have been refilled, refurbished, remanufactured or tampered with in any way, (b) experience problems resulting from misuse, improper storage, or operation outside of the published environmental specifications for the printer product or (c) exhibit wear from ordinary use. To obtain warranty service, please return the product to place of purchase (with a written description of the problem and the print samples) or contact HP customer support. At HP's option, HP will either replace products that prove to be defective or refund your purchase price. TO THE EXTENT ALLOWED BY LOCAL LAW, THE ABOVE WARRANTY IS EXCLUSIVE AND NO OTHER WARRANTY OR CONDITION, WHETHER WRITTEN OR ORAL, IS EXPRESSED OR IMPLIED AND HP SPECIFICALLY DISCLAIMS ANY IMPLIED WARRANTIES OR CONDITIONS OF MERCHANTABILITY, SATISFACTORY QUALITY, AND FITNESS FOR A PARTICULAR PURPOSE. TO THE EXTENT ALLOWED BY LOCAL LAW, IN NO EVENT WILL HP OR ITS SUPPLIERS BE LIABLE FOR DIRECT, SPECIAL INCIDENTAL, CONSEQUENTIAL (INCLUDING LOST PROFIT OR DATA), OR OTHER DAMAGE, WHETHER BASED IN CONTRACT, TORT, OR OTHERWISE. THE WARRANTY TERMS CONTAINED IN THIS STATEMENT, EXCEPT TO THE EXTENT LAWFULLY PERMITTED, DO NOT EXCLUDE, RESTRICT OR MODIFY AND ARE IN ADDITION TO THE MANDATORY STATUTORY RIGHTS APPLICABLE TO THE SALE OF THIS PRODUCT TO YOU.

Index

Symbols/Numerics

10/100 networking and wireless
print servers 252

A

accessories, part numbers 252
accessory error secondary
messages 150
acoustics 264
alerts, setting up 29
automatic two-sided path door,
rear 5
automatic two-sided printing
media-size selector 5

B

back cover, removing 87
blank pages 153
block diagram 70
button, print-cartridge-door 4

C

card stock
guidelines for using 11
cartridge door, removing 134
cartridges
drum rotation check 173
part numbers 252
Cassette assembly, part
numbers 222
checks
drum rotation 173
engine 172
half-self-test 173
heating element 173
high-voltage power supply 174
circuit diagram 181
classes 188

cleaning
high-voltage connection
points 175
high-voltage contacts 174
media path 44
pickup roller (tray 1) 46
pickup roller (tray 2) 55
printer 43
clearing jams 160
cold reset 178
configuration
HP LaserJet P2015 printer 2
HP LaserJet P2015d printer 2
HP LaserJet P2015dn printer 3
HP LaserJet P2015n printer 3
HP LaserJet P2015x printer 3
Configuration page 25
Connections
Macintosh 23
Microsoft Windows 22
conserving toner 253
consumables
ordering 188
contacting HP 261
control panel
HP ToolboxFX settings 33
removing 95
status-light patterns 140
covers
back, removing 87
cartridge door, removing 134
left-side, removing 86
part numbers 194
right-side, removing 86
top, removing 90
crooked pages 152
customer support 188

D

dc controller 74

default settings, restoring 177, 178
Demo page 25
Device Settings tab,
HP ToolboxFX 31
DIMM
adding 254
removing 256
testing 256
DIMM errors 150
Documentation tab
(HP ToolboxFX) 30
door
print cartridge 4
straight-through output 4
drum
rotation functional check 173
duplex solenoid, removing 106
duplex-drive assembly, part
numbers 218
duplex-drive gears, removing 104
duplex-drive PCA, removing 101
duplexer tray, removing 89
duplexer, part numbers 224

E

e-mail alerts, setting up 29
EconoMode 32, 253
ECU
part numbers 210
removing 119
electrostatic discharge (ESD) 84
embedded Web server
Configuration page 36
device status 36
event log 36
Information tab 36
Networking tab 36
order supplies 37
print info pages 36
product support 37

- Settings tab 36
- supplies status 36
- using 35
- engine control system 70, 74
- engine test 172
- envelopes
 - guidelines for using 9
- environmental
 - specifications 18, 264
- ESD (electrostatic discharge) 84
- EWS. See embedded Web server
- extended warranty 260

F

- face-down gears, removing 104
- fan
 - removing 103
- fatal error secondary
 - messages 147
- FCC compliance 270
- feeding problems, solving 152
- formatter
 - removing 97
- fuser
 - errors 149
 - part numbers 193, 229, 246
 - removing 103, 107
- fuser assembly, part numbers 214

G

- garbled text 153
- gear assembly, part numbers 220
- graphics
 - missing 153
 - poor quality 154

H

- half-self-test functional check 173
- hardware service 260
- heating element check 173
- heavy media, guidelines for
 - using 11
- Help tab, HP ToolboxFX 30
- high-voltage PCA 74
- high-voltage power supply,
 - checking 174
- HP Customer Care Online 188
- HP internal network port 5
- HP media 8
- HP Technical Training 188

HP ToolboxFX

- Device Settings tab 31
- Documentation tab 30
- Help tab 30
- Network Settings tab 34
- Status tab 29

I

- Identify product parts 4
- image problem solving 155
- image quality 32
- image quality, troubleshooting
 - repetitive image defects 179
- image-formation system
 - block diagram 70
 - operations 79
 - testing 173
- information pages
 - Configuration page 25
 - Demo page 25
 - Network Configuration page 25
 - Supplies Status page 25
- Information tab (embedded Web
 - server) 36
- input tray
 - loading media 14
 - tray 1 4
 - tray 2 4
- installing printer 18
- interlock assembly, removing 118
- internal components 71, 198

J

- jams
 - detection operations 77
- jams, clearing 160

L

- labels
 - guidelines for using 9
- laser/scanner
 - errors 148
 - operations 70, 76
 - removing 98
- left-side cover, removing 86
- letterhead
 - guidelines for using 11
- license, software 277
- life expectancy, print cartridge 253
- light patterns 140

lights

- accessory error secondary
 - messages 150
- fatal error secondary
 - messages 147
- loading media
 - optional tray 3 14
 - tray 1 13
 - tray 2 14

M

- main drive assembly, part
 - numbers 212
- main gear assembly,
 - removing 130
- main motor, removing 126
- manual-feed printing 15
- media
 - card stock 11
 - clearing jams 160
 - envelopes 9
 - feeding operations 77
 - guidelines for use 8
 - heavy 11
 - HP ToolboxFX settings 32
 - labels 9
 - letterhead 11
 - loading 13
 - optimizing print quality for
 - media types 7
 - paper 9
 - preprinted forms 11
 - printing manually 15
 - recommended 8
 - transparencies 9
 - types that may damage the
 - printer 8
 - types to avoid 8
- media path, cleaning 44
- memory
 - cold reset 178
 - errors 150
 - installing 254
 - NVRAM initialization 177
 - removing 256
 - testing 256
- memory-tag-reader assembly,
 - removing 99

missing
 graphics 153
 text 153
model number 4
motor, removing 126

N

Network Configuration page 25
network port, HP internal 5
Network Settings tab,
 HP ToolboxFX 34
Networking tab (embedded Web
 server) 36
NVRAM initialization 177

O

on/off switch 4
online support 188
operating environment
 specifications 18
operations
 block diagram 70
 engine control system 74
 image-formation system 79
 laser/scanner system 76
 pickup/feed/delivery system 77
 sequence of 73
optimizing print quality for media
 types 7
ordering
 parts 188
 supplies 188
output bin
 location 4
 removing jams in 165
output path, straight-through 14
output quality, HP ToolboxFX
 settings 32
overview, printer 4

P

pages, skewed 152
paper
 feeding operations 77
 HP ToolboxFX settings 32
 recommended 8
 using 9
paper input trays
 feeding problems, solving 152
part numbers
 accessories 252

Cassette assembly 222
covers 194
duplex-drive assembly 218
duplexer 224
ECU 210
fuser assembly 214
internal components 198
main drive assembly 212
supplies 252
top output bin gear
 assembly 220
parts
 ordering 188
 removing and replacing 84, 85
PCL 5e 33
PCL 6 33
phone numbers, ordering
 supplies 188
photosensitive drum
 rotation functional checks 173
physical specifications 18
pickup roller (tray 1) 46, 51
pickup roller (tray 2) 55, 62
pickup/feed/delivery system 70, 77
port, USB location 5
postscript level 3 emulation driver,
 HP ToolboxFX settings 34
power
 high-voltage PCA 74
 sequence of operations 73
 testing high-voltage 174
 troubleshooting 138
power receptacle 4
power switch 4
preprinted forms
 guidelines for using 11
print cartridge
 door 4
 HP policy on 253
 life expectancy 253
 redistributing toner 42
 status, viewing with
 HP ToolboxFX 29
 storing 253
 using HP cartridges 253
 warranty 278
print cartridges
 part numbers 252
print quality
 creases 158

curl 158
dropouts 155
gray background 156
HP ToolboxFX settings 32
light or faded print 155
loose toner 157
misformed characters 157
optimizing for media types 7
page skew 158
toner scatter outline 159
toner smear 156
toner specks 155
vertical lines 156
vertical repetitive defects 157
wave 158
wrinkles 158
print servers 252
print-cartridge door, removing 134
print-cartridge-door button 4
printer
 cleaning 43
 overview 4
 repacking 261
 specifications 263
printer information pages
 Configuration page 25
 Demo page 25
 Network Configuration page 25
 Supplies Status page 25
printer, specifications 268
printing
 Configuration page 25
 Demo page 25
 manual feed 15
 Network Configuration page 25
 Supplies Status page 25
product
 features 2

Q

quality
 HP ToolboxFX settings 32
 print 7
quality, troubleshooting
 repetitive image defects 179

R

recycling
 print cartridges 40
 redistributing toner 42

- registration assembly,
 - removing 129
- regulatory statements
 - Canadian DOC regulations 272
 - declaration of conformity statements 271
 - FCC compliance 270
 - Korean EMI statement 272
 - laser statement for Finland 273
- removing a jammed page 160
- removing parts 84, 85
- repacking the printer 261
- repair
 - contacting HP 261
 - hardware service 260
- repetitive defects,
 - troubleshooting 179
- replacing
 - parts 84, 85
 - pickup roller (tray 1) 51
 - pickup roller (tray 2) 62
- reset, cold 178
- restoring default settings 177, 178
- right-side cover, removing 86
- rollers
 - diagrams 185
 - locating 71
 - removing transfer 128
- rotation check, drum 173

S

- saving toner. See EconoMode
- screws, replacing 84
- sensors, media detection 77, 184
- separation pad
 - diagrams 185
- sequence of operations 73
- serial number 5
- service and support
 - contacting HP 261
 - hardware 260
 - HP ToolboxFX settings 33
- setting up printer 18
- settings
 - HP ToolboxFX 31
- Settings tab (embedded Web server) 36
- settings, restoring default 177, 178
- skewed pages 152

- software
 - HP ToolboxFX 28
 - software license
 - agreement 277
- solenoids, removing
 - diagrams 183
 - duplex 106
 - tray 2 pickup 130
- solving
 - blank pages 153
 - creases 158
 - curl 158
 - dropouts 155
 - feeding problems 152
 - garbled text 153
 - gray background 156
 - incomplete text 153
 - light or faded print 155
 - loose toner 157
 - misformed characters 157
 - missing graphics or text 153
 - page skew 158
 - poor graphics quality 154
 - printed page differs from onscreen page 153
 - skewed pages 152
 - toner scatter outline 159
 - toner smear 156
 - toner specks 155
 - vertical lines 156
 - vertical repetitive defects 157
 - wave 158
 - wrinkles 158
- space requirements 18
- specifications
 - acoustics 264
 - capacities and ratings 268
 - electrical 265
 - environmental 18, 264
 - media 7
 - memory 268
 - physical 267
 - port availability 268
- static precautions 84
- status
 - alerts, HP ToolboxFX 29
 - viewing with HP ToolboxFX 29

- status lights
 - accessory error secondary messages 150
 - fatal error secondary messages 147
- Status tab, HP ToolboxFX 29
- status-light patterns 140
- straight-through output door 4
- straight-through output path 14
- supplies
 - ordering 188
 - status, viewing with HP ToolboxFX 29
- Supplies Status page 25
- support 188
- switch, interlock 184
- switch, power 4

T

- table, repetitive defect 179
- technical support 188
- Technical Training, HP 188
- telephone numbers, ordering supplies 188
- tests
 - drum rotation 173
 - engine 172
 - half-self functional check 173
 - heating element 173
 - high-voltage power supply 174
- text
 - garbled 153
 - missing 153
- timing chart 180
- toner
 - conserving 253
 - loose toner 157
 - low 155
 - print cartridge door 4
 - redistributing 42
 - scatter outline 159
 - smear 156
 - specks 155
 - storing print cartridges 253
- ToolboxFX. See HP ToolboxFX
- tools, required 84
- top cover, removing 90
- top output bin gear assembly, part numbers 220
- transfer roller, removing 128

- transparencies
 - guidelines for using 9
- tray 1
 - loading 13
 - location 4
- tray 2
 - loading 14
 - location 4
- tray 2 pickup solenoid,
 - removing 130
- tray 3 14
- trays
 - duplexer, removing 89
 - feeding operations 77
- troubleshooting
 - accessory error secondary
 - messages 150
 - basic steps 138
 - drum rotation check 173
 - engine test 172
 - fatal error secondary
 - messages 147
 - half self-test 173
 - heating element 173
 - image formation 173
 - power 138
- types, media
 - HP ToolboxFX settings 32

U

- USB port
 - location 5

W

- warranty
 - extended 260
 - license 277
 - print cartridge 278
 - product 276
- Web server, embedded. *See*
embedded Web server
- Web sites, ordering parts 188
- wire harnesses, replacing 84

© 2006 Hewlett-Packard Development Company, L.P.

www.hp.com



CB366-90905

