

**SAMSUNG**

# Color Laser MFP

## CLX-317x series

CLX-3170/3170N/3170FN/3170FW

CLX-3175/3175N/3175FN/3175FW

**Model : CLX-3175FN/SEE**

# ***SERVICE*** Manual


## Samsung Color Laser MFP



## The keynote of Product

**The smallest / The lowest noise  
High Quality Multi-path Color MFP**

- Model : CLX-317x series
- Speed
  - . Mono : Up to 16 ppm in A4 (17 ppm in Letter)
  - . Color : Up to 4 ppm in A4 (4 ppm in Letter)
- Printing Resolution
  - . Max. 2400x600 dpi effective output
- Processor
  - . CHORUS3 (360Mhz), Proprietary SOC
  - Emulations : SPL-Color
- Memory : DDR2 SDRAM 128 MB
- Interfaces
  - . USB Device 2.0
  - . One 10/100 Base Tx network connector
  - . Wireless N/W (317xFW)
- Toner cartridge
  - . Black : 1K (initial) / 1.5K (sales)
  - . Color : 0.7K (initial) / 1K (sales)
- 150 Cassette, ADF
- Printer Life : 100K pages



**GSPN (Global Service Partner Network)**

**North America : [service.samsungportal.com](http://service.samsungportal.com)**

**Latin America : [latin.samsungportal.com](http://latin.samsungportal.com)**

**CIS : [cis.samsungportal.com](http://cis.samsungportal.com)**

**Europe : [europe.samsungportal.com](http://europe.samsungportal.com)**

**China : [china.samsungportal.com](http://china.samsungportal.com)**

**Asia : [asia.samsungportal.com](http://asia.samsungportal.com)**

**Mideast & Africa : [mea.samsungportal.com](http://mea.samsungportal.com)**

© Samsung Electronics Co.,Ltd. March. 2008  
Printed in Korea.

**VERSION NO. : 1.00      CODE : 3175-FN00SEE**

# Contents

## 1. Precautions

1.1 Safety Warning .....	1-1
1.2 Caution for safety .....	1-2
1.3 ESD Precautions .....	1-5

## 2. Product spec and feature

2.1 Product Specifications .....	2-1
2.1.1 Product Overview.....	2-1
2.1.2 Product Specification.....	2-2
2.1.3 Model Comparison Table.....	2-12
2.2 System Overview.....	2-13
2.2.1 System Structure .....	2-13
2.2.2 H/W description .....	2-23
2.2.3 CRUM.....	2-30
2.3 S/W Structure and Descriptions .....	2-31
2.3.1 Architecture .....	2-31
2.3.2 Language Monitor .....	2-31
2.3.3 Status Monitor.....	2-31
2.3.4 Network Interface.....	2-32
2.3.5 Printer Driver <-> Status Monitor .....	2-32
2.3.6 System F/W Flow.....	2-33
2.3.7 Alarm Shortage.....	2-34
2.3.8 Error status .....	2-34
2.3.9 CRUM Overview .....	2-35
2.3.10 Initailize Flow.....	2-36

## Continued

### 3. Disassembly and Reassembly

3.1	Precautions when replacing parts .....	3-1
3.1.1	Precautions when assembling and disassembling.....	3-1
3.1.2	Precautions when handling PBA.....	3-1
3.1.3	Releasing Plastic Latches .....	3-1
3.2	Parts for Maintenance and Repair .....	3-2
3.2.1	Replacement interval for parts with a limited life .....	3-2
3.2.2	Printer Cleaning.....	3-3
3.3	Information Related to Disassembly and Assembly .....	3-4
3.3.1	Special service parts.....	3-4
3.3.2	Screws used in the printer .....	3-5
3.4	Disassembly Procedure.....	3-8
3.4.1	Cover.....	3-8
3.4.2	Scan Assy.....	3-9
3.4.3	ADF Assy.....	3-10
3.4.4	OPE unit.....	3-12
3.4.5	Sheet ADF .....	3-13
3.4.6	CIS unit .....	3-14
3.4.7	Middle Cover .....	3-15
3.4.8	ITB.....	3-16
3.4.9	Fuser.....	3-16
3.4.10	HVPS board.....	3-17
3.4.11	Main PBA .....	3-17
3.4.12	SMPS board .....	3-18
3.4.13	LSU Unit .....	3-18
3.4.14	Holder Pad .....	3-19
3.4.15	Transfer Unit .....	3-19
3.4.16	Pick up roller .....	3-20

## Continued

### 4. Alignment & Troubleshooting

4.1 Alignment and Adjustments .....	4-1
4.1.1 Control Panel overview .....	4-1
4.1.2 Understanding The Status LED .....	4-2
4.1.3 Paper path .....	4-3
4.1.4 Menu Map .....	4-9
4.1.5 F/W Upgrade .....	4-11
4.1.6 Tech Mode .....	4-12
4.1.7 EDC Mode .....	4-17
4.1.8 Periodic Defective Image .....	4-21
4.1.9 Error Message .....	4-22
4.2 Troubleshooting .....	4-27
4.2.1 Procedure of Checking the Symptoms .....	4-27
4.2.2 Troubleshooting Checklist .....	4-28
4.2.3 Solving General Printing Problems .....	4-29
4.2.4 Solving Print Quality Problems .....	4-40
4.2.5 Common Windows Problems .....	4-58
4.2.6 Common Macintosh Problems .....	4-59
4.2.7 Common Linux Problems .....	4-60
4.2.8 Major Problems Trouble shooting .....	4-64
4.2.9 Fax & Phone Problems .....	4-80
4.2.10 Copy Problems .....	4-88
4.2.11 Scanner, OPE problems .....	4-92

### 5. Exploded Views & Parts List

Thumbnail .....	5-2
5.1 Main .....	5-3
5.2 Cover Middle .....	5-6
5.3 Cover Rear .....	5-8
5.4 Cover Front .....	5-10

## Continued

5.5 Scan Unit(4 in 1).....	5-12
5.6 Standard ADF .....	5-14
5.7 Path Lower Unit .....	5-16
5.8 Scan Lower Unit.....	5-18
5.9 OPE Unit.....	5-20
5.10 Scan Upper Unit .....	5-22
5.11 Scan Unit(3 in 1) .....	5-24
5.12 Frame1 .....	5-26
5.13 Frame2 .....	5-28
5.14 Main Drive1 .....	5-30
5.15 Main Drive2.....	5-33
5.16 Fuser Unit .....	5-35
5.17 Cartridge Transfer Unit .....	5-38
5.18 Tank Waste Unit.....	5-41
5.19 Cassette .....	5-43

## 6. System Diagram

6.1 Block Diagram .....	6-1
6.2 Connection Diagram.....	6-2

## 7. Reference Information

7.1 Tool for Troubleshooting .....	7-1
7.2 Acronyms and Abbreviations.....	7-2
7.3 Select a location for the printer .....	7-4
7.4 A4 ISO 19752 Standard Pattern.....	7-5