

Service Manual



DIGITAL COLOR LASER MFP CLX-8385ND

The keynote of Product

High-Speed Single-Path Color A4 MFP

- 38 / 38 ppm Network-ready CMFP
- 20K/15K Black/Color toner
- 30K CMYK Imaging unit
- 100K ITB
- Paper handling
 - : Up to 3 x 500sh Cassette + 100sh MP
 - : Finisher with stapler and offset stacking
 - : 100sh DADF

- 160 GB HDD
- High Performance CCDM
- Easy to install (CRU & Option)
- Color Graphic Touch-Screen LCD
- Low Cost per Page
- Direct USB
- S/W Option
 - : N/W Scan Enabler (Scan to Email/FTP/SMB/Client)
 - : SmarThru Workflow





ELECTRONICS

Service Manual

GSPN (Global Service Partner Network)

North America : service.samsungportal.com

Latin America : latin.samsungportal.com

CIS : cis.samsungportal.com

Europe : europe.samsungportal.com

China : china.samsungportal.com

Asia : asia.samsungportal.com

Mideast & Africa : mea.samsungportal.com

© Samsung Electronics Co., Ltd. July. 2009
Printed in Korea.

VERSION NO. : 1.00 CODE : 8385-0000E

www.tonerplus.com.ua



chapter 1 *Precautions*

1.1 Safety Warning	1-1
1.2 Caution for safety	1-2
1.3 ESD Precautions	1-5
1.4 Super Capacitor or Lithium Battery Precautions	1-5

chapter 2 *Product Overview*

2.1 Product Summary	2-1
2.2 Specifications	2-3
2.2.1 General Print Engine	2-3
2.2.2 Controller & S/W	2-3
2.2.3 Scan	2-6
2.2.4 Copy	2-7
2.2.5 FAX	2-8
2.2.6 Paper Handling	2-10
2.2.7 Consumables (CRU : Customer Replacement Unit)	2-14
2.2.8 Maintenance Parts (FRU : Field Replacement Unit)	2-15
2.2.9 Service & Environment	2-15
2.2.10 Options	2-16
2.2.11 Model Comparison	2-17
2.3 System Overview	2-18
2.3.1 System Configuration	2-21
2.3.2 H/W Configuration	2-22
2.3.3 Mechanic Configuration	2-40

chapter 3 *Maintenance and Disassembly*

3.1 Maintenance	3-1
3.1.1 Precautions on Maintenance	3-1
3.1.2 Check the consumables life	3-2
3.1.3 Consumables (CRU : Customer Replacement Unit)	3-3

3.1.4 Replacing the Consumables	3-4
3.1.5 Maintenance Parts (FRU : Field Replacement Unit)	3-8
3.1.6 Location of Maintenance parts	3-10
3.1.7 Replacing the Maintenance parts	3-11
3.1.8 Cleaning the machine	3-22
3.2 Disassembly and Reassembly	3-28
3.2.1 General Precautions on Disassembly	3-28
3.2.2 General Disassembly	3-33

chapter 4 Alignment & Troubleshooting

4.1 Alignment and Adjustments	4-1
4.1.1 Paper path	4-1
4.1.2 Clearing paper Jam	4-2
4.1.3 Abnormal Image Printing and Defective Roller	4-18
4.1.4 Control Panel overview	4-21
4.1.5 Understanding the Status LED	4-24
4.1.6 Menu overview	4-25
4.1.7 Firmware Upgrade	4-38
4.1.8 Diagnostics	4-42
4.2 Troubleshooting	4-83
4.2.1 Procedure of Checking the Symptoms	4-83
4.2.2 Display Message Troubleshooting	4-84
4.2.3 Image Quality Problems and Troubleshooting	4-94
4.2.4 Other Error	4-127

chapter 5 System Diagram

5.1 Block Diagram	5-1
5.1.1 System	5-1
5.1.2 Video and engine section with 8385ND HW part	5-2
5.1.3 Engin Controller	5-3
5.1.4 OPE Unit	5-4

5.1.5 DADF	5-5
5.1.6 SCF/HCF	5-6
5.2 Connection Diagram.....	5-7
5.2.1 Video Controller.....	5-7
5.2.2 Engin Controller	5-8
5.2.3 OPE Unit.....	5-9
5.2.4 DADF	5-10
5.2.5 SCF/HCF	5-11

chapter 6 *Reference Information*

6.1 Tool for Troubleshooting	6-1
6.2 Acronyms and Abbreviations	6-2
6.2.1 Acronyms	6-2
6.2.2 Service Parts	6-4
6.3 A4 ISO 19798 Standard Pattern.....	6-8
6.4 Model Information.....	6-13
6.4.1 Understanding for Model Code	6-13
6.4.2 Understanding Material Code & Name	6-14

chapter 7 *Installation*

7.1 Setting up the MFP	7-1
7.2 Option installation	7-11
7.2.1 Options Table.....	7-13
7.2.2 Memory Module.....	7-15
7.2.3 Fax Option kit.....	7-17
7.2.4 SCF unit (Second Cassette Feeder : Optional tray)	7-19
7.2.5 HCF unit (High Capacity Feeder).....	7-21
7.2.6 Stand (Tall/Small)	7-25
7.2.7 Finisher and Mailbox	7-28
7.2.8 FDI (Foreign device interface).....	7-41
7.3 Setting up the network	7-43
7.3.1 Supported operating systems	7-43

7.3.2 Configuring network protocol via the machine	7-44
7.3.3 Configuring network protocol by using the SetIP program	7-46

attached Exploded Views & Parts List

* Please see the attached.

Thumbnail	2
Harness Summary	5
Maintenance Parts	14
Option Unit.....	15
1. Main	16
2. Cover Unit	19
3. Cover Front Unit	21
4. Side Duplex	23
5. Duplex	25
6. Feed Idle	27
7. Frame Top	29
8. Frame Base	31
9. MP Unit.....	33
10. Pick Up Ass'y.....	35
11. Frame Lower1	37
12. Frame Lower2	39
13. Bottle Base	41
14. Registration	43
15. Guide REGI	45
16. Holder OPC	47
17. HV DEVE	49
18. WTB Motor.....	51
19. Toner Drive	53
20. LSU Cleaning	55
21. Frame Upper	57
22. Guide Exit	59
23. Front OPC Unit	61
24. Exit Ass'y	63
25. Fuser_LV Unit	65
26. Cartridge_Transfer	67
27. Pusher_LSU	70
28. DEVE Drive	72

Contents

29. Fuser Drive	74
30. Main Drive	76
31. Scanner Ass'y	78
32. OPE Unit	80
33. Platen Ass'y	82
34. DADF Ass'y	85
35. DADF Sub Ass'y	87
36. Cover Platen_DADF.....	89
37. Cover Open_DADF	91
38. TX Stacker_DADF	93
39. Guide Scan_DADF	95
40. Guide Pick Up_DADF	97
41. Exit Unit_DADF.....	99
42. Cassette.....	101
43. SCF.....	103
44. 1Bin Finisher (SCX-FIN11S)	106
44-1. Main Finisher.....	106
44-2. Frame Unit.....	108
44-3. Stacker Unit	110
44-4. Extension Tray Unit	112
44-5. Ejector Unit	114
44-6. Compile Unit	116
44-7. Feed Unit	118
45. 2Bin Finisher (SCX-FIN20S)	120
45-1. Main Finisher.....	120
45-2. Frame Unit.....	122
45-3. Feed Unit	126
45-4. Compile Unit	130
45-5. Ejector Unit	132
45-6. Extension Tray Unit	134
45-7. Stacker Unit	136
45-8. Top tray unit	139
46. Mail Box	141
46-1. MAIN	141
46-2. AS-SHIELD TOP STKR ASSY	143
46-3. AS-ACTUATOR SHIELD ASSY	145
46-4. AS-BASE SUB ASSY	147
46-5. AS-COVER JAM FRAME ASSY	149
47. HCF UNIT (Optional Unit)	151
47-1. ELA HOU-HCF	151
47-2. SUB PLATE-BOTTOM.....	153
47-3. SUB UNIT-REAR	155

Contents

47-4. AS-UNIT FRAME RIGHT	157
47-5. ELA HOU-UPPER	159
47-6. AS-UNIT CASSETTE	161
47-7. MEA UNIT-KNOCK UP	163
47-8. MEA UNIT-PAPER SIDE R	165
47-9. MEA UNIT-PAPER SIDE L	167
47-10. SUB GUIDE REAR	169