

**SAMSUNG**

# LASER PRINTER

**ML-2010 Series**

**ML-2015/XEV**

**Basic Model : ML-2010**

# **SERVICE** *Manual*

## LASER PRINTER



**ML-2010**

## The keynote of Product

- Speed : 22ppm (Ltr) / 20ppm (A4),  
600dpi × 1200dpi
- Paper Path : MPF Type Cassette
- Emulation : SPL (ML-2010 / ML-2015)
- Processor : 150MHz Jupiter4e CPU
- Memory : 8MB
- Toner Cartridge : Initial (1K), Sales (3K)
- MP Cassette : 150 pages / Face Down  
(50 pages)
- Manual Duplex : Manual Feed Guide
- Fuser Design : Lamp Type
- I/O : USB1.1
- Machine Life : 50K(pages)

**TONER**

[www.tonerplus.com.ua](http://www.tonerplus.com.ua)



\* This service manual is a property of Samsung Electronics Co., Ltd.  
Any unauthorized use of Manual can be punished under applicable  
international and/or domestic law.

\* This service manual is also provided on the web, the ITSELF  
system Samsung Electronics Co., Ltd.  
<http://itself.sec.samsung.co.kr>

© Samsung Electronics Co., Ltd. Aug. 2005  
Printed in Korea.

**VERSION NO. :** 1.00    **CODE :** JC-0141I



# Contents

## 1. Precautions

|                           |     |
|---------------------------|-----|
| 1.1 Safety Warning .....  | 1-1 |
| 1.2 Safety Caution .....  | 1-2 |
| 1.3 ESD Precautions ..... | 1-4 |

## 2. Product Specification

|                                  |     |
|----------------------------------|-----|
| 2.1 Product Overview .....       | 2-1 |
| 2.2 Specifications .....         | 2-1 |
| 2.3 Model Comparison Table ..... | 2-5 |

## 3. System Overview

|  |      |
|--|------|
| 3.1 System Outline .....                 | 3-1  |
| 3.2 H/W Structure and Descriptions ..... | 3-7  |
| 3.3 S/W Structure and Descriptions ..... | 3-19 |
| 3.4 Initial Product Installation .....   | 3-24 |

## 4. Alignment and Adjustments

|   |      |
|---|------|
| 4.1 Sample Pattern .....                    | 4-1  |
| 4.2 Control Panel .....                     | 4-2  |
| 4.3 Consumables and Replacement Parts ..... | 4-4  |
| 4.4 LED Status Error Messages .....         | 4-4  |
| 4.5 Periodic Defective Image .....          | 4-5  |
| 4.6 How to use DCU .....                    | 4-6  |
| 4.7 Paper Path .....                        | 4-11 |



## Continued

### 5. Disassembly and Reassembly

|  |     |
|--|-----|
| 5.1 General Precautions on Disassembly ..... | 5-1 |
| 5.2 Disassembly and Reassembly .....         | 5-2 |

### 6. Troubleshooting

|                                    |      |
|------------------------------------|------|
| 6.1 Checking Symptoms .....        | 6-1  |
| 6.2 Bad discharge .....            | 6-4  |
| 6.3 Malfunction .....              | 6-8  |
| 6.4 Bad software environment ..... | 6-13 |
| 6.5 Bad Image .....                | 6-17 |

### 7. Exploded Views & Parts List

|   |     |
|---|-----|
| 7.1 Exploded Views and Parts List ..... | 7-1 |
|---|-----|

### 8. Block diagram

|                                |     |
|--------------------------------|-----|
| 8.1 System Block Diagram ..... | 8-1 |
| 8.2 System Timing Chart .....  | 8-2 |

### 9. Connection Diagram

|                              |     |
|------------------------------|-----|
| 9.1 Connection Diagram ..... | 9-1 |
|------------------------------|-----|

### 10. Schematic Diagram

|                                      |      |
|--------------------------------------|------|
| 10.1 Main Board .....                | 10-1 |
| 10.2 Connector Circuit Diagram ..... | 10-5 |
| 10.3 SMPS Circuit Diagram .....      | 10-6 |
| 10.4 HVPS Circuit Diagram .....      | 10-7 |



## Continued

### 11. Reference Information

|  |      |
|--|------|
| 11.1 Troubleshooting Tools .....       | 11-1 |
| 11.2 Acronyms and Abbreviations .....  | 11-2 |
| 11.3 Selecting printer locations ..... | 11-4 |
| 11.4 Sample Tests Patterns .....       | 11-5 |

### 12. Circuit Description

|                              |      |
|------------------------------|------|
| 12.1 Engine Controller ..... | 12-1 |
|------------------------------|------|

