


## 6. Alignment and Adjustments

This chapter describes some of the main service procedures including:  
Using the DCU for diagnostics; Clearing paper jam and test patterns.  
Much of this chapter is also included in the user's guide.

### 6.1 How to use DCU


#### 6.1.1 DCU Setup

You can use the DCU test jig as an aid to the diagnosis of printer problems. To connect the DCU to the printer open the rear accessory cover (see page 5-9 step7) and then connect the DCU harness wire (10 pin/4 pin) to CN2(ML-2250) on the Main control board.



### ML SERIES DIAGNOSTIC CONTROL UNIT

SELF TEST



STATUS

DIAGNOSTIC

88

04	DEV 300	DEV 350	DEV 350
05	LSU READY	LSU MT & LD	LSU MOTOR
07	PAPER EMPTY	PAPER WIDTH	NEW CRU
08		EXIT SENSOR	FEED SENSOR
09	COVER OPEN		
10	COER HEATING	PRINTING TEMP	READY HEAT
	ON	OFF	ON


DIAGNOSTIC CODE	
00	MAIN MOTOR OPERATING SYSTEM
01	MAIN HIGH-VOLTAGE ON
02	TRANSFER HIGH-VOLTAGE (-)ON
03	THV(+) REFERENCE VOLTAGE
04	DEV/SUPPLY HIGH-VOLTAGE ON/PTL ON
05	LSU OPERATING SYSTEM
06	PICKUP CLUTCH ON
07	PEEMPTYP/WITH/NEW CRU TEST
08	FEED & EXIT SENSOR TEST
09	COVER OPEN SENSOR TEST
10	FUSER TEST
11	HOT BURN TEST
12	CLEAN MODE PRINT
13	THV(+) TRIGGER, ALL HV & FAN ON
14	THV(+) REFERENCE ON

NORMAL STATUS CODE	
61	WARM UP
00	READY (REGAL)
01	READY (LETTER)
02	READY (A4)
03	READY (EXECUTIVE)
04	READY (B5)
20	PRINT START
30	FEED SENSOR ON
40	FEED SENSOR OFF
50	PAPER OUT
69	SLEEP MODE


ERROR STATUS CODE	
60	OPEN FUSER ERROR
62	LOW TEMPERATURE ERROR
68	OVER HEATING ERROR
64	COVER OPEN ERROR
70	NO PAPER
71	PAPER JAM 0
72	PAPER JAM 1
73	PAPER JAM 2
95	LSU NOT READY

DIAGNOSTIC MODE


DOWN UP



SHIFT



STOP ENTER



TO ENTER DIAGNOSTIC MODE, PUSH THREE BUTTONS SIMUL ANEOUSL AND TURN THE PRINTER POWER ON.

SEC CODE : ML+5000 KC/XRX

## 6.1.2 Code

The DCU can be used in 2 modes – Status Monitoring and Self Diagnostic.

To use the DCU in Status monitoring mode connect the DCU and turn the printer power on. The 7 segment LED display will show various codes that show the progress of the print operation.

### 1) Normal Code

When the printer is warming up or during a print job the display indicates the paper position.

Code	State	Description
78	System Initialisation	The main processor is starting up
61	Warming up	The printer is on, the cover is open or close.
00~05	Ready (exact code depends on paper size)	The printer is ready. The paper is detected when the first page is printed. 00: Legal, 01: Letter, 02: A4, 03: EXEC, 04: B5
20	Print Start	The engine controller received the print order from the video controller. 20: 1st, 21: MP, 22: SCF
30	Feed Sensor On	The paper is passing out of the Feed Sensor.
40	Feed Sensor off	The paper has passed out of the Feed Sensor.
50	Paper Out	The paper has passed out of Exit Sensor.
69	Sleep Mode	The fuser power is turned off to minimize the power consumption.

### 2) Error Code

If a problem is detected during the print process printing is stopped and an error code is displayed.

Code	State	Description
60, 62, 68	Fuser Error	An error has occurred in the fuser. See section 4.3.5.9. • 60: Open Fuser Error • 62: Low Heat Error • 68: Over Heat Error
64	Cover Open	The Printer Cover is open.
65	CRU Error	The Toner Cartridge is not installed,
70	No Paper	No paper in the paper cassette.
71	Paper Jam 0	The front part of paper is jammed between pickup unit and Feed sensor.
72	Paper Jam 1	The front part of paper is jammed between the Exit sensor and Feed sensor.
73	Paper Jam 2	The front part of paper is jammed just after passing through the Exit sensor.
95	LSU Not Ready	LSU Scanner Motor not ready or Hsync signal not output.

### 6.1.3 Self Diagnostic Mode

If Error code is displayed use the Self Diagnostic Mode to assist in solving the problem. Only use the Self Diagnostic mode for fault finding as many safety features are disabled.

To enter the Self Diagnostic mode connect the DCU and hold down the [Down], [Shift] and [Stop] at the same time. Whilst holding these buttons turn the printer power on.

Code 78 will appear in the display. Continue to hold the buttons for approximately 3 seconds until 00 appears then release the buttons.



Use the [Up] or [Shift][Up] buttons to select the required test. To start the test press the [Enter] button. To stop the test press the [Shift] and [Enter] buttons together.

Code	Description
<b>00</b>	<b>Main Motor Operating System</b> The main motor is tested.
<b>01</b>	<b>Main High Voltage On (MHV-)</b> -1550 voltage output to MHV terminal. <i>Caution : High voltage probe should be used.</i>
<b>02</b>	<b>Transfer High Voltage (-) On (THV-)</b> -1200 voltage output by THV terminal. <i>Caution : High voltage probe should be used.</i>
<b>03</b>	<b>Transfer High Voltage (+) On (THV +)</b> +1300 voltage output to THV terminal. <i>Caution : High voltage probe should be used.</i>
<b>04</b>	<b>DEV/supply High Voltage</b> : DEV/Supply High Voltage Test. -430 voltage output to DEV terminal. <i>Caution : High voltage probe should be used.</i>
<b>05</b>	<b>LSU Operating System</b> The LSU scanning motor is started and the 'ON' LED is lit. When LSU motor is ready the 3 rd LED is lit.
<b>06</b>	<b>Pickup clutch on</b> The main cassette Solenoid is tested.


Code	Description
07	Paper Empty Sensor Test : The 'ON' LED indicates the status of the main cassette Paper Empty sensor.
08	Feed & Exit Sensor Test The 'OFF' LED indicates the status of the Exit sensor The 3 rd LED indicates the status of the Feed Sensor <b>Note</b> the Feed sensor also detects the presence of the toner cartridge
09	Cover Open Sensor Test The 'ON' LED indicates the status of the Cover Open sensor.
10	Fuser Test When [Enter] is pressed the Heat lamp is turned on. The 'ON' and 'OFF' LEDS indicate the lamp status
11	Hot Burn Test When the [Enter] button is pressed the printer continuously prints without detection. Turn the power off to stop this test.
12	Cleaning Mode Print Mode Causes the 'Cleaning' cycle to be repeated continuously Turn the power off to stop this test..
13	THV(+) TRIGGER. ALL HV : All high voltage are output to each HV terminal. The LSU and the fan are started. In this Mode the electronic resistance of the transfer roller is detected and the THV is checked.
14	PTL Test : Tests the PTL lamp The 'ON' and 'OFF' LEDS indicate the lamp status.
15	Fan Test : Tests the Fan The 'ON' and 'OFF' LEDS indicate the fan status.
16	Regi Clutch Test : Tests the Registration Clutch. The 'ON' and 'OFF' LEDS indicate the clutch status.
17	Regi Senosr Test : Tests the Registration Sensor. The 'ON' LED indicates the sensor status.
18	MP Pickup Test : Tests the MP pickup clutch. The 'ON' and 'OFF' LEDS indicate the clutch status.
19	MP Sensor Test : Tests the MP Paper sensor The 'ON' LED indicates the sensor status.

No.	Function	Enter	LED	Stop	Remark
00	Motor	Motor Run		Motor Stop	
01	MHV	Mhv On		Mhv Off	-1550V
02	THV(-)	Thv Negative On		Thv Negative Off	
03	THV(+)	Thv On		Thv Off	+1300V
04	DEV	Dev On		Dev Off	+430V
05	LSU	LSU Run	● On    ● Off    ● Ready	LSU Stop	
06	PickUp	Pickup On		Pickup Off	
07	PEmpty		● Paper Empty    ●		
08	Sensor		●    ● Exit    ● Feed		
09	Cover		● Cover Open    ●		
10	Fuser	Fuser On		Fuser Off	160 $\beta$ C
11	HotBurn	HotBurn On			
12	Clean Print	Clean Printing			
13	Thv Reference		● low    ● adequate    ● high		
14	PTL	PTL On		PTL Off	
15	FAN	Fan On		Fan Off	
16	Regi Clutch	Regi Clutch		Regi Clutch Off	
17	Regi Sensor		● Manual Sensor    ●		
18	MP Pickup	MP Pickup On		MP Pickup Off	
19	MP Sensor		● MP Empty    ●		


## 6.2 Paper Path



&lt;Jam0&gt;



&lt;Jam2&gt;



&lt;Jam1&gt;

- 1) After receiving the print command, the printer feeds paper from the main or optional second cassette or manual feeder as required.
- 2) The paper being fed passes the paper feed sensor. (Jam 0 occurs if the sensor is not operated within a certain time)
- 3) Having passed the paper feed sensor the paper moves to the paper exit sensor via printing process. (Jam 1 occurs if the sensor is not operated within a certain time)
- 4) The paper then passes through the paper exit sensor and out of the set. (Jam 2 occurs if the trailing edge of the paper does not pass the exit sensor within a certain time of the paper leading edge activating the exit sensor)

## 6.3 Clearing Paper Jams

Occasionally, paper can be jammed during a print job. Some of causes include:

- The tray is loaded improperly or overfilled.
- The tray has been pulled out during a print job.
- The front cover has been opened during a print job.
- Paper that does not meet paper specifications has been used.
- Paper that is outside of the supported size range has been used.


If a paper jam occurs, the On Line/Error LED on the control panel lights red. Find and remove the jammed paper. If there is no paper visible look inside the printer.

Do not use tweezers or other sharp metal tools when removing a jam. You may damage the toner cartridge, fuser rollers or potentially damage wiring insulation leading to an electric shock..

**Note** If, when removing jammed paper, the paper tears ensure that **ALL** fragments of paper are removed from the printer otherwise a jam will re-occur.


### 6.3.1 In the Paper Exit Area (JAM2)

- 1) If the paper jams as it exits to the output tray and a long portion of the paper is visible, pull the paper straight out.




When you pull the jammed paper, if there is resistance and the paper does not move immediately, stop pulling. Continue with the next step.

- 2) Open the rear output tray.



- 3) Loosen the paper if it is caught in the feed rollers. Then pull the paper gently out.




*Note: Please be careful when you open the rear cover. The inside of the printer is still hot.*

- 4) Close the rear output tray. Open and close the front cover. Printing can be resumed.


**Caution:** paper jammed in this area is very close to the fuser. This can be extremely hot. Take care not to get burned.

### 6.3.2 In the Paper Feed Area (JAM0)

1) Slide out the tray to expose the jammed paper.




2) Remove any jammed paper by pulling it out by the visible edge from the tray. Make sure that all of the paper is properly aligned in the tray.




3) Slide the tray back into the printer. Open and close the front cover. Printing can be resumed.

### 6.3.3 Around the Toner Cartridge (JAM1)

1) Open the front cover and remove the toner cartridge



2) Gently pull the paper toward you.



3) Check that there is no other paper in the printer.

4) Reinstall the toner cartridge, and then close the cover. Printing can be resumed.

### 6.3.4 Tips for Avoiding Paper Jams

---

By selecting the correct paper types, most paper jams can be avoided. If a paper jam occurs, follow the steps outlined in

- Ensure that the adjustable guides are positioned correctly.
- Do not overload the tray. Ensure that the paper is below the paper capacity mark on the right inside of the tray.
- Do not remove the paper from the tray while printing.
- Flex, fan and straighten the paper before loading.
- Do not use creased, damp or highly curled paper.
- Do not mix paper types in the input tray.
- Use only recommended print media.
- Ensure that the recommended print side is facing down when loading paper into the input tray.


## 6.4 Sample Pattern

This product has the several sample patterns for maintenance. With the sample patterns, check the existence of the abnormality. The patterns help to regularly maintain the product.

### 6.4.1 Printing a Demo Page

Print a demo page or a configuration sheet to make sure that the printer is operating correctly.

- 1) Hold down the Cancel button for about 2 seconds to print a demo page.  
Hold down the Cancel button for about 6 seconds to print the printer configuration. For ML2250 only the set configuration is printed (1 page). For ML2251N and ML2252W, both the set and network configuration pages are printed



<Demo Page : ML-1710>

<Demo Page : ML-1750>

2) The Demo page or the configuration sheet shows the printer's current configuration.

**SAMSUNG**

## ML-2250 Series

Monochrome Laser Printer



### DigitAllperformance

- Up to 22 ppm in Letter print speed (20 ppm in A4)
- True 1,200 x 1,200 dpi effective output
- Powerful 166 MHz processor
- 16 MB Memory (upgradeable up to 144 MB)
- 250-sheet paper cassette tray

### DigitAllValue

- One touch Toner Save Button - expand the life of the toner cartridge by 40%
- One touch Cancel Button

### DigitAllcompatibility

- Windows® 95/98/Me/NT 4.0/2000/XP
- Various Linux® OS including Red Hat, Caldera, Debian, Mandrake, Slackware, SuSE and Turbo Linux
- USB 2.0 (Compatible with USB 1.1), IEEE1284 parallel interface
- PCL6, IBM ProPrinter and EPSON emulations
- Optional PostScript3 emulation (ML-2250/2251N/2252W)
- Built-in 10/100 Base TX network (ML-2251N/2252W)
- Built-in 802.11b Wireless network (ML-2252W)

[www.samsungprinter.com](http://www.samsungprinter.com)


**SAMSUNG DIGITall**  
everyone's invited.

\*\*All other trademarks are the property of their respective owners.  
Samsung Electronics, All rights reserved.

## 6.4.2 Printing a cleaning sheet

If you are experiencing blurred, faded or smeared printouts. Printing a cleaning sheet cleans the drum inside the toner cartridge. This process will produce a page with toner debris, which should be discarded.

- 1) Ensure that the printer is turned on and in the Ready mode with paper loaded in the tray.



- 2) Press and hold down the Cancel button on the control panel for about 10 seconds.
- 3) Your printer automatically picks up a sheet of paper from the tray and prints out a cleaning sheet with dust or toner particles on it.

**Note:** The cartridge cleaning process takes some time. To stop printing, turn the power off.

## 6.5 Consumables and Replacement Parts

The life cycle outlined below is a general guideline for maintenance purposes and is for reference only. Environmental conditions (temperature, humidity, dust etc.) and actual use can cause these figures to vary.

COMPONENT	REPLACEMENT CYCLE	
Transfer Roller	60,000 Pages	
Fuser	80,000 Pages	
Toner Cartridge	5,000 Pages	cartridge supplied with set
	5,000 Pages	replacement cartridge


## 6.6 The LED Status Display by Each Error

ERROR	LED Status	DCU CODE
Open Fuser Error	The [Error] LED (red) and the [Toner Save] LED are simultaneously flashing at 1 second intervals.	60
Over Heat Error	The [Error] LED (orange) and the [Toner Save] LED are simultaneously flashing at 1 second intervals.	68
Low Heat Error	The [Error] LED (red) and the [Toner Save] LED are simultaneously flashing at 4 second intervals.	62
LSU not Ready Error (Pmotor Error)	The [Error] LED (green) and the [Toner Save] LED are simultaneously at 1 second intervals.	95
LSU Not Ready Error (HSYNC Error)	The printing is stop in the fad status, and the [Error] LED (green) and the [Toner Save] LED are simultaneously flashing at 4 second intervals.	96

## 6.7 Periodic Defective Image

If a mark or other printing defect occurs at regular intervals down the page it may be caused by a damaged or contaminated roller. Measure the repetition interval and refer to the table below to identify the roller concerned.

No	Roller	Defective image	Typical defect
1	OPC Drum	75.5mm	white spot on black image or black spot
2	Charge Roller	37.7mm	black spot
3	Supply Roller	44.9mm	light or dark horizontal image band
4	Developing Roller	35.3mm	horizontal image band
5	Transfer Roller	47.1mm	image ghost
6	Heat Roller	78mm	Black spot and image ghost
7	Pressure Roller	75.5mm	black spot on the backside



<Rollers Layout>