



12. Series model solution(ML-4050 and SCX-5530F)


12.1 Double Feed Error




12.2 Jam0




12.3 Jam1



12.4 No Paper/Add Paper" error on the printer and have been unable to clear it, even when they have verified there is paper in the printer




12.5 Open Cover Error




12.6 Low Toner

solid ORANGE Led


: The solid Orange Error LED is on, which means toner low status.




12.7 Over Heat Error




12.8 Low Heat Error



12.9 Fuser Door Open




12.10 aA noise troubleshooting tree




12.11 LSU Error


: The ERROR and Online LED are blinking together




12.12 Scan Lock Error




12.13 Nothing Displayed on LCD




12.14 All black printing




12.15 Blank Copy



12.16 Images at 1 Copy



12.17 Glass Broken



12.18 Document Jam

