


3-3 Scanner Ass'y

1. Before you remove the Scanner Ass'y, you should remove:
 - Rear Cover (see page 3-1)


2. Take out the Shield Main Upper. Unplug the one connector and CCD cable.




Notice :

To avoid damage to the CCD cable connector ensure that you pull the cable out carefully. Pull in line with the connector not at an angle.


3. Remove the three screws, as shown below.




4. Open the Side Cover assembly first to open the Front cover. In the other words, close the front cover first to assembly it.




5. Remove two screws.




6. Pull up the Scanner Ass'y in the direction of arrow.




8. Open the ADF Ass'y in the direction of arrow.
Pull the ADF Ass'y upward and remove it.




7. Remove the connector from the Platen Ass'y.



9. Remove the three screws securing the Platen Ass'y.




10. Pull the OPE Ass'y and unplug the one connector.



12. Unlatch the glass and r


ummy Upper Ass

14. Remove the four screws and Channel Base Frame.



16. Remove the CCD cable.


15. Remove the five screws and Dummy Scan-Lower.



17. Pull up the Shaft CCD and take out the Scanner Module.


18. Remove three screws and take out the Motor Bracket.

19. Remove the OPE Harness from the Platen PBA. Remove two screws and take out the Platen PBA.



Notice :


Take special care when reassembling the CCD Module onto the Platen Ass'y. The CCD Module is located just to the right side the Belt Tension Spring as shown below.




3-4 ADF Ass'y

1. Before you remove the ADF Ass'y, you should remove:
 - Rear Cover (see page 3-1)
 - Scanner Ass'y (see page 3-2)


2. Remove the five screws from the Platen Cover.




4. Pull the ADF Ass'y upward and remove it.




3. Open the Cover. Remove Cover Side R. Unlatch the Side Cover L by pushing the catch hooked to the Platen Cover L using a sharp tool and remove Side Cover L.




5. Tack out the Open Cover.



6. Take out the Pick-up Ass'y.
Remove the four screws and the ADF Upper.




7. Remove three screws and take out the ADF Motor ass'y.




3-5 OPE Ass'y

1. Before you remove the OPE Ass'y, you should remove:
 - Rear Cover (see page 3-1)
 - Scanner Ass'y (see page 3-2)


2. Remove ten screws securing the OPE PBA and the LCD Module from the OPE Cover.



3. Remove the contact rubbers from the unit.



4. Remove the key pad from the unit.




Caution


The above information is for the SCX-5315F model.
For the SCX-5115 model, the OPE Ass'y is slightly different, parts marked "a" are not fitted.

3-6 Side Cover Ass'y

1. Remove the two screws to release the Stopper(Main Frame side) securing the Side Cover to the Main Frame.




2. Completely open the Side Cover door. The left hand hinge (1) should be lifted to free it. Then push the whole door assembly to the left to free the right hand hinge (2).




* MP-Tray

1. To dismantle the MP tray release the lower hinges (1).




2. As shown in (1) below align the door supports in a horizontal position. This will allow the Tray-Case to be removed from the Tray Links. To remove the Tray-Links adjust the position of the Tray Link to a 45° angle to align the slot in the




* Duplex Ass'y

1. To remove the Duplex Ass'y from the Side Door Ass'y locate the plastic clips, 2 on each side, and release them.



* Transfer Roller Ass'y


1. Take out the Transfer Roller, as shown below.



3-7 Fuser Ass'y

1. Before you remove the Fuser Ass'y, you should ensure power is off and remove :
 - Rear Cover Ass'y (see page 3-1)
 - Side Cover Ass'y (see page 3-9)

2. Remove the two screws and take out the Connector Cover and the Cover Bracket.




3. Unplug the one connector.


4. Remove the three screws and take out the Fuser Ass'y.

5. Remove the four screws and take out the Thermostat.

6. Remove the two screws and take out the Halogen Lamp.




7. Remove 2 screws and hinge open the Lower Fuser Ass'y, remove the Heat Roller Ass'y from the Upper Fuser Ass'y.




3-8 Exit Ass'y

1. Before you remove Exit Ass'y, you should remove:
 - Rear Cover (see page 3-1)
 - Scanner Ass'y (see page 3-2)
2. Remove four screws, and then untie the harness from the Exit Upper. Unplug four connectors and unlatch the Dummy Base Frame, as shown below.




3. Move the Exit Roller Release Lever to the upright position as shown in the diagram below and lift the exit ass'y to remove it.



3-9 Cover Paper Exit Ass'y

1. Before you remove the Cover Paper Exit Ass'y, you should remove:
 - Rear Cover (see page 3-1)
 - Scanner Ass'y (see page 3-2)


2. Remove two screws and Cover Paper Exit Ass'y, as shown below.




3-10 Drive Ass'y

1. Before you remove the Drive Ass'y, you should remove:
 - Rear Cover (see page 3-1)
 - Shield Main Upper (see page 3-2)

2. Unplug the two connectors.
(Main Motor:9pin, Duplex Solenoid : 2pin)



4. Remove the five screws and take out the Drive Ass'y.



3. Remove the one screw and take out the Fan and Dust Fan.

