

8. Exploded Views and Parts List


Contents

8.1 Main	8-2
8.2 Housing Scanner	8-3
8.3 OPE Cover	8-4
8.4 Platen Cover Ass'y	8-5
8.5 ADF Ass'y	8-6
8.6 DADF Ass'y	8-7
8.7 DADF Platen Cover Ass'y	8-8
8.8 DADF SUB Ass'y	8-9
8.9 Side Cover Ass'y	8-10
8.10 Cassette Ass'y	8-11
8.11 Exit Ass'y	8-12
8.12 Feeder Ass'y	8-13
8.13 MP Ass'y	8-14
8.14 Base Frame	8-15
8.15 Pick-up Ass'y	8-16
8.16 Drive Ass'y	8-17
8.17 Main Frame Ass'y	8-18
8.18 Fuser Ass'y	8-19
8.19 SCF Unit(Optional Cassette)	8-20

Way to observe Part Code & Description

Part code and Description is quoted and controlled by determined standard. Refer to this determined standard, it will help with ordering Part.

- There are two kinds of Part code inscription type.



Type 1 : Controlled by Company : It can be commonly used for all kinds of product SEC produce. Mostly, electronics Parts.

Type 2 : Controlled by Division : It is used or one produce. Mostly, Mostly, mechanical Parts.


- A/S privately used part** : It is only used for A/S .

- Ass'y part** : Assembled by more than 2 Parts. If necessary part is not A/S Part, Ass'y part including necessary par can be used. It is shown in the diagram and drawing of SVC manual.


Ass'y part and A/S privately used Part is distinguished by part Code and Description. The are inscription type 2. It is recognized by Part character and front side of description.

DIVISION	PART CODE	DESCRIPTION
A/S Private	**81-***** (JB81-00039A)	AS-***** (AS-USE)
ASS'Y Part	**75-***** (JB75-00068A)	MEC-***** (MEC-CHUTE)
ASS'Y Part	**92-***** (JB92-01131A)	PBA ***** (PBA MAIN-CONTROLLER)
ASS'Y Part	**97-***** (JB97-01089A)	MEA ***** (MEA UNIT-PULLEY IDLE)


8.1 Main




8.2 Housing Scanner




8.3 OPE Cover







8.5 ADF Ass'y




8.6 DADF Ass'y




8.7 DADF Platen Cover Ass'y




8.8 DADF SUB Ass'y




8.9 Side Cover Ass'y




8.10 Cassette Ass'y





8.11 Exit Ass'y




8.12 Feeder Ass'y




8.13 MP Ass'y









8.14 Base Frame




8.15 Pick-up Ass'y




8.16 Drive Ass'y




8.17 Main Frame Ass'y



8.18 Fuser Ass'y



8.19 SCF Unit(Optional Cassette)



Service Parts List(Model: SCX-6122FN/XAX)

Service(SA:service available, SNA:service not available)

Drawer#	SEC_Code	Description	QT'y	Service
8.1-0	SCX-6122FN/XAX	22 PPM FLATBED MFP		
8.1-1-1	JC96-04180V	ELA HOU-SCANNER	1	SA
8.1-2	JC97-01556C	MEA UNIT-COVER PA EX	1	SA
8.1-2-1	JC72-00354D	PMO-TRAY EXT MP NE	1	SA
8.1-2-2	JC72-00786C	PMO-COVER PAPER EXIT	1	SA
8.1-3	JC97-01736D	MEA UNIT-CASSETTE	1	SA
8.1-4	JC97-01572C	MEA UNIT-COVER FRONT	1	SA
8.1-5	JC59-00014C	UNIT-LSU,600DPI,22	1	SA
8.1-6	JC96-04178A	ELA HOU-SHIELD SMPS	1	SA
8.1-7	JC92-01793D	PBA SUB-LIU	1	SA
8.1-8	6103-000101	SUPPORTER	2	SNA
8.1-9	JC96-02715C	ELA HOU-PICK UP PLUS	1	SA
8.1-10	JC96-02183D	ELA HOU-SIDE COVER	1	SA
8.1-11	JC96-02182B	ELA HOU-MP	1	SA
8.1-12	JC96-04010C	ELA HOU-BASE FRAME	1	SA
8.1-13	JC97-01850A	MEA UNIT-FEED ROLLER	1	SA
8.1-14	JC96-03021C	ELA HOU-FUSER E_COIL	1	SA
8.1-15	JC96-04012A	ELA HOU-FRAME MAIN	1	SA
8.1-16	JC97-01643D	MEA UNIT-EXIT	1	SA
8.1-17	JC96-04183A	ELA HOU-ENGINE DRIVE	1	SA
8.1-18	JC97-01851D	MEA UNIT-REAR COVER	1	SA
8.1-18-1	JC63-00192C	COVER-MAIN REAR DUMMY	1	SA
8.1-18-2	JC63-00191B	COVER-MAIN REAR	1	SA
8.1-19	JC92-01792C	PBA MAIN-CONTROLLER	1	SA
8.1-20	JC63-01089C	COVER-PANNEL MFP	1	SNA
8.1-21	JC96-02311A	ELA HOU-DUCT FAN	1	SA
8.1-21-1	JC31-00012A	FAN-DC	1	SA
8.1-21-2	JC72-00807A	PMO-DUCT FAN	1	SA
8.1-24	JC33-00007A	SOLENOID-PICK UP	1	SA
8.1-25	JC72-00790B	PMO-COVER EXIT REAR	1	SA
8.1-26	JC97-01624B	MEA UNIT-GUIDE CST PA	1	SA
8.1-26-1	JC72-00836A	PPR-SHEET/GUIDE PAPER	1	SA
8.1-26-2	JC72-00791B	PMO-GUIDE CST RAIL	1	SA
8.1-26-3	JC63-00078A	SHEET-FEED	2	SNA
8.1-26-4	JC70-00244A	IPR-GUIDE CASSETTE PAPER	1	SA
8.1-28	JC72-00789B	PMO-DUMMY BASE FRAME	1	SA
8.1-29	JC96-04182A	ELA HOU-SHIELD MAIN	1	SA
8.1-29-1	JC63-01092A	SHIELD-P_MAIN BOARD	1	SNA
8.1-29-2	JC39-00604A	HARNESS-INLET	1	SA
8.1-29-3	JB39-00103A	CBF HARNESS-LIU GND	1	SA
8.1-30	JC72-00801A	PMO-COVER FEED AY	1	SA
8.1-32	JC72-00835B	PMO-GUIDE PAPER OUT	1	SA
8.1-33	JC63-00072A	SHEET-CONNECTOR	1	SA
8.1-34	JC39-00336A	CBF HARNESS-LSU	1	SA
8.1-35	JC39-00590A	HARNESS-HVPS	1	SA
8.1-37	JC39-00598B	HARNESS-MAIN_MOTOR	1	SA
8.1-38	JC66-00335A	GEAR-PICK_UP	1	SA
8.1-39	JC70-00248A	IPR-SHIELD SMPS UPPER	1	SA

Service(SA:service available, SNA:service not available)

Drawer#	SEC_Code	Description	QT'y	Service
8.1-40	JC97-01574A	MEA UNIT-HOLD GND ASS'Y	1	SA
8.1-40-1	JC61-70203A	SPRING ETC-PLATE TR	1	SA
8.1-40-2	JC61-70961A	SPRING ETC-TR_L	1	SA
8.1-40-3	JB72-00819A	PMO-BUSH	1	SA
8.1-40-4	JC72-00883A	PMO-HOLDER GND TR	1	SA
8.1-41	JC97-01573A	MEA UNIT-HOLD GEAR ASS'Y	1	SA
8.1-41-1	JC61-70906A	SPRING ETC-TR_R	1	SA
8.1-41-2	JB72-00819A	PMO-BUSH	1	SA
8.1-41-3	JC72-00884A	PMO-HOLDER GEAR TR	1	SA
8.1-44	JC72-00799A	PMO-CAM JAM REMOVE	1	SA
8.1-45	JC72-00805A	PMO-LOCKER DEVE	1	SA
8.1-46	JC72-00804A	PMO-LEVER JAM REMOVE	1	SA
8.1-47	JC39-00601C	HARNESS-POWER_SWITCH	1	SA
8.1-48	JC66-40947A	GEAR-TRANSFER	1	SA
8.1-49	JC72-41191A	PMO-BEARING SHAFT	1	SA
8.1-50	JC75-00148A	MEC-TRANSFER ROLLER	1	SA
8.1-51	JC72-00834A	PMO-COVER BRKT MOTER	1	SA
8.2-0	JC96-04180V	ELA HOU-SCANNER	1	SA
8.2-2	JC96-04170V	ELA HOU-OPE	1	SA
8.2-3	JC96-04166A	ELA HOU-PLATEN	1	SNA
8.3-0	JC96-04170V	ELA HOU-OPE	1	SA
8.3-1	JC63-01155H	COVER-DUMMY	1	SNA
8.3-2	JC63-01156V	COVER-OPE	1	SNA
8.3-3	JC64-00242A	KEY-M_STOP CLEAR	1	SNA
8.3-4	JC64-00243A	KEY-M_START BLACK	1	SNA
8.3-5	JC64-00239A	KEY-M_TEL	1	SNA
8.3-7	JC64-00241A	KEY-M_FAX	2	SNA
8.3-8	JC64-00249A	KEY-M_ON HOOK	1	SNA
8.3-9	JC64-00248A	KEY-M_MENU	1	SNA
8.3-10	JC67-00198A	LENS-STATUS	1	SNA
8.3-11	JC73-00246A	RUBBER-TEL	1	SA
8.3-12	JC73-00247A	RUBBER-MODE	1	SA
8.3-13	JC73-00230A	RUBBER-MENU	1	SNA
8.3-14	JC63-01157A	COVER-LCD	1	SNA
8.3-15	JC64-00247A	KEY-M_MODE SCAN	1	SNA
8.3-16	JC64-00245A	KEY-M_MODE COPY	1	SNA
8.3-17	JC64-00246A	KEY-M_MODE FAX	1	SNA
8.3-18	JC73-00248A	RUBBER-FAX	1	SA
8.3-19	JC73-00245A	RUBBER-EMAIL	1	SA
8.3-20	JC96-03994C	ELA UNIT-OPE	1	SNA
8.3-21	JC92-01791D	PBA SUB-QWERTY	1	SA
8.3-23	6003-000154	SCREW-TAPTITE	17	SA
8.4-33	JC96-04034B	ELA HOU-SCAN UPPER	1	SA
8.4-33-1	JC72-00758B	PMO-COVER SCAN UPPER	1	SA
8.4-33-2	JC97-02800A	MEA UNIT-DUMMY UPPER	1	SA
8.4-33-2-1	JC72-00759D	PMO-DUMMY UPPER	1	SA
8.4-33-2-2	JC74-00019A	MCT-GLASS ADF	1	SA
8.4-33-2-4	JC63-00074A	SHEET-DUMMY UPPER	1	SA
8.4-33-3	JC72-00809B	SHEET ABS-REGI_EDGE	1	SA
8.4-33-4	6003-000154	SCREW-TAPTITE	2	SA
8.4-33-5	JC02-00013A	TAPE ETC-DOUBLE TAPE SMALL	3	SNA
8.4-33-6	JC02-00012A	TAPE ETC-DOUBLE TAPE LARGE	2	SNA
8.4-33-7	JC74-00018A	MCT-GLASS SCANNER(LEGAL)	1	SA
8.4-33-10	JB70-00148A	IPR-HOLDER GLASS	3	SA

Service(SA:service available, SNA:service not available)

Drawer#	SEC_Code	Description	QT'y	Service
8.4-34	JC96-04164A	ELA HOU-SCAN LOWER	1	SA
8.4-34-1	JC63-00157B	COVER-SCAN LOWER	1	SNA
8.4-34-2	JC72-00753B	PMO-COVER DUMMY LOWER	1	SA
8.4-34-3	6003-000154	SCREW-TAPTITE	15	SA
8.4-34-4	JB70-00154A	ICT-INSERT SHAFT	1	SNA
8.4-34-5	JB72-00763A	PMO-PULLEY	1	SA
8.4-34-6	JB72-00764A	PMO-HOLDER BELT	1	SA
8.4-34-7	6044-000125	RING-E	1	SA
8.4-34-8	JC96-02759B	ELA HOU-CCD MODULE	1	SA
8.4-34-9	6602-001084	BELT-TIMING GEAR	1	SA
8.4-34-11	JC61-00703A	HOLDER-M-CCD(UMAX)	1	SA
8.4-34-12	JB61-70939A	SPRING ETC-EXIT	1	SNA
8.4-34-13	JC70-00228A	IPR-BRK SCAN BD	1	SA
8.4-34-14	JC63-00158B	COVER-CCD CABLE	1	SNA
8.4-34-15	JC72-00755A	PMO-LEVER SENSOR	1	SA
8.4-34-16	JB61-00059A	SPRING ETC-BELT	1	SA
8.4-34-17	6002-000175	SCREW-TAPPING	3	SA
8.4-34-18	JC96-02751A	ELA HOU-SCAN MOTOR	1	SA
8.4-34-18-1	JC61-00702A	BRACKET-MOTOR PLATEN	1	SNA
8.4-34-18-2	6003-000154	SCREW-TAPTITE	2	SA
8.4-34-18-3	JB66-00083A	GEAR-IDLE	1	SA
8.4-34-18-4	JC66-00530A	GEAR-REDUCTION73/37	1	SA
8.4-34-18-5	JC66-00531A	GEAR-TIMING	1	SA
8.4-34-18-6	JB72-00764A	PMO-HOLDER BELT	1	SA
8.4-34-18-7	6044-000125	RING-E	2	SA
8.4-34-18-8	JB31-00011A	MOTOR STEP-SCAN	1	SA
8.4-34-19	6502-000132	CABLE CLAMP	1	SA
8.4-34-21	6003-000154	SCREW-TAPTITE	8	SA
8.4-34-22	JC39-00340A	CBF HARNESS-OPE	1	SA
8.4-34-23	JB39-00077A	CBF HARNESS-SCAN MOTOR	1	SA
8.4-34-24	JB39-00065A	CBF HARNESS-DRIVER GND	1	SNA
8.4-34-25	JC39-00236A	CBF SIGNAL-CCD FFC	1	SA
8.4-34-26	JC39-00338A	CBF HARNESS-SCAN_DSUB	1	SA
8.4-34-27	JB96-01381A	ELA UNIT-CORE	3	SA
8.4-34-28	JC66-00532A	SHAFT-CCD(UMAX)	1	SA
8.4-34-28	JC70-00239A	IPR-CHANNEL BASE FRAME	2	SA
8.5-0	JC96-03995B	ELA HOU-ADF	1	SA
8.5-1	JC97-02651D	MEA UNIT-PLATEN COVER	1	SA
8.5-1-1	JC72-00745B	PMO-TX STACKER	1	SA
8.5-1-2	JF70-10616A	IPR-WASHER SPRING CU	2	SA
8.5-1-3	JC72-00839D	PMO-DOC GUIDE L	1	SA
8.5-1-4	JC72-00838D	PMO-DOC GUIDE R	1	SA
8.5-1-5	JF72-41354A	PMO-GEAR PINION	1	SA
8.5-1-6	JC97-01731A	MEA UNIT-HINGE	2	SA
8.5-1-7	JC73-00091A	RPR-ROLLER EXIT IDLE	2	SA
8.5-1-8	JC70-00242A	IPR-SHAFT EXIT	1	SA
8.5-1-9	JB71-00038A	NPR-SPRING PINCH DRIVE	2	SA
8.5-1-10	JC72-00738B	PMO-COVER PLATEN	1	SA
8.5-1-11	JC72-00751B	PPR-SPONG SHEET	1	SA
8.5-1-12	JC72-00750B	SHEET ABS-SHEET PLATEN(PET)	1	SA
8.5-1-13	JC70-00260A	IPR-SPRING PINCH	3	SA
8.5-1-14	JC70-00265A	ICT-SHAFT PINCH	3	SNA
8.5-1-15	JG72-40663A	PMO-ROLL PINCH	3	SA
8.5-2	JC97-01581B	MEA UNIT-ADF UPPER	1	SA

Service(SA:service available, SNA:service not available)

Drawer#	SEC_Code	Description	QT'y	Service
8.5-2-1	JC72-00736B	PMO-COVER ADF UPPER	1	SA
8.5-2-2	JB73-00052A	RMO-ADF RUBBER	1	SA
8.5-2-3	JB72-00825A	PMO-HOLDER ADF	1	SA
8.5-2-4	JB73-10913A	RPR-SPONGE ADF	1	SA
8.5-2-5	JC61-00040A	SPRING ETC-COIL ADF	1	SA
8.5-2-6	JC63-00079A	SHEET-ADF	1	SA
8.5-3	JC96-03996B	ELA HOU-ADF LOWER	1	SA
8.5-3-1	JB61-00076A	SPRING ETC-TORSION DOC (CC2-F)	3	SA
8.5-3-2	6044-000159	RING-C	4	SA
8.5-3-3	JB66-00103A	GEAR-ADF 38	1	SA
8.5-3-4	JB72-00819A	PMO-BUSH	2	SA
8.5-3-5	JC75-00149A	MEC-ROLLER DRIVER	1	SA
8.5-3-6	JC72-00735B	PMO-COVER ADF LOWER	1	SA
8.5-3-7	JB72-00837A	PMO-ACTUATOR SENSOR DOC	1	SA
8.5-3-8	JC72-00747A	PMO-ACTUATOR SENSOR REGI	1	SA
8.5-3-9	JC75-00150A	MEC-ROLLER EXIT	1	SA
8.5-3-10	JG72-40732A	PMO-BUSHING HOLDER	1	SNA
8.5-3-11	JB61-70922A	SPRING ETC-CLUTCH	1	SA
8.5-3-12	JC66-00323A	GEAR-EXIT 23	1	SA
8.5-3-13	JC61-00548A	SPRING ETC-WHITE BAR	1	SA
8.5-3-14	JC70-00225A	IPR-BRKT WHITE BAR	1	SA
8.5-3-15	JC72-00752A	PPR-WHITE BAR SHEET	1	SA
8.5-3-16	JC02-00014A	TAPE ETC-ANTI BRUSH	1	SNA
8.5-3-17	JC92-01382A	PBA SUB-ADF	1	SA
8.5-3-18	JC92-01365A	PBA SUB-ADF POS SEN	1	SA
8.5-3-19	JC92-01366A	PBA SUB-ADF DET SEN	1	SA
8.5-3-20	JC39-00187A	CBF HARNESS-ADF ROLLER GND	1	SA
8.5-3-21	JB39-00065A	CBF HARNESS-DRIVER GND	1	SNA
8.5-3-22	JC72-00746A	PMO-ACTUATOR SENSOR SCAN	1	SA
8.5-3-23	JC71-00031A	NPR-SPRING GND	1	SA
8.5-3-24	JC39-00190A	CBF D SUB CABLE-ADF_MAIN CABLE	1	SA
8.5-4	JC96-02264A	ELA HOU-ADF MOTOR ASS'Y	1	SA
8.5-4-1	JB66-00101A	GEAR-CLUTCH 29	1	SA
8.5-4-2	JC70-00224A	IPR-BRKT ADF MOTOR	1	SA
8.5-4-3	JB72-00844A	PMO-WHITE CLUTCH SUB 29	1	SA
8.5-4-4	JC66-00322A	GEAR-CLUTCH 39	1	SA
8.5-4-5	JG66-40038A	GEAR-IDLE20/33	2	SA
8.5-4-6	6044-000159	RING-C	7	SA
8.5-4-7	JG66-40039A	GEAR-IDLE17/35	2	SA
8.5-4-8	JG66-40036A	GEAR-IDLE25	1	SA
8.5-4-9	JC31-00017A	MOTOR STEP-ADF	1	SA
8.5-4-10	JC66-00329A	GEAR-JAM REMOVE	1	SA
8.5-4-11	JC66-00324A	GEAR-REDUCTION 45/19	1	SA
8.5-5	JC97-01582A	MEA UNIT-PICKUP ASS'Y	1	SA
8.5-6	JC72-00722B	PMO-GUIDE PAPER	2	SA
8.5-7	JC72-00737B	PMO-COVER OPEN	1	SA
8.5-8	JC72-00739B	PMO-COVER SIDE L	1	SA
8.5-9	JC72-00740B	PMO-COVER SIDE R	1	SA
8.7-0	JC97-02651D	MEA UNIT-COVER PLATEN	1	SA
8.7-1	JC72-00738B	PMO-COVER PLATEN	1	SA
8.7-2	JC72-01251B	PMO-EXTENTION PLATEN	1	SNA
8.7-3	JC61-00746B	GUIDE-EXTENTION	1	SNA
8.7-4	JC72-00751A	PPR-SPONG SHEET	1	SA

Service(SA:service available, SNA:service not available)

Drawer#	SEC_Code	Description	QT'y	Service
8.7-5	JG72-40663A	PMO-ROLL PINCH	6	SA
8.7-6	JC70-00468A	IPR-P_PINCH(SCAN)	6	SNA
8.7-7	JC70-00265A	ICT-SHAFT PINCH	2	SA
8.7-8	JC72-00746A	PMO-ACTUATOR SENSOR SCAN	1	SA
8.7-9	JC92-01562A	PBA SUB-GATE	1	SA
8.7-10	JC97-01839A	MEA UNIT-HINGE(MCK2)	2	SA
8.7-11	JC61-00819A	PLATE-P-DUMMY PLATEN	1	SA
8.7-12	JC61-70925A	SPRING ETC-CHARGE	1	SNA
8.7-13	JB61-00076A	SPRING ETC-TORSION DOC (CC2-F)	1	SA
8.9-0	JC96-02183D	ELA HOU-SIDE COVER	1	SA
8.9-1	JC97-01578B	MEA UNIT-DUPLEX	1	SA
8.9-1-1	JC70-10232D	IPR-E-PLATE SAW(MCK2)	1	SA
8.9-1-2	JC70-00234A	IPR-BRACKET GUIDE B	1	SA
8.9-1-3	JC72-41213B	PMO-HOLDER SAW	1	SNA
8.9-1-4	JC70-00229A	IPR-BRACKET GUIDE A	1	SA
8.9-1-5	JC72-00731A	PMO-FEED FRAME	1	SA
8.9-1-6	JC61-00478A	SPRING ETC-FEED	2	SA
8.9-1-7	JC72-00730A	PMO-BUSHING FEED	1	SA
8.9-1-8	JC66-00341A	GEAR-DUP IDLER 17	3	SA
8.9-1-9	JC66-00346A	GEAR-MP/DUP DRV	1	SA
8.9-1-10	6044-000001	RING-CS	2	SNA
8.9-1-11	JC70-00231A	IPR-BRKT GROUND TR	1	SA
8.9-1-12	JG72-40744A	PMO-BUSHING TX(B4)	4	SA
8.9-1-13	JC70-00232A	IPR-BRKT GROUND A	1	SA
8.9-1-13	JC72-00764A	PMO-SHAFT DUP DRIVER	2	SA
8.9-1-14	JC73-10203A	RPR-RUBBER EXIT	2	SA
8.9-1-15	JC70-00233A	IPR-BRKT G DUP	1	SA
8.9-1-16	JC72-00732A	PMO-GP LOWER DP	1	SA
8.9-1-17	JC72-40361A	PMO-ROLLER_EXIT	2	SNA
8.9-1-18	JC61-70976A	SPRING ETC-FUSER EXIT	2	SNA
8.9-1-19	JC39-00036A	CBF HARNESS-OPE GND	1	SA
8.9-1-20	JC70-00230A	IPR-BRKT GROUND B	1	SA
8.9-2	JC97-01909B	MEA UNIT-SIDE SUB	1	SA
8.9-2-1	JC72-00806A	PMO-GUIDE DP SIDE	1	SA
8.9-2-2	JC61-00919B	GUIDE-SIDE_PUSH	1	SNA
8.9-2-3	JC72-00762D	PMO-LOCKER OPEN	1	SA
8.9-2-5	JC72-00763C	PMO-LOCKER SIDE R	1	SA
8.9-2-6	JC61-00479A	SPRING ETC-LOCKER TORSION	1	SA
8.9-2-7	JC72-00766A	PMO-TIE STOPPER	2	SA
8.9-2-8	JC97-01577C	MEA UNIT-TRAY	1	SA
8.9-2-8-1	JC72-00776B	PMO-TRAY CASE MP	1	SA
8.9-2-8-2	JC72-00778D	PMO-TRAY EXT MP	1	SA
8.9-2-8-3	JC72-00547A	PMO-SIDE GUIDE MP	1	SA
8.9-2-8-4	JC72-00777D	PMO-TRAY COVER MP	1	SA
8.9-2-8-5	JB70-10906A	IPR-GUIDE LATCH	1	SA
8.9-2-8-6	JC72-00857C	PMO-TRAY LINK MP	2	SA
8.10-1	JC72-00877C	PMO-IMPACT CASSETTE	1	SA
8.10-2	JC61-00831A	PLATE-P_GUIDE PAPER	2	SA
8.10-3	JC70-00221A	IPR-PLATE K/UP	1	SA
8.10-5	JC72-00795B	PMO-COVER CASSETTE	1	SA
8.10-6	JC72-00716B	PMO-FRAME CASSETTE	1	SA
8.10-7	JC61-00825C	GUIDE-FRONT CST PLUS	1	SNA
8.10-8	JC72-00717C	PMO-GUIDE REAR	1	SA
8.10-9	JC61-00826A	GUIDE-P-SIDE CST	1	SA

Service(SA:service available, SNA:service not available)

Drawer#	SEC_Code	Description	QT'y	Service
8.10-10	JC72-41210A	PMO-LOCKER PLATE	1	SA
8.10-11	JC69-00474A	PAD-CST PLUS	2	SA
8.10-12	JG61-70531A	SPRING ETC-LOCKER,PLATE	1	SA
8.10-13	6107-001172	SPRING-CS	1	SA
8.10-14	6107-001172	SPRING-CS	1	SA
8.10-17	JC61-00824C	GUIDE-SIDE HANDLE	1	SNA
8.10-18	JC70-00325A	IPR-P-FINGER LEFT	1	SA
8.10-19	JC61-00653B	BUSH-M-FINGER,F	2	SNA
8.10-20	6031-000021	WASHER-PLAIN	2	SNA
8.10-21	JC61-00548A	SPRING ETC-WHITE BAR	1	SA
8.10-22	JC61-00840B	GUIDE-SUB WALL	1	SNA
8.11-0	JC97-01643D	MEA UNIT-EXIT	1	SA
8.11-2	JC72-00710A	PMO-GUIDE-EXIT LOWER	1	SA
8.11-3	JC61-00484A	SPRING ETC-EXIT LOWER IDLE	4	SA
8.11-4	JC61-00547A	HOLDER-EXIT(MC)	4	SNA
8.11-5	JC72-41007A	PMO-ROLLER FD F	4	SA
8.11-6	JC72-41008A	PMO-ROLLER FD R	4	SA
8.11-7	JC61-70911A	SPRING ETC-EXIT ROLL FD	2	SA
8.11-8	JC66-00715A	SHAFT-IDLE_LOWER	1	SNA
8.11-9	JC72-40361A	PMO-ROLLER_EXIT	4	SNA
8.11-10	JC72-00708B	PMO-GUIDE_EXIT UPPER	1	SA
8.11-11	JC75-00166A	MEC-ROLLER EXIT DRIVE	2	SA
8.11-12	JC72-00885A	PMO-BEARING LARGE DP	2	SA
8.11-13	JC72-00833A	PMO-ROLLER DECURL	4	SA
8.11-14	JC72-01345A	PMO-BUSHING DP	1	SNA
8.11-15	JC72-00885A	PMO-BEARING LARGE DP	1	SA
8.11-16	JC72-00771A	PMO-HOLDER PAD,MP	1	SA
8.11-16	JC66-40912A	GEAR-DUPLEX	1	SA
8.11-17	JC72-40980A	PMO-PULLEY DUPLEX	2	SA
8.11-18	6044-000159	RING-C	4	SA
8.11-19	6602-001084	BELT-TIMING GEAR	1	SA
8.11-20	JC70-00252A	IPR-GROUND-EXIT	1	SA
8.11-21	JC72-00709B	PMO-LEVER_STACKING	1	SA
8.11-22	JC75-00095A	MEC-BRUSH ANTISTATIC	1	SA
8.11-23	6003-000154	SCREW-TAPTITE	3	SA
8.11-24	JC92-01400B	PBA SUB-BIN_FULL_SEN	1	SA
8.12-0	JC97-01850A	MEA UNIT-FEED ROLLER	1	SA
8.12-1	JC72-00821A	PMO-FRAME FEED	1	SA
8.12-3	JC66-00346A	GEAR-MP/DUP DRV	1	SA
8.12-4	JC70-00267A	ICT-SHAFT FEED	1	SNA
8.12-5	JC72-41364A	PMO-BUSHING_P/U,MP	2	SA
8.12-6	6044-000125	RING-E	2	SA
8.12-7	6044-000001	RING-CS	1	SNA
8.12-8	JC61-00849A	BRACKET-PM_FEED(25)	1	SNA
8.12-9	JC72-00727A	PMO-ROLLER FEED	1	SA
8.12-11	JC72-00725A	PMO-HOLDER PINCH SUB	1	SA
8.12-12	JC72-40261A	PMO-ROLLER FEED L	1	SA
8.12-13	JC61-00871A	HOLDER-PUSH_FEED_CST	1	SNA
8.12-14	JC72-00724A	PMO-HOLDER PINCH M	1	SA
8.12-15	JC72-40266A	PMO-SUB HOLDER FEED	1	SA
8.12-16	JC61-00481A	SPRING ETC-FEED MP	1	SA
8.12-17	6031-000021	WASHER-PLAIN	3	SNA
8.12-18	JC72-40262A	PMO-ROLLER FEED S	1	SA
8.12-19	JC70-10230A	IPR-SHAFT FEED IDLER	4	SA

Service(SA:service available, SNA:service not available)

Drawer#	SEC_Code	Description	QT'y	Service
8.12-20	JC63-00259A	SHEET-FEEDER	1	SNA
8.12-21	JC72-01315A	PMO-ROLLER PINCH FEED	2	SNA
8.12-22	6044-000159	RING-C	2	SA
8.13-0	JC96-02182B	ELA HOU-MP	1	SA
8.13-2	6003-000154	SCREW-TAPTITE	1	SA
8.13-3	6044-000125	RING-E	2	SA
8.13-5	JC61-00003A	SPRING ETC--CAM MP	1	SA
8.13-7	JC61-00483A	SPRING ETC-KNOCKUP,MP	1	SA
8.13-8	JC70-00237A	IPR-BRACKET SOLENOIDE	1	SA
8.13-9	JC72-00055A	PMO-HOLDER CAM MPF	1	SNA
8.13-10	JC72-00056A	PMO-GEAR P/U MPF	1	SA
8.13-11	JC72-00761A	PMO-ROLLER CAM.MP	1	SA
8.13-12	JC72-00767A	PMO-ACTUATOR,MP	1	SA
8.13-13	JC72-00768A	PMO-ADJUSTER,MP	1	SA
8.13-14	JC72-00769A	PMO-CAM PICK UP,MP	1	SA
8.13-15	JC72-00770B	PMO-FRAME MP	1	SA
8.13-17	JC72-00772A	PMO-HOLDER SENSOR,MP	1	SA
8.13-18	JC72-00773A	PMO-HOUSING PICK UP,MP	1	SA
8.13-19	JC72-00775A	PMO-PLATE KNOCK UP,MP	1	SA
8.13-20	JC72-41027A	PMO-IDLE PICK UP MP	2	SA
8.13-21	JC73-00089A	RPR-RUBBER PICK UP,MP	1	SA
8.13-22	JC73-00090A	RPR-RCT PAD PICKUP,MP	1	SA
8.13-23	JC69-00494A	PAD-MP(PLUS)	1	SA
8.13-24	JC92-01362A	PBA SUB-MP SEN	1	SA
8.13-25	JC72-41364A	PMO-BUSHING_P/U,MP	2	SA
8.14-0	JC96-04010C	ELA HOU-BASE FRAME	1	SA
8.14-1	JC72-00779B	PMO-BASE FRAME	1	SA
8.14-2	JC72-00785B	PMO-COVER FRONT DUMMY	1	SA
8.14-3	JC61-00486A	SPRING ETC-TORSION	1	SA
8.14-5	6003-000154	SCREW-TAPTITE	12	SA
8.14-6	JC70-00239A	IPR-CHANNEL BASE FRAME	1	SA
8.14-7	6003-000154	SCREW-TAPTITE	5	SA
8.14-8	JC61-40001A	FOOT-ML80	2	SA
8.14-9	JC70-00241A	IPR-GROUND PLATE B(BASE)	1	SA
8.14-10	6003-000154	SCREW-TAPTITE	1	SA
8.14-11	JC96-01607A	ELA M/M-AUD SPEAKER	1	SA
8.14-12	JC61-00789A	BRACKET-M-PUSH DEVE	2	SNA
8.14-13	JC61-00550A	SPRING ETC-DEVE REAR	1	SA
8.14-14	JC70-00243A	IPR-GROUND PLATE SCF	1	SA
8.14-15	JC39-00082A	CBF HARNESS-SCF	1	SA
8.14-17	JC31-00027B	FAN-DC CARDINAL	1	SA
8.14-18	JC66-00684A	SHAFT-DEVE_BOTTOM	1	SNA
8.14-19	JC61-00551A	SPRING ETC-DEVE FRONT	1	SA
8.14-20	JC61-00855A	HOLDER-M_ROLLER BOTTOM	1	SNA
8.14-21	JC61-00857A	HOLDER-CATCH CST(MC2)	1	SNA
8.14-22	4302-001183	BATTERY-NIH(2ND)	1	SA
8.14-23	JC61-00667A	STOPPER-M-FAN80	1	SA
8.14-24	JC92-01568A	PBA SUB-AIR_TMP	1	SA
8.15-0	JC96-02715C	ELA HOU-PICK UP PLUS	1	SA
8.15-1	JC70-00238A	IPR-GND FEED	1	SA
8.15-2	JC70-00235A	IPR-GND INPUT	1	SA
8.15-3	JC70-00222A	IPR-GUIDE INPUT	1	SA
8.15-4	JC72-01313A	PMO-M-ACTUATOR_NO PAPER	1	SA
8.15-6	JC92-01361A	PBA SUB-PTL	1	SA

Service(SA:service available, SNA:service not available)

Drawer#	SEC_Code	Description	QT'y	Service
8.15-7	JC72-00721A	PMO-FEED SENSOR	1	SA
8.15-8	JC72-00722B	PMO-GUIDE PAPER	1	SA
8.15-9	JC72-00726A	PMO-HOLDER SENSOR FEED	1	SA
8.15-10	JC72-00803A	PMO-LENS TONER SENSOR	1	SA
8.15-11	JC72-00822A	PMO-PTL PATH	1	SA
8.15-13	JC72-41364A	PMO-BUSHING_P/U,MP	1	SA
8.15-14	JC61-00822A	HOUSING-M-PICKUP LARGE	1	SNA
8.15-15	JC61-00823A	HOUSING-M-PICKUP SMALL	1	SNA
8.16-0	JC96-04183A	ELA HOU-ENGINE DRIVE	1	SA
8.16-2	JC31-00020C	MOTOR STEP-MCK2(MAIN)	1	SA
8.16-3	JC72-00825A	PMO-IMPELLER_DRV	1	SA
8.16-7	JC66-00345A	GEAR-71/23	1	SA
8.16-8	JC66-00580A	GEAR-OPC53/37	1	SNA
8.16-9	JC66-00337A	GEAR-86/23	1	SA
8.16-11	JC66-00350A	GEAR-31/19	1	SA
8.16-12	JC66-00342A	GEAR-RDCN FEED INNER	1	SA
8.16-13	JC66-00338A	GEAR-DEVE DRV	1	SA
8.16-14	JC66-00340A	GEAR-HUB CLUTCH	2	SA
8.16-15	JC72-00743A	PMO-DEV/COUPLING	1	SA
8.16-16	JC66-00343A	GEAR-RDCN FEED OUTER	1	SA
8.16-17	JC66-00347A	GEAR-OPC DRV	1	SA
8.16-18	JC75-00163A	MEC-BRAKE GEAR	1	SNA
8.16-19	JC66-00581A	GEAR-OPC 55/31	1	SNA
8.16-20	JC61-00853A	BRACKET-P-BRAKE	1	SNA
8.16-21	JC66-00348A	GEAR-FEED DRV	1	SA
8.16-22	JC66-00333A	GEAR-FUSER DRV INNER	1	SA
8.16-23	JC66-00334A	GEAR-GEAR FUSER DRV OUTER	1	SA
8.16-24	JC66-00349A	GEAR-SWING DRV	1	SA
8.16-25	JC66-40211B	GEAR-EXIT/U,ID	1	SA
8.16-26	JC66-00576A	LINK-P-DUPLEX	1	SNA
8.16-27	6044-000159	RING-C	1	SA
8.17-0	JC96-04012A	ELA HOU-FRAME MAIN	1	SA
8.17-1	JC72-00800A	PMO-FRAME MAIN	1	SA
8.17-2	JC72-00803A	PMO-LENS TONER SENSOR	1	SA
8.17-3	JC92-01360B	PBA SUB-TONER_RX	1	SA
8.17-4	JC70-00216A	IPR-GND OPC	1	SA
8.17-5	JC39-00592A	HARNESS-OPC GND	2	SA
8.17-7	6002-000175	SCREW-TAPPING	1	SA
8.17-9	JC72-00463A	PMO-CAP CONNECTOR L	1	SA
8.17-10	JC72-00465A	PMO-CAP CONNECTOR U	1	SA
8.17-11	JC70-00218A	IPR-GUARD C/O S/W	1	SA
8.17-12	JC70-00219A	IPR-GND TERMINAL	1	SA
8.17-13	JC39-00360A	CBF HARNESS-COVER_SW	1	SA
8.17-14	JC66-40964A	GEAR-EXIT,IDLE(Z17)	2	SA
8.17-15	6003-000154	SCREW-TAPTITE	1	SA
8.17-16	JC63-00409A	GROUND-P-FUSER_MC2	1	SNA
8.17-17	6044-000001	RING-CS	6	SNA
8.17-18	JB61-70922A	SPRING ETC-CLUTCH	2	SA
8.17-19	JC66-40211B	GEAR-EXIT/U,ID	3	SA
8.17-20	JC70-00214A	IPR-GND EXIT	1	SA
8.17-21	JC70-00298A	IPR-TERMINAL OPC	2	SNA
8.17-22	JC61-00723A	HOUSING-M-TERMINAL	1	SA
8.17-23	JC70-00272A	IPR-TERMINAL GND	1	SA
8.17-24	JC70-00271A	IPR-TERMINAL TR	1	SA

Service(SA:service available, SNA:service not available)

Drawer#	SEC_Code	Description	QT'y	Service
8.17-25	JC70-00269A	IPR-TERMINAL BLADE	2	SA
8.17-26	JC70-00270A	IPR-TERMINAL SUPPLY	2	SA
8.17-27	JC72-41010A	PMO-HOUSING TERMINAL	1	SA
8.17-28	JC70-10961A	IPR-TERMINAL FU	2	SA
8.17-29	6021-000222	NUT-HEXAGON	2	SNA
8.17-30	6001-000568	SCREW-MACHINE	2	SA
8.17-36	JC39-00600B	HARNESS-FUSER	1	SA
8.17-37	JC39-00593A	HARNESS-OPC_FUSER	1	SA
8.17-38	JC39-00377A	CBF HARNESS-THERM	1	SA
8.17-38	JC39-00589A	HARNESS-H_VOLTAGE	1	SA
8.18-0	JC96-03021C	ELA HOU-FUSER E_COIL	1	SA
8.18-1	JC96-03020C	ELA UNIT-HEAT ROLLER	1	SNA
8.18-2	JC97-01611B	MEA UNIT-ACTUATOR	1	SA
8.18-3	JC72-20902A	PEX-ROLLER F/UP(2)	3	SA
8.18-4	JC70-00064A	IPR-PIN ROLLER EXIT	3	SNA
8.18-5	JC97-01587B	MEA UNIT-CLAW	4	SA
8.18-5-1	JC61-70909A	SPRING ETC-SAPERATION	1	SA
8.18-5-2	JC72-00376B	PMO-GUIDE CLAW	1	SA
8.18-6	JC67-00067A	BRUSH-CARBON	2	SA
8.18-7	6107-001172	SPRING-CS	2	SA
8.18-8	6001-000568	SCREW-MACHINE	2	SA
8.18-9	JC63-00353A	COVER-M-BRUSH	2	SNA
8.18-10	6003-000154	SCREW-TAPTITE	5	SA
8.18-11	JC70-00469A	ELECTRODE-P-FRONT	1	SNA
8.18-12	4712-001027	THERMOSTAT	1	SA
8.18-13	6001-000568	SCREW-MACHINE	2	SA
8.18-14	1404-001340	THERMISTOR-NTC	1	SA
8.18-15	JC71-00030A	NPR-ELECTRODE M	1	SA
8.18-16	6003-000154	SCREW-TAPTITE	4	SA
8.18-17	JC70-00470A	ELECTRODE-P-GEAR	1	SNA
8.18-18	JC72-01318A	PMO-UPPER FUSER	1	SNA
8.18-19	6021-000222	NUT-HEXAGON	2	SNA
8.18-20	JC61-00485A	SPRING ETC-ACTUATOR6G	1	SA
8.18-21	JC66-00679A	LEVER-M-JAM R	1	SNA
8.18-22	JC66-00691A	ROLLER-PRESSURE	1	SNA
8.18-23	JC72-01316A	PMO-LOWER FUSER	1	SNA
8.18-24	JC70-00259A	IPR-GROUND FU	1	SA
8.18-25	JC61-00056A	SPRING ETC-PR(7300)	2	SA
8.18-26	JC66-10901A	BEARING-PRESSURE/R	2	SA
8.18-27	JC72-00817A	PMO-GUIDE INPUT	1	SA
8.18-28	JC66-00678A	LEVER-M-JAM F	1	SNA
8.18-29	JC61-01702A	BUSH-HEAT ROLLER	1	SNA
Replacement	JC69-01019C	BOX-MAIN	1	SA
Replacement	3903-000085	CBF-POWER CORD	1	SA
Replacement	JC39-00001A	CBF INTERFACE-USB	1	SA
Replacement	JF39-50094B	CBF LINE CORD	1	SA