

# FUSER

## Fuser Belt Heater

The Inlet Roll Lamp is a 250W /200V lamp used to heat the Fuse Belt. The lamp turns on at power on and cycles on and off during standby and print to maintain a constant belt temperature. Because the Inlet Roll Lamp maintains 120°C the belt constantly rotates to maintain an even temperature.

