

## High Capacity Feeder Module - Input Power

---

### Input Power

The HCF receives AC input power through its own power cord, independent of the Print Engine. The module accepts any standard, 100-127vac 50/60hrz 15amp / 220-240vac 15amp power source. The only accommodation required, for the various input voltages and geographic regions, is the power cord.

In normal operation, the HCF is switched on and off by the Print Engine, which controls the main power relays on the control panel during system power up and power down.

**Power  
Cord  
Inlet**

