

FUSER

Fuser Roll Heater Lamps

There are two Fuser Roll Heater Lamps. The Main Heater is 1000W / 200V and the Secondary Heater is 800W / 200V.

The Main Heater is on during warm up, standby and during print. The Secondary Heater is only on during print, when the fuser temperature falls below a preset NVM value. The second heater is physically shorter and is used for long runs, large paper and heavy stock.

Note: For more detail about fuser operating temperature, select the **Fuser Chart** button below.

