


High Capacity Feeder Module - Power Distribution

Power Distribution

The power supply is a universal 50/60Hz power supply and requires no adjustment or accommodation for the power line frequency or voltage (there are no jumpers or transformer taps). Power enters the HCF through the inlet Connector and is distributed by the Distribution Panel. For distribution details refer to the HCF BSD.



Reverse Side of Panel

