


Tray 3 – Paper Handling Module

Tray 3 Humidity Sensor

The Humidity Sensor for all 3 trays is located on the inside of the Tray 3 front cover. The sensor monitors the amount of moisture in the paper tray by measuring the resistance of the air in a pocket of the sensor. If the relative humidity is 50% or greater then the sensor will signal for the heaters to switch on. The figure below (inside view of Tray 3's cover) shows the location of the sensor.

Humidity Sensor



Tray 3 Humidity Sensor