



Document Feeding - Document Handling Module

Document Feeding



The document is fed from the top of the stack. The feed edge of the document is placed against the Entrance Gate in the Input Tray Assembly. The Entrance Gate is in the raised position when no documents are covering the Document Set Sensor, and the front and rear Top Cover Interlocks are both closed.



When the Document Set Sensor senses a document in the DADF Input Tray Assembly and after the user presses the machine's Start button, the Entrance Gate Solenoid drops the Entrance Gate so that the document can be fed into the DADF.