


# Xerographic Process - Xerographics

## Second BTR Transfer to Paper (2<sup>nd</sup> BTR Roll)

When all four, color images, have transferred to the Transfer Belt, paper is feed into place and the entire toner image is transferred to the paper at the 2<sup>nd</sup> BTR. After transfer, the copy/print is sent to the Fuser Assembly so the toner image can be fused with the paper and made permanent.



**Transfer to Paper**