


Fuser - IOT Module

Fuser Exit Transport


As the fused prints exit the fuser, stripper fingers on the Fuser Belt and Fuser Roll, lift the paper and guide it into the Fuser Exit Transport. The drive rolls in the transport receive drive from the Fuser Drive Motor. A Fuser Exit Sensor monitors the paper as it enters and leaves the Fuser Exit Transport. If paper is late arriving or departing the transport, a jam is declared and a fault is displayed on the User Interface Screen.




NOTE: Fuser Exit Transport shown lifted up for Fuser Belt jam clearance.

Fuser - IOT Module

Fuser Exit Transport (continued)



**Fuser Roll
Stripper Fingers**



**Fuser Belt
Stripper Fingers**