

## **Paper Tray 1 & 2 – Paper Handling Module**

---


### **Trays 1 and 2 Paper Feed**

The machine will send a signal to feed paper when the operator presses the Start Print Button or when a feed signal is sent to Tray 1 or 2 by the control logic during printer operation. The print signal will turn on the Pre Feed Motor providing drive to the feed head rollers. When the Feed Solenoid energizes, the linkage will pivot the feed head down and a sheet of paper is fed out of the tray. As the sheet of paper leaves the tray, a Pre Feed Sensor checks for jams and misfeeds by sensing the length of the paper and if it changes state within the correct time.

**Pre Feed Motor**

**Feed Solenoid**

**Pre Feed Sensor**



**Feed Head Rollers**

**Feed Solenoid Linkage**