

IBT Belt - IOT Module

Belt Home Position Sensors

There are two Belt Home Position Sensors. Belt Home Position Sensor #1 is located on the top, right hand side of the drawer underneath the transfer belt. Belt Home Position Sensor #1 is used for timing the belt seam at time 0 and aligning the image to belt registration. Belt Home Position Sensor #2 is located on the bottom left hand side of the drawer underneath the transfer belt. Sensor #2 is used for image to paper registration.

