


IBT Belt - IOT Module

IBT Belt Cleaning

The IBT belt cleaner is located on the right hand side of the IBT Belt. The blade, brush, and bottom film seal are HFSI items. The Belt Cleaning Auger Assembly is mounted in the bottom of the transfer drawer. The waste toner is removed through the auger to the Toner Waste Bottle. The inlet to the auger contains two ball bearings to eliminate clogging.



IBT Belt Cleaning System

IBT Belt - IOT Module

IBT Belt Cleaning (continued)

The photo below shows the IBT Cleaner Assembly removed.

