

LBP-1260

PARTS CATALOG

Canon

FIGURE 100 EXTERNAL COVERS, PANELS, ETC.





FIGURE 101 PRINTER UPPER ASS'Y



NUM.	PART #	DESCRIPTION
100-1	RB1-2921-020	PANEL, RIGHT
2	RB1-2922-040	PANEL, LEFT
3	RB1-2924-000	PANEL, FRONT
4	RB1-2931-000	TRAY, B
5	RF5-1157-000	COVER, DELIVERY
5A	RB1-2354-000	HINGE
5B	RB1-2932-020	LATCH
5C	RB1-5527-000	STOP, REAR
5D	RS5-2219-000	SPRING, COMPRESSION
5E	RS5-8396-000	LABEL, REAR
6	RG5-1736-000	CONTROL PANEL ASS'Y
6A	RB1-5528-000	COVER, FRONT
6B	RB1-3574-000	SPRING, LEAF
6C	RG1-3467-000	CONTROL PANEL CABLE
6D	RH6-0113-000	PANEL, CONTROL
6E	XA9-0591-000	SCREW, M3X8 (2)
7	XA9-0253-000	SCREW, W/WASHER, M3X8 (3)

NUM.	PART #	DESCRIPTION
101-1	RF5-1160-000	COVER, UPPER
1A	RB1-2329-000	ARM, HINGE, 2
2	RB1-2920-000	COVER, OPEN/CLOSE
3	RB1-2323-000	ARM, HINGE, 1 (2)
4	RB1-2324-000	PIN, HINGE (2)
5	RB1-2329-000	ARM, HINGE, 2
6	RB1-2314-000	STOP, HINGE (2)
7	RB1-2260-000	BRUSH, CLEANING
8	XA9-0253-000	SCREW, W/WASHER, M3X8
9	XA9-0663-000	SCREW, W/WASHER, M3X6 (2)

FIGURE 102 INTERNAL COMPONENTS 1






FIGURE 103 INTERNAL COMPONENTS 2




NUM.	PART #	DESCRIPTION	NUM.	PART #	DESCRIPTION
102-1	RB1-5730-000	GUIDE, CARTRIDGE, LEFT	103-1	FA9-1449-000	SCREW, TRUSS HEAD, W/WASHER (2)
2	RB1-2101-020	GUIDE, CARTRIDGE, RIGHT	2	RB1-2352-000	ROD, SWITCH
3	RB1-2105-030	SUPPORT, CARTRIDGE	3	RB1-3544-000	DUCT, 1
4	RB1-2106-000	PLATE, GROUNDING	4	RF5-0748-000	DUCT, 2
5	RB1-2927-000	GUIDE, CASSETTE, LEFT	5	RB1-5520-000	COVER, FAN
6	RB1-2111-000	ARM, SHUTTER	6	RF5-1155-000	HOLDER, PCB
7	RB1-2114-000	FOOT (5)	7	RG5-0526-000	DC CONT./LOW - VOLTAGE 2 CABLE
8	RB1-2122-000	SPRING, TORSION	8	RG5-1933-000	POWER SUPPLY ASS'Y
9	RB1-5732-000	SPRING, TORSION	9	RG5-0978-000	MAIN MOTOR CABLE
10	RB1-2125-020	HOLDER, LATCH	10	RH7-1169-000	MOTOR, DC 10.7W
11	RB1-2966-000	SPRING, SWITCH	11	RH7-1177-000	FAN
12	RB1-3553-000	COVER, MOTOR	12	XA9-0267-000	SCREW, TP, M3X6 (2)
13	RF5-1158-000	GUIDE, CASSETTE, RIGHT	13	XA9-0585-000	SCREW, W/SPRING WASHER, M3X10
13A	RB1-2124-000	SPRING, SWITCH	14	RH2-5074-020	CORD, POWER
14	RF5-0365-000	PLATE, PRESSURE, CRG, LEFT	15	XA9-0253-000	SCREW, W/WASHER, M3X8
15	RF5-0366-000	PLATE, PRESSURE, CRG, RIGHT	16	XA9-0668-000	SCREW, W/WASHER, M3X29.5
16	RG5-0903-020	LASER/SCANNER ASS'Y	17	RB1-3507-000	COVER, DC CONTROLLER
16A	RB1-2080-000	SHUTTER, LASER	18	WE8-5107-000	FERRITE CORE
16B	RS5-2170-000	SPRING, TORSION	19	RG5-0980-000	DC CONT./DELIVERY SENSOR CABLE
17	RG5-0975-000	DC CONT./SCANNER CABLE	20	RG5-1648-000	DC CONT. PCB (NOT SHOWN)
18	RG5-0976-000	DC CONT./LASER CABLE			
19	RS5-2218-000	SPRING, COMPRESSION			
20	XA9-0267-000	SCREW, TP, M3X6			
21	XA9-0591-000	SCREW, M3X8 (3)			
22	XA9-0592-000	SCREW, M4X6 (4)			
23	XA9-0639-000	SCREW, W/SPRING WASHER, M3X14 (4)			
24	XZ9-0379-000	LATCH			
25	XA9-0253-000	SCREW, W/WASHER, M3X8			
26	RB1-5731-000	SPRING, LEAF			

FIGURE 104 INTERNAL COMPONENTS 3





NUM.	PART #	DESCRIPTION
104-1	RB1-2341-000	GUIDE, I/O, OPTION (2)
2	RB1-2945-000	COVER, I/O
3	RB1-5511-000	PLATE, SHIELD
4	RB1-5512-000	PLATE, SHIELD, FRONT
5	RB1-5513-000	PLATE, SHIELD
6	RB1-5514-000	PLATE, I/O
7	RB1-5516-000	HINGE, MEMORY COVER
8	RB1-5518-000	PLATE, REINFORCEMENT
9	RB1-5522-000	GUIDE, CABLE
10	RB1-5523-000	COVER, CONNECTOR
11	RB1-5524-000	PLATE, CONTROL PANEL
12	RF5-1156-000	COVER, MEMORY BOARD
12A	RS5-8231-000	LABEL, MEMORY COVER
12B	RB1-3505-000	SCREW, TP, M3X5.5
12C	XA9-0133-000	RING, E
13	WT2-0204-000	CLIP, CABLE
14	WT2-0470-000	CLAMP, CABLE
15	WT2-5065-000	CLAMP
16	RA9-0637-000	CAP, DUST
17	WS9-0104-000	CAP, DUST
18	XA9-0267-000	SCREW, TP, M3X6 (7)
19	CNT-0002-000	VIDEO CONTROLLER PCB ASS'Y

FIGURE 105 INTERNAL COMPONENTS 4



NUM.	PART #	DESCRIPTION
105-1	RB1-2226-000	COVER, HVT
2	RB1-2236-000	GUIDE, FEEDER
3	RB1-2251-000	BLOCK CONNECTING
4	RB1-2253-000	ROLLER, FEED (6)
5	RB1-2259-040	HOLDER, PAPER, 2
6	RF5-0349-000	ROLLER, TRANSFER
7	RF5-0369-040	HOLDER, PAPER, 1
8	RG5-0515-000	CONNECTOR PCB ASS'Y
9	RG5-0468-050	TRANSFER BLOCK ASS'Y
9A	RB1-2234-000	BUSHING, RIGHT
9B	RB1-2235-000	BUSHING, LEFT
9C	RB1-2238-000	ELIMINATOR, STATIC CHARGE
9D	RB1-2239-000	PIN, CONTACT (2)
9E	RB1-2240-000	SPRING, LEAF
9F	RB1-2241-000	SPRING, LEAF
9G	RB1-2242-000	SPRING, LEAF
9H	RB1-2243-000	SPRING, LEAF
9J	RS5-2181-000	SPRING, COMPRESSION
9K	RS5-2182-000	SPRING, COMPRESSION
9L	RS5-2183-000	SPRING, COMPRESSION (2)
9M	RH9-0737-000	VARIATOR
9N	RS5-8428-000	LABEL, "CAUTION"
10	RG5-0969-000	H.V. POWER SUPPLY PCB ASS'Y
11	RG5-0979-000	DC CONT./CONNECT CABLE
12	WT2-0030-000	TIE, CABLE
13	XA9-0253-000	SCREW, W/WASHER, M3X8 (4)
14	XA9-0574-000	SCREW, HEX HEAD, W/WASHER (2)
15	XA9-0623-000	SCREW, HEX HEAD
16	XA9-0267-000	SCREW, TP, M3X6 (5)
17	RB1-2963-000	COVER, INNER
18	RB1-2353-000	PLATE, FRONT PANEL
19	RB1-3563-000	SPRING, LEAF



NUM.	PART #	DESCRIPTION
110-1	RB1-2118-000	BASE, SWITCH MOUNTING
2	RB1-2962-000	SWITCH, MAIN
3	RB1-2345-000	COVER, CABLE
4	RG5-0524-000	DC CONT./MOTOR DRIVER CABLE
5	RG5-0530-000	MOTOR DRIVER/C.FEEDER CABLE
6	RS5-2217-000	SPRING, TENSION

NUM.	PART #	DESCRIPTION
260-	RG5-0876-000	PRINTER DRIVER ASS'Y
1	RB1-2319-000	SHAFT, GEAR
2	RB1-3481-000	COVER, GEAR
3	RF5-0350-020	COUPLER, FIXING
4	RS5-0237-000	GEAR, 17T/32T
501	XD2-2100-502	RING, GRIP

FIGURE 265 PICK-UP DRIVE ASS'Y 1





FIGURE 265 PICK-UP DRIVE ASS'Y 2



NUM.	PART #	DESCRIPTION
265-1	RB1-2135-000	SPRING, LEAF
2	RB1-2154-000	FRAME, PAPER FEED, LEFT
3	RB1-2158-000	SHAFT, PICK-UP, F
4	RB1-2159-000	SHAFT, PICK-UP, M
5	RB1-2164-000	SPRING, TORSION
6	RB1-2165-000	PLATE, RELEASE, ROLLER
7	RB1-3485-000	CLAW, CLUTCH
8	RB1-2167-000	SPRING, TORSION
9	RB1-2179-000	LATCH, CASSETTE
10	RB1-2180-000	SPRING, TORSION
11	RB1-2188-000	ROLLER, OBLIQUE, B
12	RB1-2190-000	COLLAR, SPRING (2)
13	RB1-2191-000	COLLAR, OBLIQUE ROLLER
14	RB1-2193-000	SPRING, TORSION
15	RB1-2200-000	PLATE, OBLIQUE ROLLER
16	RB1-2201-000	HOLDER, SHAFT
17	RF5-1080-000	MOUNT, GEAR
18	RF5-0339-000	PLATE, SPINDLE
19	RF5-0340-000	ROLLER, OBLIQUE, A (2)
20	RF5-0747-000	HOLDER, ROLLER (2)
21	RH7-5071-000	SOLENOID
22	RH7-5075-000	SOLENOID
23	RS5-0239-000	GEAR, 48T
24	RS5-0240-000	GEAR, 16T
25	RS5-0243-000	GEAR, 39T
26	RS5-0244-000	GEAR, 25T
27	RS5-0245-000	GEAR, 35T

NUM.	PART #	DESCRIPTION
265-28	RS5-0246-000	GEAR, 31T
29	RS5-0247-000	GEAR, 19T
30	RS5-0250-000	GEAR, 16T (2)
31	RS5-0251-000	GEAR, 12T
32	RS5-0252-000	GEAR, 16T
33	RS5-0389-000	GEAR, 29T
34	RS5-0390-000	GEAR, 42T/16T
35	RS5-0391-000	GEAR, 32T/16T
36	RS5-0392-000	GEAR, 32T
37	RS5-1066-000	BUSHING, PICK-UP (2)
38	RS5-1067-000	BUSHING, OBLIQUE ROLLER (3)
39	RS5-2172-000	SPRING, TENSION
40	RS5-2216-000	SPRING, TENSION
41	RS5-2269-000	SPRING, TENSION
42	XA9-0591-000	SCREW, M3X8 (5)
43	XA9-0640-000	SCREW, W/WASHER, M3X12 (3)
44	XA9-0665-000	SCREW, SELF-TAPPING, 3X18
45	XD9-0131-000	RING, E (4)
501	XD2-2300-402	SE RING (2)

FIGURE 300 CASSETTE (UNIVERSAL)





FIGURE 301 CASSETTE (A4/LTR)



NUM.	PART #	DESCRIPTION	NUM.	PART #	DESCRIPTION
300-1	RB1-2369-000	CAM, SIZE	301-1	RB1-2372-020	ARM, SENSOR
2	RB1-2370-020	PLATE, LENGTH ADJUSTMENT	2	RB1-2956-020	BLOCK, DISPLAY
3	RB1-2372-020	ARM, SENSOR	3	RB1-2380-000	LIFTER
4	RB1-2958-000	COVER, LEFT	4	RB1-2384-000	CLAW, PAPER SEPARATING
5	RF5-0565-020	COVER, RIGHT	5	RB1-2386-000	PIN
5A	RS5-8232-000	LABEL, PAPER SIZE	6	RB1-2389-000	SPRING, TORSION
6	RB1-2375-000	DIAL	7	RB1-2935-000	COVER
7	RB1-2377-000	GEAR, 28T	8	RF5-0432-030	HOLDER, ROLLER
8	RB1-2957-000	ARM, DISPLAY	9	RF5-0561-000	BODY, CASSETTE (A4)
9	RB1-2956-020	BLOCK, DISPLAY		RF5-0562-000	BODY, CASSETTE (LTR)
10	RB1-2380-000	LIFTER	10	RF5-0435-050	PLATE, PAPER LIFTING
11	RB1-2381-000	ARM (3)	10A	RB1-2388-000	SHEET, FRICTION
12	RB1-2384-000	CLAW, PAPER SEPARATING	10B	RS2-8162-000	LABEL, INSTRUCTIONS
13	RB1-2386-000	PIN	11	RS5-2187-000	SPRING, COMPRESSION
14	RB1-2389-000	SPRING, TORSION	12	RS5-2188-000	SPRING, COMPRESSION
15	RB1-2739-000	SPRING, LEAF	13	RS5-2189-000	SPRING, COMPRESSION
16	RB1-2740-000	PLATE, CHANGING	14	RB1-2960-000	COVER (A4)
17	RS5-2186-000	SPRING, COMPRESSION		RB1-2961-000	COVER (LTR)
18	RS5-2187-000	SPRING, COMPRESSION			
19	RS5-2188-000	SPRING, COMPRESSION			
20	RF5-0563-000	BODY, CASSETTE			
21	RF5-0430-000	PLATE, SIDE			
22	RF5-0431-040	PLATE, PAPER LIFTING			
22A	RB1-2388-000	SHEET, FRICTION			
22B	RS2-8163-000	LABEL, INSTRUCTIONS			
23	RF5-0432-030	HOLDER, ROLLER			
24	RB1-2964-000	COVER, LGL			
25	RB1-2426-000	SPACER			
501	XD3-2300-322	PIN, DOWEL			

FIGURE 310 PAPER PICK-UP ASS'Y 1





FIGURE 310 PAPER PICK-UP ASS'Y 2



NUM.	PART #	DESCRIPTION	NUM.	PART #	DESCRIPTION
310-	RG5-1431-000	PAPER PICK-UP ASS'Y	310-		
1	RB1-2127-000	ROLLER, MP TRAY PICK-UP	17K	RG5-0514-000	SENSOR PCB ASS'Y
2	RB1-2128-000	GUIDE	18	RG5-0466-000	SENSOR HOLDER ASS'Y
3	RB1-2129-000	GUIDE, MP TRAY, UPPER	18A	RB1-2132-000	ARM, SENSOR, 1
4	RB1-2131-000	GUIDE	18B	RB1-2133-000	ARM, SENSOR, 2
5	RB1-2137-000	FRAME, PAPER FEED, RIGHT	18C	RB1-2134-000	HOLDER, SENSOR
6	RB1-2138-000	LEVER, SWITCH	18D	RS5-2171-000	SPRING, TENSION
7	RB1-2139-030	SPRING, LEAF	18E	WG8-0291-000	IC, TLP1230, PHOTO INTERRUPTER (2)
8	RB1-2168-000	ARM, SENSOR	18F	RG5-0528-000	SENSOR, CABLE
9	RB1-2169-000	SPRING, TORSION	19	RG5-0467-060	MP TRAY BASE ASS'Y
10	RB1-2181-000	HOLDER, GUIDE ROLLER	19A	RB1-2192-000	PLATE
11	RB1-2182-000	ROLLER, GUIDE	19B	RB1-2149-000	SHEET, SEPARATION
12	RB1-2186-000	COVER, SENSOR	19C	RB1-2152-000	ROLLER, ARM
13	RB1-2187-000	MOUNT, CONNECTOR	20	RG5-0529-000	MOTOR DRIVER/E.FEEDER CABLE
14	RB1-2126-000	ROLLER, PICK-UP	21	RG5-0512-000	PICK-UP MOTOR DRIVER PCB ASS'Y
15	RB1-3561-000	SPRING, TENSION	22	RH7-1197-000	MOTOR, STEPPING
16	RF5-0346-000	GUIDE, OPENING	23	RS5-2175-000	SPRING, COMPRESSION
17	RG5-0462-100	MP TRAY GUIDE ASS'Y	24	RB1-3488-000	PLATE, GROUNDING
17A	RB1-2170-000	GUIDE, MP TRAY	25	XA9-0591-000	SCREW, M3X8 (7)
17B	RB1-2171-000	COVER, MP TRAY GUIDE	26	XA9-0667-000	SCREW, W/WASHER, M3X21.5 (2)
17C	RB1-2173-000	HOLDER, SEPARATION PAD	27	RB1-2197-000	PIN, SENSOR HOLDER
17D	RB1-2175-040	PAD, SUB	501	XB1-2300-607	SCREW, MACH., TRUSS HEAD, M3X6 (4)
17E	RB1-2176-030	ARM, SENSOR			
17F	RB1-2177-000	LEVER, SENSOR			
17G	RF5-0343-000	PAD, SEPARATION			
17H	RS5-2176-000	SPRING, COMPRESSION			
17J	RB1-2194-000	PLATE, GROUNDING			





<p>FIGURE 320 TRANSFER GUIDE ASS'Y</p> 			<p>FIGURE 340 MULTI-PURPOSE TRAY ASS'Y</p> 		
NUM.	PART #	DESCRIPTION	NUM.	PART #	DESCRIPTION
320-	RG5-0469-020	TRANSFER GUIDE ASS'Y	340-	RG5-0635-000	MULTI-PURPOSE TRAY ASS'Y
1	RB1-2116-000	BASE, GUIDE	1	RB1-2930-000	GUIDE, SLIDE
2	RB1-2237-020	ELIMINATOR, STATIC CHARGE	2	RB1-2146-000	SPRING, SLIDE
3	RB1-2244-000	GUIDE, UPPER	3	RF5-0557-000	TRAY
4	XA9-0267-000	SCREW, TP, M3X6 (3)	3A	RS2-8161-000	LABEL, LIMIT

FIGURE 370 PAPER DELIVERY ASS'Y





FIGURE 371 DELIVERY SENSOR ASS'Y



NUM.	PART #	DESCRIPTION	NUM.	PART #	DESCRIPTION
370-	RG5-1425-000	PAPER DELIVERY ASS'Y	371-	RG5-0475-060	DELIVERY SENSOR ASS'Y
1	RB1-2295-000	SPRING, LEAF	1	RB1-2109-030	HOLDER, SENSOR
2	RB1-2928-000	FRAME, DELIVERY	2	RB1-2110-000	LEVER, SENSOR
3	RB1-2299-030	ROLLER, DELIVERY (4)	3	RS5-2169-000	SPRING, TENSION
4	RB1-2302-000	SPRING, ROLLER (4)	4	RB1-2115-040	ARM, SENSOR
5	RB1-2306-000	ARM	5	WG8-0291-000	IC, TLP1230, PHOTO INTERRUPTER
6	RB1-2307-000	SHAFT			
7	RF5-0335-000	PLATE, POSITIONING			
8	RF5-0425-040	HOLDER, ROLLER (4)			
9	RF5-1077-000	ROLLER, DELIVERY, LOWER			
10	RF5-0647-000	UPPER GUIDE, DELIVERY			
10A	RB1-2309-000	ELIMINATOR, STATIC CHARGE			
10B	RB1-2294-000	SPRING, GROUNDING			
11	RF5-1076-000	ROLLER, DELIVERY, UPPER			
12	RS5-0228-000	GEAR, 25T			
13	RS5-0229-000	GEAR, 23T			
14	RS5-1059-000	BUSHING			
15	RS5-1060-000	BUSHING			
16	RS5-2184-000	SPRING, TENSION			
17	RS5-2267-000	SPRING, COMPRESSION (4)			
18	XD9-0131-000	RING, E			
19	XF9-0410-000	BELT, COGGED			
20	RB1-5775-000	PLATE, MYLAY			
501	XD2-1100-402	RING, E			

FIGURE 810 FIXING ASS'Y 1





FIGURE 810 FIXING ASS'Y 2



NUM.	PART #	DESCRIPTION
810-	RG5-0879-000	FIXING ASS'Y
1	FB1-0253-000	RING, RETAINING (2)
2	RB1-2286-000	SPRING, GUIDE
3	RB1-3515-000	FRAME, FIXING, UPPER
4	RB1-3516-000	ROLLER, UPPER
5	RB1-3517-000	ROLLER, LOWER
6	RB1-3518-000	GUIDE, PAPER ENTRANCE
7	RB1-3522-000	LEVER, SENSOR
8	RB1-3523-000	LEVER, RELEASE, LEFT
9	RB1-3526-000	GUIDE, SEPARATION, LOWER
10	RB1-3527-000	LEVER, RELEASE, RIGHT
11	RB1-3528-000	WASHER, GROUNDING
12	RF5-0716-000	SCREW, STEPPED, W/WASHER, M3 (2)
13	RF5-0735-000	FRAME, FIXING
14	RF5-0736-000	COVER, RIGHT
15	RF5-0737-000	COVER, LEFT
16	RF5-0738-000	COVER, WIRE
16A	RS5-8380-000	LABEL, CAUTION
17	RF5-0744-000	GUIDE, SEPARATION
17A	RS5-8380-000	LABEL, CAUTION
18	RG5-0881-000	THERMOSWITCH ASS'Y
19	RG5-0977-000	FIXING CABLE ASS'Y
20	RH7-4054-000	HEATER, HALOGEN
21	RH7-7054-000	THERMISTOR
22	RS5-0231-000	GEAR, 19T
23	RS5-0388-000	GEAR, 42T
24	RS5-0393-000	GEAR, 23T

NUM.	PART #	DESCRIPTION
810-25	RS5-1097-000	BUSHING, ROLLER, RIGHT
26	RS5-1098-000	BUSHING, ROLLER, LEFT
27	RS5-1099-000	BUSHING, LOWER ROLLER (2)
28	RS5-2180-000	SPRING, TENSION (2)
29	RS5-2265-000	SPRING, COMPRESSION (2)
30	RS5-9055-000	SCREW, STEPPED, M3
31	XA9-0267-000	SCREW, TP, M3X6 (2)
32	XA9-0678-000	SCREW, TP, M3X3
33	XA9-0702-000	SCREW, W/WASHER, M3X6 (4)