

2X500 SHEET PAPER DECK PD-82K

PARTS CATALOG

REVISION 0

Canon

JAN. 1999

RY8-3302-000

PREFACE

This Parts Catalog contains listings of parts used in the 2X500 SHEET PAPER DECK PD-82K. Diagrams are provided with the listings to aid the service technician in clearly identifying the item to be ordered.

Whenever ordering parts, consult this Parts Catalog for all of the information pertaining to each item. Be sure to include in the Parts Request the full item description, the item part number, and the quantity. The parts catalog may be revised if there is significant product modification. For minor product modifications, a Service Information Bulletin will be issued.

Canon Inc.

Peripheral Products Quality Planning Div.
Peripheral Products Technical Documentation Dept
5-1, Hakusan 7-chome, Toride-shi, Ibaraki 302-8501, Japan

COPYRIGHT © 1999 CANON INC.

Printed in Japan

Imprimé au Japon

Use of this manual should be strictly supervised to avoid disclosure of confidential information.

LIST OF ORDER AND SERIAL NUMBERS

NAME	REMARKS	ORDER No.	SERIAL No.
2X500 SHEET PAPER DECK PD-82K		R95-3015	LJN00001-

CONTENTS

RA. ASSEMBLY LOCATION DIAGRAM

R10. EXTERNAL COVERS, PANELS, ETC.

R15. INTERNAL COMPONENTS

R20. PAPER DECK DRIVE ASS'Y

R30. CASSETTE (LOWER)

R31. CASSETTE (UPPER)

R40. PAPER PICK-UP ASS'Y

R50. PAPER FEED ASS'Y

R90. PCB ASS'Y LOCATION DIAGRAM

RB. NUMERICAL INDEX

HOW TO USE PARTS LISTS

Assembly Location Diagrams. These diagrams show the locations of major assemblies of the machine. Their names are identified in rectangular boxes. Below each box is the number of the Figure which shows an exploded view of the assembly.

Finding a Parts Number. Refer to the Assembly Location Diagrams and find the Figure Number of the assembly of interest. Turn to the page(s), locate the part on the exploded view, and find its Key Number. Refer to the Parts List on the page facing the exploded view and find the Key Number, Part Number and quantity required for your type of machine.

Note : While looking for a Part Number, pay particular attention to the voltage listed in the SERIAL NUMBER/REMARKS column to ensure that the Part Number selected is for your type of machine. Immediate shipping or action regarding the part depends on using its correct Part Number.

Parts List pages. The Parts List pages contain the following columns and information.

(1) Figure and Key Number column. The first column shows the Figure Number of the illustration corresponding to the Parts List, and the Key Number that identifies the part on the illustration.

(2) Part Number. The second column shows the Part Number for the part. This Number must be used when ordering replacement parts or assemblies described in the description column do not have a Part Number and are not stocked.

Note : The last three digits (suffix) of the Parts Number are called the Revision Number. The Revision Number is changed if the part is modified. Information regarding such changes will be provided by Service Information Bulletins. These Bulletins should be read carefully.

(3) Rank N. Parts marked "N" are service parts, but are not stock items. They are produced on a special-order basis.

(4) Quantity column. The quantity shown in this column is the number of parts used in the Figure. However, the quantity listed for an assembly indicates the number of that assembly per machine. The letters in this column indicate that the quantity of a parts is not specified, allowing the use of the number of parts needed for assembly and that the quantity cannot be mentioned clearly.

(5) Description column. The Description column lists the description that should be used when ordering the part.

(6) Serial Number/Remarks. When there are differences in the specifications of power supply voltage, frequency, etc., the differences are described in words or indicated by one two or three letters in front of the serial number.

(Example)

Serial number ABC00001
 ↑ This is the descriptive indicator.

If a model modified and a part is no longer interchangeable, the serial number of machines for which the part can be used is shown in this column. If there is no indication the part can be used with all models.

Numerical Index. There is a Numerical Index at the end of this catalog; it lists in numerical order every Part Number contained in the Parts Lists. The Numerical Index contains the following columns and information.

(1) Part Number. The first column shows the Part Number.

(2) Figure and Key Number column. The second column lists the Figure and Key Number for each occurrence of the part in the illustrations.

FIGURE RA ASSEMBLY LOCATION DIAGRAM




FIGURE R10 EXTERNAL COVERS,PANELS,ETC.




FIGURE R15 INTERNAL COMPONENTS




FIGURE & KEY NO.	PART NUMBER	R A N K	Q' T Y	DESCRIPTION	SERIAL NUMBER / REMARKS
R15 -	NPN		RF	INTERNAL COMPONENTS	
1	RB2-3712-000		1	HOLDER, LED	
2	RG5-4205-000		3	OUTRIGER ASS'Y	
3	RG5-4021-000		1	DC POWER SUPPLY ASS'Y	
3A	VD7-1893-151		1	FUSE	
4	WT2-5526-000		4	HEXAGON BOLT, M4	
5	RB2-2460-000		1	MOUNT, ADJUSTER RIGHT REAR	
6	RB2-2461-000		5	SPACER, ADJUSTER	
7	RB2-2523-000		1	MOUNT, ADJUSTER RIGHT CENTOR	
8	RB2-2524-000		1	MOUNT, ADJUSTER LEFT REAR	
9	RB2-3687-000		1	MOUNT, PCB	
10	RB2-3696-000		1	MOUNT, ADJUSTER, RIGHT	
11	RB2-3697-000		1	MOUNT, ADJUSTER, LEFT	
12	RB2-3699-000		2	HOLDER	
13	RF5-2556-000		1	PIN, POSITIONING	
14	RB2-3691-000		2	COVER, ADJUSTER	
15	RB1-6432-000		1	COVER, EDGE, UPPER	
16	RB2-3711-000		1	COVER, EDGE, LOWER	
17	XA9-0912-000		8	SCREW, W/WASHER, M5X12	
18	XZ9-0442-000		4	CASTER	
19	RB1-7760-000		1	MOUNT	
20	RB1-7761-000		1	GUIDE, RAIL	
21	RF1-4050-000		1	LED CABLE 2	J209, J219
22	RG5-4203-000		1	ADJUSTER MOUNT ASS'Y	
23	RB2-3667-000		1	HOLDER, SIZE	
24	WT2-0239-000		6	CLAMP, CABLE	
25	WT2-5061-000		1	SUPPORT, CABLE	
26	RB1-6909-000		2	SPRING, LEAF	
27	RB2-3702-000		1	MOUNT, RAIL	
28	XA9-0267-000		4	SCREW, TP, M3X6	
29	RB2-3613-000		2	GUIDE, RAIL	
30	RB2-3614-000		2	RAIL, TRAY	
31	RB2-3615-000		2	ROD, RAIL	
32	RB2-3510-000		2	STOPPER, RAIL	
33	RS5-2499-000		2	SPRING, TENSION	
34	RS5-2500-000		2	SPRING, TENSION	
35	VS1-5820-003		1	CONNECTOR, 3P	
36	WT2-0507-000		3	CLAMP, CABLE	
37	RF1-4049-000		1	LED CABLE 1	J1, J229
37A	VS1-5820-003		1	CONNECTOR, 3P	J219A
38	XA9-0732-000		25	SCREW, RS, M4X8	
39	XA9-0499-000		2	SCREW, W/WASHER, M4	
501	XB6-7300-607		12	SCREW, TP, M3X6	
502	XB6-7400-607		8	SCREW, TP, M4X6	

FIGURE R20 PAPER DECK DRIVE ASS'Y




FIGURE R30 CASSETTE (LOWER)




FIGURE & KEY NO.	PART NUMBER	R A N K	Q' T Y	DESCRIPTION	SERIAL NUMBER / REMARKS
R30 -	NPN		RF	CASSETTE (LOWER)	
1	RB1-6991-000		1	PANEL, FRONT	
1A	RS6-8038-000		1	LABEL, "OPERATION"	
1B	RS5-8665-000		1	LABEL, CASSETTE SIZE DISPLAY	LTR/A4, LGL/B4 11X17/A3
2	RB1-6875-020		1	PLATE, GROUNDING	
3	RB1-6877-000		1	CAM, SIZE, B	
4	RB1-6878-000		1	CAM, SIZE, C	
5	RB1-6879-000		1	CAM, SIZE, D	
6	RB1-6881-020		4	SPRING, TENSION	
7	RB1-6882-000		1	GEAR, 20T	
8	RB1-6883-000		1	PLATE, LOCK	
9	RB1-6884-000		1	LATCH, CASSETTE	
10	RB1-6885-000		1	SPRING, TENSION	
11	RB1-6887-000		1	PLATE, CHANGING	
12	RB1-6888-000		1	ARM, SENSOR	
13	RB1-6889-000		1	SHAFT, LATCH	
14	RB1-6890-000		1	BUSHING	
15	RB1-6891-000		1	SPRING, TENSION	
16	RB1-6892-000		1	SPRING, TENSION	
17	RB1-6893-000		1	SPRING, COMPRESSION	
18	RF5-2734-030		1	ROLLER, 1	
19	RB1-6895-000		1	ROLLER	
20	RB2-3589-000	N	1	BODY, CASSETTE	
21	RB1-6901-000		1	PLATE, GROUNDING	
22	RB1-6902-000		1	CAM, SIZE, A	
23	RB1-6903-000		1	SHAFT, CAM	
24	RB1-6904-000		3	CLIP	
25	RB1-6908-000		1	COVER, SIZE CAM	
26	RF5-2002-000		1	PLATE, END	
26A	RS6-8034-000		1	LABEL, "LIMIT"	
26B	RB1-6869-030		1	PLATE, REINFORCEMENT	
27	RF5-2712-000		1	PLATE, PAPER LIFTING	
27A	RB1-6872-000		1	SHEET, SEPARATION, LEATHER	
27B	RB1-6871-030		1	CUSHION	
28	RG5-3948-000		1	PANEL, LIMIT	
28A	RB1-6858-000		2	SPRING, LEAF	
28B	RB1-9619-000		1	LEVER, LOCK	
28C	RB1-9620-000		1	COVER, LEVER	
28D	RB1-6914-000		2	CLAW	
28E	XB1-2300-406		5	SCREW,MACH.,TRUSS HEAD,M3X4	
29	RG5-1910-000		1	PANEL, LIMIT	
29A	RB1-6861-000		1	PLATE, SIDE, FRONT	
29B	RB1-6863-000		1	PLATE, SIDE, REAR	
29C	RB1-6865-000		1	SPRING, LEAF	
29D	RB1-6867-000		1	SPRING, LEAF	
29E	XB1-2300-406		2	SCREW,MACH.,TRUSS HEAD,M3X4	
30	XA9-0283-000		1	SCREW, TP, M3X6	
31	RS6-8035-000		1	LABEL, OPERATION	
32	RB1-6784-000		1	PLATE, HOLDER	

FIGURE R31 CASSETTE (UPPER)




FIGURE & KEY NO.	PART NUMBER	R A N K	Q' T Y	DESCRIPTION	SERIAL NUMBER / REMARKS
R31 -	NPN		RF	CASSETTE (UPPER)	
1	RB1-6991-000		1	PANEL, FRONT	
1A	RS6-8038-000		1	LABEL, "OPERATION"	
1B	RS5-8644-000		1	LABEL, CASSETTE SIZE DISPLAY	LTR/A4, LGL/B4
2	RB2-3588-000	N	1	BODY, CASSETTE	
3	RB1-6874-000		1	PLATE, GROUNDING	
4	RB1-6875-020		1	PLATE, GROUNDING	
5	RB1-6876-000		1	CAM, SIZE, A	
6	RB1-6877-000		1	CAM, SIZE, B	
7	RB1-6878-000		1	CAM, SIZE, C	
8	RB1-6879-000		1	CAM, SIZE, D	
9	RB1-6880-000		1	SHAFT, CAM	
10	RB1-6881-020		4	SPRING, TENSION	
11	RB1-6882-000		1	GEAR, 20T	
12	RB1-6883-000		1	PLATE, LOCK	
13	RB1-6884-000		1	LATCH, CASSETTE	
14	RB1-6885-000		1	SPRING, TENSION	
15	RB1-6887-000		1	PLATE, CHANGING	
16	RB1-6888-000		1	ARM, SENSOR	
17	RB1-6889-000		1	SHAFT, LATCH	
18	RB1-6890-000		1	BUSHING	
19	RB1-6891-000		1	SPRING, TENSION	
20	RB1-6892-000		1	SPRING, TENSION	
21	RB1-6893-000		1	SPRING, COMPRESSION	
22	RF5-2734-030		1	ROLLER, 1	
23	RB1-6895-000		1	ROLLER	
24	RB1-6904-000		3	CLIP	
25	RB1-6907-000		1	COVER, SIZE CAM	
26	RF5-2002-000		1	PLATE, END	
26A	RS6-8034-000		1	LABEL, "LIMIT"	
26B	RB1-6869-030		1	PLATE, REINFORCEMENT	
27	RF5-2712-000		1	PLATE, PAPER LIFTING	
27A	RB1-6872-000		1	SHEET, SEPARATION, LEATHER	
27B	RB1-6871-030		1	CUSHION	
28	RG5-3948-000		1	PANEL, LIMIT	
28A	RB1-6858-000		2	SPRING, LEAF	
28B	RB1-9619-000		1	LEVER, LOCK	
28C	RB1-9620-000		1	COVER, LEVER	
28D	RB1-6914-000		2	CLAW	
28E	XB1-2300-406		5	SCREW,MACH.,TRUSS HEAD,M3X4	
29	RG5-1910-000		1	PANEL, LIMIT	
29A	RB1-6861-000		1	PLATE, SIDE, FRONT	
29B	RB1-6863-000		1	PLATE, SIDE, REAR	
29C	RB1-6865-000		1	SPRING, LEAF	
29D	RB1-6867-000		1	SPRING, LEAF	
29E	XB1-2300-406		5	SCREW,MACH.,TRUSS HEAD,M3X4	
30	XA9-0283-000		1	SCREW, TP, M3X6	
31	RS6-8035-000		1	LABEL, OPERATION	
32	RB1-6784-000		1	PLATE, HOLDER	
33	XA9-0866-000		4	SCREW, W/WASHER, M3X7	

FIGURE & KEY NO.	PART NUMBER	R A N K	Q' T Y	DESCRIPTION	SERIAL NUMBER / REMARKS
R31 - 34	RS5-8593-000		1	LABEL, CASSETTE	LTR/A4, LGL/B4
35	RB1-6911-000		1	PLATE, REINFORCEMENT	
36	RB1-6913-000		1	COVER, PROTECTIVE	
37	RB1-6917-000		1	STOPPER, TRAY	
38	RB1-6916-000		1	SPRING, COMPRESSION	
39	XD9-0170-000		1	PIN, DOWEL	
40	RB1-6992-000		1	PLATE, CASSETTE SIZE DISPLAY	
41	RS6-8666-000		1	LABEL, CASSETTE SIZE DISPLAY	
42	RB2-3593-000		1	GUIDE, NIP	
501	XD1-1105-233		1	WASHER, SHIM	

FIGURE R40 PAPER PICK-UP ASS'Y (1/3)




FIGURE R40 PAPER PICK-UP ASS'Y (2/3)




FIGURE R40 PAPER PICK-UP ASS'Y (3/3)




FIGURE & KEY NO.	PART NUMBER	R A N K	Q' T Y	DESCRIPTION	SERIAL NUMBER / REMARKS
R40 -	RG5-4410-000		1	PAPER PICK-UP ASS'Y	
1	RB1-6585-000		2	HOLDER, ROLLER	
2	RB2-3713-000		2	LIMITER, TORQUE	
3	RF5-1834-000		4	ROLLER, FEED	
4	RF5-2708-000		2	ROLLER, PICK-UP	
5	RS5-0739-000		2	GEAR, 38T	
6	RS5-0740-000		2	GEAR, 18T	
7	RS5-1179-000		1	BUSHING	
8	XA9-0836-000		15	SCREW, TP, M3X6	
9	RB1-7085-000		1	PIN	
10	RB1-6580-000		2	PLATE, GROUNDING	
11	RB1-6586-000		2	SHAFT, FRONT	
12	RB2-3587-000		2	FLAG, PAPER SENSING	
13	RB1-6591-000		2	ROD, RELEASE	
14	RS5-0732-020		2	GEAR, 31T	
15	RS5-0733-000		2	GEAR, 20T/41T	
16	RS5-0744-000		2	GEAR, 23T	
17	RS5-0745-000		2	GEAR, 31T	
18	RS5-2481-000		2	SPRING, TENSION	
19	RS5-2482-000		4	SPRING, TENSION	
20	RS5-2480-000		2	SPRING, COMPRESSION	
21	RF5-1423-000		2	SHAFT, CONNECTING	
22	RF5-1424-000		2	LIFTER	
23	RB2-3673-000		1	MOUNT, UPPER	
24	RB2-3682-000		1	CROSSMEMBER, GUIDE, UPPER	
25	RS5-1179-000		1	BUSHING	
26	RB1-6561-000		1	ROLLER, PAPER FEED	
27	RS5-0736-000		1	GEAR, 16T	
28	RS5-0737-000		1	GEAR, 40T	
29	RS5-1009-000		1	BUSHING	
30	RB2-2503-000		2	ROLLER, FEED	
31	RB2-3706-000		1	GUIDE, PAPER	
32	RB2-3707-000		2	SPRING, TORSION	
33	RS5-2479-000		3	SPRING, TENSION	
34	RB1-6528-000		2	SPRING, LEAF	
35	RB1-6535-000		1	CAM, PAPER PICK-UP	
36	RB1-6543-000		1	LEVER, OPEN/CLOSE SENSING	
37	RB1-6544-000		2	LINK, LIFTER	
38	RB1-6545-000		1	BLOCK, PICK-UP LOCK, UPPER	
39	RB1-6546-000		1	BLOCK, PICK-UP LOCK, LOWER	
40	RB1-6547-000		1	TRIGGER, LIFTER, UPPER	
41	RB1-6548-000		1	TRIGGER, LIFTER, LOWER	
42	RB1-6549-000		1	ARM, LIFTER, UPPER	
43	RB1-6550-000		1	ARM, LIFTER, LOWER	
44	RB1-6551-000		2	ARM, CONNECTING	
45	RS5-0734-000		1	GEAR, 100T	
46	RS5-0735-000		1	GEAR, 32T	
47	RS5-2476-020		2	SPRING, TENSION	
48	RS5-2477-000		2	SPRING, TORSION	
49	RS5-2478-000		2	SPRING, TENSION	

FIGURE & KEY NO.	PART NUMBER	R A N K	Q' T Y	DESCRIPTION	SERIAL NUMBER / REMARKS
R40 -	50		2	LEVER, LOCK, REAR	
	50A		1	LEVER, LOCK	
	50B		1	SPRING, LEAF	
	51		1	CAM, LIFT UP, UPPER	
	52		1	CAM, LIFT UP, LOWER	
	53		2	CLAW, LEFTER ARM	
	54		2	DAMPER	
	55		2	SPRING, TENSION	
	56		2	CLAW, LIFTER LOCK	
	57		2	LEVER, LEAD	
	58		2	BUSHING	
	59		1	IC, TLP1241, PHOTO-INTERRUPTER	PS3, J14
	60		1	SPRING, LEAF, 1	
	61		1	SPRING, LEAF, 2	
	62		1	PLATE, GROUNDING, 2	
	63		1	PLATE, GROUNDING, 3	
	64		1	PLATE, GROUNDING, 1	
	65		1	COVER, SMALL	
	66		1	GEAR, 31T/47T	
	67		1	CABLE, RIGHT DOOR SENSOR	J14, J1206
	68		1	PLATE, GUIDE, UPPER	
	69		1	HOLDER, ROLLER	
	70		1	BUSHING	
	71		1	MOTOR, STEPPING	SPM3, J1202
	72		1	SCREW, TP, M3X6	
	73		1	ROLLER, PAPER FEED, UPPER	
	74		1	CROSSMEMBER, GUIDE, LOWER	
	75		1	BLOCK, SUPPORT, LOWER	
	76		2	ARM, SEPARATION	
	77		2	SHAFT, SEPARATION	
	78		2	JOINT	
	79		2	JOINT	
	80		2	PIN, DOWEL	
	81		1	SOLENOID	SL1, J1203
	82		1	PAPER PICK-UP CABLE	J208, J1201
	83		1	PAPER PICK-UP PCB ASS'Y	SEE FIGURE R90
	501		6	SCREW, TAPPING, PAN HEAD, M4X10	
	502		9	RING, E	
	503		2	PIN, SPRING	
	504		2	PIN, DOWEL	
	505		2	PIN, SPRING	
	506		3	SCREW, TAPPING, PAN HEAD, M4X10	
	507		1	SCREW, TAPPING, TRUSS HEAD, M3X10	

FIGURE R50 PAPER FEED ASS'Y




FIGURE & KEY NO.	PART NUMBER	R A N K	Q' T Y	DESCRIPTION	SERIAL NUMBER / REMARKS
R50 -	RG5-4423-000		1	PAPER FEED ASS'Y	
1	FS5-0338-000		3	GEAR, 16T	
2	RB1-7818-000		4	ROLLER, FEED	
3	RB2-3728-000		1	PLATE, HINGE, FRONT	
4	RB2-3729-000		1	PLATE, HINGE, REAR	
5	RB1-7822-000		2	SPRING, TORSION	
6	RB1-7823-000		2	SPRING, TORSION	
7	RB1-7824-000		1	GUIDE, FEED, OUTER	
8	RB2-2510-000		1	ROLLER, REGISTRATION	
9	RB2-2511-000		1	ROLLER, FEED	
10	RB2-2512-000		1	SHAFT, ROLLER	
11	RB2-2513-000		1	SHAFT, HINGE	
12	RB2-3690-000		1	COVER, CLUTCH	
13	RF5-2774-000		1	COVER, FEED	
14	RF5-2765-000		1	GUIDE, FEED, INNER	
14A	RS6-8010-000		1	LABEL, FEED	
15	RH7-5226-000		1	MOTOR, STEPPING	SPM2, J302
16	RH7-5201-000		1	CLUTCH, ELECTROMAGNETIC	CL1, J1306
17	RS5-0852-000		2	GEAR, 36T	
18	RS5-1202-000		4	BUSHING	
19	RS5-1203-000		2	BUSHING	
20	RS5-2557-000		2	SPRING, TENSION	
21	RS5-2565-000		2	SPRING, COMPRESSION	
22	RS6-0406-000		1	GEAR, 38T/71T	
23	RS6-0407-000		1	GEAR, 19T/71T	
24	VS1-5820-004		1	CONNECTOR, 4P	J302A
25	XA9-0591-000		2	SCREW, M3X8	
26	XA9-0946-000		2	SCREW, W/WASHER, M3X4	
27	RG5-3858-000		4	FEED ROLLER ASS'Y	
27A	RB2-2503-000		1	ROLLER, FEED	
27B	RB2-2505-000		1	SPRING, TORSION	
28	RB2-2503-000		2	ROLLER, FEED	
29	RB2-3672-000		1	GUIDE, FEED, LOWER	
30	RB2-3707-000		2	SPRING, TORSION	
31	RB1-3001-000		2	FOOT	
32	RB1-7813-000		1	LEVER, REGIST SENSOR	
33	RB1-7814-000		1	LEVER, JAM SENSOR	
34	RB2-2502-000		2	BUSHING	
35	RS5-2556-000		2	SPRING, TENSION	
36	WG8-5362-000		1	IC, TLP1241, PHOTO-INTERRUPTER	PS1, J308
37	WT2-0204-000		1	CLIP, CABLE	
38	WT2-0507-000		2	CLAMP, CABLE	
39	WT2-5035-000		2	CLAMP, CABLE	
40	RB2-2501-000		1	PLATE, HOLDER, SENSOR	
41	WG8-5362-000		1	IC, TLP1241, PHOTO-INTERRUPTER	PS2, J307
42	RG5-4439-000		1	FEEDER CABLE	J305, J307, J308
42A	VS1-5057-006		1	CONNECTOR, 6P	J209A
43	RB2-2508-020		1	PLATE, MOUNT, MOTOR	
44	RB2-3730-000		1	LEVER, HINGE, FRONT	
45	RB2-3731-000		1	LEVER, HINGE, REAR	

FIGURE R90 PCB ASS'Y LOCATION DIAGRAM




FIGURE & KEY NO.	PART NUMBER	R A N K	Q' T Y	DESCRIPTION	SERIAL NUMBER / REMARKS
R90 -	NPN		RF	PCB ASS'Y LOCATION DIAGRAM	
1	RG5-1845-000		2	CASSETTE-SIZE SENSING PCB ASS'Y	
2	RG5-1860-030		1	PAPER PICK-UP PCB ASS'Y	
3	RG5-4442-020		1	DECK DRIVER PCB ASS'Y	
4	RG5-4441-000		1	LED PCB ASS'Y	
<hr/>					
<hr/>					
<hr/>					

RB NUMERICAL INDEX

PART NUMBER	FIGURE & KEY NO.	PART NUMBER	FIGURE & KEY NO.	PART NUMBER	FIGURE & KEY NO.
FS5-0338-000	R50 - 1	RB1-6891-000	R30 - 15	RB2-3707-000	R40 - 32
RB1-3001-000	R50 - 31		R31 - 19		R50 - 30
RB1-6432-000	R15 - 15	RB1-6892-000	R30 - 16	RB2-3711-000	R15 - 16
RB1-6526-000	R40 - 60		R31 - 20	RB2-3712-000	R15 - 1
RB1-6527-000	R40 - 61	RB1-6893-000	R30 - 17	RB2-3713-000	R40 - 2
RB1-6528-000	R40 - 34		R31 - 21	RB2-3719-000	R10 - 10
RB1-6529-000	R40 - 80	RB1-6895-000	R30 - 19	RB2-3720-000	R10 - 5
RB1-6533-000	R40 - 50A		R31 - 23	RB2-3721-000	R10 - 1
RB1-6534-000	R40 - 50B	RB1-6901-000	R30 - 21	RB2-3722-000	R10 - 2
RB1-6535-000	R40 - 35	RB1-6902-000	R30 - 22	RB2-3723-000	R10 - 6
RB1-6538-000	R40 - 53	RB1-6903-000	R30 - 23	RB2-3724-000	R10 - 8
RB1-6539-000	R40 - 54	RB1-6904-000	R30 - 24	RB2-3728-000	R50 - 3
RB1-6540-000	R40 - 56		R31 - 24	RB2-3729-000	R50 - 4
RB1-6541-000	R40 - 57	RB1-6907-000	R31 - 25	RB2-3730-000	R50 - 44
RB1-6543-000	R40 - 36	RB1-6908-000	R30 - 25	RB2-3731-000	R50 - 45
RB1-6544-000	R40 - 37	RB1-6909-000	R15 - 26	RB2-3732-000	R50 - 46
RB1-6545-000	R40 - 38	RB1-6911-000	R31 - 35	RF1-4049-000	R15 - 37
RB1-6546-000	R40 - 39	RB1-6912-000	R30 - 35	RF1-4050-000	R15 - 21
RB1-6547-000	R40 - 40	RB1-6913-000	R30 - 36	RF1-4052-000	R40 - 82
RB1-6548-000	R40 - 41		R31 - 36	RF5-1415-000	R40 - 50
RB1-6549-000	R40 - 42	RB1-6914-000	R30 - 28D	RF5-1417-000	R40 - 51
RB1-6550-000	R40 - 43		R31 - 28D	RF5-1418-000	R40 - 52
RB1-6551-000	R40 - 44	RB1-6916-000	R30 - 38	RF5-1423-000	R40 - 21
RB1-6561-000	R40 - 26		R31 - 38	RF5-1424-000	R40 - 22
RB1-6563-000	R40 - 75	RB1-6917-000	R30 - 37	RF5-1834-000	R40 - 3
RB1-6565-000	R40 - 79		R31 - 37	RF5-2002-000	R30 - 26
RB1-6567-000	R40 - 62	RB1-6991-000	R30 - 1		R31 - 26
RB1-6568-000	R40 - 63		R31 - 1	RF5-2556-000	R15 - 13
RB1-6569-030	R40 - 77	RB1-6992-000	R30 - 40	RF5-2708-000	R40 - 4
RB1-6570-000	R40 - 76		R31 - 40	RF5-2712-000	R30 - 27
RB1-6571-000	R40 - 78	RB1-7085-000	R40 - 9		R31 - 27
RB1-6579-000	R40 - 64	RB1-7760-000	R15 - 19	RF5-2734-030	R30 - 18
RB1-6580-000	R40 - 10	RB1-7761-000	R15 - 20		R31 - 22
RB1-6585-000	R40 - 1	RB1-7813-000	R50 - 32	RF5-2765-000	R50 - 14
RB1-6586-000	R40 - 11	RB1-7814-000	R50 - 33	RF5-2766-000	R10 - 14
RB1-6591-000	R40 - 13	RB1-7818-000	R50 - 2	RF5-2768-000	R20 - 2
RB1-6598-000	R40 - 73	RB1-7822-000	R50 - 5	RF5-2773-000	R10 - 9
RB1-6599-000	R40 - 65	RB1-7823-000	R50 - 6	RF5-2774-000	R50 - 13
RB1-6784-000	R30 - 32	RB1-7824-000	R50 - 7	RG5-1845-000	R90 - 1
	R31 - 32	RB1-9619-000	R30 - 28B	RG5-1860-030	R40 - 83
RB1-6858-000	R30 - 28A		R31 - 28B		R90 - 2
	R31 - 28A	RB1-9620-000	R30 - 28C	RG5-1862-000	R40 - 67
RB1-6861-000	R30 - 29A		R31 - 28C	RG5-1910-000	R30 - 29
	R31 - 29A	RB2-2460-000	R15 - 5		R31 - 29
RB1-6863-000	R30 - 29B	RB2-2461-000	R15 - 6	RG5-3858-000	R50 - 27
	R31 - 29B	RB2-2501-000	R50 - 40	RG5-3948-000	R30 - 28
RB1-6865-000	R30 - 29C	RB2-2502-000	R50 - 34		R31 - 28
	R31 - 29C	RB2-2503-000	R40 - 30	RG5-4021-000	R15 - 3
RB1-6867-000	R30 - 29D		R50 - 27A	RG5-4203-000	R15 - 22
	R31 - 29D	RB2-2505-000	R50 - 28	RG5-4205-000	R15 - 2
RB1-6869-030	R30 - 26B	RB2-2508-020	R50 - 27B	RG5-4410-000	R40 -
	R31 - 26B	RB2-2510-000	R50 - 43	RG5-4416-000	R20 -
RB1-6871-030	R30 - 27B	RB2-2511-000	R50 - 8	RG5-4423-000	R50 -
	R31 - 27B	RB2-2512-000	R50 - 9	RG5-4439-000	R50 - 42
RB1-6872-000	R30 - 27A	RB2-2513-000	R50 - 10	RG5-4441-000	R90 - 4
	R31 - 27A	RB2-2513-000	R50 - 11	RG5-4442-020	R90 - 3
RB1-6874-000	R31 - 3	RB2-2523-000	R15 - 7	RH2-5310-000	R10 - 11
RB1-6875-020	R30 - 2	RB2-2524-000	R15 - 8	RH7-1262-000	R40 - 71
	R31 - 4	RB2-3510-000	R15 - 32	RH7-5201-000	R50 - 16
RB1-6876-000	R31 - 5	RB2-3587-000	R40 - 12	RH7-5215-000	R20 - 6
RB1-6877-000	R30 - 3	RB2-3588-000	R31 - 2	RH7-5218-000	R40 - 81
	R31 - 6	RB2-3589-000	R30 - 20	RH7-5226-000	R50 - 15
RB1-6878-000	R30 - 4	RB2-3593-000	R30 - 42	RS5-0728-000	R20 - 5
	R31 - 7		R31 - 42	RS5-0732-020	R40 - 14
RB1-6879-000	R30 - 5	RB2-3613-000	R15 - 29	RS5-0733-000	R40 - 15
	R31 - 8	RB2-3614-000	R15 - 30	RS5-0734-000	R40 - 45
RB1-6880-000	R31 - 9	RB2-3615-000	R15 - 31	RS5-0735-000	R40 - 46
RB1-6881-020	R30 - 6	RB2-3667-000	R15 - 23	RS5-0736-000	R40 - 27
	R31 - 10	RB2-3670-000	R10 - 3	RS5-0737-000	R40 - 28
RB1-6882-000	R30 - 7	RB2-3672-000	R50 - 29	RS5-0738-000	R40 - 66
	R31 - 11	RB2-3673-000	R40 - 23	RS5-0739-000	R40 - 5
RB1-6883-000	R30 - 8	RB2-3682-000	R40 - 24	RS5-0740-000	R40 - 6
	R31 - 12	RB2-3685-000	R40 - 68	RS5-0744-000	R40 - 16
RB1-6884-000	R30 - 9	RB2-3686-000	R40 - 74	RS5-0745-000	R40 - 17
	R31 - 13	RB2-3687-000	R15 - 9	RS5-0852-000	R50 - 17
RB1-6885-000	R30 - 10	RB2-3690-000	R50 - 12	RS5-1009-000	R40 - 29
	R31 - 14	RB2-3691-000	R15 - 14		R40 - 70
RB1-6887-000	R30 - 11	RB2-3693-000	R40 - 69	RS5-1179-000	R40 - 7
	R31 - 15	RB2-3696-000	R15 - 10		R40 - 25
RB1-6888-000	R30 - 12	RB2-3697-000	R15 - 11		R40 - 58
	R31 - 16	RB2-3699-000	R15 - 12	RS5-1202-000	R50 - 18
RB1-6889-000	R30 - 13	RB2-3701-000	R20 - 1	RS5-1203-000	R50 - 19
	R31 - 17	RB2-3702-000	R15 - 27	RS5-2476-020	R40 - 47
RB1-6890-000	R30 - 14	RB2-3705-000	R10 - 15	RS5-2476-020	R40 - 55
	R31 - 18	RB2-3706-000	R40 - 31	RS5-2477-000	R40 - 48

PART NUMBER	FIGURE & KEY NO.	PART NUMBER	FIGURE & KEY NO.	PART NUMBER	FIGURE & KEY NO.
RS5-2478-000	R40 - 49	XD3-2200-122	R40 - 504		
RS5-2479-000	R40 - 33		R50 - 505		
RS5-2480-000	R40 - 20	XD9-0170-000	R30 - 39		
RS5-2481-000	R40 - 18		R31 - 39		
RS5-2482-000	R40 - 19	XZ9-0379-000	R10 - 7		
RS5-2499-000	R15 - 33	XZ9-0442-000	R15 - 18		
RS5-2500-000	R15 - 34				
RS5-2556-000	R50 - 35				
RS5-2557-000	R50 - 20				
RS5-2565-000	R50 - 21				
RS5-8593-000	R30 - 34				
	R31 - 34				
RS5-8644-000	R31 - 1B				
RS5-8665-000	R30 - 1B				
RS5-8665-000	R30 - 1B				
RS5-8667-000	R30 - 41				
	R30 - 41				
RS5-9099-000	R10 - 12				
RS6-0406-000	R50 - 22				
RS6-0407-000	R50 - 23				
RS6-0546-000	R20 - 3				
RS6-8010-000	R50 - 14A				
RS6-8034-000	R30 - 26A				
	R31 - 26A				
RS6-8035-000	R30 - 31				
	R31 - 31				
RS6-8038-000	R30 - 1A				
	R31 - 1A				
RS6-8149-000	R10 - 14A				
RS6-8666-000	R31 - 41				
VD7-1893-151	R15 - 3A				
VS1-5057-002	R50 - 48				
VS1-5057-006	R50 - 47				
	R50 - 42A				
VS1-5820-003	R15 - 35				
	R15 - 37A				
VS1-5820-004	R20 - 4				
	R50 - 24				
WG8-5362-000	R40 - 59				
	R50 - 36				
	R50 - 41				
WT2-0204-000	R50 - 37				
WT2-0239-000	R15 - 24				
WT2-0507-000	R15 - 36				
	R50 - 38				
	R50 - 49				
WT2-5035-000	R50 - 39				
WT2-5061-000	R15 - 25				
WT2-5526-000	R15 - 4				
XA9-0267-000	R15 - 28				
	R40 - 72				
XA9-0283-000	R30 - 30				
	R31 - 30				
XA9-0499-000	R10 - 13				
	R15 - 39				
XA9-0591-000	R10 - 4				
	R50 - 25				
XA9-0732-000	R15 - 38				
XA9-0836-000	R40 - 8				
XA9-0866-000	R30 - 33				
	R31 - 33				
XA9-0912-000	R15 - 17				
XA9-0946-000	R50 - 26				
XB1-2300-406	R30 - 28E				
	R30 - 29E				
	R31 - 28E				
	R31 - 29E				
XB4-7301-007	R40 - 507				
XB4-7401-007	R40 - 501				
XB4-7401-009	R40 - 506				
XB6-7300-607	R10 - 501				
	R15 - 501				
	R20 - 501				
	R50 - 501				
XB6-7400-607	R15 - 502				
	R10 - 502				
XD1-1105-233	R30 - 501				
	R31 - 501				
XD2-1100-502	R40 - 502				
	R50 - 502				
XD2-1100-642	R50 - 503				
XD2-1200-502	R20 - 502				
XD3-1200-102	R40 - 505				
XD3-1200-122	R40 - 503				
XD3-2200-102	R50 - 504				

Prepared by
Peripheral Products Quality Planning Div.
Peripheral Products Technical Documentation Dept.
CANON INC.
Printed in Japan

REVISION 0 [JAN. 1999]

5-1, Hakusan 7-chome, Toride-shi, Ibaraki 302-8501, Japan



The printing paper contains
70% waste paper.

Canon