


FIGURE E10

CARD READER-C1



NOTE : This assembly does not include the parts shown with key No. 501 and 502.

FIGURE & KEY NO.	PART NUMBER	R A N K	Q' T Y	DESCRIPTION	SERIAL NUMBER / REMARKS
E10 -	FG3-1890-000		1	CARD READER-C1	
1	FB3-8873-000		2	SCREW,MACH.,TRUSS HEAD,M4X4	
2	FC1-8289-000		1	COVER, LOWER, GRAY (LIGHTER)	
3	FC3-0891-000		1	PANEL, CONTROL CARD	
4	FH5-3183-000		1	CARD READER UNIT	
5	FF3-2302-000		1	MOUNT, CONTROL CARD	
501	XB3-6401-000		1	SCREW,RS,M4X10	SEE NOTE
502	XD1-4100-402		1	WASHER,TOOTHED LOCK	SEE NOTE
503	XB1-2300-807		1	SCREW,MACH.,TRUSS HEAD,M3X8	
504	XB4-6261-209		4	SCREW,TAPPING,PAN HEAD,M2.6X12	
505	XB7-2200-307		1	NUT,HEX,M3	
506	XD1-4100-402		1	WASHER,TOOTHED LOCK	