



Service Bulletin

Issued by Canon Europa N.V.

Copier B/W

Hardware

Model:

iR5570
iR6570

Ref No.:

iR6570-015
(F1-T01-0M5-10041-01)

Date:

January, 2006

Location:

Service Manual

Subject:

The information about a SNMP setup is added to the Service Manual

Location:

Functions> External and Controls> Power Supply> Energy-Saving Function


Additional contents:

When the machine is used as a Windows printer, enabling 'Use SNMP' causes the operating system to collect machine status information at specific intervals, preventing the machine from starting a sleep state.

To avoid the situation, disable the setting (Windows' printer properties).

-Disabling 'Use SNMP'

1) Select 'Configure Port' on the Ports screen (printer properties).



F-1

2) Remove the check mark from 'SNMP Status Enabled'.

The image shows a Windows-style dialog box titled "Configure Standard TCP/IP Port Monitor". The dialog is divided into several sections:

- Port Settings:**
 - Port Name: IP_172.16.185.236
 - Printer Name or IP Address: 172.16.185.236
- Protocol:**
 - Raw
 - LPR
- Raw Settings:**
 - Port Number: 9100
- LPR Settings:**
 - Queue Name: (empty)
 - LPR Byte Counting Enabled
- SNMP Settings:**
 - SNMP Status Enabled
 - Community Name: public
 - SNMP Device Index: 1

At the bottom right, there are "OK" and "Cancel" buttons.

F-2