


FIGURE E20

CARD READER-D1



NOTE : This assembly does not include the parts shown with key No. 501 and 502.

FIGURE & KEY NO.	PART NUMBER	R A N K	Q' T Y	DESCRIPTION	SERIAL NUMBER / REMARKS
E20 -	FG3-1891-000		1	CARD READER-D1	
1	FH5-3183-000		1	CARD READER UNIT	
501	XB1-1400-607		1	SCREW,MACH.,PAN HEAD,M4X6	SEE NOTE
502	XB4-7301-009		4	SCREW,TAPPING,TRUSS HEAD,M3X10	SEE NOTE
<hr/>					
<hr/>					
<hr/>					