

DISASSEMBLY

Trademarks:

Canon Inc.'s trademark, logos, product names, service marks and those trademark, logos, product names, service marks licensed to Canon Inc. by any of its affiliate or subsidiary are registered or unregistered marks of Canon Inc. or such affiliate or subsidiary in Japan and/or other countries.

Adobe, the Adobe logo, Acrobat, the Acrobat logo and Reader are either registered trademarks or trademarks of Adobe Systems Incorporated in the United States of America and/or other countries. All other trademarks, product names, service marks are generally either registered or unregistered marks of their respective owners.

Copyright:


All copyrights in the content of this Service Manual are owned or controlled by Canon Inc. You are not permitted to copy, reproduce, download, modify, adapt or translate in any way the content of this Service Manual for any purpose other than the purpose contemplated herein without prior written consent of Canon Inc.

CONTENTS

1.1 BATTERY CASE COVER	1
1.2 INK CASSETTE DOOR, PAPER CASSETTE DOOR	2
1.3 TOP COVER SECTION-(1)	3
1.4 TOP COVER SECTION-(2)	4
1.5 INK CASSETTE DOOR HOOK	5
1.6 MAIN ASS'Y, BOTTOM ASS'Y	6
1.7 USB COVER, I/F COVER	7
1.8 BOTTOM COVER ASS'Y, BATTERY CASE ASS'Y	8
1.9 MAIN SHIELD, MAIN SHEET	9
1.10 MAIN PCB SECTION, PRINT UNIT	10
1.11 SW PCB ASS'Y	11
1.12 MAIN PCB ASS'Y, MAIN-SW FPC	12
1.13 SHIELD COVER (SELPHY CP710)	13
1.14 CROSS BUTTON (SELPHY CP710)	14
1.15 OP PCB ASS'Y, OP FPC (SELPHY CP710)	15
1.16 LCD UNIT, LCD CUSHION, PRINT BUTTON (SELPHY CP710)	16
1.17 TOP COVER ASS'Y, BUTTON COVER (PRINT) (SELPHY CP710)	17

1.1 BATTERY CASE COVER

- (1) Remove the BATTERY CASE COVER.




1.2 INK CASSETTE DOOR, PAPER CASSETTE DOOR

(1) Remove the INK CASSETTE DOOR.

CAUTION

Remove the INK CASSETTE DOOR or the PAPER CASSETTE DOOR by bending the INK CASSETTE DOOR/PAPER CASSETTE DOOR slightly in the direction of the arrow as shown in the figure.

(2) Remove the PAPER CASSETTE DOOR.



1.3 TOP COVER SECTION-(1)


(1) Remove the four screws.

CAUTION

The slots in the top of the screws can be easily rounded off, so use the appropriate size driver for these screws and be careful when removing them.

NOTE (Assembly)

When installing the TOP COVER SECTION, run the lead wire into the groove.




CAUTION

The slots in the top of the screws can be easily rounded off, so use the appropriate size driver for these screws and be careful when removing them.

NOTE (Assembly)


TOP COVER SECTION



1.4 TOP COVER SECTION-(2)

[SELPHY CP710]


- (1) Open the TOP COVER SECTION in the direction of the arrow.
Then disconnect the connector and remove the TOP COVER SECTION.



[SELPHY CP710]

[SELPHY CP510]

- (1) Open the TOP COVER SECTION in the direction of the arrow.
Then disconnect the connector and remove the TOP COVER SECTION.




[SELPHY CP510]

1.5 INK CASSETTE DOOR HOOK

- (1) Remove the three screws.
- (2) Disconnect the connector.
- (3) Remove the INK CASSETTE DOOR HOOK.


CAUTION

Remove the INK CASSETTE DOOR HOOK in the direction of the arrow B while bending the side portion a little in the direction of the arrow A.



CAUTION

Remove the INK CASSETTE DOOR HOOK in the direction of the arrow B while bending the side portion a little in the direction of the arrow A.



1.6 MAIN ASS'Y, BOTTOM ASS'Y

- (1) Separate the MAIN ASS'Y and the BOTTOM ASS'Y.

CAUTION


Never hold the area around the front plate when separating or reassembling the MAIN ASS'Y and the BOTTOM ASS'Y. Be sure to hold the area around the cassette guide.

Also be careful not to drop the USB COVER and the I/F COVER.


NOTE (Assembly)

Thread the lead wires to pass under the rib as shown in the figure.

- (2) Remove the USB COVER and the I/F COVER together as an assembled unit.




CAUTION



CAUTION

Be careful not to drop the USB COVER and the I/F COVER.

NOTE (Assembly)




1.7 USB COVER, I/F COVER

- (1) Separate the USB COVER and the I/F COVER.


NOTE (Assembly)

Attach the USB COVER and the I/F COVER each other, as shown in the figure.



1.8 BOTTOM COVER ASS'Y, BATTERY CASE ASS'Y

- (1) Separate the BATTERY CASE ASS'Y and the BOTTOM COVER ASS'Y.





1.9 MAIN SHIELD, MAIN SHEET

- (1) Disconnect the three connectors.
- (2) Remove the two screws, and remove the MAIN SHIELD and the MAIN SHEET.

NOTE (Assembly)

Fold the MAIN SHEET as shown in the figure. (SELPHY CP710 ONLY)



1.10 MAIN PCB SECTION, PRINT UNIT





- (1) Remove the screw.
- (2) Disengage the dowel.
- (3) Disconnect the connector, and separate the MAIN PCB SECTION and the PRINT UNIT.

NOTE (Assembly)

Fold the FLAT CABLE as shown in the figure.


Set the INK CASSETTE and check if it comes out smoothly.

If the fold on the FLAT CABLE is not enough, the INK CASSETTE will not come out.




1.11 SW PCB ASS'Y

- (1) Remove the soldering in nine places, and remove the SW PCB ASS'Y.




1.12 MAIN PCB ASS'Y, MAIN-SW FPC

- (1) Remove the soldering in nine places, and remove the MAIN PCB ASS'Y and the MAIN-SW FPC.



1.13 SHIELD COVER (SELPHY CP710)

- (1) Remove the screw, and remove the SHIELD COVER.
- (2) Remove the two screws, and disconnect the connector.




1.14 CROSS BUTTON (SELPHY CP710)

- (1) Remove the OP PCB ASS'Y and the OP FPC together as an assembled unit.
- (2) Remove the CROSS BUTTON.

CAUTION

Be careful not to drop the CROSS BUTTON.





1.15 OP PCB ASS'Y, OP FPC (SELPHY CP710)

(1) Disconnect the connector and separate the OP FPC from the OP PCB ASS'Y.

NOTE (Assembly)

Fold the OP FPC as shown in the figure.



1.16 LCD UNIT, LCD CUSHION, PRINT BUTTON (SELPHY CP710)

- (1) Remove the two screws, and remove the LCD UNIT and the LCD CUSHION.


CAUTION

Be careful not to drop the PRINT BUTTON.

NOTE (Assembly)

Attach the LCD CUSHION so that the glossy side faces the LCD UNIT.

- (2) Remove the PRINT BUTTON.



1.17 TOP COVER ASS'Y, BUTTON COVER (PRINT) (SELPHY CP710)

- (1) Undo the linked portion, and separate the BUTTON COVER (PRINT) from the TOP COVER ASS'Y.

