

DISASSEMBLY

Trademarks:

Canon Inc.'s trademark, logos, product names, service marks and those trademark, logos, product names, service marks licensed to Canon Inc. by any of its affiliate or subsidiary are registered or unregistered marks of Canon Inc. or such affiliate or subsidiary in Japan and/or other countries. Adobe, the Adobe logo, Acrobat, the Acrobat logo and Reader are either registered trademarks or trademarks of Adobe Systems Incorporated in the United States of America and/or other countries. All other trademarks, product names, service marks are generally either registered or unregistered marks of their respective owners.

Copyright:


All copyrights in the content of this Service Manual are owned or controlled by Canon Inc. You are not permitted to copy, reproduce, download, modify, adapt or translate in any way the content of this Service Manual for any purpose other than the purpose contemplated herein without prior written consent of Canon Inc.

CONTENTS

1.1 BATTERY CASE COVER -----	1
1.2 INK CASSETTE DOOR, PAPER CASSETTE DOOR -----	2
1.3 TOP COVER SECTION-(1) -----	3
1.4 TOP COVER SECTION-(2) -----	4
1.5 INK CASSETTE DOOR HOOK -----	5
1.6 MAIN ASS'Y, BOTTOM ASS'Y -----	6
1.7 BATTERY CASE ASS'Y, BATTERY TERMINAL ASS'Y, BOTTOM COVER ASS'Y (SELPHY CP730) --	7
1.8 BOTTOM COVER ASS'Y, FAN UNIT (SELPHY CP720) -----	8
1.9 MAIN SHIELD, MAIN SHEET -----	9
1.10 MAIN PCB SECTION, PRINT UNIT -----	10
1.11 LCD UNIT, LCD CUSHION -----	11
1.12 OPR PCB ASS'Y -----	12
1.13 MODE BUTTON, ON/OFF BUTTON, CROSS BUTTON, PRINT BUTTON, DISP. BUTTON -----	13

1.1 BATTERY CASE COVER

(1) Remove the BATTERY CASE COVER.




1.2 INK CASSETTE DOOR, PAPER CASSETTE DOOR

- (1) Remove the INK CASSETTE DOOR.

CAUTION

Remove the INK CASSETTE DOOR or the PAPER CASSETTE DOOR by bending the INK CASSETTE DOOR/PAPER CASSETTE DOOR slightly in the direction of the arrow as shown in the figure.

- (2) Remove the PAPER CASSETTE DOOR.



1.3 TOP COVER SECTION-(1)


- (1) Remove the four screws.

CAUTION

The slots in the top of the screws can be easily rounded off, so use the appropriate size driver for these screws and be careful when removing them.

NOTE (Assembly)


Route the lead wire as shown in the figure.



CAUTION


The slots in the top of the screws can be easily rounded off, so use the appropriate size driver for these screws and be careful when removing them.

NOTE (Assembly)



1.4 TOP COVER SECTION-(2)

- (1) Open the TOP COVER SECTION in the direction of the arrow.
Then disconnect the two connectors and remove the TOP COVER SECTION.




1.5 INK CASSETTE DOOR HOOK

- (1) Remove the three screws.
- (2) Disconnect the connector.

NOTE (Assembly)


Route the lead wires as shown in the figure.

- (3) Disconnect the connector. (SELPHY CP730 ONLY)
- (4) Remove the INK CASSETTE DOOR HOOK.




CAUTION

Remove the INK CASSETTE DOOR HOOK in the direction of the arrow B while bending the side portion a little in the direction of the arrow A.




NOTE (Assembly)



CAUTION

Remove the INK CASSETTE DOOR HOOK in the direction of the arrow B while bending the side portion a little in the direction of the arrow A.



1.6 MAIN ASS'Y, BOTTOM ASS'Y



- (1) Separate the MAIN ASS'Y and the BOTTOM ASS'Y.

CAUTION

Never hold the area around the front plate when separating or reassembling the MAIN ASS'Y and the BOTTOM ASS'Y. Be sure to hold the area around the cassette guide.


NOTE (Assembly)

Be careful not to catch the lead wires as shown in the figure.




1.7 BATTERY CASE ASS'Y, BATTERY TERMINAL ASS'Y, BOTTOM COVER ASS'Y (SELPHY CP730)

- (1) Remove the BATTERY CASE ASS'Y and BATTERY TERMINAL ASS'Y together as an assembled unit from the BOTTOM COVER ASS'Y.
- (2) Separate the BATTERY CASE ASS'Y and the BATTERY TERMINAL ASS'Y.



1.8 BOTTOM COVER ASS'Y, FAN UNIT (SELPHY CP720)

- (1) Separate the BOTTOM COVER ASS'Y and the FAN UNIT.




1.9 MAIN SHIELD, MAIN SHEET


- (1) Remove the two screws, and remove the MAIN SHIELD and the MAIN SHEET.

NOTE (Assembly)

Fold the MAIN SHEET as shown in the figure.



NOTE (Assembly)



1.10 MAIN PCB SECTION, PRINT UNIT


- (1) Remove the screw.
- (2) Disconnect the connector, and separate the MAIN PCB SECTION and the PRINT UNIT.

NOTE (Assembly)

Fold the FLAT CABLE as shown in the figure.

Set the INK CASSETTE and check if it comes out smoothly.

If the fold on the FLAT CABLE is not enough, the INK CASSETTE will not come out.




1.11 LCD UNIT, LCD CUSHION

(SELPHY CP730)

- (1) Disconnect the connector.
- (2) Remove the screw, and remove the LCD UNIT and the LCD CUSHION.

NOTE 1 (Assembly)

Attach the LCD CUSHION so that the glossy side faces the LCD UNIT.




(SELPHY CP720)

- (1) Disconnect the connector.
- (2) Remove the two screws, and remove the LCD UNIT and the LCD CUSHION.

NOTE 2 (Assembly)

Attach the LCD CUSHION so that the glossy side faces the LCD UNIT.




1.12 OPR PCB ASS'Y

(SELPHY CP730)

- (1) Remove the five screws, and remove the OPR PCB ASS'Y.

CAUTION

When handling OPR PCB ASS'Y, be careful not to damage the Portion A which is easy to damage.




(SELPHY CP720)

- (1) Remove the five screws, and remove the OPR PCB ASS'Y.

CAUTION


When handling OPR PCB ASS'Y, be careful not to damage the Portion B which is easy to damage.



1.13 MODE BUTTON, ON/OFF BUTTON, CROSS BUTTON, PRINT BUTTON, DISP. BUTTON

(SELPHY CP730)

- (1) Remove the MODE BUTTON, the DISP. BUTTON and the CROSS BUTTON.
- (2) Remove the ON/OFF BUTTON and the PRINT BUTTON.



(SELPHY CP720)

- (1) Remove the MODE BUTTON, the ON/OFF BUTTON and the CROSS BUTTON.

