

# *DISASSEMBLY*

---

## Trademarks:

Canon Inc.'s trademark, logos, product names, service marks and those trademark, logos, product names, service marks licensed to Canon Inc. by any of its affiliate or subsidiary are registered or unregistered marks of Canon Inc. or such affiliate or subsidiary in Japan and/or other countries.

Adobe, the Adobe logo, Acrobat, the Acrobat logo and Reader are either registered trademarks or trademarks of Adobe Systems Incorporated in the United States of America and/or other countries. All other trademarks, product names, service marks are generally either registered or unregistered marks of their respective owners.

## Copyright:

All copyrights in the content of this Service Manual are owned or controlled by Canon Inc. You are not permitted to copy, reproduce, download, modify, adapt or translate in any way the content of this Service Manual for any purpose other than the purpose contemplated herein without prior written consent of Canon Inc.


# CONTENTS

1.1 BATTERY CASE COVER (SELPHY CP750) -----	1
1.2 INK CASSETTE DOOR, PAPER CASSETTE DOOR -----	2
1.3 TOP COVER ASS'Y-(1) -----	3
1.4 TOP COVER ASS'Y-(2) (SELPHY CP750/CP740) -----	4
1.5 TOP COVER ASS'Y-(2) (SELPHY CP520) -----	5
1.6 MAIN ASS'Y, BOTTOM ASS'Y-(1) -----	6
1.7 MAIN ASS'Y, BOTTOM ASS'Y-(2) -----	7
1.8 BATTERY CASE ASS'Y, BATTERY TERMINAL ASS'Y, BOTTOM COVER ASS'Y (SELPHY CP750) --	8
1.9 REAR COVER ASS'Y, BOTTOM COVER ASS'Y (SELPHY CP740/CP520) -----	9
1.10 MAIN SHIELD, MAIN SHEET (SELPHY CP750/CP740) -----	10
1.11 MAIN SHIELD, MAIN SHEET (SELPHY CP520) -----	11
1.12 MAIN PCB ASS'Y, PRINT UNIT -----	12

## 1.1 BATTERY CASE COVER (SELPHY CP750)

- (1) Remove the BATTERY CASE COVER.

(SELPHY CP750)




## 1.2 INK CASSETTE DOOR, PAPER CASSETTE DOOR

- (1) Remove the INK CASSETTE DOOR.
- (2) Remove the PAPER CASSETTE DOOR.

### CAUTION

Remove the INK CASSETTE DOOR or the PAPER CASSETTE DOOR by bending it slightly in the direction of the arrow as shown in the figure.



### 1.3 TOP COVER ASS'Y-(1)


- (1) Remove the four screws.

#### **CAUTION**

The slots in the top of the screws can be easily rounded off, so use the appropriate size driver for these screws and be careful when removing them.

#### **NOTE (Assembly)**


Route the lead wire as shown in the figure.



#### **CAUTION**

The slots in the top of the screws can be easily rounded off, so use the appropriate size driver for these screws and be careful when removing them.

#### **NOTE (Assembly)**



## 1.4 TOP COVER ASS'Y-(2) (SELPHY CP750/CP740)


- (1) Open the TOP COVER ASS'Y in the direction of the arrow.  
Then disconnect the two connectors and remove the TOP COVER ASS'Y.

### **NOTE (Assembly)**


Adjust the height of the A portion of the plate spring so that it becomes higher than the tip of the rib as shown in the figure.

(SELPHY CP750/CP740)

### **NOTE (Assembly)**




Adjust the height of the A portion of the plate spring so that it becomes higher than the tip of the rib as shown in the figure.



## 1.5 TOP COVER ASS'Y-(2) (SELPHY CP520)

- (1) Open the TOP COVER ASS'Y in the direction of the arrow.  
Then disconnect the connector and remove the TOP COVER ASS'Y.

(SELPHY CP520)



## 1.6 MAIN ASS'Y, BOTTOM ASS'Y-(1)

(1) Remove the three screws.

### NOTE 1 (Assembly)


When assembling, tighten the screws in order to the screw holes A, B, and C.

(2) Disconnect the connector.

### NOTE 2 (Assembly)

Route the lead wires as shown in the figure.

(3) Disconnect the connector. (SELPHY CP750)





## 1.7 MAIN ASS'Y, BOTTOM ASS'Y-(2)


- (1) Separate the MAIN ASS'Y and the BOTTOM ASS'Y.

### CAUTION


Never hold the area around the front plate when separating or reassembling the MAIN ASS'Y and the BOTTOM ASS'Y. Be sure to hold the area around the cassette guide.

### NOTE (Assembly)


Be careful not to catch the lead wires as shown in the figure.



### CAUTION



### NOTE (Assembly)




## 1.8 BATTERY CASE ASS'Y, BATTERY TERMINAL ASS'Y, BOTTOM COVER ASS'Y (SELPHY CP750)


- (1) Remove the BATTERY CASE ASS'Y and BATTERY TERMINAL ASS'Y together as an assembled unit from the BOTTOM COVER ASS'Y.
- (2) Separate the BATTERY TERMINAL ASS'Y from the BATTERY CASE ASS'Y.

(SELPHY CP750)


- (1) BATTERY CASE ASS'Y,  
BATTERY TERMINAL ASS'Y



- (1) BOTTOM COVER ASS'Y



- (2) BATTERY  
CASE ASS'Y




- (2) BATTERY TERMINAL ASS'Y

## 1.9 REAR COVER ASS'Y, BOTTOM COVER ASS'Y (SELPHY CP740/CP520)

- (1) Separate the REAR COVER ASS'Y from the BOTTOM COVER ASS'Y.

(SELPHY CP740/CP520)




## 1.10 MAIN SHIELD, MAIN SHEET (SELPHY CP750/CP740)

- (1) Remove the two screws, and remove the MAIN SHIELD and the MAIN SHEET.


### **NOTE (Assembly)**

Fold the MAIN SHEET as shown in the figure.

(SELPHY CP750/CP740)




### **NOTE (Assembly)**



## 1.11 MAIN SHIELD, MAIN SHEET (SELPHY CP520)

- (1) Remove the two screws, and remove the MAIN SHIELD and the MAIN SHEET.

(SELPHY CP520)



## 1.12 MAIN PCB ASS'Y, PRINT UNIT

- (1) Remove the screw.
- (2) Disconnect the two connectors, and separate the MAIN PCB ASS'Y and the PRINT UNIT.

### **NOTE (Assembly)**

Using the edge of the head heatsink as a guide, fold the FLAT CABLE as shown in the figure. Set the INK CASSETTE and check if it comes out smoothly.

If the fold on the FLAT CABLE is not enough, the INK CASSETTE will not come out.

