

SORTER S-82

PARTS CATALOG

REVISION 0

Canon

JAN. 1999

RY8-3303-000

PREFACE

This Parts Catalog contains listings of parts used in the SORTER S-82. Diagrams are provided with the listings to aid the service technician in clearly identifying the item to be ordered.

Whenever ordering parts, consult this Parts Catalog for all of the information pertaining to each item. Be sure to include in the Parts Request the full item description, the item part number, and the quantity. The parts catalog may be revised if there is significant product modification. For minor product modifications, a Service Information Bulletin will be issued.

Canon Inc.

Peripheral Products Quality Planning Div.
Peripheral Products Technical Documentation Dept
5-1, Hakusan 7-chome, Toride-shi, Ibaraki 302-8501, Japan

COPYRIGHT © 1999 CANON INC.

Printed in Japan

Imprimé au Japon

Use of this manual should be strictly supervised to avoid disclosure of confidential information.

LIST OF ORDER AND SERIAL NUMBERS

NAME	REMARKS	ORDER No.	SERIAL No.
SORTER S-82		R95-3016	LJP00001-

CONTENTS

QA. ASSEMBLY LOCATION DIAGRAM

Q01. ATTACHMENT PARTS

Q10. EXTERNAL COVERS, PANELS, ETC.

Q11. INTERNAL COMPONENTS 1

Q12. INTERNAL COMPONENTS 2

Q13. INTERNAL COMPONENTS 3

Q14. INTERNAL COMPONENTS 4

Q20. MAIN DRIVE ASS'Y

Q30. TOP COVER ASS'Y

Q31. RIGHT DOOR ASS'Y

Q32. REVERSING ASS'Y

Q35. STACK TRAY ASS'Y 1

Q36. STACK TRAY ASS'Y 2

Q90. PCB ASS'Y LOCATION DIAGRAM

QB. NUMERICAL INDEX

HOW TO USE PARTS LISTS

Assembly Location Diagrams. These diagrams show the locations of major assemblies of the machine. Their names are identified in rectangular boxes. Below each box is the number of the Figure which shows an exploded view of the assembly.

Finding a Parts Number. Refer to the Assembly Location Diagrams and find the Figure Number of the assembly of interest. Turn to the page(s), locate the part on the exploded view, and find its Key Number. Refer to the Parts List on the page facing the exploded view and find the Key Number, Part Number and quantity required for your type of machine.

Note : While looking for a Part Number, pay particular attention to the voltage listed in the SERIAL NUMBER/REMARKS column to ensure that the Part Number selected is for your type of machine. Immediate shipping or action regarding the part depends on using its correct Part Number.

Parts List pages. The Parts List pages contain the following columns and information.

(1) Figure and Key Number column. The first column shows the Figure Number of the illustration corresponding to the Parts List, and the Key Number that identifies the part on the illustration.

(2) Part Number. The second column shows the Part Number for the part. This Number must be used when ordering replacement parts or assemblies described in the description column do not have a Part Number and are not stocked.

Note : The last three digits (suffix) of the Parts Number are called the Revision Number. The Revision Number is changed if the part is modified. Information regarding such changes will be provided by Service Information Bulletins. These Bulletins should be read carefully.

(3) Rank N. Parts marked "N" are service parts, but are not stock items. They are produced on a special-order basis.

(4) Quantity column. The quantity shown in this column is the number of parts used in the Figure. However, the quantity listed for an assembly indicates the number of that assembly per machine. The letters in this column indicate that the quantity of a parts is not specified, allowing the use of the number of parts needed for assembly and that the quantity cannot be mentioned clearly.

(5) Description column. The Description column lists the description that should be used when ordering the part.

(6) Serial Number/Remarks. When there are differences in the specifications of power supply voltage, frequency, etc., the differences are described in words or indicated by one two or three letters in front of the serial number.

(Example)

Serial number ABC00001
 ↑ This is the descriptive indicator.

If a model modified and a part is no longer interchangeable, the serial number of machines for which the part can be used is shown in this column. If there is no indication the part can be used with all models.

Numerical Index. There is a Numerical Index at the end of this catalog; it lists in numerical order every Part Number contained in the Parts Lists. The Numerical Index contains the following columns and information.

(1) Part Number. The first column shows the Part Number.

(2) Figure and Key Number column. The second column lists the Figure and Key Number for each occurrence of the part in the illustrations.

FIGURE QA ASSEMBLY LOCATION DIAGRAM




FIGURE Q01 ATTACHMENT PARTS




FIGURE Q10 EXTERNAL COVERS, PANELS, ETC.




FIGURE Q11 INTERNAL COMPONENTS 1




FIGURE Q12 INTERNAL COMPONENTS 2




FIGURE & KEY NO.	PART NUMBER	R A N K	Q' T Y	DESCRIPTION	SERIAL NUMBER / REMARKS
Q12 -	NPN		RF	INTERNAL COMPONENTS 2	
1	RA2-2583-000		1	SCREW, STEPPED, M3X5	
2	RA2-2418-000		1	PULLEY, 21T	
3	RA2-2420-000		1	GEAR, 32T/PULLY, 24T	
4	RF1-3995-000		1	MOUNT, GEAR	
5	RG1-3848-000		1	REVERSING ROLLER ASS'Y	
5A	RA2-2406-000		4	ROLLER	
6	RF1-3999-000		1	PLATE, TENSION	
7	RF1-3994-000		1	PLATE, TENSION	
8	RG1-3819-000		1	MOTOR CABLE	J1, J501
9	RA2-2393-000		1	GEAR, 16T	
10	RA2-2397-000		1	GEAR, 32T	
11	RA2-2399-000		1	GEAR, 40T/PULLEY, 34T	
12	RA2-2401-000		5	SCREW, STEPPED, M4X7	
13	RA2-2404-000		1	ROLLER, INLET	
14	RA2-2407-000		1	ROLLER, DELIVERY	
15	RA2-2414-000		1	PLATE, REVERSE	
16	RA2-2417-000		1	GUIDE, INLET	
17	RA2-2425-000		1	ROLLER	
18	RA2-2426-000		1	ROLLER	
19	RA2-2440-000		4	SPRING, COMPRESION	
20	FC2-5036-000		2	SCREW, W/WASHER, M4X10	
21	RA2-2578-000		1	SCREW, STEPPED	
22	RA2-2482-000		1	SPRING, TENSION	
23	RA2-2492-000		1	LEVER, SENSOR	
24	RA2-2496-000		4	PIN, POSITIONING	
25	RA2-2506-000		1	ARM, ROLLER	
26	RA2-2525-000		1	SPRING, TORSION	
27	RA2-2529-000		1	PLATE, GROUNDING	
28	RA2-2592-000		1	SCREW, STEPPED	
29	RA2-2540-000		1	GEAR, 18T/PULLY, 34T	
30	RF1-4003-000		1	STEPPING MOTOR ASS'Y, DC 15.6W	M1, J501
31	RA2-2579-000		1	SPRING, TENSION	
32	RA2-2581-000		7	BUSHING	
33	RA2-2562-000		1	MOUNT, MOTOR	
34	RA2-2561-000		2	BEARING, BALL	
35	RA2-2555-000		1	TIMING BELT	
36	RA2-2576-000		1	TIMING BELT	
37	RA2-2546-000		1	SPRING, TENSION	
38	RA2-2569-000		2	SCREW, TP, M4X10	
501	XD2-1200-502		12	RING, E	
502	XD3-2200-082		1	PIN, DOWEL	
503	XD3-2200-122		2	PIN, DOWEL	
504	XB1-2400-606		1	SCREW, MACH., TRUSS HEAD, M4X6	
505	XB4-7401-209		9	SCREW, TAPPING, TRUSS HEAD, M4X12	
506	XD3-2200-102		2	PIN, DOWEL	

FIGURE Q13 INTERNAL COMPONENTS 3




FIGURE & KEY NO.	PART NUMBER	R A N K	Q' T Y	DESCRIPTION	SERIAL NUMBER / REMARKS
Q13 -	NPN		RF	INTERNAL COMPONENTS 3	
1	RG1-3850-000		1	DEFLECTOR SOLENOID ASS'Y	SL3, SL4, J604
2	RA2-2589-000		2	SHEET	
3	RG1-3821-000		1	DEFLECTOR SOLENOID CABLE 1	J2, J603
3A	VS1-5057-002		1	CONNECTOR, 2P	J603
4	RA2-2436-000		1	LEVER, SENSOR	
5	RG1-3828-000		1	COVER SWITCH CABLE	J11, J601
6	RG1-3829-000		1	MICROSWITCH HARNESS ASS'Y	SW1, SW2, J601
7	RA2-2441-000		2	LEVER, SWITCH	
8	RA2-2444-000		1	HOLDER, SWITCH	
9	RA2-2544-000		2	PIN	
10	RA2-2493-000		1	COVER, INLET	
11	RA2-2401-000		1	SCREW, STEPPED, M4X7	
12	RA2-2429-000		2	SPRING, TENSION	
13	RA2-2443-000		1	LEVER, SENSOR	
14	RA2-2448-000		6	ARM, DEFLECTOR	
15	RA2-2460-000		1	GUIDE, PAPER, INLET	
16	RA2-2597-000		3	DEFLECTOR	
17	RA2-2598-000		3	DEFLECTOR	
18	RA2-2479-000		1	SPRING, TENSION	
19	RA2-2491-000		1	GUIDE, PAPER	
20	RA2-2498-000		1	HOLDER, RAIL	
21	RA2-2499-000		1	GUIDE, LINK	
22	RF1-3998-000		1	ARM, SOLENOID	SL2, J603
22A	RA2-2395-000		1	ARM, SOLENOID	
22B	XD3-1200-102		1	PIN, SPRING	
23	RF1-4001-000		1	MOUNT, DEFLECTOR	
23A	RA2-2480-000		3	SPRING, COMPRESION	
24	RF1-4002-000		1	MOUNT, DEFLECTOR	
24A	RA2-2480-000		3	SPRING, COMPRESION	
25	RF1-4012-000		1	MOUNT, LATCH	
25A	RA2-2580-000		1	SHEET, LATCH	
26	RA2-2452-000		3	BUSHING	
27	RA2-2422-000		1	HOLDER, ROLLER	
28	RA2-2446-000		1	ELIMINATOR, STATIC CHARGE	
29	WG8-5362-000		1	PHOTO-INTERRUPTER	PI1, J401
30	RA2-2473-000		1	SPRING, TORTION	
31	RA2-2515-000		2	FLAG, SENSOR	
32	RA2-2551-000		1	LEVER, SENSOR	
33	RA2-2453-000		1	GEAR, 20T	
34	RA2-2457-000		1	GEAR, 20T	
35	RA2-2533-000		1	BUSHING	
36	RF1-4009-000		1	ROLLER, DELIVERY	
501	XD2-1200-242		2	RING, E	
502	XB4-7401-206		9	SCREW,TAPPING,TRUSS HEAD,M4X12	
503	XB4-7401-209		5	SCREW,TAPPING,TRUSS HEAD,M4X12	

FIGURE Q14 INTERNAL COMPONENTS 4




FIGURE & KEY NO.	PART NUMBER	R A N K	Q' T Y	DESCRIPTION	SERIAL NUMBER / REMARKS
Q14 -	NPN		RF	INTERNAL COMPONENTS 4	
1	RA2-2454-000		1	MOUNT, PCB	
2	RA2-2532-000		1	PLATE, CONNECTOR	
3	RA2-2539-000		4	SCREW, W/WASHER	
4	WT2-0204-000		1	CLIP, CABLE	
5	WT2-0262-000		2	CLIP, CABLE	
6	WT2-5035-000		1	CLAMP, CABLE	
7	RH3-2205-000		1	POWER SUPPLY ASS'Y	
8	VT2-0001-000		5	SUPPORT, PCB	
9	RA2-2585-000		1	LINK, SWITCH	
10	RG1-3820-000		1	DEFLECTOR SOLENOID CABLE 2	J4, J604
10A	VS1-5057-004		1	CONNECTOR, 4P	J604
11	RG1-3823-000		1	INLET CONNECTOR	J201, J701
12	RG1-3833-000		1	GROUNDING CABLE	
13	RA2-2583-000		2	SCREW, STEPPED, M3X5	
14	RG1-3822-000		1	GROUNDING CABLE	
15	RA2-2428-000		1	SPRING, COMPRESION	
16	RG1-3834-000		1	SENSOR CABLE	J304, J404
17	RA2-2468-000		7	LEVER, SENSOR	
18	RA2-2489-000		3	HOLDER, SENSOR	
19	RG1-3827-000		1	SENSOR CABLE	J303, J403
20	RA2-2516-000		1	ARM, LINK	
21	RA2-2556-000		1	SPACER	
22	RA2-2560-000		1	PUSH NUT	
23	RG1-3826-000		1	SENSOR CABLE	J302, J402
24	WG8-5405-000		2	IC, TLP1252, PHOTO-INTERRUPTER	PI2, PI3, J402, J403
25	WG8-5362-000		1	IC, TLP1241, PHOTO-INTERRUPTER	PI4, J404
26	RA2-2500-000		2	PLATE	
27	RG1-3825-000		1	EMP SENSOR CABLE	J7, J305
28	RG1-3824-000		1	FULL SENSOR CABLE	J8, J301
29	RA2-2596-000		1	SHEET	
30	RA2-2594-000		3	SCREW, W/WASHER, M3X6	
31	WT2-5134-000		1	CLAMP, CABLE	
501	XB4-7401-209		9	SCREW, TAPPING, TRUSS HEAD, M4X12	
502	XB6-7300-607		4	SCREW, TP, M3X6	
503	XB4-7300-809		3	SCREW, TAPPING, TRUSS HEAD, M3X8	
504	XB1-2400-607		2	SCREW, MACH., TRUSS HEAD, M4X6	
505	XB1-2300-607		1	SCREW, MACH., TRUSS HEAD, M3X6	
506	XD1-4100-402		2	WASHER, TOOTHED LOCK	

FIGURE Q20 MAIN DRIVE ASS'Y




FIGURE & KEY NO.	PART NUMBER	R A N K	Q' T Y	DESCRIPTION	SERIAL NUMBER / REMARKS
Q20 -	RG1-3839-000		1	MAIN DRIVE ASS'Y	
1	RA2-2392-000		1	GEAR, 16T	
2	RA2-2394-000		1	GEAR, 30T	
3	RA2-2410-000		1	SHAFT, DRIVE	
4	RA2-2413-000		1	SHAFT, REVERSE	
5	RA2-2438-000		1	ARM, CAM	
6	RA2-2466-000		1	GEAR, 50T	
7	RA2-2467-000		1	SPRING, TORSION	
8	RA2-2475-000		1	GEAR, 50T	
9	RA2-2541-000		1	PLATE	
10	RF1-3997-000		1	MOUNT, MOTOR	
11	WT2-0262-000		7	CLIP, CABLE	
12	RH7-5223-000		1	SOLENOID	SL1, J602
13	WT2-5547-000		1	CLIP, CABLE	
501	XD1-4200-402		1	WASHER, TOOTHED LOCK	
502	XD2-1200-402		2	RING, E	
503	XB1-2400-606		2	SCREW,MACH.,TRUSS HEAD,M4X6	
504	XD2-1200-502		3	RING, E	

FIGURE Q30 TOP COVER ASS'Y




FIGURE Q31 RIGHT DOOR ASS'Y




FIGURE & KEY NO.	PART NUMBER	R A N K	Q' T Y	DESCRIPTION	SERIAL NUMBER / REMARKS
Q31 -	RG1-3840-000		1	RIGHT DOOR ASS'Y	
1	RA2-2442-000		6	ROLLER	
2	RA2-2481-000		6	SPRING, COMPRESION	
3	RA2-2514-000		1	MOUNT, LATCH	
4	RA2-2518-000		2	SPRING, TENSION	

FIGURE Q32 REVERSING ASS'Y




FIGURE Q35 STACK TRAY ASS'Y 1




FIGURE Q36 STACK TRAY ASS'Y 2





FIGURE Q90 PCB ASS'Y LOCATION DIAGRAM



QB NUMERICAL INDEX

PART NUMBER	FIGURE & KEY NO.	PART NUMBER	FIGURE & KEY NO.	PART NUMBER	FIGURE & KEY NO.
FC2-5036-000	Q12 - 20	RA2-2489-000	Q14 - 18	RA2-2720-000	Q11 - 20
FS1-1449-000	Q10 - 10F	RA2-2491-000	Q13 - 19		Q35 - 17
RA2-2392-000	Q20 - 1		Q35 - 11		Q36 - 17
RA2-2393-000	Q12 - 9		Q36 - 11	RA2-2723-000	Q30 - 9
RA2-2394-000	Q20 - 2	RA2-2492-000	Q12 - 23	RA2-2725-000	Q10 - 9
RA2-2395-000	Q13 - 22A	RA2-2493-000	Q13 - 10	RA2-2728-000	Q10 - 7
RA2-2397-000	Q12 - 10	RA2-2494-000	Q30 - 4	RF1-3994-000	Q12 - 7
RA2-2398-000	Q30 - 1	RA2-2495-000	Q30 - 5	RF1-3995-000	Q12 - 4
RA2-2399-000	Q12 - 11	RA2-2496-000	Q12 - 24	RF1-3997-000	Q20 - 10
RA2-2400-000	Q11 - 8	RA2-2498-000	Q13 - 20	RF1-3998-000	Q13 - 22
RA2-2401-000	Q12 - 12	RA2-2499-000	Q13 - 21	RF1-3999-000	Q12 - 6
	Q13 - 11	RA2-2500-000	Q14 - 26	RF1-4001-000	Q13 - 23
RA2-2404-000	Q12 - 13	RA2-2503-000	Q32 - 4	RF1-4002-000	Q13 - 24
RA2-2406-000	Q12 - 5A	RA2-2504-000	Q32 - 5	RF1-4003-000	Q12 - 30
RA2-2407-000	Q12 - 14	RA2-2505-000	Q10 - 6	RF1-4005-000	Q01 - 1
RA2-2410-000	Q20 - 3	RA2-2506-000	Q12 - 25	RF1-4009-000	Q13 - 36
RA2-2413-000	Q20 - 4	RA2-2507-000	Q01 - 1A		Q35 - 1
RA2-2414-000	Q12 - 15	RA2-2509-000	Q30 - 6		Q36 - 1
RA2-2417-000	Q12 - 16	RA2-2510-000	Q30 - 7	RF1-4011-000	Q32 - 3
RA2-2418-000	Q12 - 2	RA2-2513-000	Q10 - 8	RF1-4012-000	Q13 - 25
RA2-2420-000	Q12 - 3	RA2-2514-000	Q31 - 3	RF1-4013-000	Q10 - 10C
RA2-2422-000	Q13 - 27	RA2-2515-000	Q13 - 31	RF1-4060-000	Q10 - 2
RA2-2425-000	Q12 - 17	RA2-2516-000	Q14 - 20	RF1-4061-000	Q10 - 1
RA2-2426-000	Q12 - 18	RA2-2518-000	Q31 - 4	RF1-4063-000	Q35 - 3
RA2-2428-000	Q14 - 15	RA2-2519-000	Q10 - 1A	RF1-4064-000	Q36 - 3
RA2-2429-000	Q13 - 12	RA2-2520-000	Q32 - 6	RF1-4065-000	Q30 - 2
RA2-2432-000	Q32 - 2	RA2-2521-000	Q32 - 7	RG1-3814-000	Q90 - 1
RA2-2436-000	Q13 - 4	RA2-2522-000	Q32 - 8	RG1-3815-000	Q90 - 2
RA2-2437-000	Q30 - 3	RA2-2523-000	Q32 - 9	RG1-3816-000	Q90 - 3
RA2-2438-000	Q20 - 5	RA2-2524-000	Q32 - 10	RG1-3817-000	Q90 - 4
RA2-2439-000	Q10 - 3	RA2-2525-000	Q12 - 26	RG1-3818-000	Q11 - 19
RA2-2440-000	Q12 - 19	RA2-2526-000	Q32 - 11	RG1-3819-000	Q12 - 8
RA2-2441-000	Q13 - 7	RA2-2527-000	Q10 - 12	RG1-3820-000	Q14 - 10
RA2-2442-000	Q31 - 1	RA2-2528-000	Q32 - 12	RG1-3821-000	Q13 - 3
RA2-2443-000	Q13 - 13	RA2-2529-000	Q12 - 27	RG1-3822-000	Q14 - 14
RA2-2444-000	Q13 - 8	RA2-2530-000	Q32 - 13	RG1-3823-000	Q14 - 11
RA2-2445-000	Q35 - 15	RA2-2532-000	Q14 - 2	RG1-3824-000	Q14 - 28
	Q36 - 15	RA2-2533-000	Q13 - 35	RG1-3825-000	Q14 - 27
RA2-2446-000	Q13 - 28	RA2-2533-000	Q35 - 12	RG1-3826-000	Q14 - 23
	Q35 - 2		Q36 - 12	RG1-3827-000	Q14 - 19
	Q36 - 2	RA2-2534-000	Q11 - 2	RG1-3828-000	Q13 - 5
RA2-2448-000	Q13 - 14		Q35 - 14	RG1-3829-000	Q13 - 6
RA2-2450-000	Q35 - 13		Q36 - 14	RG1-3830-000	Q11 - 14
RA2-2450-000	Q36 - 13	RA2-2536-000	Q32 - 14	RG1-3831-000	Q11 - 16
RA2-2452-000	Q13 - 26	RA2-2539-000	Q14 - 3	RG1-3832-000	Q32 - 15
	Q35 - 4	RA2-2540-000	Q12 - 29	RG1-3833-000	Q14 - 12
	Q36 - 4	RA2-2541-000	Q20 - 9	RG1-3834-000	Q14 - 16
RA2-2453-000	Q13 - 33	RA2-2544-000	Q13 - 9	RG1-3839-000	Q20 -
	Q35 - 5	RA2-2546-000	Q12 - 37	RG1-3840-000	Q31 -
	Q36 - 5	RA2-2551-000	Q13 - 32	RG1-3842-000	Q10 - 10
RA2-2454-000	Q14 - 1	RA2-2555-000	Q12 - 35	RG1-3844-000	Q32 -
RA2-2457-000	Q13 - 34	RA2-2556-000	Q11 - 11	RG1-3848-000	Q12 - 5
	Q35 - 6		Q14 - 21	RG1-3850-000	Q13 - 1
	Q36 - 6	RA2-2560-000	Q11 - 18	RG1-3897-000	Q35 -
RA2-2458-000	Q35 - 7		Q14 - 22	RG1-3898-000	Q36 -
	Q36 - 7	RA2-2561-000	Q12 - 34	RG1-3899-000	Q30 -
RA2-2460-000	Q13 - 15	RA2-2562-000	Q12 - 33	RG1-3901-000	Q90 - 5
RA2-2461-000	Q11 - 4	RA2-2564-000	Q11 - 6	RH2-5310-000	Q01 - 3
	Q35 - 16	RA2-2565-000	Q11 - 7	RH3-2205-000	Q14 - 7
	Q36 - 16	RA2-2566-000	Q11 - 13	RH7-5223-000	Q20 - 12
RA2-2466-000	Q20 - 6	RA2-2567-000	Q11 - 17	VS1-5057-002	Q13 - 3A
RA2-2467-000	Q20 - 7	RA2-2569-000	Q10 - 11	VS1-5057-004	Q14 - 10A
RA2-2468-000	Q14 - 17		Q12 - 38	VT2-0001-000	Q14 - 8
RA2-2473-000	Q13 - 30	RA2-2576-000	Q12 - 36	WG8-5362-000	Q13 - 29
RA2-2474-000	Q11 - 5	RA2-2578-000	Q12 - 21		Q14 - 25
	Q35 - 8	RA2-2579-000	Q12 - 31	WG8-5405-000	Q14 - 24
	Q36 - 8	RA2-2580-000	Q13 - 25A	WT2-0204-000	Q14 - 4
	Q20 - 8	RA2-2581-000	Q12 - 32	WT2-0262-000	Q14 - 5
RA2-2475-000	Q10 - 10A	RA2-2583-000	Q12 - 1		Q20 - 11
RA2-2476-000	Q10 - 10B		Q14 - 13	WT2-5035-000	Q14 - 6
RA2-2478-000	Q13 - 18	RA2-2584-000	Q32 - 1	WT2-5134-000	Q14 - 31
RA2-2479-000	Q13 - 23A	RA2-2585-000	Q14 - 9	WT2-5547-000	Q20 - 13
RA2-2480-000	Q13 - 24A	RA2-2586-000	Q11 - 12	XB1-2300-607	Q14 - 505
	Q31 - 2	RA2-2588-000	Q35 - 3A	XB1-2400-606	Q12 - 504
RA2-2481-000	Q12 - 22		Q36 - 3A		Q20 - 503
RA2-2482-000	Q11 - 9	RA2-2589-000	Q13 - 2	XB1-2400-607	Q14 - 504
RA2-2483-000	Q35 - 9	RA2-2590-000	Q11 - 3	XB4-7300-809	Q10 - 1B
	Q36 - 9	RA2-2591-000	Q11 - 1		Q11 - 502
	Q10 - 4	RA2-2592-000	Q12 - 28		Q14 - 503
RA2-2484-000	Q10 - 5	RA2-2594-000	Q14 - 30		Q32 - 501
RA2-2485-000	Q30 - 8	RA2-2596-000	Q14 - 29	XB4-7401-206	Q10 - 501
RA2-2486-000	Q01 - 2	RA2-2597-000	Q13 - 16		Q13 - 502
RA2-2487-000	Q11 - 10	RA2-2598-000	Q13 - 17	XB4-7401-209	Q10 - 502
RA2-2488-000	Q35 - 10	RA2-2599-000	Q10 - 13		Q11 - 501
	Q36 - 10	RA2-2719-000	Q11 - 15		Q12 - 505

PART NUMBER	FIGURE & KEY NO.	PART NUMBER	FIGURE & KEY NO.	PART NUMBER	FIGURE & KEY NO.
XB4-7401-209	Q13 - 503 Q14 - 501 Q30 - 501				
XB6-7300-607	Q14 - 502				
XD1-4100-402	Q14 - 506				
XD1-4200-402	Q20 - 501				
XD2-1200-132	Q32 - 502				
XD2-1200-242	Q13 - 501				
XD2-1200-402	Q20 - 502				
XD2-1200-502	Q12 - 501 Q20 - 504				
XD2-1200-642	Q10 - 10D				
XD3-1200-102	Q13 - 22B				
XD3-2200-082	Q12 - 502				
XD3-2200-102	Q12 - 506				
XD3-2200-122	Q12 - 503				
XD3-2300-162	Q10 - 10E				

Prepared by
Peripheral Products Quality Planning Div.
Peripheral Products Technical Documentation Dept.
CANON INC.
Printed in Japan

REVISION 0 [JAN. 1999]

5-1, Hakusan 7-chome, Toride-shi, Ibaraki 302-8501, Japan



The printing paper contains
70% waste paper.

Canon