



DF-670/DF-670(B)

SERVICE MANUAL

Published in October 2009

843LB111

3LBSM061

Rev. 1

CAUTION

RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE. DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS.

It may be illegal to dispose of this battery into the municipal waste stream. Check with your local solid waste officials for details in your area for proper disposal.

ATTENTION

IL Y A UN RISQUE D'EXPLOSION SI LA BATTERIE EST REMPLACÉE PAR UN MODÈLE DE TYPE INCORRECT. METTRE AU REBUT LES BATTERIES UTILISÉES SELON LES INSTRUCTIONS DONNÉES.

Il peut être illégal de jeter les batteries dans des eaux d'égout municipales. Vérifiez avec les fonctionnaires municipaux de votre région pour les détails concernant des déchets solides et une mise au rebut appropriée.

Revision history

Revision	Date	Replaced pages	Remarks
1	October 5, 2009	Contents, 1-3-1, 1-3-2, 1-3-6, 1-3-7, 1-3-11 to 1-3-15, 1-5-1	-


This page is intentionally left blank.


Safety precautions


This booklet provides safety warnings and precautions for our service personnel to ensure the safety of their customers, their machines as well as themselves during maintenance activities. Service personnel are advised to read this booklet carefully to familiarize themselves with the warnings and precautions described here before engaging in maintenance activities.

Safety warnings and precautions

Various symbols are used to protect our service personnel and customers from physical danger and to prevent damage to their property. These symbols are described below:

 **DANGER:** High risk of serious bodily injury or death may result from insufficient attention to or incorrect compliance with warning messages using this symbol.

 **WARNING:** Serious bodily injury or death may result from insufficient attention to or incorrect compliance with warning messages using this symbol.

 **CAUTION:** Bodily injury or damage to property may result from insufficient attention to or incorrect compliance with warning messages using this symbol.

Symbols

The triangle (△) symbol indicates a warning including danger and caution. The specific point of attention is shown inside the symbol.



General warning.



Warning of risk of electric shock.



Warning of high temperature.

⊘ indicates a prohibited action. The specific prohibition is shown inside the symbol.



General prohibited action.



Disassembly prohibited.

● indicates that action is required. The specific action required is shown inside the symbol.



General action required.



Remove the power plug from the wall outlet.



Always ground the copier.

1. Installation Precautions

WARNING

- Do not use a power supply with a voltage other than that specified. Avoid multiple connections to one outlet: they may cause fire or electric shock. When using an extension cable, always check that it is adequate for the rated current.
- Connect the ground wire to a suitable grounding point. Not grounding the copier may cause fire or electric shock. Connecting the earth wire to an object not approved for the purpose may cause explosion or electric shock. Never connect the ground cable to any of the following: gas pipes, lightning rods, ground cables for telephone lines and water pipes or faucets not approved by the proper authorities.



CAUTION:

- Do not place the copier on an infirm or angled surface: the copier may tip over, causing injury.
- Do not install the copier in a humid or dusty place. This may cause fire or electric shock.
- Do not install the copier near a radiator, heater, other heat source or near flammable material.



This may cause fire.



- Allow sufficient space around the copier to allow the ventilation grills to keep the machine as cool as possible. Insufficient ventilation may cause heat buildup and poor copying performance.



- Always handle the machine by the correct locations when moving it.
- Always use anti-toppling and locking devices on copiers so equipped. Failure to do this may cause the copier to move unexpectedly or topple, leading to injury.
- Avoid inhaling toner or developer excessively. Protect the eyes. If toner or developer is accidentally ingested, drink a lot of water to dilute it in the stomach and obtain medical attention immediately. If it gets into the eyes, rinse immediately with copious amounts of water and obtain medical attention.













- Advise customers that they must always follow the safety warnings and precautions in the copier's instruction handbook.







2.Precautions for Maintenance

WARNING

- Always remove the power plug from the wall outlet before starting machine disassembly. 
- Always follow the procedures for maintenance described in the service manual and other related brochures. 
- Under no circumstances attempt to bypass or disable safety features including safety mechanisms and protective circuits. 
- Always use parts having the correct specifications. 
- Always use the thermostat or thermal fuse specified in the service manual or other related brochure when replacing them. Using a piece of wire, for example, could lead to fire or other serious accident. 
- When the service manual or other serious brochure specifies a distance or gap for installation of a part, always use the correct scale and measure carefully. 
- Always check that the copier is correctly connected to an outlet with a ground connection. 
- Check that the power cable covering is free of damage. Check that the power plug is dust-free. If it is dirty, clean it to remove the risk of fire or electric shock. 
- Never attempt to disassemble the optical unit in machines using lasers. Leaking laser light may damage eyesight. 
- Handle the charger sections with care. They are charged to high potentials and may cause electric shock if handled improperly. 

CAUTION

- Wear safe clothing. If wearing loose clothing or accessories such as ties, make sure they are safely secured so they will not be caught in rotating sections. 
- Use utmost caution when working on a powered machine. Keep away from chains and belts. 
- Handle the fixing section with care to avoid burns as it can be extremely hot. 
- Check that the fixing unit thermistor, heat and press rollers are clean. Dirt on them can cause abnormally high temperatures. 

• Do not remove the ozone filter, if any, from the copier except for routine replacement.



• Do not pull on the AC power cord or connector wires on high-voltage components when removing them; always hold the plug itself.



• Do not route the power cable where it may be stood on or trapped. If necessary, protect it with a cable cover or other appropriate item.



• Treat the ends of the wire carefully when installing a new charger wire to avoid electric leaks.



• Remove toner completely from electronic components.



• Run wire harnesses carefully so that wires will not be trapped or damaged.



• After maintenance, always check that all the parts, screws, connectors and wires that were removed, have been refitted correctly. Special attention should be paid to any forgotten connector, trapped wire and missing screws.



• Check that all the caution labels that should be present on the machine according to the instruction handbook are clean and not peeling. Replace with new ones if necessary.



• Handle greases and solvents with care by following the instructions below:



- Use only a small amount of solvent at a time, being careful not to spill. Wipe spills off completely.
- Ventilate the room well while using grease or solvents.
- Allow applied solvents to evaporate completely before refitting the covers or turning the power switch on.
- Always wash hands afterwards.

• Never dispose of toner or toner bottles in fire. Toner may cause sparks when exposed directly to fire in a furnace, etc.



• Should smoke be seen coming from the copier, remove the power plug from the wall outlet immediately.



3.Miscellaneous

WARNING

• Never attempt to heat the drum or expose it to any organic solvents such as alcohol, other than the specified refiner; it may generate toxic gas.



This page is intentionally left blank.

CONTENTS

1-1 Specifications	
1-1-1 Specifications	1-1-1
1-1-2 Parts names	1-1-2
1-1-3 Machine cross section	1-1-3
1-2 Installation	
1-2-1 Installation environment	1-2-1
1-2-2 Unpacking	1-2-2
(1) Unpacking	1-2-2
(2) Remove the tapes	1-2-3
1-3 Maintenance Mode	
1-3-1 Maintenance mode (DF-670/models with color touch panel)	1-3-1
(1) Executing a maintenance item	1-3-1
(2) Maintenance mode item list	1-3-2
(3) Contents of the maintenance mode items	1-3-3
1-3-2 Maintenance mode (DF-670/models with monochrome touch panel)	1-3-6
(1) Executing a maintenance item	1-3-6
(2) Maintenance mode item list	1-3-7
(3) Contents of the maintenance mode items	1-3-8
1-3-3 Maintenance mode (DF-670(B)/models with color touch panel)	1-3-11
(1) Executing a maintenance item	1-3-11
(2) Maintenance mode item list	1-3-12
(3) Contents of the maintenance mode items	1-3-13
1-4 Troubleshooting	
1-4-1 Paper misfeed detection	1-4-1
(1) Paper misfeed indication	1-4-1
(2) Paper misfeed detection conditions	1-4-1
(3) Paper misfeeds	1-4-2
1-4-2 Self-diagnosis	1-4-3
(1) Self-diagnostic function	1-4-3
(2) Self diagnostic codes	1-4-3
1-4-3 Electric problems	1-4-5
1-4-4 Mechanical problems	1-4-6
1-5 Assembly and Disassembly	
1-5-1 Precautions for assembly and disassembly	1-5-1
(1) Precautions	1-5-1
(2) Adjusting the positions of the front side registration cursor, rear side registration cursor and trailing edge registration cursor (reference)	1-5-2
(3) Cleaning the staple	1-5-3
(4) Adjusting the pressure of curl eliminator mechanism	1-5-4
2-1 Mechanical construction	
2-1-1 Construction of each section	2-1-1
(1) Paper conveying operation in sort mode	2-1-2
2-1-2 Process table section	2-1-3
(1) Paper registration on the process table	2-1-4
2-1-3 Stapler section	2-1-5
2-2 Electrical Parts Layout	
2-2-1 Electrical parts layout	2-2-1
(1) Paper conveying section	2-2-1
(2) Process table section	2-2-2
(3) Stapler section	2-2-3

2-3 Operation of the PWBs	
2-3-1 Finisher control PWB	2-3-1
2-4 Appendixes	
Maintenance parts list	2-4-1
Periodic maintenance procedures	2-4-1
Wiring diagram	2-4-2

1-1-1 Specifications

Type	Built-in
Number of trays	1 tray
Paper weight.....	60 to 105 g/m ²
Maximum sheets (Not stapling)	A3, B4, Ledger, Legal, OfficioII, 8.5 x 13.5", Folio, 8K: 250 sheets A4, A4R, B5, Letter, LetterR, 16K: 500 sheets
Maximum sheets for stapling	A3, B4, Ledger, Legal, OfficioII, Folio, 8K: 20 sheets A4, A4R, B5, Letter, LetterR, 16K: 30 sheets
Power source	Electrically connected to the machine
Dimension.....	325 (W) x 450 (D) x 165 (H) mm 12 13/16" (W) x 17 11/16" (D) x 6 1/2" (H)
Weight.....	8 kg/17.6 lbs or less

NOTE: These specifications are subject to change without notice.

1-1-2 Parts names





Figure 1-1-1

1. Ejected paper guide extension
2. Finisher tray
3. Ejected paper guide
4. Process table
5. Finisher tray extension
6. JAM release lever
7. Staple

1-1-3 Machine cross section**Figure 1-1-2 Machine cross section**

1. Paper conveying section
2. Process table section
3. Eject section

This page is intentionally left blank.

1-2-1 Installation environment

Installation location (Be based on the machine establishment place.)

Avoid direct sunlight or bright lighting. Ensure that the photo-conductor will not be exposed to direct sunlight or other strong light when removing paper jams.

Avoid extremes of temperature and humidity, abrupt ambient temperature changes, and hot or cold air directed onto the machine.

Avoid dust and vibration.

Choose a surface capable of supporting the weight of the machine.

Place the machine on a level surface (maximum allowance inclination: 1°).

Avoid air-borne substances that may adversely affect the machine or degrade the photo-conductor, such as mercury, acidic or alkaline vapors, inorganic gasses, NOx, SOx gases and chlorine-based organic solvents.

Select a room with good ventilation.

1-2-2 Unpacking

(1) Unpacking





Figure 1-2-1 Unpacking

- | | | |
|------------------------------------|-----------------------|--------------------|
| 1. Paper conveying unit | 11. Sub staple cover | 22. Tray case |
| 2. Outer case | 12. Front eject cover | 23. Tray left pad |
| 3. Stays | 13. Rear eject cover | 24. Tray right pad |
| 4. Paper conveying unit bottom pad | 14. Blindfold seal | 25. Tray top pad |
| 5. Plastic bag | 15. Plastic bag | 26. Paper |
| 6. Accessory case | 16. Hook holder | 27. Plastic sheet |
| 7. Left upper cover | 17. Large pin | 28. Spacer B |
| 8. Finisher tray | 18. Small pin | 29. Spacer C |
| 9. Plastic bag | 19. M3 x 6 screws | 30. Staple cover |
| 10. Spacer A | 20. Staple cartridge | 31. Plastic bag |
| | 21. Process table | |


Caution: See the Installation Guide for installation.

(2) Remove the tapes**Procedure**

1. Remove two tapes from the finisher tray.

**Figure 1-2-2**

2. Remove the tape from the paper conveying unit.

**Figure 1-2-3**

3. Remove the tape from the process table.





Figure 1-2-4

1-3-1 Maintenance mode (DF-670/models with color touch panel)

The machine is equipped with a maintenance function which can be used to maintain and service the machine.

(1) Executing a maintenance item



(2) Maintenance mode item list

Section	Item No.	Content of maintenance item	Initial setting*
General	U019	Displaying the ROM version	-
Drive, paper feed, paper conveying and cooling system	U033	Checking solenoid operation	-
Operation panel and support equipment	U236	Setting the limit for the ejection section of the built-in finisher	OFF* ^{1,2}
	U246	Setting the finisher	0/0/0* ¹
Mode setting	U342	Setting the ejection restriction	ON* ^{1,2}

*Initial setting for executing U020, *1: The item initialized for executing U020, *2: The item initialized for executing U021

(3) Contents of the maintenance mode items

Maintenance item No.	Description																																				
U019	<p>Displaying the ROM version</p> <p>Description Displays the part number of the ROM fitted to each PWB.</p> <p>Purpose To check the part number or to decide, if the newest version of ROM is installed.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. The ROM version are displayed. 2. Change the screen using the cursor up/down keys. <table border="1"> <thead> <tr> <th>Display</th><th>Description</th></tr> </thead> <tbody> <tr> <td>MAIN</td><td>Main PWB ROM IC</td></tr> <tr> <td>MMI</td><td>Operation PWB ROM IC</td></tr> <tr> <td>ENGINE</td><td>Engine PWB ROM IC</td></tr> <tr> <td>ENGINE BOOT</td><td>Engine PWB booting</td></tr> <tr> <td>OPTION LANGUAGE</td><td>Optional language ROM IC</td></tr> <tr> <td>DICTIONARY</td><td>-</td></tr> <tr> <td>DP</td><td>Optional DP main PWB ROM IC</td></tr> <tr> <td>OPTION CASSETTE</td><td>Optional paper feeder main PWB ROM IC</td></tr> <tr> <td>INNER DF</td><td>Built-in finisher main PWB ROM IC</td></tr> <tr> <td>SIMPLE DF MAIN</td><td>Optional document sheet finisher main PWB ROM IC</td></tr> <tr> <td>ENGINE POWER</td><td>Engine power CPU</td></tr> <tr> <td>FAX BOOT1</td><td>Optional fax control PWB booting (port 1)</td></tr> <tr> <td>FAX APL1</td><td>Optional fax control PWB APL (port 1)</td></tr> <tr> <td>FAX IPL1</td><td>Optional fax control PWB IPL (port 1)</td></tr> <tr> <td>FAX BOOT2</td><td>Fax control PWB booting (port 2: optional dual FAX)</td></tr> <tr> <td>FAX APL2</td><td>Fax control PWB APL (port 2: optional dual FAX)</td></tr> <tr> <td>FAX IPL2</td><td>Fax control PWB IPL (port 2: optional dual FAX)</td></tr> </tbody> </table> <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	MAIN	Main PWB ROM IC	MMI	Operation PWB ROM IC	ENGINE	Engine PWB ROM IC	ENGINE BOOT	Engine PWB booting	OPTION LANGUAGE	Optional language ROM IC	DICTIONARY	-	DP	Optional DP main PWB ROM IC	OPTION CASSETTE	Optional paper feeder main PWB ROM IC	INNER DF	Built-in finisher main PWB ROM IC	SIMPLE DF MAIN	Optional document sheet finisher main PWB ROM IC	ENGINE POWER	Engine power CPU	FAX BOOT1	Optional fax control PWB booting (port 1)	FAX APL1	Optional fax control PWB APL (port 1)	FAX IPL1	Optional fax control PWB IPL (port 1)	FAX BOOT2	Fax control PWB booting (port 2: optional dual FAX)	FAX APL2	Fax control PWB APL (port 2: optional dual FAX)	FAX IPL2	Fax control PWB IPL (port 2: optional dual FAX)
Display	Description																																				
MAIN	Main PWB ROM IC																																				
MMI	Operation PWB ROM IC																																				
ENGINE	Engine PWB ROM IC																																				
ENGINE BOOT	Engine PWB booting																																				
OPTION LANGUAGE	Optional language ROM IC																																				
DICTIONARY	-																																				
DP	Optional DP main PWB ROM IC																																				
OPTION CASSETTE	Optional paper feeder main PWB ROM IC																																				
INNER DF	Built-in finisher main PWB ROM IC																																				
SIMPLE DF MAIN	Optional document sheet finisher main PWB ROM IC																																				
ENGINE POWER	Engine power CPU																																				
FAX BOOT1	Optional fax control PWB booting (port 1)																																				
FAX APL1	Optional fax control PWB APL (port 1)																																				
FAX IPL1	Optional fax control PWB IPL (port 1)																																				
FAX BOOT2	Fax control PWB booting (port 2: optional dual FAX)																																				
FAX APL2	Fax control PWB APL (port 2: optional dual FAX)																																				
FAX IPL2	Fax control PWB IPL (port 2: optional dual FAX)																																				


Maintenance item No.	Description								
U033	<p>Checking solenoid operation</p> <p>Description Applies current to each solenoid in order to check its ON status.</p> <p>Purpose To check the operation of each solenoid.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select the solenoid to be operated. 3. Press the start key. The solenoid turns on for 1 s. <table border="1"> <thead> <tr> <th>Display</th><th>Solenoids</th></tr> </thead> <tbody> <tr> <td>BRANCH1</td><td>Feedshift solenoid (FSSOL)*</td></tr> <tr> <td>BRANCH2</td><td>Feedshift solenoid (FSSOL)</td></tr> <tr> <td>MOTOR ON</td><td>The main motor (MM) and the paper feed motor (PFM) are turned on.</td></tr> </tbody> </table> <p>*Solenoid of machine. To stop motor driving, press [MOTOR ON] again.</p> <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Solenoids	BRANCH1	Feedshift solenoid (FSSOL)*	BRANCH2	Feedshift solenoid (FSSOL)	MOTOR ON	The main motor (MM) and the paper feed motor (PFM) are turned on.
Display	Solenoids								
BRANCH1	Feedshift solenoid (FSSOL)*								
BRANCH2	Feedshift solenoid (FSSOL)								
MOTOR ON	The main motor (MM) and the paper feed motor (PFM) are turned on.								
U236	<p>Setting the limit for the ejection section of the built-in finisher</p> <p>Description If the machine is equipped with an built-in finisher, this mode sets whether A5R/B5R/statement size paper is output to the machine eject tray or not.</p> <p>Purpose If the machine is equipped with an built-in finisher and if paper jams occur due to curling of paper in the built-in ejection section when two-sided copying onto A5R/B5R/statement size paper is performed, this mode is used to change the setting to ON to disable ejection to the machine eject tray.</p> <p>Setting</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select ON or OFF. <table border="1"> <thead> <tr> <th>Display</th><th>Description</th></tr> </thead> <tbody> <tr> <td>ON</td><td>Does not eject to the machine eject tray.</td></tr> <tr> <td>OFF</td><td>Eject to the machine eject tray.</td></tr> </tbody> </table> <p>Initial setting: OFF</p> <ol style="list-style-type: none"> 3. Press the start key. The setting is set. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	ON	Does not eject to the machine eject tray.	OFF	Eject to the machine eject tray.		
Display	Description								
ON	Does not eject to the machine eject tray.								
OFF	Eject to the machine eject tray.								

Maintenance item No.	Description																				
U246	<p>Setting the finisher</p> <p>Description Provides various settings for the built-in finisher, if furnished.</p> <p>Purpose Adjusts the side registration cursor stop position if paper registration is poor or stapling is made outside the specified area.</p> <p>Setting</p> <ol style="list-style-type: none">1. Press the start key.2. Select the desired cursor position.3. Change the setting using the +/- or numeric keys. <table><tr><th>Display</th><th>Description</th><th>Setting range</th><th>Initial setting</th><th>Change in value per step</th></tr><tr><td>FRONT</td><td>Front side registration cursor stop position</td><td>-4 to +4</td><td>0</td><td>0.566 mm</td></tr><tr><td>REAR</td><td>Rear side registration cursor stop position</td><td>-4 to +4</td><td>0</td><td>0.566 mm</td></tr><tr><td>END</td><td>Trailing edge registration cursor stop position</td><td>-4 to +4</td><td>0</td><td>0.566 mm</td></tr></table> <ol style="list-style-type: none">4. Press the start key. The value is set. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Setting range	Initial setting	Change in value per step	FRONT	Front side registration cursor stop position	-4 to +4	0	0.566 mm	REAR	Rear side registration cursor stop position	-4 to +4	0	0.566 mm	END	Trailing edge registration cursor stop position	-4 to +4	0	0.566 mm
Display	Description	Setting range	Initial setting	Change in value per step																	
FRONT	Front side registration cursor stop position	-4 to +4	0	0.566 mm																	
REAR	Rear side registration cursor stop position	-4 to +4	0	0.566 mm																	
END	Trailing edge registration cursor stop position	-4 to +4	0	0.566 mm																	
U342	<p>Setting the ejection restriction</p> <p>Description Sets or cancels the restriction on the number of sheets to be ejected continuously when the internal eject tray is selected as the eject location.</p> <p>Purpose According to user request, sets or cancels restriction on the number of sheets.</p> <p>Setting</p> <ol style="list-style-type: none">1. Press the start key.2. Select ON or OFF. <table><tr><th>Display</th><th>Description</th></tr><tr><td>ON</td><td>Sets restriction on the number of sheets</td></tr><tr><td>OFF</td><td>Cancels restriction on the number of sheets</td></tr></table> <p>Initial setting: ON Details of restriction (number of sheets to be ejected continuously after the start key is pressed)</p> <table><tr><th>Condition</th><th>Number of sheets</th></tr><tr><td>When no optional ejection device is installed</td><td>250</td></tr><tr><td>When the job separator is installed</td><td>150</td></tr><tr><td>When the built-in finisher is installed</td><td>100</td></tr></table> <ol style="list-style-type: none">3. Press the start key. The setting is set. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	ON	Sets restriction on the number of sheets	OFF	Cancels restriction on the number of sheets	Condition	Number of sheets	When no optional ejection device is installed	250	When the job separator is installed	150	When the built-in finisher is installed	100						
Display	Description																				
ON	Sets restriction on the number of sheets																				
OFF	Cancels restriction on the number of sheets																				
Condition	Number of sheets																				
When no optional ejection device is installed	250																				
When the job separator is installed	150																				
When the built-in finisher is installed	100																				

1-3-2 Maintenance mode (DF-670/models with monochrome touch panel)

The machine is equipped with a maintenance function which can be used to maintain and service the machine.

(1) Executing a maintenance item



(2) Maintenance mode item list

Section	Item No.	Content of maintenance item	Initial setting*
General	U019	Displaying the ROM version	-
Drive, paper feed, paper conveying and cooling system	U033	Checking solenoid operation	-
Operation panel and support equipment	U236	Setting the limit for the ejection section of the built-in finisher	OFF*1,*2
	U246	Setting the finisher	0/0/0*1
Mode setting	U342	Setting the ejection restriction	ON*1,*2

*Initial setting for executing U020, *1: The item initialized for executing U020, *2: The item initialized for executing U021

(3) Contents of the maintenance mode items

Maintenance item No.	Description																												
U019	<p>Displaying the ROM version</p> <p>Description Displays the part number of the ROM fitted to each PWB.</p> <p>Purpose To check the part number or to decide, if the newest version of ROM is installed.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. The ROM version are displayed. 2. Change the screen using the * or # keys. <table border="1"> <thead> <tr> <th>Display</th><th>Description</th></tr> </thead> <tbody> <tr> <td>MAIN</td><td>Main PWB ROM IC</td></tr> <tr> <td>MAIN BOOT</td><td>Main PWB booting</td></tr> <tr> <td>ENGINE</td><td>Engine PWB ROM IC</td></tr> <tr> <td>ENGINE BOOT</td><td>Engine PWB booting</td></tr> <tr> <td>LANGUAGE</td><td>Standard language ROM IC</td></tr> <tr> <td>OPTION LANGUAGE</td><td>Optional language ROM IC</td></tr> <tr> <td>DICTIONARY</td><td>-</td></tr> <tr> <td>PRINTER</td><td>Optional printer board ROM IC</td></tr> <tr> <td>DP</td><td>Optional DP main PWB ROM IC</td></tr> <tr> <td>OPTION CASSETTE</td><td>Optional paper feeder main PWB ROM IC</td></tr> <tr> <td>INNER DF</td><td>Built-in finisher main PWB ROM IC</td></tr> <tr> <td>SIMPLE DF MAIN</td><td>Optional document finisher main PWB ROM IC</td></tr> <tr> <td>ENGINE POWER</td><td>Engine power CPU</td></tr> </tbody> </table> <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	MAIN	Main PWB ROM IC	MAIN BOOT	Main PWB booting	ENGINE	Engine PWB ROM IC	ENGINE BOOT	Engine PWB booting	LANGUAGE	Standard language ROM IC	OPTION LANGUAGE	Optional language ROM IC	DICTIONARY	-	PRINTER	Optional printer board ROM IC	DP	Optional DP main PWB ROM IC	OPTION CASSETTE	Optional paper feeder main PWB ROM IC	INNER DF	Built-in finisher main PWB ROM IC	SIMPLE DF MAIN	Optional document finisher main PWB ROM IC	ENGINE POWER	Engine power CPU
Display	Description																												
MAIN	Main PWB ROM IC																												
MAIN BOOT	Main PWB booting																												
ENGINE	Engine PWB ROM IC																												
ENGINE BOOT	Engine PWB booting																												
LANGUAGE	Standard language ROM IC																												
OPTION LANGUAGE	Optional language ROM IC																												
DICTIONARY	-																												
PRINTER	Optional printer board ROM IC																												
DP	Optional DP main PWB ROM IC																												
OPTION CASSETTE	Optional paper feeder main PWB ROM IC																												
INNER DF	Built-in finisher main PWB ROM IC																												
SIMPLE DF MAIN	Optional document finisher main PWB ROM IC																												
ENGINE POWER	Engine power CPU																												
U033	<p>Checking solenoid operation</p> <p>Description Applies current to each solenoid in order to check its ON status.</p> <p>Purpose To check the operation of each solenoid.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select the solenoid to be operated. The solenoid turns on for 1 s. <table border="1"> <thead> <tr> <th>Display</th><th>Solenoids</th></tr> </thead> <tbody> <tr> <td>BRANCH1</td><td>Feedshift solenoid (FSSOL)*</td></tr> <tr> <td>BRANCH2</td><td>Feedshift solenoid (FSSOL)</td></tr> </tbody> </table> <p>*Solenoid of machine.</p> <ol style="list-style-type: none"> 3. Press the interrupt key. Main motor (MM) and paper feed motor (PFM) are turned on. To stop driving motors, press the interrupt key again. <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Solenoids	BRANCH1	Feedshift solenoid (FSSOL)*	BRANCH2	Feedshift solenoid (FSSOL)																						
Display	Solenoids																												
BRANCH1	Feedshift solenoid (FSSOL)*																												
BRANCH2	Feedshift solenoid (FSSOL)																												


Maintenance item No.	Description																				
U236	<p>Setting the limit for the ejection section of the built-in finisher</p> <p>Description If the machine is equipped with an built-in finisher, this mode sets whether A5R/B5R/5 1/2" x 8 1/2" size paper is output to the machine eject tray or not.</p> <p>Purpose If the machine is equipped with an built-in finisher and if paper jams occur due to curling of paper in the built-in ejection section when two-sided copying onto A5R/B5R/5 1/2" x 8 1/2" size paper is performed, this mode is used to change the setting to ON to disable ejection to the machine eject tray.</p> <p>Setting</p> <ol style="list-style-type: none">1. Press the start key.2. Select ON or OFF. <table><tr><th>Display</th><th>Description</th></tr><tr><td>ON</td><td>Does not eject to the machine eject tray.</td></tr><tr><td>OFF</td><td>Eject to the machine eject tray.</td></tr></table> <p>Initial setting: OFF</p> <ol style="list-style-type: none">3. Press the start key. The setting is set. <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	ON	Does not eject to the machine eject tray.	OFF	Eject to the machine eject tray.														
Display	Description																				
ON	Does not eject to the machine eject tray.																				
OFF	Eject to the machine eject tray.																				
U246	<p>Setting the finisher</p> <p>Description Provides various settings for the built-in finisher, if furnished.</p> <p>Purpose Adjusts the side registration cursor stop position if paper registration is poor or stapling is made outside the specified area.</p> <p>Setting</p> <ol style="list-style-type: none">1. Press the start key.2. Press [FINISHER B-IN].3. Select the desired cursor position.4. Change the setting using the cursor up/down keys. <table><tr><th>Display</th><th>Description</th><th>Setting range</th><th>Initial setting</th><th>Change in value per step</th></tr><tr><td>FRONT</td><td>Front side registration cursor stop position</td><td>-4 to +4</td><td>0</td><td>0.566 mm</td></tr><tr><td>REAR</td><td>Rear side registration cursor stop position</td><td>-4 to +4</td><td>0</td><td>0.566 mm</td></tr><tr><td>END</td><td>Trailing edge registration cursor stop position</td><td>-4 to +4</td><td>0</td><td>0.566 mm</td></tr></table> <ol style="list-style-type: none">5. Press the start key. The value is set. <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Setting range	Initial setting	Change in value per step	FRONT	Front side registration cursor stop position	-4 to +4	0	0.566 mm	REAR	Rear side registration cursor stop position	-4 to +4	0	0.566 mm	END	Trailing edge registration cursor stop position	-4 to +4	0	0.566 mm
Display	Description	Setting range	Initial setting	Change in value per step																	
FRONT	Front side registration cursor stop position	-4 to +4	0	0.566 mm																	
REAR	Rear side registration cursor stop position	-4 to +4	0	0.566 mm																	
END	Trailing edge registration cursor stop position	-4 to +4	0	0.566 mm																	

Maintenance item No.	Description														
U342	<p>Setting the ejection restriction</p> <p>Description Sets or cancels the restriction on the number of sheets to be ejected continuously when the internal eject tray is selected as the eject location.</p> <p>Purpose According to user request, sets or cancels restriction on the number of sheets.</p> <p>Setting</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select ON or OFF. <table border="1"> <thead> <tr> <th>Display</th><th>Description</th></tr> </thead> <tbody> <tr> <td>ON</td><td>Sets restriction on the number of sheets</td></tr> <tr> <td>OFF</td><td>Cancels restriction on the number of sheets</td></tr> </tbody> </table> <p>Initial setting: ON Details of restriction (number of sheets to be ejected continuously after the start key is pressed)</p> <table border="1"> <thead> <tr> <th>Condition</th><th>Number of sheets</th></tr> </thead> <tbody> <tr> <td>When no optional ejection device is installed</td><td>250</td></tr> <tr> <td>When the job separator is installed</td><td>150</td></tr> <tr> <td>When the built-in finisher is installed</td><td>100</td></tr> </tbody> </table> <ol style="list-style-type: none"> 3. Press the start key. The setting is set. <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	ON	Sets restriction on the number of sheets	OFF	Cancels restriction on the number of sheets	Condition	Number of sheets	When no optional ejection device is installed	250	When the job separator is installed	150	When the built-in finisher is installed	100
Display	Description														
ON	Sets restriction on the number of sheets														
OFF	Cancels restriction on the number of sheets														
Condition	Number of sheets														
When no optional ejection device is installed	250														
When the job separator is installed	150														
When the built-in finisher is installed	100														

1-3-3 Maintenance mode (DF-670(B)/models with color touch panel)

The machine is equipped with a maintenance function which can be used to maintain and service the machine.

(1) Executing a maintenance item



(2) Maintenance mode item list

Section	Item No.	Content of maintenance item	Initial setting*
General	U019	Displaying the ROM version	-
Drive, paper feed, paper conveying and cooling system	U033	Checking solenoid operation	-
Operation panel and support equipment	U236	Setting the finisher	OFF*1
	U246	Setting the finisher	0/0/0
Mode setting	U342	Setting the ejection restriction	ON*1

*: Factory initial setting, *1: The item initialized for executing U021

(3) Contents of the maintenance mode items

Maintenance item No.	Description																																												
U019	<p>Displaying the ROM version</p> <p>Description Displays the part number of the ROM fitted to each PWB.</p> <p>Purpose To check the part number or to decide, if the newest version of ROM is installed.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. The ROM version are displayed. 2. Change the screen using the cursor up/down keys. <table border="1"> <thead> <tr> <th>Display</th><th>Description</th></tr> </thead> <tbody> <tr><td>MAIN</td><td>Main ROM</td></tr> <tr><td>MMI</td><td>Operation ROM</td></tr> <tr><td>ENGINE</td><td>Engine ROM</td></tr> <tr><td>ENGINE BOOT</td><td>Engine booting</td></tr> <tr><td>ENGINE POWER</td><td>Engine power</td></tr> <tr><td>SCANNER</td><td>Scanner ROM</td></tr> <tr><td>BROWSER</td><td>Browser ROM</td></tr> <tr><td>OPTION LANGUAGE</td><td>Optional language ROM</td></tr> <tr><td>DICTIONARY</td><td>-</td></tr> <tr><td>DBA</td><td>Database connection</td></tr> <tr><td>Solution Framework</td><td>Solution framework</td></tr> <tr><td>DP</td><td>Optional DP ROM</td></tr> <tr><td>500x2PF</td><td>Optional paper feeder ROM</td></tr> <tr><td>1000DF</td><td>Optional document finisher ROM</td></tr> <tr><td>INNER DF</td><td>Built-in finisher ROM</td></tr> <tr><td>FAX BOOT1</td><td>Optional fax control PWB booting (port 1)</td></tr> <tr><td>FAX APL1</td><td>Optional fax control PWB APL (port 1)</td></tr> <tr><td>FAX IPL1</td><td>Optional fax control PWB IPL (port 1)</td></tr> <tr><td>FAX BOOT2</td><td>Fax control PWB booting (port 2: optional dual FAX)</td></tr> <tr><td>FAX APL2</td><td>Fax control PWB APL (port 2: optional dual FAX)</td></tr> <tr><td>FAX IPL2</td><td>Fax control PWB IPL (port 2: optional dual FAX)</td></tr> </tbody> </table> <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	MAIN	Main ROM	MMI	Operation ROM	ENGINE	Engine ROM	ENGINE BOOT	Engine booting	ENGINE POWER	Engine power	SCANNER	Scanner ROM	BROWSER	Browser ROM	OPTION LANGUAGE	Optional language ROM	DICTIONARY	-	DBA	Database connection	Solution Framework	Solution framework	DP	Optional DP ROM	500x2PF	Optional paper feeder ROM	1000DF	Optional document finisher ROM	INNER DF	Built-in finisher ROM	FAX BOOT1	Optional fax control PWB booting (port 1)	FAX APL1	Optional fax control PWB APL (port 1)	FAX IPL1	Optional fax control PWB IPL (port 1)	FAX BOOT2	Fax control PWB booting (port 2: optional dual FAX)	FAX APL2	Fax control PWB APL (port 2: optional dual FAX)	FAX IPL2	Fax control PWB IPL (port 2: optional dual FAX)
Display	Description																																												
MAIN	Main ROM																																												
MMI	Operation ROM																																												
ENGINE	Engine ROM																																												
ENGINE BOOT	Engine booting																																												
ENGINE POWER	Engine power																																												
SCANNER	Scanner ROM																																												
BROWSER	Browser ROM																																												
OPTION LANGUAGE	Optional language ROM																																												
DICTIONARY	-																																												
DBA	Database connection																																												
Solution Framework	Solution framework																																												
DP	Optional DP ROM																																												
500x2PF	Optional paper feeder ROM																																												
1000DF	Optional document finisher ROM																																												
INNER DF	Built-in finisher ROM																																												
FAX BOOT1	Optional fax control PWB booting (port 1)																																												
FAX APL1	Optional fax control PWB APL (port 1)																																												
FAX IPL1	Optional fax control PWB IPL (port 1)																																												
FAX BOOT2	Fax control PWB booting (port 2: optional dual FAX)																																												
FAX APL2	Fax control PWB APL (port 2: optional dual FAX)																																												
FAX IPL2	Fax control PWB IPL (port 2: optional dual FAX)																																												

Maintenance item No.	Description								
U033	<p>Checking solenoid operation</p> <p>Description Applies current to each solenoid in order to check its ON status.</p> <p>Purpose To check the operation of each solenoid.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select the solenoid to be operated. 3. Press the start key. The solenoid turns on for 1 s. <table border="1"> <thead> <tr> <th>Display</th><th>Solenoids</th></tr> </thead> <tbody> <tr> <td>BRANCH1</td><td>Feedshift solenoid (FSSOL)</td></tr> <tr> <td>BRANCH2</td><td>Job feedshift solenoid (JFSSOL)</td></tr> <tr> <td>MOTOR ON</td><td>The main motor (MM) and the paper feed motor (PFM) are turned on.</td></tr> </tbody> </table> <ol style="list-style-type: none"> 4. To stop motor driving, press [MOTOR ON] again. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Solenoids	BRANCH1	Feedshift solenoid (FSSOL)	BRANCH2	Job feedshift solenoid (JFSSOL)	MOTOR ON	The main motor (MM) and the paper feed motor (PFM) are turned on.
Display	Solenoids								
BRANCH1	Feedshift solenoid (FSSOL)								
BRANCH2	Job feedshift solenoid (JFSSOL)								
MOTOR ON	The main motor (MM) and the paper feed motor (PFM) are turned on.								
U236	<p>Setting the limit for the ejection section of the built-in finisher</p> <p>Description If the machine is equipped with an built-in finisher, this mode sets whether A5R/B5R/statement size paper is output to the machine top tray or not.</p> <p>Purpose If the machine is equipped with an built-in finisher and if paper jams occur due to curling of paper in the built-in ejection section when two-sided copying onto A5R/B5R/statement size paper is performed, this mode is used to change the setting to ON to disable ejection to the machine top tray.</p> <p>Setting</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select ON or OFF. <table border="1"> <thead> <tr> <th>Display</th><th>Description</th></tr> </thead> <tbody> <tr> <td>ON</td><td>Does not eject to the machine top tray.</td></tr> <tr> <td>OFF</td><td>Eject to the machine top tray.</td></tr> </tbody> </table> <p>Initial setting: OFF</p> <ol style="list-style-type: none"> 3. Press the start key. The setting is set. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	ON	Does not eject to the machine top tray.	OFF	Eject to the machine top tray.		
Display	Description								
ON	Does not eject to the machine top tray.								
OFF	Eject to the machine top tray.								

Maintenance item No.	Description																				
U246	<p>Setting the finisher</p> <p>Description Provides various settings for the built-in finisher, if furnished.</p> <p>Purpose Adjusts the side registration cursor stop position if paper registration is poor or stapling is made outside the specified area.</p> <p>Setting</p> <div><div><div>1. Press the start key.</div><div>2. Select the desired cursor position.</div><div>3. Change the setting using the +/- or numeric keys.</div></div><table><tr><th>Display</th><th>Description</th><th>Setting range</th><th>Initial setting</th><th>Change in value per step</th></tr><tr><td>FRONT</td><td>Front side registration cursor stop position</td><td>-4 to +4</td><td>0</td><td>0.566 mm</td></tr><tr><td>REAR</td><td>Rear side registration cursor stop position</td><td>-4 to +4</td><td>0</td><td>0.566 mm</td></tr><tr><td>END</td><td>Trailing edge registration cursor stop position</td><td>-4 to +4</td><td>0</td><td>0.566 mm</td></tr></table><div><div>4. Press the start key. The value is set.</div></div></div> <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Setting range	Initial setting	Change in value per step	FRONT	Front side registration cursor stop position	-4 to +4	0	0.566 mm	REAR	Rear side registration cursor stop position	-4 to +4	0	0.566 mm	END	Trailing edge registration cursor stop position	-4 to +4	0	0.566 mm
Display	Description	Setting range	Initial setting	Change in value per step																	
FRONT	Front side registration cursor stop position	-4 to +4	0	0.566 mm																	
REAR	Rear side registration cursor stop position	-4 to +4	0	0.566 mm																	
END	Trailing edge registration cursor stop position	-4 to +4	0	0.566 mm																	
U342	<p>Setting the ejection restriction</p> <p>Description Sets or cancels the restriction on the number of sheets to be ejected continuously when the internal eject tray is selected as the eject location.</p> <p>Purpose According to user request, sets or cancels restriction on the number of sheets.</p> <p>Setting</p> <div><div><div>1. Press the start key.</div><div>2. Select [ON] or [OFF].</div></div><table><tr><th>Display</th><th>Description</th></tr><tr><td>ON</td><td>Sets restriction on the number of sheets</td></tr><tr><td>OFF</td><td>Cancels restriction on the number of sheets</td></tr></table><div><div>Initial setting: ON</div><div>Details of restriction (number of sheets to be ejected continuously after the start key is pressed)</div><table><tr><th>Condition</th><th>Number of sheets</th></tr><tr><td>When no optional ejection device is installed</td><td>250 sheets</td></tr><tr><td>When the job separator is installed</td><td>150 sheets</td></tr><tr><td>When the finisher is installed</td><td>100 sheets</td></tr></table></div><div><div>3. Press the start key. The setting is set.</div></div></div> <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	ON	Sets restriction on the number of sheets	OFF	Cancels restriction on the number of sheets	Condition	Number of sheets	When no optional ejection device is installed	250 sheets	When the job separator is installed	150 sheets	When the finisher is installed	100 sheets						
Display	Description																				
ON	Sets restriction on the number of sheets																				
OFF	Cancels restriction on the number of sheets																				
Condition	Number of sheets																				
When no optional ejection device is installed	250 sheets																				
When the job separator is installed	150 sheets																				
When the finisher is installed	100 sheets																				

This page is intentionally left blank.

1-4-1 Paper misfeed detection

(1) Paper misfeed indication

When paper jams, the machine immediately stops operation and the occurrence of a paper jam is indicated on the operation panel.

To remove the jammed paper, lower the process table.

To reset the paper misfeed detection, detach and refit the process table to turn the tray open/close switch off and on.

(2) Paper misfeed detection conditions




Figure 1-4-1

Section	Description	Conditions	Specified time
Built-in finisher	80 Finisher timeout jam	Paper ejection is not output from the machine to the document finisher within specified time of the paper conveying switch (PCSW) turning on.	15 s
	81 Paper entry sensor nonarrival jam	The paper conveying switch (PCSW) is not turned on even if a specified time has elapsed after the machine eject signal was received.	2000 ms
		The paper conveying switch (PCSW) does not turn off within specified time of its turning on when paper is conveyed to the process table from the paper conveying unit.	1429 ms + Paper length
	82 Jam in stapler	The staple home position sensor (STHPS) is not turned on within the specified time when driving the staple motor (STM).	600 ms
	83 Exit sensor stay jam	The paper conveying switch (PCSW) does not turn off within specified time of its turning on when paper is ejected to the finisher tray from the process table.	1429 ms + Paper length
	96 Jam between the built-in finisher and machine	The paper conveying switch (PCSW) is not turned on within the specified time when paper is ejected to the finisher tray from the process table.	2000 ms

(3) Paper misfeeds

Problem	Causes/check procedures	Corrective measures
(1) A paper jam in built-in finisher is indicated as soon as the main power switch is turned on.	A piece of paper torn from copy paper is caught around the paper conveying switch.	Check visually and remove it, if any.
	Defective paper conveying switch.	With 5 V DC present at YC2-23 on the finisher control PWB, check if YC2-21 on the finisher control PWB remains low when the paper conveying switch is turned on and off. If it does, replace the paper conveying switch.
(2) A paper jam in built-in finisher is indicated during copying (finisher timeout jam). Jam code 80	Extremely curled paper.	Change the paper.
	Defective paper conveying switch.	With 5 V DC present at YC2-23 on the finisher control PWB, check if YC2-21 on the finisher control PWB remains low or high when the paper conveying switch is turned on and off. If it does, replace the paper conveying switch.
(3) A paper jam in built-in finisher is indicated during copying (paper jam during paper insertion to the finisher). Jam code 81	Extremely curled paper.	Change the paper.
	Defective paper conveying switch.	With 5 V DC present at YC2-23 on the finisher control PWB, check if YC2-21 on the finisher control PWB remains low or high when the paper conveying switch is turned on and off. If it does, replace the paper conveying switch.
	Check if the feedshift roller or feedshift pulley is deformed.	Check and remedy.
(4) A paper jam in built-in finisher is indicated during copying (finisher stapler jam). Jam code 82	The stapler is blocked with a staple.	Remove the stapler cartridge, and check the cartridge and the stapling section of the stapler. Remove the staple if any.
	Defective stapler section.	With 5 V DC present at YC2-24 on the finisher control PWB, check if YC2-19 on the finisher control PWB remains low or high. If it does, replace the stapler section.
(5) A paper jam in built-in finisher is indicated during copying (eject jam). Jam code 83	Defective paper conveying switch.	With 5 V DC present at YC2-23 on the finisher control PWB, check if YC2-21 on the finisher control PWB remains low when the paper conveying switch is turned on and off. If it does, replace the paper conveying switch.
	Check if the eject roller or eject pulley is deformed.	Check and remedy.
(6) A paper jam in built-in finisher is indicated during copying (jam between finisher and machine). Jam code 96	Defective paper conveying switch.	With 5 V DC present at YC2-23 on the finisher control PWB, check if YC2-21 on the finisher control PWB remains low when the paper conveying switch is turned on and off. If it does, replace the paper conveying switch.
	Check if the eject roller or eject pulley is deformed.	Check and remedy.

1-4-2 Self-diagnosis

(1) Self-diagnostic function

This unit is equipped with a self-diagnostic function. When a problem is detected, copying is disabled and the problem displayed as a code consisting of C followed by a number, indicating the nature of the problem.

A message is also displayed requesting the user to call for service.

After removing the problem, the self-diagnostic function can be reset by turning the main power switch off and back on.

(2) Self diagnostic codes

Code	Contents	Remarks	
		Causes	Check procedures/corrective measures
C8170	Finisher front side registration motor problem When the front-side registration home-position sensor is turned on during initialization, the sensor did not turn on while it has moved by 106 pulses. When the front-side registration home-position sensor is turned off during initialization, the sensor did not turn on in 3 s.	The front side registration motor connector makes poor contact.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable.
		Defective front side registration motor.	Replace front side registration motor.
		The front side registration home position sensor connector makes poor contact.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable.
		Defective front side registration home position sensor.	Replace the front side registration home position sensor.
		Defective finisher control PWB.	Replace the finisher control PWB and check for correct operation.
C8180	Finisher rear side registration motor problem When the rear-side registration home-position sensor is turned on during initialization, the sensor did not turn on while it has moved by 106 pulses. When the rear-side registration home-position sensor is turned off during initialization, the sensor did not turn on in 3 s.	The rear side registration motor connector makes poor contact.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable.
		Defective rear side registration motor.	Replace rear side registration motor.
		The rear side registration home position sensor connector makes poor contact.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable.
		Defective rear side registration home position sensor.	Replace the rear side registration home position sensor.
		Defective finisher control PWB.	Replace the finisher control PWB and check for correct operation.

Code	Contents	Remarks	
		Causes	Check procedures/corrective measures
C8190	Finisher trailing edge registration motor problem When the trailing edge registration home-position sensor is turned on during initialization, the sensor did not turn on while it has moved by 106 pulses. When the trailing edge registration home-position sensor is turned off during initialization, the sensor did not turn on in 3 s.	The trailing edge registration motor connector makes poor contact.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable.
		Defective trailing edge registration motor.	Replace trailing edge registration motor.
		The trailing edge registration home position sensor connector makes poor contact.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable.
		Defective trailing edge registration home position sensor.	Replace the trailing edge registration home position sensor.
		Defective finisher control PWB.	Replace the finisher control PWB and check for correct operation.
C8210	Finisher stapler problem The stapler home position sensor does not change state from nondetection to detection within 200 ms of the start of stapler motor counterclockwise (forward) rotation. During initialization, the stapler home position sensor does not change state from non-detection to detection within 600 ms of the start of stapler motor clockwise (reverse) rotation.	The stapler connector makes poor contact.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable.
		The stapler is blocked with a staple.	Remove the stapler cartridge, and check the cartridge and the stapling section of the stapler.
		The stapler is broken.	Replace the front stapler and check for correct operation.
		Defective finisher control PWB.	Replace the finisher control PWB and check for correct operation.

1-4-3 Electric problems

Troubleshooting to each failure must be in the order of the numbered symptoms.

Problem	Causes	Check procedures/corrective measures
(1) The paper conveying motor does not operate.	1. Poor contact in the connector terminals.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable.
	2. Broken motor coil.	Check for continuity across the coil. If none, replace the motor.
	3. Defective drive transmission system.	Check if the rollers and gears rotate smoothly. If not, grease the bushings and gears. Check for broken gears and replace if any.
(2) The feedshift solenoid does not operate.	1. Broken solenoid coil.	Check for continuity across the coil. If none, replace the solenoid.
	2. Poor contact in the connector terminals.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable.
	3. Defective engine PWB.	Run maintenance item U033 and check if the solenoid operates. If not, replace the engine PWB.
(3) The pickup solenoid does not operate.	1. Broken solenoid coil.	Check for continuity across the coil. If none, replace the solenoid.
	2. Poor contact in the connector terminals.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable.

1-4-4 Mechanical problems

Problem	Causes/check procedures	Corrective measures
(1) Paper jams.	Check if the contact between the feedshift roller and feedshift pulleys is correct.	Check and remedy.
	Check if the contact between the feedshift roller and press roller is correct.	Check and remedy.
	Check if the contact between the eject roller and eject pulleys is correct.	Check and remedy.
(2) Abnormal noise is heard.	Check if the rollers and gears operate smoothly.	Clean with isopropyl alcohol.

1-5-1 Precautions for assembly and disassembly

(1) Precautions

Before starting disassembly the finisher, press the Power key on the operation panel to off. Make sure that the Power indicator and the Memory indicator are off before turning off the main power switch. And then unplug the power cable from the wall outlet. Turning off the main power switch before pressing the Power key to off may cause damage to the equipped hard disk.

When handling PWBs (printed wiring boards), do not touch parts with bare hands. The PWBs are susceptible to static charge.

Do not touch any PWB containing ICs with bare hands or any object prone to static charge.

When removing the hook of the connector, be sure to release the hook.

Take care not to get the cables caught.

To reassemble the parts, use the original screws. If the types and the sizes of screws are not known, refer to the PARTS LIST.

(2) Adjusting the positions of the front side registration cursor, rear side registration cursor and trailing edge registration cursor (reference)

Perform the following adjustment if paper registration is poor or stapling is made outside the specified area.

Procedure





Figure 1-5-1 Stapling position

FRONT: Stop position of the front side registration cursor
 REAR : Stop position of the rear side registration cursor
 END : Stop position of the trailing edge registration cursor

Setting range: -4 to 4
 Initial setting: 0
 Changing the value by 1 changes the position by 0.566 mm.

Decreasing the value moves the front or rear side registration cursor or trailing edge registration cursor outward (➡); increasing the value moves each cursor inward (⇐). See Figure 1-5-2.




Figure 1-5-2

(3) Cleaning the staple

During periodic maintenance, remove all the staples remaining inside the machine due to failure of stapling.

Procedure

1. Open the front and left covers of the machine.
2. Open the staple cover and then remove the staple cartridge.




Figure 1-5-3

3. Remove the clip holder.
4. Remove three screws securing the staple cover and then the cover.




Figure 1-5-4

5. Remove the staples attracted to the magnet on the inside of the staple cover.
6. Refit the staple cover, staple cartridge and clip holder.
7. Close the left and front covers.





Figure 1-5-5

(4) Adjusting the pressure of curl eliminator mechanism

Increase the pressure of the curl eliminator mechanism to reduce upward curling of paper stacked on the process table if a paper jam occurs when batch ejection is performed because of strong upward curling.

Procedure

1. Remove the paper conveying unit from the machine.
2. Loosen each two screws from the front and rear curl eliminator pressure adjusting plates respectively and then remove the plates.
3. Retighten each two screws.
4. Refit the all removed parts.

**Figure 1-5-6**

2-1-1 Construction of each section

The paper conveying section consists of the components shown in Figure 2-1-1. It switches the path for the paper conveyed from the machine in sort mode. Also the paper conveying section contains a curl eliminator mechanism, which reduces curling of paper with curl eliminator rollers.




Figure 2-1-1 Paper conveying section

- | | |
|----------------------------------|------------------------------------|
| (1) Feedshift pulleys | (9) Feedshift solenoid (FSSOL) |
| (2) Feedshift roller | (10) Eject roller |
| (3) Press roller | (11) Eject pulleys |
| (4) Press roller lift | (12) Paper conveying switch (PCSW) |
| (5) Stopper | (13) Upper guide plate |
| (6) Upper curl eliminator roller | (14) Lower guide plate |
| (7) Lower curl eliminator roller | (15) Pickup solenoid (PUSOL) |
| (8) Feedshift claw | |




Figure 2-1-2 Paper conveying section block diagram

(1) Paper conveying operation in sort mode

In the sort mode, the feedshift solenoid (FSSOL) turns on and the feedshift guide of the machine operates to switch the paper path to the paper conveying unit. After curling of the conveyed paper is eliminated by the curl eliminator rollers, the paper is conveyed to the process table by the feedshift roller. When the trailing edge registration cursor of the process table shifts the paper stocked in the process table to the stopper, the pickup solenoid (PUSOL) turns on to lift the press roller and release the stopper. The stack of paper on the process table is ejected to the finisher tray by the feedshift roller and eject roller.




Figure 2-1-3

2-1-2 Process table section

The process table section consists of the components shown in Figure 2-1-4. It stores and evens up the paper conveyed from the paper conveying section and returns the stack of paper to the paper conveying section.




Figure 2-1-4 Process table section







Figure 2-1-5 Process table section block diagram

(1) Paper registration on the process table

In sort mode, the front and rear side registration cursors move to the size of the paper used to even up the sides of the stack of paper and the trailing edge registration cursor shifts the paper to the paper conveying section.

In staple-sort mode, the front and rear side registration cursors even up the sides of the stack of paper and shift the stack toward the machine front, and then the trailing edge registration cursor shifts the stack to the stapling position.

Home positions**Paper registration****Shifting the paper to the stapling position****Figure 2-1-6**

2-1-3 Stapler section

In staple-sort mode, paper stocked on the process table is stapled by the stapler. The stapler motor (STM) drives the stapler cam via the stapler drive gear to staple paper.




Figure 2-1-7 Stapler section




Figure 2-1-8 Stapler section block diagram

This page is intentionally left blank.

2-2-1 Electrical parts layout

(1) Paper conveying section






Figure 2-2-1 Paper conveying section

- | | | |
|----|-------------------------------------|--|
| 1. | Paper conveying motor (PCM)..... | Drives the paper conveying section. |
| 2. | Paper conveying switch (PCSW) | Detects a paper jam in the finisher. |
| 3. | Feedshift solenoid (FSSOL)..... | Operates the feedshift guide of the machine. |
| 4. | Pickup solenoid (PUSOL) | Operates the press roller. |

(2) Process table section**Figure 2-2-2 Process table section**

1. Finisher control PWB (FINPWB)..... Controls electrical components.
2. Process table sensor (PTS) Detects the presence of paper on the process table.
3. Trailing edge registration motor (TERM)..... Drives the trailing edge registration cursor.
4. Front side registration motor (FSRM) Drives the front side registration cursor.
5. Rear side registration motor (RSRM)..... Drives the rear side registration cursor.
6. Trailing edge registration home position sensor (TERHPS) Detects the trailing edge registration cursor in the home position.
7. Side registration front home position sensor (SRFHPS) Detects the front side registration cursor in the home position.
8. Side registration rear home position sensor (SRRHPS)..... Detects the rear side registration cursor in the home position.
9. Tray open/close switch (TOCSW)..... Detects if the process table is opened or closed.

(3) Stapler section**Figure 2-2-3 Stapler section**

1. Stapler empty sensor (STES) Detects the presence of staples.
2. Staple cartridge sensor (STCS) Detects the presence of the staple cartridge.
3. Stapler home position sensor (STHPS) Detects the stapler in the home position.
4. Stapler self-priming sensor (STSPS) Detects the pre-stapling state of the stapler.
5. Stapler motor (STM)..... Drives the stapler.

This page is intentionally left blank.

2-3-1 Finisher control PWB




Figure 2-3-1 Finisher control PWB diagram




Figure 2-3-2 Finisher control PWB silk-screen diagram

Connector	Pin No.	Signal	I/O	Voltage	Description
YC1 Connected to the machine	1	24V	I	24 V DC	24 V DC supply
	2	24V	I	24 V DC	24 V DC supply
	3	PGND	-	-	Ground
	4	PGND	-	-	Ground
	5	5V	I	5 V DC	5 V DC supply
	6	SGND	-	-	Ground
	7	DF SEL	I	0/5 V DC	Finisher select signal
	8	DF RDY	O	0/5 V DC	Finisher ready signal
	9	SDO	I	0/5 V DC (pulse)	Serial communication data signal
	10	SDI	O	0/5 V DC (pulse)	Serial communication data signal
	11	SCLK	I	0/5 V DC (pulse)	Clock signal for serial communication
	12	JCT SOL(ACT)	I	0/24 V DC	FSSOL (active): On/Off
	13	JCT SOL(RET)	I	0/24 V DC	FSSOL (return): On/Off
YC2 Connected to pickup solenoid, feedshift solenoid, paper conveying motor, stapler section and paper conveying switch	1	JCT SOL(RET)	O	0/24 V DC	FSSOL drive signal (return)
	2	PU SOL	O	0/24 V DC	PUSOL: On/Off
	3	JCT SOL(ACT)	O	0/24 V DC	FSSOL drive signal (active)
	4	CMOT A	O	0/24 V DC (pulse)	PCM drive pulse (A)
	5	JCT SOL 24V	O	24 V DC	24 V DC supply for FSSOL
	6	CMOT B	O	0/24 V DC (pulse)	PCM drive pulse (B)
	7	PU SOL 24V	O	24 V DC	24 V DC supply for PUSOL
	8	CMOT _A	O	0/24 V DC (pulse)	PCM drive pulse (_A)
	9	CMOT A 24V	O	24 V DC	24 V DC supply for PCM A
	10	CMOT _B	O	0/24 V DC (pulse)	PCM drive pulse (_B)
	11	CMOT B 24V	O	24 V DC	24 V DC supply for PCM B
	12	ST MOT R	O	0/24 V DC	STM reverse rotation drive signal
	13	ST CART	I	0/5 V DC	STCS: On/Off
	14	ST MOT R	O	0/24 V DC	STM reverse rotation drive signal
	15	ST LOW	I	0/5 V DC	STES: On/Off
	16	ST MOT F	O	0/24 V DC	STM forward rotation drive signal
	17	ST SP	O	0/5 V DC	STSPS: On/Off
	18	ST MOT F	O	0/24 V DC	STM forward rotation drive signal
	19	ST HP	I	0/5 V DC	STHS: On/Off
	20	ST GND	-	-	Ground
	21	FEED	I	0/5 V DC	PCSW: On/Off
	22	FEED GND	-	-	Ground
	23	FEED 5V	O	5 V DC	5 V DC supply for PCSW
	24	ST 5V	O	5 V DC	5 V DC supply for STM

Connector	Pin No.	Signal	I/O	Voltage	Description
YC3 Connected to process table sensor and side registration front home position sensor	1	TRAY 5V	O	5 V DC	5 V DC supply for PTS
	2	TRAY	I	0/5 V DC	PTS: On/Off
	3	TRAY GND	-	-	Ground
	4	FJHP 5V	O	5 V DC	5 V DC supply for SRFHPS
	5	FJ HP	I	0/5 V DC	SRFHPS: On/Off
	6	FJHP GND	-	-	Ground
YC4 Connected to front side registration motor, rear side registration motor and trailing edge registration motor	1	FJ A	O	0/24 V DC (pulse)	FSRM drive pulse (A)
	2	COM	O	24 V DC	24 V DC supply for FSRM
	3	FJ _B	O	0/24 V DC (pulse)	FSRM drive pulse (_B)
	4	FJ B	O	0/24 V DC (pulse)	FSRM drive pulse (B)
	5	FJ _A	O	0/24 V DC (pulse)	FSRM drive pulse (_A)
	6	RJ A	O	0/24 V DC (pulse)	RSRM drive pulse (A)
	7	COM	O	24 V DC	24 V DC supply for RSRM
	8	RJ _B	O	0/24 V DC (pulse)	RSRM drive pulse (_B)
	9	RJ B	O	0/24 V DC (pulse)	RSRM drive pulse (B)
	10	RJ _A	O	0/24 V DC (pulse)	RSRM drive pulse (_A)
	11	RE A	O	0/24 V DC (pulse)	TERM drive pulse (A)
	12	COM	O	24 V DC	24 V DC supply for TERM
	13	RE _B	O	0/24 V DC (pulse)	TERM drive pulse (_B)
	14	RE B	O	0/24 V DC (pulse)	TERM drive pulse (B)
	15	RE _A	O	0/24 V DC (pulse)	TERM drive pulse (_A)
YC5 Connected to tray open/close switch, side registration rear home position sensor and trailing edge registration home position sensor	1	TOPN 5V	-	-	5 V DC supply for TOCSW
	2	TOPN	I	0/5 V DC	TOCSW: On/Off
	3	TOPN GND	-	-	Ground
	4	RJ HP 5V	O	5 V DC	5 V DC supply for SRRHPS
	5	RJ HP	I	0/5 V DC	SRRHPS: On/Off
	6	RJ HP GND	-	-	Ground
	7	RE HP 5V	O	5 V DC	5 V DC supply for TERHPS
	8	RE HP	I	0/5 V DC	TERHPS: On/Off
	9	RE HP GND	-	-	Ground

Maintenance parts list

Maintenance part name		Part No.	Alternative part No.	Fig. No.	Ref. No.
Name used in service manual	Name used in parts list				
Process table	-	-	-	3	-
Upper curl eliminator roller	UPPER ROLLER DECURLER	3HP08110	-	2	25
Lower curl eliminator roller	PARTS ROLLER DECURLER SP	303LB94020	3LB94020	2	19
Eject roller	ROLLER EJECT	303HP08121	3HP08121	2	7
Eject pulleys	PULLEY,LOOP FEED	63210170	-	1	56
Feedshift roller	ROLLER FEED SHIFT	303HP08091	3HP08091	2	6
Feedshift pulleys	PULLEY,BRANCH	3BN08100	-	1	22
Press roller	PULLEY STOPPER PRESSURE	3HP08390	-	1	44
Switches and sensors	-	-	-	-	-


Periodic maintenance procedures

Section	Maintenance part/location	Method	Maintenance cycle	Points and cautions	Page
Paper conveying and process table section	Process table	Clean and grease	Every service	Clean the rail section and apply molycote grease EM-50L 50G (P/N: M014000080).	
	Upper curl eliminator roller	Clean Check and clean	Every service User call	Clean with alcohol. (Check and clean with alcohol when user call occurs.)	
	Lower curl eliminator roller	Clean Check and clean	Every service User call	Clean with alcohol. (Check and clean with alcohol when user call occurs.)	
	Eject roller	Clean Check and clean	Every service User call	Clean with alcohol. (Check and clean with alcohol when user call occurs.)	
	Eject pulleys	Clean Check and clean	Every service User call	Clean with alcohol. (Check and clean with alcohol when user call occurs.)	
	Feedshift roller	Clean Check and clean	Every service User call	Clean with alcohol. (Check and clean with alcohol when user call occurs.)	
	Feedshift pulleys	Clean Check and clean	Every service User call	Clean with alcohol. (Check and clean with alcohol when user call occurs.)	
	Press roller	Clean Check and clean	Every service User call	Clean with alcohol. (Check and clean with alcohol when user call occurs.)	
	Switches and sensors	Clean Check and clean	Every service User call	Airbrush.	



Section	Maintenance part/location	Method	Maintenance cycle	Points and cautions	Page
Stapler section	Magnet	Clean	Every service	Remove the staples attracted to the magnet inside the stapler cover.	P.1-5-3

Wiring diagram



KYOCERA MITA EUROPE B.V.

Hoeksteen 40, 2132 MS Hoofddorp,
The Netherlands
Phone: +31.20.654.0000
Home page: <http://www.kyoceramita-europe.com>
Email: info@kyoceramita-europe.com

KYOCERA MITA NEDERLAND B.V.
Beechavenue 25, 1119RA Schiphol-Rijk
The Netherlands
Phone: +31.20.58.77.200

KYOCERA MITA (UK) LTD
8 Beacontree Plaza
Gillette Way Reading Berks RG2 OBS,
U.K.
Phone: +44.1189.311.500

KYOCERA MITA ITALIA S.p.A.
Via G. Verdi, 89 / 91, 20063 Cernusco s/N
Milano, Italy
Phone: +39.02.92179.1

S.A. KYOCERA MITA BELGIUM N.V.
Hermesstraat 8A, 1930 Zaventem,
Belgium
Phone: +32.2.720.9270

KYOCERA MITA FRANCE S.A.
Parc Les Algorithmes Saint Aubin
91194 GIF-SUR-YVETTE,
France
Phone: +33.1.6985.2600

KYOCERA MITA ESPAÑA S.A.
Edificio Kyocera, Avda de Manacor No. 2,
28290 Las Matas (Madrid),
Spain
Phone: +34.91.631.8392

KYOCERA MITA FINLAND OY
Kirvesmiehenkatu 4, 00880 Helsinki,
Finland
Phone: +358.9.4780.5200

KYOCERA MITA (SCHWEIZ)
Hohlstrasse 614, 8048 Zürich
Switzerland
Phone: +41.1.908.4949

KYOCERA MITA DEUTSCHLAND GMBH
Otto-Hahn-Str. 12 D-40670 Meerbusch,
Germany
Phone: +49.2159.918.0

KYOCERA MITA GMBH AUSTRIA
Eduard-Kittenberger-Gasse 95,
1230 Wien,
Austria
Phone: +43.1.86338.210

KYOCERA MITA SVENSKA AB
Esbogatan 16B 164 75 Kista,
Sweden
Phone: +46.8.546.55000

KYOCERA MITA NORGE
Postboks 150 Oppsal, NO 0619 Oslo
Olaf Helsetsvai 6, NO 0694 Oslo,
Norway
Phone: +47.22.62.73.00

KYOCERA MITA DANMARK A/S
Ejby Industrivej 1, DK-2600 Glostrup,
Denmark
Phone: +45.5687.1100

KYOCERA MITA PORTUGAL LDA.
Rua do Centro Cultural, 41 (Alvalade) 1700-106 Lisbon,
Portugal
Phone: +351.21.842.9100

KYOCERA MITA SOUTH AFRICA (PTY) LTD.
527 Kyalami Boulevard,
Kyalami Business Park Midrand,
South Africa
Phone: +27.(0)11.540.2600

KYOCERA MITA AMERICA, INC.

Headquarters:
225 Sand Road,
Fairfield, New Jersey 07004-0008,
U.S.A.
Phone: (973) 808-8444

KYOCERA MITA AUSTRALIA PTY. LTD.
Level 3, 6-10 Talavera Road, North Ryde,
N.S.W. 2113 Australia
Phone: (02) 9888-9999

KYOCERA MITA NEW ZEALAND LTD.
1-3 Parkhead Place, Albany
P.O. Box 302 125 NHPC, Auckland,
New Zealand
Phone: (09) 415-4517

KYOCERA MITA (THAILAND) CORP., LTD.
9/209 Ratchada-Prachachem Road,
Bang Sue, Bangkok 10800, Thailand
Phone: (02) 586-0320

KYOCERA MITA SINGAPORE PTE LTD.
121 Genting Lane, 3rd Level,
Singapore 349572
Phone: 67418733

KYOCERA MITA HONG KONG LIMITED
11/F., Mita Centre,
552-566, Castle Peak Road,
Tsuen Wan, New Territories,
Hong Kong
Phone: 24297422

KYOCERA MITA TAIWAN Corporation.
7F-1~2, No.41, Lane 221, Gangchi Rd.
Neihu District, Taipei, Taiwan, 114. R.O.C.
Phone: (02) 87511560

KYOCERA MITA Corporation

2-28, 1-chome, Tamatsukuri, Chuo-ku
Osaka 540-8585, Japan
Phone: (06) 6764-3555
<http://www.kyoceramita.com>

KYOCERA MITA AMERICA, INC.

Headquarters:

225 Sand Road,
Fairfield, New Jersey 07004-0008
TEL : (973) 808-8444
FAX : (973) 882-6000

New York Branch:

1410 Broadway 23rd floor
New York, NY 10018
TEL : (917) 286-5400
FAX : (917) 286-5402

Northeastern Region:

225 Sand Road,
Fairfield, New Jersey 07004-0008
TEL : (973) 808-8444
FAX : (973) 882-4401

Midwestern Region:

201 Hansen Court Suite 119
Wood Dale, Illinois 60191
TEL : (630) 238-9982
FAX : (630) 238-9487

Western Region:

14101 Alton Parkway,
Irvine, California 92618-7006
TEL : (949) 457-9000
FAX : (949) 457-9119

Southeastern Region:

1500 Oakbrook Drive,
Norcross, Georgia 30093
TEL : (770) 729-9786
FAX : (770) 729-9873

Southwestern Region:

2825 West Story Road,
Irving, Texas 75038-5299
TEL : (972) 550-8987
FAX : (972) 252-9786

National Operation Center & National Training Center:

2825 West Story Road,
Irving, Texas 75038-5299
TEL : (972) 659-0055
FAX : (972) 570-5816

Latin America Division:

8240 N.W. 52nd. Terrace Dawson Building,
Suite 108 Miami, Florida 33166
TEL : (305) 421-6640
FAX : (305) 421-6666

KYOCERA MITA CANADA, LTD.

6120 Kestrel Road, Mississauga,
Ontario L5T 1S8, Canada
TEL : (905) 670-4425
FAX : (905) 670-8116

KYOCERA MITA MEXICO, S.A. DE C.V.

Av. 16 de Septiembre #407
Col. Santa Inés,
Azcapotzalco México,
D.F. 02130, México
TEL : (55) 5383-2741
FAX : (55) 5383-7804