



FS-C8520MFP FS-C8525MFP

SERVICE MANUAL

Published in August 2012
842MY113
2MYSM063
Rev.3

CAUTION

RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE. DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS.

It may be illegal to dispose of this battery into the municipal waste stream. Check with your local solid waste officials for details in your area for proper disposal.

ATTENTION

IL Y A UN RISQUE D'EXPLOSION SI LA BATTERIE EST REMPLACÉE PAR UN MODÈLE DE TYPE INCORRECT. METTRE AU REBUT LES BATTERIES UTILISÉES SELON LES INSTRUCTIONS DONNÉES.

Il peut être illégal de jeter les batteries dans des eaux d'égout municipales. Vérifiez avec les fonctionnaires municipaux de votre région pour les détails concernant des déchets solides et une mise au rebut appropriée.

Revision history

Revision	Date	Replaced pages	Remarks
1	21 June 2012	Contents, 1-3-15, 1-3-95, 1-3-96, 1-4-35, 1-5-15	-
2	19 July 2012	Contents, 1-4-36, 2-4-10 to 20	-
3	20 August 2012	1-3-82, 1-3-146 to 1-3-148, 2-4-22	-

This page is intentionally left blank.

Safety precautions

This booklet provides safety warnings and precautions for our service personnel to ensure the safety of their customers, their machines as well as themselves during maintenance activities. Service personnel are advised to read this booklet carefully to familiarize themselves with the warnings and precautions described here before engaging in maintenance activities.

Safety warnings and precautions

Various symbols are used to protect our service personnel and customers from physical danger and to prevent damage to their property. These symbols are described below:

⚠ DANGER: High risk of serious bodily injury or death may result from insufficient attention to or incorrect compliance with warning messages using this symbol.

⚠ WARNING: Serious bodily injury or death may result from insufficient attention to or incorrect compliance with warning messages using this symbol.

⚠ CAUTION: Bodily injury or damage to property may result from insufficient attention to or incorrect compliance with warning messages using this symbol.

Symbols

The triangle (\triangle) symbol indicates a warning including danger and caution. The specific point of attention is shown inside the symbol.



General warning.



Warning of risk of electric shock.



Warning of high temperature.

⊘ indicates a prohibited action. The specific prohibition is shown inside the symbol.



General prohibited action.



Disassembly prohibited.

● indicates that action is required. The specific action required is shown inside the symbol.



General action required.



Remove the power plug from the wall outlet.



Always ground the copier.

1. Installation Precautions

WARNING

- Do not use a power supply with a voltage other than that specified. Avoid multiple connections to one outlet: they may cause fire or electric shock. When using an extension cable, always check that it is adequate for the rated current. 
- Connect the ground wire to a suitable grounding point. Not grounding the copier may cause fire or electric shock. Connecting the earth wire to an object not approved for the purpose may cause explosion or electric shock. Never connect the ground cable to any of the following: gas pipes, lightning rods, ground cables for telephone lines and water pipes or faucets not approved by the proper authorities. 

CAUTION:

- Do not place the copier on an infirm or angled surface: the copier may tip over, causing injury. 
- Do not install the copier in a humid or dusty place. This may cause fire or electric shock. 
- Do not install the copier near a radiator, heater, other heat source or near flammable material. This may cause fire. 
- Allow sufficient space around the copier to allow the ventilation grills to keep the machine as cool as possible. Insufficient ventilation may cause heat buildup and poor copying performance. 
- Always handle the machine by the correct locations when moving it. 
- Always use anti-toppling and locking devices on copiers so equipped. Failure to do this may cause the copier to move unexpectedly or topple, leading to injury. 
- Avoid inhaling toner or developer excessively. Protect the eyes. If toner or developer is accidentally ingested, drink a lot of water to dilute it in the stomach and obtain medical attention immediately. If it gets into the eyes, rinse immediately with copious amounts of water and obtain medical attention. 
- Advice customers that they must always follow the safety warnings and precautions in the copier's instruction handbook. 

2. Precautions for Maintenance

WARNING

- Always remove the power plug from the wall outlet before starting machine disassembly. 
- Always follow the procedures for maintenance described in the service manual and other related brochures. 
- Under no circumstances attempt to bypass or disable safety features including safety mechanisms and protective circuits. 
- Always use parts having the correct specifications. 
- Always use the thermostat or thermal fuse specified in the service manual or other related brochure when replacing them. Using a piece of wire, for example, could lead to fire or other serious accident. 
- When the service manual or other serious brochure specifies a distance or gap for installation of a part, always use the correct scale and measure carefully. 
- Always check that the copier is correctly connected to an outlet with a ground connection. 
- Check that the power cable covering is free of damage. Check that the power plug is dust-free. If it is dirty, clean it to remove the risk of fire or electric shock. 
- Never attempt to disassemble the optical unit in machines using lasers. Leaking laser light may damage eyesight. 
- Handle the charger sections with care. They are charged to high potentials and may cause electric shock if handled improperly. 

CAUTION

- Wear safe clothing. If wearing loose clothing or accessories such as ties, make sure they are safely secured so they will not be caught in rotating sections. 
- Use utmost caution when working on a powered machine. Keep away from chains and belts. 
- Handle the fixing section with care to avoid burns as it can be extremely hot. 
- Check that the fixing unit thermistor, heat and press rollers are clean. Dirt on them can cause abnormally high temperatures. 

- Do not remove the ozone filter, if any, from the copier except for routine replacement. 
- Do not pull on the AC power cord or connector wires on high-voltage components when removing them; always hold the plug itself. 
- Do not route the power cable where it may be stood on or trapped. If necessary, protect it with a cable cover or other appropriate item. 
- Treat the ends of the wire carefully when installing a new charger wire to avoid electric leaks. 
- Remove toner completely from electronic components. 
- Run wire harnesses carefully so that wires will not be trapped or damaged. 
- After maintenance, always check that all the parts, screws, connectors and wires that were removed, have been refitted correctly. Special attention should be paid to any forgotten connector, trapped wire and missing screws. 
- Check that all the caution labels that should be present on the machine according to the instruction handbook are clean and not peeling. Replace with new ones if necessary. 
- Handle greases and solvents with care by following the instructions below: 
 - Use only a small amount of solvent at a time, being careful not to spill. Wipe spills off completely.
 - Ventilate the room well while using grease or solvents.
 - Allow applied solvents to evaporate completely before refitting the covers or turning the power switch on.
 - Always wash hands afterwards.
- Never dispose of toner or toner bottles in fire. Toner may cause sparks when exposed directly to fire in a furnace, etc. 
- Should smoke be seen coming from the copier, remove the power plug from the wall outlet immediately. 

3. Miscellaneous

WARNING

- Never attempt to heat the drum or expose it to any organic solvents such as alcohol, other than the specified refiner; it may generate toxic gas. 
- Keep the machine away from flammable liquids, gases, and aerosols. A fire or an electric shock might occur. 

This page is intentionally left blank.

CONTENTS

1-1 Specifications

1-1-1 Specifications	1-1-1
1-1-2 Parts names	1-1-6
(1) Machine (front side).....	1-1-6
(2) Machine (rear side).....	1-1-8
(3) Operation panel	1-1-9
1-1-3 Machine cross section	1-1-10

1-2 Installation

1-2-1 Installation environment.....	1-2-1
1-2-2 Unpacking and installation.....	1-2-2
(1) Installation procedure	1-2-2
(2) Setting initial copy modes.....	1-2-13
1-2-3 Install the expansion memory (option).....	1-2-14
1-2-4 Option composition	1-2-15

1-3 Maintenance Mode

1-3-1 Maintenance mode	1-3-1
(1) Executing a maintenance item	1-3-1
(2) Maintenance modes item list	1-3-2
(3) Contents of the maintenance mode items	1-3-10
1-3-2 Service mode.....	1-3-134
(1) Printing the service status page	1-3-134
(2) Executing a service mode	1-3-141
(3) Description of service mode	1-3-141

1-4 Troubleshooting

1-4-1 Paper misfeed detection	1-4-1
(1) Paper misfeed indication	1-4-1
(2) Paper misfeed detection component	1-4-2
1-4-2 Self-diagnostic function	1-4-9
(1) Self-diagnostic function	1-4-9
(2) Self-diagnostic codes	1-4-9
1-4-3 Image quality problems	1-4-37
(1) No image appears (entirely white).....	1-4-38
(2) No image appears (entirely black).....	1-4-38
(3) Image is too light.	1-4-39
(4) The background is colored.	1-4-39
(5) White streaks are printed vertically.....	1-4-39
(6) Black streaks are printed vertically.....	1-4-40
(7) Streaks are printed horizontally.....	1-4-40
(8) One side of the print image is darker than the other.	1-4-40
(9) Spots are printed.	1-4-41
(10) Image is blurred.....	1-4-41
(11) The leading edge of the image is consistently misaligned with the original.	1-4-41
(12) The leading edge of the image is sporadically misaligned with the original.	1-4-41
(13) Paper is wrinkled.....	1-4-42
(14) Image is off-set.....	1-4-42
(15) Part of image is missing.	1-4-42
(16) Fusing is loose.....	1-4-42

(17) Image is out of focus	1-4-43
(18) Image center does not align with the original center	1-4-43
1-4-4 Electric problems	1-4-44
1-4-5 Mechanical problems.....	1-4-51
1-4-6 Send error code	1-4-53
(1) Scan to SMB error codes	1-4-53
(2) Scan to FTP error codes	1-4-54
(3) Scan to E-mail error codes	1-4-55

1-5 Assembly and disassembly

1-5-1 Precautions for assembly and disassembly.....	1-5-1
(1) Precautions.....	1-5-1
(2) Drum unit	1-5-1
(3) Toner	1-5-1
(4) How to tell a genuine Kyocera Mita toner container	1-5-2
1-5-2 Outer covers	1-5-3
(1) Detaching and refitting the front cover.....	1-5-3
(2) Detaching and refitting the rear cover	1-5-5
(3) Detaching and refitting the inner tray.....	1-5-6
(4) Detaching and refitting the eject rear cover.....	1-5-8
1-5-3 Paper feed section.....	1-5-10
(1) Detaching and refitting the primary paper feed unit.....	1-5-10
(2) Detaching and refitting the MP paper feed roller and MP separation pad.....	1-5-11
(3) Detaching and refitting the registration roller	1-5-12
(4) Detaching and refitting the registration cleaner	1-5-13
(5) Detaching and refitting the MP tray	1-5-13
1-5-4 Developing section	1-5-14
(1) Detaching and refitting the developing unit	1-5-14
1-5-5 Drum section	1-5-16
(1) Detaching and refitting the drum unit.....	1-5-16
(2) Detaching and refitting the charger roller unit.....	1-5-16
1-5-6 Transfer/separation section	1-5-17
(1) Detaching and refitting the intermediate transfer unit.....	1-5-17
(2) Detaching and refitting the secondary transfer roller unit	1-5-17
1-5-7 Fuser section	1-5-18
(1) Detaching and refitting the fuser unit.....	1-5-18
1-5-8 Drive section	1-5-19
(1) Detaching and refitting the conveying motor	1-5-19
(2) Detaching and refitting the drive unit	1-5-19
1-5-9 Optical section	1-5-20
(1) Detaching and refitting the laser scanner unit	1-5-20
(2) Detaching and refitting the image scanner unit	1-5-21
(3) Detaching and refitting the LED unit.....	1-5-24
1-5-10 Document processor	1-5-26
(1) Detaching and refitting the document processor	1-5-26
(2) Detaching and refitting the DP paper feed roller and DP separation pulley	1-5-27
(3) Detaching and refitting the DP main PWB.....	1-5-29
1-5-11 PWBs.....	1-5-31
(1) Detaching and refitting the main PWB.....	1-5-31
(2) Detaching and refitting the engine PWB.....	1-5-32
(3) Detaching and refitting the power source PWB.....	1-5-33
(4) Detaching and refitting the operation panel PWB main.....	1-5-34
(5) Detaching and refitting the IH PWB.....	1-5-36

1-5-12 Others	1-5-37
(1) Detaching and refitting the language sheet	1-5-37
(2) Detaching and refitting the conveying unit.....	1-5-38
(3) Detaching and refitting the imaging fan motor	1-5-40
(4) Direction of installing the principal fan motors	1-5-40

1-6 Requirements on PWB Replacement

1-6-1 Upgrading the firmware	1-6-1
1-6-2 Remarks on PWB replacement	1-6-3
(1) Engine PWB	1-6-3
(2) DP main PWB.....	1-6-3
(3) Main PWB.....	1-6-4

2-1 Mechanical Construction

2-1-1 Paper feed/conveying section	2-1-1
(1) Cassette paper feed section	2-1-1
(2) MP tray paper feed section.....	2-1-3
(3) Conveying section	2-1-4
2-1-2 Drum section	2-1-5
2-1-3 Developing section	2-1-7
2-1-4 Optical section	2-1-9
(1) Image scanner section	2-1-9
(2) Laser scanner section	2-1-11
2-1-5 Transfer/Separation section	2-1-13
(1) Intermediate transfer unit section	2-1-13
(2) Secondary transfer roller section.....	2-1-15
2-1-6 Fuser section	2-1-16
2-1-7 Eject/Feedshift section	2-1-18
2-1-8 Duplex conveying section.....	2-1-20
2-1-9 Document processor	2-1-22
(1) Original feed section	2-1-22
(2) Original conveying section.....	2-1-24
(3) Original switchback/eject sections	2-1-26

2-2 Electrical Parts Layout

2-2-1 Electrical parts layout	2-2-1
(1) PWBs.....	2-2-1
(2) Switches and sensors.....	2-2-4
(3) Motors.....	2-2-6
(4) Others.....	2-2-8

2-3 Operation of the PWBs

2-3-1 Main PWB.....	2-3-1
2-3-2 Engine PWB	2-3-7
2-3-3 Power source PWB	2-3-20
2-3-4 IH PWB.....	2-3-23
2-3-5 Operation panel PWB main	2-3-26
2-3-6 DP main PWB.....	2-3-31

2-4 Appendixes

2-4-1 Appendixes	2-4-1
(1) Maintenance kits	2-4-1
(2) Repetitive defects gauge	2-4-2
(3) Firmware environment commands	2-4-3
(4) System Error (Fxxxx) Outline	2-4-10
(5) Chart of image adjustment procedures	2-4-21
(6) Wiring diagram	2-4-23

Installation Guide

PF-470/471 (Paper feeder)
DF-470/AK-470 (Document finisher)
FAX System(U)

1-1-1 Specifications

Machine

Item	Specifications				
	20ppm		25ppm		
Type	Desktop				
Printing method	Electrophotography by semiconductor laser, tandem (4) drum system				
Originals	Sheet, Book, 3-dimensional objects (maximum original size: A3/Ledger)				
Original feed system	Fixed				
Paper weight	Cassette	60 to 256 g/m ² (Duplex: 60 to 220 g/m ²)			
	MP tray	60 to 256 g/m ² , 230μm (Cardstock)			
Paper type	Cassette	Plain, Preprinted, Bond, Recycled, Vellum, Rough, Letter Head, Color, Pre-punched, Thick, High quality, Custom1 to 8 (Duplex: Same as simplex)			
	MP tray	Plain, Preprinted, Bond, Recycled, Vellum, Rough, Letter Head, Color, Pre-punched, Thick, High quality, Coated, Envelope, Cardstock, Transparency, Labels, Custom1 to 8			
Paper size	Cassette	A3, A4, A5, B4, B5, Ledger, Letter, Legal, Statement, Oficio II, Folio, 8K, 16K			
	MP tray	A3, A4, A5, A6, B4, B5, ISO B5, B6, Ledger, Letter, Legal, Statement, Executive, Oficio II, Folio, 8K, 16K, Envelope #10, Envelope #9, Envelope #6, Envelope Monarch, Envelope DL, Envelope C4, Envelope C5, Postcards, Return postcard, Youkei 2, Youkei 4, Custom			
Zoom level	Manual mode : 25 to 400%, 1% increments Auto mode : 400%, 200%, 141%, 122%, 115%, 86%, 81%, 70%, 50%, 25%				
Copying speed (Simplex) (When the DP is not used)		Color	B/W	Color	B/W
	A4/Letter	20 sheets/min	20 sheets/min	25 sheets/min	25 sheets/min
	A4R/LetterR	14 sheets/min	14 sheets/min	17 sheets/min	17 sheets/min
	A3/Ledger	8 sheets/min	10 sheets/min	9 sheets/min	13 sheets/min
	B4/Legal	9 sheets/min	10 sheets/min	10 sheets/min	13 sheets/min
	B5	20 sheets/min	20 sheets/min	25 sheets/min	25 sheets/min
	B5R	14 sheets/min	14 sheets/min	17 sheets/min	17 sheets/min
Copying speed (Simplex) (When using the DP)	A4/Letter	20 sheets/min	20 sheets/min	20 sheets/min	20 sheets/min
	A4R/LetterR	14 sheets/min	14 sheets/min	14 sheets/min	14 sheets/min
	A3/Ledger	8 sheets/min	10 sheets/min	9 sheets/min	10 sheets/min
	B4/Legal	9 sheets/min	10 sheets/min	10 sheets/min	11 sheets/min
	B5	20 sheets/min	20 sheets/min	20 sheets/min	20 sheets/min
	B5R	14 sheets/min	14 sheets/min	16 sheets/min	16 sheets/min
	A5R	10 sheets/min	10 sheets/min	13 sheets/min	13 sheets/min

Item		Specifications	
		20ppm	25ppm
First copy time (A4, feed from cassette)	When the DP is not used	B/W : 11.7 s or less Color : 13.6 s or less	B/W : 11.7 s or less Color : 13.6 s or less
	When using the DP	B/W : 12.7 s or less Color : 15.6 s or less	B/W : 11.7 s or less Color : 13.6 s or less
Warm-up time (22 °C/71.6 °F, 60% RH)		Power on : 55 s or less Low powermode : 10 s or less Sleep mode : 23 s or less	Power on : 45 s or less Low powermode : 10 s or less Sleep mode : 23 s or less
Paper capacity	Cassette	500 sheets (80g/m ²)	
	MP tray	100 sheets (80 g/m ² , plain paper, A4/Letter or less) 25 sheets (80 g/m ² , plain paper, A4/Letter or more)	
Output tray capacity		Inner tray : 250 sheets (80g/m ²) Job separator : 30 sheets (80g/m ²)	
Continuous copying		1 to 999 sheets	
Light source		White LED	
Scanning system		Flat bed scanning by CCD image sensor	
Photoconductor		OPC drum (diameter 30 mm)	
Image write system		Semiconductor laser:	
Charging system		Contact charger roller method	
Developer system		Touch down developing system Developer: 2-component Toner replenishing: Automatic from the toner container	
Transfer system		Primary: Transfer belt Secondary: Transfer roller	
Separation system		Small diameter separation, separation electrode	
Cleaning system		Counter blade cleaning	
Charge erasing system		Exposure by cleaning lamp (LED)	
Fusing system		One axis IH established method Heat source: IH inverter heating Abnormally high temperature protection devices: thermostat	
CPU		PowerPC464 (800MHz)	
Main memory	Standard	1.5 GB	
	Maximum	2.0 GB	
Interface	Standard	USB interface connector: 1 (USB Hi-speed) USB host: 2 (USB Hi-speed) Network interface: 1 (10BASE-T/100BASE-TX/1000BASE-T)	
	Option	eKUIO slot: 2	
		600 × 600 dpi	

Item		Specifications	
		20ppm	25ppm
Operating environment	Temperature	10 to 32.5 °C/50 to 90.5 °F	
	Humidity	15 to 80% RH	
	Altitude	2,500 m/8,202 ft or less	
	Brightness	1,500 lux or less	
Dimensions (W × D × H)		590 × 590 × 748 mm / 23 1/4" × 23 1/4 "× 29 7/16"	
Weight		80 kg / 176.4 lb (with toner containers)	
Space required (W × D)		874× 590 mm / 34 7/16" × 23 1/4" (using MP tray)	
Power source		120 V AC, 60 Hz, more than 12.0 A 220 - 240 V AC, 50/60 Hz, more than 7.2 A	
Options		Paper feeder (single cassette), Paper feeder (double cassette), Document finisher, Network kit, Fax kit, Expanded memory, Card Authentication KIT	

Document processor

Item	Specifications
Original feed method	Automatic feed
Supported original types	Sheet originals
Original sizes	Maximum: A3/Ledger Minimum : A5/Statement
Original weights	Simplex: 45 to 160 g/m ² Duplex : 50 to 120 g/m ²
Loading capacity	50 sheets (50 to 80 g/m ²) or less

Printer

Item	Specifications				
	20ppm		25ppm		
Printing speed (Simplex)		Color	B/W	Color	B/W
	A4/Letter	20 sheets/min	20 sheets/min	25 sheets/min	25 sheets/min
	A4R/LetterR	14 sheets/min	14 sheets/min	17 sheets/min	17 sheets/min
	A3/Ledger	10 sheets/min	10 sheets/min	13 sheets/min	13 sheets/min
	B4/Legal	10 sheets/min	10 sheets/min	13 sheets/min	13 sheets/min
	B5	20 sheets/min	20 sheets/min	25 sheets/min	25 sheets/min
	B5R	14 sheets/min	14 sheets/min	17 sheets/min	17 sheets/min
Printing speed (Duplex)	A5R	10 sheets/min	10 sheets/min	13 sheets/min	13 sheets/min
	A4/Letter	19 sheets/min	19 sheets/min	23 sheets/min	23 sheets/min
	A4R/LetterR	7 sheets/min	7 sheets/min	9 sheets/min	9 sheets/min
	A3/Ledger	6 sheets/min	6 sheets/min	7 sheets/min	7 sheets/min
	B4/Legal	6 sheets/min	6 sheets/min	7 sheets/min	7 sheets/min
	B5	19 sheets/min	19 sheets/min	23 sheets/min	23 sheets/min
	B5R	7 sheets/min	7 sheets/min	9 sheets/min	9 sheets/min
A5R	10 sheets/min	10 sheets/min	13 sheets/min	13 sheets/min	
First print time (A4, feed from cassette)	B/W : 11.0 s or less Color : 14.0 s or less		B/W : 10.0 s or less Color : 12.0 s or less		
Resolution	600 × 600 dpi				
Operating system	Windows2000, WindowsXP(32bit), Windows XP Professional x64 Edition, Windows Server 2003 (32-Bit x86), Windows Server 2003 x64 Edition, Windows Vista x86 Edition, Windows Vista x64 Edition, Windows Server 2008 (32-Bit x86), Windows Server 2008 x64 Edition, Windows 7 (32-Bit x86), Windows 7 (64-Bit x64), Mac OS 9.x, Mac OS X				
System requirements	IBM PC/AT compatible CPU: Celeron 600 MHz or higher RAM: It is based on the recommend environment of each OS. HDD free space: 20 MB or more				
Page description language	PRESCRIBE				

Scanner

Item		Specifications
Operating system		Windows XP (32bit/64bit), Windows Vista (32bit/64bit), Windows 7 (32bit/64bit), Windows Server 2003 (32bit/64bit), Windows Server 2008 (32bit/64bit), Windows Server 2008 R2
Resolution		600 dpi, 400 dpi, 300 dpi, 200 dpi, 200 × 100dpi, 200 × 400dpi
File format		TIFF (JPEG6.0, tn2), JPEG, XPS, PDF (1.4, /A)
Scanning speed	Simplex	B/W : 40 images/min Color: 40 images/min (A4 landscape, 300 dpi, Image quality: Text/Photo original)
	Duplex	B/W : 14 images/min Color : 14 images/min (A4 landscape, 300 dpi, Image quality: Text/Photo original)
Network protocol		TCP/IP
Transmission system		PC transmission SMB :Scan to PC FTP transmission FTP, FTP over SSL :Scan to FTP E-mail transmission SMTP :Scan to E-mail USB transmission USB :Scan to USB TWAIN SCAN TWAIN, WIA * WSDScan WSD-SCAN

* Available operating system: Windows Vista (32bit/64bit), Windows 7 (32bit/64bit),
Windows Server 2008 (32bit/64bit), Windows Server 2008 R2

NOTE: These specifications are subject to change without notice.

1-1-2 Parts names

(1) Machine (front side)




Figure 1-1-1

- | | |
|----------------------------|------------------------------|
| 1. Cassette | 9. DP top cover |
| 2. Paper width guides | 10. DP paper feed roller |
| 3. Paper length guide | 11. DP forwarding roller |
| 4. MP (multi purpose) tray | 12. DP separation pully |
| 5. MP tray extension | 13. DP original width guides |
| 6. MP Paper width guides | 14. Original table |
| 7. Inner tray | 15. USB memory slot |
| 8. Operation panel | |




Figure 1-1-2

- | | | |
|-------------------------------|------------------------|-----------------------|
| 16. Front cover | 24. Fuser unit | 32. Drum unit /K |
| 17. Duct cover | 25. Toner container /Y | 33. Developer unit /Y |
| 18. Waste toner box | 26. Toner container /C | 34. Developer unit /C |
| 19. Right cover 1 | 27. Toner container /M | 35. Developer unit /M |
| 20. MP paper feed roller | 28. Toner container /K | 36. Developer unit /K |
| 21. Right registration roller | 29. Drum unit /Y | 37. Duct holder |
| 22. Secondary transfer roller | 30. Drum unit /C | |
| 23. Feed shift guide | 31. Drum unit /M | |

(2) Machine (rear side)




Figure 1-1-3

- | | |
|------------------------------------|---------------------------------|
| 38. Main power switch | 45. Inlet connector |
| 39. Scanner lock lever | 46. Option interface slot 1 |
| 40. DP interface connector | 47. Network interface connector |
| 41. Controller box cover | 48. USB port |
| 42. DF interface connector | 49. USB interface connector |
| 43. Cassette heater switch (cover) | 50. Option interface slot 2 |
| 44. Outlet connector | |

(3) Operation panel





Figure 1-1-4

- | | | |
|--------------------------|--------------------------------------|-----------------------------|
| 1. Message display | 11. Enter key | 19. Document box key / LED |
| 2. Interrupt key / LED | 12. Start key / LED | 20. FAX key / LED |
| 3. Numeric keys | 13. Stop key | 21. Job separator LED |
| 4. Logout key / LED | 14. System menu/Counter key / LED | 22. Auto color key / LED |
| 5. Energy saver / LED | 15. Status/Job cancel / LED | 23. Full color key / LED |
| 6. Reset key | 16. Copy key / LED | 24. Black & white key / LED |
| 7. Power key / LED | 17. Favorite key / Application / LED | 25. Processing LED |
| 8. Main power LED | 18. Send key / LED | 26. Memory LED |
| 9. Clear key | | 27. Attention LED |
| 10. Quick No. search key | | |



1-1-3 Machine cross section





Figure 1-1-5

- | | | |
|---|------------------------------|------------------------------------|
| 1. Cassette | 8. Eject section | 16. Developer unit /K |
| 2. Cassette paper feed section | 9. Duplex/conveying section | 17. Drum unit /Y |
| 3. MP tray paper feed section | 10. Image scanner unit (ISU) | 18. Drum unit /C |
| 4. Conveying section | 11. Charger roller unit | 19. Drum unit /M |
| 5. Primary transfer section | 12. Toner container /YCMK | 20. Drum unit /K |
| 6. Secondary transfer section / Separation sections | 13. Developer unit /Y | 21. Laser scanner unit (LSU) /YCMK |
| 7. Fuser unit | 14. Developer unit /C | 22. Document processor (DP) |
| | 15. Developer unit /M | |



1-2-1 Installation environment

1. Temperature: 10 to 32.5°C/50 to 90.5°F
2. Humidity: 15 to 80% RH
3. Power supply: 120 V AC, 12.0 A
220 - 240 V AC, 6.5 A
4. Power supply frequency: 50 Hz $\pm 2\%$ /60 Hz $\pm 2\%$
5. Installation location

Avoid direct sunlight or bright lighting. Ensure that the photoconductor will not be exposed to direct sunlight or other strong light when removing paper jams.

Avoid locations subject to high temperature and high humidity or low temperature and low humidity; an abrupt change in the environmental temperature; and cool or hot, direct air.

Avoid places subject to dust and vibrations.

Choose a surface capable of supporting the weight of the machine.

Place the machine on a level surface (maximum allowance inclination: 1°).

Avoid air-borne substances that may adversely affect the machine or degrade the photoconductor, such as mercury, acidic or alkaline vapors, inorganic gasses, NO_x, SO_x gases and chlorine-based organic solvents.

Select a well-ventilated location.

6. Allow sufficient access for proper operation and maintenance of the machine.





Figure 1-2-1

1-2-2 Unpacking and installation

(1) Installation procedure



Unpacking




Figure 1-2-2

- | | | |
|----------------------------|------------------------------|------------------------------|
| 1. Bottom case | 11. Upper pad R | 21. Power cord |
| 2. Bottom pad R | 12. Upper pad L | 22. Hinge joints |
| 3. Bottom pad L | 13. Toner container /YCM | 23. Quick installation guide |
| 4. Machine cover | 14. Toner container /K | 24. Reinforcement parts |
| 5. Machine | 15. Plastic bag (250 × 650) | 25. Plastic bag |
| 6. Inner case R | 16. CD-ROM *1 | 26. Lower pad |
| 7. Inner case L | 17. Installation guide, etc. | 27. Front pad |
| 8. Spacer A | 18. Plastic bag | 28. Desiccant |
| 9. Plastic bag (540 × 950) | 19. Job separator tray | |
| 10. Outer case | 20. Plastic bag (400 × 600) | |

*1 Excluding 230V AC model

TONER
www.toshiba.com Place the machine on a level surface.

Remove the tapes and spacer

1. Remove four tapes.




Figure 1-2-3

2. Open the DP top cover.
3. Slide two DP original width guides and then remove the pad.
4. Close the DP top cover.




Figure 1-2-4

- 5. Open the DP.
- 6. Remove the protective sheet and paper.




Figure 1-2-5

- 7. Remove the paper.
- 8. Close the DP.




Figure 1-2-6

9. Remove the tape.




Figure 1-2-7

10. Peel off two protective sheets.
11. Remove the spacer.




Figure 1-2-8

Install the job separator tray

1. Gently push the job separator tray into the machine along the guides.

ATTENTION: When installing the Job separator tray, be cautious of the position of a paper guide.





Figure 1-2-9

Release the scanner lock lever

1. Pull the scanner lock lever in the direction of the arrow. This will unlock the scanner mechanism.




Figure 1-2-10

Install the optional paper feeder

1. Install the optional paper feeder as required.




Figure 1-2-11

Load paper

1. Pressing the paper width adjusting tab as shown, move the paper width guides to fit the paper size.




Figure 1-2-12

2. Adjust the paper length guide to fit the paper size.




Figure 1-2-13

3. Align the paper so that it is abut with the right end of the cassette.
4. Insert the cassette size plate.
5. Gently push the cassette back in.




Figure 1-2-14

Install the toner container

1. Open the front cover.
2. Hold the toner container vertically and tap the upper part five times or more. Turn the toner container upside down and tap the upper part five times or more.




Figure 1-2-15

3. Shake the toner container up and down five times or more. Turn the toner container upside down and shake it five times or more.




Figure 1-2-16

4. Shake the toner container approximately five or six times in the horizontal direction to stir toner.




Figure 1-2-17

5. Gently push the toner container into the machine.
Push the container all the way into the machine until it locks in place.




Figure 1-2-18

Switch the cassette heater switch

1. Release the hook and then remove the switch cover.
2. Turn the cassette heater switch on.
Note: When the cassette heater is used, it turns it on.
3. Refit the switch cover.




Figure 1-2-19

Install the other optional devices

1. Install the optional devices (Document finisher, Fax kit, etc.) as required.

Connect the power cord

1. Connect the power cord to the connector on the machine.
2. Insert the power plug into the wall outlet.

Installing toner

1. Turn the main power switch on.
The machine automatically starts to feed toner in the developer unit.
Note: When the main power switch is turned on for the first time, it takes about one minute until entering the state that can be copied.
2. The drive chain is disengaged when toner installation is completed.

Output an own-status report (maintenance item U000)

1. Enter 000 using the numeric keys and press the start key.
2. Select Maintenance and press the start key to output a list of the current settings of the maintenance items.
3. Press the stop key.

Exit maintenance mode

1. Enter "001" using the numeric keys and press the start key.

Print out a user setting list

1. Select [Report Print] to print a user setting list.

Make test copies

1. Place an original and make test copies.

Attaching the language label (Excluding 240V AC)

1. Attach the corresponding language label as required.

Installation is completed.

(2) Setting initial copy modes

Factory settings are as follows:

Maintenance item No.	Contents	Factory setting
U253	Switching between double and single counts	Double count (A3/Ledger)
U260	Selecting the timing for copy counting	Eject
U285	Setting service status page	On
U326	Setting the black line cleaning indication	On/8
U343	Switching between duplex/simplex copy mode	Off

1-2-3 Install the expansion memory (option)

Procedure

1. Turn off the main power switch.
Caution: Do not insert or remove expansion memory while machine power is on.
Doing so may cause damage to the machine and the expansion memory.
2. Release four hooks and then remove the controller box cover.
3. Remove two screws.




Figure 1-2-20

4. Remove the memory slot cover.
5. Insert the expansion memory into the memory socket so that the notches on the memory align with the corresponding protrusions in the slot.
6. Refit the memory slot cover.
7. Refit two screws.
8. Refit the controller box cover.
9. Print a status page to check the memory expansion. (See 1-3-135)
If memory expansion has been properly performed, information on the installed memory is printed with the total memory capacity has been increased. Standard memory capacity is 1024 MB.









Figure 1-2-21

1-2-4 Option composition


		<p>DF-470 (500 sheets) (Document finisher)</p>
		<p>AK-470 (Bridge unit)</p>
		<p>PF-790 (500 sheets x 1) (Paper feeder + Cabinet)</p>
		<p>PF-471 (500 sheets x 2) (Paper feeder)</p>
	<p>IB-50 (Gigabit ethernet board)</p>	
	<p>FAX System(U)</p>	
	<p>UG-33 ThinPrint Activation Kit</p>	
	<p>Card Authentication Kit (B)</p>	

This page is intentionally left blank.

1-3-1 Maintenance mode

The machine is equipped with a maintenance function which can be used to maintain and service the machine.

(1) Executing a maintenance item



(2) Maintenance modes item list

Section	Item No.	Content of maintenance item	Initial setting	
			20ppm	25ppm
General	U000	Outputting an own-status report	-	
	U001	Exiting the maintenance mode	-	
	U002	Setting the factory default data	-	
	U004	Setting the machine number	-	
	U019	Displaying the ROM version	-	
Initialization	U021	Memory initializing	-	
Drive, paper feed and paper conveying system	U030	Checking the operation of the motors	-	
	U031	Checking switches and sensors for paper conveying	-	
	U032	Checking the operation of the clutches	-	
	U033	Checking the operation of the solenoids	-	
	U034	Adjusting the print start timing Leading edge registration Center line	41/41/41 0/0/0/0/0	
	U035	Setting the printing area for folio paper	330/210	
	U037	Checking the operation of the fan motors	-	
	U051	Adjusting the deflection in the paper	0/0/0/0	
	U053	Setting the adjustment of the motor speed	-1/-3/-4/ -4/-3/-3/13 -3/-2/-3/ -3/-1/-1/3 -1/-3/-3/ -3/-2/-2/10	-1/-3/-5/ -5/-3/-3/13 -3/-2/-3/ -3/-1/-1/3 -1/-3/-4/ -4/-2/-2/10
Optical	U063	Adjusting the shading position	0	
	U065	Adjusting the scanner magnification	0/0	
	U066	Adjusting the scanner leading edge registration	0/0	
	U067	Adjusting the scanner center line	0/0	
	U068	Adjusting the scanning position for originals from the DP	0/0	
	U070	Adjusting the DP magnification	0/0	
	U071	Adjusting the DP scanning timing	0/0/0/0	
	U072	Adjusting the DP center line	0/0	
	U074	Adjusting the DP input light luminosity	0	
	U089	Outputting a MIP-PG pattern	-	
	U099	Adjusting original size detection	40/30/20/19 50/50/50/49 (When DP is installed.)	

Section	Item No.	Content of maintenance item	Initial setting	
			20ppm	25ppm
High voltage	U100	Setting the main high voltage	Auto 0/0/0/0 -/-/-/ 145/145/145/145 Mode0 Off	
	U101	Setting the voltage for the primary transfer	40/25 0/4/4/4 -2/2/2/2 24	45/25 0/5/5/5 -3/2/2/2 30
	U106	Setting the voltage for the secondary transfer	66/46/34 70/48/32 68/48/35 72/50/34 51/36/26 54/37/25 43/30/22 45/31/22 40/33/25 59/42/31 62/42/32 66/44/32 48/33/25 51/34/24 43/30/22 45/31/22	83/58/42 88/60/40 85/60/44 90/62/42 64/45/33 68/47/32 43/30/22 45/31/21 40/33/25 59/42/31 78/53/40 83/55/38 60/41/31 64/43/30 43/30/22 45/31/21
	U107	Setting the voltage for the intermediate transfer cleaning	10/9/9 10/9/9 72/45/54 60/42/35 72/45/72 60/42/35	13/9/10 13/9/10 90/45/68 90/68/45 90/45/90 90/68/45
	U108	Setting separation shift bias	16/16 8/10 8/8 8/8 2/0/0/100	20/20 10/12 10/10 8/8 3/0/0/100
	U111	Checking the drum drive time	0/0/0/0	
	U118	Displaying the drum history	-	
	U123	Displaying the transfer belt unit history	-	
	U127	Checking/clearing the transfer count	-	



Section	Item No.	Content of maintenance item	Initial setting	
			20ppm	25ppm
Developer	U135	Checking toner motor operation	-	
	U136	Setting toner near end detection	0/0	
	U139	Displaying the temperature and humidity outside the machine	-	
	U140	Setting developer bias	480/480/450/450 50/50/50/50 380/380/350/350 180/180/150/150 150/150/150/150 180/180/150/150 36/36/36/36 36/36/36/36 36/36/36/36 37/37/37/37 33/33/33/33 33/33/33/33 1500/1500/1500/1500 1150/1150/1150/1150 1150/1150/1150/1150 0/0/0/0 0/0/0/0	
	U147	Setting for toner applying operation	0/60	
	U150	Checking sensors for toner	-	
	U157	Checking the developing drive time	0/0/0/0	
	Fuser	U161	Setting the fuser control temperature	210/240/ 190/95/85/ 110/135/ 140/140/ 115/135/ 240/85/40/ 200/85
U167		Displaying fuser heater temperature	0	
U168		Confirmation/setting the fuser drive time	0/0	
U169		Confirmation/setting the fuser drive time	-	
U199		Displaying fuser heater temperature	-	
Operation panel and support equipment	U201	Initializing the touch panel	-	
	U203	Checking DP operation	-	
	U207	Checking the operation panel keys	-	
	U222	Setting the IC card type	Other	
	U243	Checking the operation of the DP motors	-	
	U244	Checking the DP switches	-	

Section	Item No.	Content of maintenance item	Initial setting	
			20ppm	25ppm
Mode setting	U250	Checking/clearing the maintenance cycle	200000/200000/0	
	U251	Checking/clearing the maintenance counter	0/0/0	
	U252	Setting the destination	-	
	U253	Switching between double and single counts	Double count (A3/Ledger)	
	U260	Selecting the timing for copy counting	Eject	
	U265	Setting OEM purchaser code	-	
	U285	Setting service status page	ON	
	U325	Setting the paper interval	1	
	U326	Setting the black line cleaning indication	ON/8	
	U332	Setting the size conversion factor	1.0	
	U341	Specific paper feed location setting for printing function	Off/Off/Off	
	U343	Switching between duplex/simplex copy mode	Off	
	U345	Setting the value for maintenance due indication	0	
Image processing	U402	Adjusting margins of image printing	3.0/2.5/2.5/5.0	
	U403	Adjusting margins for scanning an original on the contact glass	2.0/2.0/2.0/2.0	
	U404	Adjusting margins for scanning an original from the DP	3.0/2.5/3.0/4.0	
	U407	Adjusting the leading edge registration for memory image printing	0	
	U411	Adjusting the scanner automatically	-	
	U425	Setting the target White Black Gray1 Gray2 Gray3 C M Y R G B Adjust original	93.6/0.9/-0.4 10.6/-0.2/-0.7 76.2/-0.2/1.2 25.2/-0.2/-0.2 51.3/-0.3/0.3 72.6/-32.8/-11.5 48.1/69.9/-6.1 86.2/-18.6/81.7 46.7/54.2/38.6 67.8/-51.3/48.9 38.8/25.3/-22.8 5.0/10.0/190.0	

Section	Item No.	Content of maintenance item	Initial setting	
			20ppm	25ppm
Image processing	U429	Setting the offset for the color balance Text+Photo Photo Text Graphics/Map Copy/Printout	0/0/0/0/0 0/0/0/0/0 0/0/0/0/0 0/0/0/0/0 0/0/0/0/0	
	U432	Setting the center offset for the exposure	0/0/0	
	U464	Setting the ID correction operation	On/On 10/20/10 935/400 895/200 885/200 846/130	
	U467	Setting the color registration adjustment	-	
	U468	Checking the color registration data	-	
	U470	Setting the JPEG compression ratio Copy Send HC-PDF Photo Text System	85/85/85/85 15/25/60/15/25/60 30/40/51/70/90/ 30/40/51/70/90 30/40/51/70/90/ 30/40/51/70/90 90/90	
	U473	Adjusting laser power output	92/92/92/50	
	U486	Setting color/black and white operation mode	Mode2	
	Fax	U600	Initializing all data	-
U601		Initializing permanent data	-	
U603		Setting user data 1	DTMF	
U604		Setting user data 2	2 (120 V) 1 (220-240 V)	
U605		Clearing data	-	
U610		Setting system 1 Setting the number of lines to be ignored when receiving a fax at 100% magnification Setting the number of lines to be ignored when receiving a fax in the auto reduction mode Setting the number of lines to be ignored when receiving a fax (A4R/LetterR) in the auto reduction mode	0 3 0	

Section	Item No.	Content of maintenance item	Initial setting	
			20ppm	25ppm
Fax	U611	Setting system 2		
		Setting the number of adjustment lines for automatic reduction		7
		Setting the number of adjustment lines for automatic reduction when A4 paper is set		22
	U612	Setting the number of adjustment lines for automatic reduction when letter size paper is set		26
		Setting system 3		
	U615	Setting system 6		Ledger
		Setting the remote switching mode		One
	U620	Setting the transmission system 1		
		Setting the auto redialing interval		
	U625	Setting the number of times of auto redialing		
Setting communication control 1				
U630	Setting the communication starting speed		14400bps/V17	
	Setting the reception speed		14400bps	
	Setting the waiting period to prevent echo problems at the sender		300	
	Setting the waiting period to prevent echo problems at the receiver		75	
U631	Setting communication control 2			
	Setting ECM transmission		On	
	Setting ECM reception		On	
U632	Setting the frequency of the CED signal		2100	
	Setting communication control 3			
U633	Setting the DIS signal to 4 bytes		Off	
	Setting the CNG detection times in the fax/telephone auto select mode		2Time	
U634	Setting communication control 4			
	Enabling/disabling V.34 communication		On	
	Setting the number of times of DIS signal reception		On	
	Setting the number of times of DIS signal reception		Once	
U634	Setting the reference for RTN signal output		15%	
	Setting communication control 5		0	

Section	Item No.	Content of maintenance item	Initial setting	
			20ppm	25ppm
Fax	U640	Setting communication time 1		
		Setting the one-shot detection time for remote switching		7
	U641	Setting the continuous detection time for remote switching		80
		Setting communication time 2		
	Setting the T0 time-out time		56	
	Setting the T1 time-out time		36	
	Setting the T2 time-out time		69	
	Setting the Ta time-out time		30	
Setting the Tb1 time-out time		20		
Setting the Tb2 time-out time		80		
Setting the Tc time-out time		60		
Setting the Td time-out time		9 (120 V) 6 (220-240 V)		
U650	Setting modem 1			
	Setting the G3 transmission cable equalizer		0dB	
U651	Setting the G3 reception cable equalizer		0dB	
	Setting the modem detection level		-43dBm	
U651	Setting modem 2			
	Modem output level		-11 (120 V) -11 (220-240 V)	
U660	DTMF output level (main value)		-6 (120 V) -8 (220-240 V)	
	DTMF output level (level difference)		2	
U660	Setting the NCU			
	Setting the connection to PBX/PSTN		PSTN	
U670	Setting PSTN dial tone detection		On	
	Setting busy tone detection		On	
U695	Setting for a PBX		Loop	
	Setting the loop current detection before dialing		On	
U670	Outputting lists		-	
U695	FAX function customize		On/Off	
U699	Setting the software switches		-	

Section	Item No.	Content of maintenance item	Initial setting	
			20ppm	25ppm
Others	U901	Checking copy counts by paper feed locations	0/0/0/0/0	
	U903	Checking/clearing the paper jam counts	-	
	U904	Checking/clearing the call for service counts	-	
	U905	Checking counts by optional devices	0/0/0/0	
	U910	Clearing the print coverage data	-	
	U917	Setting backup data reading/writing	-	
	U927	Clearing the all copy counts and machine life counts (one time only)	-	
	U942	Setting of deflection for feeding from DP	0/0	
	U977	Data capture mode	-	
	U984	Checking the developing unit number	-	
	U985	Displaying the developer history	-	

(3) Contents of the maintenance mode items

Item No.	Description																
U000	<p data-bbox="288 293 703 322">Outputting an own-status report</p> <p data-bbox="288 360 440 389">Description Outputs lists of the current settings of the maintenance items and paper jam and service call occurrences. Outputs the event log. Also sends output data to the USB memory.</p> <p data-bbox="288 465 400 495">Purpose To check the current setting of the maintenance items, or paper jam or service call occurrences. Before initializing or replacing the backup RAM, output a list of the current settings of the maintenance items to reenter the settings after initialization or replacement.</p> <p data-bbox="288 640 384 669">Method</p> <ol data-bbox="304 674 1094 770" style="list-style-type: none"> 1. Press the start key. 2. Select the item to be output using the cursor up/down keys. 3. Select On or Off using the cursor left/right keys or numeric keys. <table border="1" data-bbox="336 786 1401 976"> <thead> <tr> <th data-bbox="336 786 639 831">Display</th> <th data-bbox="639 786 1401 831">Output list</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 831 639 875">Maintenance</td> <td data-bbox="639 831 1401 875">List of the current settings of the maintenance modes</td> </tr> <tr> <td data-bbox="336 875 639 920">Event</td> <td data-bbox="639 875 1401 920">Outputs the event log</td> </tr> <tr> <td data-bbox="336 920 639 965">All</td> <td data-bbox="639 920 1401 965">Outputs the all reports</td> </tr> </tbody> </table> <ol data-bbox="304 987 743 1016" style="list-style-type: none"> 4. Press the start key. A list is output. <p data-bbox="288 1055 727 1084">Method: Send to the USB memory</p> <ol data-bbox="304 1088 1430 1364" style="list-style-type: none"> 1. Press the power key on the operation panel, and after verifying the main power indicator has gone off, switch off the main power switch. 2. Insert USB memory in USB memory slot. 3. Turn the main power switch on. 4. Enter the maintenance item. 5. Press the start key. 6. Select the item to be send. 7. Select [Text] or [HTML]. <table border="1" data-bbox="336 1379 1401 1570"> <thead> <tr> <th data-bbox="336 1379 639 1424">Display</th> <th data-bbox="639 1379 1401 1424">Output list</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1424 639 1469">Print</td> <td data-bbox="639 1424 1401 1469">Outputs the report</td> </tr> <tr> <td data-bbox="336 1469 639 1514">USB (Text)</td> <td data-bbox="639 1469 1401 1514">Sends output data to the USB memory (text type)</td> </tr> <tr> <td data-bbox="336 1514 639 1559">USB (HTML)</td> <td data-bbox="639 1514 1401 1559">Sends output data to the USB memory (HTML type)</td> </tr> </tbody> </table> <ol data-bbox="304 1581 807 1644" style="list-style-type: none"> 8. Press the start key. Output will be sent to the USB memory. <p data-bbox="288 1682 440 1711">Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Output list	Maintenance	List of the current settings of the maintenance modes	Event	Outputs the event log	All	Outputs the all reports	Display	Output list	Print	Outputs the report	USB (Text)	Sends output data to the USB memory (text type)	USB (HTML)	Sends output data to the USB memory (HTML type)
Display	Output list																
Maintenance	List of the current settings of the maintenance modes																
Event	Outputs the event log																
All	Outputs the all reports																
Display	Output list																
Print	Outputs the report																
USB (Text)	Sends output data to the USB memory (text type)																
USB (HTML)	Sends output data to the USB memory (HTML type)																

Item No.	Description																																																																																																																																																																																																	
U000	<div style="border: 1px solid black; padding: 10px;"> <h3 style="margin: 0;">Event Log</h3> <p style="margin: 0;">MFP (2) 04/Sep/2010 08:40</p> <p style="margin: 0;">(1) Firmware version 2KZ_2000.000.000 2010.09.04 (3) [XXXXXXXX] (4) [XXXXXXXX] (5) [XXXXXXXX]</p> <hr/> <div style="display: flex; justify-content: space-between;"> <div style="width: 48%;"> <p>(7) Paper Jam Log</p> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th>#</th> <th>Count.</th> <th>Event Descriptions</th> </tr> </thead> <tbody> <tr><td>16</td><td>1876543</td><td>0501.01.08.01.01</td></tr> <tr><td>15</td><td>166554</td><td>4002.01.08.01.01</td></tr> <tr><td>14</td><td>4988</td><td>0501.01.08.01.01</td></tr> <tr><td>13</td><td>4988</td><td>4002.01.08.01.01</td></tr> <tr><td>12</td><td>4988</td><td>0501.01.08.01.01</td></tr> <tr><td>11</td><td>4988</td><td>4002.01.08.01.01</td></tr> <tr><td>10</td><td>1103</td><td>0501.01.08.01.01</td></tr> <tr><td>9</td><td>1103</td><td>4002.01.08.01.01</td></tr> <tr><td>8</td><td>1103</td><td>0501.01.08.01.01</td></tr> <tr><td>7</td><td>1103</td><td>4002.01.08.01.01</td></tr> <tr><td>6</td><td>1027</td><td>0501.01.08.01.01</td></tr> <tr><td>5</td><td>1027</td><td>4002.01.08.01.01</td></tr> <tr><td>4</td><td>1027</td><td>0501.01.08.01.01</td></tr> <tr><td>3</td><td>1027</td><td>4002.01.08.01.01</td></tr> <tr><td>2</td><td>406</td><td>0501.01.08.01.01</td></tr> <tr><td>1</td><td>36</td><td>4002.01.08.01.01</td></tr> </tbody> </table> </div> <div style="width: 48%;"> <p>(8) Service Call Log</p> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th>#</th> <th>Count.</th> <th>Service Code</th> </tr> </thead> <tbody> <tr><td>8</td><td>1881214</td><td>01.6000</td></tr> <tr><td>7</td><td>178944</td><td>01.2100</td></tr> <tr><td>6</td><td>5296</td><td>01.4000</td></tr> <tr><td>5</td><td>5295</td><td>01.6000</td></tr> <tr><td>4</td><td>2099</td><td>01.2100</td></tr> <tr><td>3</td><td>1054</td><td>01.4000</td></tr> <tr><td>2</td><td>809</td><td>01.6000</td></tr> <tr><td>1</td><td>30</td><td>01.2100</td></tr> </tbody> </table> <p>(9) Maintenance Log</p> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th>#</th> <th>Count.</th> <th>Item</th> </tr> </thead> <tbody> <tr><td>8</td><td>1045571</td><td>01.00</td></tr> <tr><td>7</td><td>104511</td><td>01.00</td></tr> <tr><td>6</td><td>7045</td><td>01.00</td></tr> <tr><td>5</td><td>3454</td><td>01.00</td></tr> <tr><td>4</td><td>3454</td><td>01.01</td></tr> <tr><td>3</td><td>3454</td><td>01.01</td></tr> <tr><td>2</td><td>417</td><td>01.01</td></tr> <tr><td>1</td><td>34</td><td>01.01</td></tr> </tbody> </table> <p>(10) Unknown toner Log</p> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th>#</th> <th>Count.</th> <th>Item</th> </tr> </thead> <tbody> <tr><td>5</td><td>3454</td><td>01.00</td></tr> <tr><td>4</td><td>3454</td><td>01.00</td></tr> <tr><td>3</td><td>3454</td><td>01.00</td></tr> <tr><td>2</td><td>406</td><td>01.00</td></tr> <tr><td>1</td><td>32</td><td>01.00</td></tr> </tbody> </table> </div> </div> <div style="margin: 10px 0;"> <table style="margin-left: auto; margin-right: auto; border: 1px solid black; padding: 5px;"> <tr> <td style="text-align: center; padding: 0 5px;">0501</td> <td style="text-align: center; padding: 0 5px;">.01</td> <td style="text-align: center; padding: 0 5px;">.08</td> <td style="text-align: center; padding: 0 5px;">.01</td> <td style="text-align: center; padding: 0 5px;">.01</td> </tr> <tr> <td style="text-align: center; padding: 0 5px;">(a)</td> <td style="text-align: center; padding: 0 5px;">(b)</td> <td style="text-align: center; padding: 0 5px;">(c)</td> <td style="text-align: center; padding: 0 5px;">(d)</td> <td style="text-align: center; padding: 0 5px;">(e)</td> </tr> </table> </div> <p style="margin: 10px 0;">(11) Counter Log</p> <table style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 33%;">(f) J0100: 0</td> <td style="width: 33%;">J0511: 0</td> <td style="width: 33%;">J4201: 0</td> <td style="width: 33%;">(g) C0030: 1</td> <td style="width: 33%;">C2000: 1</td> <td style="width: 33%;">(h) T00: 1</td> </tr> <tr> <td>J0101: 0</td> <td>J0512: 0</td> <td>J4202: 0</td> <td>C0070: 1</td> <td>C2010: 1</td> <td>T01: 1</td> </tr> <tr> <td>J0104: 0</td> <td>J0513: 0</td> <td>J4203: 0</td> <td>C0100: 1</td> <td>C2600: 1</td> <td></td> </tr> <tr> <td>J0106: 0</td> <td>J0518: 0</td> <td>J4208: 0</td> <td>C0120: 1</td> <td>C3100: 1</td> <td></td> </tr> <tr> <td>J0107: 0</td> <td>J0519: 0</td> <td>J4209: 0</td> <td>C0130: 1</td> <td>C3200: 1</td> <td></td> </tr> <tr> <td>.</td> <td>.</td> <td>.</td> <td>.</td> <td>.</td> <td></td> </tr> </table> <p style="text-align: right; margin-top: 10px;">(6) [XXXXXXXXXXXXXXXXXXXX]</p> </div>	#	Count.	Event Descriptions	16	1876543	0501.01.08.01.01	15	166554	4002.01.08.01.01	14	4988	0501.01.08.01.01	13	4988	4002.01.08.01.01	12	4988	0501.01.08.01.01	11	4988	4002.01.08.01.01	10	1103	0501.01.08.01.01	9	1103	4002.01.08.01.01	8	1103	0501.01.08.01.01	7	1103	4002.01.08.01.01	6	1027	0501.01.08.01.01	5	1027	4002.01.08.01.01	4	1027	0501.01.08.01.01	3	1027	4002.01.08.01.01	2	406	0501.01.08.01.01	1	36	4002.01.08.01.01	#	Count.	Service Code	8	1881214	01.6000	7	178944	01.2100	6	5296	01.4000	5	5295	01.6000	4	2099	01.2100	3	1054	01.4000	2	809	01.6000	1	30	01.2100	#	Count.	Item	8	1045571	01.00	7	104511	01.00	6	7045	01.00	5	3454	01.00	4	3454	01.01	3	3454	01.01	2	417	01.01	1	34	01.01	#	Count.	Item	5	3454	01.00	4	3454	01.00	3	3454	01.00	2	406	01.00	1	32	01.00	0501	.01	.08	.01	.01	(a)	(b)	(c)	(d)	(e)	(f) J0100: 0	J0511: 0	J4201: 0	(g) C0030: 1	C2000: 1	(h) T00: 1	J0101: 0	J0512: 0	J4202: 0	C0070: 1	C2010: 1	T01: 1	J0104: 0	J0513: 0	J4203: 0	C0100: 1	C2600: 1		J0106: 0	J0518: 0	J4208: 0	C0120: 1	C3100: 1		J0107: 0	J0519: 0	J4209: 0	C0130: 1	C3200: 1		
#	Count.	Event Descriptions																																																																																																																																																																																																
16	1876543	0501.01.08.01.01																																																																																																																																																																																																
15	166554	4002.01.08.01.01																																																																																																																																																																																																
14	4988	0501.01.08.01.01																																																																																																																																																																																																
13	4988	4002.01.08.01.01																																																																																																																																																																																																
12	4988	0501.01.08.01.01																																																																																																																																																																																																
11	4988	4002.01.08.01.01																																																																																																																																																																																																
10	1103	0501.01.08.01.01																																																																																																																																																																																																
9	1103	4002.01.08.01.01																																																																																																																																																																																																
8	1103	0501.01.08.01.01																																																																																																																																																																																																
7	1103	4002.01.08.01.01																																																																																																																																																																																																
6	1027	0501.01.08.01.01																																																																																																																																																																																																
5	1027	4002.01.08.01.01																																																																																																																																																																																																
4	1027	0501.01.08.01.01																																																																																																																																																																																																
3	1027	4002.01.08.01.01																																																																																																																																																																																																
2	406	0501.01.08.01.01																																																																																																																																																																																																
1	36	4002.01.08.01.01																																																																																																																																																																																																
#	Count.	Service Code																																																																																																																																																																																																
8	1881214	01.6000																																																																																																																																																																																																
7	178944	01.2100																																																																																																																																																																																																
6	5296	01.4000																																																																																																																																																																																																
5	5295	01.6000																																																																																																																																																																																																
4	2099	01.2100																																																																																																																																																																																																
3	1054	01.4000																																																																																																																																																																																																
2	809	01.6000																																																																																																																																																																																																
1	30	01.2100																																																																																																																																																																																																
#	Count.	Item																																																																																																																																																																																																
8	1045571	01.00																																																																																																																																																																																																
7	104511	01.00																																																																																																																																																																																																
6	7045	01.00																																																																																																																																																																																																
5	3454	01.00																																																																																																																																																																																																
4	3454	01.01																																																																																																																																																																																																
3	3454	01.01																																																																																																																																																																																																
2	417	01.01																																																																																																																																																																																																
1	34	01.01																																																																																																																																																																																																
#	Count.	Item																																																																																																																																																																																																
5	3454	01.00																																																																																																																																																																																																
4	3454	01.00																																																																																																																																																																																																
3	3454	01.00																																																																																																																																																																																																
2	406	01.00																																																																																																																																																																																																
1	32	01.00																																																																																																																																																																																																
0501	.01	.08	.01	.01																																																																																																																																																																																														
(a)	(b)	(c)	(d)	(e)																																																																																																																																																																																														
(f) J0100: 0	J0511: 0	J4201: 0	(g) C0030: 1	C2000: 1	(h) T00: 1																																																																																																																																																																																													
J0101: 0	J0512: 0	J4202: 0	C0070: 1	C2010: 1	T01: 1																																																																																																																																																																																													
J0104: 0	J0513: 0	J4203: 0	C0100: 1	C2600: 1																																																																																																																																																																																														
J0106: 0	J0518: 0	J4208: 0	C0120: 1	C3100: 1																																																																																																																																																																																														
J0107: 0	J0519: 0	J4209: 0	C0130: 1	C3200: 1																																																																																																																																																																																														
.																																																																																																																																																																																														
.																																																																																																																																																																																														
.																																																																																																																																																																																														
.																																																																																																																																																																																														
.																																																																																																																																																																																														

Figure 1-3-1



Item No.	Description				
U000	Detail of event log				
	No.	Items	Description		
	(1)	System version			
	(2)	System date			
	(3)	Engine soft version			
	(4)	Engine boot version			
	(5)	Operation panel mask version			
	(6)	Machine serial number			
	(7)	Paper Jam Log	<p>#</p> <p>Remembers 1 to 16 of occurrence. If the occurrence of the previous paper jam is less than 16, all of the paper jams are logged. When the occurrence exceeds 16, the oldest occurrence is removed.</p>	<p>Count.</p> <p>The total page count at the time of the paper jam.</p>	<p>Event</p> <p>Log code (hexadecimal, 5 categories)</p> <p>(a) Cause of a paper jam (b) Paper source (c) Paper size (d) Paper type (e) Paper eject</p> <p>(a) Cause of paper jam (Hexadecimal)</p> <p>Refer to P.1-4-1 for paper jam location</p> <p>0000: Initial jam 0100: Secondary paper feed request time out 0101: Waiting for process package to be ready 0104: Waiting for conveying package to be ready 0106: Paper feeding request for duplex printing time out 0107: Waiting for fuser package to be ready 0110: Right cover open 0111: Front cover open 0120: Receiving a duplex paper feeding request while paper is empty 0121: Exceeding number of duplex pages circulated 0210: Right lower cover open 0501: No paper feed from cassette 1 0502: No paper feed from cassette 2 0503: No paper feed from cassette 3 0508: No paper feed from duplex section 0509: No paper feed from MP tray 0511: Multiple sheets in cassette 1 0512: Multiple sheets in cassette 2 0513: Multiple sheets in cassette 3 0518: Multiple sheets in duplex section 0519: Multiple sheets in MP tray 1403: PF feed sensor 1 non arrival jam 1413: PF feed sensor 1 stay jam 4002: Registration sensor non arrival jam (cassette 2) 4003: Registration sensor non arrival jam (cassette 3)</p>

Item No.	Description							
U000	<table border="1"> <thead> <tr> <th data-bbox="295 282 375 327">No.</th> <th data-bbox="375 282 574 327">Items</th> <th data-bbox="574 282 1415 327">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="295 327 375 2000">(7) cont.</td> <td data-bbox="375 327 574 2000">Paper Jam Log</td> <td data-bbox="574 327 1415 2000"> 4012: Registration sensor stay jam (cassette 2) 4013: Registration sensor stay jam (cassette 3) 4201: Eject sensor non arrival jam (cassette 1) 4202: Eject sensor non arrival jam (cassette 2) 4203: Eject sensor non arrival jam (cassette 3) 4208: Eject sensor non arrival jam (duplex) 4209: Eject sensor non arrival jam (Mp tray) 4211: Eject sensor stay jam (cassette 1) 4212: Eject sensor stay jam (cassette 2) 4213: Eject sensor stay jam (cassette 3) 4218: Eject sensor stay jam (duplex) 4219: Eject sensor stay jam (MP tray) 4301: Duplex sensor non arrival jam (cassette 1) 4302: Duplex sensor non arrival jam (cassette 2) 4303: Duplex sensor non arrival jam (cassette 3) 4309: Duplex sensor non arrival jam (MP tray) 4311: Duplex sensor stay jam (cassette 1) 4312: Duplex sensor stay jam (cassette 2) 4313: Duplex sensor stay jam (cassette 3) 4319: Duplex sensor stay jam (MP tray) 4901: Bridge conveying sensor 1 non arrival jam (cassette 1) 4902: Bridge conveying sensor 1 non arrival jam (cassette 2) 4903: Bridge conveying sensor 1 non arrival jam (cassette 3) 4908: Bridge conveying sensor 1 non arrival jam (duplex) 4909: Bridge conveying sensor 1 non arrival jam (MP tray) 4911: Bridge conveying sensor 1 stay jam (cassette 1) 4912: Bridge conveying sensor 1 stay jam (cassette 2) 4913: Bridge conveying sensor 1 stay jam (cassette 3) 4918: Bridge conveying sensor 1 stay jam (duplex) 4919: Bridge conveying sensor 1 stay jam (MP tray) 5001: Bridge conveying sensor 3 non arrival jam (cassette 1) 5002: Bridge conveying sensor 3 non arrival jam (cassette 2) 5003: Bridge conveying sensor 3 non arrival jam (cassette 3) 5008: Bridge conveying sensor 3 non arrival jam (duplex) 5009: Bridge conveying sensor 3 non arrival jam (MP tray) 5011: Bridge conveying sensor 3 stay jam (cassette 1) 5012: Bridge conveying sensor 3 stay jam (cassette 2) 5013: Bridge conveying sensor 3 stay jam (cassette 3) 5018: Bridge conveying sensor 3 stay jam (duplex) 5019: Bridge conveying sensor 3 stay jam (MP tray) 6023: Staple cover open 6043: DF top cover open 6103: DF paper conveying sensor non arrival jam 6113: DF paper conveying sensor stay jam 6123: DF paper conveying sensor remaining jam 6413: DF eject paper sensor stay jam 6423: DF eject paper sensor remaining jam 6803: Front adjustment plate operation ON error </td> </tr> </tbody> </table>		No.	Items	Description	(7) cont.	Paper Jam Log	4012: Registration sensor stay jam (cassette 2) 4013: Registration sensor stay jam (cassette 3) 4201: Eject sensor non arrival jam (cassette 1) 4202: Eject sensor non arrival jam (cassette 2) 4203: Eject sensor non arrival jam (cassette 3) 4208: Eject sensor non arrival jam (duplex) 4209: Eject sensor non arrival jam (Mp tray) 4211: Eject sensor stay jam (cassette 1) 4212: Eject sensor stay jam (cassette 2) 4213: Eject sensor stay jam (cassette 3) 4218: Eject sensor stay jam (duplex) 4219: Eject sensor stay jam (MP tray) 4301: Duplex sensor non arrival jam (cassette 1) 4302: Duplex sensor non arrival jam (cassette 2) 4303: Duplex sensor non arrival jam (cassette 3) 4309: Duplex sensor non arrival jam (MP tray) 4311: Duplex sensor stay jam (cassette 1) 4312: Duplex sensor stay jam (cassette 2) 4313: Duplex sensor stay jam (cassette 3) 4319: Duplex sensor stay jam (MP tray) 4901: Bridge conveying sensor 1 non arrival jam (cassette 1) 4902: Bridge conveying sensor 1 non arrival jam (cassette 2) 4903: Bridge conveying sensor 1 non arrival jam (cassette 3) 4908: Bridge conveying sensor 1 non arrival jam (duplex) 4909: Bridge conveying sensor 1 non arrival jam (MP tray) 4911: Bridge conveying sensor 1 stay jam (cassette 1) 4912: Bridge conveying sensor 1 stay jam (cassette 2) 4913: Bridge conveying sensor 1 stay jam (cassette 3) 4918: Bridge conveying sensor 1 stay jam (duplex) 4919: Bridge conveying sensor 1 stay jam (MP tray) 5001: Bridge conveying sensor 3 non arrival jam (cassette 1) 5002: Bridge conveying sensor 3 non arrival jam (cassette 2) 5003: Bridge conveying sensor 3 non arrival jam (cassette 3) 5008: Bridge conveying sensor 3 non arrival jam (duplex) 5009: Bridge conveying sensor 3 non arrival jam (MP tray) 5011: Bridge conveying sensor 3 stay jam (cassette 1) 5012: Bridge conveying sensor 3 stay jam (cassette 2) 5013: Bridge conveying sensor 3 stay jam (cassette 3) 5018: Bridge conveying sensor 3 stay jam (duplex) 5019: Bridge conveying sensor 3 stay jam (MP tray) 6023: Staple cover open 6043: DF top cover open 6103: DF paper conveying sensor non arrival jam 6113: DF paper conveying sensor stay jam 6123: DF paper conveying sensor remaining jam 6413: DF eject paper sensor stay jam 6423: DF eject paper sensor remaining jam 6803: Front adjustment plate operation ON error
No.	Items	Description						
(7) cont.	Paper Jam Log	4012: Registration sensor stay jam (cassette 2) 4013: Registration sensor stay jam (cassette 3) 4201: Eject sensor non arrival jam (cassette 1) 4202: Eject sensor non arrival jam (cassette 2) 4203: Eject sensor non arrival jam (cassette 3) 4208: Eject sensor non arrival jam (duplex) 4209: Eject sensor non arrival jam (Mp tray) 4211: Eject sensor stay jam (cassette 1) 4212: Eject sensor stay jam (cassette 2) 4213: Eject sensor stay jam (cassette 3) 4218: Eject sensor stay jam (duplex) 4219: Eject sensor stay jam (MP tray) 4301: Duplex sensor non arrival jam (cassette 1) 4302: Duplex sensor non arrival jam (cassette 2) 4303: Duplex sensor non arrival jam (cassette 3) 4309: Duplex sensor non arrival jam (MP tray) 4311: Duplex sensor stay jam (cassette 1) 4312: Duplex sensor stay jam (cassette 2) 4313: Duplex sensor stay jam (cassette 3) 4319: Duplex sensor stay jam (MP tray) 4901: Bridge conveying sensor 1 non arrival jam (cassette 1) 4902: Bridge conveying sensor 1 non arrival jam (cassette 2) 4903: Bridge conveying sensor 1 non arrival jam (cassette 3) 4908: Bridge conveying sensor 1 non arrival jam (duplex) 4909: Bridge conveying sensor 1 non arrival jam (MP tray) 4911: Bridge conveying sensor 1 stay jam (cassette 1) 4912: Bridge conveying sensor 1 stay jam (cassette 2) 4913: Bridge conveying sensor 1 stay jam (cassette 3) 4918: Bridge conveying sensor 1 stay jam (duplex) 4919: Bridge conveying sensor 1 stay jam (MP tray) 5001: Bridge conveying sensor 3 non arrival jam (cassette 1) 5002: Bridge conveying sensor 3 non arrival jam (cassette 2) 5003: Bridge conveying sensor 3 non arrival jam (cassette 3) 5008: Bridge conveying sensor 3 non arrival jam (duplex) 5009: Bridge conveying sensor 3 non arrival jam (MP tray) 5011: Bridge conveying sensor 3 stay jam (cassette 1) 5012: Bridge conveying sensor 3 stay jam (cassette 2) 5013: Bridge conveying sensor 3 stay jam (cassette 3) 5018: Bridge conveying sensor 3 stay jam (duplex) 5019: Bridge conveying sensor 3 stay jam (MP tray) 6023: Staple cover open 6043: DF top cover open 6103: DF paper conveying sensor non arrival jam 6113: DF paper conveying sensor stay jam 6123: DF paper conveying sensor remaining jam 6413: DF eject paper sensor stay jam 6423: DF eject paper sensor remaining jam 6803: Front adjustment plate operation ON error						

Item No.	Description				
U000	No.	Items	Description		
	(7) cont.	Paper Jam Log	6813: Front adjustment plate operation OFF error 6903: Rear adjustment plate operation ON error 6913: Rear adjustment plate operation OFF error 7013: Staple operation error 7023: Staple initial operation error 7913: Sequence error 1 (operation prohibited) 7923: Sequence error 2 (initial operation error) 7933: Sequence error 3 (Error in the reception of backup data) 7943: Sequence error 4 (standby) 7953: Sequence error 5 (Error in between copies) 9000: No original feed 9001: DP original conveying jam 9004: DP original swichback jam 9010: DP open 9011: DP top cover open 9110: DP paper feed sensor stay jam 9200: DP registration sensor non arrival jam 9400: DP timing sensor non arrival jam 9410: DP timing sensor stay jam		
	(b) Detail of paper source (Hexadecimal)				
	00: MP tray 01: Cassette 1 02: Cassette 2 (paper feeder 1) 03: Cassette 3 (paper feeder 2) 04 to 09: Reserved				
	(c) Detail of paper size (Hexadecimal)				
<table border="0"> <tbody> <tr> <td data-bbox="574 1276 853 1848"> 00: (Not specified) 01: Monarch 02: Business 03: International DL 04: International C5 05: Executive 06: Letter-R 86: Letter-E 07: Legal 08: A4R 88: A4E 09: B5R 89: B5E 0A: A3 </td> <td data-bbox="853 1276 1133 1848"> 0B: B4 0C: Ledger 0D: A5R 0E: A6 0F: B6 10: Commercial #9 11: Commercial #6 12: ISO B5 13: Custom size 1E: C4 1F: Postcard 20: Reply-paid post- card 21: Oficio II </td> <td data-bbox="1133 1276 1423 1848"> 22: Special 1 23: Special 2 24: A3 wide 25: Ledger wide 26: Full bleed paper (12 x 8) 27: 8K 28: 16K-R A8: 16K-E 32: Statement-R B2: Statement-E 33: Folio 34: Western type 2 35: Western type 4 </td> </tr> </tbody> </table>			00: (Not specified) 01: Monarch 02: Business 03: International DL 04: International C5 05: Executive 06: Letter-R 86: Letter-E 07: Legal 08: A4R 88: A4E 09: B5R 89: B5E 0A: A3	0B: B4 0C: Ledger 0D: A5R 0E: A6 0F: B6 10: Commercial #9 11: Commercial #6 12: ISO B5 13: Custom size 1E: C4 1F: Postcard 20: Reply-paid post- card 21: Oficio II	22: Special 1 23: Special 2 24: A3 wide 25: Ledger wide 26: Full bleed paper (12 x 8) 27: 8K 28: 16K-R A8: 16K-E 32: Statement-R B2: Statement-E 33: Folio 34: Western type 2 35: Western type 4
00: (Not specified) 01: Monarch 02: Business 03: International DL 04: International C5 05: Executive 06: Letter-R 86: Letter-E 07: Legal 08: A4R 88: A4E 09: B5R 89: B5E 0A: A3	0B: B4 0C: Ledger 0D: A5R 0E: A6 0F: B6 10: Commercial #9 11: Commercial #6 12: ISO B5 13: Custom size 1E: C4 1F: Postcard 20: Reply-paid post- card 21: Oficio II	22: Special 1 23: Special 2 24: A3 wide 25: Ledger wide 26: Full bleed paper (12 x 8) 27: 8K 28: 16K-R A8: 16K-E 32: Statement-R B2: Statement-E 33: Folio 34: Western type 2 35: Western type 4			

Item No.	Description				
U000	No.	Items	Description		
	(7) cont.	Paper Jam Log	(d) Detail of paper type (Hexadecimal) 01: Plain 0A: Color 15: Custom 1 02: Transparency 0B: Prepunched 16: Custom 2 03: Preprinted 0C: Envelope 17: Custom 3 04: Labels 0D: Cardstock 18: Custom 4 05: Bond 0E: Coated 19: Custom 5 06: Recycled 0F: 2nd side 1A: Custom 6 07: Vellum 10: Thick 1B: Custom 7 08: Rough 11: High quality 1C: Custom 8 09: Letterhead (e) Detail of paper eject location (Hexadecimal) 01: Face down (FD) 02: Face up (FU)/Document finisher face up (FU)/ 03: Document finisher face down (FD)		
	(8)	Service Call Log	#	Count.	Service Code
			Remembers 1 to 8 of occurrence of self diagnostics error. If the occurrence of the previous diagnostics error is less than 8, all of the diagnostics errors are logged.	The total page count at the time of the self diagnostics error.	Self diagnostic error code (See page 1-4-9) Example: 01.6000 01: Self diagnostic error 6000: Self diagnostic error code number
	(9)	Maintenance Log	#	Count.	Item
			Remembers 1 to 8 of occurrence of replacement. If the occurrence of the previous replacement of toner container is less than 8, all of the occurrences of replacement are logged.	The total page count at the time of the replacement of the toner container.	Code of maintenance replacing item (1 byte, 2 categories) First byte (Replacing item) 01: Toner container Second byte (Type of replacing item) 00: Black First byte (Replacing item) 02: Maintenance kit Second byte (Type of replacing item) 01: MK-896A 02: MK-896B

Item No.	Description				
U000	No.	Items	Description		
	(10)	Unknown Toner Log	#	Count.	Item
			Remembers 1 to 5 of occurrence of unknown toner detection. If the occurrence of the previous unknown toner detection is less than 5, all of the unknown toner detection are logged.	The total page count at the time of the toner empty error with using an unknown toner container.	Unknown toner log code (1 byte, 2 categories) First byte 01: Toner container (Fixed) Second byte 00: Black
	(11)	Counter Log Comprised of three log counters including paper jams, self diagnostics errors, and replacement of the toner container.	(f) Paper jam Indicates the log counter of paper jams depending on location. Refer to Paper Jam Log. All instances including those are not occurred are displayed.	(g) Self diagnostic error Indicates the log counter of self diagnostics errors depending on cause. (See page 1-3-12) Example: C6000: 4 Self diagnostics error 6000 has happened four times.	(h) Maintenance item replacing Indicates the log counter depending on the maintenance item for maintenance. T: Toner container 00: Black M: Maintenance kit 01: MK-477/475/479 Example: T00: 1 The toner container has been replaced once.

Item No.	Description										
U001	<p>Exiting the maintenance mode</p> <p>Description Exits the maintenance mode and returns to the normal copy mode.</p> <p>Purpose To exit the maintenance mode.</p> <p>Method Press the start key. The normal copy mode is entered.</p>										
U002	<p>Setting the factory default data</p> <p>Description Restores the machine conditions to the factory default settings.</p> <p>Purpose To move the mirror frame of the scanner to the position for transport</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select [Mode1(All)]. 3. Press the start key. The mirror frame of the scanner returns to the position for transport. 4. Turn the main power switch off and on. <p>* : An error code is displayed in case of an initialization error. When errors occurred, turn main power switch off then on, and execute initialization using maintenance item U002.</p> <p>Error codes</p> <table border="1" data-bbox="336 1205 1399 1444"> <thead> <tr> <th data-bbox="336 1205 641 1254">Codes</th> <th data-bbox="641 1205 1399 1254">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1254 641 1303">0001</td> <td data-bbox="641 1254 1399 1303">Entity error</td> </tr> <tr> <td data-bbox="336 1303 641 1352">0002</td> <td data-bbox="641 1303 1399 1352">Controller error</td> </tr> <tr> <td data-bbox="336 1352 641 1402">0020</td> <td data-bbox="641 1352 1399 1402">Engine error</td> </tr> <tr> <td data-bbox="336 1402 641 1444">0040</td> <td data-bbox="641 1402 1399 1444">Scanner error</td> </tr> </tbody> </table>	Codes	Description	0001	Entity error	0002	Controller error	0020	Engine error	0040	Scanner error
Codes	Description										
0001	Entity error										
0002	Controller error										
0020	Engine error										
0040	Scanner error										

Item No.	Description										
U004	<p data-bbox="290 241 654 273">Setting the machine number</p> <p data-bbox="290 309 438 340">Description Sets or displays the machine number.</p> <p data-bbox="290 376 399 407">Purpose To check or set the machine number.</p> <p data-bbox="290 483 386 515">Method</p> <p data-bbox="306 519 566 551">1. Press the start key.</p> <p data-bbox="335 555 1241 586">If the machine serial number of engine PWB matches with that of main PWB</p> <table border="1" data-bbox="338 595 1401 689"> <thead> <tr> <th data-bbox="338 595 641 640">Display</th> <th data-bbox="641 595 1401 640">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="338 640 641 689">Machine No.</td> <td data-bbox="641 640 1401 689">Displays the machine serial number</td> </tr> </tbody> </table> <p data-bbox="335 703 1324 734">If the machine serial number of engine PWB does not match with that of main PWB</p> <table border="1" data-bbox="338 743 1401 891"> <thead> <tr> <th data-bbox="338 743 641 788">Display</th> <th data-bbox="641 743 1401 788">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="338 788 641 833">Machine No.(Main)</td> <td data-bbox="641 788 1401 833">Displays the machine serial number of main</td> </tr> <tr> <td data-bbox="338 833 641 891">Machine No.(Eng)</td> <td data-bbox="641 833 1401 891">Displays the machine serial number of engine</td> </tr> </tbody> </table> <p data-bbox="290 936 383 967">Setting Carry out if the machine serial number does not match.</p> <p data-bbox="306 1003 885 1106">1. Select [Execute]. 2. Press the start key. Writing of serial No. starts. 3. Turn the main power switch off and on.</p> <p data-bbox="290 1142 438 1173">Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Machine No.	Displays the machine serial number	Display	Description	Machine No.(Main)	Displays the machine serial number of main	Machine No.(Eng)	Displays the machine serial number of engine
Display	Description										
Machine No.	Displays the machine serial number										
Display	Description										
Machine No.(Main)	Displays the machine serial number of main										
Machine No.(Eng)	Displays the machine serial number of engine										

Item No.	Description																																																								
U019	<p data-bbox="287 241 651 275">Displaying the ROM version</p> <p data-bbox="287 309 440 342">Description</p> <p data-bbox="287 344 970 378">Displays the part number of the ROM fitted to each PWB.</p> <p data-bbox="287 380 400 414">Purpose</p> <p data-bbox="287 416 1238 450">To check the part number or to decide, if the newest version of ROM is installed.</p> <p data-bbox="287 483 387 517">Method</p> <ol data-bbox="304 519 957 589" style="list-style-type: none"> 1. Press the start key. The ROM version are displayed. 2. Change the screen using the cursor up/down keys. <table border="1" data-bbox="336 595 1399 1939"> <thead> <tr> <th data-bbox="336 595 641 640">Display</th> <th data-bbox="641 595 1399 640">Description</th> </tr> </thead> <tbody> <tr><td>Main</td><td>Main ROM</td></tr> <tr><td>MMI</td><td>Operation ROM</td></tr> <tr><td>Engine</td><td>Engine ROM</td></tr> <tr><td>Engine Boot</td><td>Engine booting</td></tr> <tr><td>RFID</td><td>RFID ROM</td></tr> <tr><td>IH CPU</td><td>IH CPU ROM</td></tr> <tr><td>IH CPU Boot</td><td>IH CPU booting</td></tr> <tr><td>IO CPU</td><td>IO CPU ROM</td></tr> <tr><td>IO CPU Boot</td><td>IO CPU booting</td></tr> <tr><td>LSU CPU</td><td>LSU CPU ROM</td></tr> <tr><td>LSU CPU Boot</td><td>LSU CPU booting</td></tr> <tr><td>Browser</td><td>Browser ROM</td></tr> <tr><td>Option Language</td><td>Optional language ROM</td></tr> <tr><td>Dictionary</td><td>Kanji dictionary ROM</td></tr> <tr><td>Color Table1</td><td>Color Table1 ROM</td></tr> <tr><td>Color Table2</td><td>Color Table2 ROM</td></tr> <tr><td>DP</td><td>Document processor ROM</td></tr> <tr><td>DP Boot</td><td>Document processor booting</td></tr> <tr><td>PF</td><td>Paper feeder ROM</td></tr> <tr><td>PF Boot</td><td>Paper feeder booting</td></tr> <tr><td>DF</td><td>Document finisher ROM</td></tr> <tr><td>DF Boot</td><td>Document finisher booting</td></tr> <tr><td>AK</td><td>Bridge ROM</td></tr> <tr><td>AK Boot</td><td>Bridge booting</td></tr> <tr><td>Fax APL</td><td>Fax control PWB APL</td></tr> <tr><td>Fax Boot</td><td>Fax control PWB booting</td></tr> <tr><td>Fax IPL</td><td>Fax control PWB IPL</td></tr> </tbody> </table> <p data-bbox="287 1973 440 2007">Completion</p> <p data-bbox="287 2009 1254 2042">Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Main	Main ROM	MMI	Operation ROM	Engine	Engine ROM	Engine Boot	Engine booting	RFID	RFID ROM	IH CPU	IH CPU ROM	IH CPU Boot	IH CPU booting	IO CPU	IO CPU ROM	IO CPU Boot	IO CPU booting	LSU CPU	LSU CPU ROM	LSU CPU Boot	LSU CPU booting	Browser	Browser ROM	Option Language	Optional language ROM	Dictionary	Kanji dictionary ROM	Color Table1	Color Table1 ROM	Color Table2	Color Table2 ROM	DP	Document processor ROM	DP Boot	Document processor booting	PF	Paper feeder ROM	PF Boot	Paper feeder booting	DF	Document finisher ROM	DF Boot	Document finisher booting	AK	Bridge ROM	AK Boot	Bridge booting	Fax APL	Fax control PWB APL	Fax Boot	Fax control PWB booting	Fax IPL	Fax control PWB IPL
Display	Description																																																								
Main	Main ROM																																																								
MMI	Operation ROM																																																								
Engine	Engine ROM																																																								
Engine Boot	Engine booting																																																								
RFID	RFID ROM																																																								
IH CPU	IH CPU ROM																																																								
IH CPU Boot	IH CPU booting																																																								
IO CPU	IO CPU ROM																																																								
IO CPU Boot	IO CPU booting																																																								
LSU CPU	LSU CPU ROM																																																								
LSU CPU Boot	LSU CPU booting																																																								
Browser	Browser ROM																																																								
Option Language	Optional language ROM																																																								
Dictionary	Kanji dictionary ROM																																																								
Color Table1	Color Table1 ROM																																																								
Color Table2	Color Table2 ROM																																																								
DP	Document processor ROM																																																								
DP Boot	Document processor booting																																																								
PF	Paper feeder ROM																																																								
PF Boot	Paper feeder booting																																																								
DF	Document finisher ROM																																																								
DF Boot	Document finisher booting																																																								
AK	Bridge ROM																																																								
AK Boot	Bridge booting																																																								
Fax APL	Fax control PWB APL																																																								
Fax Boot	Fax control PWB booting																																																								
Fax IPL	Fax control PWB IPL																																																								

Item No.	Description										
U021	<p data-bbox="290 241 533 275">Memory initializing</p> <p data-bbox="290 311 440 340">Description</p> <p data-bbox="290 347 1422 445">Initializes all settings, except those pertinent to the type of machine, namely each counter, service call history and mode setting. Also initializes backup RAM according to region specification selected in maintenance item U252 Setting the destination.</p> <p data-bbox="290 452 400 481">Purpose</p> <p data-bbox="290 488 922 517">To return the machine settings to their factory default.</p> <p data-bbox="290 553 387 582">Method</p> <ol data-bbox="308 589 1342 757" style="list-style-type: none"> 1. Press the start key. 2. Select [Execute]. 3. Press the start key. All data other than that for adjustments due to variations between machines is initialized based on the destination setting. 4. Turn the main power switch off and on. <p data-bbox="339 763 1059 792">* : An error code is displayed in case of an initialization error.</p> <p data-bbox="371 799 1426 860">When errors occurred, turn main power switch off then on, and execute initialization using maintenance item U021.</p> <p data-bbox="336 898 488 927">Error codes</p> <table border="1" data-bbox="336 943 1399 1182"> <thead> <tr> <th data-bbox="336 943 641 987">Codes</th> <th data-bbox="641 943 1399 987">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 987 641 1032">0001</td> <td data-bbox="641 987 1399 1032">Entity error</td> </tr> <tr> <td data-bbox="336 1032 641 1077">0002</td> <td data-bbox="641 1032 1399 1077">Controller error</td> </tr> <tr> <td data-bbox="336 1077 641 1122">0020</td> <td data-bbox="641 1077 1399 1122">Engine error</td> </tr> <tr> <td data-bbox="336 1122 641 1182">0040</td> <td data-bbox="641 1122 1399 1182">Scanner error</td> </tr> </tbody> </table>	Codes	Description	0001	Entity error	0002	Controller error	0020	Engine error	0040	Scanner error
Codes	Description										
0001	Entity error										
0002	Controller error										
0020	Engine error										
0040	Scanner error										




Item No.	Description																				
U030	<p data-bbox="287 241 766 275">Checking the operation of the motors</p> <p data-bbox="287 309 438 342">Description Drives each motor.</p> <p data-bbox="287 376 399 409">Purpose To check the operation of each motor.</p> <p data-bbox="287 488 391 521">Method</p> <ol data-bbox="303 521 813 622" style="list-style-type: none"> 1. Press the start key. 2. Select the motor to be operated. 3. Press the start key. The operation starts. <table border="1" data-bbox="335 633 1401 1137"> <thead> <tr> <th data-bbox="343 633 641 678">Display</th> <th data-bbox="641 633 1401 678">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="343 678 641 723">Feed</td> <td data-bbox="641 678 1401 723">Conveying motor (CM) is turned on</td> </tr> <tr> <td data-bbox="343 723 641 768">Exit(CW)</td> <td data-bbox="641 723 1401 768">Eject motor (EM) is turned on clockwise</td> </tr> <tr> <td data-bbox="343 768 641 813">Exit(CCW)</td> <td data-bbox="641 768 1401 813">Eject motor (EM) is turned on counterclockwise</td> </tr> <tr> <td data-bbox="343 813 641 857">Drum K</td> <td data-bbox="641 813 1401 857">Drum motor K (DRM-K) is turned on</td> </tr> <tr> <td data-bbox="343 857 641 902">Drum COL</td> <td data-bbox="641 857 1401 902">Drum motor YCM (DRM-YCM) is turned on</td> </tr> <tr> <td data-bbox="343 902 641 947">DLP K(CW)</td> <td data-bbox="641 902 1401 947">Developer motor K (DRM-K) is turned on clockwise</td> </tr> <tr> <td data-bbox="343 947 641 992">DLP K(CCW)</td> <td data-bbox="641 947 1401 992">Developer motor K (DRM-K) is turned on counterclockwise</td> </tr> <tr> <td data-bbox="343 992 641 1037">DLP COL(CW)</td> <td data-bbox="641 992 1401 1037">Developer motor YCM (DRM-YCM) is turned on clockwise</td> </tr> <tr> <td data-bbox="343 1037 641 1081">DLP COL(CCW)</td> <td data-bbox="641 1037 1401 1081">Developer motor YCM (DRM-YCM) is turned on counterclockwise</td> </tr> </tbody> </table> <ol data-bbox="303 1160 782 1193" style="list-style-type: none"> 4. To stop operation, press the stop key. <p data-bbox="287 1227 438 1261">Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Feed	Conveying motor (CM) is turned on	Exit(CW)	Eject motor (EM) is turned on clockwise	Exit(CCW)	Eject motor (EM) is turned on counterclockwise	Drum K	Drum motor K (DRM-K) is turned on	Drum COL	Drum motor YCM (DRM-YCM) is turned on	DLP K(CW)	Developer motor K (DRM-K) is turned on clockwise	DLP K(CCW)	Developer motor K (DRM-K) is turned on counterclockwise	DLP COL(CW)	Developer motor YCM (DRM-YCM) is turned on clockwise	DLP COL(CCW)	Developer motor YCM (DRM-YCM) is turned on counterclockwise
Display	Description																				
Feed	Conveying motor (CM) is turned on																				
Exit(CW)	Eject motor (EM) is turned on clockwise																				
Exit(CCW)	Eject motor (EM) is turned on counterclockwise																				
Drum K	Drum motor K (DRM-K) is turned on																				
Drum COL	Drum motor YCM (DRM-YCM) is turned on																				
DLP K(CW)	Developer motor K (DRM-K) is turned on clockwise																				
DLP K(CCW)	Developer motor K (DRM-K) is turned on counterclockwise																				
DLP COL(CW)	Developer motor YCM (DRM-YCM) is turned on clockwise																				
DLP COL(CCW)	Developer motor YCM (DRM-YCM) is turned on counterclockwise																				

Item No.	Description																				
U031	<p data-bbox="290 241 960 275">Checking switches and sensors for paper conveying</p> <p data-bbox="290 311 440 340">Description</p> <p data-bbox="290 344 1302 376">Displays the on-off status of each paper detection switch or sensor on the paper path.</p> <p data-bbox="290 380 400 409">Purpose</p> <p data-bbox="290 414 1177 445">To check if the switches and sensors for paper conveying operate correctly.</p> <p data-bbox="290 483 387 512">Method</p> <ol data-bbox="306 517 1134 584" style="list-style-type: none"> 1. Press the start key. 2. Turn each switch or sensor on and off manually to check the status. <p data-bbox="333 589 1401 651">When a switch or sensor is detected to be in the ON position, the display for that switch or sensor will be "1".</p> <table border="1" data-bbox="336 667 1399 1146"> <thead> <tr> <th data-bbox="336 667 639 712">Display</th> <th data-bbox="639 667 1399 712">Switches and sensors</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 712 639 757">Switch 00000000</td> <td data-bbox="639 712 1399 757"></td> </tr> <tr> <td data-bbox="336 757 639 801"> 1st digit</td> <td data-bbox="639 757 1399 801">Euser pre sensor (FUPS)</td> </tr> <tr> <td data-bbox="336 801 639 846"> 2nd digit</td> <td data-bbox="639 801 1399 846">Bridge detection switch (BRDSW)</td> </tr> <tr> <td data-bbox="336 846 639 891"> 3rd digit</td> <td data-bbox="639 846 1399 891">Job paper full sensor (JPFS)</td> </tr> <tr> <td data-bbox="336 891 639 936"> 4th digit</td> <td data-bbox="639 891 1399 936">Paper full sensor (PFS)</td> </tr> <tr> <td data-bbox="336 936 639 981"> 5th digit</td> <td data-bbox="639 936 1399 981">Feed sensor (FS)</td> </tr> <tr> <td data-bbox="336 981 639 1025"> 6th digit</td> <td data-bbox="639 981 1399 1025">Duplex sensor (DUS)</td> </tr> <tr> <td data-bbox="336 1025 639 1070"> 7th digit</td> <td data-bbox="639 1025 1399 1070">Eject sensor (ES)</td> </tr> <tr> <td data-bbox="336 1070 639 1115"> 8th digit</td> <td data-bbox="639 1070 1399 1115">Registration sensor (RS)</td> </tr> </tbody> </table> <p data-bbox="290 1193 440 1223">Completion</p> <p data-bbox="290 1227 1254 1258">Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Switches and sensors	Switch 00000000		1st digit	Euser pre sensor (FUPS)	2nd digit	Bridge detection switch (BRDSW)	3rd digit	Job paper full sensor (JPFS)	4th digit	Paper full sensor (PFS)	5th digit	Feed sensor (FS)	6th digit	Duplex sensor (DUS)	7th digit	Eject sensor (ES)	8th digit	Registration sensor (RS)
Display	Switches and sensors																				
Switch 00000000																					
1st digit	Euser pre sensor (FUPS)																				
2nd digit	Bridge detection switch (BRDSW)																				
3rd digit	Job paper full sensor (JPFS)																				
4th digit	Paper full sensor (PFS)																				
5th digit	Feed sensor (FS)																				
6th digit	Duplex sensor (DUS)																				
7th digit	Eject sensor (ES)																				
8th digit	Registration sensor (RS)																				


Item No.	Description														
U032	<p>Checking the operation of the clutches</p> <p>Description Turns each clutch on.</p> <p>Purpose To check the operation of each clutch.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select the clutch to be operated. 3. Press the start key. The operation starts. <table border="1" data-bbox="336 631 1401 967"> <thead> <tr> <th data-bbox="336 631 641 676">Display</th> <th data-bbox="641 631 1401 676">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 676 641 721">Main</td> <td data-bbox="641 676 1401 721">Main motor (MM) is turned on</td> </tr> <tr> <td data-bbox="336 721 641 766">Feed</td> <td data-bbox="641 721 1401 766">Paper feed clutch (PFCL) is turned on</td> </tr> <tr> <td data-bbox="336 766 641 810">Regist</td> <td data-bbox="641 766 1401 810">Registration clutch (RCL) is turned on</td> </tr> <tr> <td data-bbox="336 810 641 855">Duplex</td> <td data-bbox="641 810 1401 855">Duplex clutch (DUCL) is turned on</td> </tr> <tr> <td data-bbox="336 855 641 900">Middle</td> <td data-bbox="641 855 1401 900">Middle clutch (MCL) is turned on</td> </tr> <tr> <td data-bbox="336 900 641 967">DLP</td> <td data-bbox="641 900 1401 967">Developer stop clutch (DEVSCCL) is turned on</td> </tr> </tbody> </table> <ol style="list-style-type: none"> 4. Press the stop key. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Main	Main motor (MM) is turned on	Feed	Paper feed clutch (PFCL) is turned on	Regist	Registration clutch (RCL) is turned on	Duplex	Duplex clutch (DUCL) is turned on	Middle	Middle clutch (MCL) is turned on	DLP	Developer stop clutch (DEVSCCL) is turned on
Display	Description														
Main	Main motor (MM) is turned on														
Feed	Paper feed clutch (PFCL) is turned on														
Regist	Registration clutch (RCL) is turned on														
Duplex	Duplex clutch (DUCL) is turned on														
Middle	Middle clutch (MCL) is turned on														
DLP	Developer stop clutch (DEVSCCL) is turned on														
U033	<p>Checking the operation of the solenoids</p> <p>Description Turns each solenoid on.</p> <p>Purpose To check the operation of each solenoid.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select the solenoid to be operated. 3. Press the start key. The operation starts. <table border="1" data-bbox="336 1552 1401 1697"> <thead> <tr> <th data-bbox="336 1552 641 1597">Display</th> <th data-bbox="641 1552 1401 1597">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1597 641 1641">MPT</td> <td data-bbox="641 1597 1401 1641">MP solenoid (MPSOL) is turned on</td> </tr> <tr> <td data-bbox="336 1641 641 1697">Eject</td> <td data-bbox="641 1641 1401 1697">Feedshift solenoid (FSSOL) is turned on</td> </tr> </tbody> </table> <ol style="list-style-type: none"> 4. Press the stop key. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	MPT	MP solenoid (MPSOL) is turned on	Eject	Feedshift solenoid (FSSOL) is turned on								
Display	Description														
MPT	MP solenoid (MPSOL) is turned on														
Eject	Feedshift solenoid (FSSOL) is turned on														

Item No.	Description																										
U034	<p data-bbox="288 241 683 275">Adjusting the print start timing</p> <p data-bbox="288 309 440 342">Description Adjusts the leading edge registration or center line.</p> <p data-bbox="288 376 400 409">Purpose Make the adjustment if there is a regular error between the leading edges of the copy image and original. Make the adjustment if there is a regular error between the center lines of the copy image and original.</p> <p data-bbox="288 589 387 622">Method</p> <ol data-bbox="304 622 699 689" style="list-style-type: none"> 1. Press the start key. 2. Select the item to be adjusted. <table border="1" data-bbox="336 701 1401 846"> <thead> <tr> <th data-bbox="336 701 639 745">Display</th> <th data-bbox="639 701 1401 745">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 745 639 790">LSU Out Top</td> <td data-bbox="639 745 1401 790">Leading edge registration adjustment</td> </tr> <tr> <td data-bbox="336 790 639 846">LSU Out Left</td> <td data-bbox="639 790 1401 846">Center line adjustment</td> </tr> </tbody> </table> <p data-bbox="288 891 935 925">Adjustment: Leading edge registration adjustment</p> <ol data-bbox="304 925 839 1059" style="list-style-type: none"> 1. Press the system menu key. 2. Press the start key to output a test pattern. 3. Press the system menu key. 4. Select the item to be adjusted. <table border="1" data-bbox="336 1070 1401 1406"> <thead> <tr> <th data-bbox="336 1070 528 1149">Display</th> <th data-bbox="528 1070 922 1149">Description</th> <th data-bbox="922 1070 1082 1149">Setting range</th> <th data-bbox="1082 1070 1193 1149">Initial setting</th> <th data-bbox="1193 1070 1401 1149">Change in value per step</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1149 528 1238">MPT(L)</td> <td data-bbox="528 1149 922 1238">Paper feed from MP tray (when large size paper is used)</td> <td data-bbox="922 1149 1082 1238">-128 to 127</td> <td data-bbox="1082 1149 1193 1238">41</td> <td data-bbox="1193 1149 1401 1238">0.1 mm</td> </tr> <tr> <td data-bbox="336 1238 528 1328">Cassette(L)</td> <td data-bbox="528 1238 922 1328">Paper feed from cassette (when large size paper is used)</td> <td data-bbox="922 1238 1082 1328">-128 to 127</td> <td data-bbox="1082 1238 1193 1328">41</td> <td data-bbox="1193 1238 1401 1328">0.1 mm</td> </tr> <tr> <td data-bbox="336 1328 528 1406">Duplex(L)</td> <td data-bbox="528 1328 922 1406">Duplex mode (second) (when large size paper is used)</td> <td data-bbox="922 1328 1082 1406">-128 to 127</td> <td data-bbox="1082 1328 1193 1406">41</td> <td data-bbox="1193 1328 1401 1406">0.1 mm</td> </tr> </tbody> </table> <p data-bbox="336 1440 882 1473">Large size: 218 mm or more in width of paper.</p>	Display	Description	LSU Out Top	Leading edge registration adjustment	LSU Out Left	Center line adjustment	Display	Description	Setting range	Initial setting	Change in value per step	MPT(L)	Paper feed from MP tray (when large size paper is used)	-128 to 127	41	0.1 mm	Cassette(L)	Paper feed from cassette (when large size paper is used)	-128 to 127	41	0.1 mm	Duplex(L)	Duplex mode (second) (when large size paper is used)	-128 to 127	41	0.1 mm
Display	Description																										
LSU Out Top	Leading edge registration adjustment																										
LSU Out Left	Center line adjustment																										
Display	Description	Setting range	Initial setting	Change in value per step																							
MPT(L)	Paper feed from MP tray (when large size paper is used)	-128 to 127	41	0.1 mm																							
Cassette(L)	Paper feed from cassette (when large size paper is used)	-128 to 127	41	0.1 mm																							
Duplex(L)	Duplex mode (second) (when large size paper is used)	-128 to 127	41	0.1 mm																							

Item No.	Description																														
U034	<p data-bbox="304 241 1340 309">5. Change the setting value using the cursor left/right keys or numeric keys. For output example 1, increase the value. For output example 2, decrease the value.</p> <div data-bbox="367 324 1189 660" style="text-align: center;"> <p data-bbox="367 347 526 436">Leading edge registration (20 ± 1.5 mm)</p> <p data-bbox="550 593 710 627">Correct image</p> <p data-bbox="813 593 933 660">Output example 1</p> <p data-bbox="1045 593 1165 660">Output example 2</p> </div> <p data-bbox="782 683 941 716">Figure 1-3-2</p> <p data-bbox="304 750 766 784">6. Press the start key. The value is set.</p> <p data-bbox="287 851 391 884">Remark</p> <p data-bbox="287 891 1109 925">Changing the larger sizes settings affects those for the smaller sizes.</p> <p data-bbox="287 958 391 992">Caution</p> <p data-bbox="287 996 1404 1064">Check the copy image after the adjustment. If the image is still incorrect, perform the following adjustments in maintenance mode.</p> <div data-bbox="295 1075 901 1176" style="text-align: center;"> <pre> graph LR U034[U034] --> U066["U066 (P.1-3-33)"] U066 --> U071["U071 (P.1-3-38)"] </pre> </div> <p data-bbox="287 1220 750 1254">Adjustment: Center line adjustment</p> <ol data-bbox="304 1258 845 1388" style="list-style-type: none"> 1. Press the system menu key. 2. Press the start key to output a test pattern. 3. Press the system menu key. 4. Select the item to be adjusted. <table border="1" data-bbox="335 1400 1396 1792"> <thead> <tr> <th>Display</th> <th>Description</th> <th>Setting range</th> <th>Initial setting</th> <th>Change in value per step</th> </tr> </thead> <tbody> <tr> <td>MPT</td> <td>Paper feed from MP tray</td> <td>-128 to 127</td> <td>0</td> <td>0.1 mm</td> </tr> <tr> <td>Cassette1</td> <td>Paper feed from cassette 1</td> <td>-128 to 127</td> <td>0</td> <td>0.1 mm</td> </tr> <tr> <td>Cassette2</td> <td>Paper feed from optional cassette 2</td> <td>-128 to 127</td> <td>0</td> <td>0.1 mm</td> </tr> <tr> <td>Cassette3</td> <td>Paper feed from optional cassette 3</td> <td>-128 to 127</td> <td>0</td> <td>0.1 mm</td> </tr> <tr> <td>Duplex</td> <td>Duplex mode (second)</td> <td>-128 to 127</td> <td>0</td> <td>0.1 mm</td> </tr> </tbody> </table>	Display	Description	Setting range	Initial setting	Change in value per step	MPT	Paper feed from MP tray	-128 to 127	0	0.1 mm	Cassette1	Paper feed from cassette 1	-128 to 127	0	0.1 mm	Cassette2	Paper feed from optional cassette 2	-128 to 127	0	0.1 mm	Cassette3	Paper feed from optional cassette 3	-128 to 127	0	0.1 mm	Duplex	Duplex mode (second)	-128 to 127	0	0.1 mm
Display	Description	Setting range	Initial setting	Change in value per step																											
MPT	Paper feed from MP tray	-128 to 127	0	0.1 mm																											
Cassette1	Paper feed from cassette 1	-128 to 127	0	0.1 mm																											
Cassette2	Paper feed from optional cassette 2	-128 to 127	0	0.1 mm																											
Cassette3	Paper feed from optional cassette 3	-128 to 127	0	0.1 mm																											
Duplex	Duplex mode (second)	-128 to 127	0	0.1 mm																											


Item No.	Description
<p>U034</p>	<p>5. Change the setting value using the cursor left/right keys or numeric keys. For output example 1, increase the value. For output example 2, decrease the value.</p> <p style="text-align: center;">Center line of printing (within ± 0.5 mm)</p> <div style="display: flex; justify-content: space-around; align-items: center;"> <div style="text-align: center;">  <p>Correct image</p> </div> <div style="text-align: center;">  <p>Output example 1</p> </div> <div style="text-align: center;">  <p>Output example 2</p> </div> </div> <p style="text-align: center;">Figure 1-3-3</p> <p>6. Press the start key. The value is set.</p> <p>Caution Check the copy image after the adjustment. If the image is still incorrect, perform the following adjustments in maintenance mode.</p> <div style="display: flex; justify-content: center; align-items: center; gap: 20px;"> <div style="border: 1px solid black; padding: 5px; text-align: center;">U034</div> <div style="font-size: 24px;">→</div> <div style="border: 1px solid black; padding: 5px; text-align: center;">U067 (P.1-3-34)</div> <div style="font-size: 24px;">→</div> <div style="border: 1px solid black; padding: 5px; text-align: center;">U072 (P.1-3-40)</div> </div> <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>

Item No.	Description														
U035	<p>Setting the printing area for folio paper</p> <p>Description Changes the printing area for copying on folio paper.</p> <p>Purpose To prevent cropped images on the trailing edge or left/right side of copy paper by setting the actual printing area for folio paper.</p> <p>Setting</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select the item to be set. 3. Change the setting value using the cursor left/right keys. <table border="1" data-bbox="336 667 1401 808"> <thead> <tr> <th>Display</th> <th>Description</th> <th>Setting range</th> <th>Initial setting</th> </tr> </thead> <tbody> <tr> <td>Length</td> <td>Length</td> <td>330 to 356 mm</td> <td>330</td> </tr> <tr> <td>Width</td> <td>Width</td> <td>200 to 220 mm</td> <td>210</td> </tr> </tbody> </table> <ol style="list-style-type: none"> 4. Press the start key. The value is set. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Setting range	Initial setting	Length	Length	330 to 356 mm	330	Width	Width	200 to 220 mm	210		
Display	Description	Setting range	Initial setting												
Length	Length	330 to 356 mm	330												
Width	Width	200 to 220 mm	210												
U037	<p>Checking the operation of the fan motors</p> <p>Description Drives each fan motor.</p> <p>Purpose To check the operation of each fan motor.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select the fan motor to be operated. 3. Press the start key. The operation starts. <table border="1" data-bbox="336 1402 1401 1736"> <thead> <tr> <th>Display</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>All</td> <td>All fan motors are turned on</td> </tr> <tr> <td>Low Power</td> <td>Power source fan motor (PSFM) is turned on</td> </tr> <tr> <td>Container</td> <td>Container fan motor (CFM) is turned on</td> </tr> <tr> <td>IH Coil</td> <td>IH Coil fan motor (IHCFM) is turned on</td> </tr> <tr> <td>LSU Cooling</td> <td>LSU Cooling fan motor (LSUFM) is turned on</td> </tr> <tr> <td>IH Edge</td> <td>IH fan motor (IHFM) is turned on</td> </tr> </tbody> </table> <p>To stop operation, press the stop key.</p> <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	All	All fan motors are turned on	Low Power	Power source fan motor (PSFM) is turned on	Container	Container fan motor (CFM) is turned on	IH Coil	IH Coil fan motor (IHCFM) is turned on	LSU Cooling	LSU Cooling fan motor (LSUFM) is turned on	IH Edge	IH fan motor (IHFM) is turned on
Display	Description														
All	All fan motors are turned on														
Low Power	Power source fan motor (PSFM) is turned on														
Container	Container fan motor (CFM) is turned on														
IH Coil	IH Coil fan motor (IHCFM) is turned on														
LSU Cooling	LSU Cooling fan motor (LSUFM) is turned on														
IH Edge	IH fan motor (IHFM) is turned on														

Item No.	Description																				
U051	<p>Adjusting the deflection in the paper</p> <p>Description Adjusts the deflection in the paper at the registration roller.</p> <p>Purpose Make the adjustment if the leading edge of the copy image is missing or varies randomly, or if the copy paper is Z-folded.</p> <p>Adjustment</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Press the system menu key. 3. Place an original and press the start key to make a test copy. 4. Press the system menu key. 5. Select the item to be adjusted. <table border="1" data-bbox="336 734 1399 974"> <thead> <tr> <th>Display</th> <th>Description</th> <th>Setting range</th> <th>Initial setting</th> </tr> </thead> <tbody> <tr> <td>MPT</td> <td>Paper feed from MP tray</td> <td>-30 to 20</td> <td>0</td> </tr> <tr> <td>Cassette</td> <td>Paper feed from cassette 1</td> <td>-30 to 20</td> <td>0</td> </tr> <tr> <td>PF</td> <td>Paper feed from paper feeder</td> <td>-30 to 20</td> <td>0</td> </tr> <tr> <td>Duplex</td> <td>Duplex mode (second)</td> <td>-30 to 20</td> <td>0</td> </tr> </tbody> </table> <ol style="list-style-type: none"> 6. Change the setting value using the cursor left/right keys or numeric keys. For output example 1, increase the value. For output example 2, decrease the value. The greater the value, the larger the deflection; the smaller the value, the smaller the deflection. <div data-bbox="592 1178 1142 1451" style="text-align: center;">  <p data-bbox="619 1391 707 1417">Original</p> <p data-bbox="810 1391 927 1451">Copy example 1</p> <p data-bbox="1007 1391 1123 1451">Copy example 2</p> </div> <p data-bbox="783 1480 938 1507">Figure 1-3-4</p> <ol style="list-style-type: none"> 7. Press the start key. The value is set. <p>Completion Press the stop key. The indication for selecting a maintenance item No. appears.</p>	Display	Description	Setting range	Initial setting	MPT	Paper feed from MP tray	-30 to 20	0	Cassette	Paper feed from cassette 1	-30 to 20	0	PF	Paper feed from paper feeder	-30 to 20	0	Duplex	Duplex mode (second)	-30 to 20	0
Display	Description	Setting range	Initial setting																		
MPT	Paper feed from MP tray	-30 to 20	0																		
Cassette	Paper feed from cassette 1	-30 to 20	0																		
PF	Paper feed from paper feeder	-30 to 20	0																		
Duplex	Duplex mode (second)	-30 to 20	0																		

Item No.	Description																																
U053	<p data-bbox="288 241 831 275">Setting the adjustment of the motor speed</p> <p data-bbox="288 311 440 340">Description</p> <p data-bbox="288 344 927 374">Performs fine adjustment of the speeds of the motors.</p> <p data-bbox="288 380 400 409">Purpose</p> <p data-bbox="288 414 1366 479">Basically, the setting need not be changed. Modify settings by interlock setting only if faulty images occur.</p> <p data-bbox="288 517 387 546">Method</p> <ol data-bbox="304 553 1102 618" style="list-style-type: none"> 1. Press the start key. 2. Select the item. The screen for executing each item is displayed. <table border="1" data-bbox="336 629 1383 824"> <thead> <tr> <th data-bbox="336 629 564 674">Display</th> <th data-bbox="564 629 1383 674">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 674 564 719">Full</td> <td data-bbox="564 674 1383 719">Speed correction value setting at full velocity</td> </tr> <tr> <td data-bbox="336 719 564 763">Half</td> <td data-bbox="564 719 1383 763">Speed correction value setting at half velocity</td> </tr> <tr> <td data-bbox="336 763 564 808">3/4</td> <td data-bbox="564 763 1383 808">Speed correction value setting at 3/4 velocity</td> </tr> </tbody> </table> <ol data-bbox="304 837 1058 969" style="list-style-type: none"> 3. Press the system menu key. 4. Place an original and press the start key to make a test copy. 5. Press the system menu key. 6. Select the item to be adjusted. <table border="1" data-bbox="336 983 1383 1576"> <thead> <tr> <th data-bbox="336 983 564 1061">Display</th> <th data-bbox="564 983 1214 1061">Description</th> <th data-bbox="1214 983 1383 1061">Setting range</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1061 564 1106">Feed</td> <td data-bbox="564 1061 1214 1106">Conveying motor (CM) speed adjustment</td> <td data-bbox="1214 1061 1383 1106">-50 to 50</td> </tr> <tr> <td data-bbox="336 1106 564 1151">Exit</td> <td data-bbox="564 1106 1214 1151">Eject motor (EM) speed adjustment</td> <td data-bbox="1214 1106 1383 1151">-40 to 40</td> </tr> <tr> <td data-bbox="336 1151 564 1196">Drum(CMY)</td> <td data-bbox="564 1151 1214 1196">Drum motor (DRM-YCM) speed adjustment</td> <td data-bbox="1214 1151 1383 1196">-50 to 50</td> </tr> <tr> <td data-bbox="336 1196 564 1240">Drum(K)</td> <td data-bbox="564 1196 1214 1240">Drum motor (DRM-K) speed adjustment</td> <td data-bbox="1214 1196 1383 1240">-50 to 50</td> </tr> <tr> <td data-bbox="336 1240 564 1285">DLP(CMY)</td> <td data-bbox="564 1240 1214 1285">DLP motor (DEVM-YCM) speed adjustment</td> <td data-bbox="1214 1240 1383 1285">-50 to 50</td> </tr> <tr> <td data-bbox="336 1285 564 1330">DLP(K)</td> <td data-bbox="564 1285 1214 1330">DLP motor (DEVM-K) speed adjustment</td> <td data-bbox="1214 1285 1383 1330">-50 to 50</td> </tr> <tr> <td data-bbox="336 1330 564 1375">Fixing</td> <td data-bbox="564 1330 1214 1375">Fixing motor(FUM) speed adjustment</td> <td data-bbox="1214 1330 1383 1375">-50 to 50</td> </tr> </tbody> </table> <ol data-bbox="304 1590 1198 1655" style="list-style-type: none"> 7. Change the setting value using the cursor left/right keys or numeric keys. 8. Press the start key. The value is set. <p data-bbox="288 1729 440 1758">Completion</p> <p data-bbox="288 1762 1246 1792">Press the stop key. The indication for selecting a maintenance item No. appears.</p>	Display	Description	Full	Speed correction value setting at full velocity	Half	Speed correction value setting at half velocity	3/4	Speed correction value setting at 3/4 velocity	Display	Description	Setting range	Feed	Conveying motor (CM) speed adjustment	-50 to 50	Exit	Eject motor (EM) speed adjustment	-40 to 40	Drum(CMY)	Drum motor (DRM-YCM) speed adjustment	-50 to 50	Drum(K)	Drum motor (DRM-K) speed adjustment	-50 to 50	DLP(CMY)	DLP motor (DEVM-YCM) speed adjustment	-50 to 50	DLP(K)	DLP motor (DEVM-K) speed adjustment	-50 to 50	Fixing	Fixing motor(FUM) speed adjustment	-50 to 50
Display	Description																																
Full	Speed correction value setting at full velocity																																
Half	Speed correction value setting at half velocity																																
3/4	Speed correction value setting at 3/4 velocity																																
Display	Description	Setting range																															
Feed	Conveying motor (CM) speed adjustment	-50 to 50																															
Exit	Eject motor (EM) speed adjustment	-40 to 40																															
Drum(CMY)	Drum motor (DRM-YCM) speed adjustment	-50 to 50																															
Drum(K)	Drum motor (DRM-K) speed adjustment	-50 to 50																															
DLP(CMY)	DLP motor (DEVM-YCM) speed adjustment	-50 to 50																															
DLP(K)	DLP motor (DEVM-K) speed adjustment	-50 to 50																															
Fixing	Fixing motor(FUM) speed adjustment	-50 to 50																															

Item No.	Description										
U063	<p data-bbox="288 241 686 275">Adjusting the shading position</p> <p data-bbox="288 309 440 342">Description</p> <p data-bbox="288 344 828 378">Changes the shading position of the scanner.</p> <p data-bbox="288 380 400 414">Purpose</p> <p data-bbox="288 416 1428 479">Used when the white line continue to appear longitudinally on the image after the shading plate is cleaned.</p> <p data-bbox="288 481 1428 546">This is due to flaws or stains inside the shading plate. To prevent this problem, the shading position should be changed so that shading is possible without being affected by the flaws or stains.</p> <p data-bbox="288 589 384 622">Setting</p> <ol data-bbox="308 624 1198 723" style="list-style-type: none"> 1. Press the start key. 2. Select [Position]. 3. Change the setting value using the cursor left/right keys or numeric keys. <table border="1" data-bbox="336 734 1399 864"> <thead> <tr> <th data-bbox="336 734 528 815">Display</th> <th data-bbox="528 734 922 815">Description</th> <th data-bbox="922 734 1082 815">Setting range</th> <th data-bbox="1082 734 1193 815">Initial setting</th> <th data-bbox="1193 734 1399 815">Change in value per step</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 815 528 864">Position</td> <td data-bbox="528 815 922 864">Shading position</td> <td data-bbox="922 815 1082 864">-6 to 18</td> <td data-bbox="1082 815 1193 864">0</td> <td data-bbox="1193 815 1399 864">0.091 mm</td> </tr> </tbody> </table> <p data-bbox="336 875 1414 940">Increasing the value moves the shading position toward the machine left, and decreasing it moves the position toward the machine right.</p> <ol data-bbox="308 943 767 976" style="list-style-type: none"> 4. Press the start key. The value is set. <p data-bbox="288 1014 448 1048">Supplement</p> <p data-bbox="288 1050 1417 1115">While this maintenance item is being executed, copying from an original is available in interrupt copying mode (which is activated by pressing the system menu key).</p> <p data-bbox="288 1153 440 1187">Completion</p> <p data-bbox="288 1189 1254 1223">Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Setting range	Initial setting	Change in value per step	Position	Shading position	-6 to 18	0	0.091 mm
Display	Description	Setting range	Initial setting	Change in value per step							
Position	Shading position	-6 to 18	0	0.091 mm							


Item No.	Description															
U065	<p data-bbox="288 241 754 271">Adjusting the scanner magnification</p> <p data-bbox="288 311 440 340">Description</p> <p data-bbox="288 344 877 374">Adjusts the magnification of the original scanning.</p> <p data-bbox="288 380 400 409">Purpose</p> <p data-bbox="288 414 1276 443">Make the adjustment if the magnification in the main scanning direction is incorrect.</p> <p data-bbox="288 448 1316 477">Make the adjustment if the magnification in the auxiliary scanning direction is incorrect.</p> <p data-bbox="288 517 392 546">Caution</p> <p data-bbox="288 551 1013 580">Adjust the magnification of the scanner in the following order.</p> <div data-bbox="295 600 1359 692" style="border: 1px solid black; padding: 5px; text-align: center;">  <pre> graph LR U053["U053 (P.1-3-29)"] --> U065M["U065 main scan- ning direction"] U065M --> U065A["U065 auxiliary scan- ning direction"] U065A --> U067["U067 (P.1-3-34)"] U067 --> U070["U070 (P.1-3-37)"] </pre> </div> <p data-bbox="288 741 387 770">Method</p> <ol data-bbox="304 777 1058 945" style="list-style-type: none"> 1. Press the start key. 2. Press the system menu key. 3. Place an original and press the start key to make a test copy. 4. Press the system menu key. 5. Select the item to be adjusted. <table border="1" data-bbox="336 958 1401 1207"> <thead> <tr> <th>Display</th> <th>Description</th> <th>Setting range</th> <th>Initial setting</th> <th>Change in value per step</th> </tr> </thead> <tbody> <tr> <td>Y Scan Zoom</td> <td>Scanner magnification in the main scanning direction</td> <td>-75 to 75</td> <td>0</td> <td>0.02 %</td> </tr> <tr> <td>X Scan Zoom</td> <td>Scanner magnification in the auxiliary scanning direction</td> <td>-125 to 125</td> <td>0</td> <td>0.02 %</td> </tr> </tbody> </table> <p data-bbox="288 1252 643 1281">Adjustment: [Y Scan Zoom]</p> <ol data-bbox="304 1288 1303 1352" style="list-style-type: none"> 1. Change the setting value using the cursor left/right keys or numeric keys. For copy example 1, increase the value. For copy example 2, decrease the value. <div data-bbox="671 1375 1062 1599" style="text-align: center;">  <p data-bbox="683 1541 770 1570">Original</p> <p data-bbox="810 1541 922 1599">Copy example 1</p> <p data-bbox="954 1541 1062 1599">Copy example 2</p> </div> <p data-bbox="783 1626 938 1655">Figure 1-3-5</p> <ol data-bbox="304 1695 766 1724" style="list-style-type: none"> 2. Press the start key. The value is set. 	Display	Description	Setting range	Initial setting	Change in value per step	Y Scan Zoom	Scanner magnification in the main scanning direction	-75 to 75	0	0.02 %	X Scan Zoom	Scanner magnification in the auxiliary scanning direction	-125 to 125	0	0.02 %
Display	Description	Setting range	Initial setting	Change in value per step												
Y Scan Zoom	Scanner magnification in the main scanning direction	-75 to 75	0	0.02 %												
X Scan Zoom	Scanner magnification in the auxiliary scanning direction	-125 to 125	0	0.02 %												


Item No.	Description
U065	<p data-bbox="288 241 643 275">Adjustment: [X Scan Zoom]</p> <p data-bbox="308 277 1302 342">1. Change the setting value using the cursor left/right keys or numeric keys. For copy example 1, increase the value. For copy example 2, decrease the value.</p> <div data-bbox="673 367 1062 591" style="text-align: center;"><p data-bbox="684 530 767 557">Original</p><p data-bbox="810 530 922 591">Copy example 1</p><p data-bbox="951 530 1062 591">Copy example 2</p></div> <p data-bbox="783 618 938 651" style="text-align: center;">Figure 1-3-6</p> <p data-bbox="304 689 766 723">2. Press the start key. The value is set.</p> <p data-bbox="288 757 440 790">Completion</p> <p data-bbox="288 792 1254 826">Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>

Item No.	Description															
U066	<p data-bbox="288 241 898 275">Adjusting the scanner leading edge registration</p> <p data-bbox="288 309 440 342">Description</p> <p data-bbox="288 344 1117 378">Adjusts the scanner leading edge registration of the original scanning.</p> <p data-bbox="288 380 400 414">Purpose</p> <p data-bbox="288 416 1426 483">Make the adjustment if there is a regular error between the leading edges of the copy image and original.</p> <p data-bbox="288 517 440 551">Adjustment</p> <ol data-bbox="304 553 1058 723" style="list-style-type: none"> 1. Press the start key. 2. Press the system menu key. 3. Place an original and press the start key to make a test copy. 4. Press the system menu key. 5. Select the item to be adjusted. <table border="1" data-bbox="336 734 1401 981"> <thead> <tr> <th>Display</th> <th>Description</th> <th>Setting range</th> <th>Initial setting</th> <th>Change in value per step</th> </tr> </thead> <tbody> <tr> <td>Front</td> <td>Scanner leading edge registration</td> <td>-45 to 45</td> <td>0</td> <td>0.091 mm</td> </tr> <tr> <td>Rotate</td> <td>Scanner leading edge registration (rotate copying)</td> <td>-45 to 45</td> <td>0</td> <td>0.100mm</td> </tr> </tbody> </table> <ol data-bbox="304 992 1302 1059" style="list-style-type: none"> 6. Change the setting value using the cursor left/right keys or numeric keys. For copy example 1, increase the value. For copy example 2, decrease the value. <div data-bbox="619 1081 1182 1391" style="text-align: center;"> <p>Scanner leading edge registration (within ± 2.5 mm)</p> <p>Original Copy example 1 Copy example 2</p> </div> <p data-bbox="783 1420 938 1453">Figure 1-3-7</p> <ol data-bbox="304 1487 767 1520" style="list-style-type: none"> 7. Press the start key. The value is set. <p data-bbox="288 1554 392 1588">Caution</p> <p data-bbox="288 1590 1401 1657">Check the copy image after the adjustment. If the image is still incorrect, perform the following adjustments in maintenance mode.</p> <div data-bbox="293 1675 1129 1771" style="text-align: center;"> <pre> graph LR U066[U066] --> U403[U403 (P.1-3-78)] U403 --> U071[U071 (P.1-3-38)] U071 --> U404[U404 (P.1-3-79)] </pre> </div> <p data-bbox="288 1816 440 1850">Completion</p> <p data-bbox="288 1852 1254 1886">Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Setting range	Initial setting	Change in value per step	Front	Scanner leading edge registration	-45 to 45	0	0.091 mm	Rotate	Scanner leading edge registration (rotate copying)	-45 to 45	0	0.100mm
Display	Description	Setting range	Initial setting	Change in value per step												
Front	Scanner leading edge registration	-45 to 45	0	0.091 mm												
Rotate	Scanner leading edge registration (rotate copying)	-45 to 45	0	0.100mm												


Item No.	Description															
U067	<p>Adjusting the scanner center line</p> <p>Description Adjusts the scanner center line of the original scanning.</p> <p>Purpose Perform this adjustment if there is a unmatched error between the center lines of the copy image and original.</p> <p>Adjustment</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Press the system menu key. 3. Place an original and press the start key to make a test copy. 4. Press the system menu key. 5. Select the item to be adjusted. <table border="1" data-bbox="336 734 1401 949"> <thead> <tr> <th>Display</th> <th>Description</th> <th>Setting range</th> <th>Initial setting</th> <th>Change in value per step</th> </tr> </thead> <tbody> <tr> <td>Front</td> <td>Scanner center line</td> <td>-40 to 40</td> <td>0</td> <td>0.085 mm</td> </tr> <tr> <td>Rotate</td> <td>Scanner center line (rotate copying)</td> <td>-40 to 40</td> <td>0</td> <td>0.100 mm</td> </tr> </tbody> </table> <ol style="list-style-type: none"> 6. Change the setting value using the cursor left/right keys or numeric keys. For copy example 1, increase the value. For copy example 2, decrease the value. <div data-bbox="647 1048 1074 1339" style="text-align: center;"> <p>Scanner center line (within ± 2.0 mm)</p> <p>Original Copy example 1 Copy example 2</p> </div> <p style="text-align: center;">Figure 1-3-8</p> <ol style="list-style-type: none"> 7. Press the start key. The value is set. <p>Caution Check the copy image after the adjustment. If the image is still incorrect, perform the following adjustments in maintenance mode.</p> <div data-bbox="293 1617 1129 1711" style="text-align: center;"> <pre> graph LR U067[U067] --> U403[U403 (P.1-3-78)] U403 --> U072[U072 (P.1-3-40)] U072 --> U404[U404 (P.1-3-79)] </pre> </div> <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Setting range	Initial setting	Change in value per step	Front	Scanner center line	-40 to 40	0	0.085 mm	Rotate	Scanner center line (rotate copying)	-40 to 40	0	0.100 mm
Display	Description	Setting range	Initial setting	Change in value per step												
Front	Scanner center line	-40 to 40	0	0.085 mm												
Rotate	Scanner center line (rotate copying)	-40 to 40	0	0.100 mm												

Item No.	Description															
U068	<p data-bbox="288 241 1021 275">Adjusting the scanning position for originals from the DP</p> <p data-bbox="288 311 440 340">Description</p> <p data-bbox="288 344 1414 412">Adjusts the position for scanning originals from the DP. Performs the test copy at the four scanning positions after adjusting.</p> <p data-bbox="288 416 400 445">Purpose</p> <p data-bbox="288 450 1426 517">Used when the image fogging occurs because the scanning position is not proper when the DP is used. Run U071 to adjust the timing of DP leading edge when the scanning position is changed.</p> <p data-bbox="288 553 384 582">Setting</p> <p data-bbox="304 586 571 616">1. Press the start key.</p> <table border="1" data-bbox="336 629 1399 880"> <thead> <tr> <th data-bbox="336 629 528 712">Display</th> <th data-bbox="528 629 922 712">Description</th> <th data-bbox="922 629 1082 712">Setting range</th> <th data-bbox="1082 629 1193 712">Initial setting</th> <th data-bbox="1193 629 1399 712">Change in value per step</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 712 528 795">DP Read</td> <td data-bbox="528 712 922 795">Starting position adjustment for scanning originals</td> <td data-bbox="922 712 1082 795">-55 to 55</td> <td data-bbox="1082 712 1193 795">0</td> <td data-bbox="1193 712 1399 795">0.091 mm</td> </tr> <tr> <td data-bbox="336 795 528 880">Black Line</td> <td data-bbox="528 795 922 880">Scanning position for the test copy originals</td> <td data-bbox="922 795 1082 880">0 to 3</td> <td data-bbox="1082 795 1193 880">0</td> <td data-bbox="1193 795 1399 880">-</td> </tr> </tbody> </table> <p data-bbox="304 891 549 920">2. Select [DP Read].</p> <p data-bbox="304 925 1126 954">3. Change the setting using the cursor left/right keys or numeric keys.</p> <p data-bbox="333 958 1426 1025">When the setting value is increased, the scanning position moves to the right and it moves to the left when the setting value is decreased.</p> <p data-bbox="304 1030 766 1059">4. Press the start key. The value is set.</p> <p data-bbox="304 1064 564 1093">5. Select [Black Line].</p> <p data-bbox="304 1097 1126 1126">6. Change the setting using the cursor left/right keys or numeric keys.</p> <p data-bbox="304 1131 766 1160">7. Press the start key. The value is set.</p> <p data-bbox="304 1164 1417 1193">8. Set the original (the one which density is known) in the DP and press the system menu key.</p> <p data-bbox="304 1198 834 1227">9. Press the start key. Test copy is executed.</p> <p data-bbox="288 1232 1426 1299">10. Perform the test copy at each scanning position with the setting value from 0 to 3 and check that no black line appears and the image is normally scanned.</p> <p data-bbox="288 1335 440 1364">Completion</p> <p data-bbox="288 1368 1254 1397">Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Setting range	Initial setting	Change in value per step	DP Read	Starting position adjustment for scanning originals	-55 to 55	0	0.091 mm	Black Line	Scanning position for the test copy originals	0 to 3	0	-
Display	Description	Setting range	Initial setting	Change in value per step												
DP Read	Starting position adjustment for scanning originals	-55 to 55	0	0.091 mm												
Black Line	Scanning position for the test copy originals	0 to 3	0	-												


Item No.	Description															
U070	<p data-bbox="287 241 691 275">Adjusting the DP magnification</p> <p data-bbox="287 309 440 342">Description</p> <p data-bbox="287 344 764 378">Adjusts the DP original scanning speed.</p> <p data-bbox="287 380 400 414">Purpose</p> <p data-bbox="287 416 1417 483">Perform this adjustment if the magnification is incorrect in the auxiliary scanning direction when the DP is used.</p> <p data-bbox="287 517 440 551">Adjustment</p> <ol data-bbox="304 553 1182 723" style="list-style-type: none"> 1. Press the start key. 2. Press the system menu key. 3. Place an original on the DP and press the start key to make a test copy. 4. Press the system menu key. 5. Select the item to be adjusted. <table border="1" data-bbox="336 734 1401 981"> <thead> <tr> <th>Display</th> <th>Description</th> <th>Setting range</th> <th>Initial setting</th> <th>Change in value per step</th> </tr> </thead> <tbody> <tr> <td>Y Scan Zoom</td> <td>Magnification in the main scanning direction</td> <td>-125 to 125</td> <td>0</td> <td>0.02 %</td> </tr> <tr> <td>X Scan Zoom</td> <td>Magnification in the auxiliary scanning direction</td> <td>-125 to 125</td> <td>0</td> <td>0.02 %</td> </tr> </tbody> </table> <p data-bbox="287 1025 643 1059">Adjustment: [Y Scan Zoom]</p> <ol data-bbox="304 1061 1302 1128" style="list-style-type: none"> 1. Change the setting value using the cursor left/right keys or numeric keys. For copy example 1, increase the value. For copy example 2, decrease the value. <div data-bbox="671 1151 1062 1375" style="text-align: center;">  <p data-bbox="683 1317 1062 1375">Original Copy example 1 Copy example 2</p> </div> <p data-bbox="783 1400 938 1433">Figure 1-3-9</p>	Display	Description	Setting range	Initial setting	Change in value per step	Y Scan Zoom	Magnification in the main scanning direction	-125 to 125	0	0.02 %	X Scan Zoom	Magnification in the auxiliary scanning direction	-125 to 125	0	0.02 %
Display	Description	Setting range	Initial setting	Change in value per step												
Y Scan Zoom	Magnification in the main scanning direction	-125 to 125	0	0.02 %												
X Scan Zoom	Magnification in the auxiliary scanning direction	-125 to 125	0	0.02 %												

Item No.	Description
<p>U070</p>	<p>2. Press the start key. The value is set.</p> <p>Adjustment: [X Scan Zoom]</p> <p>1. Change the setting value using the cursor left/right keys or numeric keys. For copy example 1, increase the value. For copy example 2, decrease the value.</p> <div style="text-align: center;">  <p>The figure shows three square boxes, each containing a black arrow pointing upwards. The first box is labeled 'Original' and has a medium-height arrow. The second box is labeled 'Copy example 1' and has a shorter arrow. The third box is labeled 'Copy example 2' and has a taller arrow.</p> </div> <p>Figure 1-3-10</p> <p>2. Press the start key. The value is set.</p> <p>Caution Check the copy image after the adjustment. If the image is still incorrect, perform the following adjustments in maintenance mode.</p> <div style="text-align: center;">  <pre> graph LR A[U070] --> B[U071 (P.1-3-38)] B --> C[U404 (P.1-3-79)] </pre> </div> <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>



Item No.	Description																									
U071	<p data-bbox="288 241 719 275">Adjusting the DP scanning timing</p> <p data-bbox="288 311 440 340">Description</p> <p data-bbox="288 344 762 376">Adjusts the DP original scanning timing.</p> <p data-bbox="288 380 400 409">Purpose</p> <p data-bbox="288 414 1422 479">Make the adjustment if there is a regular error between the leading or trailing edges of the original and the copy image when the DP is used.</p> <p data-bbox="288 517 387 546">Method</p> <ol data-bbox="304 553 1182 719" style="list-style-type: none"> 1. Press the start key. 2. Press the system menu key. 3. Place an original on the DP and press the start key to make a test copy. 4. Press the system menu key. 5. Select the item to be adjusted. <table border="1" data-bbox="336 734 1401 1149"> <thead> <tr> <th>Display</th> <th>Description</th> <th>Setting range</th> <th>Initial setting</th> <th>Change in value per step</th> </tr> </thead> <tbody> <tr> <td>Front Head</td> <td>Leading edge registration (first side)</td> <td>-80 to 80</td> <td>0</td> <td>0.119 mm</td> </tr> <tr> <td>Front Tail</td> <td>Trailing edge registration (first side)</td> <td>-80 to 80</td> <td>0</td> <td>0.119 mm</td> </tr> <tr> <td>Back Head</td> <td>Leading edge registration (second side)</td> <td>-80 to 80</td> <td>0</td> <td>0.119 mm</td> </tr> <tr> <td>Back Tail</td> <td>Trailing edge registration (second side)</td> <td>-80 to 80</td> <td>0</td> <td>0.119 mm</td> </tr> </tbody> </table> <p data-bbox="288 1189 783 1220">Adjustment: Leading edge registration</p> <ol data-bbox="304 1225 1302 1290" style="list-style-type: none"> 1. Change the setting value using the cursor left/right keys or numeric keys. For copy example 1, increase the value. For copy example 2, decrease the value. <div data-bbox="655 1314 1066 1554" style="text-align: center;">  <p data-bbox="671 1496 756 1525">Original</p> <p data-bbox="804 1496 916 1554">Copy example 1</p> <p data-bbox="951 1496 1062 1554">Copy example 2</p> </div> <p data-bbox="775 1579 943 1610">Figure 1-3-11</p> <ol data-bbox="304 1648 767 1680" style="list-style-type: none"> 2. Press the start key. The value is set. <p data-bbox="288 1718 392 1747">Caution</p> <p data-bbox="288 1751 1382 1816">If the first side is adjusted, check the second side and if adjustment is required, carry out the adjustment.</p> <p data-bbox="288 1821 1401 1886">Check the copy image after the adjustment. If the image is still incorrect, perform the following adjustments in maintenance mode.</p> <div data-bbox="293 1904 676 1998" style="text-align: center;">  </div>	Display	Description	Setting range	Initial setting	Change in value per step	Front Head	Leading edge registration (first side)	-80 to 80	0	0.119 mm	Front Tail	Trailing edge registration (first side)	-80 to 80	0	0.119 mm	Back Head	Leading edge registration (second side)	-80 to 80	0	0.119 mm	Back Tail	Trailing edge registration (second side)	-80 to 80	0	0.119 mm
Display	Description	Setting range	Initial setting	Change in value per step																						
Front Head	Leading edge registration (first side)	-80 to 80	0	0.119 mm																						
Front Tail	Trailing edge registration (first side)	-80 to 80	0	0.119 mm																						
Back Head	Leading edge registration (second side)	-80 to 80	0	0.119 mm																						
Back Tail	Trailing edge registration (second side)	-80 to 80	0	0.119 mm																						

Item No.	Description
U071	<p>Adjustment: Trailing edge registration</p> <p>1. Change the setting value using the cursor left/right keys or numeric keys. For copy example 1, increase the value. For copy example 2, decrease the value.</p> <div data-bbox="687 365 1050 604" style="text-align: center;"> <p>Original Copy example 1 Copy example 2</p> </div> <p style="text-align: center;">Figure 1-3-12</p> <p>2. Press the start key. The value is set.</p> <p>Caution If the first side is adjusted, check the second side and if adjustment is required, carry out the adjustment. Check the copy image after the adjustment. If the image is still incorrect, perform the following adjustments in maintenance mode.</p> <div data-bbox="293 954 676 1048" style="text-align: center;"> <pre> graph LR U071[U071] --> U404[U404 (P.1-3-79)] </pre> </div> <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>

Item No.	Description																		
U072	<p data-bbox="288 241 651 271">Adjusting the DP center line</p> <p data-bbox="288 311 440 340">Description</p> <p data-bbox="288 344 927 374">Adjusts the scanning start position for the DP original.</p> <p data-bbox="288 380 400 409">Purpose</p> <p data-bbox="288 414 1426 479">Perform the adjustment if there is a regular error between the centers of the original and the copy image when the DP is used.</p> <p data-bbox="288 519 440 548">Adjustment</p> <ol data-bbox="308 553 1182 719" style="list-style-type: none"> 1. Press the start key. 2. Press the system menu key. 3. Place an original on the DP and press the start key to make a test copy. 4. Press the system menu key. 5. Select the item to be adjusted. <table border="1" data-bbox="336 734 1401 913"> <thead> <tr> <th>Display</th> <th>Description</th> <th>Setting range</th> <th>Initial setting</th> <th>Change in value per step</th> </tr> </thead> <tbody> <tr> <td>Front</td> <td>DP center line (first side)</td> <td>-80 to 80</td> <td>0</td> <td>0.119 mm</td> </tr> <tr> <td>Back</td> <td>DP center line (second side)</td> <td>-80 to 80</td> <td>0</td> <td>0.119 mm</td> </tr> </tbody> </table> <ol data-bbox="308 925 1302 990" style="list-style-type: none"> 6. Change the setting value using the cursor left/right keys or numeric keys. For copy example 1, increase the value. For copy example 2, decrease the value. <div data-bbox="655 1021 1082 1252" style="text-align: center;">  <p data-bbox="671 1193 756 1223">Original</p> <p data-bbox="810 1193 922 1252">Copy example 1</p> <p data-bbox="963 1193 1075 1252">Copy example 2</p> </div> <p data-bbox="775 1272 946 1301">Figure 1-3-13</p> <ol data-bbox="308 1341 767 1370" style="list-style-type: none"> 7. Press the start key. The value is set. <p data-bbox="288 1411 392 1440">Caution</p> <p data-bbox="288 1444 1382 1509">If the first side is adjusted, check the second side and if adjustment is required, carry out the adjustment.</p> <p data-bbox="288 1514 1402 1579">Check the copy image after the adjustment. If the image is still incorrect, perform the following adjustments in maintenance mode.</p> <div data-bbox="293 1594 676 1688" style="text-align: center;"> <table border="1"> <tr> <td data-bbox="293 1594 448 1688">U072</td> <td data-bbox="448 1594 523 1688">→</td> <td data-bbox="523 1594 676 1688">U404 (P.1-3-79)</td> </tr> </table> </div> <p data-bbox="288 1740 440 1769">Completion</p> <p data-bbox="288 1774 1254 1803">Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Setting range	Initial setting	Change in value per step	Front	DP center line (first side)	-80 to 80	0	0.119 mm	Back	DP center line (second side)	-80 to 80	0	0.119 mm	U072	→	U404 (P.1-3-79)
Display	Description	Setting range	Initial setting	Change in value per step															
Front	DP center line (first side)	-80 to 80	0	0.119 mm															
Back	DP center line (second side)	-80 to 80	0	0.119 mm															
U072	→	U404 (P.1-3-79)																	

Item No.	Description								
U074	<p data-bbox="288 241 786 275">Adjusting the DP input light luminosity</p> <p data-bbox="288 311 440 340">Description</p> <p data-bbox="288 344 1054 376">Sets the luminosity correction for scanning originals from the DP.</p> <p data-bbox="288 380 392 409">Purpose</p> <p data-bbox="288 414 1410 479">Modify the setting only if a spotted background appears when a bluish original is scanned from the DP.</p> <p data-bbox="288 515 384 544">Setting</p> <ol data-bbox="308 548 1198 613" style="list-style-type: none"> 1. Press the start key. 2. Change the setting value using the cursor left/right keys or numeric keys. <table border="1" data-bbox="347 622 1410 748"> <thead> <tr> <th data-bbox="352 629 576 696">Display</th> <th data-bbox="576 629 1046 696">Description</th> <th data-bbox="1046 629 1230 696">Setting range</th> <th data-bbox="1230 629 1406 696">Initial setting</th> </tr> </thead> <tbody> <tr> <td data-bbox="352 696 576 748">Coefficient</td> <td data-bbox="576 696 1046 748">DP input light luminosity correction</td> <td data-bbox="1046 696 1230 748">0 to 3</td> <td data-bbox="1230 696 1406 748">0</td> </tr> </tbody> </table> <p data-bbox="288 777 1358 808">Settings 0: No correction / 1: Slight correction / 2: Medium correction / 3: Strong correction</p> <ol data-bbox="308 813 767 844" style="list-style-type: none"> 3. Press the start key. The value is set. <p data-bbox="288 880 448 909">Supplement</p> <p data-bbox="288 913 1418 978">While this maintenance item is being executed, copying from an original is available in interrupt copying mode (which is activated by pressing the system menu key).</p> <p data-bbox="288 1014 440 1043">Completion</p> <p data-bbox="288 1048 1254 1079">Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Setting range	Initial setting	Coefficient	DP input light luminosity correction	0 to 3	0
Display	Description	Setting range	Initial setting						
Coefficient	DP input light luminosity correction	0 to 3	0						

Item No.	Description																											
U089	<p data-bbox="288 241 651 275">Outputting a MIP-PG pattern</p> <p data-bbox="288 311 440 340">Description</p> <p data-bbox="288 344 1050 374">Selects and outputs the MIP-PG pattern created in the machine.</p> <p data-bbox="288 380 400 409">Purpose</p> <p data-bbox="288 414 1422 479">To check copier status other than scanner when adjusting image printing, using MIP-PG pattern output (with-out scanning).</p> <p data-bbox="288 517 387 546">Method</p> <ol data-bbox="304 553 1082 618" style="list-style-type: none"> 1. Press the start key. 2. Select the MIP-PG pattern to be output and press the start key. <table border="1" data-bbox="333 636 1398 1137"> <thead> <tr> <th data-bbox="336 640 600 685">Display</th> <th data-bbox="600 640 919 685">PG pattern to be output</th> <th data-bbox="919 640 1394 685">Purpose</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 685 600 730">256GRADATION</td> <td data-bbox="600 685 919 730">256-gradation PG</td> <td data-bbox="919 685 1394 730">To check the gradation reproducibility</td> </tr> <tr> <td data-bbox="336 730 600 808">COLOR BELT</td> <td data-bbox="600 730 919 808">Four color belts PG</td> <td data-bbox="919 730 1394 808">To check the developing state and the engine section ID</td> </tr> <tr> <td data-bbox="336 808 600 853">GRAY(C)</td> <td data-bbox="600 808 919 853">Cyan PG</td> <td data-bbox="919 808 1394 853">To check the drum quality</td> </tr> <tr> <td data-bbox="336 853 600 898">GRAY(M)</td> <td data-bbox="600 853 919 898">Magenta PG</td> <td data-bbox="919 853 1394 898">To check the drum quality</td> </tr> <tr> <td data-bbox="336 898 600 943">GRAY(Y)</td> <td data-bbox="600 898 919 943">Yellow PG</td> <td data-bbox="919 898 1394 943">To check the drum quality</td> </tr> <tr> <td data-bbox="336 943 600 987">GRAY(K)</td> <td data-bbox="600 943 919 987">Black PG</td> <td data-bbox="919 943 1394 987">To check the drum quality</td> </tr> <tr> <td data-bbox="336 987 600 1032">WHITE</td> <td data-bbox="600 987 919 1032">Blank paper PG</td> <td data-bbox="919 987 1394 1032">To check the drum quality</td> </tr> <tr> <td data-bbox="336 1032 600 1133">GRADATION GRAY</td> <td data-bbox="600 1032 919 1133">5-gradation gray PG</td> <td data-bbox="919 1032 1394 1133">To check for vertical lines on the laser scanner unit</td> </tr> </tbody> </table> <ol data-bbox="304 1164 898 1229" style="list-style-type: none"> 3. Press the system menu key. 4. Press the start key. A MIP-PG pattern is output. <p data-bbox="288 1265 440 1294">Completion</p> <p data-bbox="288 1299 1254 1328">Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	PG pattern to be output	Purpose	256GRADATION	256-gradation PG	To check the gradation reproducibility	COLOR BELT	Four color belts PG	To check the developing state and the engine section ID	GRAY(C)	Cyan PG	To check the drum quality	GRAY(M)	Magenta PG	To check the drum quality	GRAY(Y)	Yellow PG	To check the drum quality	GRAY(K)	Black PG	To check the drum quality	WHITE	Blank paper PG	To check the drum quality	GRADATION GRAY	5-gradation gray PG	To check for vertical lines on the laser scanner unit
Display	PG pattern to be output	Purpose																										
256GRADATION	256-gradation PG	To check the gradation reproducibility																										
COLOR BELT	Four color belts PG	To check the developing state and the engine section ID																										
GRAY(C)	Cyan PG	To check the drum quality																										
GRAY(M)	Magenta PG	To check the drum quality																										
GRAY(Y)	Yellow PG	To check the drum quality																										
GRAY(K)	Black PG	To check the drum quality																										
WHITE	Blank paper PG	To check the drum quality																										
GRADATION GRAY	5-gradation gray PG	To check for vertical lines on the laser scanner unit																										

Item No.	Description																																									
U099	<p data-bbox="288 241 703 275">Adjusting original size detection</p> <p data-bbox="288 311 440 340">Description</p> <p data-bbox="288 344 1302 374">Checks the operation of the original size sensor and sets the sensing threshold value.</p> <p data-bbox="288 380 400 409">Purpose</p> <p data-bbox="288 414 1431 479">To adjust the sensitivity of the sensor and size judgement time if the original size sensor malfunctions frequently due to incident light or the like.</p> <p data-bbox="288 517 387 546">Method</p> <ol data-bbox="308 553 1099 618" style="list-style-type: none"> 1. Press the start key. 2. Select the item. The screen for executing each item is displayed. <table border="1" data-bbox="336 631 1399 893"> <thead> <tr> <th data-bbox="336 631 641 678">Display</th> <th data-bbox="641 631 1399 678">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 678 641 725">Data1</td> <td data-bbox="641 678 1399 725">Displaying original size sensor transmission data</td> </tr> <tr> <td data-bbox="336 725 641 808">B/W Level1</td> <td data-bbox="641 725 1399 808">B/W LEVEL setting original size sensor threshold value Setting original size judgment time</td> </tr> <tr> <td data-bbox="336 808 641 893">Data2</td> <td data-bbox="641 808 1399 893">Displaying original size sensor transmission data (when DP is installed)</td> </tr> </tbody> </table> <p data-bbox="288 936 572 965">Method: [Data1/Data2]</p> <ol data-bbox="308 969 1425 1034" style="list-style-type: none"> 1. Place the original and close the original cover or DP. The detection sensor transmission data is displayed. <table border="1" data-bbox="336 1048 1399 1240"> <thead> <tr> <th data-bbox="336 1048 641 1095">Display</th> <th data-bbox="641 1048 1399 1095">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1095 641 1142">Original Area (dot)</td> <td data-bbox="641 1095 1399 1142">Detected original width size (dot)</td> </tr> <tr> <td data-bbox="336 1142 641 1189">Original Area (mm)</td> <td data-bbox="641 1142 1399 1189">Detected original width size (mm)</td> </tr> <tr> <td data-bbox="336 1189 641 1240">Size SW L</td> <td data-bbox="641 1189 1399 1240">Displays the original size sensor (OSS) ON/OFF</td> </tr> </tbody> </table> <p data-bbox="288 1301 560 1330">Setting: [B/W Level1]</p> <ol data-bbox="308 1335 1206 1400" style="list-style-type: none"> 1. Select an item to be set. 2. Change the setting value using the cursor left/right keys or numeric keys. <table border="1" data-bbox="336 1413 1399 1688"> <thead> <tr> <th data-bbox="336 1413 550 1496">Display</th> <th data-bbox="550 1413 991 1496">Description</th> <th data-bbox="991 1413 1126 1496">Setting range</th> <th colspan="2" data-bbox="1126 1413 1399 1496">Initial setting</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1496 550 1543">Original 1</td> <td data-bbox="550 1496 991 1543">Original threshold value</td> <td data-bbox="991 1496 1126 1543">0 to 255</td> <td data-bbox="1126 1496 1262 1543">40</td> <td data-bbox="1262 1496 1399 1543">50*</td> </tr> <tr> <td data-bbox="336 1543 550 1590">Original 2</td> <td data-bbox="550 1543 991 1590">Original threshold value</td> <td data-bbox="991 1543 1126 1590">0 to 255</td> <td data-bbox="1126 1543 1262 1590">30</td> <td data-bbox="1262 1543 1399 1590">50*</td> </tr> <tr> <td data-bbox="336 1590 550 1637">Original 2</td> <td data-bbox="550 1590 991 1637">Original threshold value</td> <td data-bbox="991 1590 1126 1637">0 to 255</td> <td data-bbox="1126 1590 1262 1637">20</td> <td data-bbox="1262 1590 1399 1637">50*</td> </tr> <tr> <td data-bbox="336 1637 550 1688">Light Source</td> <td data-bbox="550 1637 991 1688">Light source threshold value</td> <td data-bbox="991 1637 1126 1688">0 to 255</td> <td data-bbox="1126 1637 1262 1688">19</td> <td data-bbox="1262 1637 1399 1688">49*</td> </tr> </tbody> </table> <p data-bbox="341 1715 600 1744">When DP is installed.</p> <p data-bbox="335 1749 1358 1778">Note: A smaller value increases the sensor sensitivity, and a larger value decreases it.</p> <ol data-bbox="308 1818 767 1848" style="list-style-type: none"> 3. Press the start key. The value is set. <p data-bbox="288 1888 440 1917">Completion</p> <p data-bbox="288 1921 1118 1951">Press the stop key. The screen for maintenance item No. is displayed.</p>	Display	Description	Data1	Displaying original size sensor transmission data	B/W Level1	B/W LEVEL setting original size sensor threshold value Setting original size judgment time	Data2	Displaying original size sensor transmission data (when DP is installed)	Display	Description	Original Area (dot)	Detected original width size (dot)	Original Area (mm)	Detected original width size (mm)	Size SW L	Displays the original size sensor (OSS) ON/OFF	Display	Description	Setting range	Initial setting		Original 1	Original threshold value	0 to 255	40	50*	Original 2	Original threshold value	0 to 255	30	50*	Original 2	Original threshold value	0 to 255	20	50*	Light Source	Light source threshold value	0 to 255	19	49*
Display	Description																																									
Data1	Displaying original size sensor transmission data																																									
B/W Level1	B/W LEVEL setting original size sensor threshold value Setting original size judgment time																																									
Data2	Displaying original size sensor transmission data (when DP is installed)																																									
Display	Description																																									
Original Area (dot)	Detected original width size (dot)																																									
Original Area (mm)	Detected original width size (mm)																																									
Size SW L	Displays the original size sensor (OSS) ON/OFF																																									
Display	Description	Setting range	Initial setting																																							
Original 1	Original threshold value	0 to 255	40	50*																																						
Original 2	Original threshold value	0 to 255	30	50*																																						
Original 2	Original threshold value	0 to 255	20	50*																																						
Light Source	Light source threshold value	0 to 255	19	49*																																						

Item No.	Description																				
U100	<p data-bbox="288 241 667 275">Setting the main high voltage</p> <p data-bbox="288 311 440 340">Description</p> <p data-bbox="288 344 1086 376">Controls the charger roller voltage to optimize the surface potential.</p> <p data-bbox="288 383 400 412">Purpose</p> <p data-bbox="288 416 1433 448">To change the setting value to adjust the image if an image failure (background blur, etc.) occurs.</p> <p data-bbox="288 486 387 515">Method</p> <ol data-bbox="308 519 1101 584" style="list-style-type: none"> 1. Press the start key. 2. Select the item. The screen for executing each item is displayed. <table border="1" data-bbox="336 598 1386 790"> <thead> <tr> <th data-bbox="336 598 641 642">Display</th> <th data-bbox="641 598 1386 642">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 642 641 687">Base</td> <td data-bbox="641 642 1386 687">MC DC bias</td> </tr> <tr> <td data-bbox="336 687 641 732">Protect Table</td> <td data-bbox="641 687 1386 732">Drum protection control table</td> </tr> <tr> <td data-bbox="336 732 641 790">Drum Aging</td> <td data-bbox="641 732 1386 790">Aging for an electrification roller</td> </tr> </tbody> </table> <p data-bbox="288 835 480 864">Method:[Base]</p> <ol data-bbox="308 869 1101 900" style="list-style-type: none"> 1. Select the item. The screen for executing each item is displayed. <table border="1" data-bbox="336 913 1386 1059"> <thead> <tr> <th data-bbox="336 913 641 958">Display</th> <th data-bbox="641 913 1386 958">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 958 641 1003">Mode</td> <td data-bbox="641 958 1386 1003">MC compensation mode</td> </tr> <tr> <td data-bbox="336 1003 641 1059">Bias</td> <td data-bbox="641 1003 1386 1059">MC DC bias</td> </tr> </tbody> </table> <p data-bbox="288 1104 480 1133">Setting:[Mode]</p> <ol data-bbox="308 1137 1101 1169" style="list-style-type: none"> 1. Select the item. The screen for executing each item is displayed. <table border="1" data-bbox="336 1182 1386 1355"> <thead> <tr> <th data-bbox="336 1182 641 1227">Display</th> <th data-bbox="641 1182 1386 1227">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1227 641 1305">Auto</td> <td data-bbox="641 1227 1386 1305">Each color radical semi- value display and a degree setup of a standard value</td> </tr> <tr> <td data-bbox="336 1305 641 1355">Manual</td> <td data-bbox="641 1305 1386 1355">A value setup of each color</td> </tr> </tbody> </table> <p data-bbox="288 1368 512 1400">Initial setting: Auto</p>	Display	Description	Base	MC DC bias	Protect Table	Drum protection control table	Drum Aging	Aging for an electrification roller	Display	Description	Mode	MC compensation mode	Bias	MC DC bias	Display	Description	Auto	Each color radical semi- value display and a degree setup of a standard value	Manual	A value setup of each color
Display	Description																				
Base	MC DC bias																				
Protect Table	Drum protection control table																				
Drum Aging	Aging for an electrification roller																				
Display	Description																				
Mode	MC compensation mode																				
Bias	MC DC bias																				
Display	Description																				
Auto	Each color radical semi- value display and a degree setup of a standard value																				
Manual	A value setup of each color																				

Item No.	Description																																							
U100	Setting:[Bias]																																							
	1. Select an item to be set.																																							
	2. Change the setting value using the +/- keys or numeric keys.																																							
	<table border="1"> <thead> <tr> <th data-bbox="336 367 531 434">Display</th> <th data-bbox="531 367 1062 434">Description</th> <th data-bbox="1062 367 1230 434">Setting range</th> <th data-bbox="1230 367 1385 434">Initial setting</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 434 531 479">1st</td> <td data-bbox="531 434 1062 479">Manual adjustment value (1st)</td> <td data-bbox="1062 434 1230 479">0 to 250</td> <td data-bbox="1230 434 1385 479">145</td> </tr> <tr> <td data-bbox="336 479 531 524">2nd</td> <td data-bbox="531 479 1062 524">Manual adjustment value (2nd)</td> <td data-bbox="1062 479 1230 524">0 to 250</td> <td data-bbox="1230 479 1385 524">145</td> </tr> <tr> <td data-bbox="336 524 531 568">3rd</td> <td data-bbox="531 524 1062 568">Manual adjustment value (3rd)</td> <td data-bbox="1062 524 1230 568">0 to 250</td> <td data-bbox="1230 524 1385 568">145</td> </tr> <tr> <td data-bbox="336 568 531 613">4th</td> <td data-bbox="531 568 1062 613">Manual adjustment value (4th)</td> <td data-bbox="1062 568 1230 613">0 to 250</td> <td data-bbox="1230 568 1385 613">145</td> </tr> <tr> <td data-bbox="336 613 531 658">Default(1st)</td> <td data-bbox="531 613 1062 658">Manual adjustment base value (1st)</td> <td data-bbox="1062 613 1230 658">0 to 250</td> <td data-bbox="1230 613 1385 658">-</td> </tr> <tr> <td data-bbox="336 658 531 703">Default(2nd)</td> <td data-bbox="531 658 1062 703">Manual adjustment base value (2nd)</td> <td data-bbox="1062 658 1230 703">0 to 250</td> <td data-bbox="1230 658 1385 703">-</td> </tr> <tr> <td data-bbox="336 703 531 748">Default(3rd)</td> <td data-bbox="531 703 1062 748">Manual adjustment base value (3rd)</td> <td data-bbox="1062 703 1230 748">0 to 250</td> <td data-bbox="1230 703 1385 748">-</td> </tr> <tr> <td data-bbox="336 748 531 824">Default(4th)</td> <td data-bbox="531 748 1062 824">Manual adjustment base value (4th)</td> <td data-bbox="1062 748 1230 824">0 to 250</td> <td data-bbox="1230 748 1385 824">-</td> </tr> </tbody> </table>				Display	Description	Setting range	Initial setting	1st	Manual adjustment value (1st)	0 to 250	145	2nd	Manual adjustment value (2nd)	0 to 250	145	3rd	Manual adjustment value (3rd)	0 to 250	145	4th	Manual adjustment value (4th)	0 to 250	145	Default(1st)	Manual adjustment base value (1st)	0 to 250	-	Default(2nd)	Manual adjustment base value (2nd)	0 to 250	-	Default(3rd)	Manual adjustment base value (3rd)	0 to 250	-	Default(4th)	Manual adjustment base value (4th)	0 to 250	-
	Display	Description	Setting range	Initial setting																																				
	1st	Manual adjustment value (1st)	0 to 250	145																																				
	2nd	Manual adjustment value (2nd)	0 to 250	145																																				
	3rd	Manual adjustment value (3rd)	0 to 250	145																																				
	4th	Manual adjustment value (4th)	0 to 250	145																																				
	Default(1st)	Manual adjustment base value (1st)	0 to 250	-																																				
	Default(2nd)	Manual adjustment base value (2nd)	0 to 250	-																																				
	Default(3rd)	Manual adjustment base value (3rd)	0 to 250	-																																				
	Default(4th)	Manual adjustment base value (4th)	0 to 250	-																																				
	3. Press the start key. The value is set.																																							
	Setting:[Bias]																																							
1. Select an item to be set.																																								
2. Change the setting value using the +/- keys or numeric keys.																																								
<table border="1"> <thead> <tr> <th data-bbox="336 981 531 1048">Display</th> <th data-bbox="531 981 1062 1048">Description</th> <th data-bbox="1062 981 1230 1048">Setting range</th> <th data-bbox="1230 981 1385 1048">Initial setting</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1048 531 1093">1st</td> <td data-bbox="531 1048 1062 1093">MC DC bias (1st)</td> <td data-bbox="1062 1048 1230 1093">0 to 250</td> <td data-bbox="1230 1048 1385 1093">145</td> </tr> <tr> <td data-bbox="336 1093 531 1137">2nd</td> <td data-bbox="531 1093 1062 1137">MC DC bias (2nd)</td> <td data-bbox="1062 1093 1230 1137">0 to 250</td> <td data-bbox="1230 1093 1385 1137">145</td> </tr> <tr> <td data-bbox="336 1137 531 1182">3rd</td> <td data-bbox="531 1137 1062 1182">MC DC bias (3rd)</td> <td data-bbox="1062 1137 1230 1182">0 to 250</td> <td data-bbox="1230 1137 1385 1182">145</td> </tr> <tr> <td data-bbox="336 1182 531 1294">4th</td> <td data-bbox="531 1182 1062 1294">MC DC bias (4th)</td> <td data-bbox="1062 1182 1230 1294">0 to 250</td> <td data-bbox="1230 1182 1385 1294">145</td> </tr> </tbody> </table>				Display	Description	Setting range	Initial setting	1st	MC DC bias (1st)	0 to 250	145	2nd	MC DC bias (2nd)	0 to 250	145	3rd	MC DC bias (3rd)	0 to 250	145	4th	MC DC bias (4th)	0 to 250	145																	
Display	Description	Setting range	Initial setting																																					
1st	MC DC bias (1st)	0 to 250	145																																					
2nd	MC DC bias (2nd)	0 to 250	145																																					
3rd	MC DC bias (3rd)	0 to 250	145																																					
4th	MC DC bias (4th)	0 to 250	145																																					
3. Press the start key. The value is set.																																								
Supplement																																								
While this maintenance item is being executed, copying from an original is available in interrupt copying mode (which is activated by pressing the system menu key).																																								

Item No.	Description												
U100	<p data-bbox="288 241 571 271">Setting:[Protect table]</p> <p data-bbox="308 277 624 306">1. Select an item to be set.</p> <table border="1" data-bbox="336 320 1386 465"> <thead> <tr> <th data-bbox="336 320 531 365">Display</th> <th data-bbox="531 320 1386 365">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 365 531 409">Mode0</td> <td data-bbox="531 365 1386 409">It changes by drum drive time.</td> </tr> <tr> <td data-bbox="336 409 531 465">Mode1</td> <td data-bbox="531 409 1386 465">Initial fixation</td> </tr> </tbody> </table> <p data-bbox="288 479 539 508">Initial setting: Mode0</p> <p data-bbox="308 515 767 544">2. Press the start key. The value is set.</p> <p data-bbox="288 584 563 613">Setting:[Drum Aging]</p> <p data-bbox="308 620 624 649">1. Select an item to be set.</p> <table border="1" data-bbox="336 663 1386 808"> <thead> <tr> <th data-bbox="336 663 531 707">Display</th> <th data-bbox="531 663 1386 707">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 707 531 752">On</td> <td data-bbox="531 707 1386 752">with aging (it operates by lapsed time)</td> </tr> <tr> <td data-bbox="336 752 531 808">Off</td> <td data-bbox="531 752 1386 808">with not aging</td> </tr> </tbody> </table> <p data-bbox="288 822 494 851">Initial setting: Off</p> <p data-bbox="308 857 767 887">2. Press the start key. The value is set.</p> <p data-bbox="288 927 440 956">Completion</p> <p data-bbox="288 963 1426 1028">Press the stop key when main charger output stops. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Mode0	It changes by drum drive time.	Mode1	Initial fixation	Display	Description	On	with aging (it operates by lapsed time)	Off	with not aging
Display	Description												
Mode0	It changes by drum drive time.												
Mode1	Initial fixation												
Display	Description												
On	with aging (it operates by lapsed time)												
Off	with not aging												

Item No.	Description																																																						
U101	<p data-bbox="290 241 836 275">Setting the voltage for the primary transfer</p> <p data-bbox="290 309 440 342">Description</p> <p data-bbox="290 344 855 378">Sets the control voltage for the primary transfer.</p> <p data-bbox="290 380 400 414">Purpose</p> <p data-bbox="290 416 1262 450">To change the setting when any density problems, such as too dark or light, occur.</p> <p data-bbox="290 483 387 517">Method</p> <ol data-bbox="308 519 1102 584" style="list-style-type: none"> 1. Press the start key. 2. Select the item. The screen for executing each item is displayed. <table border="1" data-bbox="336 600 1401 842"> <thead> <tr> <th data-bbox="336 600 639 645">Display</th> <th data-bbox="639 600 1401 645">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 645 639 689">Base</td> <td data-bbox="639 645 1401 689">Standard value</td> </tr> <tr> <td data-bbox="336 689 639 734">1st side</td> <td data-bbox="639 689 1401 734">Correction value of single-side printing</td> </tr> <tr> <td data-bbox="336 734 639 779">2nd side</td> <td data-bbox="639 734 1401 779">Correction value of duplex printing</td> </tr> <tr> <td data-bbox="336 779 639 842">B/W</td> <td data-bbox="639 779 1401 842">Correction value of monochrome printing</td> </tr> </tbody> </table> <p data-bbox="290 891 480 925">Setting: [Base]</p> <ol data-bbox="308 927 1198 992" style="list-style-type: none"> 1. Select the item to be set. 2. Change the setting value using the cursor left/right keys or numeric keys. <table border="1" data-bbox="336 1005 1401 1198"> <thead> <tr> <th data-bbox="336 1005 528 1099" rowspan="2">Display</th> <th data-bbox="528 1005 927 1099" rowspan="2">Description</th> <th data-bbox="927 1005 1094 1099" rowspan="2">Setting range</th> <th colspan="2" data-bbox="1094 1005 1401 1050">Initial setting</th> </tr> <tr> <th data-bbox="1094 1050 1246 1099">20ppm</th> <th data-bbox="1246 1050 1401 1099">25ppm</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1099 528 1144">Full</td> <td data-bbox="528 1099 927 1144">Full speed printing</td> <td data-bbox="927 1099 1094 1144">0 to 100</td> <td data-bbox="1094 1099 1246 1144">40</td> <td data-bbox="1246 1099 1401 1144">45</td> </tr> <tr> <td data-bbox="336 1144 528 1198">Half</td> <td data-bbox="528 1144 927 1198">Half speed printing</td> <td data-bbox="927 1144 1094 1198">0 to 100</td> <td data-bbox="1094 1144 1246 1198">25</td> <td data-bbox="1246 1144 1401 1198">25</td> </tr> </tbody> </table> <ol data-bbox="308 1211 767 1245" style="list-style-type: none"> 3. Press the start key. The value is set. <p data-bbox="290 1279 647 1312">Setting: [1st side/02nd side]</p> <ol data-bbox="308 1314 1198 1379" style="list-style-type: none"> 1. Select the item to be set. 2. Change the setting value using the cursor left/right keys or numeric keys. <table border="1" data-bbox="336 1393 1401 1682"> <thead> <tr> <th data-bbox="336 1393 528 1487" rowspan="2">Display</th> <th data-bbox="528 1393 927 1487" rowspan="2">Description</th> <th data-bbox="927 1393 1094 1487" rowspan="2">Setting range</th> <th colspan="2" data-bbox="1094 1393 1401 1438">Initial setting</th> </tr> <tr> <th data-bbox="1094 1438 1246 1487">20ppm</th> <th data-bbox="1246 1438 1401 1487">25ppm</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1487 528 1532">1st</td> <td data-bbox="528 1487 927 1532">Correction value (Yellow)</td> <td data-bbox="927 1487 1094 1532">-50 to 50</td> <td data-bbox="1094 1487 1246 1532">0/-2</td> <td data-bbox="1246 1487 1401 1532">0/-3</td> </tr> <tr> <td data-bbox="336 1532 528 1576">2nd</td> <td data-bbox="528 1532 927 1576">Correction value (Cyan)</td> <td data-bbox="927 1532 1094 1576">-50 to 50</td> <td data-bbox="1094 1532 1246 1576">4/2</td> <td data-bbox="1246 1532 1401 1576">5/2</td> </tr> <tr> <td data-bbox="336 1576 528 1621">3rd</td> <td data-bbox="528 1576 927 1621">Correction value (Magenta)</td> <td data-bbox="927 1576 1094 1621">-50 to 50</td> <td data-bbox="1094 1576 1246 1621">4/2</td> <td data-bbox="1246 1576 1401 1621">0/2</td> </tr> <tr> <td data-bbox="336 1621 528 1682">4th</td> <td data-bbox="528 1621 927 1682">Correction value (Black)</td> <td data-bbox="927 1621 1094 1682">-50 to 50</td> <td data-bbox="1094 1621 1246 1682">4/2</td> <td data-bbox="1246 1621 1401 1682">5/2</td> </tr> </tbody> </table> <ol data-bbox="308 1695 767 1729" style="list-style-type: none"> 3. Press the start key. The value is set. 	Display	Description	Base	Standard value	1st side	Correction value of single-side printing	2nd side	Correction value of duplex printing	B/W	Correction value of monochrome printing	Display	Description	Setting range	Initial setting		20ppm	25ppm	Full	Full speed printing	0 to 100	40	45	Half	Half speed printing	0 to 100	25	25	Display	Description	Setting range	Initial setting		20ppm	25ppm	1st	Correction value (Yellow)	-50 to 50	0/-2	0/-3	2nd	Correction value (Cyan)	-50 to 50	4/2	5/2	3rd	Correction value (Magenta)	-50 to 50	4/2	0/2	4th	Correction value (Black)	-50 to 50	4/2	5/2
Display	Description																																																						
Base	Standard value																																																						
1st side	Correction value of single-side printing																																																						
2nd side	Correction value of duplex printing																																																						
B/W	Correction value of monochrome printing																																																						
Display	Description	Setting range	Initial setting																																																				
			20ppm	25ppm																																																			
Full	Full speed printing	0 to 100	40	45																																																			
Half	Half speed printing	0 to 100	25	25																																																			
Display	Description	Setting range	Initial setting																																																				
			20ppm	25ppm																																																			
1st	Correction value (Yellow)	-50 to 50	0/-2	0/-3																																																			
2nd	Correction value (Cyan)	-50 to 50	4/2	5/2																																																			
3rd	Correction value (Magenta)	-50 to 50	4/2	0/2																																																			
4th	Correction value (Black)	-50 to 50	4/2	5/2																																																			

Item No.	Description												
U101	<p data-bbox="288 241 469 271">Setting: [B/W]</p> <ol data-bbox="304 277 1198 342" style="list-style-type: none"> <li data-bbox="304 277 632 306">1. Select the item to be set. <li data-bbox="304 311 1198 342">2. Change the setting value using the cursor left/right keys or numeric keys. <table border="1" data-bbox="336 353 1401 499"> <thead> <tr> <th data-bbox="336 353 528 450" rowspan="2">Display</th> <th data-bbox="528 353 930 450" rowspan="2">Description</th> <th data-bbox="930 353 1094 450" rowspan="2">Setting range</th> <th colspan="2" data-bbox="1094 353 1401 398">Initial setting</th> </tr> <tr> <th data-bbox="1094 398 1249 450">20ppm</th> <th data-bbox="1249 398 1401 450">25ppm</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 450 528 499">Value</td> <td data-bbox="528 450 930 499">Correction value</td> <td data-bbox="930 450 1094 499">-50 to 50</td> <td data-bbox="1094 450 1249 499">24</td> <td data-bbox="1249 450 1401 499">30</td> </tr> </tbody> </table> <ol data-bbox="304 521 767 553" style="list-style-type: none"> <li data-bbox="304 521 767 553">3. Press the start key. The value is set. <p data-bbox="288 591 440 620">Completion</p> <p data-bbox="288 624 1254 656">Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Setting range	Initial setting		20ppm	25ppm	Value	Correction value	-50 to 50	24	30
Display	Description				Setting range	Initial setting							
		20ppm	25ppm										
Value	Correction value	-50 to 50	24	30									

Item No.	Description																																																
U106	<p data-bbox="288 241 871 275">Setting the voltage for the secondary transfer</p> <p data-bbox="288 309 440 342">Description</p> <p data-bbox="288 344 890 378">Sets the control voltage for the secondary transfer.</p> <p data-bbox="288 380 400 414">Purpose</p> <p data-bbox="288 416 1262 450">To change the setting when any density problems, such as too dark or light, occur.</p> <p data-bbox="288 483 387 517">Method</p> <ol data-bbox="308 519 1102 584" style="list-style-type: none"> 1. Press the start key. 2. Select the item. The screen for executing each item is displayed. <table border="1" data-bbox="336 595 1401 741"> <thead> <tr> <th data-bbox="336 595 639 640">Display</th> <th data-bbox="639 595 1401 640">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 640 639 685">Color</td> <td data-bbox="639 640 1401 685">Correction value of color printing</td> </tr> <tr> <td data-bbox="336 685 639 741">B/W</td> <td data-bbox="639 685 1401 741">Correction value of monochrome printing</td> </tr> </tbody> </table> <p data-bbox="288 790 485 824">Method:[Color]</p> <ol data-bbox="308 826 1102 860" style="list-style-type: none"> 1. Select the item. The screen for executing each item is displayed. <table border="1" data-bbox="336 871 1401 1207"> <thead> <tr> <th data-bbox="336 871 639 916">Display</th> <th data-bbox="639 871 1401 916">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 916 639 960">Light/Normal1</td> <td data-bbox="639 916 1401 960">Weight of paper (light to usual 1)</td> </tr> <tr> <td data-bbox="336 960 639 1005">Normal2/3</td> <td data-bbox="639 960 1401 1005">Weight of paper (usual 2 to 3)</td> </tr> <tr> <td data-bbox="336 1005 639 1050">Heavy1</td> <td data-bbox="639 1005 1401 1050">Weight of paper (heavy 1)</td> </tr> <tr> <td data-bbox="336 1050 639 1095">Heavy2-3</td> <td data-bbox="639 1050 1401 1095">Weight of paper (heavy 2 to 3)</td> </tr> <tr> <td data-bbox="336 1095 639 1140">OHP</td> <td data-bbox="639 1095 1401 1140">Kind of paper (OHP)</td> </tr> <tr> <td data-bbox="336 1140 639 1207">Coated</td> <td data-bbox="639 1140 1401 1207">Kind of paper (Coated paper)</td> </tr> </tbody> </table> <p data-bbox="288 1256 1010 1290">Method: [Light/Normal1 / Normal2/3 / Heavy1 / Heavy2-3]</p> <ol data-bbox="308 1292 1102 1326" style="list-style-type: none"> 1. Select the item. The screen for executing each item is displayed. <table border="1" data-bbox="336 1337 1401 1482"> <thead> <tr> <th data-bbox="336 1337 639 1382">Display</th> <th data-bbox="639 1337 1401 1382">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1382 639 1426">1st side</td> <td data-bbox="639 1382 1401 1426">Correction value of single-side printing</td> </tr> <tr> <td data-bbox="336 1426 639 1482">2nd side</td> <td data-bbox="639 1426 1401 1482">Correction value of duplex printing</td> </tr> </tbody> </table> <p data-bbox="288 1532 627 1565">Setting:[1st side/2nd side]</p> <ol data-bbox="308 1568 1198 1632" style="list-style-type: none"> 1. Select the item to be set. 2. Change the setting value using the cursor left/right keys or numeric keys. <table border="1" data-bbox="336 1644 1401 1991"> <thead> <tr> <th data-bbox="336 1644 564 1733" rowspan="2">Display</th> <th data-bbox="564 1644 900 1733" rowspan="2">Description</th> <th data-bbox="900 1644 1064 1733" rowspan="2">Setting range</th> <th colspan="2" data-bbox="1064 1644 1401 1688">Initial setting</th> </tr> <tr> <th data-bbox="1064 1688 1230 1733">20ppm</th> <th data-bbox="1230 1688 1401 1733">25ppm</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1733 564 1823">Width<160</td> <td data-bbox="564 1733 900 1823">width of paper<160</td> <td data-bbox="900 1733 1064 1823">0 to 200</td> <td data-bbox="1064 1733 1230 1823">66/68/51/43 70/72/54/45</td> <td data-bbox="1230 1733 1401 1823">83/85/64/43 88/90/68/45</td> </tr> <tr> <td data-bbox="336 1823 564 1912">160<=Width<220</td> <td data-bbox="564 1823 900 1912">160<= width of paper <220</td> <td data-bbox="900 1823 1064 1912">0 to 200</td> <td data-bbox="1064 1823 1230 1912">46/48/36/30 48/50/37/31</td> <td data-bbox="1230 1823 1401 1912">58/60/45/30 60/62/47/31</td> </tr> <tr> <td data-bbox="336 1912 564 1991">220<=Width</td> <td data-bbox="564 1912 900 1991">220<= width of paper</td> <td data-bbox="900 1912 1064 1991">0 to 200</td> <td data-bbox="1064 1912 1230 1991">34/35/26/22 32/34/25/22</td> <td data-bbox="1230 1912 1401 1991">42/44/33/22 40/42/32/21</td> </tr> </tbody> </table> <ol data-bbox="308 2002 767 2036" style="list-style-type: none"> 3. Press the start key. The value is set. 	Display	Description	Color	Correction value of color printing	B/W	Correction value of monochrome printing	Display	Description	Light/Normal1	Weight of paper (light to usual 1)	Normal2/3	Weight of paper (usual 2 to 3)	Heavy1	Weight of paper (heavy 1)	Heavy2-3	Weight of paper (heavy 2 to 3)	OHP	Kind of paper (OHP)	Coated	Kind of paper (Coated paper)	Display	Description	1st side	Correction value of single-side printing	2nd side	Correction value of duplex printing	Display	Description	Setting range	Initial setting		20ppm	25ppm	Width<160	width of paper<160	0 to 200	66/68/51/43 70/72/54/45	83/85/64/43 88/90/68/45	160<=Width<220	160<= width of paper <220	0 to 200	46/48/36/30 48/50/37/31	58/60/45/30 60/62/47/31	220<=Width	220<= width of paper	0 to 200	34/35/26/22 32/34/25/22	42/44/33/22 40/42/32/21
Display	Description																																																
Color	Correction value of color printing																																																
B/W	Correction value of monochrome printing																																																
Display	Description																																																
Light/Normal1	Weight of paper (light to usual 1)																																																
Normal2/3	Weight of paper (usual 2 to 3)																																																
Heavy1	Weight of paper (heavy 1)																																																
Heavy2-3	Weight of paper (heavy 2 to 3)																																																
OHP	Kind of paper (OHP)																																																
Coated	Kind of paper (Coated paper)																																																
Display	Description																																																
1st side	Correction value of single-side printing																																																
2nd side	Correction value of duplex printing																																																
Display	Description	Setting range	Initial setting																																														
			20ppm	25ppm																																													
Width<160	width of paper<160	0 to 200	66/68/51/43 70/72/54/45	83/85/64/43 88/90/68/45																																													
160<=Width<220	160<= width of paper <220	0 to 200	46/48/36/30 48/50/37/31	58/60/45/30 60/62/47/31																																													
220<=Width	220<= width of paper	0 to 200	34/35/26/22 32/34/25/22	42/44/33/22 40/42/32/21																																													

Item No.	Description																																																																
U106	<p>Setting:[OHP/Coated]</p> <p>1. Select the item to be set.</p> <p>2. Change the setting value using the cursor left/right keys or numeric keys.</p> <table border="1"> <thead> <tr> <th rowspan="2">Display</th> <th rowspan="2">Description</th> <th rowspan="2">Setting range</th> <th colspan="2">Initial setting</th> </tr> <tr> <th>20ppm</th> <th>25ppm</th> </tr> </thead> <tbody> <tr> <td>Width<160</td> <td>width of paper<160</td> <td>0 to 200</td> <td>40/59</td> <td>40/59</td> </tr> <tr> <td>160<=Width<220</td> <td>160<= width of paper <220</td> <td>0 to 200</td> <td>33/42</td> <td>33/42</td> </tr> <tr> <td>220<=Width</td> <td>220<= width of paper</td> <td>0 to 200</td> <td>25/31</td> <td>25/31</td> </tr> </tbody> </table> <p>3. Press the start key. The value is set.</p> <p>Method:[B/W]</p> <p>1. Select the item. The screen for executing each item is displayed.</p> <table border="1"> <thead> <tr> <th>Display</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>Light/Normal1</td> <td>Weight of paper (light to usual 1)</td> </tr> <tr> <td>Heavy1</td> <td>Weight of paper (heavy 1)</td> </tr> <tr> <td>Heavy2-3</td> <td>Weight of paper (heavy 2 to 3)</td> </tr> </tbody> </table> <p>Method: [Light/Normal1 / Heavy1 / Heavy2-3]</p> <p>1. Select the item. The screen for executing each item is displayed.</p> <table border="1"> <thead> <tr> <th>Display</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>1st side</td> <td>Correction value of single-side printing</td> </tr> <tr> <td>2nd side</td> <td>Correction value of duplex printing</td> </tr> </tbody> </table> <p>Setting:[1st side/2nd side]</p> <p>1. Select the item to be set.</p> <p>2. Change the setting value using the cursor left/right keys or numeric keys.</p> <table border="1"> <thead> <tr> <th rowspan="2">Display</th> <th rowspan="2">Description</th> <th rowspan="2">Setting range</th> <th colspan="2">Initial setting</th> </tr> <tr> <th>20ppm</th> <th>25ppm</th> </tr> </thead> <tbody> <tr> <td rowspan="2">Width<160</td> <td rowspan="2">width of paper<160</td> <td rowspan="2">0 to 200</td> <td>62/48/43</td> <td>78/60/43</td> </tr> <tr> <td>66/51/45</td> <td>83/64/45</td> </tr> <tr> <td rowspan="2">160<=Width<220</td> <td rowspan="2">160<= width of paper <220</td> <td rowspan="2">0 to 200</td> <td>42/33/30</td> <td>53/41/30</td> </tr> <tr> <td>44/34/31</td> <td>55/43/31</td> </tr> <tr> <td rowspan="2">220<=Width</td> <td rowspan="2">220<= width of paper</td> <td rowspan="2">0 to 200</td> <td>32/25/22</td> <td>40/31/22</td> </tr> <tr> <td>32/24/22</td> <td>38/30/21</td> </tr> </tbody> </table> <p>3. Press the start key. The value is set.</p> <p>Completion</p> <p>Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Setting range	Initial setting		20ppm	25ppm	Width<160	width of paper<160	0 to 200	40/59	40/59	160<=Width<220	160<= width of paper <220	0 to 200	33/42	33/42	220<=Width	220<= width of paper	0 to 200	25/31	25/31	Display	Description	Light/Normal1	Weight of paper (light to usual 1)	Heavy1	Weight of paper (heavy 1)	Heavy2-3	Weight of paper (heavy 2 to 3)	Display	Description	1st side	Correction value of single-side printing	2nd side	Correction value of duplex printing	Display	Description	Setting range	Initial setting		20ppm	25ppm	Width<160	width of paper<160	0 to 200	62/48/43	78/60/43	66/51/45	83/64/45	160<=Width<220	160<= width of paper <220	0 to 200	42/33/30	53/41/30	44/34/31	55/43/31	220<=Width	220<= width of paper	0 to 200	32/25/22	40/31/22	32/24/22	38/30/21
	Display				Description	Setting range	Initial setting																																																										
		20ppm	25ppm																																																														
	Width<160	width of paper<160	0 to 200	40/59	40/59																																																												
	160<=Width<220	160<= width of paper <220	0 to 200	33/42	33/42																																																												
	220<=Width	220<= width of paper	0 to 200	25/31	25/31																																																												
	Display	Description																																																															
	Light/Normal1	Weight of paper (light to usual 1)																																																															
	Heavy1	Weight of paper (heavy 1)																																																															
	Heavy2-3	Weight of paper (heavy 2 to 3)																																																															
Display	Description																																																																
1st side	Correction value of single-side printing																																																																
2nd side	Correction value of duplex printing																																																																
Display	Description	Setting range	Initial setting																																																														
			20ppm	25ppm																																																													
Width<160	width of paper<160	0 to 200	62/48/43	78/60/43																																																													
			66/51/45	83/64/45																																																													
160<=Width<220	160<= width of paper <220	0 to 200	42/33/30	53/41/30																																																													
			44/34/31	55/43/31																																																													
220<=Width	220<= width of paper	0 to 200	32/25/22	40/31/22																																																													
			32/24/22	38/30/21																																																													

Item No.	Description																																													
U107	<p data-bbox="288 241 1011 275">Setting the voltage for the intermediate transfer cleaning</p> <p data-bbox="288 311 440 340">Description</p> <p data-bbox="288 344 1050 376">Sets the control voltage for the intermediate transfer cleaning.</p> <p data-bbox="288 383 400 412">Purpose</p> <p data-bbox="288 416 1385 448">To change the setting when the offset by a defective cleaning of the transfer belt is generate.</p> <p data-bbox="288 486 387 515">Method</p> <ol data-bbox="304 519 1101 584" style="list-style-type: none"> 1. Press the start key. 2. Select the item. The screen for executing each item is displayed. <table border="1" data-bbox="336 595 1401 790"> <thead> <tr> <th data-bbox="336 595 639 640">Display</th> <th data-bbox="639 595 1401 640">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 640 639 685">Belt(A)</td> <td data-bbox="639 640 1401 685">Correction value of belt A</td> </tr> <tr> <td data-bbox="336 685 639 730">Belt(B)</td> <td data-bbox="639 685 1401 730">Correction value of belt B</td> </tr> <tr> <td data-bbox="336 730 639 790">Belt(C)</td> <td data-bbox="639 730 1401 790">Correction value of belt C</td> </tr> </tbody> </table> <p data-bbox="288 831 383 860">Setting</p> <ol data-bbox="304 864 1198 929" style="list-style-type: none"> 1. Select the item to be set. 2. Change the setting value using the cursor left/right keys or numeric keys. <table border="1" data-bbox="336 943 1401 1364"> <thead> <tr> <th data-bbox="336 943 517 1039" rowspan="2">Display</th> <th data-bbox="517 943 957 1039" rowspan="2">Description</th> <th data-bbox="957 943 1096 1039" rowspan="2">Setting range</th> <th colspan="2" data-bbox="1096 943 1401 987">Initial setting</th> </tr> <tr> <th data-bbox="1096 987 1251 1039">20ppm</th> <th data-bbox="1251 987 1401 1039">25ppm</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1039 517 1084">Full</td> <td data-bbox="517 1039 957 1084">Full speed printing of color</td> <td data-bbox="957 1039 1096 1084">0 to 200</td> <td data-bbox="1096 1039 1251 1084">10/72/72</td> <td data-bbox="1251 1039 1401 1084">13/90/90</td> </tr> <tr> <td data-bbox="336 1084 517 1128">Half</td> <td data-bbox="517 1084 957 1128">Half speed printing of color</td> <td data-bbox="957 1084 1096 1128">0 to 200</td> <td data-bbox="1096 1084 1251 1128">9/45/45</td> <td data-bbox="1251 1084 1401 1128">9/45/45</td> </tr> <tr> <td data-bbox="336 1128 517 1173">3/4</td> <td data-bbox="517 1128 957 1173">75% of full speed printing of color</td> <td data-bbox="957 1128 1096 1173">0 to 200</td> <td data-bbox="1096 1128 1251 1173">9/54/72</td> <td data-bbox="1251 1128 1401 1173">10/68/90</td> </tr> <tr> <td data-bbox="336 1173 517 1218">B/W Full</td> <td data-bbox="517 1173 957 1218">Full speed printing of monochrome</td> <td data-bbox="957 1173 1096 1218">0 to 200</td> <td data-bbox="1096 1173 1251 1218">10/60/60</td> <td data-bbox="1251 1173 1401 1218">13/90/90</td> </tr> <tr> <td data-bbox="336 1218 517 1263">B/W Half</td> <td data-bbox="517 1218 957 1263">Half speed printing of monochrome</td> <td data-bbox="957 1218 1096 1263">0 to 200</td> <td data-bbox="1096 1218 1251 1263">9/42/42</td> <td data-bbox="1251 1218 1401 1263">9/68/68</td> </tr> <tr> <td data-bbox="336 1263 517 1364">B/W 3/4</td> <td data-bbox="517 1263 957 1364">75% of full speed printing of monochrome</td> <td data-bbox="957 1263 1096 1364">0 to 200</td> <td data-bbox="1096 1263 1251 1364">9/35/35</td> <td data-bbox="1251 1263 1401 1364">10/45/45</td> </tr> </tbody> </table> <ol data-bbox="304 1373 767 1404" style="list-style-type: none"> 3. Press the start key. The value is set. <p data-bbox="288 1442 440 1471">Completion</p> <p data-bbox="288 1476 1254 1507">Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Belt(A)	Correction value of belt A	Belt(B)	Correction value of belt B	Belt(C)	Correction value of belt C	Display	Description	Setting range	Initial setting		20ppm	25ppm	Full	Full speed printing of color	0 to 200	10/72/72	13/90/90	Half	Half speed printing of color	0 to 200	9/45/45	9/45/45	3/4	75% of full speed printing of color	0 to 200	9/54/72	10/68/90	B/W Full	Full speed printing of monochrome	0 to 200	10/60/60	13/90/90	B/W Half	Half speed printing of monochrome	0 to 200	9/42/42	9/68/68	B/W 3/4	75% of full speed printing of monochrome	0 to 200	9/35/35	10/45/45
Display	Description																																													
Belt(A)	Correction value of belt A																																													
Belt(B)	Correction value of belt B																																													
Belt(C)	Correction value of belt C																																													
Display	Description	Setting range	Initial setting																																											
			20ppm	25ppm																																										
Full	Full speed printing of color	0 to 200	10/72/72	13/90/90																																										
Half	Half speed printing of color	0 to 200	9/45/45	9/45/45																																										
3/4	75% of full speed printing of color	0 to 200	9/54/72	10/68/90																																										
B/W Full	Full speed printing of monochrome	0 to 200	10/60/60	13/90/90																																										
B/W Half	Half speed printing of monochrome	0 to 200	9/42/42	9/68/68																																										
B/W 3/4	75% of full speed printing of monochrome	0 to 200	9/35/35	10/45/45																																										

Item No.	Description																																												
U108	<p data-bbox="288 241 651 275">Setting separation shift bias</p> <p data-bbox="288 311 440 340">Description</p> <p data-bbox="288 344 983 376">Adjusts output of separation shift bias and ON/OFF timing.</p> <p data-bbox="288 380 400 409">Purpose</p> <p data-bbox="288 414 994 445">To set when the separated malfunction of the paper occurs.</p> <p data-bbox="288 483 387 512">Method</p> <ol data-bbox="304 517 1102 584" style="list-style-type: none"> 1. Press the start key. 2. Select the item. The screen for executing each item is displayed. <table border="1" data-bbox="336 595 1407 884"> <thead> <tr> <th data-bbox="336 595 639 640">Display</th> <th data-bbox="639 595 1407 640">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 640 639 685">Light/Normal1</td> <td data-bbox="639 640 1407 685">Weight of paper (light to usual 1)</td> </tr> <tr> <td data-bbox="336 685 639 730">Normal2/3</td> <td data-bbox="639 685 1407 730">Weight of paper (usual 2 to 3)</td> </tr> <tr> <td data-bbox="336 730 639 775">Heavy1</td> <td data-bbox="639 730 1407 775">Weight of paper (heavy 1)</td> </tr> <tr> <td data-bbox="336 775 639 819">Coated</td> <td data-bbox="639 775 1407 819">Kind of paper (Coated paper)</td> </tr> <tr> <td data-bbox="336 819 639 884">Timing</td> <td data-bbox="639 819 1407 884">Setting of the separation timing</td> </tr> </tbody> </table> <p data-bbox="288 943 387 972">Method</p> <ol data-bbox="304 976 1102 1008" style="list-style-type: none"> 1. Select the item. The screen for executing each item is displayed. <table border="1" data-bbox="336 1019 1407 1189"> <thead> <tr> <th data-bbox="336 1019 580 1093">Display</th> <th data-bbox="580 1019 1059 1093">Description</th> <th data-bbox="1059 1019 1225 1093">Setting range</th> <th data-bbox="1225 1019 1407 1093">Initial setting</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1093 580 1137">1st side</td> <td data-bbox="580 1093 1059 1137">Correction value of single-side printing</td> <td data-bbox="1059 1093 1225 1137">0 to 40</td> <td data-bbox="1225 1093 1407 1137">22/10/10/10</td> </tr> <tr> <td data-bbox="336 1137 580 1189">2nd side</td> <td data-bbox="580 1137 1059 1189">Correction value of duplex printing</td> <td data-bbox="1059 1137 1225 1189">0 to 40</td> <td data-bbox="1225 1137 1407 1189">22/12/10/10</td> </tr> </tbody> </table> <p data-bbox="288 1247 383 1276">Setting</p> <ol data-bbox="304 1281 1198 1348" style="list-style-type: none"> 1. Select the item to be set. 2. Change the setting value using the cursor left/right keys or numeric keys. <table border="1" data-bbox="336 1359 1407 1637"> <thead> <tr> <th data-bbox="336 1359 580 1442">Display</th> <th data-bbox="580 1359 1059 1442">Description</th> <th data-bbox="1059 1359 1225 1442">Setting range</th> <th data-bbox="1225 1359 1407 1442">Initial setting</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1442 580 1487">Add Normal Lead</td> <td data-bbox="580 1442 1059 1487">for the leading edge on paper</td> <td data-bbox="1059 1442 1225 1487">0 to 20</td> <td data-bbox="1225 1442 1407 1487">3</td> </tr> <tr> <td data-bbox="336 1487 580 1532">On Timing 1</td> <td data-bbox="580 1487 1059 1532">Adjustment of the ON Timing 1</td> <td data-bbox="1059 1487 1225 1532">-100 to 100</td> <td data-bbox="1225 1487 1407 1532">0</td> </tr> <tr> <td data-bbox="336 1532 580 1576">On Timing 2</td> <td data-bbox="580 1532 1059 1576">Adjustment of the ON Timing 2</td> <td data-bbox="1059 1532 1225 1576">-100 to 100</td> <td data-bbox="1225 1532 1407 1576">0</td> </tr> <tr> <td data-bbox="336 1576 580 1637">Off Timing</td> <td data-bbox="580 1576 1059 1637">Adjustment of the OFF Timing</td> <td data-bbox="1059 1576 1225 1637">-100 to 100</td> <td data-bbox="1225 1576 1407 1637">100</td> </tr> </tbody> </table> <ol data-bbox="304 1659 767 1691" style="list-style-type: none"> 3. Press the start key. The value is set. <p data-bbox="288 1729 440 1758">Completion</p> <p data-bbox="288 1762 1254 1794">Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Light/Normal1	Weight of paper (light to usual 1)	Normal2/3	Weight of paper (usual 2 to 3)	Heavy1	Weight of paper (heavy 1)	Coated	Kind of paper (Coated paper)	Timing	Setting of the separation timing	Display	Description	Setting range	Initial setting	1st side	Correction value of single-side printing	0 to 40	22/10/10/10	2nd side	Correction value of duplex printing	0 to 40	22/12/10/10	Display	Description	Setting range	Initial setting	Add Normal Lead	for the leading edge on paper	0 to 20	3	On Timing 1	Adjustment of the ON Timing 1	-100 to 100	0	On Timing 2	Adjustment of the ON Timing 2	-100 to 100	0	Off Timing	Adjustment of the OFF Timing	-100 to 100	100
Display	Description																																												
Light/Normal1	Weight of paper (light to usual 1)																																												
Normal2/3	Weight of paper (usual 2 to 3)																																												
Heavy1	Weight of paper (heavy 1)																																												
Coated	Kind of paper (Coated paper)																																												
Timing	Setting of the separation timing																																												
Display	Description	Setting range	Initial setting																																										
1st side	Correction value of single-side printing	0 to 40	22/10/10/10																																										
2nd side	Correction value of duplex printing	0 to 40	22/12/10/10																																										
Display	Description	Setting range	Initial setting																																										
Add Normal Lead	for the leading edge on paper	0 to 20	3																																										
On Timing 1	Adjustment of the ON Timing 1	-100 to 100	0																																										
On Timing 2	Adjustment of the ON Timing 2	-100 to 100	0																																										
Off Timing	Adjustment of the OFF Timing	-100 to 100	100																																										

Item No.	Description										
U111	<p data-bbox="290 241 670 273">Checking the drum drive time</p> <p data-bbox="290 311 440 342">Description</p> <p data-bbox="290 344 1426 412">Displays the drum drive time for checking a figure, which is used as a reference when correcting the high voltage based on time.</p> <p data-bbox="290 414 400 445">Purpose</p> <p data-bbox="290 448 596 479">To check the drum status.</p> <p data-bbox="290 517 387 548">Method</p> <ol data-bbox="308 551 922 618" style="list-style-type: none"> 1. Press the start key. 2. Select the item. The drum drive time is displayed. <table border="1" data-bbox="336 631 1401 871"> <thead> <tr> <th data-bbox="336 631 641 676">Display</th> <th data-bbox="641 631 1401 676">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 676 641 721">C</td> <td data-bbox="641 676 1401 721">Cyan drum drive time</td> </tr> <tr> <td data-bbox="336 721 641 766">M</td> <td data-bbox="641 721 1401 766">Magenta drum drive time</td> </tr> <tr> <td data-bbox="336 766 641 810">Y</td> <td data-bbox="641 766 1401 810">Yellow drum drive time</td> </tr> <tr> <td data-bbox="336 810 641 855">K</td> <td data-bbox="641 810 1401 855">Black drum drive time</td> </tr> </tbody> </table> <p data-bbox="290 925 384 956">Setting</p> <ol data-bbox="308 958 1233 1025" style="list-style-type: none"> 1. Change the drum drive time using the cursor left/right keys or numeric keys. 2. Press the start key. The drum drive time is set. <p data-bbox="290 1064 440 1095">Completion</p> <p data-bbox="290 1097 1256 1128">Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	C	Cyan drum drive time	M	Magenta drum drive time	Y	Yellow drum drive time	K	Black drum drive time
Display	Description										
C	Cyan drum drive time										
M	Magenta drum drive time										
Y	Yellow drum drive time										
K	Black drum drive time										

Item No.	Description																
U118	<p>Displaying the drum history</p> <p>Description Displays the past record of machine number and the drum counter.</p> <p>Purpose To check the count value of machine number and the drum counter.</p> <p>Method</p> <ol style="list-style-type: none"> Press the start key. The each history displayed by five cases. <table border="1" data-bbox="336 562 1401 801"> <thead> <tr> <th>Display</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>C</td> <td>Cyan drum past record</td> </tr> <tr> <td>M</td> <td>Magenta drum past record</td> </tr> <tr> <td>Y</td> <td>Yellow drum past record</td> </tr> <tr> <td>K</td> <td>Black drum past record</td> </tr> </tbody> </table> <ol style="list-style-type: none"> The history of a machine number and a drum counter for each color is displayed by three cases.T <table border="1" data-bbox="336 920 1401 1061"> <thead> <tr> <th>Display</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>Machine History 1 - 3</td> <td>Historical records of the machine number</td> </tr> <tr> <td>Cnt History 1 - 3</td> <td>Historical records of drum counter</td> </tr> </tbody> </table> <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	C	Cyan drum past record	M	Magenta drum past record	Y	Yellow drum past record	K	Black drum past record	Display	Description	Machine History 1 - 3	Historical records of the machine number	Cnt History 1 - 3	Historical records of drum counter
Display	Description																
C	Cyan drum past record																
M	Magenta drum past record																
Y	Yellow drum past record																
K	Black drum past record																
Display	Description																
Machine History 1 - 3	Historical records of the machine number																
Cnt History 1 - 3	Historical records of drum counter																
U123	<p>Displaying the transfer belt unit history</p> <p>Description Displays the past record of machine number and the transfer belt unit counter.</p> <p>Purpose To check the count value of machine number and the transfer counter.</p> <p>Method</p> <ol style="list-style-type: none"> Press the start key. The history of a machine number and a transfer belt unit counter for each color is displayed by three cases. <table border="1" data-bbox="320 1597 1417 1738"> <thead> <tr> <th>Display</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>Machine History 1 - 3</td> <td>Historical records of the machine number</td> </tr> <tr> <td>Count History 1 - 3</td> <td>Historical records of transfer belt unit counter</td> </tr> </tbody> </table> <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Machine History 1 - 3	Historical records of the machine number	Count History 1 - 3	Historical records of transfer belt unit counter										
Display	Description																
Machine History 1 - 3	Historical records of the machine number																
Count History 1 - 3	Historical records of transfer belt unit counter																

Item No.	Description						
U127	<p>Checking/clearing the transfer count</p> <p>Description Displays and clears the counts of the transfer counter.</p> <p>Purpose To check the count after replacement of the transfer belt unit or transfer roller. Also to clear the counts after replacing transfer roller.</p> <p>Method 1. Press the start key. The current counts of the transfer counter is displayed.</p> <table border="1" data-bbox="319 593 1409 734"> <thead> <tr> <th data-bbox="319 593 651 638">Display</th> <th data-bbox="651 593 1409 638">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="319 638 651 683">Mid Trans</td> <td data-bbox="651 638 1409 683">Transfer belt unit counter value</td> </tr> <tr> <td data-bbox="319 683 651 734">2nd Trans</td> <td data-bbox="651 683 1409 734">Transfer roller counter value</td> </tr> </tbody> </table> <p>Clearing 1. Select [Clear]. 2. Press the start key. The counter value is cleared.</p> <p>Setting 1. Change the counter value using the cursor left/right keys or numeric keys. 2. Press the start key. The counter value is set.</p> <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Mid Trans	Transfer belt unit counter value	2nd Trans	Transfer roller counter value
Display	Description						
Mid Trans	Transfer belt unit counter value						
2nd Trans	Transfer roller counter value						
U135	<p>Checking toner motor operation</p> <p>Description Drives toner motors.</p> <p>Purpose To check the operation of toner motors.</p> <p>Remarks When driving the toner motors long time or several times, developing section becomes the toner full and is locked.</p> <p>Method 1. Press the start key. 2. Select [Toner]. 3. Press the start key. The operation starts.</p> <p>Completion Press the stop key after operation stops. The screen for selecting a maintenance item No. is displayed.</p>						

Item No.	Description												
U136	<p>Setting toner near end detection</p> <p>Description Sets the level that indicates the number of sheets that can be printed from occurrence of toner near end to toner empty.</p> <p>Purpose To change the setting to advance detection of near end if the interval from toner near end to toner empty seems too short.</p> <p>Setting</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select the item to be set. 3. Change the setting value using the cursor left/right keys or numeric keys. <table border="1" data-bbox="347 663 1412 831"> <thead> <tr> <th>Display</th> <th>Description</th> <th>Setting range</th> <th>Initial setting</th> </tr> </thead> <tbody> <tr> <td>K</td> <td>Setting the level of black toner</td> <td>0 to 10*</td> <td>0</td> </tr> <tr> <td>CMY</td> <td>Setting the level of cyan/magenta/yellow toner</td> <td>0 to 10*</td> <td>0</td> </tr> </tbody> </table> <p>Increasing the setting makes the interval from toner near end to toner empty longer. Decreasing the setting makes the interval from toner near end to toner empty shorter. If 0 is set, toner near end will not be detected. * : The change is not in the level of set value 5 to 10.</p> <ol style="list-style-type: none"> 4. Press the start key. The value is set. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Setting range	Initial setting	K	Setting the level of black toner	0 to 10*	0	CMY	Setting the level of cyan/magenta/yellow toner	0 to 10*	0
Display	Description	Setting range	Initial setting										
K	Setting the level of black toner	0 to 10*	0										
CMY	Setting the level of cyan/magenta/yellow toner	0 to 10*	0										
U139	<p>Displaying the temperature and humidity outside the machine</p> <p>Description Displays the detected temperature and humidity outside the machine.</p> <p>Purpose To check the temperature and humidity outside the machine.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. The detected temperature and humidity are displayed. <table border="1" data-bbox="347 1480 1412 1767"> <thead> <tr> <th>Display</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>External Temperature</td> <td>External temperature (°C)</td> </tr> <tr> <td>External Humidity</td> <td>External humidity (g/m³)</td> </tr> <tr> <td>LSU Temp (K)</td> <td>Internal temperature around the laser scanner unit (°C)</td> </tr> <tr> <td>LSU Temp(COL)</td> <td>Internal temperature around the transfer section (°C)</td> </tr> <tr> <td>Dev Temp</td> <td>Internal temperature around the developing section (°C)</td> </tr> </tbody> </table> <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	External Temperature	External temperature (°C)	External Humidity	External humidity (g/m ³)	LSU Temp (K)	Internal temperature around the laser scanner unit (°C)	LSU Temp(COL)	Internal temperature around the transfer section (°C)	Dev Temp	Internal temperature around the developing section (°C)
Display	Description												
External Temperature	External temperature (°C)												
External Humidity	External humidity (g/m ³)												
LSU Temp (K)	Internal temperature around the laser scanner unit (°C)												
LSU Temp(COL)	Internal temperature around the transfer section (°C)												
Dev Temp	Internal temperature around the developing section (°C)												

Item No.	Description																																																							
U140	<p data-bbox="290 241 577 273">Setting developer bias</p> <p data-bbox="290 309 440 340">Description</p> <p data-bbox="290 344 804 376">Setting the value of various developer bias.</p> <p data-bbox="290 380 399 412">Purpose</p> <p data-bbox="290 416 871 448">To check and setting the value of developer bias.</p> <p data-bbox="290 483 386 515">Method</p> <ol data-bbox="316 519 798 577" style="list-style-type: none"> 1. Press the start key. 2. Select the item to be set or displayed. <table border="1" data-bbox="347 586 1412 972"> <thead> <tr> <th data-bbox="355 598 651 642">Display</th> <th data-bbox="651 598 1404 642">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="355 642 651 687">Mag DC</td> <td data-bbox="651 642 1404 687">Setting the value of magnet DC bias.</td> </tr> <tr> <td data-bbox="355 687 651 732">Sleeve DC</td> <td data-bbox="651 687 1404 732">Setting the value of sleeve DC bias.</td> </tr> <tr> <td data-bbox="355 732 651 777">Clock Freq</td> <td data-bbox="651 732 1404 777">Setting the value of clock frequency.</td> </tr> <tr> <td data-bbox="355 777 651 822">Clock Duty</td> <td data-bbox="651 777 1404 822">Setting the value of clock duty.</td> </tr> <tr> <td data-bbox="355 822 651 866">AC Ctrl</td> <td data-bbox="651 822 1404 866">Setting the value of AC control voltage.</td> </tr> <tr> <td data-bbox="355 866 651 911">On Timing</td> <td data-bbox="651 866 1404 911">Setting the value of developer On timing.</td> </tr> <tr> <td data-bbox="355 911 651 967">Off Timing</td> <td data-bbox="651 911 1404 967">Setting the value of developer Off timing.</td> </tr> </tbody> </table> <p data-bbox="290 1034 1046 1066">Setting: [Mag DC/Sleeve DC/Clock Freq/Clock Duty/AC Ctrl]</p> <ol data-bbox="306 1070 1197 1128" style="list-style-type: none"> 1. Select the item to be set. 2. Change the setting value using the cursor left/right keys or numeric keys. <table border="1" data-bbox="336 1144 1412 1803"> <thead> <tr> <th data-bbox="344 1155 564 1227">Display</th> <th data-bbox="564 1155 1118 1227">Description</th> <th data-bbox="1118 1155 1404 1227">Initial setting</th> </tr> </thead> <tbody> <tr> <td data-bbox="344 1227 564 1272">1st</td> <td data-bbox="564 1227 1118 1272">Setting the value of yellow.</td> <td data-bbox="1118 1227 1404 1272">480/180/36/37/1500</td> </tr> <tr> <td data-bbox="344 1272 564 1317">2nd</td> <td data-bbox="564 1272 1118 1317">Setting the value of cyan.</td> <td data-bbox="1118 1272 1404 1317">480/180/36/37/1500</td> </tr> <tr> <td data-bbox="344 1317 564 1361">3rd</td> <td data-bbox="564 1317 1118 1361">Setting the value of magenta.</td> <td data-bbox="1118 1317 1404 1361">450/150/36/37/1500</td> </tr> <tr> <td data-bbox="344 1361 564 1406">4th</td> <td data-bbox="564 1361 1118 1406">Setting the value of black.</td> <td data-bbox="1118 1361 1404 1406">450/150/36/37/1500</td> </tr> <tr> <td data-bbox="344 1406 564 1451">Remove 1st</td> <td data-bbox="564 1406 1118 1451">Setting the value of remove yellow.</td> <td data-bbox="1118 1406 1404 1451">50/150/36/33/1150</td> </tr> <tr> <td data-bbox="344 1451 564 1496">Remove 2nd</td> <td data-bbox="564 1451 1118 1496">Setting the value of remove cyan.</td> <td data-bbox="1118 1451 1404 1496">50/150/36/33/1150</td> </tr> <tr> <td data-bbox="344 1496 564 1541">Remove 3rd</td> <td data-bbox="564 1496 1118 1541">Setting the value of remove magenta.</td> <td data-bbox="1118 1496 1404 1541">50/150/36/33/1150</td> </tr> <tr> <td data-bbox="344 1541 564 1585">Remove 4th</td> <td data-bbox="564 1541 1118 1585">Setting the value of remove black.</td> <td data-bbox="1118 1541 1404 1585">50/150/36/33/1150</td> </tr> <tr> <td data-bbox="344 1585 564 1630">Remove 1st Half</td> <td data-bbox="564 1585 1118 1630">Setting the value of remove yellow Half.</td> <td data-bbox="1118 1585 1404 1630">380/180/36/33/1150</td> </tr> <tr> <td data-bbox="344 1630 564 1675">Remove 2nd Half</td> <td data-bbox="564 1630 1118 1675">Setting the value of remove cyan Half.</td> <td data-bbox="1118 1630 1404 1675">380/180/36/33/1150</td> </tr> <tr> <td data-bbox="344 1675 564 1720">Remove 3rd Half</td> <td data-bbox="564 1675 1118 1720">Setting the value of remove magenta Half.</td> <td data-bbox="1118 1675 1404 1720">350/150/36/33/1150</td> </tr> <tr> <td data-bbox="344 1720 564 1787">Remove 4th Half</td> <td data-bbox="564 1720 1118 1787">Setting the value of remove black Half.</td> <td data-bbox="1118 1720 1404 1787">350/150/36/33/1150</td> </tr> </tbody> </table> <ol data-bbox="306 1836 766 1868" style="list-style-type: none"> 3. Press the start key. The value is set. 	Display	Description	Mag DC	Setting the value of magnet DC bias.	Sleeve DC	Setting the value of sleeve DC bias.	Clock Freq	Setting the value of clock frequency.	Clock Duty	Setting the value of clock duty.	AC Ctrl	Setting the value of AC control voltage.	On Timing	Setting the value of developer On timing.	Off Timing	Setting the value of developer Off timing.	Display	Description	Initial setting	1st	Setting the value of yellow.	480/180/36/37/1500	2nd	Setting the value of cyan.	480/180/36/37/1500	3rd	Setting the value of magenta.	450/150/36/37/1500	4th	Setting the value of black.	450/150/36/37/1500	Remove 1st	Setting the value of remove yellow.	50/150/36/33/1150	Remove 2nd	Setting the value of remove cyan.	50/150/36/33/1150	Remove 3rd	Setting the value of remove magenta.	50/150/36/33/1150	Remove 4th	Setting the value of remove black.	50/150/36/33/1150	Remove 1st Half	Setting the value of remove yellow Half.	380/180/36/33/1150	Remove 2nd Half	Setting the value of remove cyan Half.	380/180/36/33/1150	Remove 3rd Half	Setting the value of remove magenta Half.	350/150/36/33/1150	Remove 4th Half	Setting the value of remove black Half.	350/150/36/33/1150
Display	Description																																																							
Mag DC	Setting the value of magnet DC bias.																																																							
Sleeve DC	Setting the value of sleeve DC bias.																																																							
Clock Freq	Setting the value of clock frequency.																																																							
Clock Duty	Setting the value of clock duty.																																																							
AC Ctrl	Setting the value of AC control voltage.																																																							
On Timing	Setting the value of developer On timing.																																																							
Off Timing	Setting the value of developer Off timing.																																																							
Display	Description	Initial setting																																																						
1st	Setting the value of yellow.	480/180/36/37/1500																																																						
2nd	Setting the value of cyan.	480/180/36/37/1500																																																						
3rd	Setting the value of magenta.	450/150/36/37/1500																																																						
4th	Setting the value of black.	450/150/36/37/1500																																																						
Remove 1st	Setting the value of remove yellow.	50/150/36/33/1150																																																						
Remove 2nd	Setting the value of remove cyan.	50/150/36/33/1150																																																						
Remove 3rd	Setting the value of remove magenta.	50/150/36/33/1150																																																						
Remove 4th	Setting the value of remove black.	50/150/36/33/1150																																																						
Remove 1st Half	Setting the value of remove yellow Half.	380/180/36/33/1150																																																						
Remove 2nd Half	Setting the value of remove cyan Half.	380/180/36/33/1150																																																						
Remove 3rd Half	Setting the value of remove magenta Half.	350/150/36/33/1150																																																						
Remove 4th Half	Setting the value of remove black Half.	350/150/36/33/1150																																																						

Item No.	Description																				
U140	<p>Setting: [On Timing/On Timing]</p> <ol style="list-style-type: none"> Select the item to be set. Change the setting value using the cursor left/right keys or numeric keys. <table border="1" data-bbox="336 353 1422 629"> <thead> <tr> <th>Display</th> <th>Description</th> <th>Setting range</th> <th>Initial setting</th> </tr> </thead> <tbody> <tr> <td>1st</td> <td>Setting the value of yellowt.</td> <td>-500 to 500</td> <td>0/0</td> </tr> <tr> <td>2nd</td> <td>Setting the value of cyan.</td> <td>-500 to 500</td> <td>0/0</td> </tr> <tr> <td>3rd</td> <td>Setting the value of magenta.</td> <td>-500 to 500</td> <td>0/0</td> </tr> <tr> <td>4th</td> <td>Setting the value of black.</td> <td>-500 to 500</td> <td>0/0</td> </tr> </tbody> </table> <ol style="list-style-type: none"> Press the start key. The value is set. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Setting range	Initial setting	1st	Setting the value of yellowt.	-500 to 500	0/0	2nd	Setting the value of cyan.	-500 to 500	0/0	3rd	Setting the value of magenta.	-500 to 500	0/0	4th	Setting the value of black.	-500 to 500	0/0
Display	Description	Setting range	Initial setting																		
1st	Setting the value of yellowt.	-500 to 500	0/0																		
2nd	Setting the value of cyan.	-500 to 500	0/0																		
3rd	Setting the value of magenta.	-500 to 500	0/0																		
4th	Setting the value of black.	-500 to 500	0/0																		
U147	<p>Setting for toner applying operation</p> <p>Description Sets the mode for removing charged toner in the developer unit (T7 control: Toner applying operation).</p> <p>Purpose Changing settings are not required. However, when the documents with lower print density (e.g. less than 2%) should customarily printed in a great volume, mode must be changed. If the charged toner stays inside the developer unit, density decreases.</p> <p>Setting</p> <ol style="list-style-type: none"> Press the start key Select the item to be set. Change the setting value using the cursor left/right keys or numeric keys. <table border="1" data-bbox="336 1361 1422 1532"> <thead> <tr> <th>Display</th> <th>Description</th> <th>Setting range</th> <th>Initial setting</th> </tr> </thead> <tbody> <tr> <td>T7</td> <td>T7 Operational mode</td> <td>0 to 1</td> <td>0</td> </tr> <tr> <td>Drum T7</td> <td>Drum T7 operational mode</td> <td>0 to 255</td> <td>60</td> </tr> </tbody> </table> <ol style="list-style-type: none"> Press the start key. The setting is set. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Setting range	Initial setting	T7	T7 Operational mode	0 to 1	0	Drum T7	Drum T7 operational mode	0 to 255	60								
Display	Description	Setting range	Initial setting																		
T7	T7 Operational mode	0 to 1	0																		
Drum T7	Drum T7 operational mode	0 to 255	60																		

Item No.	Description																								
U150	<p data-bbox="288 241 641 271">Checking sensors for toner</p> <p data-bbox="288 309 440 338">Description</p> <p data-bbox="288 344 1082 374">Displays the on-off status of each sensor or switch related to toner.</p> <p data-bbox="288 380 400 409">Purpose</p> <p data-bbox="288 416 938 445">To check if the sensors and switches operate correctly.</p> <p data-bbox="288 483 387 512">Method</p> <ol data-bbox="312 519 1115 577" style="list-style-type: none"> 1. Press the start key. 2. Select the item. The screen for executing each item is displayed. <table border="1" data-bbox="347 589 1412 732"> <thead> <tr> <th data-bbox="352 589 651 633">Display</th> <th data-bbox="651 589 1407 633">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="352 633 651 678">T/C</td> <td data-bbox="651 633 1407 678">Displays the state of the toner sensor.</td> </tr> <tr> <td data-bbox="352 678 651 732">Waste Box</td> <td data-bbox="651 678 1407 732">Displays the state of the waste toner box.</td> </tr> </tbody> </table> <p data-bbox="288 743 464 772">Method: [T/C]</p> <ol data-bbox="312 779 1402 875" style="list-style-type: none"> 1. Turn each switch or sensor on and off manually to check the status. When a switch or sensor is detected to be in the ON position, the display for that switch or sensor will be "1" <table border="1" data-bbox="336 891 1412 1178"> <thead> <tr> <th data-bbox="341 891 639 936">Display</th> <th data-bbox="639 891 1407 936">Switches and sensors</th> </tr> </thead> <tbody> <tr> <td data-bbox="341 936 639 981">T/C Sensor 1st</td> <td data-bbox="639 936 1407 981">Displays the state of the toner sensor (Yellow).</td> </tr> <tr> <td data-bbox="341 981 639 1025">T/C Sensor 2nd</td> <td data-bbox="639 981 1407 1025">Displays the state of the toner sensor (Cyan).</td> </tr> <tr> <td data-bbox="341 1025 639 1070">T/C Sensor 3rd</td> <td data-bbox="639 1025 1407 1070">Displays the state of the toner sensor (Magenta).</td> </tr> <tr> <td data-bbox="341 1070 639 1115">T/C Sensor 4th</td> <td data-bbox="639 1070 1407 1115">Displays the state of the toner sensor (Black).</td> </tr> <tr> <td data-bbox="341 1115 639 1178">Motor</td> <td data-bbox="639 1115 1407 1178">Drives developer motor, developer clutch.</td> </tr> </tbody> </table> <ol data-bbox="312 1193 823 1223" style="list-style-type: none"> 2. To stop motor driving, press the stop key. <p data-bbox="288 1261 557 1290">Method: [Waste Box]</p> <ol data-bbox="312 1296 1402 1393" style="list-style-type: none"> 1. Turn each switch or sensor on and off manually to check the status. When a switch or sensor is detected to be in the ON position, the display for that switch or sensor will be "1" <table border="1" data-bbox="336 1408 1412 1552"> <thead> <tr> <th data-bbox="341 1408 639 1453">Display</th> <th data-bbox="639 1408 1407 1453">Switches and sensors</th> </tr> </thead> <tbody> <tr> <td data-bbox="341 1453 639 1498">Waste Box Sensor</td> <td data-bbox="639 1453 1407 1498">Displays the state of the waste toner box.</td> </tr> <tr> <td data-bbox="341 1498 639 1552">Motor</td> <td data-bbox="639 1498 1407 1552">Drives developer motor, developer clutch.</td> </tr> </tbody> </table> <ol data-bbox="312 1568 823 1597" style="list-style-type: none"> 2. To stop motor driving, press the stop key. <p data-bbox="288 1635 440 1664">Completion</p> <p data-bbox="288 1671 1254 1700">Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	T/C	Displays the state of the toner sensor.	Waste Box	Displays the state of the waste toner box.	Display	Switches and sensors	T/C Sensor 1st	Displays the state of the toner sensor (Yellow).	T/C Sensor 2nd	Displays the state of the toner sensor (Cyan).	T/C Sensor 3rd	Displays the state of the toner sensor (Magenta).	T/C Sensor 4th	Displays the state of the toner sensor (Black).	Motor	Drives developer motor, developer clutch.	Display	Switches and sensors	Waste Box Sensor	Displays the state of the waste toner box.	Motor	Drives developer motor, developer clutch.
Display	Description																								
T/C	Displays the state of the toner sensor.																								
Waste Box	Displays the state of the waste toner box.																								
Display	Switches and sensors																								
T/C Sensor 1st	Displays the state of the toner sensor (Yellow).																								
T/C Sensor 2nd	Displays the state of the toner sensor (Cyan).																								
T/C Sensor 3rd	Displays the state of the toner sensor (Magenta).																								
T/C Sensor 4th	Displays the state of the toner sensor (Black).																								
Motor	Drives developer motor, developer clutch.																								
Display	Switches and sensors																								
Waste Box Sensor	Displays the state of the waste toner box.																								
Motor	Drives developer motor, developer clutch.																								

Item No.	Description																														
U157	<p data-bbox="287 237 742 271">Checking the developing drive time</p> <p data-bbox="287 302 438 331">Description Displays the developing drive time for checking a figure, which is used as a reference when correcting the toner control.</p> <p data-bbox="287 398 395 427">Purpose To check the developing drive time after replacing the developing unit.</p> <p data-bbox="287 495 384 524">Method 1. Press the start key. The developing drive time of each color is displayed.</p> <table border="1" data-bbox="339 562 1404 801"> <thead> <tr> <th data-bbox="339 562 646 607">Display</th> <th data-bbox="646 562 1404 607">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="339 607 646 651">C</td> <td data-bbox="646 607 1404 651">Cyan developing drive time (min)</td> </tr> <tr> <td data-bbox="339 651 646 696">M</td> <td data-bbox="646 651 1404 696">Magenta developing drive time (min)</td> </tr> <tr> <td data-bbox="339 696 646 741">Y</td> <td data-bbox="646 696 1404 741">Yellow developing drive time (min)</td> </tr> <tr> <td data-bbox="339 741 646 786">K</td> <td data-bbox="646 741 1404 786">Black developing drive time (min)</td> </tr> </tbody> </table> <p data-bbox="287 869 379 898">Setting 1. Select the item to be set. 2. Change the setting value using the cursor left/right keys or numeric keys.</p> <table border="1" data-bbox="339 976 1407 1245"> <thead> <tr> <th data-bbox="339 976 523 1048">Display</th> <th data-bbox="523 976 1010 1048">Description</th> <th data-bbox="1010 976 1209 1048">Setting range</th> <th data-bbox="1209 976 1407 1048">Initial setting</th> </tr> </thead> <tbody> <tr> <td data-bbox="339 1048 523 1093">C</td> <td data-bbox="523 1048 1010 1093">Cyan developing drive time (min)</td> <td data-bbox="1010 1048 1209 1093">0 to 59999</td> <td data-bbox="1209 1048 1407 1093">0</td> </tr> <tr> <td data-bbox="339 1093 523 1137">M</td> <td data-bbox="523 1093 1010 1137">Magenta developing drive time (min)</td> <td data-bbox="1010 1093 1209 1137">0 to 59999</td> <td data-bbox="1209 1093 1407 1137">0</td> </tr> <tr> <td data-bbox="339 1137 523 1182">Y</td> <td data-bbox="523 1137 1010 1182">Yellow developing drive time (min)</td> <td data-bbox="1010 1137 1209 1182">0 to 59999</td> <td data-bbox="1209 1137 1407 1182">0</td> </tr> <tr> <td data-bbox="339 1182 523 1227">K</td> <td data-bbox="523 1182 1010 1227">Black developing drive time (min)</td> <td data-bbox="1010 1182 1209 1227">0 to 59999</td> <td data-bbox="1209 1182 1407 1227">0</td> </tr> </tbody> </table> <p data-bbox="287 1279 778 1308">3. Press the start key. The setting is set.</p> <p data-bbox="287 1346 438 1375">Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	C	Cyan developing drive time (min)	M	Magenta developing drive time (min)	Y	Yellow developing drive time (min)	K	Black developing drive time (min)	Display	Description	Setting range	Initial setting	C	Cyan developing drive time (min)	0 to 59999	0	M	Magenta developing drive time (min)	0 to 59999	0	Y	Yellow developing drive time (min)	0 to 59999	0	K	Black developing drive time (min)	0 to 59999	0
Display	Description																														
C	Cyan developing drive time (min)																														
M	Magenta developing drive time (min)																														
Y	Yellow developing drive time (min)																														
K	Black developing drive time (min)																														
Display	Description	Setting range	Initial setting																												
C	Cyan developing drive time (min)	0 to 59999	0																												
M	Magenta developing drive time (min)	0 to 59999	0																												
Y	Yellow developing drive time (min)	0 to 59999	0																												
K	Black developing drive time (min)	0 to 59999	0																												

Item No.	Description																																																																																											
U161	Setting the fuser control temperature																																																																																											
Description																																																																																												
Changes the fuser control temperature and control temperature correction value and other set values.																																																																																												
Purpose																																																																																												
Normally no change is necessary. However, this mode can be used to prevent curling or creasing of paper, or solve a fuser problem on thick paper.																																																																																												
Setting																																																																																												
1. Press the start key.																																																																																												
2. Select the item to be set.																																																																																												
3. Change the setting value using the cursor left/right keys.																																																																																												
<table border="1"> <thead> <tr> <th data-bbox="338 703 558 831" rowspan="2">Display</th> <th data-bbox="558 703 1015 831" rowspan="2">Description</th> <th data-bbox="1015 703 1179 831" rowspan="2">Setting range</th> <th colspan="2" data-bbox="1179 703 1409 781">Initial setting</th> </tr> <tr> <th data-bbox="1179 781 1294 831">20ppm</th> <th data-bbox="1294 781 1409 831">25ppm</th> </tr> </thead> <tbody> <tr> <td data-bbox="338 831 558 909">Copy Curb(Edge)</td> <td data-bbox="558 831 1015 909">Prevention temperature of overtemperature rise under copy</td> <td data-bbox="1015 831 1179 909">100 to 250</td> <td data-bbox="1179 831 1294 909">210</td> <td data-bbox="1294 831 1409 909">210</td> </tr> <tr> <td data-bbox="338 909 558 987">Curb(Edge)</td> <td data-bbox="558 909 1015 987">Prevention temperature of overtemperature rise</td> <td data-bbox="1015 909 1179 987">100 to 250</td> <td data-bbox="1179 909 1294 987">240</td> <td data-bbox="1294 909 1409 987">240</td> </tr> <tr> <td data-bbox="338 987 558 1066">Return(Edge)</td> <td data-bbox="558 987 1015 1066">Return temperature of overtemperature rise</td> <td data-bbox="1015 987 1179 1066">100 to 250</td> <td data-bbox="1179 987 1294 1066">190</td> <td data-bbox="1294 987 1409 1066">190</td> </tr> <tr> <td data-bbox="338 1066 558 1122">Ready(Edge)</td> <td data-bbox="558 1066 1015 1122">Ready display temperature</td> <td data-bbox="1015 1066 1179 1122">0 to 200</td> <td data-bbox="1179 1066 1294 1122">95</td> <td data-bbox="1294 1066 1409 1122">100</td> </tr> <tr> <td data-bbox="338 1122 558 1178">Pressure(Press)</td> <td data-bbox="558 1122 1015 1178">Pressurizing beginning temperature</td> <td data-bbox="1015 1122 1179 1178">0 to 200</td> <td data-bbox="1179 1122 1294 1178">85</td> <td data-bbox="1294 1122 1409 1178">90</td> </tr> <tr> <td data-bbox="338 1178 558 1256">High speed(Center)</td> <td data-bbox="558 1178 1015 1256">Full speed shift temperature</td> <td data-bbox="1015 1178 1179 1256">0 to 200</td> <td data-bbox="1179 1178 1294 1256">110</td> <td data-bbox="1294 1178 1409 1256">115</td> </tr> <tr> <td data-bbox="338 1256 558 1312">Ready(Center)</td> <td data-bbox="558 1256 1015 1312">Ready display temperature</td> <td data-bbox="1015 1256 1179 1312">100 to 200</td> <td data-bbox="1179 1256 1294 1312">135</td> <td data-bbox="1294 1256 1409 1312">140</td> </tr> <tr> <td data-bbox="338 1312 558 1368">Drive(Center)</td> <td data-bbox="558 1312 1015 1368">The second stability temperature</td> <td data-bbox="1015 1312 1179 1368">100 to 200</td> <td data-bbox="1179 1312 1294 1368">140</td> <td data-bbox="1294 1312 1409 1368">145</td> </tr> <tr> <td data-bbox="338 1368 558 1447">Full speed(Center)</td> <td data-bbox="558 1368 1015 1447">Print control temperature</td> <td data-bbox="1015 1368 1179 1447">100 to 200</td> <td data-bbox="1179 1368 1294 1447">140</td> <td data-bbox="1294 1368 1409 1447">145</td> </tr> <tr> <td data-bbox="338 1447 558 1525">Wait(Center)</td> <td data-bbox="558 1447 1015 1525">Control temperature when being standing by</td> <td data-bbox="1015 1447 1179 1525">100 to 200</td> <td data-bbox="1179 1447 1294 1525">115</td> <td data-bbox="1294 1447 1409 1525">120</td> </tr> <tr> <td data-bbox="338 1525 558 1603">WarmUp Curb(Center)</td> <td data-bbox="558 1525 1015 1603">Electric power control temperature at start-up</td> <td data-bbox="1015 1525 1179 1603">0 to 200</td> <td data-bbox="1179 1525 1294 1603">135</td> <td data-bbox="1294 1525 1409 1603">140</td> </tr> <tr> <td data-bbox="338 1603 558 1682">Curb(Center)</td> <td data-bbox="558 1603 1015 1682">Prevention temperature of overtemperature rise</td> <td data-bbox="1015 1603 1179 1682">170 to 250</td> <td data-bbox="1179 1603 1294 1682">240</td> <td data-bbox="1294 1603 1409 1682">240</td> </tr> <tr> <td data-bbox="338 1682 558 1760">Low power(Center)</td> <td data-bbox="558 1682 1015 1760">Low electric power control temperature</td> <td data-bbox="1015 1682 1179 1760">0 to 200</td> <td data-bbox="1179 1682 1294 1760">85</td> <td data-bbox="1294 1682 1409 1760">90</td> </tr> <tr> <td data-bbox="338 1760 558 1816">Ready(Press)</td> <td data-bbox="558 1760 1015 1816">Ready display temperature</td> <td data-bbox="1015 1760 1179 1816">0 to 200</td> <td data-bbox="1179 1760 1294 1816">40</td> <td data-bbox="1294 1760 1409 1816">45</td> </tr> <tr> <td data-bbox="338 1816 558 1895">Curb(Press)</td> <td data-bbox="558 1816 1015 1895">Prevention temperature of overtemperature rise</td> <td data-bbox="1015 1816 1179 1895">170 to 250</td> <td data-bbox="1179 1816 1294 1895">200</td> <td data-bbox="1294 1816 1409 1895">200</td> </tr> <tr> <td data-bbox="338 1895 558 1973">Wait Off-set(Press)</td> <td data-bbox="558 1895 1015 1973">Correction temperature when being standing by</td> <td data-bbox="1015 1895 1179 1973">0 to 200</td> <td data-bbox="1179 1895 1294 1973">85</td> <td data-bbox="1294 1895 1409 1973">90</td> </tr> </tbody> </table>						Display	Description	Setting range	Initial setting		20ppm	25ppm	Copy Curb(Edge)	Prevention temperature of overtemperature rise under copy	100 to 250	210	210	Curb(Edge)	Prevention temperature of overtemperature rise	100 to 250	240	240	Return(Edge)	Return temperature of overtemperature rise	100 to 250	190	190	Ready(Edge)	Ready display temperature	0 to 200	95	100	Pressure(Press)	Pressurizing beginning temperature	0 to 200	85	90	High speed(Center)	Full speed shift temperature	0 to 200	110	115	Ready(Center)	Ready display temperature	100 to 200	135	140	Drive(Center)	The second stability temperature	100 to 200	140	145	Full speed(Center)	Print control temperature	100 to 200	140	145	Wait(Center)	Control temperature when being standing by	100 to 200	115	120	WarmUp Curb(Center)	Electric power control temperature at start-up	0 to 200	135	140	Curb(Center)	Prevention temperature of overtemperature rise	170 to 250	240	240	Low power(Center)	Low electric power control temperature	0 to 200	85	90	Ready(Press)	Ready display temperature	0 to 200	40	45	Curb(Press)	Prevention temperature of overtemperature rise	170 to 250	200	200	Wait Off-set(Press)	Correction temperature when being standing by	0 to 200	85	90
Display	Description	Setting range	Initial setting																																																																																									
			20ppm	25ppm																																																																																								
Copy Curb(Edge)	Prevention temperature of overtemperature rise under copy	100 to 250	210	210																																																																																								
Curb(Edge)	Prevention temperature of overtemperature rise	100 to 250	240	240																																																																																								
Return(Edge)	Return temperature of overtemperature rise	100 to 250	190	190																																																																																								
Ready(Edge)	Ready display temperature	0 to 200	95	100																																																																																								
Pressure(Press)	Pressurizing beginning temperature	0 to 200	85	90																																																																																								
High speed(Center)	Full speed shift temperature	0 to 200	110	115																																																																																								
Ready(Center)	Ready display temperature	100 to 200	135	140																																																																																								
Drive(Center)	The second stability temperature	100 to 200	140	145																																																																																								
Full speed(Center)	Print control temperature	100 to 200	140	145																																																																																								
Wait(Center)	Control temperature when being standing by	100 to 200	115	120																																																																																								
WarmUp Curb(Center)	Electric power control temperature at start-up	0 to 200	135	140																																																																																								
Curb(Center)	Prevention temperature of overtemperature rise	170 to 250	240	240																																																																																								
Low power(Center)	Low electric power control temperature	0 to 200	85	90																																																																																								
Ready(Press)	Ready display temperature	0 to 200	40	45																																																																																								
Curb(Press)	Prevention temperature of overtemperature rise	170 to 250	200	200																																																																																								
Wait Off-set(Press)	Correction temperature when being standing by	0 to 200	85	90																																																																																								
4. Press the start key. The value is set.																																																																																												

Item No.	Description						
U161	<p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>						
U167	<p>Checking/setting the fuser count</p> <p>Description Displays and sets the fuser count for checking.</p> <p>Purpose To check or set the fuser count after replacement of the fuser unit.</p> <p>Method 1. Press the start key. The fuser count is displayed.</p> <table border="1" data-bbox="347 689 1407 786"> <thead> <tr> <th data-bbox="352 689 523 734">Display</th> <th data-bbox="523 689 1402 734">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="352 734 523 786">Cnt</td> <td data-bbox="523 734 1402 786">Fuser count value</td> </tr> </tbody> </table> <p>Setting:[Cnt] 1. Press [Cnt]. 2. Change the setting using the cursor left/right keys or numeric keys. 3. Press the start key. The setting is set.</p> <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Cnt	Fuser count value		
Display	Description						
Cnt	Fuser count value						
U168	<p>Confirmation/setting the fuser drive time</p> <p>Description Displays and settings the specification of fuser drive time for checking.</p> <p>Purpose To check or set the drive time of fuser unit after replacement of the fuser unit.</p> <p>Method 1. Press the start key. The drive time of fuser unit is displayed.</p> <table border="1" data-bbox="347 1413 1412 1559"> <thead> <tr> <th data-bbox="352 1413 652 1458">Display</th> <th data-bbox="652 1413 1407 1458">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="352 1458 652 1503">Press</td> <td data-bbox="652 1458 1407 1503">Counts of the fuser drive time (Pressing force)</td> </tr> <tr> <td data-bbox="352 1503 652 1559">Release</td> <td data-bbox="652 1503 1407 1559">Counts of the fuser drive time (Decompression)</td> </tr> </tbody> </table> <p>Setting 1. Select the item to be set. 2. Change the setting using the cursor left/right keys or numeric keys. 3. Press the start key. The value is set.</p> <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Press	Counts of the fuser drive time (Pressing force)	Release	Counts of the fuser drive time (Decompression)
Display	Description						
Press	Counts of the fuser drive time (Pressing force)						
Release	Counts of the fuser drive time (Decompression)						

Item No.	Description								
U169	<p>Confirmation/setting the fuser power supply</p> <p>Description Displays and settings the specification of fuser power supply for checking.</p> <p>Purpose To check or set the specification of fuser power supply after replacement of the fuser power supply.</p> <p>Method 1. Press the start key. The specification of fuser power supply is displayed.</p> <table border="1" data-bbox="347 566 1412 696"> <thead> <tr> <th data-bbox="347 566 651 611">Display</th> <th data-bbox="651 566 1412 611">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="347 611 651 696">Mode</td> <td data-bbox="651 611 1412 696">Specification of fuser power supply (1: 100V , 2: 200V , 3: 120V)</td> </tr> </tbody> </table> <p>Setting 1. Change the setting using the cursor left/right keys or numeric keys. 2. Press the start key. The value is set.</p> <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Mode	Specification of fuser power supply (1: 100V , 2: 200V , 3: 120V)				
Display	Description								
Mode	Specification of fuser power supply (1: 100V , 2: 200V , 3: 120V)								
U199	<p>Displaying fuser heater temperature</p> <p>Description Displays the detected fuser temperature.</p> <p>Purpose To check the fuser temperature.</p> <p>Method 1. Press the start key. The current setting is displayed.</p> <table border="1" data-bbox="347 1317 1412 1485"> <thead> <tr> <th data-bbox="347 1317 651 1361">Display</th> <th data-bbox="651 1317 1412 1361">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="347 1361 651 1406">Fix Press</td> <td data-bbox="651 1361 1412 1406">Press roller center temperature (°C)</td> </tr> <tr> <td data-bbox="347 1406 651 1451">Fix Edge</td> <td data-bbox="651 1406 1412 1451">Heat roller edge temperature (°C)</td> </tr> <tr> <td data-bbox="347 1451 651 1485">Fix Center</td> <td data-bbox="651 1451 1412 1485">Heat roller center temperature (°C)</td> </tr> </tbody> </table> <p>Completion Press the stop key. The screen for selecting a maintenance mode No. is displayed.</p>	Display	Description	Fix Press	Press roller center temperature (°C)	Fix Edge	Heat roller edge temperature (°C)	Fix Center	Heat roller center temperature (°C)
Display	Description								
Fix Press	Press roller center temperature (°C)								
Fix Edge	Heat roller edge temperature (°C)								
Fix Center	Heat roller center temperature (°C)								

Item No.	Description						
U201	<p data-bbox="292 244 628 273">Initializing the touch panel</p> <p data-bbox="292 315 440 344">Description</p> <p data-bbox="292 349 1174 378">Automatically correct the positions of the X- and Y-axes of the touch panel.</p> <p data-bbox="292 383 400 412">Purpose</p> <p data-bbox="292 416 1275 445">To automatically correct the display positions on the touch panel after it is replaced.</p> <p data-bbox="292 488 387 517">Method</p> <ol data-bbox="308 521 711 584" style="list-style-type: none"> 1. Press the start key. 2. Select the [Initialize] or [Check]. <table border="1" data-bbox="336 598 1401 741"> <thead> <tr> <th data-bbox="336 598 641 642">Display</th> <th data-bbox="641 598 1401 642">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 642 641 687">Initialize</td> <td data-bbox="641 642 1401 687">Adjusts the display on the panel automatically</td> </tr> <tr> <td data-bbox="336 687 641 741">Check</td> <td data-bbox="641 687 1401 741">Checks the display on the touch panel</td> </tr> </tbody> </table> <p data-bbox="292 784 528 813">Method: [Initialize]</p> <ol data-bbox="308 817 1302 987" style="list-style-type: none"> 1. Press the start key. 2. Press the center of the + keys. Be sure to press three + keys displayed in order. The touch panel is adjusted automatically. 3. Press the indicated three + keys, and then check the display. 4. Press the stop key. The screen for selecting a maintenance item No. is displayed. <p data-bbox="292 1025 501 1055">Method: [Check]</p> <ol data-bbox="308 1059 1339 1196" style="list-style-type: none"> 1. Press the start key. 2. Press the indicated three + keys, and then check the display. When adjusting the display, press [Initialize] to execute the adjustment automatically. 3. Press the stop key. The screen for selecting a maintenance item No. is displayed. <p data-bbox="292 1234 440 1263">Completion</p> <p data-bbox="292 1267 1254 1296">Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Initialize	Adjusts the display on the panel automatically	Check	Checks the display on the touch panel
Display	Description						
Initialize	Adjusts the display on the panel automatically						
Check	Checks the display on the touch panel						

Item No.	Description																
U203	<p data-bbox="290 241 587 273">Checking DP operation</p> <p data-bbox="290 311 440 342">Description</p> <p data-bbox="290 344 1046 376">Simulates the original conveying operation separately in the DP.</p> <p data-bbox="290 383 400 414">Purpose</p> <p data-bbox="290 416 612 448">To check the DP operation.</p> <p data-bbox="290 486 387 517">Method</p> <ol data-bbox="308 519 1082 618" style="list-style-type: none"> 1. Press the start key. 2. Place an original in the DP if running this simulation with paper. 3. Select the speed to be operated. <table border="1" data-bbox="336 631 1401 777"> <thead> <tr> <th data-bbox="336 631 641 676">Display</th> <th data-bbox="641 631 1401 676">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 676 641 721">Normal Speed</td> <td data-bbox="641 676 1401 721">Normal reading (600 dpi)</td> </tr> <tr> <td data-bbox="336 721 641 777">High Speed</td> <td data-bbox="641 721 1401 777">High-speed reading</td> </tr> </tbody> </table> <ol data-bbox="308 786 699 817" style="list-style-type: none"> 4. Select the item to be operated. <table border="1" data-bbox="336 831 1401 1137"> <thead> <tr> <th data-bbox="336 831 641 875">Display</th> <th data-bbox="641 831 1401 875">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 875 641 954">CCD ADP (Non-P)</td> <td data-bbox="641 875 1401 954">Without paper, single-sided original of CCD (continuous operation)</td> </tr> <tr> <td data-bbox="336 954 641 999">CCD ADP</td> <td data-bbox="641 954 1401 999">With paper, single-sided original of CCD</td> </tr> <tr> <td data-bbox="336 999 641 1077">CCD RADP (Non-P)</td> <td data-bbox="641 999 1401 1077">Without paper, double-sided original of CCD (continuous operation)</td> </tr> <tr> <td data-bbox="336 1077 641 1137">CCD RADP</td> <td data-bbox="641 1077 1401 1137">With paper, double-sided original of CCD</td> </tr> </tbody> </table> <ol data-bbox="308 1151 916 1218" style="list-style-type: none"> 5. Press the start key. The operation starts. 6. To stop continuous operation, press the stop key. <p data-bbox="290 1256 440 1288">Completion</p> <p data-bbox="290 1290 1254 1321">Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Normal Speed	Normal reading (600 dpi)	High Speed	High-speed reading	Display	Description	CCD ADP (Non-P)	Without paper, single-sided original of CCD (continuous operation)	CCD ADP	With paper, single-sided original of CCD	CCD RADP (Non-P)	Without paper, double-sided original of CCD (continuous operation)	CCD RADP	With paper, double-sided original of CCD
Display	Description																
Normal Speed	Normal reading (600 dpi)																
High Speed	High-speed reading																
Display	Description																
CCD ADP (Non-P)	Without paper, single-sided original of CCD (continuous operation)																
CCD ADP	With paper, single-sided original of CCD																
CCD RADP (Non-P)	Without paper, double-sided original of CCD (continuous operation)																
CCD RADP	With paper, double-sided original of CCD																

Item No.	Description						
U207	<p>Checking the operation panel keys</p> <p>Description Checks operation of the operation panel keys.</p> <p>Purpose To check operation of all the keys and LEDs on the operation panel.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. The screen for executing is displayed. 2. [Count0] is displayed and the leftmost LED on the operation panel lights. 3. As the keys lined up in the same line as the lit indicator are pressed in the order from the top to the bottom, the figure shown on the touch panel increases in increments of 1. When all the keys in that line are pressed and if there are any LEDs corresponding to the keys in the line on the immediate right, the top LED in that line will light. 4. When all the keys on the operation panel have been pressed, all the LEDs light for up to 10 seconds. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>						
U222	<p>Setting the IC card type</p> <p>Description Sets the type of IC card.</p> <p>Purpose To change the type of IC card.</p> <p>Setting</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select the item. <table border="1" data-bbox="336 1301 1401 1447"> <thead> <tr> <th data-bbox="336 1301 641 1350">Display</th> <th data-bbox="641 1301 1401 1350">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1350 641 1400">Other</td> <td data-bbox="641 1350 1401 1400">The type of IC card is SSFC.</td> </tr> <tr> <td data-bbox="336 1400 641 1447">SSFC</td> <td data-bbox="641 1400 1401 1447">The type of IC card is not SSFC.</td> </tr> </tbody> </table> <p>* : Initial setting: Other</p> <ol style="list-style-type: none"> 3. Press the start key. The setting is set. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Other	The type of IC card is SSFC.	SSFC	The type of IC card is not SSFC.
Display	Description						
Other	The type of IC card is SSFC.						
SSFC	The type of IC card is not SSFC.						

Item No.	Description										
U243	<p data-bbox="288 241 813 275">Checking the operation of the DP motors</p> <p data-bbox="288 311 440 340">Description</p> <p data-bbox="288 344 791 374">Turns the motors or clutches in the DP on.</p> <p data-bbox="288 383 400 412">Purpose</p> <p data-bbox="288 416 932 445">To check the operation of the DP motors and clutches.</p> <p data-bbox="288 486 387 515">Method</p> <ol data-bbox="308 519 815 620" style="list-style-type: none"> 1. Press the start key. 2. Select the item to be operated. 3. Press the start key. The operation starts. <table border="1" data-bbox="336 631 1401 871"> <thead> <tr> <th data-bbox="336 631 641 680">Display</th> <th data-bbox="641 631 1401 680">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 680 641 730">Conv Motor</td> <td data-bbox="641 680 1401 730">DP paper feed motor (DPPFM) is turned on</td> </tr> <tr> <td data-bbox="336 730 641 779">Rev Motor</td> <td data-bbox="641 730 1401 779">DP switchback motor (DPSBM) is turned on</td> </tr> <tr> <td data-bbox="336 779 641 828">Feed Clutch</td> <td data-bbox="641 779 1401 828">DP paper feed clutch (DPPFCL) is turned on</td> </tr> <tr> <td data-bbox="336 828 641 871">Regist Clutch</td> <td data-bbox="641 828 1401 871">DP registration clutch (DPRCL) is turned on</td> </tr> </tbody> </table> <ol data-bbox="308 882 834 911" style="list-style-type: none"> 4. To turn each motor off, press the stop key. <p data-bbox="288 949 440 978">Completion</p> <p data-bbox="288 983 1433 1050">Press the stop key when operation stops. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Conv Motor	DP paper feed motor (DPPFM) is turned on	Rev Motor	DP switchback motor (DPSBM) is turned on	Feed Clutch	DP paper feed clutch (DPPFCL) is turned on	Regist Clutch	DP registration clutch (DPRCL) is turned on
Display	Description										
Conv Motor	DP paper feed motor (DPPFM) is turned on										
Rev Motor	DP switchback motor (DPSBM) is turned on										
Feed Clutch	DP paper feed clutch (DPPFCL) is turned on										
Regist Clutch	DP registration clutch (DPRCL) is turned on										

Item No.	Description																				
U244	<p data-bbox="290 241 625 273">Checking the DP switches</p> <p data-bbox="290 311 440 342">Description</p> <p data-bbox="290 344 951 376">Displays the status of the respective switches in the DP.</p> <p data-bbox="290 383 400 414">Purpose</p> <p data-bbox="290 416 1031 448">To check if the respective switches in the DP operate correctly.</p> <p data-bbox="290 486 387 517">Method</p> <ol data-bbox="308 519 1134 584" style="list-style-type: none"> 1. Press the start key. 2. Turn each switch or sensor on and off manually to check the status. <p data-bbox="335 586 1402 651">When a switch or sensor is detected to be in the ON position, the display for that switch or sensor will be "1".</p> <table border="1" data-bbox="336 667 1401 1146"> <thead> <tr> <th data-bbox="336 667 639 712">Display</th> <th data-bbox="639 667 1401 712">Switches and sensors</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 712 639 757">Switch 00000000</td> <td data-bbox="639 712 1401 757"></td> </tr> <tr> <td data-bbox="336 757 639 801"> 1st digit</td> <td data-bbox="639 757 1401 801">DP interlock switch (DPILSW)</td> </tr> <tr> <td data-bbox="336 801 639 846"> 2nd digit</td> <td data-bbox="639 801 1401 846">DP open/close sensor (DPOCS)</td> </tr> <tr> <td data-bbox="336 846 639 891"> 3rd digit</td> <td data-bbox="639 846 1401 891">DP paper feed sensor (DPPFS)</td> </tr> <tr> <td data-bbox="336 891 639 936"> 4th digit</td> <td data-bbox="639 891 1401 936">DP registration sensor (DPRS)</td> </tr> <tr> <td data-bbox="336 936 639 981"> 5th digit</td> <td data-bbox="639 936 1401 981">DP timing sensor (DPTS)</td> </tr> <tr> <td data-bbox="336 981 639 1025"> 6th digit</td> <td data-bbox="639 981 1401 1025">DP original sensor (DPOS)</td> </tr> <tr> <td data-bbox="336 1025 639 1070"> 7th digit</td> <td data-bbox="639 1025 1401 1070">DP original size length sensor (DPOLS)</td> </tr> <tr> <td data-bbox="336 1070 639 1115"> 8th digit</td> <td data-bbox="639 1070 1401 1115">-</td> </tr> </tbody> </table> <p data-bbox="290 1193 440 1225">Completion</p> <p data-bbox="290 1227 1254 1258">Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Switches and sensors	Switch 00000000		1st digit	DP interlock switch (DPILSW)	2nd digit	DP open/close sensor (DPOCS)	3rd digit	DP paper feed sensor (DPPFS)	4th digit	DP registration sensor (DPRS)	5th digit	DP timing sensor (DPTS)	6th digit	DP original sensor (DPOS)	7th digit	DP original size length sensor (DPOLS)	8th digit	-
Display	Switches and sensors																				
Switch 00000000																					
1st digit	DP interlock switch (DPILSW)																				
2nd digit	DP open/close sensor (DPOCS)																				
3rd digit	DP paper feed sensor (DPPFS)																				
4th digit	DP registration sensor (DPRS)																				
5th digit	DP timing sensor (DPTS)																				
6th digit	DP original sensor (DPOS)																				
7th digit	DP original size length sensor (DPOLS)																				
8th digit	-																				

Item No.	Description																
U250	<p data-bbox="290 241 817 275">Checking/clearing the maintenance cycle</p> <p data-bbox="290 309 440 342">Description Changes preset values for maintenance cycle and automatic grayscale adjustment.</p> <p data-bbox="290 376 400 409">Purpose Provides changing the time when the message to acknowledge to conduct maintenance and automatic grayscale adjustment is periodically displayed.</p> <p data-bbox="290 517 384 551">Setting</p> <ol data-bbox="306 555 1129 656" style="list-style-type: none"> 1. Press the start key. 2. Select the item to be changed. 3. Change the setting using the cursor left/right keys or numeric keys. <table border="1" data-bbox="317 667 1402 927"> <thead> <tr> <th data-bbox="320 667 504 745">Display</th> <th data-bbox="504 667 1023 745">Description</th> <th data-bbox="1023 667 1241 745">Setting range</th> <th data-bbox="1241 667 1402 745">Initial setting</th> </tr> </thead> <tbody> <tr> <td data-bbox="320 745 504 790">M.Cnt A</td> <td data-bbox="504 745 1023 790">Preset values for maintenance cycle (A)</td> <td data-bbox="1023 745 1241 790">0 to 9999999</td> <td data-bbox="1241 745 1402 790">200000</td> </tr> <tr> <td data-bbox="320 790 504 835">M.Cnt B</td> <td data-bbox="504 790 1023 835">Preset values for maintenance cycle (B)</td> <td data-bbox="1023 790 1241 835">0 to 9999999</td> <td data-bbox="1241 790 1402 835">200000</td> </tr> <tr> <td data-bbox="320 835 504 927">M.Cnt HT</td> <td data-bbox="504 835 1023 927">Preset values for automatic grayscale adjustment</td> <td data-bbox="1023 835 1241 927">0 to 9999999</td> <td data-bbox="1241 835 1402 927">0</td> </tr> </tbody> </table> <ol data-bbox="306 958 852 992" style="list-style-type: none"> 4. Press the start key. The setting value is set. <p data-bbox="290 1025 400 1059">Clearing</p> <ol data-bbox="306 1064 903 1131" style="list-style-type: none"> 1. Select [Clear]. 2. Press the start key. The setting value is cleared. <p data-bbox="290 1164 440 1198">Completion</p> <p data-bbox="290 1202 1254 1236">Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Setting range	Initial setting	M.Cnt A	Preset values for maintenance cycle (A)	0 to 9999999	200000	M.Cnt B	Preset values for maintenance cycle (B)	0 to 9999999	200000	M.Cnt HT	Preset values for automatic grayscale adjustment	0 to 9999999	0
Display	Description	Setting range	Initial setting														
M.Cnt A	Preset values for maintenance cycle (A)	0 to 9999999	200000														
M.Cnt B	Preset values for maintenance cycle (B)	0 to 9999999	200000														
M.Cnt HT	Preset values for automatic grayscale adjustment	0 to 9999999	0														

Item No.	Description																
U251	<p data-bbox="288 241 847 271">Checking/clearing the maintenance counter</p> <p data-bbox="288 311 440 340">Description</p> <p data-bbox="288 344 1378 409">Displays and clears or changes the maintenance count and automatic grayscale adjustment count.</p> <p data-bbox="288 414 400 443">Purpose</p> <p data-bbox="288 448 1418 515">To verify the maintenance counter count and automatic grayscale count. Also to clear the count during maintenance service.</p> <p data-bbox="288 555 384 584">Setting</p> <ol data-bbox="304 589 1126 687" style="list-style-type: none"> 1. Press the start key. 2. Select the item to be changed. 3. Change the setting using the cursor left/right keys or numeric keys. <table border="1" data-bbox="319 698 1401 927"> <thead> <tr> <th data-bbox="319 698 513 781">Display</th> <th data-bbox="513 698 1032 781">Description</th> <th data-bbox="1032 698 1246 781">Setting range</th> <th data-bbox="1246 698 1401 781">Initial setting</th> </tr> </thead> <tbody> <tr> <td data-bbox="319 781 513 831">M.Cnt A</td> <td data-bbox="513 781 1032 831">Count value for maintenance cycle (A)</td> <td data-bbox="1032 781 1246 831">0 to 9999999</td> <td data-bbox="1246 781 1401 831">0</td> </tr> <tr> <td data-bbox="319 831 513 880">M.Cnt B</td> <td data-bbox="513 831 1032 880">Count value for maintenance cycle (B)</td> <td data-bbox="1032 831 1246 880">0 to 9999999</td> <td data-bbox="1246 831 1401 880">0</td> </tr> <tr> <td data-bbox="319 880 513 927">M.Cnt HT</td> <td data-bbox="513 880 1032 927">Automatic grayscale adjustment count</td> <td data-bbox="1032 880 1246 927">0 to 9999999</td> <td data-bbox="1246 880 1401 927">0</td> </tr> </tbody> </table> <ol data-bbox="304 952 852 981" style="list-style-type: none"> 4. Press the start key. The setting value is set. <p data-bbox="288 1021 400 1050">Clearing</p> <ol data-bbox="304 1055 903 1120" style="list-style-type: none"> 1. Select [Clear]. 2. Press the start key. The setting value is cleared. <p data-bbox="288 1160 440 1189">Completion</p> <p data-bbox="288 1193 1254 1223">Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Setting range	Initial setting	M.Cnt A	Count value for maintenance cycle (A)	0 to 9999999	0	M.Cnt B	Count value for maintenance cycle (B)	0 to 9999999	0	M.Cnt HT	Automatic grayscale adjustment count	0 to 9999999	0
Display	Description	Setting range	Initial setting														
M.Cnt A	Count value for maintenance cycle (A)	0 to 9999999	0														
M.Cnt B	Count value for maintenance cycle (B)	0 to 9999999	0														
M.Cnt HT	Automatic grayscale adjustment count	0 to 9999999	0														

Item No.	Description																												
U252	<p data-bbox="290 241 580 271">Setting the destination</p> <p data-bbox="290 311 440 340">Description</p> <p data-bbox="290 344 1254 374">Switches the operations and screens of the machine according to the destination.</p> <p data-bbox="290 380 400 409">Purpose</p> <p data-bbox="290 414 1426 479">To be executed after initializing the backup RAM, in order to return the setting to the value before replacement or initialization.</p> <p data-bbox="290 517 387 546">Method</p> <ol data-bbox="308 553 600 618" style="list-style-type: none"> 1. Press the start key. 2. Select the destination. <table border="1" data-bbox="336 631 1401 1014"> <thead> <tr> <th data-bbox="336 631 639 676">Display</th> <th data-bbox="639 631 1401 676">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 676 639 721">Japan Metric</td> <td data-bbox="639 676 1401 721">Metric (Japan) specifications</td> </tr> <tr> <td data-bbox="336 721 639 766">Inch</td> <td data-bbox="639 721 1401 766">Inch (North America) specifications</td> </tr> <tr> <td data-bbox="336 766 639 810">Europe Metric</td> <td data-bbox="639 766 1401 810">Metric (Europe) specifications</td> </tr> <tr> <td data-bbox="336 810 639 855">Asia Pacific</td> <td data-bbox="639 810 1401 855">Metric (Asia Pacific) specifications</td> </tr> <tr> <td data-bbox="336 855 639 900">Australia</td> <td data-bbox="639 855 1401 900">Australia specifications</td> </tr> <tr> <td data-bbox="336 900 639 945">China</td> <td data-bbox="639 900 1401 945">China specifications</td> </tr> <tr> <td data-bbox="336 945 639 1014">Korea</td> <td data-bbox="639 945 1401 1014">Korea specifications</td> </tr> </tbody> </table> <ol data-bbox="308 1025 798 1090" style="list-style-type: none"> 3. Press the start key. 4. Turn the main power switch off and on. <p data-bbox="336 1095 1059 1124">* : An error code is displayed in case of an initialization error.</p> <p data-bbox="371 1128 1426 1193">When errors occurred, turn main power switch off then on, and execute initialization using maintenance item U252.</p> <p data-bbox="336 1232 488 1261">Error codes</p> <table border="1" data-bbox="336 1274 1401 1563"> <thead> <tr> <th data-bbox="336 1274 639 1319">Codes</th> <th data-bbox="639 1274 1401 1319">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1319 639 1364">0001</td> <td data-bbox="639 1319 1401 1364">Entity error</td> </tr> <tr> <td data-bbox="336 1364 639 1408">0002</td> <td data-bbox="639 1364 1401 1408">Controller error</td> </tr> <tr> <td data-bbox="336 1408 639 1453">0003</td> <td data-bbox="639 1408 1401 1453">OS error</td> </tr> <tr> <td data-bbox="336 1453 639 1498">0020</td> <td data-bbox="639 1453 1401 1498">Engine error</td> </tr> <tr> <td data-bbox="336 1498 639 1563">0040</td> <td data-bbox="639 1498 1401 1563">Scanner error</td> </tr> </tbody> </table>	Display	Description	Japan Metric	Metric (Japan) specifications	Inch	Inch (North America) specifications	Europe Metric	Metric (Europe) specifications	Asia Pacific	Metric (Asia Pacific) specifications	Australia	Australia specifications	China	China specifications	Korea	Korea specifications	Codes	Description	0001	Entity error	0002	Controller error	0003	OS error	0020	Engine error	0040	Scanner error
Display	Description																												
Japan Metric	Metric (Japan) specifications																												
Inch	Inch (North America) specifications																												
Europe Metric	Metric (Europe) specifications																												
Asia Pacific	Metric (Asia Pacific) specifications																												
Australia	Australia specifications																												
China	China specifications																												
Korea	Korea specifications																												
Codes	Description																												
0001	Entity error																												
0002	Controller error																												
0003	OS error																												
0020	Engine error																												
0040	Scanner error																												

Item No.	Description																
U253	<p>Switching between double and single counts</p> <p>Description Switches the count system for the total counter and other counters.</p> <p>Purpose Used to select, according to the preference of the user (copy service provider), if folio size paper is to be counted as one sheet (single count) or two sheets (double count).</p> <p>Setting</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select the item to set. <table border="1" data-bbox="336 629 1401 752"> <thead> <tr> <th>Display</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>Color</td> <td>Count system of color mode</td> </tr> <tr> <td>B/W</td> <td>Count system of black/white mode</td> </tr> </tbody> </table> <ol style="list-style-type: none"> 3. Select the count system. <table border="1" data-bbox="336 817 1401 1055"> <thead> <tr> <th>Display</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>SGL (All)</td> <td>Single count for all size paper</td> </tr> <tr> <td>DBL (A3/Ledger)</td> <td>Double count for A3/Ledger size or larger</td> </tr> <tr> <td>DBL (B4)</td> <td>Double count for B4 size or larger</td> </tr> <tr> <td>DBLFolio)</td> <td>Double count for Folio size or larger</td> </tr> </tbody> </table> <p>* : Initial setting: DBL (A3/Ledger)</p> <ol style="list-style-type: none"> 4. Press the start key. The setting is set. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Color	Count system of color mode	B/W	Count system of black/white mode	Display	Description	SGL (All)	Single count for all size paper	DBL (A3/Ledger)	Double count for A3/Ledger size or larger	DBL (B4)	Double count for B4 size or larger	DBLFolio)	Double count for Folio size or larger
Display	Description																
Color	Count system of color mode																
B/W	Count system of black/white mode																
Display	Description																
SGL (All)	Single count for all size paper																
DBL (A3/Ledger)	Double count for A3/Ledger size or larger																
DBL (B4)	Double count for B4 size or larger																
DBLFolio)	Double count for Folio size or larger																
U260	<p>Selecting the timing for copy counting</p> <p>Description Changes the copy count timing for the total counter and other counters.</p> <p>Purpose To be set according to user request.</p> <p>Setting</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select the copy count timing. <table border="1" data-bbox="336 1644 1401 1789"> <thead> <tr> <th>Display</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>Feed</td> <td>When secondary paper feed starts</td> </tr> <tr> <td>Eject</td> <td>When the paper is ejected</td> </tr> </tbody> </table> <p>* : Initial setting: Eject</p> <ol style="list-style-type: none"> 3. Press the start key. The setting is set. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Feed	When secondary paper feed starts	Eject	When the paper is ejected										
Display	Description																
Feed	When secondary paper feed starts																
Eject	When the paper is ejected																

Item No.	Description								
U265	<p>Setting OEM purchaser code</p> <p>Description Sets the OEM purchaser code.</p> <p>Purpose Sets the code when replacing the main PWB and the like.</p> <p>Setting</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Change the preset value using the numeric keys. 3. Press the start key. The setting is set. 4. Turn the main power switch off and on. 								
U285	<p>Setting service status page</p> <p>Description Determines displaying the print coverage report on reporting.</p> <p>Purpose According to user request, changes the setting.</p> <p>Setting</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select [On] or [Off]. <table border="1" data-bbox="336 1025 1401 1169"> <thead> <tr> <th data-bbox="336 1025 641 1070">Display</th> <th data-bbox="641 1025 1401 1070">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1070 641 1115">On</td> <td data-bbox="641 1070 1401 1115">Displays the print coverage</td> </tr> <tr> <td data-bbox="336 1115 641 1169">Off</td> <td data-bbox="641 1115 1401 1169">Not to display the print coverage</td> </tr> </tbody> </table> <p>* : Initial setting: On</p> <ol style="list-style-type: none"> 3. Press the start key. The setting is set. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	On	Displays the print coverage	Off	Not to display the print coverage		
Display	Description								
On	Displays the print coverage								
Off	Not to display the print coverage								
U325	<p>Setting the paper interval</p> <p>Description Determines the interval between pages and the toner replenishment amount when printing pages with high print coverage.</p> <p>Purpose Modify the settings only if a spotted background or uneven density appears when printing pages with high print coverage.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Change the setting using the cursor left/right keys or numeric keys. <table border="1" data-bbox="319 1756 1398 1886"> <thead> <tr> <th data-bbox="319 1756 501 1832">Display</th> <th data-bbox="501 1756 1015 1832">Description</th> <th data-bbox="1015 1756 1225 1832">Setting range</th> <th data-bbox="1225 1756 1398 1832">Initial setting</th> </tr> </thead> <tbody> <tr> <td data-bbox="319 1832 501 1886">Rank</td> <td data-bbox="501 1832 1015 1886">Setting the rank</td> <td data-bbox="1015 1832 1225 1886">0 to 4</td> <td data-bbox="1225 1832 1398 1886">1</td> </tr> </tbody> </table> <ol style="list-style-type: none"> 3. Press the start key. The setting value is set. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Setting range	Initial setting	Rank	Setting the rank	0 to 4	1
Display	Description	Setting range	Initial setting						
Rank	Setting the rank	0 to 4	1						



Item No.	Description																				
U326	<p data-bbox="288 241 810 275">Setting the black line cleaning indication</p> <p data-bbox="288 311 440 340">Description</p> <p data-bbox="288 344 1193 376">Sets whether to display the cleaning guidance when detecting the black line.</p> <p data-bbox="288 380 400 409">Purpose</p> <p data-bbox="288 414 1422 481">Displays the cleaning guidance in order to make the call for service with the black line decrease by the rubbish on the contact glass when scanning from the DP.</p> <p data-bbox="288 517 387 546">Method</p> <ol data-bbox="308 553 1139 618" style="list-style-type: none"> 1. Press the start key. 2. Select the item to set. The screen for setting each item is displayed. <table border="1" data-bbox="336 631 1401 777"> <thead> <tr> <th data-bbox="336 631 639 678">Display</th> <th data-bbox="639 631 1401 678">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 678 639 725">Black Line Mode</td> <td data-bbox="639 678 1401 725">Black line cleaning guidance ON/OFF setting</td> </tr> <tr> <td data-bbox="336 725 639 777">Black Line Cnt</td> <td data-bbox="639 725 1401 777">Setting counts of the cleaning guidance indication</td> </tr> </tbody> </table> <p data-bbox="288 819 628 851">Setting: [Black Line Mode]</p> <ol data-bbox="308 855 564 887" style="list-style-type: none"> 1. Select [On] or [Off]. <table border="1" data-bbox="336 898 1401 1043"> <thead> <tr> <th data-bbox="336 898 639 945">Display</th> <th data-bbox="639 898 1401 945">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 945 639 992">On</td> <td data-bbox="639 945 1401 992">Displays the cleaning guidance</td> </tr> <tr> <td data-bbox="336 992 639 1043">Off</td> <td data-bbox="639 992 1401 1043">Not to display the cleaning guidance</td> </tr> </tbody> </table> <p data-bbox="336 1055 576 1086">* : Initial setting: On</p> <ol data-bbox="308 1090 782 1122" style="list-style-type: none"> 2. Press the start key. The setting is set. <p data-bbox="288 1158 603 1189">Setting: [Black Line Cnt]</p> <ol data-bbox="308 1193 1198 1258" style="list-style-type: none"> 1. Select [Cnt]. 2. Change the setting value using the cursor left/right keys or numeric keys. <table border="1" data-bbox="336 1270 1401 1438"> <thead> <tr> <th data-bbox="336 1270 564 1352">Display</th> <th data-bbox="564 1270 1066 1352">Description</th> <th data-bbox="1066 1270 1233 1352">Setting range</th> <th data-bbox="1233 1270 1401 1352">Initial setting</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1352 564 1438">Cnt</td> <td data-bbox="564 1352 1066 1438">Setting counts of the cleaning guidance indication (x 1000 sheets)</td> <td data-bbox="1066 1352 1233 1438">0 to 255</td> <td data-bbox="1233 1352 1401 1438">8</td> </tr> </tbody> </table> <p data-bbox="336 1447 1394 1512">* : When setting is 0, the black line cleaning indication is displayed only if the black line is detected.</p> <ol data-bbox="308 1516 767 1547" style="list-style-type: none"> 3. Press the start key. The value is set. <p data-bbox="288 1583 440 1615">Completion</p> <p data-bbox="288 1619 1254 1650">Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Black Line Mode	Black line cleaning guidance ON/OFF setting	Black Line Cnt	Setting counts of the cleaning guidance indication	Display	Description	On	Displays the cleaning guidance	Off	Not to display the cleaning guidance	Display	Description	Setting range	Initial setting	Cnt	Setting counts of the cleaning guidance indication (x 1000 sheets)	0 to 255	8
Display	Description																				
Black Line Mode	Black line cleaning guidance ON/OFF setting																				
Black Line Cnt	Setting counts of the cleaning guidance indication																				
Display	Description																				
On	Displays the cleaning guidance																				
Off	Not to display the cleaning guidance																				
Display	Description	Setting range	Initial setting																		
Cnt	Setting counts of the cleaning guidance indication (x 1000 sheets)	0 to 255	8																		

Item No.	Description								
U332	<p>Setting the size conversion factor</p> <p>Description Sets the coefficient of nonstandard sizes in relation to the A4/Letter size. The coefficient set here is used to convert the black ratio in relation to the A4/Letter size and to display the result in user simulation.</p> <p>Purpose To set the coefficient for converting the black ratio for nonstandard sizes in relation to the A4/Letter size.</p> <p>Setting</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select [Rate]. 3. Change the setting using the cursor left/right keys or numeric keys. <table border="1" data-bbox="336 734 1401 831"> <thead> <tr> <th>Display</th> <th>Description</th> <th>Setting range</th> <th>Initial setting</th> </tr> </thead> <tbody> <tr> <td>Rate</td> <td>Size parameter</td> <td>0.1 to 3.0</td> <td>1.0</td> </tr> </tbody> </table> <ol style="list-style-type: none"> 4. Press the start key. The value is set. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Setting range	Initial setting	Rate	Size parameter	0.1 to 3.0	1.0
Display	Description	Setting range	Initial setting						
Rate	Size parameter	0.1 to 3.0	1.0						
U341	<p>Specific paper feed location setting for printing function</p> <p>Description Sets a paper feed location specified for printer output.</p> <p>Purpose To use a paper feed location only for printer output. A paper feed location specified for printer output cannot be used for copy output.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select the paper feed location for the printer. 3. Select [On] or [Off] using the cursor left/right keys. <table border="1" data-bbox="336 1451 1401 1644"> <thead> <tr> <th>Display</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>Cassette1</td> <td>Cassette 1</td> </tr> <tr> <td>Cassette2</td> <td>Cassette 2 (optional paper feeder)</td> </tr> <tr> <td>Cassette3</td> <td>Cassette 3 (optional paper feeder)</td> </tr> </tbody> </table> <p>* : When an optional paper feed device is not installed, the corresponding count is not displayed.</p> <ol style="list-style-type: none"> 4. Press the start key. The setting is set. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Cassette1	Cassette 1	Cassette2	Cassette 2 (optional paper feeder)	Cassette3	Cassette 3 (optional paper feeder)
Display	Description								
Cassette1	Cassette 1								
Cassette2	Cassette 2 (optional paper feeder)								
Cassette3	Cassette 3 (optional paper feeder)								

Item No.	Description								
U343	<p>Switching between duplex/simplex copy mode</p> <p>Description Switches the initial setting between duplex and simplex copy.</p> <p>Purpose To be set according to frequency of use: set to the more frequently used mode.</p> <p>Setting</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select [On] or [Off]. <table border="1" data-bbox="336 595 1401 741"> <thead> <tr> <th data-bbox="336 595 639 640">Display</th> <th data-bbox="639 595 1401 640">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 640 639 685">On</td> <td data-bbox="639 640 1401 685">Duplex copy</td> </tr> <tr> <td data-bbox="336 685 639 741">Off</td> <td data-bbox="639 685 1401 741">Simplex copy</td> </tr> </tbody> </table> <p>* : Initial setting: Off</p> <ol style="list-style-type: none"> 3. Press the start key. The setting is set. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	On	Duplex copy	Off	Simplex copy		
Display	Description								
On	Duplex copy								
Off	Simplex copy								
U345	<p>Setting the value for maintenance due indication</p> <p>Description Sets when to display a message notifying that the time for maintenance is about to be reached, by setting the number of copies that can be made before the current maintenance cycle ends. When the difference between the number of copies of the maintenance cycle and that of the maintenance count reaches the set value, the message is displayed.</p> <p>Purpose To change the time for maintenance due indication.</p> <p>Setting</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select [Cnt]. 3. Change the setting using the cursor left/right keys or numeric keys. <table border="1" data-bbox="336 1440 1401 1637"> <thead> <tr> <th data-bbox="336 1440 488 1518">Display</th> <th data-bbox="488 1440 1098 1518">Description</th> <th data-bbox="1098 1440 1249 1518">Setting range</th> <th data-bbox="1249 1440 1401 1518">Initial setting</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1518 488 1637">Cnt</td> <td data-bbox="488 1518 1098 1637">Time for maintenance due indication (Remaining number of copies that can be made before the current maintenance cycle ends)</td> <td data-bbox="1098 1518 1249 1637">0 to 9999</td> <td data-bbox="1249 1518 1401 1637">0</td> </tr> </tbody> </table> <ol style="list-style-type: none"> 4. Press the start key. The value is set. <p>Clearing</p> <ol style="list-style-type: none"> 1. Select [Clear]. 2. Press the start key. The value is cleared. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Setting range	Initial setting	Cnt	Time for maintenance due indication (Remaining number of copies that can be made before the current maintenance cycle ends)	0 to 9999	0
Display	Description	Setting range	Initial setting						
Cnt	Time for maintenance due indication (Remaining number of copies that can be made before the current maintenance cycle ends)	0 to 9999	0						

Item No.	Description																									
U402	<p>Adjusting margins of image printing</p> <p>Description Adjusts margins for image printing.</p> <p>Purpose Make the adjustment if margins are incorrect.</p> <p>Adjustment</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Press the system menu key. 3. Press the start key to output a test pattern. 4. Press the system menu key. 5. Select the item to be adjusted. <table border="1" data-bbox="336 698 1401 974"> <thead> <tr> <th>Display</th> <th>Description</th> <th>Setting range</th> <th>Initial setting</th> <th>Change in value per step</th> </tr> </thead> <tbody> <tr> <td>Lead</td> <td>Printer leading edge margin</td> <td>0 to 10.0</td> <td>3.0</td> <td>0.1 mm</td> </tr> <tr> <td>A Margin</td> <td>Printer left margin</td> <td>0 to 10.0</td> <td>2.5</td> <td>0.1 mm</td> </tr> <tr> <td>C Margin</td> <td>Printer right margin</td> <td>0 to 10.0</td> <td>2.5</td> <td>0.1 mm</td> </tr> <tr> <td>Trail</td> <td>Printer trailing edge margin</td> <td>0 to 10.0</td> <td>5.0</td> <td>0.1 mm</td> </tr> </tbody> </table> <ol style="list-style-type: none"> 6. Change the setting value using the cursor left/right keys or numeric keys. Increasing the value makes the margin wider, and decreasing it makes the margin narrower. <div data-bbox="529 1077 1197 1496" style="text-align: center;"> <p>Printer leading edge margin (3.0 ± 2.5 mm)</p> <p>Printer left margin (2.0 +2.0/-1.5 mm)</p> <p>Printer right margin (2.0 +2.0/-1.5 mm)</p> <p>Printer trailing edge margin (3.0 ± 2.5 mm)</p> </div> <p>Figure 1-3-14</p> <ol style="list-style-type: none"> 7. Press the start key. The value is set. <p>Caution Check the copy image after the adjustment. If the image is still incorrect, perform the following adjustments in maintenance mode.</p> <div data-bbox="293 1778 903 1872" style="text-align: center;"> <pre> graph LR U402[U402] --> U403[U403 (P.1-3-78)] U403 --> U404[U404 (P.1-3-79)] </pre> </div> <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Setting range	Initial setting	Change in value per step	Lead	Printer leading edge margin	0 to 10.0	3.0	0.1 mm	A Margin	Printer left margin	0 to 10.0	2.5	0.1 mm	C Margin	Printer right margin	0 to 10.0	2.5	0.1 mm	Trail	Printer trailing edge margin	0 to 10.0	5.0	0.1 mm
Display	Description	Setting range	Initial setting	Change in value per step																						
Lead	Printer leading edge margin	0 to 10.0	3.0	0.1 mm																						
A Margin	Printer left margin	0 to 10.0	2.5	0.1 mm																						
C Margin	Printer right margin	0 to 10.0	2.5	0.1 mm																						
Trail	Printer trailing edge margin	0 to 10.0	5.0	0.1 mm																						

Item No.	Description																												
U403	<p data-bbox="288 241 1102 275">Adjusting margins for scanning an original on the contact glass</p> <p data-bbox="288 311 440 340">Description</p> <p data-bbox="288 344 1023 376">Adjusts margins for scanning the original on the contact glass.</p> <p data-bbox="288 383 400 412">Purpose</p> <p data-bbox="288 416 855 448">Perform the adjustment if margins are incorrect.</p> <p data-bbox="288 483 440 512">Adjustment</p> <ol data-bbox="308 517 1054 685" style="list-style-type: none"> 1. Press the start key. 2. Press the system menu key. 3. Place an original and press the start key to make a test copy. 4. Press the system menu key. 5. Select the item to be adjusted. <table border="1" data-bbox="336 701 1401 976"> <thead> <tr> <th>Display</th> <th>Description</th> <th>Setting range</th> <th>Initial setting</th> <th>Change in value per step</th> </tr> </thead> <tbody> <tr> <td>A Margin</td> <td>Scanner left margin</td> <td>0 to 10.0</td> <td>2.0</td> <td>0.5 mm</td> </tr> <tr> <td>B Margin</td> <td>Scanner leading edge margin</td> <td>0 to 10.0</td> <td>2.0</td> <td>0.5 mm</td> </tr> <tr> <td>C Margin</td> <td>Scanner right margin</td> <td>0 to 10.0</td> <td>2.0</td> <td>0.5 mm</td> </tr> <tr> <td>D Margin</td> <td>Scanner trailing edge margin</td> <td>0 to 10.0</td> <td>2.0</td> <td>0.5 mm</td> </tr> </tbody> </table> <ol data-bbox="308 987 1425 1055" style="list-style-type: none"> 6. Change the setting value using the cursor left/right keys or numeric keys. Increasing the value makes the margin wider, and decreasing it makes the margin narrower. <div data-bbox="528 1077 1193 1496" style="text-align: center;"> <p>The diagram shows a rectangular scanner bed with four margin indicators. At the top, 'Scanner leading edge margin (3.0 ± 2.5 mm)' is indicated with a downward arrow. At the bottom, 'Scanner trailing edge margin (3.0 ± 2.0 mm)' is indicated with an upward arrow. On the left side, 'Scanner left margin (2.5 +1.5/-2.0 mm)' is indicated with a rightward arrow. On the right side, 'Scanner right margin (2.5 +1.5/-2.0 mm)' is indicated with a leftward arrow.</p> </div> <p data-bbox="775 1525 946 1554">Figure 1-3-15</p> <ol data-bbox="308 1592 767 1624" style="list-style-type: none"> 7. Press the start key. The value is set. <p data-bbox="288 1662 392 1691">Caution</p> <p data-bbox="288 1695 1401 1762">Check the copy image after the adjustment. If the image is still incorrect, perform the following adjustments in maintenance mode.</p> <div data-bbox="293 1778 676 1872" style="text-align: center;"> <table border="1"> <tr> <td data-bbox="293 1778 448 1872">U403</td> <td data-bbox="448 1778 520 1872">→</td> <td data-bbox="520 1778 676 1872">U404 (P.1-3-79)</td> </tr> </table> </div> <p data-bbox="288 1921 440 1951">Completion</p> <p data-bbox="288 1955 1243 1986">Press the stop key. The indication for selecting a maintenance item No. appears.</p>	Display	Description	Setting range	Initial setting	Change in value per step	A Margin	Scanner left margin	0 to 10.0	2.0	0.5 mm	B Margin	Scanner leading edge margin	0 to 10.0	2.0	0.5 mm	C Margin	Scanner right margin	0 to 10.0	2.0	0.5 mm	D Margin	Scanner trailing edge margin	0 to 10.0	2.0	0.5 mm	U403	→	U404 (P.1-3-79)
Display	Description	Setting range	Initial setting	Change in value per step																									
A Margin	Scanner left margin	0 to 10.0	2.0	0.5 mm																									
B Margin	Scanner leading edge margin	0 to 10.0	2.0	0.5 mm																									
C Margin	Scanner right margin	0 to 10.0	2.0	0.5 mm																									
D Margin	Scanner trailing edge margin	0 to 10.0	2.0	0.5 mm																									
U403	→	U404 (P.1-3-79)																											

Item No.	Description																									
<p>U404</p>	<p>Adjusting margins for scanning an original from the DP</p> <p>Description Adjusts margins for scanning the original from the DP.</p> <p>Purpose Perform the adjustment if margins are incorrect.</p> <p>Caution Before making this adjustment, ensure that the following adjustments have been made in maintenance mode</p> <div style="text-align: center;">  <pre> graph LR U402["U402 (P.1-3-77)"] --> U403["U403 (P.1-3-78)"] U403 --> U404["U404"] </pre> </div> <p>Adjustment</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Press the system menu key. 3. Place an original on the DP and press the start key to make a test copy. 4. Press the system menu key. 5. Select the item to be adjusted. <table border="1" data-bbox="336 958 1401 1234"> <thead> <tr> <th>Display</th> <th>Description</th> <th>Setting range</th> <th>Initial setting</th> <th>Change in value per step</th> </tr> </thead> <tbody> <tr> <td>A Margin</td> <td>DP left margin</td> <td>0 to 10.0</td> <td>3.0</td> <td>0.5 mm</td> </tr> <tr> <td>B Margin</td> <td>DP leading edge margin</td> <td>0 to 10.0</td> <td>2.5</td> <td>0.5 mm</td> </tr> <tr> <td>C Margin</td> <td>DP right margin</td> <td>0 to 10.0</td> <td>3.0</td> <td>0.5 mm</td> </tr> <tr> <td>D Margin</td> <td>DP trailing edge margin</td> <td>0 to 10.0</td> <td>4.0</td> <td>0.5 mm</td> </tr> </tbody> </table> <ol style="list-style-type: none"> 6. Change the setting value using the cursor left/right keys or numeric keys. Increasing the value makes the margin wider, and decreasing it makes the margin narrower. <div style="text-align: center;">  </div> <p>Figure 1-3-16</p> <ol style="list-style-type: none"> 7. Press the start key. The value is set. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Setting range	Initial setting	Change in value per step	A Margin	DP left margin	0 to 10.0	3.0	0.5 mm	B Margin	DP leading edge margin	0 to 10.0	2.5	0.5 mm	C Margin	DP right margin	0 to 10.0	3.0	0.5 mm	D Margin	DP trailing edge margin	0 to 10.0	4.0	0.5 mm
Display	Description	Setting range	Initial setting	Change in value per step																						
A Margin	DP left margin	0 to 10.0	3.0	0.5 mm																						
B Margin	DP leading edge margin	0 to 10.0	2.5	0.5 mm																						
C Margin	DP right margin	0 to 10.0	3.0	0.5 mm																						
D Margin	DP trailing edge margin	0 to 10.0	4.0	0.5 mm																						

Item No.	Description										
<p>U407</p>	<p>Adjusting the leading edge registration for memory image printing</p> <p>Description Adjusts the leading edge registration during memory copying.</p> <p>Purpose Perform the following adjustment if there is a regular error between the leading edge of the copy image on the front face and that on the reverse face during duplex switchback copying.</p> <p>Caution Before Performing this adjustment, ensure that the following adjustments have been made in maintenance mode.</p> <div data-bbox="293 633 1433 842" style="border: 1px solid black; padding: 5px; margin: 10px 0;"> <pre> graph LR U034["U034 (P.1-3-24)"] --> U402["U402 (P.1-3-77)"] U402 --> U066["U066 (P.1-3-33)"] U066 --> U403["U403 (P.1-3-78)"] U403 --> U071["U071 (P.1-3-38)"] U071 --> Arrow1[] U404["U404 (P.1-3-79)"] --> U407["U407"] </pre> </div> <p>Adjustment</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Press the system menu key. 3. Place an original and press the start key to make a test copy. 4. Press the system menu key. 5. Select [Adj Data]. <table border="1" data-bbox="336 1111 1401 1274" style="width: 100%; border-collapse: collapse; text-align: center;"> <thead> <tr> <th>Display</th> <th>Description</th> <th>Setting range</th> <th>Initial setting</th> <th>Change in value per step</th> </tr> </thead> <tbody> <tr> <td>Adj Data</td> <td>Leading edge registration for memory image printing</td> <td>-47 to 47</td> <td>0</td> <td>0.1 mm</td> </tr> </tbody> </table> <ol style="list-style-type: none"> 6. Change the setting value using the cursor left/right keys or numeric keys. For copy example 1, decrease the value. For copy example 2, increase the value. <div data-bbox="655 1375 1066 1617" style="text-align: center; margin: 10px 0;"> <div style="display: flex; justify-content: space-around; width: 100%;"> <div style="text-align: center;">Original</div> <div style="text-align: center;">Copy example 1</div> <div style="text-align: center;">Copy example 2</div> </div> </div> <p style="text-align: center;">Figure 1-3-17</p> <ol style="list-style-type: none"> 7. Press the start key. The value is set. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Setting range	Initial setting	Change in value per step	Adj Data	Leading edge registration for memory image printing	-47 to 47	0	0.1 mm
Display	Description	Setting range	Initial setting	Change in value per step							
Adj Data	Leading edge registration for memory image printing	-47 to 47	0	0.1 mm							



Item No.	Description															
U411	<p>Adjusting the scanner automatically</p> <p>Description Uses a specified original and automatically adjusts the following items in the scanner and the DP scanning sections. Scanner section: Original size magnification, leading edge timing, center line, input gamma, input gamma in monochrome mode and matrix DP scanning section: Original size magnification, leading edge timing, center line</p> <p>Purpose To perform automatic adjustment of various items in the scanner and the DP scanning sections.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select the item. <table border="1" data-bbox="336 734 1401 1149"> <thead> <tr> <th data-bbox="336 734 564 815">Display</th> <th data-bbox="564 734 1098 815">Description</th> <th data-bbox="1098 734 1401 815">Original to be used for adjustment (P/N)</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 815 564 896">Table</td> <td data-bbox="564 815 1098 896">Automatic adjustment in the scanner section</td> <td data-bbox="1098 815 1401 896">7505000005</td> </tr> <tr> <td data-bbox="336 896 564 976">DP</td> <td data-bbox="564 896 1098 976">Automatic adjustment in the DP scanning section:</td> <td data-bbox="1098 896 1401 976">302AC68243</td> </tr> <tr> <td data-bbox="336 976 564 1104">All</td> <td data-bbox="564 976 1098 1104">Performs automatic adjustment in the DP scanning section following automatic adjustment in the scanner section</td> <td data-bbox="1098 976 1401 1104">7505000005/ 302AC68243</td> </tr> <tr> <td data-bbox="336 1104 564 1149">Target</td> <td data-bbox="564 1104 1098 1149">Set-up for obtaining the target value</td> <td data-bbox="1098 1104 1401 1149">-</td> </tr> </tbody> </table> <p>Method: Table</p> <p>To manually enter the target value</p> <ol style="list-style-type: none"> 1. Enter the target values which are shown on the specified original (P/N: 7505000005) executing maintenance item U425. 2. Set a specified original (P/N: 7505000005) on the platen. 3. Enter maintenance item U411. 4. Select [Target]. 5. Select [U425] using the cursor left/right keys. 6. Select [Table]. 7. Press the start key. Auto adjustment starts. <p>To manually enter the target value</p> <p>The accuracy of adjustment is worse than the manual entry.</p> <ol style="list-style-type: none"> 1. Set a specified original (P/N: 7505000005) on the platen. 2. Enter maintenance item U411. 3. Select [Target]. 4. Select [Auto] using the cursor left/right keys. 5. Select [Table]. 6. Press the start key. Auto adjustment starts. <p>* : When automatic adjustment has normally completed, [OK] is displayed. If a problem occurs during auto adjustment, [NG XX] (XX is replaced by an error code) is displayed and operation stops. Should this happen, determine the details of the problem and repeat the procedure from the beginning.</p>	Display	Description	Original to be used for adjustment (P/N)	Table	Automatic adjustment in the scanner section	7505000005	DP	Automatic adjustment in the DP scanning section:	302AC68243	All	Performs automatic adjustment in the DP scanning section following automatic adjustment in the scanner section	7505000005/ 302AC68243	Target	Set-up for obtaining the target value	-
Display	Description	Original to be used for adjustment (P/N)														
Table	Automatic adjustment in the scanner section	7505000005														
DP	Automatic adjustment in the DP scanning section:	302AC68243														
All	Performs automatic adjustment in the DP scanning section following automatic adjustment in the scanner section	7505000005/ 302AC68243														
Target	Set-up for obtaining the target value	-														

Item No.	Description																																																		
U411	<p>Method: DP</p> <ol style="list-style-type: none"> 1. Select [DP]. 2. Set a specified original (P/N: 302AC68243) in the DP. <ul style="list-style-type: none"> * : When running this test chart, you first must clean the feed rollers with alcohol and ensure the DP width guides are correctly positioned against the original. 3. Press the start key. Auto adjustment starts. <ul style="list-style-type: none"> * : When automatic adjustment has normally completed, [OK] is displayed. If a problem occurs during auto adjustment, [NG XX] (XX is replaced by an error code) is displayed and operation stops. Should this happen, determine the details of the problem and repeat the procedure from the beginning. <p>Error Codes</p> <table border="1" data-bbox="335 660 1412 1926"> <thead> <tr> <th data-bbox="343 660 454 705">Codes</th> <th data-bbox="454 660 1404 705">Description</th> </tr> </thead> <tbody> <tr><td>00</td><td>Automatic adjustment success</td></tr> <tr><td>01</td><td>Black band detection error (scanner leading edge registration)</td></tr> <tr><td>03</td><td>Black band detection error (scanner main scanning direction magnification)</td></tr> <tr><td>04</td><td>Black band is not detected (scanner leading edge registration)</td></tr> <tr><td>05</td><td>Black band is not detected (scanner center line)</td></tr> <tr><td>06</td><td>Black band is not detected (scanner main scanning direction magnification)</td></tr> <tr><td>07</td><td>Black band is not detected (scanner auxiliary scanning direction magnification)</td></tr> <tr><td>08</td><td>Black band is not detected (DP main scanning direction magnification far end)</td></tr> <tr><td>09</td><td>Black band is not detected (DP main scanning direction magnification near end)</td></tr> <tr><td>0a</td><td>Black band is not detected (DP auxiliary scanning direction magnification leading edge)</td></tr> <tr><td>0b</td><td>Black band is not detected (DP auxiliary scanning direction magnification leading edge original check)</td></tr> <tr><td>0c</td><td>Black band is not detected (DP auxiliary scanning direction trailing edge)</td></tr> <tr><td>0d</td><td>White band is not detected (DP auxiliary scanning direction trailing edge 2)</td></tr> <tr><td>0e</td><td>DMA time out</td></tr> <tr><td>0f</td><td>Auxiliary scanning direction magnification error</td></tr> <tr><td>10</td><td>Auxiliary scanning direction leading edge detection error</td></tr> <tr><td>11</td><td>Auxiliary scanning direction trailing edge detection error</td></tr> <tr><td>12</td><td>Auxiliary scanning direction skew 1.5 error</td></tr> <tr><td>13</td><td>Maintenance request error</td></tr> <tr><td>14</td><td>Main scanning direction center line error</td></tr> <tr><td>15</td><td>Main scanning direction skew 1.5 error</td></tr> <tr><td>16</td><td>Main scanning direction magnification error</td></tr> <tr><td>17</td><td>Service call error</td></tr> <tr><td>18</td><td>DP paper misfeed error</td></tr> </tbody> </table>	Codes	Description	00	Automatic adjustment success	01	Black band detection error (scanner leading edge registration)	03	Black band detection error (scanner main scanning direction magnification)	04	Black band is not detected (scanner leading edge registration)	05	Black band is not detected (scanner center line)	06	Black band is not detected (scanner main scanning direction magnification)	07	Black band is not detected (scanner auxiliary scanning direction magnification)	08	Black band is not detected (DP main scanning direction magnification far end)	09	Black band is not detected (DP main scanning direction magnification near end)	0a	Black band is not detected (DP auxiliary scanning direction magnification leading edge)	0b	Black band is not detected (DP auxiliary scanning direction magnification leading edge original check)	0c	Black band is not detected (DP auxiliary scanning direction trailing edge)	0d	White band is not detected (DP auxiliary scanning direction trailing edge 2)	0e	DMA time out	0f	Auxiliary scanning direction magnification error	10	Auxiliary scanning direction leading edge detection error	11	Auxiliary scanning direction trailing edge detection error	12	Auxiliary scanning direction skew 1.5 error	13	Maintenance request error	14	Main scanning direction center line error	15	Main scanning direction skew 1.5 error	16	Main scanning direction magnification error	17	Service call error	18	DP paper misfeed error
Codes	Description																																																		
00	Automatic adjustment success																																																		
01	Black band detection error (scanner leading edge registration)																																																		
03	Black band detection error (scanner main scanning direction magnification)																																																		
04	Black band is not detected (scanner leading edge registration)																																																		
05	Black band is not detected (scanner center line)																																																		
06	Black band is not detected (scanner main scanning direction magnification)																																																		
07	Black band is not detected (scanner auxiliary scanning direction magnification)																																																		
08	Black band is not detected (DP main scanning direction magnification far end)																																																		
09	Black band is not detected (DP main scanning direction magnification near end)																																																		
0a	Black band is not detected (DP auxiliary scanning direction magnification leading edge)																																																		
0b	Black band is not detected (DP auxiliary scanning direction magnification leading edge original check)																																																		
0c	Black band is not detected (DP auxiliary scanning direction trailing edge)																																																		
0d	White band is not detected (DP auxiliary scanning direction trailing edge 2)																																																		
0e	DMA time out																																																		
0f	Auxiliary scanning direction magnification error																																																		
10	Auxiliary scanning direction leading edge detection error																																																		
11	Auxiliary scanning direction trailing edge detection error																																																		
12	Auxiliary scanning direction skew 1.5 error																																																		
13	Maintenance request error																																																		
14	Main scanning direction center line error																																																		
15	Main scanning direction skew 1.5 error																																																		
16	Main scanning direction magnification error																																																		
17	Service call error																																																		
18	DP paper misfeed error																																																		

Item No.	Description										
U411	<table border="1" data-bbox="336 286 1415 524"><thead><tr><th data-bbox="336 286 459 331">Codes</th><th data-bbox="459 286 1415 331">Description</th></tr></thead><tbody><tr><td data-bbox="336 331 459 376">1a</td><td data-bbox="459 331 1415 376">Original error (Dirt of the original for adjustment and damage)</td></tr><tr><td data-bbox="336 376 459 421">1b</td><td data-bbox="459 376 1415 421">Original error (scanner input gamma adjustment)</td></tr><tr><td data-bbox="336 421 459 465">1c</td><td data-bbox="459 421 1415 465">Original error (scanner matrix adjustment)</td></tr><tr><td data-bbox="336 465 459 524">63</td><td data-bbox="459 465 1415 524">TestRAW acquisition completion</td></tr></tbody></table> <p data-bbox="288 584 1206 651">Completion Press the stop key. The screen for selecting a maintenance item is displayed.</p>	Codes	Description	1a	Original error (Dirt of the original for adjustment and damage)	1b	Original error (scanner input gamma adjustment)	1c	Original error (scanner matrix adjustment)	63	TestRAW acquisition completion
Codes	Description										
1a	Original error (Dirt of the original for adjustment and damage)										
1b	Original error (scanner input gamma adjustment)										
1c	Original error (scanner matrix adjustment)										
63	TestRAW acquisition completion										

Item No.	Description																																						
U425	<p data-bbox="288 241 512 275">Setting the target</p> <p data-bbox="288 311 440 340">Description</p> <p data-bbox="288 344 1362 409">Enters the lab values that is indicated on the back of the chart (P/N: 7505000005) used for adjustment.</p> <p data-bbox="288 414 400 443">Purpose</p> <p data-bbox="288 448 1406 479">Performs data input in order to correct for differences in originals during automatic adjustment.</p> <p data-bbox="288 517 387 546">Method</p> <ol data-bbox="304 553 632 618" style="list-style-type: none"> 1. Press the start key. 2. Select the item to be set. <table border="1" data-bbox="336 631 1399 1254"> <thead> <tr> <th data-bbox="336 631 639 676">Display</th> <th data-bbox="639 631 1399 676">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 676 639 721">White</td> <td data-bbox="639 676 1399 721">Setting the white patch for the original for adjustment</td> </tr> <tr> <td data-bbox="336 721 639 766">Black</td> <td data-bbox="639 721 1399 766">Setting the black patch for the original for adjustment</td> </tr> <tr> <td data-bbox="336 766 639 810">Gray1</td> <td data-bbox="639 766 1399 810">Setting the Gray1 patch for the original for adjustment</td> </tr> <tr> <td data-bbox="336 810 639 855">Gray2</td> <td data-bbox="639 810 1399 855">Setting the Gray2 patch for the original for adjustment</td> </tr> <tr> <td data-bbox="336 855 639 900">Gray3</td> <td data-bbox="639 855 1399 900">Setting the Gray3 patch for the original for adjustment</td> </tr> <tr> <td data-bbox="336 900 639 945">C</td> <td data-bbox="639 900 1399 945">Setting the cyan patch for the original for adjustment</td> </tr> <tr> <td data-bbox="336 945 639 990">M</td> <td data-bbox="639 945 1399 990">Setting the magenta patch for the original for adjustment</td> </tr> <tr> <td data-bbox="336 990 639 1034">Y</td> <td data-bbox="639 990 1399 1034">Setting the yellow patch for the original for adjustment</td> </tr> <tr> <td data-bbox="336 1034 639 1079">R</td> <td data-bbox="639 1034 1399 1079">Setting the red patch for the original for adjustment</td> </tr> <tr> <td data-bbox="336 1079 639 1124">G</td> <td data-bbox="639 1079 1399 1124">Setting the green patch for the original for adjustment</td> </tr> <tr> <td data-bbox="336 1124 639 1169">B</td> <td data-bbox="639 1124 1399 1169">Setting the blue patch for the original for adjustment</td> </tr> <tr> <td data-bbox="336 1169 639 1254">Adjust Original</td> <td data-bbox="639 1169 1399 1254">Setting the main and auxiliary scanning directions</td> </tr> </tbody> </table> <ol data-bbox="304 1263 632 1294" style="list-style-type: none"> 3. Select the item to be set. <table border="1" data-bbox="336 1308 1399 1498"> <thead> <tr> <th data-bbox="336 1308 639 1352">Display</th> <th data-bbox="639 1308 1019 1352">Description</th> <th data-bbox="1019 1308 1399 1352">Setting range</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1352 639 1397">L</td> <td data-bbox="639 1352 1019 1397">Setting the L value</td> <td data-bbox="1019 1352 1399 1397">0.0 to 100.0</td> </tr> <tr> <td data-bbox="336 1397 639 1442">a</td> <td data-bbox="639 1397 1019 1442">Setting the a value</td> <td data-bbox="1019 1397 1399 1442">-200.0 to 200.0</td> </tr> <tr> <td data-bbox="336 1442 639 1498">b</td> <td data-bbox="639 1442 1019 1498">Setting the b value</td> <td data-bbox="1019 1442 1399 1498">-200.0 to 200.0</td> </tr> </tbody> </table> <ol data-bbox="304 1509 1406 1610" style="list-style-type: none"> 4. Enters the value that is indicated on the back of the chart using the cursor left/right keys or numeric keys. 5. Press the start key. The value is set. 	Display	Description	White	Setting the white patch for the original for adjustment	Black	Setting the black patch for the original for adjustment	Gray1	Setting the Gray1 patch for the original for adjustment	Gray2	Setting the Gray2 patch for the original for adjustment	Gray3	Setting the Gray3 patch for the original for adjustment	C	Setting the cyan patch for the original for adjustment	M	Setting the magenta patch for the original for adjustment	Y	Setting the yellow patch for the original for adjustment	R	Setting the red patch for the original for adjustment	G	Setting the green patch for the original for adjustment	B	Setting the blue patch for the original for adjustment	Adjust Original	Setting the main and auxiliary scanning directions	Display	Description	Setting range	L	Setting the L value	0.0 to 100.0	a	Setting the a value	-200.0 to 200.0	b	Setting the b value	-200.0 to 200.0
Display	Description																																						
White	Setting the white patch for the original for adjustment																																						
Black	Setting the black patch for the original for adjustment																																						
Gray1	Setting the Gray1 patch for the original for adjustment																																						
Gray2	Setting the Gray2 patch for the original for adjustment																																						
Gray3	Setting the Gray3 patch for the original for adjustment																																						
C	Setting the cyan patch for the original for adjustment																																						
M	Setting the magenta patch for the original for adjustment																																						
Y	Setting the yellow patch for the original for adjustment																																						
R	Setting the red patch for the original for adjustment																																						
G	Setting the green patch for the original for adjustment																																						
B	Setting the blue patch for the original for adjustment																																						
Adjust Original	Setting the main and auxiliary scanning directions																																						
Display	Description	Setting range																																					
L	Setting the L value	0.0 to 100.0																																					
a	Setting the a value	-200.0 to 200.0																																					
b	Setting the b value	-200.0 to 200.0																																					


Item No.	Description
U425	<p>Setting: [Adjust Original]</p> <ol style="list-style-type: none"> 1. Measure the distance from the leading edge to the top of black belt 1 of the original at A, B and C. Measurement procedure <ol style="list-style-type: none"> 1) Measure the distance from the leading edge to the top of black belt 1 of the original at A (30 mm from the left edge), B (148.5 mm from the left edge) and C (267 mm from the left edge), respectively. 2) Apply the following formula for the values obtained: $((A + B + C) / 3)$ 2. Enter the values solved using the cursor left/right keys or numeric keys in [Dist1]. 3. Press the start key. The value is set. 4. Measure the distance from the left edge to the right edge black belt 2 of the original at F. Measurement procedure <ol style="list-style-type: none"> 1) Measure the distance from the left edge to the right edge black belt 2 of the original at F (15 mm from the top edge of black belt 1). 5. Enter the values using the cursor left/right keys or numeric keys in [Dist2]. 6. Press the start key. The value is set. 7. Measure the distance from the top edge of black belt 1 to the bottom of black belt 3 of the original at D and E. Measurement procedure <ol style="list-style-type: none"> 1) Measure the distance from the top edge of black belt 1 to the bottom of black belt 3 of the original at D (30 mm from the left edge) and E (267 mm from the left edge), respectively. 2) Apply the following formula for the values obtained: $(D/2 + E/2)$ 8. Enter the measured value using the cursor left/right keys or numeric keys in [Dist3]. 9. Press the start key. The value is set.  <div style="border: 1px solid black; padding: 5px; width: fit-content; margin-left: auto; margin-right: auto;"> $[DIST1] = (A+B+C)/3$ $[DIST2] = F$ $[DIST3] = D/2 + E/2$ </div> <p style="text-align: center;">Original for adjustment (P/N: 7505000005)</p>

Figure 1-3-18

Completion

Press the stop key. The screen for selecting a maintenance item No. is displayed.

Item No.	Description																																
U429	<p data-bbox="287 237 778 271">Setting the offset for the color balance</p> <p data-bbox="287 304 437 333">Description</p> <p data-bbox="287 336 1370 394">Displays and changes the density for each color during copying in the various image quality modes.</p> <p data-bbox="287 398 395 427">Purpose</p> <p data-bbox="287 430 735 459">To change the balance for each color.</p> <p data-bbox="287 495 384 524">Method</p> <ol data-bbox="311 526 1345 589" style="list-style-type: none"> 1. Press the start key. 2. Select the image quality mode. The setting screen for the selected item is displayed. <table border="1" data-bbox="347 600 1412 887"> <thead> <tr> <th data-bbox="352 600 651 645">Display</th> <th data-bbox="651 600 1407 645">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="352 645 651 689">Text + Photo</td> <td data-bbox="651 645 1407 689">Density of each color in the text & photo mode</td> </tr> <tr> <td data-bbox="352 689 651 734">Photo</td> <td data-bbox="651 689 1407 734">Density of each color in the photo mode</td> </tr> <tr> <td data-bbox="352 734 651 779">Text</td> <td data-bbox="651 734 1407 779">Density of each color in the text mode</td> </tr> <tr> <td data-bbox="352 779 651 824">Graphics/Map</td> <td data-bbox="651 779 1407 824">Density of each color in the graphics/map mode</td> </tr> <tr> <td data-bbox="352 824 651 887">Copy/Print out</td> <td data-bbox="651 824 1407 887">Density of each color in the printed document mode</td> </tr> </tbody> </table> <p data-bbox="287 927 379 956">Setting</p> <ol data-bbox="311 958 1211 1021" style="list-style-type: none"> 1. Select the item to be set. 2. Change the setting value using the cursor left/right keys or numeric keys. <table border="1" data-bbox="347 1032 1412 1305"> <thead> <tr> <th data-bbox="352 1032 576 1115">Display</th> <th data-bbox="576 1032 1046 1115">Description</th> <th data-bbox="1046 1032 1230 1115">Setting range</th> <th data-bbox="1230 1032 1407 1115">Initial setting</th> </tr> </thead> <tbody> <tr> <td data-bbox="352 1115 576 1160">C</td> <td data-bbox="576 1115 1046 1160">Value of the cyan setting</td> <td data-bbox="1046 1115 1230 1160">-5 to 5</td> <td data-bbox="1230 1115 1407 1160">0</td> </tr> <tr> <td data-bbox="352 1160 576 1205">M</td> <td data-bbox="576 1160 1046 1205">Value of the magenta setting</td> <td data-bbox="1046 1160 1230 1205">-5 to 5</td> <td data-bbox="1230 1160 1407 1205">0</td> </tr> <tr> <td data-bbox="352 1205 576 1249">Y</td> <td data-bbox="576 1205 1046 1249">Value of the yellow setting</td> <td data-bbox="1046 1205 1230 1249">-5 to 5</td> <td data-bbox="1230 1205 1407 1249">0</td> </tr> <tr> <td data-bbox="352 1249 576 1305">K</td> <td data-bbox="576 1249 1046 1305">Value of the black setting</td> <td data-bbox="1046 1249 1230 1305">-5 to 5</td> <td data-bbox="1230 1249 1407 1305">0</td> </tr> </tbody> </table> <p data-bbox="347 1335 1281 1364">Increasing the value darkens the density and decreasing it lightens the density.</p> <ol data-bbox="311 1366 778 1395" style="list-style-type: none"> 3. Press the start key. The value is set. <p data-bbox="287 1431 443 1460">Supplement</p> <p data-bbox="287 1462 1414 1525">While this maintenance item is being executed, copying from an original is available in interrupt copying mode (which is activated by pressing the system menu key).</p> <p data-bbox="287 1561 437 1590">Completion</p> <p data-bbox="287 1592 1251 1621">Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Text + Photo	Density of each color in the text & photo mode	Photo	Density of each color in the photo mode	Text	Density of each color in the text mode	Graphics/Map	Density of each color in the graphics/map mode	Copy/Print out	Density of each color in the printed document mode	Display	Description	Setting range	Initial setting	C	Value of the cyan setting	-5 to 5	0	M	Value of the magenta setting	-5 to 5	0	Y	Value of the yellow setting	-5 to 5	0	K	Value of the black setting	-5 to 5	0
Display	Description																																
Text + Photo	Density of each color in the text & photo mode																																
Photo	Density of each color in the photo mode																																
Text	Density of each color in the text mode																																
Graphics/Map	Density of each color in the graphics/map mode																																
Copy/Print out	Density of each color in the printed document mode																																
Display	Description	Setting range	Initial setting																														
C	Value of the cyan setting	-5 to 5	0																														
M	Value of the magenta setting	-5 to 5	0																														
Y	Value of the yellow setting	-5 to 5	0																														
K	Value of the black setting	-5 to 5	0																														

Item No.	Description																						
U432	<p data-bbox="290 241 817 273">Setting the center offset for the exposure</p> <p data-bbox="290 311 440 342">Description</p> <p data-bbox="290 344 1426 479">Sets the offset value for the setting data for exposure centering adjustment under user simulation. For example, if the value for the exposure centering adjustment is set to -1 and you change the offset value to +2, image processing is performed as though the exposure centering adjustment setting is +1.</p> <p data-bbox="290 486 400 517">Purpose</p> <p data-bbox="290 519 804 551">Set according to the preference of the user.</p> <p data-bbox="290 589 384 620">Setting</p> <ol data-bbox="308 622 1262 687" style="list-style-type: none"> 1. Press the start key. 2. Select the item to be set. The setting screen for the selected item is displayed. <table border="1" data-bbox="347 696 1385 840"> <thead> <tr> <th data-bbox="352 703 627 748">Display</th> <th data-bbox="627 703 1380 748">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="352 748 627 792">Color</td> <td data-bbox="627 748 1380 792">Exposure offset setting for the color mode</td> </tr> <tr> <td data-bbox="352 792 627 837">B/W</td> <td data-bbox="627 792 1380 837">Exposure offset setting for the black and white mode</td> </tr> </tbody> </table> <ol data-bbox="308 869 1198 934" style="list-style-type: none"> 3. Select image quality mode to be set. 4. Change the setting value using the cursor left/right keys or numeric keys. <table border="1" data-bbox="336 943 1385 1171"> <thead> <tr> <th data-bbox="341 949 564 1025">Display</th> <th data-bbox="564 949 1050 1025">Description</th> <th data-bbox="1050 949 1219 1025">Setting range</th> <th data-bbox="1219 949 1380 1025">Initial setting</th> </tr> </thead> <tbody> <tr> <td data-bbox="341 1025 564 1070">Text + Photo</td> <td data-bbox="564 1025 1050 1070">Offset value for the text & photo mode</td> <td data-bbox="1050 1025 1219 1070">-3 to 3</td> <td data-bbox="1219 1025 1380 1070">0</td> </tr> <tr> <td data-bbox="341 1070 564 1115">Photo</td> <td data-bbox="564 1070 1050 1115">Offset value for the photo mode</td> <td data-bbox="1050 1070 1219 1115">-3 to 3</td> <td data-bbox="1219 1070 1380 1115">0</td> </tr> <tr> <td data-bbox="341 1115 564 1167">Text</td> <td data-bbox="564 1115 1050 1167">Offset value for the text mode</td> <td data-bbox="1050 1115 1219 1167">-3 to 3</td> <td data-bbox="1219 1115 1380 1167">0</td> </tr> </tbody> </table> <p data-bbox="336 1200 1398 1335">* : If the setting value is increased to increase the exposure centering adjustment value, images is darker. If the setting value is decreased to decrease the exposure centering adjustment value, images is lighter.</p> <ol data-bbox="308 1341 767 1373" style="list-style-type: none"> 5. Press the start key. The value is set. <p data-bbox="290 1411 448 1442">Supplement</p> <p data-bbox="290 1444 1418 1509">While this maintenance item is being executed, copying from an original is available in interrupt copying mode (which is activated by pressing the system menu key).</p> <p data-bbox="290 1547 440 1579">Completion</p> <p data-bbox="290 1581 1254 1612">Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Color	Exposure offset setting for the color mode	B/W	Exposure offset setting for the black and white mode	Display	Description	Setting range	Initial setting	Text + Photo	Offset value for the text & photo mode	-3 to 3	0	Photo	Offset value for the photo mode	-3 to 3	0	Text	Offset value for the text mode	-3 to 3	0
Display	Description																						
Color	Exposure offset setting for the color mode																						
B/W	Exposure offset setting for the black and white mode																						
Display	Description	Setting range	Initial setting																				
Text + Photo	Offset value for the text & photo mode	-3 to 3	0																				
Photo	Offset value for the photo mode	-3 to 3	0																				
Text	Offset value for the text mode	-3 to 3	0																				

Item No.	Description																																								
U464	<p data-bbox="287 235 730 264">Setting the ID correction operation</p> <p data-bbox="287 302 437 331">Description Turns ID correction (calibration) on or off. Also, this determines the duration of calibration and the timing of calibration during printing. Also, this allows individual settings for calibration operation by enabling custom settings.</p> <p data-bbox="287 421 395 450">Purpose To restrict calibration when poor image quality is generated. Also, this allows individual settings for calibration by enabling custom settings in setting the calibration cycle under the machine defaults depending on the user preferences.</p> <p data-bbox="287 573 384 602">Method</p> <ol data-bbox="304 609 1259 674" style="list-style-type: none"> 1. Press the start key. 2. Select the item to be set. The setting screen for the selected item is displayed. <table border="1" data-bbox="347 683 1412 972"> <thead> <tr> <th data-bbox="352 689 651 734">Display</th> <th data-bbox="651 689 1407 734">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="352 734 651 779">Permission</td> <td data-bbox="651 734 1407 779">Setting of operation permission</td> </tr> <tr> <td data-bbox="352 779 651 824">Time Interval</td> <td data-bbox="651 779 1407 824">Setting of driving time</td> </tr> <tr> <td data-bbox="352 824 651 869">Bias Target</td> <td data-bbox="651 824 1407 869">Setting of Bias target</td> </tr> <tr> <td data-bbox="352 869 651 913">Gamma Target</td> <td data-bbox="651 869 1407 913">Setting of quantities of light target</td> </tr> <tr> <td data-bbox="352 913 651 965">Calib</td> <td data-bbox="651 913 1407 965">Execution of calibration</td> </tr> </tbody> </table> <p data-bbox="287 1019 560 1048">Setting: [Permission]</p> <ol data-bbox="304 1055 1195 1120" style="list-style-type: none"> 1. Select the item to be set. 2. Change the setting value using the cursor left/right keys or numeric keys. <table border="1" data-bbox="347 1128 1412 1341"> <thead> <tr> <th data-bbox="352 1135 576 1211">Display</th> <th data-bbox="576 1135 1046 1211">Description</th> <th data-bbox="1046 1135 1230 1211">Setting range</th> <th data-bbox="1230 1135 1407 1211">Initial setting</th> </tr> </thead> <tbody> <tr> <td data-bbox="352 1211 576 1263">Calib</td> <td data-bbox="576 1211 1046 1263">Setting the permission of calibration.</td> <td data-bbox="1046 1211 1230 1263">On/Off</td> <td data-bbox="1230 1211 1407 1263">On</td> </tr> <tr> <td data-bbox="352 1263 576 1337">Paper Int Calib</td> <td data-bbox="576 1263 1046 1337">Setting the permission of calibration between paper.</td> <td data-bbox="1046 1263 1230 1337">On/Off</td> <td data-bbox="1230 1263 1407 1337">On</td> </tr> </tbody> </table> <ol data-bbox="304 1364 762 1393" style="list-style-type: none"> 3. Press the start key. The value is set. <p data-bbox="287 1435 579 1464">Setting: [Time Interval]</p> <ol data-bbox="304 1471 1195 1536" style="list-style-type: none"> 1. Select the item to be set. 2. Change the setting value using the cursor left/right keys or numeric keys. <table border="1" data-bbox="347 1545 1412 1834"> <thead> <tr> <th data-bbox="352 1552 576 1581">Display</th> <th data-bbox="576 1552 1046 1581">Description</th> <th data-bbox="1046 1552 1230 1581">Setting</th> <th data-bbox="1230 1552 1407 1581">Initial set-</th> </tr> </thead> <tbody> <tr> <td data-bbox="352 1581 576 1657">Paper Int Calib</td> <td data-bbox="576 1581 1046 1657">Setting the driving time of the calibration between paper.</td> <td data-bbox="1046 1581 1230 1657">0 to 100</td> <td data-bbox="1230 1581 1407 1657">10</td> </tr> <tr> <td data-bbox="352 1657 576 1733">Sleep Out</td> <td data-bbox="576 1657 1046 1733">Setting the execution time of sleeve return calibration.</td> <td data-bbox="1046 1657 1230 1733">0 to 100</td> <td data-bbox="1230 1657 1407 1733">20</td> </tr> <tr> <td data-bbox="352 1733 576 1832">T/C Calib</td> <td data-bbox="576 1733 1046 1832">Setting the execution time of T/C calibration.</td> <td data-bbox="1046 1733 1230 1832">0 to 100</td> <td data-bbox="1230 1733 1407 1832">10</td> </tr> </tbody> </table> <ol data-bbox="304 1850 762 1879" style="list-style-type: none"> 3. Press the start key. The value is set. 	Display	Description	Permission	Setting of operation permission	Time Interval	Setting of driving time	Bias Target	Setting of Bias target	Gamma Target	Setting of quantities of light target	Calib	Execution of calibration	Display	Description	Setting range	Initial setting	Calib	Setting the permission of calibration.	On/Off	On	Paper Int Calib	Setting the permission of calibration between paper.	On/Off	On	Display	Description	Setting	Initial set-	Paper Int Calib	Setting the driving time of the calibration between paper.	0 to 100	10	Sleep Out	Setting the execution time of sleeve return calibration.	0 to 100	20	T/C Calib	Setting the execution time of T/C calibration.	0 to 100	10
Display	Description																																								
Permission	Setting of operation permission																																								
Time Interval	Setting of driving time																																								
Bias Target	Setting of Bias target																																								
Gamma Target	Setting of quantities of light target																																								
Calib	Execution of calibration																																								
Display	Description	Setting range	Initial setting																																						
Calib	Setting the permission of calibration.	On/Off	On																																						
Paper Int Calib	Setting the permission of calibration between paper.	On/Off	On																																						
Display	Description	Setting	Initial set-																																						
Paper Int Calib	Setting the driving time of the calibration between paper.	0 to 100	10																																						
Sleep Out	Setting the execution time of sleeve return calibration.	0 to 100	20																																						
T/C Calib	Setting the execution time of T/C calibration.	0 to 100	10																																						

Item No.	Description																														
U464	<p data-bbox="287 241 750 271">Setting: [Bias Target/Gamma Target]</p> <ol data-bbox="287 275 1197 336" style="list-style-type: none"> <li data-bbox="287 275 630 304">1. Select the item to be set. <li data-bbox="287 309 1197 336">2. Change the setting value using the cursor left/right keys or numeric keys. <table border="1" data-bbox="347 344 1412 618"> <thead> <tr> <th data-bbox="352 344 576 423">Display</th> <th data-bbox="576 344 1046 423">Description</th> <th data-bbox="1046 344 1230 423">Setting range</th> <th data-bbox="1230 344 1407 423">Initial setting</th> </tr> </thead> <tbody> <tr> <td data-bbox="352 423 576 468">1st</td> <td data-bbox="576 423 1046 468">Setting of target (Yellow)</td> <td data-bbox="1046 423 1230 468">10 to 1000</td> <td data-bbox="1230 423 1407 468">935/400</td> </tr> <tr> <td data-bbox="352 468 576 512">2nd</td> <td data-bbox="576 468 1046 512">Setting of target (Cyan)</td> <td data-bbox="1046 468 1230 512">10 to 1000</td> <td data-bbox="1230 468 1407 512">895/200</td> </tr> <tr> <td data-bbox="352 512 576 557">3rd</td> <td data-bbox="576 512 1046 557">Setting of target (Magenta)</td> <td data-bbox="1046 512 1230 557">10 to 1000</td> <td data-bbox="1230 512 1407 557">885/200</td> </tr> <tr> <td data-bbox="352 557 576 618">4th</td> <td data-bbox="576 557 1046 618">Setting of target (Black)</td> <td data-bbox="1046 557 1230 618">10 to 1000</td> <td data-bbox="1230 557 1407 618">846/130</td> </tr> </tbody> </table> <p data-bbox="287 656 762 685">3. Press the start key. The value is set.</p> <p data-bbox="287 723 485 752">Method: [Calib]</p> <ol data-bbox="287 757 813 817" style="list-style-type: none"> <li data-bbox="287 757 630 786">1. Select the item to be set <li data-bbox="287 790 813 817">2. Press the start key. The operation starts. <table border="1" data-bbox="347 831 1407 1070"> <thead> <tr> <th data-bbox="352 831 659 875">Display</th> <th data-bbox="659 831 1402 875">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="352 875 659 920">Regist</td> <td data-bbox="659 875 1402 920">Executes the calibration to correct registration.</td> </tr> <tr> <td data-bbox="352 920 659 965">Gamma</td> <td data-bbox="659 920 1402 965">Executes the calibration to quantities of light.</td> </tr> <tr> <td data-bbox="352 965 659 1010">Paper Int</td> <td data-bbox="659 965 1402 1010">Executes the calibration between paper.</td> </tr> <tr> <td data-bbox="352 1010 659 1070">Color Regist</td> <td data-bbox="659 1010 1402 1070">Executes the calibration to color registration.</td> </tr> </tbody> </table> <p data-bbox="287 1099 730 1128">To stop operation, press the stop key.</p> <p data-bbox="287 1167 437 1196">Completion</p> <p data-bbox="287 1200 1252 1229">Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Setting range	Initial setting	1st	Setting of target (Yellow)	10 to 1000	935/400	2nd	Setting of target (Cyan)	10 to 1000	895/200	3rd	Setting of target (Magenta)	10 to 1000	885/200	4th	Setting of target (Black)	10 to 1000	846/130	Display	Description	Regist	Executes the calibration to correct registration.	Gamma	Executes the calibration to quantities of light.	Paper Int	Executes the calibration between paper.	Color Regist	Executes the calibration to color registration.
Display	Description	Setting range	Initial setting																												
1st	Setting of target (Yellow)	10 to 1000	935/400																												
2nd	Setting of target (Cyan)	10 to 1000	895/200																												
3rd	Setting of target (Magenta)	10 to 1000	885/200																												
4th	Setting of target (Black)	10 to 1000	846/130																												
Display	Description																														
Regist	Executes the calibration to correct registration.																														
Gamma	Executes the calibration to quantities of light.																														
Paper Int	Executes the calibration between paper.																														
Color Regist	Executes the calibration to color registration.																														

Item No.	Description																
U467	<p>Setting the color registration adjustment</p> <p>Description Sets the color registration adjustment.</p> <p>Purpose If color variance is uneven due to a sensor failure, etc., turn this off and temporarily make a manual adjustment.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select the item to be set. <table border="1" data-bbox="347 629 1412 752"> <thead> <tr> <th data-bbox="352 629 651 674">Display</th> <th data-bbox="651 629 1407 674">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="352 674 651 712">Permission</td> <td data-bbox="651 674 1407 712">Setting of operation permission</td> </tr> <tr> <td data-bbox="352 712 651 752">Timing</td> <td data-bbox="651 712 1407 752">Setting of execution timing of resist correction</td> </tr> </tbody> </table> <p>Setting</p> <ol style="list-style-type: none"> 1. Change the setting value using the cursor left/right keys or numeric keys. 2. Press the start key. The value is set. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Permission	Setting of operation permission	Timing	Setting of execution timing of resist correction										
Display	Description																
Permission	Setting of operation permission																
Timing	Setting of execution timing of resist correction																
U468	<p>Checking the color registration data</p> <p>Description Displays the color registration correction data and transfer belt speed correction data.</p> <p>Purpose To check the corresponding data.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select the item to be reference. The screen for the selected item is displayed. <table border="1" data-bbox="347 1402 1412 1939"> <thead> <tr> <th data-bbox="352 1402 651 1447">Display</th> <th data-bbox="651 1402 1407 1447">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="352 1447 651 1518">Auto (1st)</td> <td data-bbox="651 1447 1407 1518">Display the auto color registration adjustment value for 1st color</td> </tr> <tr> <td data-bbox="352 1518 651 1590">Auto (2nd)</td> <td data-bbox="651 1518 1407 1590">Display the auto color registration adjustment value for 2nd color</td> </tr> <tr> <td data-bbox="352 1590 651 1662">Auto (3rd)</td> <td data-bbox="651 1590 1407 1662">Display the auto color registration adjustment value for 3rd color</td> </tr> <tr> <td data-bbox="352 1662 651 1733">Manual (1st)</td> <td data-bbox="651 1662 1407 1733">Display the manual color registration adjustment value for 1st color</td> </tr> <tr> <td data-bbox="352 1733 651 1805">Manual (2nd)</td> <td data-bbox="651 1733 1407 1805">Display the manual color registration adjustment value for 2nd color</td> </tr> <tr> <td data-bbox="352 1805 651 1877">Manual (3rd)</td> <td data-bbox="651 1805 1407 1877">Display the manual color registration adjustment value for 3rd color</td> </tr> <tr> <td data-bbox="352 1877 651 1939">Initialize</td> <td data-bbox="651 1877 1407 1939">Execution of initialization</td> </tr> </tbody> </table>	Display	Description	Auto (1st)	Display the auto color registration adjustment value for 1st color	Auto (2nd)	Display the auto color registration adjustment value for 2nd color	Auto (3rd)	Display the auto color registration adjustment value for 3rd color	Manual (1st)	Display the manual color registration adjustment value for 1st color	Manual (2nd)	Display the manual color registration adjustment value for 2nd color	Manual (3rd)	Display the manual color registration adjustment value for 3rd color	Initialize	Execution of initialization
Display	Description																
Auto (1st)	Display the auto color registration adjustment value for 1st color																
Auto (2nd)	Display the auto color registration adjustment value for 2nd color																
Auto (3rd)	Display the auto color registration adjustment value for 3rd color																
Manual (1st)	Display the manual color registration adjustment value for 1st color																
Manual (2nd)	Display the manual color registration adjustment value for 2nd color																
Manual (3rd)	Display the manual color registration adjustment value for 3rd color																
Initialize	Execution of initialization																

Item No.	Description																																				
U468	<p>Displaying: [Auto]</p> <p>1. Select [Auto(1st)], [Auto(2nd)] or [Auto(3rd)]. The current value is displayed.</p> <table border="1" data-bbox="347 349 1412 535"> <thead> <tr> <th data-bbox="352 353 651 394">Display</th> <th data-bbox="651 353 1407 394">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="352 394 651 434">LSU Out Top</td> <td data-bbox="651 394 1407 434">Image up-to-date timing</td> </tr> <tr> <td data-bbox="352 434 651 474">LSU Out Left</td> <td data-bbox="651 434 1407 474">Image optical axis adjustment</td> </tr> <tr> <td data-bbox="352 474 651 515">Magnification(Whole)</td> <td data-bbox="651 474 1407 515">Correction data of original size magnification in whole</td> </tr> </tbody> </table> <p>Displaying: [Manual]</p> <p>1. Select [Manua(1st)], [Manual(2nd)] or [Manual(3rd)]. The current value is displayed.</p> <table border="1" data-bbox="347 770 1412 1341"> <thead> <tr> <th data-bbox="352 775 651 815">Display</th> <th data-bbox="651 775 1407 815">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="352 815 651 855">LSU Out Top</td> <td data-bbox="651 815 1407 855">Image up-to-date timing</td> </tr> <tr> <td data-bbox="352 855 651 896">LSU Out Left</td> <td data-bbox="651 855 1407 896">Image optical axis adjustment</td> </tr> <tr> <td data-bbox="352 896 651 936">Magnification(Whole)</td> <td data-bbox="651 896 1407 936">Correction data of original size magnification in whole</td> </tr> <tr> <td data-bbox="352 936 651 976">Magnification(Part1)</td> <td data-bbox="651 936 1407 976">Correction data of original size magnification in a part 1</td> </tr> <tr> <td data-bbox="352 976 651 1016">Magnification(Part2)</td> <td data-bbox="651 976 1407 1016">Correction data of original size magnification in a part 2</td> </tr> <tr> <td data-bbox="352 1016 651 1057">Magnification(Part3)</td> <td data-bbox="651 1016 1407 1057">Correction data of original size magnification in a part 3</td> </tr> <tr> <td data-bbox="352 1057 651 1097">Magnification(Part4)</td> <td data-bbox="651 1057 1407 1097">Correction data of original size magnification in a part 4</td> </tr> <tr> <td data-bbox="352 1097 651 1137">Magnification(Part5)</td> <td data-bbox="651 1097 1407 1137">Correction data of original size magnification in a part 5</td> </tr> <tr> <td data-bbox="352 1137 651 1178">Magnification(Part6)</td> <td data-bbox="651 1137 1407 1178">Correction data of original size magnification in a part 6</td> </tr> <tr> <td data-bbox="352 1178 651 1218">Magnification(Part7)</td> <td data-bbox="651 1178 1407 1218">Correction data of original size magnification in a part 7</td> </tr> <tr> <td data-bbox="352 1218 651 1258">Magnification(Part8)</td> <td data-bbox="651 1218 1407 1258">Correction data of original size magnification in a part 8</td> </tr> </tbody> </table> <p>Method: [Initialize]</p> <p>1. Select [Initialize]. 2. Select [Execute] and then press the start key. * : Initialization is executed.</p> <table border="1" data-bbox="347 1532 1412 1621"> <thead> <tr> <th data-bbox="352 1536 651 1576">Display</th> <th data-bbox="651 1536 1407 1576">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="352 1576 651 1617">Execute</td> <td data-bbox="651 1576 1407 1617">Execution of initialization</td> </tr> </tbody> </table> <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	LSU Out Top	Image up-to-date timing	LSU Out Left	Image optical axis adjustment	Magnification(Whole)	Correction data of original size magnification in whole	Display	Description	LSU Out Top	Image up-to-date timing	LSU Out Left	Image optical axis adjustment	Magnification(Whole)	Correction data of original size magnification in whole	Magnification(Part1)	Correction data of original size magnification in a part 1	Magnification(Part2)	Correction data of original size magnification in a part 2	Magnification(Part3)	Correction data of original size magnification in a part 3	Magnification(Part4)	Correction data of original size magnification in a part 4	Magnification(Part5)	Correction data of original size magnification in a part 5	Magnification(Part6)	Correction data of original size magnification in a part 6	Magnification(Part7)	Correction data of original size magnification in a part 7	Magnification(Part8)	Correction data of original size magnification in a part 8	Display	Description	Execute	Execution of initialization
Display	Description																																				
LSU Out Top	Image up-to-date timing																																				
LSU Out Left	Image optical axis adjustment																																				
Magnification(Whole)	Correction data of original size magnification in whole																																				
Display	Description																																				
LSU Out Top	Image up-to-date timing																																				
LSU Out Left	Image optical axis adjustment																																				
Magnification(Whole)	Correction data of original size magnification in whole																																				
Magnification(Part1)	Correction data of original size magnification in a part 1																																				
Magnification(Part2)	Correction data of original size magnification in a part 2																																				
Magnification(Part3)	Correction data of original size magnification in a part 3																																				
Magnification(Part4)	Correction data of original size magnification in a part 4																																				
Magnification(Part5)	Correction data of original size magnification in a part 5																																				
Magnification(Part6)	Correction data of original size magnification in a part 6																																				
Magnification(Part7)	Correction data of original size magnification in a part 7																																				
Magnification(Part8)	Correction data of original size magnification in a part 8																																				
Display	Description																																				
Execute	Execution of initialization																																				

Item No.	Description																										
U470	<p data-bbox="290 241 750 273">Setting the JPEG compression ratio</p> <p data-bbox="290 309 440 340">Description</p> <p data-bbox="290 344 1158 376">Sets the compression ratio for JPEG images in each image quality mode.</p> <p data-bbox="290 380 400 412">Purpose</p> <p data-bbox="290 416 1418 582">To change the setting in accordance with the image that the user is copying. For example, in order to soften the coarseness of the image when making copies at over 200% magnification, change the level of compression by raising the value. Lowering the value will increase the compression and thereby lower the image quality; Raising the value will increase image quality but lower the image processing speed.</p> <p data-bbox="290 622 387 654">Method</p> <ol data-bbox="306 658 632 721" style="list-style-type: none"> 1. Press the start key. 2. Select the item to be set. <table border="1" data-bbox="336 734 1401 927"> <thead> <tr> <th data-bbox="336 734 641 779">Display</th> <th data-bbox="641 734 1401 779">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 779 641 824">Copy</td> <td data-bbox="641 779 1401 824">Compression ratio for copying</td> </tr> <tr> <td data-bbox="336 824 641 869">Send</td> <td data-bbox="641 824 1401 869">Compression ratio for sending</td> </tr> <tr> <td data-bbox="336 869 641 927">System</td> <td data-bbox="641 869 1401 927">Compression ratio for temporary storage in system</td> </tr> </tbody> </table> <p data-bbox="290 972 485 1003">Setting: [Copy]</p> <ol data-bbox="306 1008 632 1039" style="list-style-type: none"> 1. Select the item to be set. <table border="1" data-bbox="336 1052 1401 1196"> <thead> <tr> <th data-bbox="336 1052 641 1097">Display</th> <th data-bbox="641 1052 1401 1097">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1097 641 1142">Photo</td> <td data-bbox="641 1097 1401 1142">Compression ratio in the photo mode</td> </tr> <tr> <td data-bbox="336 1142 641 1196">Text</td> <td data-bbox="641 1142 1401 1196">Compression ratio in the text mode</td> </tr> </tbody> </table> <ol data-bbox="306 1205 1200 1272" style="list-style-type: none"> 2. Select the item to be set. 3. Change the setting value using the cursor left/right keys or numeric keys. <table border="1" data-bbox="336 1285 1401 1464"> <thead> <tr> <th data-bbox="336 1285 564 1366">Display</th> <th data-bbox="564 1285 1066 1366">Description</th> <th data-bbox="1066 1285 1232 1366">Setting range</th> <th data-bbox="1232 1285 1401 1366">Initial setting</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1366 564 1411">Y</td> <td data-bbox="564 1366 1066 1411">Compression ratio of brightness</td> <td data-bbox="1066 1366 1232 1411">1 to 100</td> <td data-bbox="1232 1366 1401 1411">85</td> </tr> <tr> <td data-bbox="336 1411 564 1464">CbCr</td> <td data-bbox="564 1411 1066 1464">Compression ratio of color differential</td> <td data-bbox="1066 1411 1232 1464">1 to 100</td> <td data-bbox="1232 1411 1401 1464">85</td> </tr> </tbody> </table> <ol data-bbox="306 1473 766 1505" style="list-style-type: none"> 4. Press the start key. The value is set. 	Display	Description	Copy	Compression ratio for copying	Send	Compression ratio for sending	System	Compression ratio for temporary storage in system	Display	Description	Photo	Compression ratio in the photo mode	Text	Compression ratio in the text mode	Display	Description	Setting range	Initial setting	Y	Compression ratio of brightness	1 to 100	85	CbCr	Compression ratio of color differential	1 to 100	85
Display	Description																										
Copy	Compression ratio for copying																										
Send	Compression ratio for sending																										
System	Compression ratio for temporary storage in system																										
Display	Description																										
Photo	Compression ratio in the photo mode																										
Text	Compression ratio in the text mode																										
Display	Description	Setting range	Initial setting																								
Y	Compression ratio of brightness	1 to 100	85																								
CbCr	Compression ratio of color differential	1 to 100	85																								

Item No.	Description																																												
U470	<p data-bbox="288 241 480 271">Setting: [Send]</p> <p data-bbox="288 277 632 306">1. Select the item to be set.</p> <table border="1" data-bbox="336 320 1401 510"> <thead> <tr> <th data-bbox="336 320 639 365">Display</th> <th data-bbox="639 320 1401 365">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 365 639 409">Photo</td> <td data-bbox="639 365 1401 409">Compression ratio in the photo mode</td> </tr> <tr> <td data-bbox="336 409 639 454">Text</td> <td data-bbox="639 409 1401 454">Compression ratio in the text mode</td> </tr> <tr> <td data-bbox="336 454 639 510">HC-PDF</td> <td data-bbox="639 454 1401 510">Compression ratio of high compression PDF</td> </tr> </tbody> </table> <p data-bbox="288 562 632 591">2. Select the item to be set.</p> <p data-bbox="288 598 1198 658">3. Change the setting value using the cursor left/right keys or numeric keys. [Photo] or [Text]</p> <table border="1" data-bbox="336 672 1401 851"> <thead> <tr> <th data-bbox="336 672 549 750">Display</th> <th data-bbox="549 672 1019 750">Description</th> <th data-bbox="1019 672 1187 750">Setting range</th> <th data-bbox="1187 672 1401 750">Initial setting</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 750 549 795">Y1 to Y5</td> <td data-bbox="549 750 1019 795">Compression ratio of brightness</td> <td data-bbox="1019 750 1187 795">1 to 100</td> <td data-bbox="1187 750 1401 795">30/40/51/70/90</td> </tr> <tr> <td data-bbox="336 795 549 851">CbCr1 to CbCr5</td> <td data-bbox="549 795 1019 851">Compression ratio of color differential</td> <td data-bbox="1019 795 1187 851">1 to 100</td> <td data-bbox="1187 795 1401 851">30/40/51/70/90</td> </tr> </tbody> </table> <p data-bbox="336 864 453 893">[HC-PDF]</p> <table border="1" data-bbox="336 907 1401 1086"> <thead> <tr> <th data-bbox="336 907 549 985">Display</th> <th data-bbox="549 907 1019 985">Description</th> <th data-bbox="1019 907 1187 985">Setting range</th> <th data-bbox="1187 907 1401 985">Initial setting</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 985 549 1030">Y3 to Y3</td> <td data-bbox="549 985 1019 1030">Compression ratio of brightness</td> <td data-bbox="1019 985 1187 1030">1 to 100</td> <td data-bbox="1187 985 1401 1030">15/25/60</td> </tr> <tr> <td data-bbox="336 1030 549 1086">CbCr3 to CbCr3</td> <td data-bbox="549 1030 1019 1086">Compression ratio of color differential</td> <td data-bbox="1019 1030 1187 1086">1 to 100</td> <td data-bbox="1187 1030 1401 1086">15/25/60</td> </tr> </tbody> </table> <p data-bbox="288 1099 767 1128">4. Press the start key. The value is set.</p> <p data-bbox="288 1167 512 1196">Setting: [System]</p> <p data-bbox="288 1202 632 1232">1. Select the item to be set.</p> <p data-bbox="288 1238 1198 1267">2. Change the setting value using the cursor left/right keys or numeric keys.</p> <table border="1" data-bbox="336 1281 1401 1460"> <thead> <tr> <th data-bbox="336 1281 563 1359">Display</th> <th data-bbox="563 1281 1066 1359">Description</th> <th data-bbox="1066 1281 1233 1359">Setting range</th> <th data-bbox="1233 1281 1401 1359">Initial setting</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1359 563 1404">Y</td> <td data-bbox="563 1359 1066 1404">Compression ratio of brightness</td> <td data-bbox="1066 1359 1233 1404">1 to 100</td> <td data-bbox="1233 1359 1401 1404">90</td> </tr> <tr> <td data-bbox="336 1404 563 1460">CbCr</td> <td data-bbox="563 1404 1066 1460">Compression ratio of color differential</td> <td data-bbox="1066 1404 1233 1460">1 to 100</td> <td data-bbox="1233 1404 1401 1460">90</td> </tr> </tbody> </table> <p data-bbox="288 1473 767 1503">3. Press the start key. The value is set.</p> <p data-bbox="288 1541 448 1570">Supplement</p> <p data-bbox="288 1576 1417 1637">While this maintenance item is being executed, copying from an original is available in interrupt copying mode (which is activated by pressing the system menu key).</p> <p data-bbox="288 1675 440 1704">Completion</p> <p data-bbox="288 1711 1254 1740">Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Photo	Compression ratio in the photo mode	Text	Compression ratio in the text mode	HC-PDF	Compression ratio of high compression PDF	Display	Description	Setting range	Initial setting	Y1 to Y5	Compression ratio of brightness	1 to 100	30/40/51/70/90	CbCr1 to CbCr5	Compression ratio of color differential	1 to 100	30/40/51/70/90	Display	Description	Setting range	Initial setting	Y3 to Y3	Compression ratio of brightness	1 to 100	15/25/60	CbCr3 to CbCr3	Compression ratio of color differential	1 to 100	15/25/60	Display	Description	Setting range	Initial setting	Y	Compression ratio of brightness	1 to 100	90	CbCr	Compression ratio of color differential	1 to 100	90
Display	Description																																												
Photo	Compression ratio in the photo mode																																												
Text	Compression ratio in the text mode																																												
HC-PDF	Compression ratio of high compression PDF																																												
Display	Description	Setting range	Initial setting																																										
Y1 to Y5	Compression ratio of brightness	1 to 100	30/40/51/70/90																																										
CbCr1 to CbCr5	Compression ratio of color differential	1 to 100	30/40/51/70/90																																										
Display	Description	Setting range	Initial setting																																										
Y3 to Y3	Compression ratio of brightness	1 to 100	15/25/60																																										
CbCr3 to CbCr3	Compression ratio of color differential	1 to 100	15/25/60																																										
Display	Description	Setting range	Initial setting																																										
Y	Compression ratio of brightness	1 to 100	90																																										
CbCr	Compression ratio of color differential	1 to 100	90																																										

Item No.	Description																				
U473	<p data-bbox="287 237 662 271">Adjusting laser power output</p> <p data-bbox="287 304 437 333">Description Adjusts the laser output power for each color.</p> <p data-bbox="287 367 395 396">Purpose Enter the exposure density correction data after replacing the laser scanner unit.</p> <p data-bbox="287 463 379 492">Setting</p> <ol data-bbox="304 497 1197 595" style="list-style-type: none"> 1. Press the start key. 2. Select the item to be set. 3. Change the setting value using the cursor left/right keys or numeric keys. <table border="1" data-bbox="347 604 1412 869"> <thead> <tr> <th data-bbox="352 611 539 678">Display</th> <th data-bbox="539 611 1107 678">Description</th> <th data-bbox="1107 611 1259 678">Setting range</th> <th data-bbox="1259 611 1407 678">Initial setting</th> </tr> </thead> <tbody> <tr> <td data-bbox="352 678 539 723">1st</td> <td data-bbox="539 678 1107 723">Setting the LSU laser power (Yellow)</td> <td data-bbox="1107 678 1259 723">0 to 255</td> <td data-bbox="1259 678 1407 723">92</td> </tr> <tr> <td data-bbox="352 723 539 768">2nd</td> <td data-bbox="539 723 1107 768">Setting the LSU laser power (Cyan)</td> <td data-bbox="1107 723 1259 768">0 to 255</td> <td data-bbox="1259 723 1407 768">92</td> </tr> <tr> <td data-bbox="352 768 539 813">3rd</td> <td data-bbox="539 768 1107 813">Setting the LSU laser power (Magenta)</td> <td data-bbox="1107 768 1259 813">0 to 255</td> <td data-bbox="1259 768 1407 813">92</td> </tr> <tr> <td data-bbox="352 813 539 857">4th</td> <td data-bbox="539 813 1107 857">Setting the LSU laser power (Black)</td> <td data-bbox="1107 813 1259 857">0 to 255</td> <td data-bbox="1259 813 1407 857">50</td> </tr> </tbody> </table> <ol data-bbox="304 884 762 913" style="list-style-type: none"> 4. Press the start key. The value is set. <p data-bbox="287 949 437 978">Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Setting range	Initial setting	1st	Setting the LSU laser power (Yellow)	0 to 255	92	2nd	Setting the LSU laser power (Cyan)	0 to 255	92	3rd	Setting the LSU laser power (Magenta)	0 to 255	92	4th	Setting the LSU laser power (Black)	0 to 255	50
Display	Description	Setting range	Initial setting																		
1st	Setting the LSU laser power (Yellow)	0 to 255	92																		
2nd	Setting the LSU laser power (Cyan)	0 to 255	92																		
3rd	Setting the LSU laser power (Magenta)	0 to 255	92																		
4th	Setting the LSU laser power (Black)	0 to 255	50																		

Item No.	Description										
U486	<p data-bbox="288 241 871 275">Setting color/black and white operation mode</p> <p data-bbox="288 311 440 340">Description</p> <p data-bbox="288 344 1358 409">When color and B/W documents are mixed, sets operation mode after a color document is detected.</p> <p data-bbox="288 414 400 443">Purpose</p> <p data-bbox="288 448 1401 548">To ensure productivity when copying color and B/W documents in ACS mode, select Mode3. However, selecting Mode3 will increase the maintenance count for cyan, magenta, and yellow color developer units even when there is a B/W original after a color original.</p> <p data-bbox="288 589 384 618">Setting</p> <ol data-bbox="304 622 564 687" style="list-style-type: none"> 1. Press the start key. 2. Select the mode. <table border="1" data-bbox="336 701 1401 1464"> <thead> <tr> <th data-bbox="336 701 475 745">Display</th> <th data-bbox="475 701 1401 745">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 745 475 880">Mode1</td> <td data-bbox="475 745 1401 880">A mode suited for the user with high black-and-white usage in which the occurrence of color printing during continuous printing is minimum. Color / monochrome mode is switched for every original.</td> </tr> <tr> <td data-bbox="336 880 475 1115">Mode2</td> <td data-bbox="475 880 1401 1115">A mode suited for the user with high black-and-white usage in which the occurrence of color printing during continuous printing is maximum. Printing in color mode resumes up to 10 pages in a row even an interrupt is made to switch to black and white mode, until printing is diverted to black and white mode from color mode at the 11th page (color processing is terminated).</td> </tr> <tr> <td data-bbox="336 1115 475 1317">Mode3</td> <td data-bbox="475 1115 1401 1317">A mode suited for the user with high black-and-white usage in which the occurrence of color printing during continuous printing is maximum. Mode suited for high color printing volume Once diverted to color mode, the black and white printings are executed in color processing mode.</td> </tr> <tr> <td data-bbox="336 1317 475 1464">Auto</td> <td data-bbox="475 1317 1401 1464">Mode that allows to select from modes 1 through 3 depending on the usage. Mode is selected from three modes depending on the percentage of color and black and white printings in the total number of print pages during a pre-determined period.</td> </tr> </tbody> </table> <p data-bbox="336 1485 584 1514">Initial setting: Mode2</p> <ol data-bbox="304 1518 783 1547" style="list-style-type: none"> 3. Press the start key. The setting is set. <p data-bbox="288 1588 440 1617">Completion</p> <p data-bbox="288 1621 1254 1650">Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Mode1	A mode suited for the user with high black-and-white usage in which the occurrence of color printing during continuous printing is minimum. Color / monochrome mode is switched for every original.	Mode2	A mode suited for the user with high black-and-white usage in which the occurrence of color printing during continuous printing is maximum. Printing in color mode resumes up to 10 pages in a row even an interrupt is made to switch to black and white mode, until printing is diverted to black and white mode from color mode at the 11th page (color processing is terminated).	Mode3	A mode suited for the user with high black-and-white usage in which the occurrence of color printing during continuous printing is maximum. Mode suited for high color printing volume Once diverted to color mode, the black and white printings are executed in color processing mode.	Auto	Mode that allows to select from modes 1 through 3 depending on the usage. Mode is selected from three modes depending on the percentage of color and black and white printings in the total number of print pages during a pre-determined period.
Display	Description										
Mode1	A mode suited for the user with high black-and-white usage in which the occurrence of color printing during continuous printing is minimum. Color / monochrome mode is switched for every original.										
Mode2	A mode suited for the user with high black-and-white usage in which the occurrence of color printing during continuous printing is maximum. Printing in color mode resumes up to 10 pages in a row even an interrupt is made to switch to black and white mode, until printing is diverted to black and white mode from color mode at the 11th page (color processing is terminated).										
Mode3	A mode suited for the user with high black-and-white usage in which the occurrence of color printing during continuous printing is maximum. Mode suited for high color printing volume Once diverted to color mode, the black and white printings are executed in color processing mode.										
Auto	Mode that allows to select from modes 1 through 3 depending on the usage. Mode is selected from three modes depending on the percentage of color and black and white printings in the total number of print pages during a pre-determined period.										

Item No.	Description
<p>U486</p>	<p>Details on the modes</p> <div data-bbox="287 331 1436 683"> <p>Mode 1</p> </div> <div data-bbox="287 728 1436 1086"> <p>Mode 2</p> </div> <div data-bbox="287 1131 1436 1489"> <p>Mode 3</p> </div>

Figure 1-3-19

Item No.	Description																																																																												
U600	<p>Initializing all data</p> <p>Description Initializes software switches and all data in the backup data on the FAX control PWB, according to the destination and OEM. Executes the check of the file system, when abnormality of the file system is detected, initializes the file system, communication past record and register setting contents.</p> <p>Purpose To initialize the FAX control PWB.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select [Country Code] and enter a destination code using the numeric keys. Refer to the destination code list on following for the destination code. OEM code is no operation necessary. 3. Select [Execute]. 4. Press the start key. Data initialization starts. To cancel data initialization, press the stop key. 5. After data initialization, ROM version are displayed. A ROM version displays three kinds, application, boot, and IPL. <p>Destination code list</p> <table border="1" data-bbox="336 976 1401 1888"> <thead> <tr> <th>Code</th> <th>Destination</th> <th>Code</th> <th>Destination</th> </tr> </thead> <tbody> <tr> <td>000</td> <td>Japan</td> <td>253</td> <td>CTR21 (European nations)</td> </tr> <tr> <td>009</td> <td>Australia</td> <td></td> <td>Italy</td> </tr> <tr> <td>038</td> <td>China</td> <td></td> <td>Germany</td> </tr> <tr> <td>080</td> <td>Hong Kong</td> <td></td> <td>Spain</td> </tr> <tr> <td>084</td> <td>Indonesia</td> <td></td> <td>U.K.</td> </tr> <tr> <td>088</td> <td>Israel</td> <td></td> <td>Netherlands</td> </tr> <tr> <td>097</td> <td>Korea</td> <td></td> <td>Sweden</td> </tr> <tr> <td>108</td> <td>Malaysia</td> <td></td> <td>France</td> </tr> <tr> <td>126</td> <td>New Zealand</td> <td></td> <td>Austria</td> </tr> <tr> <td>136</td> <td>Peru</td> <td></td> <td>Switzerland</td> </tr> <tr> <td>137</td> <td>Philippines</td> <td></td> <td>Belgium</td> </tr> <tr> <td>152</td> <td>Middle East</td> <td></td> <td>Denmark</td> </tr> <tr> <td>156</td> <td>Singapore</td> <td></td> <td>Finland</td> </tr> <tr> <td>159</td> <td>South Africa</td> <td></td> <td>Portugal</td> </tr> <tr> <td>169</td> <td>Thailand</td> <td></td> <td>Ireland</td> </tr> <tr> <td>181</td> <td>U.S.A.</td> <td></td> <td>Norway</td> </tr> <tr> <td>242</td> <td>South America</td> <td>254</td> <td>Taiwan</td> </tr> <tr> <td>243</td> <td>Saudi Arabia</td> <td></td> <td></td> </tr> </tbody> </table>	Code	Destination	Code	Destination	000	Japan	253	CTR21 (European nations)	009	Australia		Italy	038	China		Germany	080	Hong Kong		Spain	084	Indonesia		U.K.	088	Israel		Netherlands	097	Korea		Sweden	108	Malaysia		France	126	New Zealand		Austria	136	Peru		Switzerland	137	Philippines		Belgium	152	Middle East		Denmark	156	Singapore		Finland	159	South Africa		Portugal	169	Thailand		Ireland	181	U.S.A.		Norway	242	South America	254	Taiwan	243	Saudi Arabia		
Code	Destination	Code	Destination																																																																										
000	Japan	253	CTR21 (European nations)																																																																										
009	Australia		Italy																																																																										
038	China		Germany																																																																										
080	Hong Kong		Spain																																																																										
084	Indonesia		U.K.																																																																										
088	Israel		Netherlands																																																																										
097	Korea		Sweden																																																																										
108	Malaysia		France																																																																										
126	New Zealand		Austria																																																																										
136	Peru		Switzerland																																																																										
137	Philippines		Belgium																																																																										
152	Middle East		Denmark																																																																										
156	Singapore		Finland																																																																										
159	South Africa		Portugal																																																																										
169	Thailand		Ireland																																																																										
181	U.S.A.		Norway																																																																										
242	South America	254	Taiwan																																																																										
243	Saudi Arabia																																																																												

Item No.	Description								
U601	<p>Initializing permanent data</p> <p>Description Initializes software switches on the FAX control PWB according to the destination and OEM.</p> <p>Purpose To initialize the FAX control PWB without changing user registration data.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select [Country Code] and enter a destination code using the numeric keys. Refer to the destination code list on page 1-3-97 for the destination code. OEM code is no operation necessary. 3. Select [Execute]. 4. Press the start key. Data initialization starts. To cancel data initialization, press the back key. 5. After data initialization, ROM version are displayed. A ROM version displays three kinds, application, boot, and IPL. 								
U603	<p>Setting user data 1</p> <p>Description Makes user settings to enable the use of the machine as a fax.</p> <p>Purpose To be executed as required.</p> <p>Setting</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select [Line Type]. 3. Select the setting. <table border="1" data-bbox="336 1234 1401 1424"> <thead> <tr> <th data-bbox="336 1234 639 1279">Display</th> <th data-bbox="639 1234 1401 1279">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1279 639 1323">DTMF</td> <td data-bbox="639 1279 1401 1323">DTMF</td> </tr> <tr> <td data-bbox="336 1323 639 1368">10PPS</td> <td data-bbox="639 1323 1401 1368">10 PPS</td> </tr> <tr> <td data-bbox="336 1368 639 1424">20PPS</td> <td data-bbox="639 1368 1401 1424">20 PPS</td> </tr> </tbody> </table> <p>* : Initial setting: DTMF</p> <ol style="list-style-type: none"> 4. Press the start key. The setting is set. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	DTMF	DTMF	10PPS	10 PPS	20PPS	20 PPS
Display	Description								
DTMF	DTMF								
10PPS	10 PPS								
20PPS	20 PPS								

Item No.	Description								
U604	<p>Setting user data 2</p> <p>Description Makes user settings to enable the use of the machine as a fax.</p> <p>Purpose Use this if the user wishes to adjust the number of rings that occur before the unit switches into fax receiving mode when fax/telephone auto-select is enabled.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select [Rings(F/T) #]. 3. Change the setting using the cursor left/right keys or numeric keys. <table border="1" data-bbox="336 667 1401 797"> <thead> <tr> <th>Display</th> <th>Description</th> <th>Setting range</th> <th>Initial setting</th> </tr> </thead> <tbody> <tr> <td>Rings(F/T) #</td> <td>Number of fax/telephone rings</td> <td>0 to 15</td> <td>2 (120 V)/ 1 (220-240 V)</td> </tr> </tbody> </table> <p>* : If you set this to 0, the unit will start fax reception without any ringing.</p> <ol style="list-style-type: none"> 4. Press the start key. The value is set. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Setting range	Initial setting	Rings(F/T) #	Number of fax/telephone rings	0 to 15	2 (120 V)/ 1 (220-240 V)
Display	Description	Setting range	Initial setting						
Rings(F/T) #	Number of fax/telephone rings	0 to 15	2 (120 V)/ 1 (220-240 V)						
U605	<p>Clearing data</p> <p>Description Initializes data related to the fax transmission such as transmission history.</p> <p>Purpose To clear the transmission history.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select [Comm REC]. 3. Press the start key. Initialization processing starts. When processing is finished, [Completed] is displayed. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>								

Item No.	Description																								
U610	<p data-bbox="290 241 502 275">Setting system 1</p> <p data-bbox="290 311 438 340">Description</p> <p data-bbox="290 344 1404 412">Makes settings for fax reception regarding the sizes of the fax paper and received images and automatic printing of the protocol list.</p> <p data-bbox="290 450 386 479">Method</p> <ol data-bbox="308 486 632 546" style="list-style-type: none"> 1. Press the start key. 2. Select the item to be set. <table border="1" data-bbox="336 562 1401 857"> <thead> <tr> <th data-bbox="336 562 639 607">Display</th> <th data-bbox="639 562 1401 607">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 607 639 689">Cut Line:A4</td> <td data-bbox="639 607 1401 689">Sets the number of lines to be ignored when receiving a fax (A4R/LetterR) in the auto reduction mode.</td> </tr> <tr> <td data-bbox="336 689 639 772">Cut Line:100%</td> <td data-bbox="639 689 1401 772">Sets the number of lines to be ignored when receiving a fax at 100% magnification.</td> </tr> <tr> <td data-bbox="336 772 639 857">Cut Line:Auto</td> <td data-bbox="639 772 1401 857">Sets the number of lines to be ignored when receiving a fax in the auto reduction mode.</td> </tr> </tbody> </table> <p data-bbox="290 904 1407 967">Setting the number of lines to be ignored when receiving a fax (A4R/LetterR) in the auto reduction mode</p> <p data-bbox="290 974 1431 1072">Sets the maximum number of lines to be ignored if the received data volume exceeds the recording capacity when the data is recorded in the auto reduction mode onto A4R or LetterR paper under the conditions below.</p> <p data-bbox="290 1077 1425 1142">If the number of excess lines is below the setting, those lines are ignored. If over the setting, the entire data on a page is further reduced so that it can be recorded on the same page.</p> <ol data-bbox="308 1149 1126 1178" style="list-style-type: none"> 1. Change the setting using the cursor left/right keys or numeric keys. <table border="1" data-bbox="336 1191 1401 1391"> <thead> <tr> <th data-bbox="336 1191 823 1274">Description</th> <th data-bbox="823 1191 1003 1274">Setting range</th> <th data-bbox="1003 1191 1187 1274">Initial setting</th> <th data-bbox="1187 1191 1401 1274">Change in value per step</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1274 823 1391">Number of lines to be ignored when receiving a fax (A4R, letter) in the auto reduction mode</td> <td data-bbox="823 1274 1003 1391">0 to 22</td> <td data-bbox="1003 1274 1187 1391">0</td> <td data-bbox="1187 1274 1401 1391">16 lines</td> </tr> </tbody> </table> <p data-bbox="336 1402 1396 1498">* : Increase the setting if a page received in the reduction mode is over-reduced and too much trailing edge margin is left. Decrease it if the received image does not include all transmitted data.</p> <ol data-bbox="308 1507 766 1536" style="list-style-type: none"> 2. Press the start key. The value is set. <p data-bbox="290 1574 1372 1606">Setting the number of lines to be ignored when receiving a fax at 100% magnification</p> <p data-bbox="290 1610 1431 1709">Sets the maximum number of lines to be ignored if the received data volume exceeds the recording capacity when recording the data at 100% magnification. If the number of excess lines is below the setting, those lines are ignored. If over the setting, they are recorded on the next page.</p> <ol data-bbox="308 1715 1126 1744" style="list-style-type: none"> 1. Change the setting using the cursor left/right keys or numeric keys. <table border="1" data-bbox="336 1758 1401 1921"> <thead> <tr> <th data-bbox="336 1758 823 1841">Description</th> <th data-bbox="823 1758 1003 1841">Setting range</th> <th data-bbox="1003 1758 1187 1841">Initial setting</th> <th data-bbox="1187 1758 1401 1841">Change in value per step</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1841 823 1921">Number of lines to be ignored when receiving at 100%</td> <td data-bbox="823 1841 1003 1921">0 to 22</td> <td data-bbox="1003 1841 1187 1921">3</td> <td data-bbox="1187 1841 1401 1921">16 lines</td> </tr> </tbody> </table> <p data-bbox="336 1933 1366 1995">* : Increase the setting if a blank second page is output, and decrease it if the received image does not include the entire transmitted data.</p> <ol data-bbox="308 2002 766 2031" style="list-style-type: none"> 2. Press the start key. The value is set. 	Display	Description	Cut Line:A4	Sets the number of lines to be ignored when receiving a fax (A4R/LetterR) in the auto reduction mode.	Cut Line:100%	Sets the number of lines to be ignored when receiving a fax at 100% magnification.	Cut Line:Auto	Sets the number of lines to be ignored when receiving a fax in the auto reduction mode.	Description	Setting range	Initial setting	Change in value per step	Number of lines to be ignored when receiving a fax (A4R, letter) in the auto reduction mode	0 to 22	0	16 lines	Description	Setting range	Initial setting	Change in value per step	Number of lines to be ignored when receiving at 100%	0 to 22	3	16 lines
Display	Description																								
Cut Line:A4	Sets the number of lines to be ignored when receiving a fax (A4R/LetterR) in the auto reduction mode.																								
Cut Line:100%	Sets the number of lines to be ignored when receiving a fax at 100% magnification.																								
Cut Line:Auto	Sets the number of lines to be ignored when receiving a fax in the auto reduction mode.																								
Description	Setting range	Initial setting	Change in value per step																						
Number of lines to be ignored when receiving a fax (A4R, letter) in the auto reduction mode	0 to 22	0	16 lines																						
Description	Setting range	Initial setting	Change in value per step																						
Number of lines to be ignored when receiving at 100%	0 to 22	3	16 lines																						

Item No.	Description								
U610	<p data-bbox="288 241 1439 275">Setting the number of lines to be ignored when receiving a fax in the auto reduction mode</p> <p data-bbox="288 277 1439 412">Sets the maximum number of lines to be ignored if the received data volume exceeds the recording capacity when the data is recorded in the auto reduction mode. If the number of excess lines is below the setting, those lines are ignored. If over the setting, the entire data on a page is further reduced so that it can be recorded on the same page.</p> <p data-bbox="308 414 1129 448">1. Change the setting using the cursor left/right keys or numeric keys.</p> <table border="1" data-bbox="336 459 1401 622"> <thead> <tr> <th data-bbox="336 459 823 539">Description</th> <th data-bbox="823 459 1005 539">Setting range</th> <th data-bbox="1005 459 1187 539">Initial setting</th> <th data-bbox="1187 459 1401 539">Change in value per step</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 539 823 622">Number of lines to be ignored when receiving in the auto reduction mode</td> <td data-bbox="823 539 1005 622">0 to 22</td> <td data-bbox="1005 539 1187 622">0</td> <td data-bbox="1187 539 1401 622">16 lines</td> </tr> </tbody> </table> <p data-bbox="336 633 1401 734">* : Increase the setting if a page received in the reduction mode is over-reduced and too much trailing edge margin is left. Decrease it if the received image does not include all transmitted data.</p> <p data-bbox="308 736 767 770">2. Press the start key. The value is set.</p> <p data-bbox="288 804 440 837">Completion</p> <p data-bbox="288 840 1257 873">Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Description	Setting range	Initial setting	Change in value per step	Number of lines to be ignored when receiving in the auto reduction mode	0 to 22	0	16 lines
Description	Setting range	Initial setting	Change in value per step						
Number of lines to be ignored when receiving in the auto reduction mode	0 to 22	0	16 lines						

Item No.	Description																																
U611	<p data-bbox="288 241 507 275">Setting system 2</p> <p data-bbox="288 311 440 340">Description Sets the number of adjustment lines for automatic reduction.</p> <p data-bbox="288 416 387 445">Method</p> <ol data-bbox="304 452 632 517" style="list-style-type: none"> 1. Press the start key. 2. Select the item to be set. <table border="1" data-bbox="336 526 1401 790"> <thead> <tr> <th data-bbox="336 526 639 571">Display</th> <th data-bbox="639 526 1401 571">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 571 639 616">Adj Lines</td> <td data-bbox="639 571 1401 616">Sets the number of adjustment lines for automatic reduction.</td> </tr> <tr> <td data-bbox="336 616 639 705">Adj Lines(A4)</td> <td data-bbox="639 616 1401 705">Sets the number of adjustment lines for automatic reduction when A4 paper is set.</td> </tr> <tr> <td data-bbox="336 705 639 790">Adj Lines(LT)</td> <td data-bbox="639 705 1401 790">Sets the number of adjustment lines for automatic reduction when letter size paper is set.</td> </tr> </tbody> </table> <p data-bbox="288 831 1094 860">Setting the number of adjustment lines for automatic reduction Sets the number of adjustment lines for automatic reduction.</p> <ol data-bbox="304 900 1126 929" style="list-style-type: none"> 1. Change the setting using the cursor left/right keys or numeric keys. <table border="1" data-bbox="336 943 1401 1108"> <thead> <tr> <th data-bbox="336 943 823 1025">Description</th> <th data-bbox="823 943 1005 1025">Setting range</th> <th data-bbox="1005 943 1187 1025">Initial setting</th> <th data-bbox="1187 943 1401 1025">Change in value per step</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1025 823 1108">Number of adjustment lines for automatic reduction</td> <td data-bbox="823 1025 1005 1108">0 to 22</td> <td data-bbox="1005 1025 1187 1108">7</td> <td data-bbox="1187 1025 1401 1108">16 lines</td> </tr> </tbody> </table> <ol data-bbox="304 1117 767 1146" style="list-style-type: none"> 2. Press the start key. The value is set. <p data-bbox="288 1187 1366 1216">Setting the number of adjustment lines for automatic reduction when A4 paper is set Sets the number of adjustment lines for automatic reduction when A4 paper is set.</p> <ol data-bbox="304 1256 1126 1285" style="list-style-type: none"> 1. Change the setting using the cursor left/right keys or numeric keys. <table border="1" data-bbox="336 1299 1401 1464"> <thead> <tr> <th data-bbox="336 1299 823 1382">Description</th> <th data-bbox="823 1299 1005 1382">Setting range</th> <th data-bbox="1005 1299 1187 1382">Initial setting</th> <th data-bbox="1187 1299 1401 1382">Change in value per step</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1382 823 1464">Number of adjustment lines for automatic reduction when A4 paper is set</td> <td data-bbox="823 1382 1005 1464">0 to 22</td> <td data-bbox="1005 1382 1187 1464">22</td> <td data-bbox="1187 1382 1401 1464">16 lines</td> </tr> </tbody> </table> <ol data-bbox="304 1473 767 1503" style="list-style-type: none"> 2. Press the start key. The value is set. <p data-bbox="288 1543 1406 1606">Setting the number of adjustment lines for automatic reduction when letter size paper is set Sets the number of adjustment lines for automatic reduction when letter size paper is set.</p> <ol data-bbox="304 1646 1126 1675" style="list-style-type: none"> 1. Change the setting using the cursor left/right keys or numeric keys. <table border="1" data-bbox="336 1688 1401 1888"> <thead> <tr> <th data-bbox="336 1688 823 1771">Description</th> <th data-bbox="823 1688 1005 1771">Setting range</th> <th data-bbox="1005 1688 1187 1771">Initial setting</th> <th data-bbox="1187 1688 1401 1771">Change in value per step</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1771 823 1888">Number of adjustment lines for automatic reduction when letter size paper is set</td> <td data-bbox="823 1771 1005 1888">0 to 26</td> <td data-bbox="1005 1771 1187 1888">26</td> <td data-bbox="1187 1771 1401 1888">16 lines</td> </tr> </tbody> </table> <ol data-bbox="304 1897 767 1926" style="list-style-type: none"> 2. Press the start key. The value is set. <p data-bbox="288 1966 440 1995">Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Adj Lines	Sets the number of adjustment lines for automatic reduction.	Adj Lines(A4)	Sets the number of adjustment lines for automatic reduction when A4 paper is set.	Adj Lines(LT)	Sets the number of adjustment lines for automatic reduction when letter size paper is set.	Description	Setting range	Initial setting	Change in value per step	Number of adjustment lines for automatic reduction	0 to 22	7	16 lines	Description	Setting range	Initial setting	Change in value per step	Number of adjustment lines for automatic reduction when A4 paper is set	0 to 22	22	16 lines	Description	Setting range	Initial setting	Change in value per step	Number of adjustment lines for automatic reduction when letter size paper is set	0 to 26	26	16 lines
Display	Description																																
Adj Lines	Sets the number of adjustment lines for automatic reduction.																																
Adj Lines(A4)	Sets the number of adjustment lines for automatic reduction when A4 paper is set.																																
Adj Lines(LT)	Sets the number of adjustment lines for automatic reduction when letter size paper is set.																																
Description	Setting range	Initial setting	Change in value per step																														
Number of adjustment lines for automatic reduction	0 to 22	7	16 lines																														
Description	Setting range	Initial setting	Change in value per step																														
Number of adjustment lines for automatic reduction when A4 paper is set	0 to 22	22	16 lines																														
Description	Setting range	Initial setting	Change in value per step																														
Number of adjustment lines for automatic reduction when letter size paper is set	0 to 26	26	16 lines																														

Item No.	Description																				
U612	<p data-bbox="288 241 507 275">Setting system 3</p> <p data-bbox="288 311 440 340">Description</p> <p data-bbox="288 344 1398 409">Makes settings for fax transmission regarding operation and automatic printing of the protocol list.</p> <p data-bbox="288 450 387 479">Method</p> <ol data-bbox="308 486 999 548" style="list-style-type: none"> 1. Press the start key. 2. Select the item to be set using the cursor up/down keys. <table border="1" data-bbox="336 562 1401 741"> <thead> <tr> <th data-bbox="336 562 639 607">Display</th> <th data-bbox="639 562 1401 607">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 607 639 696">Auto Reduct</td> <td data-bbox="639 607 1401 696">Selects if auto reduction in the auxiliary direction is to be performed.</td> </tr> <tr> <td data-bbox="336 696 639 741">Protocol List</td> <td data-bbox="639 696 1401 741">Sets the automatic printing of the protocol list.</td> </tr> </tbody> </table> <p data-bbox="288 786 1185 815">Selecting if auto reduction in the auxiliary direction is to be performed</p> <p data-bbox="288 819 1426 884">Sets whether to receive a long document by automatically reducing it in the auxiliary direction or at 100% magnification.</p> <ol data-bbox="308 889 911 918" style="list-style-type: none"> 1. Select the setting using the cursor left/right keys. <table border="1" data-bbox="336 931 1401 1111"> <thead> <tr> <th data-bbox="336 931 639 976">Display</th> <th data-bbox="639 931 1401 976">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 976 639 1066">On</td> <td data-bbox="639 976 1401 1066">Auto reduction is performed if the received document is longer than the fax paper.</td> </tr> <tr> <td data-bbox="336 1066 639 1111">Off</td> <td data-bbox="639 1066 1401 1111">Auto reduction is not performed.</td> </tr> </tbody> </table> <p data-bbox="336 1122 576 1151">* : Initial setting: On</p> <ol data-bbox="308 1155 782 1184" style="list-style-type: none"> 2. Press the start key. The setting is set. <p data-bbox="288 1225 914 1254">Setting the automatic printing of the protocol list</p> <p data-bbox="288 1258 884 1288">Sets if the protocol list is automatically printed out.</p> <ol data-bbox="308 1292 911 1321" style="list-style-type: none"> 1. Select the setting using the cursor left/right keys. <table border="1" data-bbox="336 1335 1401 1599"> <thead> <tr> <th data-bbox="336 1335 639 1379">Display</th> <th data-bbox="639 1335 1401 1379">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1379 639 1469">Err</td> <td data-bbox="639 1379 1401 1469">The protocol list is automatically printed out after communication only if a communication error occurs.</td> </tr> <tr> <td data-bbox="336 1469 639 1559">On</td> <td data-bbox="639 1469 1401 1559">The protocol list is automatically printed out after communication.</td> </tr> <tr> <td data-bbox="336 1559 639 1599">Off</td> <td data-bbox="639 1559 1401 1599">The protocol list is not printed out automatically.</td> </tr> </tbody> </table> <p data-bbox="336 1610 576 1639">* : Initial setting: Off</p> <ol data-bbox="308 1644 782 1673" style="list-style-type: none"> 2. Press the start key. The setting is set. <p data-bbox="288 1713 440 1742">Completion</p> <p data-bbox="288 1747 1254 1776">Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Auto Reduct	Selects if auto reduction in the auxiliary direction is to be performed.	Protocol List	Sets the automatic printing of the protocol list.	Display	Description	On	Auto reduction is performed if the received document is longer than the fax paper.	Off	Auto reduction is not performed.	Display	Description	Err	The protocol list is automatically printed out after communication only if a communication error occurs.	On	The protocol list is automatically printed out after communication.	Off	The protocol list is not printed out automatically.
Display	Description																				
Auto Reduct	Selects if auto reduction in the auxiliary direction is to be performed.																				
Protocol List	Sets the automatic printing of the protocol list.																				
Display	Description																				
On	Auto reduction is performed if the received document is longer than the fax paper.																				
Off	Auto reduction is not performed.																				
Display	Description																				
Err	The protocol list is automatically printed out after communication only if a communication error occurs.																				
On	The protocol list is automatically printed out after communication.																				
Off	The protocol list is not printed out automatically.																				

Item No.	Description						
U615	<p>Setting system 6</p> <p>Description Makes settings for fax reception regarding the sizes of the fax paper and received images.</p> <p>Purpose To set the maximum recording width and processing method when 11" width fax paper is loaded on an inch specification machine.</p> <p>Setting</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select [RX Width For 11"]. 3. Select the setting. <table border="1" data-bbox="336 667 1401 846"> <thead> <tr> <th data-bbox="336 667 641 712">Display</th> <th data-bbox="641 667 1401 712">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 712 641 801">Ledger</td> <td data-bbox="641 712 1401 801">Communicates to the destination unit 11" width as A3 width and records at 100% magnifications.</td> </tr> <tr> <td data-bbox="336 801 641 846">B4</td> <td data-bbox="641 801 1401 846">Communicates to the destination unit 11" width as B4 width.</td> </tr> </tbody> </table> <p>* : Initial setting: Ledger</p> <ol style="list-style-type: none"> 4. Press the start key. The setting is set. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Ledger	Communicates to the destination unit 11" width as A3 width and records at 100% magnifications.	B4	Communicates to the destination unit 11" width as B4 width.
Display	Description						
Ledger	Communicates to the destination unit 11" width as A3 width and records at 100% magnifications.						
B4	Communicates to the destination unit 11" width as B4 width.						
U620	<p>Setting the remote switching mode</p> <p>Description Sets the signal detection method for remote switching. Be sure to change the setting according to the type of telephone connected to the machine.</p> <p>Setting</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select [Remort Mode]. 3. Select the mode. <table border="1" data-bbox="336 1397 1401 1541"> <thead> <tr> <th data-bbox="336 1397 641 1442">Display</th> <th data-bbox="641 1397 1401 1442">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1442 641 1487">One</td> <td data-bbox="641 1442 1401 1487">One-shot detection</td> </tr> <tr> <td data-bbox="336 1487 641 1541">Cont</td> <td data-bbox="641 1487 1401 1541">Continuous detection</td> </tr> </tbody> </table> <p>* : Initial setting: One</p> <ol style="list-style-type: none"> 4. Press the start key. The setting is set. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	One	One-shot detection	Cont	Continuous detection
Display	Description						
One	One-shot detection						
Cont	Continuous detection						

Item No.	Description																		
U625	<p data-bbox="288 241 724 271">Setting the transmission system 1</p> <p data-bbox="288 311 440 340">Description</p> <p data-bbox="288 344 1315 374">Makes settings for the auto redialing interval and the number of times of auto redialing.</p> <p data-bbox="288 380 400 409">Purpose</p> <p data-bbox="288 414 1426 512">Change the setting to prevent the following problems: fax transmission is not possible due to too short redial interval, or fax transmission takes too much time to complete due to too long redial interval.</p> <p data-bbox="288 553 387 582">Method</p> <ol data-bbox="308 589 632 651" style="list-style-type: none"> 1. Press the start key. 2. Select the item to be set. <table border="1" data-bbox="336 665 1399 808"> <thead> <tr> <th data-bbox="336 665 639 710">Display</th> <th data-bbox="639 665 1399 710">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 710 639 754">Interval</td> <td data-bbox="639 710 1399 754">Setting the auto redialing interval</td> </tr> <tr> <td data-bbox="336 754 639 808">Times</td> <td data-bbox="639 754 1399 808">Setting the number of times of auto redialing</td> </tr> </tbody> </table> <p data-bbox="288 853 716 882">Setting the auto redialing interval</p> <ol data-bbox="308 889 930 918" style="list-style-type: none"> 1. Change the setting using the cursor left/right keys. <table border="1" data-bbox="336 931 1399 1025"> <thead> <tr> <th data-bbox="336 931 868 976">Description</th> <th data-bbox="868 931 1096 976">Setting range</th> <th data-bbox="1096 931 1399 976">Initial setting</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 976 868 1025">Redialing interval</td> <td data-bbox="868 976 1096 1025">1 to 9 (min.)</td> <td data-bbox="1096 976 1399 1025">3 (120 V)/2 (220-240 V)</td> </tr> </tbody> </table> <ol data-bbox="308 1034 766 1064" style="list-style-type: none"> 2. Press the start key. The value is set. <p data-bbox="288 1106 860 1135">Setting the number of times of auto redialing</p> <ol data-bbox="308 1142 1126 1171" style="list-style-type: none"> 1. Change the setting using the cursor left/right keys or numeric keys. <table border="1" data-bbox="336 1184 1399 1279"> <thead> <tr> <th data-bbox="336 1184 868 1229">Description</th> <th data-bbox="868 1184 1096 1229">Setting range</th> <th data-bbox="1096 1184 1399 1229">Initial setting</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1229 868 1279">Number of redialing</td> <td data-bbox="868 1229 1096 1279">0 to 15</td> <td data-bbox="1096 1229 1399 1279">2 (120 V)/3 (220-240 V)</td> </tr> </tbody> </table> <ol data-bbox="308 1288 766 1317" style="list-style-type: none"> 2. Press the start key. The value is set. <p data-bbox="288 1357 440 1386">Completion</p> <p data-bbox="288 1391 1254 1420">Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Interval	Setting the auto redialing interval	Times	Setting the number of times of auto redialing	Description	Setting range	Initial setting	Redialing interval	1 to 9 (min.)	3 (120 V)/2 (220-240 V)	Description	Setting range	Initial setting	Number of redialing	0 to 15	2 (120 V)/3 (220-240 V)
Display	Description																		
Interval	Setting the auto redialing interval																		
Times	Setting the number of times of auto redialing																		
Description	Setting range	Initial setting																	
Redialing interval	1 to 9 (min.)	3 (120 V)/2 (220-240 V)																	
Description	Setting range	Initial setting																	
Number of redialing	0 to 15	2 (120 V)/3 (220-240 V)																	

Item No.	Description																														
U630	<p data-bbox="288 241 707 271">Setting communication control 1</p> <p data-bbox="288 311 440 340">Description</p> <p data-bbox="288 344 1069 374">Makes settings for fax transmission regarding the communication.</p> <p data-bbox="288 414 387 443">Method</p> <ol data-bbox="308 448 632 515" style="list-style-type: none"> 1. Press the start key. 2. Select the item to be set. <table border="1" data-bbox="336 526 1399 837"> <thead> <tr> <th data-bbox="336 526 639 571">Display</th> <th data-bbox="639 526 1399 571">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 571 639 616">TX Speed</td> <td data-bbox="639 571 1399 616">Sets the communication starting speed.</td> </tr> <tr> <td data-bbox="336 616 639 660">RX Speed</td> <td data-bbox="639 616 1399 660">Sets the reception speed.</td> </tr> <tr> <td data-bbox="336 660 639 750">TX Echo</td> <td data-bbox="639 660 1399 750">Sets the waiting period to prevent echo problems at the sender.</td> </tr> <tr> <td data-bbox="336 750 639 837">RX Echo</td> <td data-bbox="639 750 1399 837">Sets the waiting period to prevent echo problems at the receiver.</td> </tr> </tbody> </table> <p data-bbox="288 882 826 911">Setting the communication starting speed</p> <p data-bbox="288 916 1418 983">Sets the initial communication speed when starting transmission. When the destination unit has V.34 capability, V.34 is selected for transmission, regardless of this setting.</p> <ol data-bbox="308 987 549 1016" style="list-style-type: none"> 1. Select the setting. <table border="1" data-bbox="336 1028 1399 1267"> <thead> <tr> <th data-bbox="336 1028 639 1072">Display</th> <th data-bbox="639 1028 1399 1072">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1072 639 1117">14400bps/V17</td> <td data-bbox="639 1072 1399 1117">V.17, 14400 bps</td> </tr> <tr> <td data-bbox="336 1117 639 1162">9600bps/V29</td> <td data-bbox="639 1117 1399 1162">V.17, 9600 bps</td> </tr> <tr> <td data-bbox="336 1162 639 1207">4800bps/V27ter</td> <td data-bbox="639 1162 1399 1207">V.27ter, 4800 bps</td> </tr> <tr> <td data-bbox="336 1207 639 1267">2400bps/V27ter</td> <td data-bbox="639 1207 1399 1267">V.27ter, 2400 bps</td> </tr> </tbody> </table> <p data-bbox="336 1279 711 1308">* : Initial setting: 14400bps/V17</p> <ol data-bbox="308 1312 782 1341" style="list-style-type: none"> 2. Press the start key. The setting is set. <p data-bbox="288 1382 643 1411">Setting the reception speed</p> <p data-bbox="288 1415 1409 1482">Sets the reception speed that the sender is informed of using the DIS or NSF signal. When the destination unit has V.34 capability, V.34 is selected, regardless of the setting.</p> <ol data-bbox="308 1487 549 1516" style="list-style-type: none"> 1. Select the setting. <table border="1" data-bbox="336 1527 1399 1769"> <thead> <tr> <th data-bbox="336 1527 639 1572">Display</th> <th data-bbox="639 1527 1399 1572">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1572 639 1617">14400bps</td> <td data-bbox="639 1572 1399 1617">V.17, V.33, V.29, V.27ter</td> </tr> <tr> <td data-bbox="336 1617 639 1662">9600bps</td> <td data-bbox="639 1617 1399 1662">V.29, V.27ter</td> </tr> <tr> <td data-bbox="336 1662 639 1706">4800bps</td> <td data-bbox="639 1662 1399 1706">V.27ter</td> </tr> <tr> <td data-bbox="336 1706 639 1769">2400bps</td> <td data-bbox="639 1706 1399 1769">V.27ter (fallback only)</td> </tr> </tbody> </table> <p data-bbox="336 1780 657 1809">* : Initial setting: 14400bps</p> <ol data-bbox="308 1814 782 1843" style="list-style-type: none"> 2. Press the start key. The setting is set. 	Display	Description	TX Speed	Sets the communication starting speed.	RX Speed	Sets the reception speed.	TX Echo	Sets the waiting period to prevent echo problems at the sender.	RX Echo	Sets the waiting period to prevent echo problems at the receiver.	Display	Description	14400bps/V17	V.17, 14400 bps	9600bps/V29	V.17, 9600 bps	4800bps/V27ter	V.27ter, 4800 bps	2400bps/V27ter	V.27ter, 2400 bps	Display	Description	14400bps	V.17, V.33, V.29, V.27ter	9600bps	V.29, V.27ter	4800bps	V.27ter	2400bps	V.27ter (fallback only)
Display	Description																														
TX Speed	Sets the communication starting speed.																														
RX Speed	Sets the reception speed.																														
TX Echo	Sets the waiting period to prevent echo problems at the sender.																														
RX Echo	Sets the waiting period to prevent echo problems at the receiver.																														
Display	Description																														
14400bps/V17	V.17, 14400 bps																														
9600bps/V29	V.17, 9600 bps																														
4800bps/V27ter	V.27ter, 4800 bps																														
2400bps/V27ter	V.27ter, 2400 bps																														
Display	Description																														
14400bps	V.17, V.33, V.29, V.27ter																														
9600bps	V.29, V.27ter																														
4800bps	V.27ter																														
2400bps	V.27ter (fallback only)																														

Item No.	Description												
U630	<p>Setting the waiting period to prevent echo problems at the sender Sets the period before a DCS signal is sent after a DIS signal is received. Used when problems occur due to echoes at the sender.</p> <p>1. Select the setting.</p> <table border="1" data-bbox="336 389 1401 533"> <thead> <tr> <th data-bbox="336 389 641 434">Display</th> <th data-bbox="641 389 1401 434">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 434 641 479">500</td> <td data-bbox="641 434 1401 479">Sends a DCS 500 ms after receiving a DIS.</td> </tr> <tr> <td data-bbox="336 479 641 533">300</td> <td data-bbox="641 479 1401 533">Sends a DCS 300 ms after receiving a DIS.</td> </tr> </tbody> </table> <p>* : Initial setting: 300</p> <p>2. Press the start key. The setting is set.</p> <p>Setting the waiting period to prevent echo problems at the receiver Sets the period before an NSF, CSI or DIS signal is sent after a CED signal is received. Used when problems occur due to echoes at the receiver.</p> <p>1. Select the setting.</p> <table border="1" data-bbox="336 792 1401 936"> <thead> <tr> <th data-bbox="336 792 641 837">Display</th> <th data-bbox="641 792 1401 837">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 837 641 882">500</td> <td data-bbox="641 837 1401 882">Sends an NSF, CSI or DIS 500 ms after receiving a CED.</td> </tr> <tr> <td data-bbox="336 882 641 936">75</td> <td data-bbox="641 882 1401 936">Sends an NSF, CSI or DIS 75 ms after receiving a CED.</td> </tr> </tbody> </table> <p>* : Initial setting: 75</p> <p>2. Press the start key. The setting is set.</p> <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	500	Sends a DCS 500 ms after receiving a DIS.	300	Sends a DCS 300 ms after receiving a DIS.	Display	Description	500	Sends an NSF, CSI or DIS 500 ms after receiving a CED.	75	Sends an NSF, CSI or DIS 75 ms after receiving a CED.
Display	Description												
500	Sends a DCS 500 ms after receiving a DIS.												
300	Sends a DCS 300 ms after receiving a DIS.												
Display	Description												
500	Sends an NSF, CSI or DIS 500 ms after receiving a CED.												
75	Sends an NSF, CSI or DIS 75 ms after receiving a CED.												

Item No.	Description																										
U631	<p data-bbox="288 241 710 271">Setting communication control 2</p> <p data-bbox="288 311 440 340">Description</p> <p data-bbox="288 344 799 374">Makes settings regarding fax transmission.</p> <p data-bbox="288 414 387 443">Method</p> <ol data-bbox="308 448 632 515" style="list-style-type: none"> 1. Press the start key. 2. Select the item to be set. <table border="1" data-bbox="336 526 1399 719"> <thead> <tr> <th data-bbox="336 526 639 571">Display</th> <th data-bbox="639 526 1399 571">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 571 639 616">ECM TX</td> <td data-bbox="639 571 1399 616">Sets ECM transmission.</td> </tr> <tr> <td data-bbox="336 616 639 660">ECM RX</td> <td data-bbox="639 616 1399 660">Sets ECM reception.</td> </tr> <tr> <td data-bbox="336 660 639 719">CED Freq</td> <td data-bbox="639 660 1399 719">Sets the frequency of the CED signal.</td> </tr> </tbody> </table> <p data-bbox="288 761 624 790">Setting ECM transmission</p> <p data-bbox="288 795 1374 862">To be set to Off when reduction of transmission costs is of higher priority than image quality. This should not be set to Off when connecting to the IP (Internet Protocol) telephone line.</p> <ol data-bbox="308 866 549 896" style="list-style-type: none"> 1. Select the setting. <table border="1" data-bbox="336 907 1399 1055"> <thead> <tr> <th data-bbox="336 907 639 952">Display</th> <th data-bbox="639 907 1399 952">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 952 639 996">On</td> <td data-bbox="639 952 1399 996">ECM transmission is enabled.</td> </tr> <tr> <td data-bbox="336 996 639 1055">Off</td> <td data-bbox="639 996 1399 1055">ECM transmission is disabled.</td> </tr> </tbody> </table> <p data-bbox="336 1059 576 1088">* : Initial setting: On</p> <ol data-bbox="308 1093 782 1122" style="list-style-type: none"> 2. Press the start key. The setting is set. <p data-bbox="288 1164 576 1193">Setting ECM reception</p> <p data-bbox="288 1198 1374 1265">To be set to Off when reduction of transmission costs is of higher priority than image quality. This should not be set to Off when connecting to the IP (Internet Protocol) telephone line.</p> <ol data-bbox="308 1270 549 1299" style="list-style-type: none"> 1. Select the setting. <table border="1" data-bbox="336 1310 1399 1458"> <thead> <tr> <th data-bbox="336 1310 639 1355">Display</th> <th data-bbox="639 1310 1399 1355">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1355 639 1400">On</td> <td data-bbox="639 1355 1399 1400">ECM reception is enabled.</td> </tr> <tr> <td data-bbox="336 1400 639 1458">Off</td> <td data-bbox="639 1400 1399 1458">ECM reception is disabled.</td> </tr> </tbody> </table> <p data-bbox="336 1462 576 1491">* : Initial setting: On</p> <ol data-bbox="308 1496 782 1525" style="list-style-type: none"> 2. Press the start key. The setting is set. <p data-bbox="288 1568 798 1597">Setting the frequency of the CED signal</p> <p data-bbox="288 1601 1431 1668">Sets the frequency of the CED signal. Used as one of the measures to improve transmission performance for international communications.</p> <ol data-bbox="308 1673 549 1702" style="list-style-type: none"> 1. Select the setting. <table border="1" data-bbox="336 1713 1399 1861"> <thead> <tr> <th data-bbox="336 1713 639 1758">Display</th> <th data-bbox="639 1713 1399 1758">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1758 639 1803">2100</td> <td data-bbox="639 1758 1399 1803">2100 Hz</td> </tr> <tr> <td data-bbox="336 1803 639 1861">1100</td> <td data-bbox="639 1803 1399 1861">1100 Hz</td> </tr> </tbody> </table> <p data-bbox="336 1865 600 1895">* : Initial setting: 2100</p> <ol data-bbox="308 1899 782 1928" style="list-style-type: none"> 2. Press the start key. The setting is set. <p data-bbox="288 1971 440 2000">Completion</p> <p data-bbox="288 2004 1254 2033">Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	ECM TX	Sets ECM transmission.	ECM RX	Sets ECM reception.	CED Freq	Sets the frequency of the CED signal.	Display	Description	On	ECM transmission is enabled.	Off	ECM transmission is disabled.	Display	Description	On	ECM reception is enabled.	Off	ECM reception is disabled.	Display	Description	2100	2100 Hz	1100	1100 Hz
Display	Description																										
ECM TX	Sets ECM transmission.																										
ECM RX	Sets ECM reception.																										
CED Freq	Sets the frequency of the CED signal.																										
Display	Description																										
On	ECM transmission is enabled.																										
Off	ECM transmission is disabled.																										
Display	Description																										
On	ECM reception is enabled.																										
Off	ECM reception is disabled.																										
Display	Description																										
2100	2100 Hz																										
1100	1100 Hz																										

Item No.	Description																		
U632	<p data-bbox="290 241 710 273">Setting communication control 3</p> <p data-bbox="290 311 440 338">Description</p> <p data-bbox="290 344 1069 376">Makes settings for fax transmission regarding the communication.</p> <p data-bbox="290 414 387 441">Method</p> <ol data-bbox="308 450 632 515" style="list-style-type: none"> 1. Press the start key. 2. Select the item to be set. <table border="1" data-bbox="336 526 1401 705"> <thead> <tr> <th data-bbox="336 526 641 571">Display</th> <th data-bbox="641 526 1401 571">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 571 641 616">DIS 4Byte</td> <td data-bbox="641 571 1401 616">Sets the DIS signal to 4 bytes.</td> </tr> <tr> <td data-bbox="336 616 641 705">Num OF CNG(F/T)</td> <td data-bbox="641 616 1401 705">Sets the CNG detection times in the fax/telephone auto select mode.</td> </tr> </tbody> </table> <p data-bbox="290 750 699 781">Setting the DIS signal to 4 bytes</p> <p data-bbox="290 786 976 817">Sets if bit 33 and later bits of the DIS/DTC signal are sent.</p> <ol data-bbox="308 822 549 853" style="list-style-type: none"> 1. Select the setting. <table border="1" data-bbox="336 864 1401 1008"> <thead> <tr> <th data-bbox="336 864 641 909">Display</th> <th data-bbox="641 864 1401 909">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 909 641 954">On</td> <td data-bbox="641 909 1401 954">Bit 33 and later bits of the DIS/DTC signal are not sent.</td> </tr> <tr> <td data-bbox="336 954 641 1008">Off</td> <td data-bbox="641 954 1401 1008">Bit 33 and later bits of the DIS/DTC signal are sent.</td> </tr> </tbody> </table> <p data-bbox="336 1014 576 1046">* : Initial setting: Off</p> <ol data-bbox="308 1050 782 1081" style="list-style-type: none"> 2. Press the start key. The setting is set. <p data-bbox="290 1120 1185 1151">Setting the CNG detection times in the fax/telephone auto select mode</p> <p data-bbox="290 1155 1102 1187">Sets the CNG detection times in the fax/telephone auto select mode.</p> <ol data-bbox="308 1191 549 1223" style="list-style-type: none"> 1. Select the setting. <table border="1" data-bbox="336 1234 1401 1377"> <thead> <tr> <th data-bbox="336 1234 641 1279">Display</th> <th data-bbox="641 1234 1401 1279">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1279 641 1323">1Time</td> <td data-bbox="641 1279 1401 1323">Detects CNG once.</td> </tr> <tr> <td data-bbox="336 1323 641 1377">2Time</td> <td data-bbox="641 1323 1401 1377">Detects CNG twice.</td> </tr> </tbody> </table> <p data-bbox="336 1384 612 1415">* : Initial setting: 2Time</p> <ol data-bbox="308 1420 782 1451" style="list-style-type: none"> 2. Press the start key. The setting is set. <p data-bbox="290 1489 440 1520">Completion</p> <p data-bbox="290 1525 1256 1556">Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	DIS 4Byte	Sets the DIS signal to 4 bytes.	Num OF CNG(F/T)	Sets the CNG detection times in the fax/telephone auto select mode.	Display	Description	On	Bit 33 and later bits of the DIS/DTC signal are not sent.	Off	Bit 33 and later bits of the DIS/DTC signal are sent.	Display	Description	1Time	Detects CNG once.	2Time	Detects CNG twice.
Display	Description																		
DIS 4Byte	Sets the DIS signal to 4 bytes.																		
Num OF CNG(F/T)	Sets the CNG detection times in the fax/telephone auto select mode.																		
Display	Description																		
On	Bit 33 and later bits of the DIS/DTC signal are not sent.																		
Off	Bit 33 and later bits of the DIS/DTC signal are sent.																		
Display	Description																		
1Time	Detects CNG once.																		
2Time	Detects CNG twice.																		

Item No.	Description																										
U633	<p data-bbox="288 241 710 271">Setting communication control 4</p> <p data-bbox="288 311 440 340">Description</p> <p data-bbox="288 344 1069 374">Makes settings for fax transmission regarding the communication.</p> <p data-bbox="288 380 400 409">Purpose</p> <p data-bbox="288 414 1018 443">To reduce transmission errors when a low quality line is used.</p> <p data-bbox="288 483 387 512">Method</p> <ol data-bbox="308 517 632 582" style="list-style-type: none"> 1. Press the start key. 2. Select the item to be set. <table border="1" data-bbox="336 595 1399 837"> <thead> <tr> <th data-bbox="336 595 639 640">Display</th> <th data-bbox="639 595 1399 640">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 640 639 685">V.34</td> <td data-bbox="639 640 1399 685">Enables or disables V.34 communication.</td> </tr> <tr> <td data-bbox="336 685 639 730">V.34-3429Hz</td> <td data-bbox="639 685 1399 730">Sets the V.34 symbol speed (3429 Hz).</td> </tr> <tr> <td data-bbox="336 730 639 775">DIS 2Res</td> <td data-bbox="639 730 1399 775">Sets the number of times of DIS signal reception.</td> </tr> <tr> <td data-bbox="336 775 639 837">RTN Check</td> <td data-bbox="639 775 1399 837">Sets the reference for RTN signal output.</td> </tr> </tbody> </table> <p data-bbox="288 882 798 911">Enabling/disabling V.34 communication</p> <p data-bbox="288 916 1303 945">Sets whether V.34 communication is enabled/disabled for transmission and reception.</p> <ol data-bbox="308 949 549 978" style="list-style-type: none"> 1. Select the setting. <table border="1" data-bbox="336 992 1399 1234"> <thead> <tr> <th data-bbox="336 992 564 1037">Display</th> <th data-bbox="564 992 1399 1037">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1037 564 1081">On</td> <td data-bbox="564 1037 1399 1081">V.34 communication is enabled for both transmission and reception.</td> </tr> <tr> <td data-bbox="336 1081 564 1126">TX</td> <td data-bbox="564 1081 1399 1126">V.34 communication is enabled for transmission only.</td> </tr> <tr> <td data-bbox="336 1126 564 1171">RX</td> <td data-bbox="564 1126 1399 1171">V.34 communication is enabled for reception only.</td> </tr> <tr> <td data-bbox="336 1171 564 1234">Off</td> <td data-bbox="564 1171 1399 1234">V.34 communication is disabled for both transmission and reception.</td> </tr> </tbody> </table> <p data-bbox="336 1243 576 1272">* : Initial setting: On</p> <ol data-bbox="308 1276 780 1305" style="list-style-type: none"> 2. Press the start key. The setting is set. <p data-bbox="288 1346 802 1375">Setting the V.34 symbol speed (3429 Hz)</p> <p data-bbox="288 1379 849 1408">Sets if the V.34 symbol speed 3429 Hz is used.</p> <ol data-bbox="308 1413 549 1442" style="list-style-type: none"> 1. Select the setting. <table border="1" data-bbox="336 1456 1399 1603"> <thead> <tr> <th data-bbox="336 1456 639 1500">Display</th> <th data-bbox="639 1456 1399 1500">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1500 639 1545">On</td> <td data-bbox="639 1500 1399 1545">V.34 symbol speed 3429 Hz is used.</td> </tr> <tr> <td data-bbox="336 1545 639 1603">Off</td> <td data-bbox="639 1545 1399 1603">V.34 symbol speed 3429 Hz is not used.</td> </tr> </tbody> </table> <p data-bbox="336 1612 576 1641">* : Initial setting: On</p> <ol data-bbox="308 1646 780 1675" style="list-style-type: none"> 2. Press the start key. The setting is set. 	Display	Description	V.34	Enables or disables V.34 communication.	V.34-3429Hz	Sets the V.34 symbol speed (3429 Hz).	DIS 2Res	Sets the number of times of DIS signal reception.	RTN Check	Sets the reference for RTN signal output.	Display	Description	On	V.34 communication is enabled for both transmission and reception.	TX	V.34 communication is enabled for transmission only.	RX	V.34 communication is enabled for reception only.	Off	V.34 communication is disabled for both transmission and reception.	Display	Description	On	V.34 symbol speed 3429 Hz is used.	Off	V.34 symbol speed 3429 Hz is not used.
Display	Description																										
V.34	Enables or disables V.34 communication.																										
V.34-3429Hz	Sets the V.34 symbol speed (3429 Hz).																										
DIS 2Res	Sets the number of times of DIS signal reception.																										
RTN Check	Sets the reference for RTN signal output.																										
Display	Description																										
On	V.34 communication is enabled for both transmission and reception.																										
TX	V.34 communication is enabled for transmission only.																										
RX	V.34 communication is enabled for reception only.																										
Off	V.34 communication is disabled for both transmission and reception.																										
Display	Description																										
On	V.34 symbol speed 3429 Hz is used.																										
Off	V.34 symbol speed 3429 Hz is not used.																										

Item No.	Description																
U633	<p>Setting the number of times of DIS signal reception Sets the number of times to receive the DIS signal to once or twice. Used as one of the correction measures for transmission errors and other problems.</p> <ol style="list-style-type: none"> Select the setting. <table border="1" data-bbox="336 387 1401 533"> <thead> <tr> <th>Display</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>Once</td> <td>Responds to the first signal.</td> </tr> <tr> <td>Twice</td> <td>Responds to the second signal.</td> </tr> </tbody> </table> <p>* : Initial setting: Once</p> <ol style="list-style-type: none"> Press the start key. The setting is set. <p>Setting the reference for RTN signal output Sets the error line rate as the reference for RTN signal output. If transmission errors occur frequently due to the quality of the line, they can be reduced by lowering this setting.</p> <ol style="list-style-type: none"> Select the setting. <table border="1" data-bbox="336 792 1401 1032"> <thead> <tr> <th>Display</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>5%</td> <td>Error line rate of 5%</td> </tr> <tr> <td>10%</td> <td>Error line rate of 10%</td> </tr> <tr> <td>15%</td> <td>Error line rate of 15%</td> </tr> <tr> <td>20%</td> <td>Error line rate of 20%</td> </tr> </tbody> </table> <p>* : Initial setting: 15%</p> <ol style="list-style-type: none"> Press the start key. The setting is set. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Once	Responds to the first signal.	Twice	Responds to the second signal.	Display	Description	5%	Error line rate of 5%	10%	Error line rate of 10%	15%	Error line rate of 15%	20%	Error line rate of 20%
Display	Description																
Once	Responds to the first signal.																
Twice	Responds to the second signal.																
Display	Description																
5%	Error line rate of 5%																
10%	Error line rate of 10%																
15%	Error line rate of 15%																
20%	Error line rate of 20%																
U634	<p>Setting communication control 5</p> <p>Description Sets the maximum number of error bytes judged acceptable when receiving a TCF signal. Used as a measure to ease transmission conditions if transmission errors occur.</p> <p>Setting</p> <ol style="list-style-type: none"> Press the start key. Select [TCF Check]. Change the setting using the cursor left/right keys or numeric keys. <table border="1" data-bbox="336 1585 1401 1682"> <thead> <tr> <th>Description</th> <th>Setting range</th> <th>Initial setting</th> </tr> </thead> <tbody> <tr> <td>Number of allowed error bytes when detecting TCF</td> <td>0 to 255</td> <td>0</td> </tr> </tbody> </table> <ol style="list-style-type: none"> Press the start key. The value is set. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Description	Setting range	Initial setting	Number of allowed error bytes when detecting TCF	0 to 255	0										
Description	Setting range	Initial setting															
Number of allowed error bytes when detecting TCF	0 to 255	0															

Item No.	Description																		
U640	<p data-bbox="288 241 671 271">Setting communication time 1</p> <p data-bbox="288 311 440 340">Description</p> <p data-bbox="288 344 1406 412">Sets the detection time when one-shot detection is selected for remote switching. (This setting item will be displayed, but the setting made is ineffective.)</p> <p data-bbox="288 416 1426 483">Sets the detection time when continuous detection is selected for remote switching. (This setting item will be displayed, but the setting made is ineffective.)</p> <p data-bbox="288 519 387 548">Method</p> <ol data-bbox="308 555 632 618" style="list-style-type: none"> 1. Press the start key. 2. Select the item to be set. <table border="1" data-bbox="336 631 1401 777"> <thead> <tr> <th data-bbox="336 631 641 678">Display</th> <th data-bbox="641 631 1401 678">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 678 641 725">Time (One)</td> <td data-bbox="641 678 1401 725">Sets the one-shot detection time for remote switching.</td> </tr> <tr> <td data-bbox="336 725 641 777">Time (Cont)</td> <td data-bbox="641 725 1401 777">Sets the continuous detection time for remote switching.</td> </tr> </tbody> </table> <p data-bbox="288 815 1010 844">Setting the one-shot detection time for remote switching</p> <ol data-bbox="308 851 932 880" style="list-style-type: none"> 1. Change the setting using the cursor left/right keys. <table border="1" data-bbox="336 893 1401 990"> <thead> <tr> <th data-bbox="336 893 975 940">Description</th> <th data-bbox="975 893 1187 940">Setting range</th> <th data-bbox="1187 893 1401 940">Initial setting</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 940 975 990">One-shot detection time for remote switching</td> <td data-bbox="975 940 1187 990">0 to 255</td> <td data-bbox="1187 940 1401 990">7</td> </tr> </tbody> </table> <ol data-bbox="308 999 766 1028" style="list-style-type: none"> 2. Press the start key. The value is set. <p data-bbox="288 1066 1042 1095">Setting the continuous detection time for remote switching</p> <ol data-bbox="308 1102 932 1131" style="list-style-type: none"> 1. Change the setting using the cursor left/right keys. <table border="1" data-bbox="336 1144 1401 1240"> <thead> <tr> <th data-bbox="336 1144 975 1191">Description</th> <th data-bbox="975 1144 1187 1191">Setting range</th> <th data-bbox="1187 1144 1401 1191">Initial setting</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1191 975 1240">Continuous detection time for remote switching</td> <td data-bbox="975 1191 1187 1240">0 to 255</td> <td data-bbox="1187 1191 1401 1240">80</td> </tr> </tbody> </table> <ol data-bbox="308 1249 766 1279" style="list-style-type: none"> 2. Press the start key. The value is set. <p data-bbox="288 1317 440 1346">Completion</p> <p data-bbox="288 1352 1254 1382">Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Time (One)	Sets the one-shot detection time for remote switching.	Time (Cont)	Sets the continuous detection time for remote switching.	Description	Setting range	Initial setting	One-shot detection time for remote switching	0 to 255	7	Description	Setting range	Initial setting	Continuous detection time for remote switching	0 to 255	80
Display	Description																		
Time (One)	Sets the one-shot detection time for remote switching.																		
Time (Cont)	Sets the continuous detection time for remote switching.																		
Description	Setting range	Initial setting																	
One-shot detection time for remote switching	0 to 255	7																	
Description	Setting range	Initial setting																	
Continuous detection time for remote switching	0 to 255	80																	

Item No.	Description																														
U641	<p data-bbox="288 241 673 271">Setting communication time 2</p> <p data-bbox="288 311 440 340">Description</p> <p data-bbox="288 344 799 374">Sets the time-out time for fax transmission.</p> <p data-bbox="288 380 400 409">Purpose</p> <p data-bbox="288 414 1222 443">To improve transmission performance for international communications mainly.</p> <p data-bbox="288 483 387 512">Method</p> <ol data-bbox="304 517 632 582" style="list-style-type: none"> 1. Press the start key. 2. Select the item to be set. <table border="1" data-bbox="336 595 1399 1028"> <thead> <tr> <th data-bbox="336 595 639 640">Display</th> <th data-bbox="639 595 1399 640">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 640 639 685">T0 Time Out</td> <td data-bbox="639 640 1399 685">Sets the T0 time-out time.</td> </tr> <tr> <td data-bbox="336 685 639 730">T1 Time Out</td> <td data-bbox="639 685 1399 730">Sets the T1 time-out time.</td> </tr> <tr> <td data-bbox="336 730 639 775">T2 Time Out</td> <td data-bbox="639 730 1399 775">Sets the T2 time-out time.</td> </tr> <tr> <td data-bbox="336 775 639 819">Ta Time Out</td> <td data-bbox="639 775 1399 819">Sets the Ta time-out time.</td> </tr> <tr> <td data-bbox="336 819 639 864">Tb1 Time Out</td> <td data-bbox="639 819 1399 864">Sets the Tb1 time-out time.</td> </tr> <tr> <td data-bbox="336 864 639 909">Tb2 Time Out</td> <td data-bbox="639 864 1399 909">Sets the Tb2 time-out time.</td> </tr> <tr> <td data-bbox="336 909 639 954">Tc Time Out</td> <td data-bbox="639 909 1399 954">Sets the Tc time-out time.</td> </tr> <tr> <td data-bbox="336 954 639 1028">Td Time Out</td> <td data-bbox="639 954 1399 1028">Sets the Td time-out time.</td> </tr> </tbody> </table> <p data-bbox="288 1070 644 1099">Setting the T0 time-out time</p> <p data-bbox="288 1104 1230 1133">Sets the time before detecting a CED or DIS signal after a dialing signal is sent.</p> <p data-bbox="288 1137 1386 1202">Depending on the quality of the exchange, or when the auto select function is selected at the destination unit, a line can be disconnected. Change the setting to prevent this problem.</p> <ol data-bbox="304 1207 932 1236" style="list-style-type: none"> 1. Change the setting using the cursor left/right keys. <table border="1" data-bbox="336 1249 1399 1348"> <thead> <tr> <th data-bbox="336 1249 975 1294">Description</th> <th data-bbox="975 1249 1187 1294">Setting range</th> <th data-bbox="1187 1249 1399 1294">Initial setting</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1294 975 1348">T0 time-out time</td> <td data-bbox="975 1294 1187 1348">30 to 90 s</td> <td data-bbox="1187 1294 1399 1348">56</td> </tr> </tbody> </table> <ol data-bbox="304 1352 767 1382" style="list-style-type: none"> 2. Press the start key. The value is set. <p data-bbox="288 1424 644 1453">Setting the T1 time-out time</p> <p data-bbox="288 1458 1422 1523">Sets the time before receiving the correct signal after call reception. No change is necessary for this maintenance item.</p> <ol data-bbox="304 1527 932 1556" style="list-style-type: none"> 1. Change the setting using the cursor left/right keys. <table border="1" data-bbox="336 1570 1399 1668"> <thead> <tr> <th data-bbox="336 1570 975 1615">Description</th> <th data-bbox="975 1570 1187 1615">Setting range</th> <th data-bbox="1187 1570 1399 1615">Initial setting</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1615 975 1668">T1 time-out time</td> <td data-bbox="975 1615 1187 1668">30 to 90 s</td> <td data-bbox="1187 1615 1399 1668">36</td> </tr> </tbody> </table> <ol data-bbox="304 1673 767 1702" style="list-style-type: none"> 2. Press the start key. The value is set. 	Display	Description	T0 Time Out	Sets the T0 time-out time.	T1 Time Out	Sets the T1 time-out time.	T2 Time Out	Sets the T2 time-out time.	Ta Time Out	Sets the Ta time-out time.	Tb1 Time Out	Sets the Tb1 time-out time.	Tb2 Time Out	Sets the Tb2 time-out time.	Tc Time Out	Sets the Tc time-out time.	Td Time Out	Sets the Td time-out time.	Description	Setting range	Initial setting	T0 time-out time	30 to 90 s	56	Description	Setting range	Initial setting	T1 time-out time	30 to 90 s	36
Display	Description																														
T0 Time Out	Sets the T0 time-out time.																														
T1 Time Out	Sets the T1 time-out time.																														
T2 Time Out	Sets the T2 time-out time.																														
Ta Time Out	Sets the Ta time-out time.																														
Tb1 Time Out	Sets the Tb1 time-out time.																														
Tb2 Time Out	Sets the Tb2 time-out time.																														
Tc Time Out	Sets the Tc time-out time.																														
Td Time Out	Sets the Td time-out time.																														
Description	Setting range	Initial setting																													
T0 time-out time	30 to 90 s	56																													
Description	Setting range	Initial setting																													
T1 time-out time	30 to 90 s	36																													

Item No.	Description																						
U641	<p data-bbox="288 241 646 271">Setting the T2 time-out time</p> <p data-bbox="288 277 801 306">The T2 time-out time decides the following.</p> <p data-bbox="288 313 863 342">From CFR signal output to image data reception</p> <p data-bbox="288 349 940 378">From image data reception to the next signal reception</p> <p data-bbox="288 385 1035 414">In ECM, from RNR signal detection to the next signal reception</p> <p data-bbox="308 421 932 450">1. Change the setting using the cursor left/right keys.</p> <table border="1" data-bbox="336 459 1401 591"> <thead> <tr> <th data-bbox="336 459 807 539">Description</th> <th data-bbox="807 459 991 539">Setting range</th> <th data-bbox="991 459 1171 539">Initial setting</th> <th data-bbox="1171 459 1401 539">Change in value per step</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 539 807 591">T2 time-out time</td> <td data-bbox="807 539 991 591">1 to 255</td> <td data-bbox="991 539 1171 591">69</td> <td data-bbox="1171 539 1401 591">100 ms</td> </tr> </tbody> </table> <p data-bbox="308 600 766 629">2. Press the start key. The value is set.</p> <p data-bbox="288 667 643 696">Setting the Ta time-out time</p> <p data-bbox="288 703 1423 871">In the fax/telephone auto select mode, sets the time to continue ringing an operator through the connected telephone after receiving a call as a fax machine (see figure 1-3-20). A fax signal is received within the Ta set time, or the fax mode is selected automatically when the time elapses. In fax/telephone auto select mode, change the setting when fax reception is unsuccessful or a telephone fails to receive a call.</p> <p data-bbox="308 878 932 907">1. Change the setting using the cursor left/right keys.</p> <table border="1" data-bbox="336 916 1401 1014"> <thead> <tr> <th data-bbox="336 916 975 965">Description</th> <th data-bbox="975 916 1187 965">Setting range</th> <th data-bbox="1187 916 1401 965">Initial setting</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 965 975 1014">Ta time-out time</td> <td data-bbox="975 965 1187 1014">1 to 255</td> <td data-bbox="1187 965 1401 1014">30</td> </tr> </tbody> </table> <p data-bbox="308 1023 766 1052">2. Press the start key. The value is set.</p> <div data-bbox="515 1081 1217 1458"> </div> <p data-bbox="612 1494 1110 1523">Figure 1-3-20 Ta/Tb1/Tb2 time-out time</p> <p data-bbox="288 1561 662 1590">Setting the Tb1 time-out time</p> <p data-bbox="288 1597 1423 1697">In the fax/telephone auto select mode, sets the time to start sending the ring back tone after receiving a call as a fax machine (see figure 1-3-20). In fax/telephone auto select mode, change the setting when fax reception is unsuccessful or a telephone fails to receive a call.</p> <p data-bbox="308 1704 932 1733">1. Change the setting using the cursor left/right keys.</p> <table border="1" data-bbox="336 1742 1401 1874"> <thead> <tr> <th data-bbox="336 1742 807 1823">Description</th> <th data-bbox="807 1742 991 1823">Setting range</th> <th data-bbox="991 1742 1171 1823">Initial setting</th> <th data-bbox="1171 1742 1401 1823">Change in value per step</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1823 807 1874">Tb1 time-out time</td> <td data-bbox="807 1823 991 1874">1 to 255</td> <td data-bbox="991 1823 1171 1874">20</td> <td data-bbox="1171 1823 1401 1874">100 ms</td> </tr> </tbody> </table> <p data-bbox="308 1883 766 1912">2. Press the start key. The value is set.</p>	Description	Setting range	Initial setting	Change in value per step	T2 time-out time	1 to 255	69	100 ms	Description	Setting range	Initial setting	Ta time-out time	1 to 255	30	Description	Setting range	Initial setting	Change in value per step	Tb1 time-out time	1 to 255	20	100 ms
Description	Setting range	Initial setting	Change in value per step																				
T2 time-out time	1 to 255	69	100 ms																				
Description	Setting range	Initial setting																					
Ta time-out time	1 to 255	30																					
Description	Setting range	Initial setting	Change in value per step																				
Tb1 time-out time	1 to 255	20	100 ms																				

Item No.	Description																				
U641	<p>Setting the Tb2 time-out time</p> <p>In the fax/telephone auto select mode, sets the time to start ringing an operator through the connected telephone after receiving a call as a fax machine (see figure 1-3-20). In the fax/telephone auto select mode, change the setting when fax reception is unsuccessful or a telephone fails to receive a call.</p> <p>1. Change the setting using the cursor left/right keys.</p> <table border="1" data-bbox="336 459 1401 589"> <thead> <tr> <th>Description</th> <th>Setting range</th> <th>Initial setting</th> <th>Change in value per step</th> </tr> </thead> <tbody> <tr> <td>Tb2 time-out time</td> <td>1 to 255</td> <td>80</td> <td>100 ms</td> </tr> </tbody> </table> <p>2. Press the start key. The value is set.</p> <p>Setting the Tc time-out time</p> <p>In the TAD mode, set the time to check if there are any triggers for shifting to fax reception after a connected telephone receives a call. Only the telephone function is available if shifting is not made within the set Tc time.</p> <p>In the TAD mode, change the setting when fax reception is unsuccessful or a telephone fails to receive a call.</p> <p>1. Change the setting using the cursor left/right keys.</p> <table border="1" data-bbox="336 918 1401 1014"> <thead> <tr> <th>Description</th> <th>Setting range</th> <th>Initial setting</th> </tr> </thead> <tbody> <tr> <td>Tc time-out time</td> <td>1 to 255</td> <td>60</td> </tr> </tbody> </table> <p>2. Press the start key. The value is set.</p> <p>Setting the Td time-out time</p> <p>Sets the length of the time required to determine silent status (fax), one of the triggers for Tc time check. In the TAD mode, change the setting when fax reception is unsuccessful or a telephone fails to receive a call. Be sure not to set it too short; otherwise, the mode may be shifted to fax while the unit is being used as a telephone.</p> <p>1. Change the setting using the cursor left/right keys.</p> <table border="1" data-bbox="336 1310 1401 1406"> <thead> <tr> <th>Description</th> <th>Setting range</th> <th>Initial setting</th> </tr> </thead> <tbody> <tr> <td>Td time-out time</td> <td>1 to 255</td> <td>9 (120 V)/6 (220-240 V)</td> </tr> </tbody> </table> <p>2. Press the start key. The value is set.</p> <p>Completion</p> <p>Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Description	Setting range	Initial setting	Change in value per step	Tb2 time-out time	1 to 255	80	100 ms	Description	Setting range	Initial setting	Tc time-out time	1 to 255	60	Description	Setting range	Initial setting	Td time-out time	1 to 255	9 (120 V)/6 (220-240 V)
Description	Setting range	Initial setting	Change in value per step																		
Tb2 time-out time	1 to 255	80	100 ms																		
Description	Setting range	Initial setting																			
Tc time-out time	1 to 255	60																			
Description	Setting range	Initial setting																			
Td time-out time	1 to 255	9 (120 V)/6 (220-240 V)																			

Item No.	Description								
U650	<p>Setting modem 1</p> <p>Description Sets the G3 cable equalizer. Sets the modem detection level.</p> <p>Purpose Perform the following adjustment to make the equalizer compatible with the line characteristics. To improve the transmission performance when a low quality line is used.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select the item to be set. <table border="1" data-bbox="336 631 1401 824"> <thead> <tr> <th data-bbox="336 631 641 680">Display</th> <th data-bbox="641 631 1401 680">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 680 641 730">Reg G3 TX Eqr</td> <td data-bbox="641 680 1401 730">Sets the G3 transmission cable equalizer.</td> </tr> <tr> <td data-bbox="336 730 641 779">Reg G3 RX Eqr</td> <td data-bbox="641 730 1401 779">Sets the G3 reception cable equalizer.</td> </tr> <tr> <td data-bbox="336 779 641 824">RX Mdm Level</td> <td data-bbox="641 779 1401 824">Sets the modem detection level.</td> </tr> </tbody> </table> <p>Setting the G3 transmission cable equalizer</p> <ol style="list-style-type: none"> 1. Select [0dB], [4dB], [8dB] or [12dB]. * : Initial setting: 0dB 2. Press the start key. The setting is set. <p>Setting the G3 reception cable equalizer</p> <ol style="list-style-type: none"> 1. Select [0dB], [4dB], [8dB] or [12dB]. * : Initial setting: 0dB 2. Press the start key. The setting is set. <p>Setting the modem detection level</p> <ol style="list-style-type: none"> 1. Select [-33dBm], [-38dBm], [-43dBm] or [-48dBm] using the cursor up/down keys. * : Initial setting: -43dBm 2. Press the start key. The setting is set. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Reg G3 TX Eqr	Sets the G3 transmission cable equalizer.	Reg G3 RX Eqr	Sets the G3 reception cable equalizer.	RX Mdm Level	Sets the modem detection level.
Display	Description								
Reg G3 TX Eqr	Sets the G3 transmission cable equalizer.								
Reg G3 RX Eqr	Sets the G3 reception cable equalizer.								
RX Mdm Level	Sets the modem detection level.								

Item No.	Description																
U651	<p>Setting modem 2</p> <p>Description Sets the modem output level. Sets the DTMF output level of a push-button dial telephone.</p> <p>Purpose Used if problems occur when sending a signal with a push-button dial telephone.</p> <p>Setting</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select the item to be set. 3. Change the setting using the cursor left/right keys or numeric keys. <table border="1" data-bbox="336 667 1385 963"> <thead> <tr> <th>Display</th> <th>Description</th> <th>Setting range</th> <th>Initial setting</th> </tr> </thead> <tbody> <tr> <td>Sgl LV Mdm</td> <td>Modem output level</td> <td>1 to 15</td> <td>9 (120 V) 10 (220-240 V)</td> </tr> <tr> <td>DTMF LV(C)</td> <td>DTMF output level (main value)</td> <td>0 to 15.0</td> <td>5 (120 V) 10.5 (220-240 V)</td> </tr> <tr> <td>DTMF LV(D)</td> <td>DTMF output level (level difference)</td> <td>0 to 5.5</td> <td>2 (120 V) 2.5 (220-240 V)</td> </tr> </tbody> </table> <ol style="list-style-type: none"> 4. Press the start key. The setting is set. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Setting range	Initial setting	Sgl LV Mdm	Modem output level	1 to 15	9 (120 V) 10 (220-240 V)	DTMF LV(C)	DTMF output level (main value)	0 to 15.0	5 (120 V) 10.5 (220-240 V)	DTMF LV(D)	DTMF output level (level difference)	0 to 5.5	2 (120 V) 2.5 (220-240 V)
Display	Description	Setting range	Initial setting														
Sgl LV Mdm	Modem output level	1 to 15	9 (120 V) 10 (220-240 V)														
DTMF LV(C)	DTMF output level (main value)	0 to 15.0	5 (120 V) 10.5 (220-240 V)														
DTMF LV(D)	DTMF output level (level difference)	0 to 5.5	2 (120 V) 2.5 (220-240 V)														

Item No.	Description																								
U660	<p data-bbox="288 241 496 271">Setting the NCU</p> <p data-bbox="288 311 440 340">Description</p> <p data-bbox="288 344 951 374">Makes setting regarding the network control unit (NCU).</p> <p data-bbox="288 380 400 409">Purpose</p> <p data-bbox="288 414 624 443">To be executed as required.</p> <p data-bbox="288 483 387 512">Method</p> <ol data-bbox="308 517 632 582" style="list-style-type: none"> 1. Press the start key. 2. Select the item to be set. <table border="1" data-bbox="336 595 1399 884"> <thead> <tr> <th data-bbox="336 595 639 640">Display</th> <th data-bbox="639 595 1399 640">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 640 639 685">Exchange</td> <td data-bbox="639 640 1399 685">Sets the connection to PBX/PSTN.</td> </tr> <tr> <td data-bbox="336 685 639 730">Dial Tone</td> <td data-bbox="639 685 1399 730">Sets PSTN dial tone detection.</td> </tr> <tr> <td data-bbox="336 730 639 775">Busy Tone</td> <td data-bbox="639 730 1399 775">Sets busy tone detection.</td> </tr> <tr> <td data-bbox="336 775 639 819">PBX Setting</td> <td data-bbox="639 775 1399 819">Setting for a PBX.</td> </tr> <tr> <td data-bbox="336 819 639 884">DC Loop</td> <td data-bbox="639 819 1399 884">Sets the loop current detection before dialing.</td> </tr> </tbody> </table> <p data-bbox="288 927 754 956">Setting the connection to PBX/PSTN</p> <p data-bbox="288 960 1331 990">Selects if a fax is to be connected to either a PBX or public switched telephone network.</p> <ol data-bbox="308 994 549 1023" style="list-style-type: none"> 1. Select the setting. <table border="1" data-bbox="336 1037 1399 1187"> <thead> <tr> <th data-bbox="336 1037 639 1081">Display</th> <th data-bbox="639 1037 1399 1081">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1081 639 1126">PSTN</td> <td data-bbox="639 1081 1399 1126">Connected to the public switched telephone network.</td> </tr> <tr> <td data-bbox="336 1126 639 1187">PBX</td> <td data-bbox="639 1126 1399 1187">Connected to a PBX.</td> </tr> </tbody> </table> <p data-bbox="336 1193 611 1223">* : Initial setting: PSTN</p> <ol data-bbox="308 1227 782 1256" style="list-style-type: none"> 2. Press the start key. The setting is set. <p data-bbox="288 1296 705 1326">Setting PSTN dial tone detection</p> <p data-bbox="288 1330 1426 1395">Selects if the dial tone is detected to check the telephone is off the hook when a fax is connected to a public switched telephone network.</p> <ol data-bbox="308 1400 549 1429" style="list-style-type: none"> 1. Select the setting. <table border="1" data-bbox="336 1442 1399 1592"> <thead> <tr> <th data-bbox="336 1442 639 1487">Display</th> <th data-bbox="639 1442 1399 1487">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1487 639 1532">On</td> <td data-bbox="639 1487 1399 1532">Detects the dial tone.</td> </tr> <tr> <td data-bbox="336 1532 639 1592">Off</td> <td data-bbox="639 1532 1399 1592">Does not detect the dial tone.</td> </tr> </tbody> </table> <p data-bbox="336 1599 576 1628">* : Initial setting: On</p> <ol data-bbox="308 1632 782 1662" style="list-style-type: none"> 2. Press the start key. The setting is set. 	Display	Description	Exchange	Sets the connection to PBX/PSTN.	Dial Tone	Sets PSTN dial tone detection.	Busy Tone	Sets busy tone detection.	PBX Setting	Setting for a PBX.	DC Loop	Sets the loop current detection before dialing.	Display	Description	PSTN	Connected to the public switched telephone network.	PBX	Connected to a PBX.	Display	Description	On	Detects the dial tone.	Off	Does not detect the dial tone.
Display	Description																								
Exchange	Sets the connection to PBX/PSTN.																								
Dial Tone	Sets PSTN dial tone detection.																								
Busy Tone	Sets busy tone detection.																								
PBX Setting	Setting for a PBX.																								
DC Loop	Sets the loop current detection before dialing.																								
Display	Description																								
PSTN	Connected to the public switched telephone network.																								
PBX	Connected to a PBX.																								
Display	Description																								
On	Detects the dial tone.																								
Off	Does not detect the dial tone.																								

Item No.	Description																		
U660	<p>Setting busy tone detection When a fax signal is sent, sets whether the line is disconnected immediately after a busy tone is detected, or the busy tone is not detected and the line remains connected until T0 time-out time. Fax transmission may fail due to incorrect busy tone detection. When set to 2, this problem may be prevented. However, the line is not disconnected within the T0 time-out time even if the destination line is busy.</p> <p>1. Select the setting.</p> <table border="1" data-bbox="336 495 1401 636"> <thead> <tr> <th>Display</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>On</td> <td>Detects busy tone.</td> </tr> <tr> <td>Off</td> <td>Does not detect busy tone.</td> </tr> </tbody> </table> <p>* : Initial setting: On</p> <p>2. Press the start key. The setting is set.</p> <p>Setting for a PBX Selects the mode to connect an outside call when connected to a PBX. According to the type of the PBX connected, select the mode to connect an outside call.</p> <p>1. Select the setting.</p> <table border="1" data-bbox="336 898 1401 1039"> <thead> <tr> <th>Display</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>Flash</td> <td>Flashing mode</td> </tr> <tr> <td>Loop</td> <td>Code number mode</td> </tr> </tbody> </table> <p>* : Initial setting: Loop</p> <p>2. Press the start key. The setting is set.</p> <p>Setting the loop current detection before dialing Sets if the loop current detection is performed before dialing.</p> <p>1. Select the setting.</p> <table border="1" data-bbox="336 1267 1401 1408"> <thead> <tr> <th>Display</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>On</td> <td>Performs loop current detection before dialing.</td> </tr> <tr> <td>Off</td> <td>Does not perform loop current detection before dialing.</td> </tr> </tbody> </table> <p>* : Initial setting: On</p> <p>2. Press the start key. The setting is set.</p> <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	On	Detects busy tone.	Off	Does not detect busy tone.	Display	Description	Flash	Flashing mode	Loop	Code number mode	Display	Description	On	Performs loop current detection before dialing.	Off	Does not perform loop current detection before dialing.
Display	Description																		
On	Detects busy tone.																		
Off	Does not detect busy tone.																		
Display	Description																		
Flash	Flashing mode																		
Loop	Code number mode																		
Display	Description																		
On	Performs loop current detection before dialing.																		
Off	Does not perform loop current detection before dialing.																		

Item No.	Description																				
U670	<p data-bbox="290 241 491 273">Outputting lists</p> <p data-bbox="290 309 440 340">Description</p> <p data-bbox="290 344 877 376">Outputs a list of data regarding fax transmissions.</p> <p data-bbox="290 380 1385 443">Printing a list is disabled either when a job is remaining in the buffer or when [Pause All Print Jobs] is pressed to halt printing.</p> <p data-bbox="290 448 399 479">Purpose</p> <p data-bbox="290 483 1187 515">To check conditions of use, settings and transmission procedures of the fax.</p> <p data-bbox="290 551 386 582">Method</p> <ol data-bbox="306 586 880 685" style="list-style-type: none"> 1. Press the start key. 2. Select the item to be output. 3. Press the start key. The selected list is output. <table border="1" data-bbox="338 698 1401 1281"> <thead> <tr> <th data-bbox="338 698 641 743">Display</th> <th data-bbox="641 698 1401 743">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="338 743 641 833">Sys Conf Report</td> <td data-bbox="641 743 1401 833">Outputs a list of software switches, self telephone number, confidential boxes, ROM versions and other information.</td> </tr> <tr> <td data-bbox="338 833 641 900">Action List</td> <td data-bbox="641 833 1401 900">Outputs a list of error history, transmission line details and other information.</td> </tr> <tr> <td data-bbox="338 900 641 990">Self Sts Report</td> <td data-bbox="641 900 1401 990">Outputs a list of settings in maintenance mode (own-status report) regarding fax transmission only.</td> </tr> <tr> <td data-bbox="338 990 641 1034">Protocol List</td> <td data-bbox="641 990 1401 1034">Outputs a list of transmission procedures.</td> </tr> <tr> <td data-bbox="338 1034 641 1079">Error List</td> <td data-bbox="641 1034 1401 1079">Outputs a list of error.</td> </tr> <tr> <td data-bbox="338 1079 641 1124">Addr List(No.)</td> <td data-bbox="641 1079 1401 1124">Outputs address book in order IDs were added</td> </tr> <tr> <td data-bbox="338 1124 641 1169">Addr List(Idx)</td> <td data-bbox="641 1124 1401 1169">Outputs address book in order of names</td> </tr> <tr> <td data-bbox="338 1169 641 1214">One-touch List</td> <td data-bbox="641 1169 1401 1214">Outputs a list of one-touch.</td> </tr> <tr> <td data-bbox="338 1214 641 1281">Group List</td> <td data-bbox="641 1214 1401 1281">Outputs a list of group.</td> </tr> </tbody> </table> <p data-bbox="290 1326 440 1357">Completion</p> <p data-bbox="290 1361 1254 1393">Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Sys Conf Report	Outputs a list of software switches, self telephone number, confidential boxes, ROM versions and other information.	Action List	Outputs a list of error history, transmission line details and other information.	Self Sts Report	Outputs a list of settings in maintenance mode (own-status report) regarding fax transmission only.	Protocol List	Outputs a list of transmission procedures.	Error List	Outputs a list of error.	Addr List(No.)	Outputs address book in order IDs were added	Addr List(Idx)	Outputs address book in order of names	One-touch List	Outputs a list of one-touch.	Group List	Outputs a list of group.
Display	Description																				
Sys Conf Report	Outputs a list of software switches, self telephone number, confidential boxes, ROM versions and other information.																				
Action List	Outputs a list of error history, transmission line details and other information.																				
Self Sts Report	Outputs a list of settings in maintenance mode (own-status report) regarding fax transmission only.																				
Protocol List	Outputs a list of transmission procedures.																				
Error List	Outputs a list of error.																				
Addr List(No.)	Outputs address book in order IDs were added																				
Addr List(Idx)	Outputs address book in order of names																				
One-touch List	Outputs a list of one-touch.																				
Group List	Outputs a list of group.																				

Item No.	Description																		
U695	<p data-bbox="288 241 596 271">FAX function customize</p> <p data-bbox="288 311 440 340">Description</p> <p data-bbox="288 344 1426 409">Sets fax batch transmission ON/OFF. Also changes the print size priority at the time of small size reception.</p> <p data-bbox="288 414 400 443">Purpose</p> <p data-bbox="288 448 622 477">To be executed as required.</p> <p data-bbox="288 517 384 546">Setting</p> <p data-bbox="304 551 549 580">1. Select the setting.</p> <table border="1" data-bbox="336 595 1401 741"> <thead> <tr> <th data-bbox="336 595 639 640">Display</th> <th data-bbox="639 595 1401 640">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 640 639 685">FAX Bulk TX</td> <td data-bbox="639 640 1401 685">fax batch transmission On/Off</td> </tr> <tr> <td data-bbox="336 685 639 741">A5 Pt Pri Chg</td> <td data-bbox="639 685 1401 741">Change of print size priority at the time of small size reception</td> </tr> </tbody> </table> <p data-bbox="288 786 576 815">Setting: [FAX Bulk TX]</p> <p data-bbox="304 819 927 848">1. Select [On] or [Off] using the cursor left/right keys.</p> <table border="1" data-bbox="336 864 1401 1010"> <thead> <tr> <th data-bbox="336 864 639 909">Display</th> <th data-bbox="639 864 1401 909">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 909 639 954">On</td> <td data-bbox="639 909 1401 954">Fax batch transmission is enabled.</td> </tr> <tr> <td data-bbox="336 954 639 1010">Off</td> <td data-bbox="639 954 1401 1010">Fax batch transmission is disabled.</td> </tr> </tbody> </table> <p data-bbox="336 1016 576 1046">* : Initial setting: On</p> <p data-bbox="304 1050 782 1079">2. Press the start key. The setting is set.</p> <p data-bbox="288 1124 587 1153">Setting: [A5 Pt Pri Chg]</p> <p data-bbox="304 1158 927 1187">1. Select [On] or [Off] using the cursor left/right keys.</p> <table border="1" data-bbox="336 1202 1401 1348"> <thead> <tr> <th data-bbox="336 1202 639 1247">Display</th> <th data-bbox="639 1202 1401 1247">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1247 639 1292">On</td> <td data-bbox="639 1247 1401 1292">At the time of A5 size reception: A5→B5→A4→B4→A3</td> </tr> <tr> <td data-bbox="336 1292 639 1348">Off</td> <td data-bbox="639 1292 1401 1348">At the time of A5 size reception: A5→A4→B5→A3→B4</td> </tr> </tbody> </table> <p data-bbox="336 1355 576 1384">* : Initial setting: Off</p> <p data-bbox="304 1388 782 1417">2. Press the start key. The setting is set.</p> <p data-bbox="288 1462 440 1491">Completion</p> <p data-bbox="288 1496 1254 1525">Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	FAX Bulk TX	fax batch transmission On/Off	A5 Pt Pri Chg	Change of print size priority at the time of small size reception	Display	Description	On	Fax batch transmission is enabled.	Off	Fax batch transmission is disabled.	Display	Description	On	At the time of A5 size reception: A5→B5→A4→B4→A3	Off	At the time of A5 size reception: A5→A4→B5→A3→B4
Display	Description																		
FAX Bulk TX	fax batch transmission On/Off																		
A5 Pt Pri Chg	Change of print size priority at the time of small size reception																		
Display	Description																		
On	Fax batch transmission is enabled.																		
Off	Fax batch transmission is disabled.																		
Display	Description																		
On	At the time of A5 size reception: A5→B5→A4→B4→A3																		
Off	At the time of A5 size reception: A5→A4→B5→A3→B4																		

Item No.	Description																																														
U699	<p data-bbox="288 241 667 271">Setting the software switches</p> <p data-bbox="288 311 440 340">Description</p> <p data-bbox="288 344 1046 374">Sets the software switches on the FAX control PWB individually.</p> <p data-bbox="288 380 400 409">Purpose</p> <p data-bbox="288 414 1366 515">To change the setting when a problem such as split output of received originals occurs. Since the communication performance is largely affected, normally this setting need not be changed.</p> <p data-bbox="288 555 387 584">Method</p> <ol data-bbox="304 589 1390 790" style="list-style-type: none"> 1. Press the start key. 2. Press [SW No.]. 3. Enter the desired software switch number (3 digits) using the numeric keys and press the enter key. 4. Use numeric keys 7 to 0 to switch each bit between 0 and 1. 5. Press the start key to set the value. <p data-bbox="288 831 440 860">Completion</p> <p data-bbox="288 864 1254 893">Press the stop key. The screen for selecting a maintenance item No. is displayed.</p> <p data-bbox="288 934 1102 963">List of Software Switches of Which the Setting Can Be Changed</p> <p data-bbox="288 1003 762 1032"><Communication control procedure></p> <table border="1" data-bbox="336 1048 1401 2007"> <thead> <tr> <th data-bbox="336 1048 427 1093">No.</th> <th data-bbox="427 1048 592 1093">Bit</th> <th data-bbox="592 1048 1401 1093">Item</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1093 427 1189" rowspan="2">36</td> <td data-bbox="427 1093 592 1144">7654</td> <td data-bbox="592 1093 1401 1144">Coding format in transmission</td> </tr> <tr> <td data-bbox="427 1144 592 1189">3210</td> <td data-bbox="592 1144 1401 1189">Coding format in reception</td> </tr> <tr> <td data-bbox="336 1189 427 1480" rowspan="6">37</td> <td data-bbox="427 1189 592 1240">5</td> <td data-bbox="592 1189 1401 1240">33600 bps/V34</td> </tr> <tr> <td data-bbox="427 1240 592 1292">4</td> <td data-bbox="592 1240 1401 1292">31200 bps/V34</td> </tr> <tr> <td data-bbox="427 1292 592 1344">3</td> <td data-bbox="592 1292 1401 1344">28800 bps/V34</td> </tr> <tr> <td data-bbox="427 1344 592 1395">2</td> <td data-bbox="592 1344 1401 1395">26400 bps/V34</td> </tr> <tr> <td data-bbox="427 1395 592 1447">1</td> <td data-bbox="592 1395 1401 1447">24000 bps/V34</td> </tr> <tr> <td data-bbox="427 1447 592 1480">0</td> <td data-bbox="592 1447 1401 1480">21600 bps/V34</td> </tr> <tr> <td data-bbox="336 1480 427 1861" rowspan="8">38</td> <td data-bbox="427 1480 592 1532">7</td> <td data-bbox="592 1480 1401 1532">19200 bps/V34</td> </tr> <tr> <td data-bbox="427 1532 592 1583">6</td> <td data-bbox="592 1532 1401 1583">16800 bps/V34</td> </tr> <tr> <td data-bbox="427 1583 592 1635">5</td> <td data-bbox="592 1583 1401 1635">14400 bps/V34</td> </tr> <tr> <td data-bbox="427 1635 592 1686">4</td> <td data-bbox="592 1635 1401 1686">12000 bps/V34</td> </tr> <tr> <td data-bbox="427 1686 592 1738">3</td> <td data-bbox="592 1686 1401 1738">9600 bps/V34</td> </tr> <tr> <td data-bbox="427 1738 592 1789">2</td> <td data-bbox="592 1738 1401 1789">7200 bps/V34</td> </tr> <tr> <td data-bbox="427 1789 592 1841">1</td> <td data-bbox="592 1789 1401 1841">4800 bps/V34</td> </tr> <tr> <td data-bbox="427 1841 592 1861">0</td> <td data-bbox="592 1841 1401 1861">2400 bps/V34</td> </tr> <tr> <td data-bbox="336 1861 427 1912">41</td> <td data-bbox="427 1861 592 1912">3</td> <td data-bbox="592 1861 1401 1912">FSK detection in V.8</td> </tr> <tr> <td data-bbox="336 1912 427 1964" rowspan="2">42</td> <td data-bbox="427 1912 592 1964">4</td> <td data-bbox="592 1912 1401 1964">4800 bps when low-speed setting is active</td> </tr> <tr> <td data-bbox="427 1964 592 2007">2</td> <td data-bbox="592 1964 1401 2007">FIF length in transmission of more than 4 times of DIS/DTC signal</td> </tr> </tbody> </table>	No.	Bit	Item	36	7654	Coding format in transmission	3210	Coding format in reception	37	5	33600 bps/V34	4	31200 bps/V34	3	28800 bps/V34	2	26400 bps/V34	1	24000 bps/V34	0	21600 bps/V34	38	7	19200 bps/V34	6	16800 bps/V34	5	14400 bps/V34	4	12000 bps/V34	3	9600 bps/V34	2	7200 bps/V34	1	4800 bps/V34	0	2400 bps/V34	41	3	FSK detection in V.8	42	4	4800 bps when low-speed setting is active	2	FIF length in transmission of more than 4 times of DIS/DTC signal
No.	Bit	Item																																													
36	7654	Coding format in transmission																																													
	3210	Coding format in reception																																													
37	5	33600 bps/V34																																													
	4	31200 bps/V34																																													
	3	28800 bps/V34																																													
	2	26400 bps/V34																																													
	1	24000 bps/V34																																													
	0	21600 bps/V34																																													
38	7	19200 bps/V34																																													
	6	16800 bps/V34																																													
	5	14400 bps/V34																																													
	4	12000 bps/V34																																													
	3	9600 bps/V34																																													
	2	7200 bps/V34																																													
	1	4800 bps/V34																																													
	0	2400 bps/V34																																													
41	3	FSK detection in V.8																																													
42	4	4800 bps when low-speed setting is active																																													
	2	FIF length in transmission of more than 4 times of DIS/DTC signal																																													

TONER

www.tonerplus.com.ua

Item No.	Description		
U699	<Communication time setting>		
	No.	Bit	Item
	53	76543210	T3 timeout setting
	54	76543210	T4 timeout setting (automatic equipment)
	55	76543210	T5 timeout setting
	60	76543210	Time before transmission of CNG (1100 Hz) signal
	63	76543210	T0 timeout setting (manual equipment)
	64	7	Phase C timeout in ECM reception
	66	76543210	Timeout 1 in countermeasures against echo
	68	76543210	Timeout for FSK detection start in V.8
	<Modem setting>		
	No.	Bit	Item
	89	76543	RX gain adjust
	<NCU setting>		
	No.	Bit	Item
	121	7654	Dial tone/busy tone detection pattern
	122	7654	Busy tone detection pattern
		1	Busy tone detection in automatic FAX/TEL switching
	125	76543210	Access code registration for connection to PSTN
	126	7654	FAX/TEL automatic switching ring back tone ON/OFF cycle
	<Calling time setting>		
	No.	Bit	Item
	133	76543210	DTMF signal transmission time
	134	76543210	DTMF signal pause time
	141	76543210	Ringer detection cycle (minimum)
	142	76543210	Ringer detection cycle (maximum)
	143	76543210	Ringer ON time detection
144	76543210	Ringer OFF time detection	
145	76543210	Ringer OFF non-detection time	
147	76543210	Dial tone detection time (continuous tone)	
148	76543210	Allowable dial tone interruption time	
149	76543210	Time for transmitting selection signal after closing the DC circuit	
151	76543210	Ringer frequency detection invalid time	

Item No.	Description												
U901	<p data-bbox="288 241 884 275">Checking copy counts by paper feed locations</p> <p data-bbox="288 311 440 340">Description</p> <p data-bbox="288 344 943 376">Displays or clears copy counts by paper feed locations.</p> <p data-bbox="288 380 400 409">Purpose</p> <p data-bbox="288 414 1417 479">To check the time to replace consumable parts. Also to clear the counts after replacing the consumable parts.</p> <p data-bbox="288 517 387 546">Method</p> <p data-bbox="308 553 1160 584">1. Press the start key. The counts by paper feed locations are displayed.</p> <table border="1" data-bbox="336 595 1399 884"> <thead> <tr> <th data-bbox="336 595 639 645">Display</th> <th data-bbox="639 595 1399 645">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 645 639 689">MPT</td> <td data-bbox="639 645 1399 689">MP tray</td> </tr> <tr> <td data-bbox="336 689 639 734">Cassette1</td> <td data-bbox="639 689 1399 734">Cassette 1</td> </tr> <tr> <td data-bbox="336 734 639 779">Cassette2</td> <td data-bbox="639 734 1399 779">Cassette 2 (optional paper feeder)</td> </tr> <tr> <td data-bbox="336 779 639 824">Cassette3</td> <td data-bbox="639 779 1399 824">Cassette 3 (optional paper feeder)</td> </tr> <tr> <td data-bbox="336 824 639 884">Duplex</td> <td data-bbox="639 824 1399 884">Duplex unit</td> </tr> </tbody> </table> <p data-bbox="336 891 1404 958">* : When an optional paper feed device is not installed, the corresponding count is not displayed.</p> <p data-bbox="288 996 400 1025">Clearing</p> <p data-bbox="308 1032 916 1167">1. Select the counts to be cleared. [Cassette2] and [Cassette3] cannot be cleared. 2. Select the counts for all and press [Clear]. 3. Press the start key. The counter value is cleared.</p> <p data-bbox="288 1205 440 1234">Completion</p> <p data-bbox="288 1240 1254 1272">Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	MPT	MP tray	Cassette1	Cassette 1	Cassette2	Cassette 2 (optional paper feeder)	Cassette3	Cassette 3 (optional paper feeder)	Duplex	Duplex unit
Display	Description												
MPT	MP tray												
Cassette1	Cassette 1												
Cassette2	Cassette 2 (optional paper feeder)												
Cassette3	Cassette 3 (optional paper feeder)												
Duplex	Duplex unit												

Item No.	Description						
U903	<p data-bbox="290 241 798 275">Checking/clearing the paper jam counts</p> <p data-bbox="290 311 440 340">Description</p> <p data-bbox="290 344 890 374">Displays or clears the jam counts by jam locations.</p> <p data-bbox="290 380 400 409">Purpose</p> <p data-bbox="290 414 1390 443">To check the paper jam status. Also to clear the jam counts after replacing consumable parts.</p> <p data-bbox="290 486 387 515">Method</p> <ol data-bbox="308 519 564 582" style="list-style-type: none"> 1. Press the start key. 2. Select the item. <table border="1" data-bbox="336 595 1399 741"> <thead> <tr> <th data-bbox="336 595 641 645">Display</th> <th data-bbox="641 595 1399 645">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 645 641 694">Cnt</td> <td data-bbox="641 645 1399 694">Displays/clears the jam counts</td> </tr> <tr> <td data-bbox="336 694 641 741">Total Cnt</td> <td data-bbox="641 694 1399 741">Displays the total jam counts</td> </tr> </tbody> </table> <p data-bbox="290 786 466 815">Method: [Cnt]</p> <ol data-bbox="308 819 1002 1025" style="list-style-type: none"> 1. Select [Cnt]. The count of jam code by type is displayed. Codes for which the count value is 0 are not displayed. 2. Change the screen using the cursor up/down keys. 3. Select the count value for jam code and press [Clear]. The individual counter cannot be cleared. 4. Press the start key. The counter value is cleared. <p data-bbox="290 1064 536 1093">Method: [Total Cnt]</p> <ol data-bbox="308 1097 1149 1198" style="list-style-type: none"> 1. Select [Total Cnt]. The total number of jam code by type is displayed. 2. Change the screen using the cursor up/down keys. The total number of jam count cannot be cleared. <p data-bbox="290 1236 440 1265">Completion</p> <p data-bbox="290 1270 1254 1299">Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Cnt	Displays/clears the jam counts	Total Cnt	Displays the total jam counts
Display	Description						
Cnt	Displays/clears the jam counts						
Total Cnt	Displays the total jam counts						

Item No.	Description						
U904	<p data-bbox="290 241 858 273">Checking/clearing the call for service counts</p> <p data-bbox="290 311 440 338">Description</p> <p data-bbox="290 344 952 376">Displays or clears the service call code counts by types.</p> <p data-bbox="290 383 400 409">Purpose</p> <p data-bbox="290 416 839 448">To check the service call code status by types.</p> <p data-bbox="290 454 1174 486">Also to clear the service call code counts after replacing consumable parts.</p> <p data-bbox="290 524 384 551">Method</p> <ol data-bbox="308 557 564 618" style="list-style-type: none"> 1. Press the start key. 2. Select the item. <table border="1" data-bbox="336 633 1401 777"> <thead> <tr> <th data-bbox="336 633 641 678">Display</th> <th data-bbox="641 633 1401 678">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 678 641 723">Cnt</td> <td data-bbox="641 678 1401 723">Displays/clears the call for service counts</td> </tr> <tr> <td data-bbox="336 723 641 777">Total Cnt</td> <td data-bbox="641 723 1401 777">Displays the total call for service counts</td> </tr> </tbody> </table> <p data-bbox="290 824 464 855">Method: [Cnt]</p> <ol data-bbox="308 862 1150 1061" style="list-style-type: none"> 1. Select [Cnt]. The count for service call detection by type is displayed. Codes for which the count value is 0 are not displayed. 2. Change the screen using the cursor up/down keys. 3. Select the count value for service call code and press [Clear]. The individual counter cannot be cleared. 4. Press the start key. The counter value is cleared. <p data-bbox="290 1099 533 1131">Method: [Total Cnt]</p> <ol data-bbox="308 1137 1257 1234" style="list-style-type: none"> 1. Select [Total Cnt]. The total number of service call counts by type is displayed. 2. Change the screen using the cursor up/down keys. The total number of service call count cannot be cleared. <p data-bbox="290 1272 440 1303">Completion</p> <p data-bbox="290 1310 1254 1341">Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Cnt	Displays/clears the call for service counts	Total Cnt	Displays the total call for service counts
Display	Description						
Cnt	Displays/clears the call for service counts						
Total Cnt	Displays the total call for service counts						

Item No.	Description																		
U905	<p>Checking counts by optional devices</p> <p>Description Displays the counts of document processor or document finisher.</p> <p>Purpose To check the use of document processor or document finisher.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select the device to be checked. The count of the selected device is displayed. <table border="1" data-bbox="336 595 1401 741"> <thead> <tr> <th>Display</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>DP</td> <td>Counts of document processor</td> </tr> <tr> <td>DF</td> <td>Counts of document finisher</td> </tr> </tbody> </table> <p>DP</p> <table border="1" data-bbox="336 831 1401 976"> <thead> <tr> <th>Display</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>ADP</td> <td>Counts of single-sided originals that has passed through the DP</td> </tr> <tr> <td>RADP</td> <td>Counts of double-sided originals that has passed through the DP</td> </tr> </tbody> </table> <p>DF</p> <table border="1" data-bbox="336 1066 1401 1211"> <thead> <tr> <th>Display</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>Sorter</td> <td>Counts of copies that has passed through the sorter</td> </tr> <tr> <td>Staple</td> <td>Frequency the stapler has been activated</td> </tr> </tbody> </table> <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	DP	Counts of document processor	DF	Counts of document finisher	Display	Description	ADP	Counts of single-sided originals that has passed through the DP	RADP	Counts of double-sided originals that has passed through the DP	Display	Description	Sorter	Counts of copies that has passed through the sorter	Staple	Frequency the stapler has been activated
Display	Description																		
DP	Counts of document processor																		
DF	Counts of document finisher																		
Display	Description																		
ADP	Counts of single-sided originals that has passed through the DP																		
RADP	Counts of double-sided originals that has passed through the DP																		
Display	Description																		
Sorter	Counts of copies that has passed through the sorter																		
Staple	Frequency the stapler has been activated																		
U910	<p>Clearing the print coverage data</p> <p>Description Clears the accumulated data for the print coverage per A4 size paper and its period of time (as shown on the service status report).</p> <p>Purpose To clear data as required at times such as during maintenance service.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select [Execute]. 3. Press the start key. The print coverage data is cleared. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>																		

Item No.	Description																																				
U917	<p>Setting backup data reading/writing</p> <p>Description Retrieves the backup data to a USB memory from the machine; or writes the data from the USB memory to the machine.</p> <p>Purpose Machine information is backed up and restored.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the power key on the operation panel, and after verifying the power indicator has gone off, switch off the main power switch. 2. Insert USB memory in USB memory slot. 3. Turn the main power switch on. Wait for 10 seconds to allow the machine to recognize the USB memory. 4. Enter the maintenance item. 5. Press the start key. 6. Select [Export] or [Import] and press the start key. <table border="1" data-bbox="336 801 1401 949"> <thead> <tr> <th data-bbox="336 801 639 853">Display</th> <th data-bbox="639 801 1401 853">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 853 639 898">Import</td> <td data-bbox="639 853 1401 898">Writing data from the USB memory to the machine</td> </tr> <tr> <td data-bbox="336 898 639 949">Export</td> <td data-bbox="639 898 1401 949">Retrieving from the machine to a USB memory</td> </tr> </tbody> </table> <ol style="list-style-type: none"> 7. Select the item. <table border="1" data-bbox="336 1003 1401 1621"> <thead> <tr> <th data-bbox="336 1003 549 1055">Display</th> <th data-bbox="549 1003 927 1055">Description</th> <th data-bbox="927 1003 1401 1055">Depending data</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1055 549 1099">Address Book</td> <td data-bbox="549 1055 927 1099">Address book</td> <td data-bbox="927 1055 1401 1099">-</td> </tr> <tr> <td data-bbox="336 1099 549 1144">Job Account</td> <td data-bbox="549 1099 927 1144">Job accounting</td> <td data-bbox="927 1099 1401 1144">-</td> </tr> <tr> <td data-bbox="336 1144 549 1189">One Touch</td> <td data-bbox="549 1144 927 1189">Information on one-touch key</td> <td data-bbox="927 1144 1401 1189">Address book</td> </tr> <tr> <td data-bbox="336 1189 549 1234">User</td> <td data-bbox="549 1189 927 1234">User managements</td> <td data-bbox="927 1189 1401 1234">Job accounting</td> </tr> <tr> <td data-bbox="336 1234 549 1323">Program</td> <td data-bbox="549 1234 927 1323">Program information</td> <td data-bbox="927 1234 1401 1323">Job accountings and user managements</td> </tr> <tr> <td data-bbox="336 1323 549 1413">Shortcut</td> <td data-bbox="549 1323 927 1413">Shortcut information</td> <td data-bbox="927 1323 1401 1413">Job accountings, user managements and document box information</td> </tr> <tr> <td data-bbox="336 1413 549 1480">Document Box</td> <td data-bbox="549 1413 927 1480">Document box information</td> <td data-bbox="927 1413 1401 1480">Job accountings and user managements</td> </tr> <tr> <td data-bbox="336 1480 549 1547">Fax Forward</td> <td data-bbox="549 1480 927 1547">FAX transfer information</td> <td data-bbox="927 1480 1401 1547">Job accountings, user managements and document box information</td> </tr> <tr> <td data-bbox="336 1547 549 1621">IC Card</td> <td data-bbox="549 1547 927 1621">IC Card information</td> <td data-bbox="927 1547 1401 1621">-</td> </tr> </tbody> </table> <p>* : Since data are dependent with each other, data other than those assigned are also retrieved or written in.</p> <ol style="list-style-type: none"> 8. Select [On] using the cursor left/right keys. 9. Press the start key. Starts reading or writing. The progress of selected item is displayed in %. When an error occurs, the operation is canceled and an error code is displayed. 10. When normally completed, [Fin] is displayed. 11. Turn the main power switch off and on after completing writing when selecting [Import]. 	Display	Description	Import	Writing data from the USB memory to the machine	Export	Retrieving from the machine to a USB memory	Display	Description	Depending data	Address Book	Address book	-	Job Account	Job accounting	-	One Touch	Information on one-touch key	Address book	User	User managements	Job accounting	Program	Program information	Job accountings and user managements	Shortcut	Shortcut information	Job accountings, user managements and document box information	Document Box	Document box information	Job accountings and user managements	Fax Forward	FAX transfer information	Job accountings, user managements and document box information	IC Card	IC Card information	-
Display	Description																																				
Import	Writing data from the USB memory to the machine																																				
Export	Retrieving from the machine to a USB memory																																				
Display	Description	Depending data																																			
Address Book	Address book	-																																			
Job Account	Job accounting	-																																			
One Touch	Information on one-touch key	Address book																																			
User	User managements	Job accounting																																			
Program	Program information	Job accountings and user managements																																			
Shortcut	Shortcut information	Job accountings, user managements and document box information																																			
Document Box	Document box information	Job accountings and user managements																																			
Fax Forward	FAX transfer information	Job accountings, user managements and document box information																																			
IC Card	IC Card information	-																																			

Item No.	Description			
U917	Error Codes			
	Codes	Description	Codes	Description
	e002	Parameter error	e31e	User managements error
	e003	File write error	e31f	User managements open error
	e004	File initialization error	e320	User managements error
	e005	File error	e321	User managements open error
	e006	Processing error	e322	User managements list error
	e010	Address book clear error (contact)	e323	User managements list error
	e011	Address book open error (contact)	e324	Shortcut open error
	e012	Address book list error (contact)	e325	Shortcut list error
	e013	Address book list error (contact)	e326	Shortcut list error
	e014	Address book clear error (group)	e410	Box file open error
	e015	Address book open error (group)	e411	Box error in writing
	e016	Address book list error (group)	e412	Box error in reading
	e017	Address book list error (group)	e413	Box list error
	e110	Job accounting clear error	e414	Box list error
	e111	Job accounting open error	e415	Box error
	e112	Job accounting open error	e416	Box error
	e113	Job accounting error in writing	e417	Box open error
	e114	Job accounting list error	e418	Box close error
	e115	Job accounting list error	e419	Box creation error
	e210	One-touch open error	e41a	Box creation error
	e211	One-touch list error	e41b	Box deletion error
	e212	One-touch list error	e41c	Box movement error
	e310	User managements backup error	e510	Program error in writing
	e311	User managements clear error	e511	Program error in reading
	e312	User managements open error	e710	Fax memory open error
	e313	User managements open error	e711	Fax memory initialization error
	e314	User managements open error	e712	Fax memory list error
	e315	User managements error in writing	e713	Fax memory error
	e316	User managements list error	e714	Fax memory error
	e317	User managements list error	e715	Fax memory mode error
	e318	User managements list error	e716	Fax memory error
	e319	User managements list error	e717	Fax memory error
	e31a	User managements open error	e718	Fax memory mode error
	e31b	User managements error	e910	File reading error
	e31c	User managements error	e911	File writing error
	e31d	User managements open error	e912	Data mismatch

Item No.	Description																																																															
U917	Error Codes																																																															
	<table border="1"> <thead> <tr> <th data-bbox="295 288 414 333">Codes</th> <th data-bbox="414 288 901 333">Description</th> <th data-bbox="901 288 1021 333">Codes</th> <th data-bbox="1021 288 1423 333">Description</th> </tr> </thead> <tbody> <tr> <td>e913</td> <td>Log file open error</td> <td>d008</td> <td>File rename error</td> </tr> <tr> <td>e914</td> <td>Log file error in writing</td> <td>d009</td> <td>File open error</td> </tr> <tr> <td>e915</td> <td>Directory open error</td> <td>d00a</td> <td>File close error</td> </tr> <tr> <td>e916</td> <td>Directory error in reading</td> <td>d00b</td> <td>File reading error</td> </tr> <tr> <td>e917</td> <td>Synchronization error</td> <td>d00c</td> <td>File writing error</td> </tr> <tr> <td>e918</td> <td>Synchronization error</td> <td>d00d</td> <td>File copy error</td> </tr> <tr> <td>d000</td> <td>Unspecified error</td> <td>d00e</td> <td>File compressed error</td> </tr> <tr> <td>d001</td> <td>HDD unavailable</td> <td>d00f</td> <td>File decompressed error</td> </tr> <tr> <td>d002</td> <td>USB memory is not inserted</td> <td>d010</td> <td>Directory open error</td> </tr> <tr> <td>d003</td> <td>File for writing is not found in the USB</td> <td>d011</td> <td>Directory creation error</td> </tr> <tr> <td>d004</td> <td>File for reading is not found in the HDD</td> <td>d012</td> <td>File writing error</td> </tr> <tr> <td>d005</td> <td>USB error in writing</td> <td>d013</td> <td>File reading error</td> </tr> <tr> <td>d006</td> <td>USB error in reading</td> <td>d014</td> <td>File deletion error</td> </tr> <tr> <td>d007</td> <td>USB unmount error</td> <td>d015</td> <td>File copy error to the USB</td> </tr> </tbody> </table>				Codes	Description	Codes	Description	e913	Log file open error	d008	File rename error	e914	Log file error in writing	d009	File open error	e915	Directory open error	d00a	File close error	e916	Directory error in reading	d00b	File reading error	e917	Synchronization error	d00c	File writing error	e918	Synchronization error	d00d	File copy error	d000	Unspecified error	d00e	File compressed error	d001	HDD unavailable	d00f	File decompressed error	d002	USB memory is not inserted	d010	Directory open error	d003	File for writing is not found in the USB	d011	Directory creation error	d004	File for reading is not found in the HDD	d012	File writing error	d005	USB error in writing	d013	File reading error	d006	USB error in reading	d014	File deletion error	d007	USB unmount error	d015	File copy error to the USB
Codes	Description	Codes	Description																																																													
e913	Log file open error	d008	File rename error																																																													
e914	Log file error in writing	d009	File open error																																																													
e915	Directory open error	d00a	File close error																																																													
e916	Directory error in reading	d00b	File reading error																																																													
e917	Synchronization error	d00c	File writing error																																																													
e918	Synchronization error	d00d	File copy error																																																													
d000	Unspecified error	d00e	File compressed error																																																													
d001	HDD unavailable	d00f	File decompressed error																																																													
d002	USB memory is not inserted	d010	Directory open error																																																													
d003	File for writing is not found in the USB	d011	Directory creation error																																																													
d004	File for reading is not found in the HDD	d012	File writing error																																																													
d005	USB error in writing	d013	File reading error																																																													
d006	USB error in reading	d014	File deletion error																																																													
d007	USB unmount error	d015	File copy error to the USB																																																													
	<p data-bbox="295 1052 438 1086">Completion</p> <p data-bbox="295 1086 1252 1120">Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>																																																															
U927	<p data-bbox="295 1137 1157 1171">Clearing the all copy counts and machine life counts (one time only)</p> <p data-bbox="295 1205 438 1238">Description</p> <p data-bbox="295 1238 726 1272">Resets all of the counts back to zero.</p> <p data-bbox="295 1305 446 1339">Supplement</p> <p data-bbox="295 1339 1420 1417">The total account counter and the machine life counter can be cleared only once if all count values are 1000 or less.</p> <p data-bbox="295 1451 391 1485">Method</p> <ol data-bbox="311 1485 1189 1585" style="list-style-type: none"> 1. Press the start key. 2. Select [Execute]. 3. Press the start key. All copy counts and machine life counts are cleared. <p data-bbox="295 1619 438 1653">Completion</p> <p data-bbox="295 1653 1252 1686">Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>																																																															

Item No.	Description															
U942	<p data-bbox="288 241 807 275">Setting of deflection for feeding from DP</p> <p data-bbox="288 311 440 340">Description</p> <p data-bbox="288 344 1139 374">Adjusts the deflection generated when the document processor is used.</p> <p data-bbox="288 380 400 409">Purpose</p> <p data-bbox="288 414 1406 479">Use this mode if an original non-feed jam, oblique feed or wrinkling of original occurs when the document processor is used.</p> <p data-bbox="288 517 384 546">Setting</p> <ol data-bbox="304 553 1206 757" style="list-style-type: none"> 1. Press the start key. 2. Press the system menu key. 3. Place an original on the DP and press the start key to make a test copy. 4. Press the system menu key. 5. Select the item to be adjusted. 6. Change the setting value using the cursor left/right keys or numeric keys. <table border="1" data-bbox="336 768 1401 1016"> <thead> <tr> <th data-bbox="336 768 528 853">Display</th> <th data-bbox="528 768 922 853">Description</th> <th data-bbox="922 768 1082 853">Setting range</th> <th data-bbox="1082 768 1193 853">Initial setting</th> <th data-bbox="1193 768 1401 853">Change in value per step</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 853 528 938">Front</td> <td data-bbox="528 853 922 938">Deflection of DP paper feed motor (DPPFM)</td> <td data-bbox="922 853 1082 938">-50 to 50</td> <td data-bbox="1082 853 1193 938">0</td> <td data-bbox="1193 853 1401 938">0.119 mm</td> </tr> <tr> <td data-bbox="336 938 528 1016">Back</td> <td data-bbox="528 938 922 1016">Deflection of DP switchback motor (DPSBM)</td> <td data-bbox="922 938 1082 1016">-50 to 50</td> <td data-bbox="1082 938 1193 1016">0</td> <td data-bbox="1193 938 1401 1016">0.119 mm</td> </tr> </tbody> </table> <p data-bbox="336 1032 1377 1095">* : The greater the value, the larger the deflection; the smaller the value, the smaller the deflection.</p> <p data-bbox="371 1099 1414 1164">If an original non-feed jam or oblique feed occurs, increase the setting value. If wrinkling of original occurs, decrease the value.</p> <ol data-bbox="304 1169 767 1198" style="list-style-type: none"> 7. Press the start key. The value is set. <p data-bbox="288 1236 440 1265">Completion</p> <p data-bbox="288 1270 1254 1299">Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Setting range	Initial setting	Change in value per step	Front	Deflection of DP paper feed motor (DPPFM)	-50 to 50	0	0.119 mm	Back	Deflection of DP switchback motor (DPSBM)	-50 to 50	0	0.119 mm
Display	Description	Setting range	Initial setting	Change in value per step												
Front	Deflection of DP paper feed motor (DPPFM)	-50 to 50	0	0.119 mm												
Back	Deflection of DP switchback motor (DPSBM)	-50 to 50	0	0.119 mm												


Item No.	Description										
U977	<p>Data capture mode</p> <p>Description Store the print data sent to the machine into USB memory.</p> <p>Purpose In case to occur the error at printing, check the print data sent to the machine.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the power key on the operation panel, and after verifying the main power indicator has gone off, switch off the main power switch. 2. Insert USB memory in USB memory slot. 3. Turn the main power switch on. 4. Enter maintenance item U977. 5. Select [Execute]. 6. Press the start key. 7. Send the print data to the machine. Once the print data is stored into USB memory, [Finish] will be displayed. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>										
U984	<p>Checking the developing unit number</p> <p>Description Displays the developing unit number.</p> <p>Purpose To check the developing unit number.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. The developing unit number for each color is displayed. <table border="1" data-bbox="347 1272 1412 1480"> <thead> <tr> <th data-bbox="347 1272 683 1317">Display</th> <th data-bbox="683 1272 1412 1317">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="347 1317 683 1361">C</td> <td data-bbox="683 1317 1412 1361">Cyan developing unit number</td> </tr> <tr> <td data-bbox="347 1361 683 1406">M</td> <td data-bbox="683 1361 1412 1406">Magenta developing unit number</td> </tr> <tr> <td data-bbox="347 1406 683 1451">Y</td> <td data-bbox="683 1406 1412 1451">Yellow developing unit number</td> </tr> <tr> <td data-bbox="347 1451 683 1480">K</td> <td data-bbox="683 1451 1412 1480">Black developing unit number</td> </tr> </tbody> </table> <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	C	Cyan developing unit number	M	Magenta developing unit number	Y	Yellow developing unit number	K	Black developing unit number
Display	Description										
C	Cyan developing unit number										
M	Magenta developing unit number										
Y	Yellow developing unit number										
K	Black developing unit number										

Item No.	Description																
U985	<p data-bbox="288 241 707 275">Displaying the developer history</p> <p data-bbox="288 311 440 340">Description</p> <p data-bbox="288 344 1139 374">Displays the past record of machine number and the developer counter.</p> <p data-bbox="288 380 400 409">Purpose</p> <p data-bbox="288 414 1147 443">To check the count value of machine number and the developer counter.</p> <p data-bbox="288 486 387 515">Method</p> <ol data-bbox="304 519 643 582" style="list-style-type: none"> 1. Press the start key. 2. Select the color to check. <table border="1" data-bbox="347 593 1412 831"> <thead> <tr> <th data-bbox="352 600 651 638">Display</th> <th data-bbox="651 600 1407 638">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="352 645 651 683">C</td> <td data-bbox="651 645 1407 683">Cyan developing unit past record</td> </tr> <tr> <td data-bbox="352 689 651 728">M</td> <td data-bbox="651 689 1407 728">Magenta developing unit past record</td> </tr> <tr> <td data-bbox="352 734 651 772">Y</td> <td data-bbox="651 734 1407 772">Yellow developing unit past record</td> </tr> <tr> <td data-bbox="352 779 651 817">K</td> <td data-bbox="651 779 1407 817">Black developing unit past record</td> </tr> </tbody> </table> <ol data-bbox="304 857 1390 920" style="list-style-type: none"> 3. The history of a machine number and a developing counter for each color is displayed by three cases. <table border="1" data-bbox="336 934 1399 1079"> <thead> <tr> <th data-bbox="341 940 639 978">Display</th> <th data-bbox="639 940 1394 978">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="341 985 639 1023">Machine History 1 - 3</td> <td data-bbox="639 985 1394 1023">Historical records of the machine number</td> </tr> <tr> <td data-bbox="341 1030 639 1068">Cnt History 1 - 3</td> <td data-bbox="639 1030 1394 1068">Historical records of developer counter</td> </tr> </tbody> </table> <p data-bbox="288 1124 440 1153">Completion</p> <p data-bbox="288 1158 1254 1187">Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	C	Cyan developing unit past record	M	Magenta developing unit past record	Y	Yellow developing unit past record	K	Black developing unit past record	Display	Description	Machine History 1 - 3	Historical records of the machine number	Cnt History 1 - 3	Historical records of developer counter
Display	Description																
C	Cyan developing unit past record																
M	Magenta developing unit past record																
Y	Yellow developing unit past record																
K	Black developing unit past record																
Display	Description																
Machine History 1 - 3	Historical records of the machine number																
Cnt History 1 - 3	Historical records of developer counter																

1-3-2 Service mode

The machine is equipped with a maintenance function which can be used to maintain and service the machine.

(1) Printing the service status page



Service items	Description
Service Status	<p>Printing a status page for service purpose</p> <p>Description Prints a status page for service purpose. The status page includes various settings and service cumulative.</p> <p>Purpose To acquire the current printing environmental parameters and cumulative information.</p> <p>Method 1. Select [Service status]. 2. Select [YES]. Two pages will be printed.</p> <p>Completion Press the System Menu/Counter key.</p>



Service items	Description																																																														
	<p data-bbox="387 241 683 273">Service status page (1)</p> <div data-bbox="338 304 1396 1765" style="border: 1px solid black; padding: 10px;"> <h3 data-bbox="363 327 799 376">Service Status Page</h3> <p data-bbox="363 376 422 403">MFP</p> <p data-bbox="1150 371 1342 398">(2) 2011/09/28 15:15</p> <p data-bbox="352 427 845 454">(1) Firmware version 2MY_2F00.001.001 2011.09.28</p> <p data-bbox="979 405 1353 454">(3) [XXXXXXXX] (4) [XXXXXXXX] (5) [XXXXXXXX]</p> <hr/> <h4 data-bbox="368 504 654 530">Controller Information</h4> <p data-bbox="400 535 544 562">Memory status</p> <table data-bbox="363 562 746 645"> <tr> <td>(7) Standard Size</td> <td>128.0 KB</td> </tr> <tr> <td>(8) Option Slot</td> <td>128.0 KB</td> </tr> <tr> <td>(9) Total Size</td> <td>256.0 KB</td> </tr> </table> <p data-bbox="879 562 1046 589">(29) FRPO Status</p> <table data-bbox="927 589 1348 645"> <tr> <td>User Top Margin</td> <td>A1+A2/100</td> <td>0.00</td> </tr> <tr> <td>User Left Margin</td> <td>A3+A4/100</td> <td>0.00</td> </tr> </table> <p data-bbox="400 663 448 689">Time</p> <table data-bbox="352 689 820 768"> <tr> <td>(10) Local Time Zone</td> <td>+01:00 Tokio</td> </tr> <tr> <td>(11) Date and Time</td> <td>10/10/2010 12:00</td> </tr> <tr> <td>(12) Time Server</td> <td>10.183.53.13</td> </tr> </table> <p data-bbox="400 786 564 813">Installed Options</p> <table data-bbox="352 813 775 972"> <tr> <td>(13) Paper feeder</td> <td>Cassette</td> </tr> <tr> <td>(14) Finisher</td> <td>500-Finisher</td> </tr> <tr> <td>(15) Card Authentication Kit (B)</td> <td>Installed</td> </tr> <tr> <td>(16) USB Keyboard</td> <td>Connected</td> </tr> <tr> <td>(17) USB Keyboard Type</td> <td>US -English</td> </tr> <tr> <td>(18) UG-33</td> <td>Installed</td> </tr> </table> <p data-bbox="400 987 544 1014">Print Coverage</p> <p data-bbox="352 1014 906 1041">(19) Average(%) / Usage Page(A4/Letter Conversion)</p> <p data-bbox="352 1041 443 1068">(20) Total</p> <table data-bbox="411 1068 703 1171"> <tr> <td>K: 1.10</td> <td>/ 1111111.11</td> </tr> <tr> <td>C: 2.20</td> <td>/ 2222222.22</td> </tr> <tr> <td>M: 3.30</td> <td>/ 3333333.33</td> </tr> <tr> <td>Y: 4.40</td> <td>/ 4444444.44</td> </tr> </table> <p data-bbox="352 1171 459 1198">(21) Copy</p> <table data-bbox="411 1198 703 1301"> <tr> <td>K: 1.10</td> <td>/ 1111111.11</td> </tr> <tr> <td>C: 2.20</td> <td>/ 2222222.22</td> </tr> <tr> <td>M: 3.30</td> <td>/ 3333333.33</td> </tr> <tr> <td>Y: 4.40</td> <td>/ 4444444.44</td> </tr> </table> <p data-bbox="927 1256 1331 1283">PDF mode Y5 00</p> <p data-bbox="352 1301 469 1328">(22) Printer</p> <table data-bbox="411 1328 703 1435"> <tr> <td>K: 1.10</td> <td>/ 1111111.11</td> </tr> <tr> <td>C: 2.20</td> <td>/ 2222222.22</td> </tr> <tr> <td>M: 3.30</td> <td>/ 3333333.33</td> </tr> <tr> <td>Y: 4.40</td> <td>/ 4444444.44</td> </tr> </table> <p data-bbox="352 1435 448 1462">(23) FAX</p> <table data-bbox="411 1462 692 1489"> <tr> <td>K: 1.10</td> <td>/ 1111111.11</td> </tr> </table> <p data-bbox="352 1489 882 1516">(24) Period (27/10/2009 - 03/11/2009 08:40)</p> <p data-bbox="352 1516 842 1543">(25) Last Page K/C/M/Y(%) 1.00 / 2.22 / 3.33 / 4.44</p> <p data-bbox="400 1574 560 1601">FAX Information</p> <table data-bbox="352 1601 628 1682"> <tr> <td>(26) Rings (Normal)</td> <td>3</td> </tr> <tr> <td>(27) Rings (FAX/TEL)</td> <td>3</td> </tr> <tr> <td>(28) Rings (TAD)</td> <td>3</td> </tr> </table> <p data-bbox="858 1697 871 1724">1</p> <p data-bbox="1094 1697 1361 1724">(6) [XXXXXXXXXXXXXXXXXXXX]</p> </div>	(7) Standard Size	128.0 KB	(8) Option Slot	128.0 KB	(9) Total Size	256.0 KB	User Top Margin	A1+A2/100	0.00	User Left Margin	A3+A4/100	0.00	(10) Local Time Zone	+01:00 Tokio	(11) Date and Time	10/10/2010 12:00	(12) Time Server	10.183.53.13	(13) Paper feeder	Cassette	(14) Finisher	500-Finisher	(15) Card Authentication Kit (B)	Installed	(16) USB Keyboard	Connected	(17) USB Keyboard Type	US -English	(18) UG-33	Installed	K: 1.10	/ 1111111.11	C: 2.20	/ 2222222.22	M: 3.30	/ 3333333.33	Y: 4.40	/ 4444444.44	K: 1.10	/ 1111111.11	C: 2.20	/ 2222222.22	M: 3.30	/ 3333333.33	Y: 4.40	/ 4444444.44	K: 1.10	/ 1111111.11	C: 2.20	/ 2222222.22	M: 3.30	/ 3333333.33	Y: 4.40	/ 4444444.44	K: 1.10	/ 1111111.11	(26) Rings (Normal)	3	(27) Rings (FAX/TEL)	3	(28) Rings (TAD)	3
(7) Standard Size	128.0 KB																																																														
(8) Option Slot	128.0 KB																																																														
(9) Total Size	256.0 KB																																																														
User Top Margin	A1+A2/100	0.00																																																													
User Left Margin	A3+A4/100	0.00																																																													
(10) Local Time Zone	+01:00 Tokio																																																														
(11) Date and Time	10/10/2010 12:00																																																														
(12) Time Server	10.183.53.13																																																														
(13) Paper feeder	Cassette																																																														
(14) Finisher	500-Finisher																																																														
(15) Card Authentication Kit (B)	Installed																																																														
(16) USB Keyboard	Connected																																																														
(17) USB Keyboard Type	US -English																																																														
(18) UG-33	Installed																																																														
K: 1.10	/ 1111111.11																																																														
C: 2.20	/ 2222222.22																																																														
M: 3.30	/ 3333333.33																																																														
Y: 4.40	/ 4444444.44																																																														
K: 1.10	/ 1111111.11																																																														
C: 2.20	/ 2222222.22																																																														
M: 3.30	/ 3333333.33																																																														
Y: 4.40	/ 4444444.44																																																														
K: 1.10	/ 1111111.11																																																														
C: 2.20	/ 2222222.22																																																														
M: 3.30	/ 3333333.33																																																														
Y: 4.40	/ 4444444.44																																																														
K: 1.10	/ 1111111.11																																																														
(26) Rings (Normal)	3																																																														
(27) Rings (FAX/TEL)	3																																																														
(28) Rings (TAD)	3																																																														

Figure 1-3-21



Service items	Description	
	Detail of service status page	
No.	Description	Supplement
(1)	Firmware version	-
(2)	System date	-
(3)	Engine soft version	-
(4)	Engine boot version	-
(5)	Operation panel mask version	-
(6)	Machine serial number	-
(7)	Standard memory size	-
(8)	Optional memory size	-
(9)	Total memory size	-
(10)	Local time zone	-
(11)	Report output date	Day/Month/Year hour:minute
(12)	NTP server name	-
(13)	Presence or absence of the optional paper feeder	Paper feeder 1/Paper feeder 2/Not Installed
(14)	Presence or absence of the optional paper finisher	500-Finisher/Not Installed
(15)	Presence or absence of the optional IC card authentication kit	Installed/Not Installed/Trial
(16)	The connection state of an optional USB keyboard	Connected/Not Connected
(17)	Displays setting of optional USB Keyboard	US-English/US English with Euro/German/ French
(18)	Presence or absence of optional UG-33	Installed/Not Installed/Trial
(19)	Page of relation to the A4/Letter	-
(20)	Average coverage for total	Black/Cyan/Magenta/Yellow
(21)	Average coverage for copy	Black/Cyan/Magenta/Yellow
(22)	Average coverage for printer	Black/Cyan/Magenta/Yellow
(23)	Average coverage for fax	Black/Cyan/Magenta/Yellow
(24)	Cleared date and output date	-
(25)	Coverage on the final output page	-
(26)	Number of rings	0 to 15
(27)	Number of rings before automatic switching	0 to 15
(28)	Number of rings before connecting to answering machine	0 to 15

TON


www.tonerplus.com.ua

Service items	Description	
	No.	Description
		Supplement
	(29)	FRPO setting -
	(30)	NV RAM version _ 1F3 1225 _ 1F3 1225 (a) (b) (c) (d) (e) (f) (a) Consistency of the present software version and the database _ (underscore): OK * (Asterisk): NG (b) Database version (c) The oldest time stamp of database version (d) Consistency of the present software version and the ME firmware version _ (underscore): OK * (Asterisk): NG (e) ME firmware version (f) The oldest time stamp of the ME database version Normal if (a) and (d) are underscored, and (b) and (e) are identical with (c) and (f).
	(31)	Fax firmware version -
	(32)	Mac address -
	(33)	Number of original feed from DP -
	(34)	The last sent date and time -
	(35)	Transmission address -
	(36)	Destination information -
	(37)	Area information -
	(38)	Margin settings Top margin/Left margin
	(39)	Top offset for each paper source MP tray/Paper feeder 1/Paper feeder 2/Duplex/ Page rotation
	(40)	Left offset for each paper source MP tray/Paper feeder 1/Paper feeder 2/Duplex/ Page rotation
	(41)	Margin/Page length/Page width settings Top margin integer part/Top margin decimal part/ Left margin integer part/Left margin decimal part/ Page length integer part/Page length decimal part/ Page width integer part/Page width decimal part
	(42)	Life counter (The first line) Machine life/MP tray/Cassette/Paper feeder 1/ Paper feeder 2 /Duplex
		Life counter (The second line) Drum unit K/Drum unit C/Drum unit M/Drum unit Y/ Intermediate transfer unit/Developer unit K/ Developer unit C/Developer unit M/Developer unit Y/Maintenance kit
	(43)	Panel lock information 0: OFF/1: Partial lock/2: Full lock

Service items	Description																			
	No.	Description																		
		Supplement																		
(44)	USB information	U00: Not installed/U01: Full speed/U02: Hi speed																		
(45)	Paper handling information	0: Paper source unit select/1: Paper source unit																		
(46)	Color printing double count mode	0: All single counts 3: Folio, Single count, Less than 330 mm (length)																		
(47)	Black and white printing double count mode	0: All single counts 3: Folio, Single count, Less than 330 mm (length)																		
(48)	Billing counting timing	-																		
(49)	Temperature (machine inside)	-																		
(50)	Temperature (machine outside)	-																		
(51)	Relative temperature (machine outside)	-																		
(52)	Absolute temperature (machine outside)	-																		
(53)	Thermistor temperature (LSU)	-																		
(54)	Thermistor temperature (LSU2)	-																		
(55)	Fixed assets number	-																		
(56)	Job end judgment time-out time	-																		
(57)	Job end detection mode	-																		
(58)	Media type attributes 1 to 28 (Not used: 18, 19, 20)	<table border="0"> <tr> <td>Weight settings</td> <td>Fuser settings</td> </tr> <tr> <td>0: Light</td> <td>0: High</td> </tr> <tr> <td>1: Normal 1</td> <td>1: Middle</td> </tr> <tr> <td>2: Normal 2</td> <td>2: Low</td> </tr> <tr> <td>3: Normal 3</td> <td>3: Vellum</td> </tr> <tr> <td>4: Heavy 1</td> <td>Duplex settings</td> </tr> <tr> <td>5: Heavy 2</td> <td>0: Disable</td> </tr> <tr> <td>6: Heavy 3</td> <td>1: Enable</td> </tr> <tr> <td>7: Extra Heavy</td> <td></td> </tr> </table>	Weight settings	Fuser settings	0: Light	0: High	1: Normal 1	1: Middle	2: Normal 2	2: Low	3: Normal 3	3: Vellum	4: Heavy 1	Duplex settings	5: Heavy 2	0: Disable	6: Heavy 3	1: Enable	7: Extra Heavy	
Weight settings	Fuser settings																			
0: Light	0: High																			
1: Normal 1	1: Middle																			
2: Normal 2	2: Low																			
3: Normal 3	3: Vellum																			
4: Heavy 1	Duplex settings																			
5: Heavy 2	0: Disable																			
6: Heavy 3	1: Enable																			
7: Extra Heavy																				
(59)	Calibration information	-																		
(60)	Calibration information	76 Bytes																		
(61)	The initial characteristic of a sensor	37 Bytes																		
(62)	Calibration information	24 Bytes																		
(63)	Calibration information	64 Bytes																		
(64)	Calibration information	48 Bytes																		

Service items	Description																					
	<table border="1"> <thead> <tr> <th data-bbox="392 300 459 333">No.</th> <th data-bbox="464 300 786 333">Description</th> <th data-bbox="791 300 1415 333">Supplement</th> </tr> </thead> </table>	No.	Description	Supplement																		
No.	Description	Supplement																				
	(65) Calibration information	64 Bytes																				
	(66) Calibration information	64 Bytes																				
	(67) The amount of gaps of resist compensation	24 Bytes																				
	(68) The interval of resist compensation	56 Bytes																				
	(69) Patch length of resist compensation	64 Bytes																				
	(70) Calibration information	64 Bytes																				
	(71) Calibration information	64 Bytes																				
	(72) RFID information	-																				
	(73) RFID reader/writer version information	-																				
	(74) Toner install mode information	0: Off 1: On																				
	(75) Soft version of the optional paper feeder	Paper feeder 1/Paper feeder 2																				
	(76) Version of the optional message	-																				
	(77) Version of the color table	-																				
	(78) Version of second color table	-																				
	(79) Maintenance information	-																				
	(80) Altitude	0: Standard 1: High altitude 1 2: High altitude 2																				
	(81) Charger roller correction	1 to 5																				
	(82) Shift restrictions of an one-sheet original	0:Off 1:On																				
	(83) Drum serial number	Black/Cyan/Magenta/Yellow																				
	<p data-bbox="539 1599 740 1621">Code conversion</p> <table border="1" data-bbox="539 1644 1222 1738"> <thead> <tr> <th data-bbox="547 1655 603 1688">A</th> <th data-bbox="608 1655 663 1688">B</th> <th data-bbox="668 1655 724 1688">C</th> <th data-bbox="729 1655 785 1688">D</th> <th data-bbox="790 1655 845 1688">E</th> <th data-bbox="850 1655 906 1688">F</th> <th data-bbox="911 1655 967 1688">G</th> <th data-bbox="971 1655 1027 1688">H</th> <th data-bbox="1032 1655 1088 1688">I</th> <th data-bbox="1093 1655 1149 1688">J</th> </tr> </thead> <tbody> <tr> <td data-bbox="547 1695 603 1729">0</td> <td data-bbox="608 1695 663 1729">1</td> <td data-bbox="668 1695 724 1729">2</td> <td data-bbox="729 1695 785 1729">3</td> <td data-bbox="790 1695 845 1729">4</td> <td data-bbox="850 1695 906 1729">5</td> <td data-bbox="911 1695 967 1729">6</td> <td data-bbox="971 1695 1027 1729">7</td> <td data-bbox="1032 1695 1088 1729">8</td> <td data-bbox="1093 1695 1149 1729">9</td> </tr> </tbody> </table>		A	B	C	D	E	F	G	H	I	J	0	1	2	3	4	5	6	7	8	9
A	B	C	D	E	F	G	H	I	J													
0	1	2	3	4	5	6	7	8	9													

(2) Executing a service mode



(3) Description of service mode

Service items	Description
<p>Enable Repaired Unit</p>	<p>Release the disconnection of the cassette and the document feeder.</p> <p>Description Restore the system control when the defective unit is replaced to enable the unit. The menu is displayed only when the unit is detached for failure.</p> <p>Purpose Perform when the defective unit is replaced.</p> <p>Method 1. Enter the service menu. 2. Select [Enable Repaired Unit]. 3. Press [Start].</p> <p>Completion The unit is automatically powered after execution.</p>



Service items	Description
Maintenance (A)	<p>Reset the counter of the maintenance kit(A).</p> <p>Description Reset the kit counter when replacing the maintenance kit. The menu is displayed only when replacing the maintenance kit.</p> <p>Purpose Perform when the maintenance kit is replaced.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Enter the service menu. 2. Select [Maintenance (A)]. 3. Press [Start]. <p>Completion Automatically completes when the confirmation display is shown.</p>
Maintenance (B)	<p>Reset the counter of the maintenance kit(B).</p> <p>Description Reset the kit counter when replacing the maintenance kit. The menu is displayed only when replacing the maintenance kit.</p> <p>Purpose Perform when the maintenance kit is replaced.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Enter the service menu. 2. Select [Maintenance (B)]. 3. Press [Start]. <p>Completion Automatically completes when the confirmation display is shown.</p>

Service items	Description
Center line alignment	<p data-bbox="387 244 1034 277">Alignment of the cassette and MP tray and duplex</p> <p data-bbox="387 315 539 342">Description</p> <p data-bbox="387 349 946 376">Perform settings for the center line adjustment.</p> <p data-bbox="387 418 497 445">Purpose</p> <p data-bbox="387 452 1329 479">Perform if the alignment has not been obtained after the center line adjustment.</p> <p data-bbox="387 521 485 548">Method</p> <ol data-bbox="403 555 820 656" style="list-style-type: none"><li data-bbox="403 555 715 582">1. Enter the service menu.<li data-bbox="403 589 820 616">2. Select [Center Line Adjustment].<li data-bbox="403 622 595 649">3. Press [Save]. <p data-bbox="387 696 539 723">Completion</p> <p data-bbox="387 730 874 757">Press the Save key in the setting display.</p>

Service items	Description																																																																												
FAX country code	<p>FAX Country Code</p> <p>Description Initializes software switches and all data in the backup data on the FAX control PWB, according to the destination.</p> <p>Purpose To initialize the FAX control PWB.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Enter the Service Setting menu. 2. Select [FAX Country Code] using the cursor up/down keys. 3. Press the start key. 4. Enter a destination code using the numeric keys. 5. Press the start key. The setting is set. 6. Press the start key. Data initialization starts. <p>Destination code list</p> <table border="1" data-bbox="435 840 1385 1751"> <thead> <tr> <th>Code</th> <th>Destination</th> <th>Code</th> <th>Destination</th> </tr> </thead> <tbody> <tr> <td>000</td> <td>Japan</td> <td>253</td> <td>CTR21 (European nations)</td> </tr> <tr> <td>009</td> <td>Australia</td> <td></td> <td>Italy</td> </tr> <tr> <td>038</td> <td>China</td> <td></td> <td>Germany</td> </tr> <tr> <td>080</td> <td>Hong Kong</td> <td></td> <td>Spain</td> </tr> <tr> <td>084</td> <td>Indonesia</td> <td></td> <td>U.K.</td> </tr> <tr> <td>088</td> <td>Israel</td> <td></td> <td>Netherlands</td> </tr> <tr> <td>097</td> <td>Korea</td> <td></td> <td>Sweden</td> </tr> <tr> <td>108</td> <td>Malaysia</td> <td></td> <td>France</td> </tr> <tr> <td>126</td> <td>New Zealand</td> <td></td> <td>Austria</td> </tr> <tr> <td>136</td> <td>Peru</td> <td></td> <td>Switzerland</td> </tr> <tr> <td>137</td> <td>Philippines</td> <td></td> <td>Belgium</td> </tr> <tr> <td>152</td> <td>Middle East</td> <td></td> <td>Denmark</td> </tr> <tr> <td>156</td> <td>Singapore</td> <td></td> <td>Finland</td> </tr> <tr> <td>159</td> <td>South Africa</td> <td></td> <td>Portugal</td> </tr> <tr> <td>169</td> <td>Thailand</td> <td></td> <td>Ireland</td> </tr> <tr> <td>181</td> <td>U.S.A.</td> <td></td> <td>Norway</td> </tr> <tr> <td>242</td> <td>South America</td> <td>254</td> <td>Taiwan</td> </tr> <tr> <td>243</td> <td>Saudi Arabia</td> <td></td> <td></td> </tr> </tbody> </table> <p>Completion Press the stop key.</p>	Code	Destination	Code	Destination	000	Japan	253	CTR21 (European nations)	009	Australia		Italy	038	China		Germany	080	Hong Kong		Spain	084	Indonesia		U.K.	088	Israel		Netherlands	097	Korea		Sweden	108	Malaysia		France	126	New Zealand		Austria	136	Peru		Switzerland	137	Philippines		Belgium	152	Middle East		Denmark	156	Singapore		Finland	159	South Africa		Portugal	169	Thailand		Ireland	181	U.S.A.		Norway	242	South America	254	Taiwan	243	Saudi Arabia		
Code	Destination	Code	Destination																																																																										
000	Japan	253	CTR21 (European nations)																																																																										
009	Australia		Italy																																																																										
038	China		Germany																																																																										
080	Hong Kong		Spain																																																																										
084	Indonesia		U.K.																																																																										
088	Israel		Netherlands																																																																										
097	Korea		Sweden																																																																										
108	Malaysia		France																																																																										
126	New Zealand		Austria																																																																										
136	Peru		Switzerland																																																																										
137	Philippines		Belgium																																																																										
152	Middle East		Denmark																																																																										
156	Singapore		Finland																																																																										
159	South Africa		Portugal																																																																										
169	Thailand		Ireland																																																																										
181	U.S.A.		Norway																																																																										
242	South America	254	Taiwan																																																																										
243	Saudi Arabia																																																																												

Service items	Description								
FAX call Setting	<p>FAX call setting</p> <p>Description Selects if a fax is to be connected to either a PBX or public switched telephone network. Selects the mode to connect an outside call when connected to a PBX. Access code registration for connection to PSTN.</p> <p>Purpose To be executed as required.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Enter the Service Setting menu. 2. Select [FAX Call Set.] using the cursor up/down keys. 3. Press the start key. <table border="1" data-bbox="437 701 1385 893"> <thead> <tr> <th data-bbox="437 701 703 748">Display</th> <th data-bbox="703 701 1385 748">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="437 748 703 795">Exchange Select.</td> <td data-bbox="703 748 1385 795">Setting the connection to PBX/PSTN</td> </tr> <tr> <td data-bbox="437 795 703 842">PBX Setting</td> <td data-bbox="703 795 1385 842">Setting for a PBX</td> </tr> <tr> <td data-bbox="437 842 703 889">Dial No. to PSTN</td> <td data-bbox="703 842 1385 889">Setting access code to PSTN</td> </tr> </tbody> </table> <p>Setting the connection to PBX/PSTN</p> <ol style="list-style-type: none"> 1. Select [Exchange Select.] using the cursor up/down keys. 2. Press the start key. 3. Select [PBX] or [PSTN] using the cursor up/down keys. 4. Press the start key. The setting is set. <p>Setting for PBX</p> <ol style="list-style-type: none"> 1. Select [PBX Setting] using the cursor up/down keys. 2. Press the start key. 3. Select [Loop], [Flash] or [Earth] using the cursor up/down keys. 4. Press the start key. The setting is set. <p>Setting access code to PSTN</p> <ol style="list-style-type: none"> 1. Select [Dial No. to PSTN] using the cursor up/down keys. 2. Press the start key. 3. Enter access code using the numeric keys. (0 to 9, 00 to 99) 4. Press the start key. The setting is set. <p>Completion Press the stop key.</p>	Display	Description	Exchange Select.	Setting the connection to PBX/PSTN	PBX Setting	Setting for a PBX	Dial No. to PSTN	Setting access code to PSTN
Display	Description								
Exchange Select.	Setting the connection to PBX/PSTN								
PBX Setting	Setting for a PBX								
Dial No. to PSTN	Setting access code to PSTN								

Service items	Description
Altitude adjustment	<p>Setting altitude adjustment</p> <p>Description Sets the altitude adjustment mode.</p> <p>Purpose Used when print quality deteriorates in an installation at the altitude of 1,500 meters or higher.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Enter the Service Setting menu. 2. Select [Altitude Adj.]. 3. Press the start key. 4. Select [Normal], [High 1], [High 2] or [High 3]). 5. Press the start key. The setting is set. <p>Completion Press the stop key.</p>
Main charger adjustment	<p>Setting main charger output</p> <p>Description Sets the main charger output. This is executable only when the altitude adjustment mode is set to [Normal].</p> <p>Purpose Execute when the image density declines or an offset has occurred.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Enter the Service Setting menu. 2. Select [MC]. 3. Press the start key. 4. Select [1], [2] , [3] , [4] or [5]. 5. Press the start key. The setting is set. <p>Completion Press the stop key.</p>



Service items	Description
Developer cleaning	<p>Setting developer cleaning</p> <p>Description Execute toner discharging and replenishing repeatedly to cast the deteriorated toner out of the developer unit.</p> <p>Purpose The deterioration of image due to the low development density and blurring will be reduced.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Enter the Service Setting menu. 2. Select [DEV-CLN]. 3. Press [Start]. <p>Completion Press the [OK] key in the confirmation display.</p>
Main chager roller cleaning	<p>Setting main chager roller cleaning</p> <p>Description White streaks are resulted by the conductive substance, soaked in the charging roller, being adhered at a nip formed between the charging roller and the drum when they have been left inactive for a prolonged period. White streaks are prevented by rotating the drum before the image is formed, because the conductive substance is scraped off with the cleaning blade.</p> <p>OFF: Aging to cancel bleeding is not performed. ON: Aging to cancel bleeding is performed.</p> <p>Purpose Conduct when white streaks are resulted in the lengthwise direction of the drum.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Enter the Service Setting menu. 2. Select [MC-CLN]. 3. Select [OFF] or [ON].



Service items	Description
Memory Diagnostics	<p>Perform a memory diagnostic</p> <p>Description Diagnose memory at power up (whether reading and writing are executable).</p> <p>Purpose Execute memory check in purpose of rectifying a defective memory device which may possibly cause an unresolvable F call, locking, or abnormal images.</p> <p>Method</p> <ol style="list-style-type: none">1. Enter the Service Setting menu.2. Select [Memory Diagnostics].3. Press [Start].4. Turn the main power switch off and on. Allow more than 5 seconds between Off and On.

1-4-1 Paper misfeed detection

(1) Paper misfeed indication

When a paper misfeed occurs, the machine immediately stops copying and displays the jam location on the operation panel.

Paper misfeed counts sorted by component can be checked by maintenance item U903.

To remove the paper jammed in the machine, open the right cover and pull the cassette out.

To remove the original jammed in DP or the document finisher, open the top cover.

Paper misfeed can be reset by opening and closing the respective covers.




Figure 1-4-1

- (A) Misfeed in the MP tray
- (B) Misfeed in right cover 1
- (C) Misfeed in cassette 1
- (D) Misfeed in right cover 3
- (E) Misfeed in cassette 2
- (F) Misfeed in cassette 3
- (G) Misfeed in the document finisher
- (H) Stapler problem
- (I) Misfeed in the bridge
- (J) Misfeed in the document processor

(2) Paper misfeed detection component




Figure 1-4-2

Code	Contents	Conditions	Jam location*
0000	Initial jam	The power is turned on when a sensor in the conveying system is on.	-
0100	Secondary paper feed request time out	Secondary paper feed request given by the controller is unreachable.	B
0101	Waiting for process package to be ready	Process package won't be ready.	B
0104	Waiting for conveying package to be ready	Conveying package won't be ready.	B
0106	Paper feeding request for duplex printing time out	Paper feeding request for duplex printing given by the controller is unreachable.	B
0107	Waiting for fuser package to be ready	Fuser package won't be ready.	-
0110	Right cover open	The right cover is opened during printing.	-
0111	Front cover open	The front cover is opened during printing.	-
0120	Receiving a duplex paper feeding request while paper is empty	Paper feed request was received from the duplex section despite the absence of paper in the duplex section.	B
0121	Exceeding number of duplex pages circulated	The controller issued the duplex section a request for more pages than the duplex print cycle contains.	B
0210	Right lower cover open	The right lower cover is opened during printing.	-
0501	No paper feed from cassette 1	The registration sensor (RS) does not turn on during paper feed from cassette 1.	C
0502	No paper feed from cassette 2	PF feed sensor 1 (PFFS1) does not turn on during paper feed from cassette 2 (Retry 1 times).	E
0503	No paper feed from cassette 3	PF feed sensor 2 (PFFS2) does not turn on during paper feed from cassette 3 (Retry 1 times).	F
0508	No paper feed from duplex section	The registration sensor (RS) does not turn on during paper feed from the duplex section.	B
0509	No paper feed from MP tray	The registration sensor (RS) does not turn on during paper feed from the MP tray.	A
0511	Multiple sheets in cassette 1	The registration sensor (RS) does not turn off during paper feed from cassette 1.	C
0512	Multiple sheets in cassette 2	PF feed sensor 1 (PFFS1) does not turn off during paper feed from cassette 2.	E
0513	Multiple sheets in cassette 3	PF feed sensor 2 (PFFS2) does not turn off during paper feed from cassette 3.	F
0518	Multiple sheets in duplex section	The registration sensor (RS) does not turn off during paper feed from the duplex section.	B
0519	Multiple sheets in MP tray	The registration sensor (RS) does not turn off during paper feed from the MP tray.	A

*: Refer to figure 1-4-1 for paper jam location (see page 1-4-1).

Code	Contents	Conditions	Jam location*
1403	PF feed sensor 1 non arrival jam	PF feed sensor 1 (PFFS1) does not turn on during paper feed from cassette 3.	D
1413	PF feed sensor 1 stay jam	PF feed sensor 1 (PFFS1) does not turn off during paper feed from cassette 3.	D
4002	Registration sensor non arrival jam	The registration sensor (RS) does not turn on during paper feed from cassette 2.	D
4003		The registration sensor (RS) does not turn on during paper feed from cassette 3.	D
4012	Registration sensor stay jam	The registration sensor (RS) does not turn off during paper feed from cassette 2.	D
4013		The registration sensor (RS) does not turn off during paper feed from cassette 3.	D
4101	Fuser pre sensor non arrival jam	The fuser pre sensor (FUPS) does not turn on during paper feed from cassette 1.	B
4102		The fuser pre sensor (FUPS) does not turn on during paper feed from cassette 2.	B
4103		The fuser pre sensor (FUPS) does not turn on during paper feed from cassette 3.	B
4108		The fuser pre sensor (FUPS) does not turn on during paper feed from duplex section.	B
4109		The fuser pre sensor (FUPS) does not turn on during paper feed from MP tray.	B
4111		Fuser pre sensor stay jam	The fuser pre sensor (FUPS) does not turn off during paper feed from cassette 1.
4112	The fuser pre sensor (FUPS) does not turn off during paper feed from cassette 2.		B
4113	The fuser pre sensor (FUPS) does not turn off during paper feed from cassette 3.		B
4118	The fuser pre sensor (FUPS) does not turn off during paper feed from the duplex section.		B
4119	The fuser pre sensor (FUPS) does not turn off during paper feed from the MP tray.		B

*: Refer to figure 1-4-1 for paper jam location (see page 1-4-1).

Code	Contents	Conditions	Jam location*
4201	Eject sensor non arrival jam	The eject sensor (ES) does not turn on during paper feed from cassette 1.	B
4202		The eject sensor (ES) does not turn on during paper feed from cassette 2.	B
4203		The eject sensor (ES) does not turn on during paper feed from cassette 3.	B
4208		The eject sensor (ES) does not turn on during paper feed from duplex section.	B
4209		The eject sensor (ES) does not turn on during paper feed from MP tray.	B
4211	Eject sensor stay jam	The eject sensor (ES) does not turn off during paper feed from cassette 1.	B
4212		The eject sensor (ES) does not turn off during paper feed from cassette 2.	B
4213		The eject sensor (ES) does not turn off during paper feed from cassette 3.	B
4218		The eject sensor (ES) does not turn off during paper feed from the duplex section.	B
4219		The eject sensor (ES) does not turn off during paper feed from the MP tray.	B
4301	Duplex sensor non arrival jam	The duplex sensor (DUS) does not turn on during paper feed from cassette 1.	B
4302		The duplex sensor (DUS) does not turn on during paper feed from cassette 2.	B
4303		The duplex sensor (DUS) does not turn on during paper feed from cassette 3.	B
4309		The duplex sensor (DUS) does not turn on during paper feed from the MP tray.	B
4311	Duplex sensor stay jam	The duplex sensor (DUS) does not turn off during paper feed from cassette 1.	B
4312		The duplex sensor (DUS) does not turn off during paper feed from cassette 2.	B
4313		The duplex sensor (DUS) does not turn off during paper feed from cassette 3.	B
4319		The duplex sensor (DUS) does not turn off during paper feed from the MP tray.	B

Code	Contents	Conditions	Jam location*
4901	Bridge conveying sensor 1 non arrival jam	The bridge conveying sensor 1 (BRCS1) does not turn on during paper feed from cassette 1.	B
4902		The bridge conveying sensor 1 (BRCS1) does not turn on during paper feed from cassette 2.	B
4903		The bridge conveying sensor 1 (BRCS1) does not turn on during paper feed from cassette 3.	B
4908		The bridge conveying sensor 1 (BRCS1) does not turn on during paper feed from duplex section.	B
4909		The bridge conveying sensor 1 (BRCS1) does not turn on during paper feed from the MP tray.	B
4911	Bridge conveying sensor 1 stay jam	The bridge conveying sensor 1 (BRCS1) does not turn off during paper feed from cassette 1.	I
4912		The bridge conveying sensor 1 (BRCS1) does not turn off during paper feed from cassette 2.	I
4913		The bridge conveying sensor 1 (BRCS1) does not turn off during paper feed from cassette 3.	I
4918		The bridge conveying sensor 1 (BRCS1) does not turn off during paper feed from duplex section.	I
4919		The bridge conveying sensor 1 (BRCS1) does not turn off during paper feed from the MP tray.	I
5001	Bridge conveying sensor 3 non arrival jam	The bridge conveying sensor 3 (BRCS3) does not turn on during paper feed from cassette 1.	I
5002		The bridge conveying sensor 3 (BRCS3) does not turn on during paper feed from cassette 2.	I
5003		The bridge conveying sensor 3 (BRCS3) does not turn on during paper feed from cassette 3.	I
5008		The bridge conveying sensor 3 (BRCS3) does not turn on during paper feed from the duplex section.	I
5009		The bridge conveying sensor 3 (BRCS3) does not turn on during paper feed from the MP tray.	I
5011	Bridge conveying sensor 3 stay jam	The bridge conveying sensor 3 (BRCS3) does not turn off during paper feed from cassette 1.	I
5012		The bridge conveying sensor 3 (BRCS3) does not turn off during paper feed from cassette 2.	I
5013		The bridge conveying sensor 3 (BRCS3) does not turn off during paper feed from cassette 3.	I
5018		The bridge conveying sensor 3 (BRCS3) does not turn off during paper feed from duplex section.	I
5019		The bridge conveying sensor 3 (BRCS3) does not turn off during paper feed from the MP tray.	I

*: Refer to figure 1-4-1 for paper jam location (see page 1-4-1).

Code	Contents	Conditions	Jam location*
6023	Staple cover open	The staple cover is opened during operation.	G
6043	DF top cover open	The DF top cover is opened during operation.	G
6103	DF paper conveying sensor non arrival jam	The paper conveying sensor (PCS) does not turned on even if a specified time has elapsed after the machine eject signal was received.	I
6113	DF paper conveying sensor stay jam	The paper conveying sensor (PCS) does not turn off within the specified time of its turning on.	G
6123	DF paper conveying sensor remaining jam	The paper conveying sensor (PCS) does not turned on when the power is turned on or the cover is closed.	G
6413	DF eject paper sensor stay jam	The eject paper sensor (EPS) does not turn off within the specified time.	G
6423	DF eject paper sensor remaining jam	The eject paper sensor (EPS) does not turned on when the power is turned on or the cover is closed.	G
6803	Front adjustment plate operation ON error	The adjustment sensor 1 (ADS1) does turned on when the job is executed.	H
6813	Front adjustment plate operation OFF error	The adjustment sensor 1 (ADS1) does not turned off when the job is executed.	H
6903	Rear adjustment plate operation ON error	The adjustment sensor 2 (ADS2) does not turned on when the job is executed.	H
6913	Rear adjustment plate operation OFF error	The adjustment sensor 2 (ADS2) does not turned off when the job is executed.	H
7013	Staple operation error	The next staple hasn't head-poked for the next copy to bind after a predetermined interval while clinching has commenced.	H
7023	Staple initial operation error	Head-poking has not been accomplished after 10 attempts in the initialization at power up or closing the cover.	H
7913	Sequence error 1 (operation prohibited)	Operation commenced in the state the finisher is prohibited to operate.	G
7923	Sequence error 2 (initialoperation error)	A request for maintenance mode has occurred in the state the finisher is prohibited to operate or has commenced operation.	G
7933	Sequence error 3 (Error in the reception of backup data)	A backup data command has been received in the state the operation has initiated.	G
7943	Sequence error 4 (standby)	Operation has started in the state standby is prohibited.	G
7953	Sequence error 5 (Error in between copies)	An illegal inter-page or inter-copy interval has occurred.	G

*: Refer to figure 1-4-1 for paper jam location (see page 1-4-1).

Code	Contents	Conditions	Jam location*
7963	Sequence error 6	The finisher does not deliver the eject-complete command in 15 seconds after the bridge eject sensor is turned off.	G
9001	DP original conveying jam	DP timing sensor (DPTS) turns off within the specified time since the sensor turns on.	J
9004	DP original switchback jam	During duplex switchback scanning, the DP registration sensor (DPRS) does not turn on within specified time of the DP timing sensor (DPTS) turning off.	J
9010	DP open	The DP is opened during original feeding. Sensor in the conveying system is on when the power is turned on or the cover is closed.	-
9011	DP top cover open	The DP top cover is opened during original feeding.	-
9110	DP paper feed sensor stay jam	The DP paper feed sensor (DPPFS) or DP registration sensor (DPRS) does not turn off within the specified time of the DP timing sensor (DPTS) turning on.	J
9200	DP registration sensor non arrival jam	The DP registration sensor (DPRS) does not turn on within the specified time of the DP paper feed sensor (DPPFS) turning on.	J
9400	DP timing sensor non arrival jam	The DP timing sensor (DPTS) does not turn on within the specified time of the DP registration sensor (DPRS) turning on (Retry 5 times).	J
9410	DP timing sensor stay jam	The DP timing sensor (DPTS) does not turned off within the specified time its turning on.	J

*: Refer to figure 1-4-1 for paper jam location (see page 1-4-1).

1-4-2 Self-diagnostic function

(1) Self-diagnostic function

This machine is equipped with self-diagnostic function. When a problem is detected, the machine stops printing and display an error message on the operation panel. An error message consists of a message prompting a contact with service personnel and a four-digit error code indicating the type of the error.

(2) Self-diagnostic codes

If the part causing the problems not designated as a service part, replace the assembly comprising the part.

Code	Contents	Causes	Check procedures/ corrective measures
0030	FAX control PWB system error Processing with the fax software was disabled due to a hardware problem.	Defective FAX control PWB.	Replace the fax control PWB and check for correct operation.
0070	FAX control PWB incompatible detection error In the initial communication with the FAX control PWB, the normal communication command is not transmitted.	Defective FAX software.	Install the fax software.
		Defective FAX control PWB.	Replace the fax control PWB and check for correct operation.
0100	Backup memory device error	Defective flash memory.	Replace the main PWB and check for correct operation (see page 1-5-31).
		Defective main PWB.	
0120	MAC address data error The data includes an invalid MAC address.	Defective flash memory.	Replace the main PWB and check for correct operation (see page 1-5-31).
		Defective engine PWB.	Replace the engine PWB and check for correct operation (see page 1-5-32).
0130	Backup memory read/write error (main PWB)	Defective flash memory.	Replace the main PWB and check for correct operation (see page 1-5-31).
		Defective main PWB.	
0140	Backup memory data error (main PWB)	Defective flash memory.	Replace the main PWB and check for correct operation (see page 1-5-31).
		Defective main PWB.	

Code	Contents	Causes	Check procedures/ corrective measures
0150	Backup memory read/write error (engine PWB) Detecting engine PWB EEPROM communication error.	The engine PWB EEPROM was improperly installed.	Check the EEPROM is properly installed and remedy if necessary.
		Defective engine PWB.	Replace the engine PWB and check for correct operation (see page 1-5-32).
		Defective EEPROM.	Contact the Service Administrative Division.
0160	Backup memory data error (engine PWB)	Defective flash memory.	Replace the engine PWB and check for correct operation (see page 1-5-32).
		Defective engine PWB.	
0170	Billing counting error A checksum error is detected in the main and engine backup memories for the billing counters.	Data in the EEPROM .	Contact the Service Administrative Division.
		Defective PWB.	Replace the main PWB or the engine PWB and check for correct operation (see page 1-5-31, 1-5-32).
0180	Machine number mismatch Machine number of main and engine does not match.	Data in the EEPROM .	Contact the Service Administrative Division.
0320	I/O CPU communication error A communication error is detected 10 times in succession.	Defective PWB.	Replace the main PWB or the engine PWB and check for correct operation. (see page 1-5-31, 1-5-32)
0630	DMA error DMA transmission of image data does not complete within the specified period of time.	Poor contact in the connector terminals.	Check the connection the signal cable for CIS and the main PWB, and the continuity across the connector terminals. Repair or replace if necessary.
		Defective main PWB.	Replace the main PWB and check for correct operation (see page 1-5-31).
0800	Image processing error The JAM100 fee counter is continuously generated.	Defective main PWB.	Replace the main PWB and check for correct operation (see page 1-5-31).
0830	FAX control PWB flash program area checksum error A checksum error occurred with the program of the FAX control PWB.	Defective FAX software.	Install the fax software.
		Defective FAX control PWB.	Replace the FAX control PWB.

Code	Contents	Causes	Check procedures/ corrective measures
0840	Faults of RTC The time is judged to go back based on the comparison of the RTC time and the current time or five years or more have passed.	The battery is disconnected from the main PWB.	Check visually and remedy if necessary
		Defective main PWB.	Replace the main PWB and check for correct operation (see page 1-5-31).
0870	FAX control PWB to main PWB high capacity data transfer error High-capacity data transfer between the FAX control PWB and the main PWB of the machine was not normally performed even if the data transfer was retried the specified times.	Improper installation FAX control PWB.	Reinstall the FAX control PWB.
		Defective FAX control PWB or main PWB.	Replace the FAX control PWB or main PWB and check for correct operation (see page 1-5-31).
0920	Fax file system error The backup data is not retained for file system abnormality of flash memory of the FAX control PWB.	Defective FAX control PWB.	Replace the FAX control PWB and check for correct operation.
1010	Lift motor error After cassette 1 is inserted, the lift sensor does not turn on within 12 s. This error is detected four times successively.	Defective bottom plate elevation mechanism in the cassette.	Check to see if the bottom plate can move smoothly and repair any problem that is found.
		Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity of the connector cable. If necessary, replace the cable. Lift motor and engine PWB (YC1)
		Defective drive transmission system of the lift motor.	Check if the gears rotate smoothly. If not, grease the bushes and gears. Check for broken gears and replace if necessary.
		Defective lift motor.	Replace the lift motor.
		Defective engine PWB.	Replace the engine PWB and check for correct operation (see page 1-5-32).

Code	Contents	Causes	Check procedures/ corrective measures
1020	PF lift motor 1 error (paper feeder) After cassette 2 is inserted, PF lift sensor 1 does not turn on within 12 s. This error is detected four times successively.	Defective bottom plate elevation mechanism in the cassette.	Check to see if the bottom plate can move smoothly and repair any problem that is found.
		Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity of the connector cable. If necessary, replace the cable. PF lift motor 1 and PF main PWB (YC4)
		Defective drive transmission system of the PF lift motor 1.	Check if the gears rotate smoothly. If not, grease the bushes and gears. Check for broken gears and replace if necessary.
		Defective PF lift motor 1.	Replace the PF lift motor 1.
		Defective PF main PWB.	Replace the PF main PWB (Refer to the service manual of the paper feeder).
1030	PF lift motor 2 error (paper feeder) After cassette 3 is inserted, PF lift sensor 2 does not turn on within 12 s. This error is detected four times successively.	Defective bottom plate elevation mechanism in the cassette.	Check to see if the bottom plate can move smoothly and repair it if any problem is found.
		Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity of the connector cable. If necessary, replace the cable. PF lift motor 2 and PF main PWB (YC7)
		Defective drive transmission system of the PF lift motor 2.	Check if the gears rotate smoothly. If not, grease the bushes and gears. Check for broken gears and replace if any.
		Defective PF lift motor 2.	Replace the PF lift motor 2.
		Defective PF main PWB.	Replace the PF main PWB (Refer to the service manual of the paper feeder).

Code	Contents	Causes	Check procedures/ corrective measures
1800	Paper feeder communication error A communication error is detected 10 times in succession.	Improper installation of the paper feeder.	Follow the installation instruction carefully again.
		Defective connector cable or poor contact of the connector.	Reinsert the connector. Also check for continuity of the connector cable. If necessary, replace the cable. PF main PWB (YC3) and engine PWB (YC20)
		Defective engine PWB.	Replace the engine PWB and check for correct operation (see page 1-5-32).
		Defective PF main PWB.	Replace the PF main PWB (Refer to the service manual of the paper feeder).
1900	Paper feeder EEPROM error When writing the data, the write data and the read data is not continuously in agreement 4 times.	Defective PF main PWB.	Replace the PF main PWB (Refer to the service manual of the paper feeder).
		Device damage of EEPROM.	Contact the Service Administrative Division.
1950	Transfer belt unit EEPROM error No response is issued from the device in reading/writing for 5 ms or more and this problem is repeated five times successively. Mismatch of reading data from two locations occurs eight times successively. Mismatch between writing data and reading data occurs eight times successively.	Defective transfer PWB.	Replace the transfer PWB and check for correct operation.
		Device damage of EEPROM.	Contact the Service Administrative Division.
2101	Developer motor K steady-state error The rated speed signal detected the stability OFF continuously for 1 s after the developer motor K stabilizes.	Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity of the connector cable. If necessary, replace the cable. Developer motor K and engine PWB (YC4)
		Defective drive transmission system.	Check if the rollers and gears rotate smoothly. If not, grease the bushings and gears. Check for broken gears and replace if necessary.
		Defective motor.	Replace the Developer motor K.
		Defective PWB.	Replace the engine PWB and check for correct operation (see page 1-5-32).

Code	Contents	Causes	Check procedures/ corrective measures
2102	Developer motor YCM steady-state error The rated speed signal detected the stability OFF continuously for 1 s after the developer motor YCM stabilizes.	Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. Developer motor YCM and engine PWB (YC3)
		Defective drive transmission system.	Check if the rollers and gears rotate smoothly. If not, grease the bushings and gears. Check for broken gears and replace if any.
		Defective motor.	Replace the Developer motor YCM.
		Defective PWB.	Replace the engine PWB and check for correct operation (see page 1-5-32).
2111	Developer motor K startup error Developer motor K is not stabilized within 2 s since the motor is activated.	Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity of the connector cable. If necessary, replace the cable. Developer motor K and engine PWB (YC4)
		Defective drive transmission system.	Check if the rollers and gears rotate smoothly. If not, grease the bushings and gears. Check for broken gears and replace if necessary.
		Defective motor.	Replace the Developer motor K.
		Defective PWB.	Replace the engine PWB and check for correct operation (see page 1-5-32).
2112	Developer motor YCM startup error Developer motor YCM is not stabilized within 2 s since the motor is activated.	Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If necessary, replace the cable. Developer motor YCM and engine PWB (YC4)
		Defective drive transmission system.	Check if the rollers and gears rotate smoothly. If not, grease the bushings and gears. Check for broken gears and replace if necessary.
		Defective motor.	Replace the Developer motor YCM.
		Defective PWB.	Replace the engine PWB and check for correct operation (see page 1-5-32).

Code	Contents	Causes	Check procedures/ corrective measures
2201	Drum motor K steady-state error The rated speed signal detected the stability OFF continuously for 1 s after the drum motor K stabilizes.	Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. Drum motor K and engine PWB (YC3)
		Defective drive transmission system.	Check if the rollers and gears rotate smoothly. If not, grease the bushings and gears. Check for broken gears and replace if any.
		Defective motor.	Replace the Drum motor K.
		Defective PWB.	Replace the engine PWB and check for correct operation (see page 1-5-32).
2202	Drum motor YCM steady-state error The rated speed signal detected the stability OFF continuously for 1 s after the drum motor YCM stabilizes.	Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. Drum motor YCM and engine PWB (YC3)
		Defective drive transmission system.	Check if the rollers and gears rotate smoothly. If not, grease the bushings and gears. Check for broken gears and replace if any.
		Defective motor.	Replace the Drum motor YCM.
		Defective PWB.	Replace the engine PWB and check for correct operation (see page 1-5-32).
2211	Drum motor K startup error Drum motor K is not stabilized within 2 s since the motor is activated.	Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. Drum motor K and engine PWB (YC3)
		Defective drive transmission system.	Check if the rollers and gears rotate smoothly. If not, grease the bushings and gears. Check for broken gears and replace if any.
		Defective motor.	Replace the Drum motor K.
		Defective PWB.	Replace the engine PWB and check for correct operation (see page 1-5-32).
2212	Drum motor YCM startup error Drum motor YCM is not stabilized within 2 s since the motor is activated.	Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. Drum motor YCM and engine PWB (YC3)
		Defective drive transmission system.	Check if the rollers and gears rotate smoothly. If not, grease the bushings and gears. Check for broken gears and replace if any.
		Defective motor.	Replace the Drum motor YCM.
		Defective PWB.	Replace the engine PWB and check for correct operation (see page 1-5-32).

Code	Contents	Causes	Check procedures/ corrective measures
2300	Fuser motor steady-state error The rated speed signal detected the stability OFF continuously for 1 s after the fuser motor stabilizes.	Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. Fuser motor and engine PWB (YC4)
		Defective drive transmission system.	Check if the rollers and gears rotate smoothly. If not, grease the bushings and gears. Check for broken gears and replace if any.
		Defective motor.	Replace the Fuser motor.
		Defective PWB.	Replace the engine PWB and check for correct operation (see page 1-5-32).
2310	Fuser motor startup error Fuser motor is not stabilized within 2 s since the motor is activated.	Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. Fuser motor and engine PWB (YC3)
		Defective drive transmission system.	Check if the rollers and gears rotate smoothly. If not, grease the bushings and gears. Check for broken gears and replace if any.
		Defective motor.	Replace the fuser motor.
		Defective PWB.	Replace the engine PWB and check for correct operation (see page 1-5-32).
2550	Conveying motor steady-state error The rated speed signal detected the stability OFF continuously for 1 s after the conveying motor stabilizes.	Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. Conveying motor and engine PWB (YC2)
		Defective drive transmission system.	Check if the rollers and gears rotate smoothly. If not, grease the bushings and gears. Check for broken gears and replace if any.
		Defective motor.	Replace the Conveying motor.
		Defective PWB.	Replace the engine PWB and check for correct operation (see page 1-5-32).
2560	Conveying motor startup error Conveying motor is not stabilized within 2 s since the motor is activated.	Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. Conveying motor and engine PWB (YC2)
		Defective drive transmission system.	Check if the rollers and gears rotate smoothly. If not, grease the bushings and gears. Check for broken gears and replace if any.
		Defective motor.	Replace the conveying motor.
		Defective PWB.	Replace the engine PWB and check for correct operation (see page 1-5-32).

Code	Contents	Causes	Check procedures/ corrective measures
2600	PF drive motor error (paper feeder) When the PF drive motor is driven, error signal is detected continuously for 1 s.	Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. PF drive motor and PF main PWB (YC2)
		Defective drive transmission system.	Check if the rollers and gears rotate smoothly. If not, grease the bushes and gears. Check for broken gears and replace if any.
		Defective motor.	Replace the PF drive motor.
		Defective PWB.	Replace the PF main PWB (Refer to the service manual for the paper feeder).
2700	TC belt motor error When the TC belt motor is driven, error signal is detected continuously for 1 s.	Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. TC belt motor and TC PWB(YC2) TC PWB and TC connect PWB(YC1) TC connect PWB and engine PWB(YC5)
		Defective drive transmission system.	Check if the rollers and gears rotate smoothly. If not, grease the bushings and gears. Check for broken gears and replace if any.
		Defective motor.	Replace the TC belt motor.
		Defective PWB.	Replace the engine PWB or TC PWB or TC connect PWB check for correct operation (see page 1-5-32).
3100	ISU home position error ON/OFF of the HP sensor doesn't change by retrying, after a prescribed pulse passes from power supply ON.	Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. Home position sensor and engine PWB (YC13)
		Defective home position sensor.	Replace the home position sensor.
		Defective ISU motor.	Replace the ISU motor.
		Defective CCD PWB.	Replace the image scanner unit (see page 1-5-21).
		Defective engine PWB.	Replace the engine PWB and check for correct operation (see page 1-5-32).

Code	Contents	Causes	Check procedures/ corrective measures
3200	Exposure lamp error The peak count during CCD turned on does not count up for 300 seconds . When the white standard data at the time of an initial is lower than a rated value.	Defective connector cable or poor contact of the connector.	Reinsert the connector. Also check for continuity within the connector cable. If necessary, replace the cable. LED PWB and main PWB (YC112) CCD PWB and main PWB (YC113)
		Defective exposure lamp.	Replace the image scanner unit (see page 1-5-21).
		Defective CCD PWB.	
		Defective main PWB.	Replace the main PWB and check for correct operation (see page 1-5-31).
3500	Communication error A wrong read-back value.	Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. CCD PWB and main PWB (YC113)
		Defective CCD PWB.	Replace the image scanner unit (see page 1-5-21).
		Defective main PWB.	Replace the main PWB and check for correct operation (see page 1-5-31).
3600	Scanner sequence error	Defective main PWB or engine PWB.	Replace the main PWB or the engine PWB and check for correct operation (see page 1-5-31 or 1-5-32).
4001	Polygon motor (K) steady-state error The rated speed signal detected the stability OFF continuously for 1 s after the polygon motor (K) stabilizes.	Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. Laser scanner unit (K) and LSU connect PWB(YC5) LSU connect PWB and engine PWB (YC12)
		Defective motor.	Replace the Laser scanner unit (K).
		Defective PWB.	Replace the engine PWB or LSU connect PWB and check for correct operation (see page 1-5-32).
4002	Polygon motor (C) steady-state error The rated speed signal detected the stability OFF continuously for 1 s after the polygon motor (C) stabilizes.	Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. Laser scanner unit (C) and LSU connect PWB(YC6) LSU connect PWB and engine PWB (YC12)
		Defective motor.	Replace the Laser scanner unit (C).
		Defective PWB.	Replace the engine PWB or LSU connect PWB and check for correct operation (see page 1-5-32).

Code	Contents	Causes	Check procedures/ corrective measures
4003	Polygon motor (M) steady-state error The rated speed signal detected the stability OFF continuously for 1 s after the polygon motor (M) stabilizes.	Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. Laser scanner unit (M) and LSU connect PWB(YC7) LSU connect PWB and engine PWB (YC12)
		Defective motor.	Replace the Laser scanner unit (M).
		Defective PWB.	Replace the engine PWB or LSU connect PWB and check for correct operation (see page 1-5-32).
4004	Polygon motor (Y) steady-state error The rated speed signal detected the stability OFF continuously for 1 s after the polygon motor (Y) stabilizes.	Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. Laser scanner unit (Y) and LSU connect PWB(YC8) LSU connect PWB and engine PWB (YC12)
		Defective motor.	Replace the Laser scanner unit (Y).
		Defective PWB.	Replace the engine PWB or LSU connect PWB and check for correct operation (see page 1-5-32).
4011	Polygon motor (K) startup error Polygon motor (K) is not stabilized within 10 s since the motor is activated.	Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. Laser scanner unit (K) and LSU connect PWB(YC5) LSU connect PWB and engine PWB (YC12)
		Defective motor.	Replace the Laser scanner unit (K).
		Defective PWB.	Replace the engine PWB or LSU connect PWB and check for correct operation (see page 1-5-32).
4012	Polygon motor (C) startup error Polygon motor (C) is not stabilized within 10 s since the motor is activated.	Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. Laser scanner unit (C) and LSU connect PWB(YC6) LSU connect PWB and engine PWB (YC12)
		Defective motor.	Replace the Laser scanner unit (C).
		Defective PWB.	Replace the engine PWB or LSU connect PWB and check for correct operation (see page 1-5-32).

Code	Contents	Causes	Check procedures/ corrective measures
4013	Polygon motor (M) startup error Polygon motor (M) is not stabilized within 10 s since the motor is activated.	Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. Laser scanner unit (M) and LSU connect PWB(YC7) LSU connect PWB and engine PWB (YC12)
		Defective motor.	Replace the Laser scanner unit (M).
		Defective PWB.	Replace the engine PWB or LSU connect PWB and check for correct operation (see page 1-5-32).
4014	Polygon motor (Y) startup error Polygon motor (Y) is not stabilized within 10 s since the motor is activated.	Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. Laser scanner unit (Y) and LSU connect PWB(YC8) LSU connect PWB and engine PWB (YC12)
		Defective motor.	Replace the Laser scanner unit (Y).
		Defective PWB.	Replace the engine PWB or LSU connect PWB and check for correct operation (see page 1-5-32).
4101	BD initialization problem (K) BD is not detected within one second after the polygon motor stabilizes.	Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. BDPWB and APCPWB APCPWB and LSU connect PWB (YC1) LSU connect PWB and engine PWB (YC12)
		Defective APCPWB.	Replace the Laser scanner unit (K). (see page 1-5-20)
		Defective BDPWB.	
		Defective Main PWB.	Replace the main PWB and check for correct operation (see page 1-5-31).
4102	BD initialization problem (C) BD is not detected within one second after the polygon motor stabilizes.	Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. BDPWB and APCPWB APCPWB and LSU connect PWB (YC2) LSU connect PWB and engine PWB (YC12)
		Defective APCPWB.	Replace the Laser scanner unit (C). (see page 1-5-20)
		Defective BDPWB.	
		Defective Main PWB.	Replace the main PWB and check for correct operation (see page 1-5-31).

Code	Contents	Causes	Check procedures/ corrective measures
4103	BD initialization problem (M) BD is not detected within one second after the polygon motor stabilizes.	Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. BDPWB and APCPWB APCPWB and LSU connect PWB (YC3) LSU connect PWB and engine PWB (YC12)
		Defective APCPWB.	Replace the Laser scanner unit (M). (see page 1-5-20)
		Defective BDPWB.	
		Defective Main PWB.	Replace the main PWB and check for correct operation (see page 1-5-31).
4104	BD initialization problem (Y) BD is not detected within one second after the polygon motor stabilizes.	Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. BDPWB and APCPWB APCPWB and LSU connect PWB (YC4) LSU connect PWB and engine PWB (YC12)
		Defective APCPWB.	Replace the Laser scanner unit (M). (see page 1-5-20)
		Defective BDPWB.	
		Defective Main PWB.	Replace the main PWB and check for correct operation (see page 1-5-31).
4600	LSU cleaning motor error When the LSU cleaning motor is driven, an error signal is detected continuously for 1 s.	Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity of the connector cable. If none, replace the cable. LSU cleaning motor and LSU connect PWB(YC11) LSU connect PWB and engine PWB(YC12)
		Defective drive transmission system.	Check if the rollers and gears rotate smoothly. If not, grease the bushings and gears. Check for broken gears and replace if any.
		Defective motor. Defective PWB.	Replace the LSU cleaning motor. Replace the engine PWB or LSU connect PWB check for correct operation (see page 1-5-32).

Code	Contents	Causes	Check procedures/ corrective measures
4700	VIDEO ASIC device error Mismatch of reading data from two locations occurs eight times successively. Mismatch between writing data and reading data occurs eight times successively.	Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. Main PWB (YC105) and engine PWB (YC17)
		Defective main PWB or engine PWB.	Replace the main PWB or the engine PWB and check for correct operation (see page 1-5-31, 1-5-32).
4950	LSU CPU communication error A communication error is detected 10 times in succession.	Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. Main PWB and engine PWB (YC26)
		Defective PWB.	Replace the main PWB or engine PWB and check for correct operation (see page 1-5-31, 1-5-32).
6000	Broken fuser heater wire Fuser thermistor 2 does not reach 80° C/176 °F even after 20 s during warming up. The detected temperature of fuser thermistor 2 does not reach the specified temperature (ready indication temperature) for 200 s in warming up after reached to 80° C/176 °F.	Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. IH coil unit and IHPWB IHPWB and engine PWB (YC7)
		Deformed connector pin.	If the I/F connector pins of the fuser unit and the main unit are deformed owing to foreign matters, such as paper dusts, replace the connectors or the units including the connectors.
		Defective IH PWB.	Replace the IH PWB and check for correct operation (see page 1-5-36).
		Fuser thermostat triggered.	Reinsert the fuser unit (see page 1-5-18).
		Broken fuser heater wire.	
Defective engine PWB.	Replace the engine PWB and check for correct operation (see page 1-5-32).		
6020	Abnormally high fuser thermistor 2 (center) temperature The fuser thermistor 2 detects a temperature higher than 240°C/464°F continuously for 1 s.	Deformed connector pin.	If the I/F connector pins of the fuser unit and the main unit are deformed owing to foreign matters, such as paper dusts, replace the connectors or the units including the connectors.
		Shorted fuser thermistor.	Replace the fuser unit (see page 1-5-18).
		Defective engine PWB.	Replace the engine PWB and check for correct operation (see page 1-5-32).

Code	Contents	Causes	Check procedures/ corrective measures
6030	Fuser thermistor 2 (center) break error A/D value of the fuser thermistor 2 exceeds 1010 bit continuously for 1 s during warming up.	Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. Fuser thermistor2 and fuser PWB (YC2) Fuser unit and engine PWB (YC22)
		Deformed connector pin.	If the I/F connector pins of the fuser unit and the main unit are deformed owing to foreign matters, such as paper dusts, replace the connectors or the units including the connectors.
		Defective fuser thermistor.	Replace the fuser unit (see page 1-5-18).
		Defective engine PWB.	Replace the engine PWB and check for correct operation (see page 1-5-32).
6040	NC sensor error When a sensor detected the temperature higher than 150 °C/302 °F continuously for 5 seconds.	Deformed connector pin.	If the I/F connector pins of the fuser unit and the main unit are deformed owing to foreign matters, such as paper dusts, replace the connectors or the units including the connectors.
		Shorted fuser thermistor.	Replace the fuser unit (see page 1-5-18).
		Defective engine PWB.	Replace the engine PWB and check for correct operation (see page 1-5-32).
6050	Abnormally low fuser thermistor 2 (center) temperature The fuser temperature lower than 100 °C/212 °F is detected continuously for 1 s during printing.	Deformed connector pin.	If the I/F connector pins of the fuser unit and the main unit are deformed owing to foreign matters, such as paper dusts, replace the connectors or the units including the connectors.
		Defective fuser thermistor.	Replace the fuser unit (see page 1-5-18).
		Defective fuser heater.	
		Defective engine PWB.	Replace the engine PWB and check for correct operation (see page 1-5-32).

Code	Contents	Causes	Check procedures/ corrective measures
6120	Abnormally high fuser thermistor 3 (press roller) temperature The fuser temperature exceeds 200 °C/392 °F for 1 s.	Deformed connector pin.	If the I/F connector pins of the fuser unit and the main unit are deformed owing to foreign matters, such as paper dusts, replace the connectors or the units including the connectors.
		Defective IH PWB.	Replace the IH PWB and check for correct operation (see page 1-5-36).
		Defective fuser thermistor.	Replace the fuser unit (see page 1-5-18).
		Defective engine PWB.	Replace the engine PWB and check for correct operation (see page 1-5-32).
6130	Fuser thermistor 3 (press roller) break error Fuser thermistor 3 does not reach 30° C/86 °F even after 60 s during warming up. The detected temperature of fuser thermistor 3 does not reach the specified temperature (ready indication temperature) for 200 s in warming up after reached to 30° C/86 °F.	Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. Fuser thermistor 3 and fuser PWB (YC4) Fuser unit and engine PWB (YC22)
		Deformed connector pin.	If the I/F connector pins of the fuser unit and the main unit are deformed owing to foreign matters, such as paper dusts, replace the connectors or the units including the connectors.
		Defective IH PWB.	Replace the IH PWB and check for correct operation (see page 1-5-36).
		Defective fuser thermistor.	Replace the fuser unit (see page 1-5-18).
6150	Abnormally low fuser thermistor 3 (press roller) temperature The fuser temperature lower than 30 °C/86 °F is detected continuously for 1 s.	Deformed connector pin.	If the I/F connector pins of the fuser unit and the main unit are deformed owing to foreign matters, such as paper dusts, replace the connectors or the units including the connectors.
		Defective fuser thermistor.	Replace the fuser unit (see page 1-5-18).
		Defective fuser heater.	
		Defective engine PWB.	Replace the engine PWB and check for correct operation (see page 1-5-32).

Code	Contents	Causes	Check procedures/ corrective measures
6200	Broken fuser edge heater wire Fuser thermistor 1 does not reach 50° C/122 °F even after 20 s during warming up. The detected temperature of fuser thermistor 1 does not reach the specified temperature (ready indication temperature) for 60 s in warming up after reaching 50° C/122 °F.	Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. IH coil unit and IHPWB IHPWB and engine PWB (YC7)
		Deformed connector pin.	If the I/F connector pins of the fuser unit and the main unit are deformed owing to foreign matters, such as paper dusts, replace the connectors or the units including the connectors.
		Fuser thermostat triggered.	Reinsert the fuser unit (see page 1-5-18).
		Broken fuser heater wire.	
		Defective engine PWB.	Replace the engine PWB and check for correct operation (see page 1-5-32).
6220	Abnormally high fuser thermistor 1 (edge) temperature The fuser temperature exceeds 240 °C/464 °F for 1 s.	Deformed connector pin.	If the I/F connector pins of the fuser unit and the main unit are deformed owing to foreign matters, such as paper dusts, replace the connectors or the units including the connectors.
		Defective cooling fan motor.	Replace the fuser fan motor.
		Defective fuser thermistor.	Replace the fuser unit (see page 1-5-18).
		Defective engine PWB.	Replace the engine PWB and check for correct operation (see page 1-5-32).
6230	Fuser thermistor 1 (edge) break error During warming up a heater, fuser thermistor 2 detects a temperature of 100 °C/212 °F or higher and, fuser thermistor 1 detects a temperature of 37 °C/99 °F or lower.	Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. Fuser thermistor 1 and fuser PWB (YC3) Fuser unit and engine PWB (YC22)
		Deformed connector pin.	If the I/F connector pins of the fuser unit and the main unit are deformed owing to foreign matters, such as paper dusts, replace the connectors or the units including the connectors.
		Defective fuser thermistor.	Replace the fuser unit (see page 1-5-18).
		Defective engine PWB.	Replace the engine PWB and check for correct operation (see page 1-5-32).

Code	Contents	Causes	Check procedures/ corrective measures
6250	Abnormally low fuser thermistor 1 (edge) temperature The fuser temperature lower than 80 °C/176 °F is detected continuously for 1 s during printing.	Deformed connector pin.	If the I/F connector pins of the fuser unit and the main unit are deformed owing to foreign matters, such as paper dusts, replace the connectors or the units including the connectors.
		Defective IH PWB.	Replace the IH PWB and check for correct operation (see page 1-5-36).
		Defective fuser thermistor.	Replace the fuser unit (see page 1-5-18).
		Defective fuser heater.	
		Defective engine PWB.	Replace the engine PWB and check for correct operation (see page 1-5-32).
6410	Fuser unit type mismatch problem Absence of the fuser unit is detected.	Fuser unit connector inserted incorrectly.	Reinsert the fuser unit connector if necessary.
		Different type of the fuser unit is installed.	Install the correct fuser unit.
6600	Belt rotation error The belt was detected to stop for 2 s continuously during motor remote is on.	Defective fuser motor.	Replace the fuser motor.
		Defective IH belt.	Replace the fuser unit (see page 1-5-18).
		Defective IH PWB.	Replace the IH PWB and check for correct operation (see page 1-5-36).
		Defective engine PWB.	Replace the engine PWB and check for correct operation (see page 1-5-32).
6710	CPU thermal runaway (IHPWB)	Defective IH PWB.	Replace the IH PWB and check for correct operation (see page 1-5-36).
6720	Belt rotation error (IHPWB)	Defective IH PWB.	Replace the IH PWB and check for correct operation (see page 1-5-36).
		Defective fuser motor.	Replace the fuser motor.
		Defective fuser unit.	Replace the fuser unit.
6730	Abnormally high IGBT1 temperature (IHPWB)	Defective IH PWB.	Replace the IH PWB and check for correct operation (see page 1-5-36).
		Defective cooling fan motor.	Replace the IH fan motor.

Code	Contents	Causes	Check procedures/ corrective measures
6740	Abnormally high IGBT2 temperature (IHPWB)	Defective IH PWB.	Replace the IH PWB and check for correct operation (see page 1-5-36).
		Defective cooling fan motor.	Replace the IH fan motor.
6750	Abnormally output overcurrent (IHPWB)	Defective IH PWB.	Replace the IH PWB and check for correct operation (see page 1-5-36).
		Defective fuser unit.	Replace the fuser unit.
6760	Abnormally AC input overcurrent (IHPWB)	Defective IH PWB.	Replace the IH PWB and check for correct operation (see page 1-5-36).
6770	Abnormally low electric power (IHPWB)	Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable.
		Defective IH PWB.	Replace the IH PWB and check for correct operation (see page 1-5-36).
6930	IH coil fan motor error The alarm signal was detected for 5 seconds continuously during operation.	Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. IH coil fan motor and engine PWB(YC21)
		Defective cooling fan motor.	Replace the IH coil fan motor.
		Defective IH PWB.	Replace the IH PWB and check for correct operation (see page 1-5-36).
6950	IH CPU communication error A communication error is detected 3 times in succession.	Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable.
		Defective IH PWB.	Replace the IH PWB and check for correct operation (see page 1-5-36).
		Defective engine PWB.	Replace the engine PWB and check for correct operation (see page 1-5-32).
6990	Fuser unit type mismatch problem Absence of the fuser unit is detected.	Defective IH PWB.	Replace the IH PWB and check for correct operation (see page 1-5-36).

Code	Contents	Causes	Check procedures/ corrective measures
7101	Toner sensor K error	Defective Developer unit.	Replace the developer unit K (see page 1-5-14).
		Defective PWB.	Replace the engine PWB check for correct operation (see page 1-5-32).
7102	Toner sensor C error	Defective Developer unit.	Replace the developer unit C (see page 1-5-14).
		Defective PWB.	Replace the engine PWB check for correct operation (see page 1-5-32).
7103	Toner sensor M error	Defective Developer unit.	Replace the developer unit M (see page 1-5-14).
		Defective PWB.	Replace the engine PWB check for correct operation (see page 1-5-32).
7104	Toner sensor Y error	Defective Developer unit.	Replace the developer unit Y (see page 1-5-14).
		Defective PWB.	Replace the engine PWB check for correct operation (see page 1-5-32).
7601	ID sensor 1 (front) error	Defective ID sensor.	Replace the ID sensor 1.
		Defective PWB.	Replace the engine PWB check for correct operation (see page 1-5-32).
7602	ID sensor 2 (rear) error	Defective ID sensor.	Replace the ID sensor 2.
		Defective PWB.	Replace the engine PWB check for correct operation (see page 1-5-32).
7611	ID sensor (K) density error When ID sensor 2 detected CTD is 500 or less.	Defective ID sensor.	Replace the ID sensor.
		Defective PWB.	Replace the engine PWB check for correct operation (see page 1-5-32).
7612	ID sensor (C) density error When ID sensor 2 detected CTD is 500 or less.	Defective ID sensor.	Replace the ID sensor.
		Defective PWB.	Replace the engine PWB check for correct operation (see page 1-5-32).
7613	ID sensor (M) density error When ID sensor 2 detected CTD is 500 or less.	Defective ID sensor.	Replace the ID sensor.
		Defective PWB.	Replace the engine PWB check for correct operation (see page 1-5-32).

Code	Contents	Causes	Check procedures/ corrective measures
7614	ID sensor (Y) density error When ID sensor 2 detected CTD is 500 or less.	Defective ID sensor.	Replace the ID sensor.
		Defective PWB.	Replace the engine PWB check for correct operation (see page 1-5-32).
7620	ID sensor timing error Color registration correction was failed.	Defective ID sensor.	Replace the ID sensor.
		Defective PWB.	Replace the engine PWB check for correct operation (see page 1-5-32).
7800	Broken external thermistor wire The external thermistor delivers 0.3V or more.	Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. Temperature sensor and engine PWB (YC21)
		Defective temperature sensor.	Replace the temperature sensor.
7810	Short-circuited external thermistor wire external thermistor delivers 3V or more.	Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. Temperature sensor and engine PWB (YC21)
		Defective temperature sensor.	Replace the temperature sensor.
7901	Drum K EEPROM error No response is issued from the device in reading/writing for 5 ms or more and this problem is repeated five times successively. Mismatch of reading data from two locations occurs eight times successively. Mismatch between writing data and reading data occurs eight times successively.	Poor contact in the connector terminals.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. Drum unit (K) and drum connect PWB(YC5) drum connect PWB and engine connect PWB (YC4) Engine connect PWB and engine PWB (YC9)
		Defective drum PWB.	Replace the drum unit K (see 1-5-16).

Code	Contents	Causes	Check procedures/ corrective measures
7902	<p>Drum C EEPROM error No response is issued from the device in reading/writing for 5 ms or more and this problem is repeated five times successively. Mismatch of reading data from two locations occurs eight times successively. Mismatch between writing data and reading data occurs eight times successively.</p>	Poor contact in the connector terminals.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. Drum unit (C) and drum connect PWB(YC3) drum connect PWB and engine connect PWB (YC4) Engine connect PWB and engine PWB (YC9)
		Defective drum PWB.	Replace the drum unit C (see 1-5-16).
7903	<p>Drum M EEPROM error No response is issued from the device in reading/writing for 5 ms or more and this problem is repeated five times successively. Mismatch of reading data from two locations occurs eight times successively. Mismatch between writing data and reading data occurs eight times successively.</p>	Poor contact in the connector terminals.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. Drum unit (M) and drum connect PWB(YC4) drum connect PWB and engine connect PWB (YC4) Engine connect PWB and engine PWB (YC9)
		Defective drum PWB.	Replace the drum unit M (see 1-5-16).
7904	<p>Drum Y EEPROM error No response is issued from the device in reading/writing for 5 ms or more and this problem is repeated five times successively. Mismatch of reading data from two locations occurs eight times successively. Mismatch between writing data and reading data occurs eight times successively.</p>	Poor contact in the connector terminals.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. Drum unit (Y) and drum connect PWB(YC2) drum connect PWB and engine connect PWB (YC4) Engine connect PWB and engine PWB (YC9)
		Defective drum PWB.	Replace the drum unit Y (see 1-5-16).
7911	<p>Developing unit K EEPROM error No response is issued from the device in reading/writing for 5 ms or more and this problem is repeated five times successively. Mismatch of reading data from two locations occurs eight times successively. Mismatch between writing data and reading data occurs eight times successively.</p>	Poor contact in the connector terminals.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. Developer unit (K) and drum connect PWB(YC9) drum connect PWB and engine connect PWB (YC4) Engine connect PWB and engine PWB (YC12)
		Defective developing PWB.	Replace the developer unit K (see 1-5-14).

Code	Contents	Causes	Check procedures/ corrective measures
7912	<p>Developing unit C EEPROM error</p> <p>No response is issued from the device in reading/writing for 5 ms or more and this problem is repeated five times successively.</p> <p>Mismatch of reading data from two locations occurs eight times successively.</p> <p>Mismatch between writing data and reading data occurs eight times successively.</p>	<p>Poor contact in the connector terminals.</p>	<p>Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable.</p> <p>Developer unit (C) and drum connect PWB(YC7)</p> <p>drum connect PWB and engine connect PWB (YC4)</p> <p>Engine connect PWB and engine PWB (YC12)</p>
		<p>Defective developing PWB.</p>	<p>Replace the developer unit C (see 1-5-14).</p>
7913	<p>Developing unit M EEPROM error</p> <p>No response is issued from the device in reading/writing for 5 ms or more and this problem is repeated five times successively.</p> <p>Mismatch of reading data from two locations occurs eight times successively.</p> <p>Mismatch between writing data and reading data occurs eight times successively.</p>	<p>Poor contact in the connector terminals.</p>	<p>Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable.</p> <p>Developer unit (M) and drum connect PWB(YC8)</p> <p>drum connect PWB and engine connect PWB (YC4)</p> <p>Engine connect PWB and engine PWB (YC12)</p>
		<p>Defective developing PWB.</p>	<p>Replace the developer unit M (see 1-5-14).</p>
7914	<p>Developing unit Y EEPROM error</p> <p>No response is issued from the device in reading/writing for 5 ms or more and this problem is repeated five times successively.</p> <p>Mismatch of reading data from two locations occurs eight times successively.</p> <p>Mismatch between writing data and reading data occurs eight times successively.</p>	<p>Poor contact in the connector terminals.</p>	<p>Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable.</p> <p>Developer unit (Y) and drum connect PWB(YC6)</p> <p>drum connect PWB and engine connect PWB (YC4)</p> <p>Engine connect PWB and engine PWB (YC12)</p>
		<p>Defective developing PWB.</p>	<p>Replace the developer unit Y (see 1-5-14).</p>

Code	Contents	Causes	Check procedures/ corrective measures
8030	Tray upper limit detection problem (document finisher) When the tray elevation motor raises a tray, the ON status of the tray upper limit sensor is detected.	Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. Tray upper limit sensor and DF main PWB (CN5) Paper surface sensor 1/2 and DF main PWB (CN6)
		Defective tray upper limit sensor, paper surface sensor 1/2.	Replace the sensor.
		Defective DF main PWB.	Replace the DF main PWB and check for correct operation.
8040	Belt problem (document finisher) The belt sensor does not turn on/off within specified time of the belt solenoid turning on.	Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. Belt sensor and DF main PWB (CN10) Belt solenoid and DF main PWB (CN21)
		Defective belt sensor.	Replace the belt sensor.
		Defective belt solenoid.	Replace the belt solenoid.
		Defective DF main PWB.	Replace the DF main PWB and check for correct operation.
8140	Tray elevation motor problem (document finisher) The tray low limit sensor or paper surface sensor 1/2 cannot be detected to be on within 10 s since the tray elevation motor is activated.	Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. Tray elevation motor and DF main PWB (CN12)
		Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. Tray lower limit sensor, and DF main PWB (CN5) Paper surface sensor 1/2 and DF main PWB (CN6)
		The tray elevation motor malfunctions.	Replace the tray elevation motor.
		Defective tray lower limit sensor, paper surface sensor 1/2.	Replace the sensor.
		Defective DF main PWB.	Replace the DF main PWB and check for correct operation.

Code	Contents	Causes	Check procedures/ corrective measures
8210	Stapler problem (document finisher) Jam 7012 or 7023 is indicated.	Defective connector cable of staple or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable.
		The stapler is blocked with a staple.	Remove the stapler cartridge, and check the cartridge and the stapling section of the stapler.
		The stapler is broken.	Replace the stapler and check for correct operation.
		Defective DF main PWB.	Replace the DF main PWB and check for correct operation.
8320	Adjustment motor 2 problem (document finisher) The adjustment sensor 2 does not turn on/off within specified time of the adjustment motor 2 turning on.	Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. Adjustment motor 2 and DF main PWB (CN18) Adjustment sensor 2 and DF main PWB (CN7)
		Defective adjustment sensor 2.	Replace the adjustment sensor 2.
		Defective adjustment motor 2.	Replace the adjustment motor 2.
		Defective DF main PWB.	Replace the DF main PWB and check for correct operation.
8330	Adjustment motor 1 problem (document finisher) The adjustment sensor 1 does not turn on/off within specified time of the adjustment motor 1 turning on.	Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. Adjustment motor 1 and DF main PWB (CN18) Adjustment sensor 1 and DF main PWB (CN7)
		Defective adjustment sensor 1.	Replace the adjustment sensor 1.
		Defective adjustment motor 1.	Replace the adjustment motor 1.
		Defective DF main PWB.	Replace the DF main PWB and check for correct operation.

Code	Contents	Causes	Check procedures/ corrective measures
8350	Roller motor problem (document finisher) The roller sensor does not turn on/off within specified time of the roller motor turning on.	Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. Roller motor and DF main PWB (CN20) Roller sensor and DF main PWB (CN11)
		Defective roller sensor.	Replace the roller sensor.
		Defective roller motor.	Replace the roller motor.
		Defective DF main PWB.	Replace the DF main PWB and check for correct operation.
8360	Slide motor problem (document finisher) The slide sensor does not turn on/off within specified time of the slide motor turning on.	Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. Slide motor and DF main PWB (CN14) Slide sensor and DF main PWB (CN22)
		Defective slide sensor.	Replace the slide sensor.
		Defective slide motor.	Replace the slide motor.
		Defective DF main PWB.	Replace the DF main PWB and check for correct operation.
8460	EEPROM problem (document finisher) Reading from or writing to EEPROM cannot be performed.	Defective EEPROM or DF main PWB.	Replace the DF main PWB and check for correct operation.
8800	Document finisher communication error A communication error is detected 10 times in succession.	Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. Engine PWB (YC19) and DF relay PWB (YC2) DF relay PWB (YC3) and DF main PWB (CN1)
		Defective DF main PWB.	Replace the DF main PWB and check for correct operation.
		Defective engine PWB.	Replace the engine PWB and check for correct operation (see page 1-5-32).

Code	Contents	Causes	Check procedures/ corrective measures
8830	Bridge communication error (document finisher) A communication error is detected 10 times in succession.	Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. Engine PWB (YC19) and DF relay PWB (YC2) DF relay PWB (YC4) and bridge PWB (YC5)
		Defective bridge PWB.	Replace the bridge PWB and check for correct operation.
		Defective engine PWB.	Replace the engine PWB and check for correct operation (see page 1-5-32).
8900	Backup memory data problem (document finisher) Read and write data does not match 3 times in succession.	Defective connector cable or poor contact in the connector.	Check the connection of connector on the finisher main PWB and the connector of the machine, and the continuity across the connector terminals. Repair or replace if necessary.
		EEPROM installed incorrectly.	Install EEPROM correctly.
		Defective finisher main PWB.	Replace the finisher main PWB and check for correct operation.
9000	Document processor communication error A communication error is detected 10 times in succession.	Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. DP main PWB and engine PWB (YC18)
		Defective DP main PWB.	Replace the DP main PWB and check for correct operation (see page 1-5-29).
9060	DP EEPROM error Mismatch between writing data and reading data occurs three times successively. Mismatch of reading data from two locations occurs three times successively.	Defective DP main PWB.	Replace the DP main PWB and check for correct operation (see page 1-5-29).
		Device damage of EEPROM.	Contact the Service Administrative Division.
9500			Contact the Service Administrative Division.
9510			
9520			

Code	Contents	Causes	Check procedures/ corrective measures
F000	Main PWB - operation panel PWB communication error	Defective main PWB.	Turn the main power switch off/on to restart the machine. If the error is not resolved, replace main PWB (see page 1-5-31).
		Defective operation panel PWB.	Replace the operation panel PWB and check for correct operation.
F010	Main PWB checksum error	Defective main PWB.	Turn the main power switch off/on to restart the machine. If the error is not resolved, replace main PWB (see page 1-5-31).
F011			
F012			
F013			
F040	Main PWB - print engine communication error	Defective main PWB.	Turn the main power switch off/on to restart the machine. If the error is not resolved, replace main PWB (see page 1-5-31).
		Defective engine PWB.	Replace the engine PWB and check for correct operation (see page 1-5-32).
F050	Print engine ROM checksum error	Defective engine PWB.	Turn the main power switch off/on to restart the machine. If the error is not resolved, replace engine PWB (see page 1-5-32).

1-4-3 Image quality problems

If the part causing the problem is not designated as a service part, replace with the assembly comprising the part.

(1) No image appears (entirely white).



See page 1-4-38

(2) No image appears (entirely black).




See page 1-4-38

(3) Image is too light.



See page 1-4-39

(4) The background is colored.




See page 1-4-39

(5) White streaks are printed vertically.




See page 1-4-39

(6) Black streaks are printed vertically.



See page 1-4-40

(7) Streaks are printed horizontally.



See page 1-4-40

(8) One side of the print image is darker than the other.



See page 1-4-40

(9) Spots are printed.



See page 1-4-41

(10) Image is blurred.



See page 1-4-41

(11) The leading edge of the image is consistently misaligned with the original.




See page 1-4-41

(12) The leading edge of the image is sporadically misaligned with the original.



See page 1-4-41

(13) Paper is wrinkled.




See page 1-4-42

(14) Offset occurs.




See page 1-4-42

(15) Part of image is missing.



See page 1-4-42

(16) Fusing is loose.



See page 1-4-42

(17) Image is out of focus.



See page 1-4-43

(18) Image center does not align with the original center.




See page 1-4-43

TOLLER

www.tollerplus.com

(1) No image appears (entirely white).

Print example	Causes		Check procedures/corrective measures
	Defective transfer bias output.	Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity of the connector cable. If necessary, replace the cable. High voltage PWB and engine PWB (YC15) High voltage PWB sub and engine PWB (YC13)
		Defective high voltage PWB.	Replace the high voltage PWB.
		Defective high voltage PWB sub.	Replace the high voltage PWB sub.
		Defective engine PWB.	Replace the engine PWB (see page 1-5-32).
	Defective developer bias output.	Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity of the connector cable. If necessary, replace the cable. High voltage PWB and engine PWB (YC15)
		Defective high voltage PWB.	Replace the high voltage PWB.
		Defective engine PWB.	Replace the engine PWB (see page 1-5-32).
	No LSU laser is output.	Defective laser scanner unit.	Replace the laser scanner unit (see page 1-5-20).
		Defective main PWB.	Replace the main PWB (see page 1-5-31).


(2) No image appears (entirely black).

Print example	Causes		Check procedures/corrective measures
	No main charging.	Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. High voltage PWB and engine PWB (YC15)
		Defective charger roller unit.	Replace the charger roller unit (see page 1-5-16).
		Defective high voltage PWB.	Replace the high voltage PWB.
		Defective engine PWB.	Replace the engine PWB (see page 1-5-32).
	Exposure lamp fails to light.	Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. LED PWB and main PWB (YC112) CCD PWB and main PWB (YC113)
		Defective CCD PWB.	Replace the image scanner unit (see page 1-5-21).
		Defective main PWB.	Replace the main PWB (see page 1-5-31).

(3) Image is too light.

Print example	Causes		Check procedures/corrective measures
	Defective transfer charger output.	Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. High voltage PWB and engine PWB (YC15) High voltage PWB sub and engine PWB (YC13)
		Defective high voltage PWB.	Replace the high voltage PWB (see page 1-5-36).
		Defective high voltage PWB sub.	Replace the high voltage PWB sub (see page 1-5-36).
		Defective engine PWB.	Replace the engine PWB (see page 1-5-32).
	Insufficient toner.	If the display shows the message requesting toner replenishment, replace the container.	
Deteriorated toner.	Perform the drum refresh operation.		


(4) The background is colored.

Print example	Causes		Check procedures/corrective measures
	Defective main charger output.	Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. High voltage PWB and engine PWB (YC15)
		Defective high voltage PWB.	Replace the high voltage PWB.
		Defective engine PWB.	Replace the engine PWB (see page 1-5-32).
	Deteriorated toner.	Perform the drum refresh operation.	


(5) White streaks are printed vertically.

Print example	Causes	Check procedures/corrective measures
	Foreign matter in the developer unit.	Check if the magnetic brush is formed uniformly. Replace the developer unit if any foreign matter (see page 1-5-14).
	Dirty shading plate.	Clean the shading plate.
	Adhesion of soiling to transfer belt.	Clean the transfer belt. Replace the intermediate transfer unit if it is extremely dirty (see page 1-5-17).
	Adhesion of soiling to transfer roller.	Clean the transfer roller. Replace the transfer roller unit if it is extremely dirty (see page 1-5-17).
	Dirty LSU dust shield glass.	Perform the LSU dust shield glass cleaning.

(6) Black streaks are printed vertically.

Print example	Causes	Check procedures/corrective measures
	Dirty contact glass.	Clean the contact glass.
	Dirty slit glass.	Clean the slit glass.
	Dirty or flawed drum.	Perform the drum refresh operation. Flawed drum. Replace the drum unit (see page 1-5-16).
	Deformed or worn cleaning blade in the drum unit.	Replace the drum unit (see page 1-5-16).
	Defective transfer belt.	Replace the intermediate transfer unit (see page 1-5-17).
	Defective transfer roller.	Replace the transfer roller unit(see page 1-5-17).
	Dirty scanner mirror.	Clean the scanner mirror.


(7) Streaks are printed horizontally.

Print example	Causes	Check procedures/corrective measures
	Dirty or flawed drum.	Perform the drum refresh operation. Flawed drum. Replace the drum unit (see page 1-5-16).
	Dirty developer section.	Clean any part contaminated with toner in the developer section.
	Poor contact of grounding terminal of drum unit.	Check the installation of the drum unit. If it operates incorrectly, replace it (see page 1-5-16).


(8) One side of the print image is darker than the other.

Print example	Causes	Check procedures/corrective measures
	Defective exposure lamp.	Replace the LED PWB (see page 1-5-24).


(9) Spots are printed.

Print example	Causes	Check procedures/corrective measures
	Dirty contact glass.	Clean the contact glass.
	Dirty or flawed drum.	Perform the drum refresh operation. Flawed drum. Replace the drum unit (see page 1-5-16).
	Deformed or worn cleaning blade in the drum unit.	Replace the drum unit (see page 1-5-16).
	Flawed developer roller.	Replace the developer unit (see page 1-5-14).
	Dirty heat roller and press roller.	Clean the heat roller and press roller.

(10) Image is blurred.

Print example	Causes	Check procedures/corrective measures
	Scanner moves erratically.	Check if there is any foreign matter on the front and rear scanner rails. If any, remove it.
	Deformed press roller.	Replace the fuser unit (see page 1-5-18).
	Paper conveying section drive problem.	Check the gears and belts and, if necessary, grease them.


(11) The leading edge of the image is consistently misaligned with the original.

Print example	Causes	Check procedures/corrective measures
	Misadjusted leading edge registration.	Run maintenance mode U034 to readjust the leading edge registration (see page 1-3-24).
	Misadjusted scanner leading edge registration.	Run maintenance mode U066 to readjust the scanner leading edge registration (see page 1-3-33).


(12) The leading edge of the image is sporadically misaligned with the original.

Print example	Causes	Check procedures/corrective measures
	Paper feed clutch, registration clutch or duplex clutch operating incorrectly.	Check the installation of the clutch. If it operates incorrectly, replace it.

(13) Paper is wrinkled.

Print example	Causes	Check procedures/corrective measures
	Paper curled.	Check the paper storage conditions.
	Paper damp.	Check the paper storage conditions.
	Defective pressure springs.	Replace the fuser unit (see page 1-5-18).


(14) Image is off-set.

Print example	Causes	Check procedures/corrective measures
	Deformed or worn cleaning blade in the drum unit.	Replace the drum unit (see page 1-5-16).
	Defective fuser unit.	Replace the fuser unit (see page 1-5-18).
	Wrong types of paper.	Check if the paper meets specifications. Replace paper.

(15) Part of image is missing.

Print example	Causes	Check procedures/corrective measures
	Paper damp.	Check the paper storage conditions.
	Paper creased.	Replace the paper.
	Drum condensation.	Perform the drum refresh operation.
	Dirty or flawed drum.	Perform the drum refresh operation. Flawed drum. Replace the drum unit (see page 1-5-16).
	Dirty transfer belt.	Clean the transfer belt. Replace the intermediate transfer unit if it is extremely dirty (see page 1-5-17).
	Dirty transfer roller.	Clean the transfer roller. Replace the transfer roller unit if it is extremely dirty (see page 1-5-17).

(16) Fusing is loose.

Print example	Causes	Check procedures/corrective measures
	Wrong types of paper.	Check if the paper meets specifications, replace paper.
	Flawed heat roller or press roller.	Replace the fuser unit (see page 1-5-18).
	Defective pressure springs.	
	Defective fuser heater.	

(17) Image is out of focus.

Print example	Causes	Check procedures/corrective measures
	Defective image scanning unit.	Replace the image scanning unit (see page 1-5-21).
	Drum condensation.	Perform the drum refresh operation.

(18) Image center does not align with the original center.

Print example	Causes	Check procedures/corrective measures
	Misadjusted image center line.	Run maintenance item U034 to readjust the center line of image printing (see page 1-3-25).
	Misadjusted scanner center line.	Run maintenance item U067 to readjust the scanner leading edge registration (see page 1-3-34).
	Original is not placed correctly.	Place the original correctly.

1-4-4 Electric problems

If the part causing the problem is not designated as a service part, replace with the assembly comprising the part.

Troubleshooting to each failure must be made in the order of the numbered Problems.

Problem	Causes	Check procedures/corrective measures
(1) The machine does not operate when the main power switch is turned on.	1. No electricity at the power outlet.	Measure the input voltage.
	2. The power cord is not plugged in properly.	Check the contact between the power plug and the outlet.
	3. Broken power cord.	Check for continuity. If none, replace the cord.
	4. Defective main power switch.	Check for continuity across the contacts. If none, replace the power switch.
	5. Defective interlock switch.	Check for continuity across the contacts of interlock switch. If none, replace the power source PWB (see page 1-5-33).
	6. Defective power source PWB.	Replace the power source PWB (see page 1-5-33).
(2) ISU motor does not operate.	1. Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. ISU motor and engine PWB (YC17)
	2. Defective drive transmission system.	Check if the rollers and gears rotate smoothly. If not, grease the bushes and gears. Check for broken gears and replace if any.
	3. Defective motor.	Replace the ISU motor.
	4. Defective PWB.	Replace the engine PWB and check for correct operation (see page 1-5-32).
(3) Eject motor does not operate.	1. Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. Eject motor and engine PWB (YC6)
	2. Defective drive transmission system.	Check if the rollers and gears rotate smoothly. If not, grease the bushes and gears. Check for broken gears and replace if any.
	3. Defective motor.	Replace the eject motor.
	4. Defective PWB.	Replace the engine PWB and check for correct operation (see page 1-5-32).

Problem	Causes	Check procedures/corrective measures
(4) ID Shutter motor does not operate.	1. Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. ID Shutter motor and engine connect PWB (YC17) engine connect PWB and engine PWB (YC9)
	2. Defective drive transmission system.	Check if the rollers and gears rotate smoothly. If not, grease the bushes and gears. Check for broken gears and replace if any.
	3. Defective motor.	Replace the ID Shuttermotor.
	4. Defective PWB.	Replace the engine PWB or engine connect PWB and check for correct operation (see page 1-5-32).
(5) Fuser pressure release motor does not operate.	1. Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. Fuser pressure release motor and engine PWB (YC22)
	2. Defective drive transmission system.	Check if the rollers and gears rotate smoothly. If not, grease the bushes and gears. Check for broken gears and replace if any.
	3. Defective motor.	Replace the Fuser pressure release motor.
	4. Defective PWB.	Replace the engine PWB and check for correct operation (see page 1-5-32).
(6) Controller fan motor does not operate.	1. Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. Controller fan motor and main PWB (YC41)
	2. Defective motor.	Replace the controller fan motor.
	3. Defective PWB.	Replace the main PWB and check for correct operation (see page 1-5-31).
(7) Power source fan motor does not operate.	1. Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. Power source fan motor and engine connect PWB (YC11) engine connect PWB and engine PWB (YC9)
	2. Defective motor.	Replace the power source fan motor.
	3. Defective PWB.	Replace the engine PWB or engine connect PWB and check for correct operation (see page 1-5-32).
(8) Developer fan motor does not operate.	1. Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. Developer fan motor and engine connect PWB (YC6) engine connect PWB and engine PWB (YC9)
	2. Defective motor.	Replace the developer fan motor.
	3. Defective PWB.	Replace the engine PWB or engine connect PWB and check for correct operation (see page 1-5-32).

Problem	Causes	Check procedures/corrective measures
(9) LSU fan motor does not operate.	1. Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. LSU fan motor and engine connect PWB (YC6) Engine connect PWB and engine PWB (YC9)
	2. Defective motor.	Replace the LSU fan motor.
	3. Defective PWB.	Replace the engine PWB engine connect PWB and check for correct operation (see page 1-5-32).
(10) IH fan motor does not operate.	1. Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. IH fan motor and main PWB (YC4)
	2. Defective motor.	Replace the IH fan motor.
	3. Defective PWB.	Replace the engine PWB and check for correct operation (see page 1-5-32).
(11) Fuser fan motor does not operate.	1. Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. Fuser fan motor and engine PWB (YC28)
	2. Defective motor.	Replace the Fuser fan motor.
	3. Defective PWB.	Replace the engine PWB and check for correct operation (see page 1-5-32).
(12) Container fan motor does not operate.	1. Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. Container fan motor and engine PWB (YC21)
	2. Defective motor.	Replace the container fan motor.
	3. Defective PWB.	Replace the engine PWB and check for correct operation (see page 1-5-32).
(13) IH coil fan motor does not operate.	1. Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. IH coil fan motor and engine PWB (YC21)
	2. Defective motor.	Replace the IH coil fan motor.
	3. Defective PWB.	Replace the engine PWB and check for correct operation (see page 1-5-32).
(14) Imaging fan motor does not operate.	1. Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. Imaging fan motor and engine connect PWB (YC11) Engine connect PWB and engine PWB
	2. Defective motor.	Replace the Imaging fan motor.
	3. Defective PWB.	Replace the engine PWB or engine connect PWB and check for correct operation (see page 1-5-32).
(15) Paper feed clutch does not operate.	1. Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. Paper feed clutch and engine PWB (YC2)
	2. Defective clutch.	Replace the paper feed clutch.
	3. Defective PWB.	Replace the engine PWB and check for correct operation (see page 1-5-32).

Problem	Causes	Check procedures/corrective measures
(16) Mid clutch does not operate.	1. Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. Mid clutch and engine PWB (YC2)
	2. Defective clutch.	Replace the mid clutch.
	3. Defective PWB.	Replace the engine PWB and check for correct operation (see page 1-5-32).
(17) Registration clutch does not operate.	1. Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. Registration clutch and engine PWB (YC2)
	2. Defective clutch.	Replace the registration clutch.
	3. Defective PWB.	Replace the engine PWB and check for correct operation (see page 1-5-32).
(18) Duplex clutch does not operate.	1. Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. Duplex clutch and engine PWB (YC2)
	2. Defective clutch.	Replace the duplex clutch.
	3. Defective PWB.	Replace the engine PWB and check for correct operation (see page 1-5-32).
(19) Developer stop clutch does not operate.	1. Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. Developer stop clutch and engine PWB (YC3)
	2. Defective clutch.	Replace the developer stop clutch.
	3. Defective PWB.	Replace the engine PWB and check for correct operation (see page 1-5-32).
(20) MP solenoid does not operate.	1. Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. MP solenoid and engine PWB (YC2)
	2. Defective solenoid.	Replace the MP solenoid.
	3. Defective PWB.	Replace the engine PWB and check for correct operation (see page 1-5-32).
(21) Feedshift solenoid does not operate.	1. Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. Feedshift solenoid and engine PWB (YC20)
	2. Defective solenoid.	Replace the Feedshift solenoid.
	3. Defective PWB.	Replace the engine PWB and check for correct operation (see page 1-5-32).

Problem	Causes	Check procedures/corrective measures
(22) The message requesting paper to be loaded is shown when paper is present on the cassette.	1. Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. Paper sensor and engine connect PWB (YC15) Engine connect PWB to engine PWB (YC9)
	2. Deformed actuator of the paper sensor.	Check visually and replace if necessary.
	3. Defective paper sensor.	Replace the cassette PWB.
	4. Defective PWB.	Replace the engine PWB or engine connect PWB and check for correct operation (see page 1-5-32).
(23) The message requesting paper to be loaded is shown when paper is present on the MP tray.	1. Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. MP paper sensor and engine PWB (YC28)
	2. Deformed actuator of the MP paper sensor.	Check visually and replace if necessary.
	3. Defective MP paper sensor.	Replace the MP paper sensor.
	4. Defective PWB.	Replace the engine PWB and check for correct operation (see page 1-5-32).
(24) The size of paper on the cassette is not displayed correctly.	1. Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. Paper size width switch and engine PWB (YC14) Paper size length switch and engine PWB (YC14)
	2. Defective cassette size switch.	Replace the paper size width switch or paper size length switch.
	3. Defective PWB.	Replace the engine PWB and check for correct operation (see page 1-5-32).
(25) A paper jam in the paper feed, paper conveying or eject section is indicated when the main power switch is turned on.	1. A piece of paper torn from paper is caught around registration sensor, duplex sensor, feed sensor or eject sensor.	Check visually and remove it, if any.
	2. Defective sensor.	Replace the registration sensor, duplex sensor, feed sensor or eject sensor.
(26) A message indicating cover open is displayed when the front cover or right cover is closed.	1. Deformed actuator of the interlock switch.	Check visually and replace if necessary.
	2. Defective interlock switch.	Replace the interlock switch.

Problem	Causes	Check procedures/corrective measures
(27) The LED lamp does not turn on when original is present on the DP.	1. Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. DP original sensor and DP main PWB (YC3) DP main PWB (YC1) and engine PWB (YC18)
	2. Defective DP original sensor.	Replace the DP original sensor.
	3. Defective PWB.	Replace the DP LED PWB and check for correct operation. Replace the engine PWB and check for correct operation (see page 1-5-32).
(28) The size of original on the DP is not displayed correctly.	1. Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. DP original size width sensor and DP main PWB (YC4) DP original size length sensor and DP main PWB (YC2) DP main PWB (YC1) and engine PWB (YC18)
	2. Defective original size sensor.	Replace the DP original size width sensor or DP original size length sensor.
	3. Defective PWB.	Replace the DP main PWB or engine PWB and check for correct operation (see page 1-5-29,1-5-32).
(29) DP paper feed motor does not operate.	1. Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. DP paper feed motor and DP main PWB (YC9) DP main PWB (YC1) and engine PWB (YC18)
	2. Defective drive transmission system.	Check if the rollers and gears rotate smoothly. If not, grease the bushes and gears. Check for broken gears and replace if any.
	3. Defective motor.	Replace the DP paper feed motor.
	4. Defective PWB.	Replace the DP main PWB or engine PWB and check for correct operation (see page 1-5-29,1-5-32).
(30) DP switchback motor does not operate.	1. Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. DP switchback motor and DP main PWB (YC9) DP main PWB (YC1) and engine PWB (YC18)
	2. Defective drive transmission system.	Check if the rollers and gears rotate smoothly. If not, grease the bushes and gears. Check for broken gears and replace if any.
	3. Defective motor.	Replace the DP switchback motor.
	4. Defective PWB.	Replace the DP main PWB or engine PWB and check for correct operation (see page 1-5-29,1-5-32).

Problem	Causes	Check procedures/corrective measures
(31) DP paper feed clutch does not operate.	1. Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. DP paper feed clutch and DP main PWB (YC8) DP main PWB (YC1) and engine PWB (YC18)
	2. Defective clutch.	Replace the DP paper feed clutch.
	3. Defective PWB.	Replace the DP main PWB or engine PWB and check for correct operation (see page 1-5-29,1-5-32).
(32) DP registration clutch does not operate.	1. Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. DP registration clutch and DP main PWB (YC8) DP main PWB (YC1) and engine PWB (YC18)
	2. Defective clutch.	Replace the DP registration clutch.
	3. Defective PWB.	Replace the DP main PWB or engine PWB and check for correct operation (see page 1-5-29,1-5-32).
(33) An original jams when the main power switch is turned on.	1. A piece of paper torn from an original is caught around the DP paper feed sensor, DP registration sensor or DP timing sensor.	Check visually and remove it, if any.
	2. Defective sensor.	Replace the DP paper feed sensor, DP registration sensor or DP timing sensor.
(34) A message indicating cover open is displayed when the DP top cover is closed.	1. Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. DP open/close sensor and DP main PWB (YC5) DP main PWB (YC1) and engine PWB (YC18)
	2. Defective DP open/close sensor.	Replace the DP open/close sensor.

1-4-5 Mechanical problems

If the part causing the problem was not supplied, use the unit including the part for replacement.

Problem	Causes/check procedures	Corrective measures
(1) No primary paper feed.	Check if the surfaces of the following rollers are dirty with paper dusts. Pickup roller Paper feed roller MP paper feed roller	Clean with isopropyl alcohol.
	Check if any of the following rollers is deformed. Pickup roller Paper feed roller MP paper feed roller	Check visually and replace any deformed (see page 1-5-10, 1-5-11).
	Defective paper feed clutch installation.	Check visually and remedy if necessary.
(2) No secondary paper feed.	Check if the surfaces of the following rollers are dirty with paper powder. Right registration roller Left registration roller	Clean with isopropyl alcohol.
	Defective registration clutch installation.	Check visually and remedy if necessary.
(3) Skewed paper feed.	Paper width guide in the cassette are installed incorrectly.	Check the paper width guide visually and remedy or replace if necessary.
(4) Multiple sheets of paper are fed.	Check if the paper is excessively curled.	Change the paper.
	Paper is loaded incorrectly.	Load the paper correctly.
	Check if the retard roller is worn.	Replace the retard roller if it is worn (see page 1-5-10).
(5) Paper jams.	Check if the paper is excessively curled.	Change the paper.
	Check if the contact between the right and left registration rollers is correct.	Check visually and remedy if necessary.
	Check if the heat roller or press roller is extremely dirty or deformed.	Check visually and replace the fuser unit (see page 1-5-18).
(6) Toner drops on the paper conveying path.	Check if the drum unit or developer unit is extremely dirty.	Clean the drum unit or developer unit.

Problem	Causes/check procedures	Corrective measures
(7) Abnormal noise is heard.	Check if the rollers, pulleys and gears operate smoothly.	Grease the bushes and gears.
	Check if the following clutches are installed correctly. Paper feed clutch Mid clutch Registration clutch Duplex clutch	Check visually and remedy if necessary.
(8) No primary original feed.	Check if the surfaces of the following pulleys are dirty with paper powder. DP forwarding pulley DP paper feed roller	Clean with isopropyl alcohol.
	Check if the following pulleys is deformed. DP forwarding pulley DP paper feed roller	Check visually and replace any deformed (see page 1-5-27).
(9) Multiple sheets of original are fed.	Original is not correctly set.	Set the original correctly.
	Check if the DP separation pulley is worn.	Replace the DP separation pulley if it is worn (see page 1-5-27).
(10) Originals jam.	Originals being used do not conform with the specifications.	Use only originals conforming to the specifications.
	Check if the surfaces of the following pulleys are dirty with paper powder. DP forwarding pulley DP paper feed roller	Clean with isopropyl alcohol.
	Check if the contact between the registration roller and registration pulley is correct.	Check visually and remedy if necessary.
	Check if the contact between the conveying roller and conveying pulley is correct.	Check visually and remedy if necessary.
	Check if the contact between the eject roller and eject pulley is correct.	Check visually and remedy if necessary.
	Check if the contact between the switchback roller and switchback pulley is correct.	Check visually and remedy if necessary.

1-4-6 Send error code

This section describes the scanning errors and descriptions, preventive actions, as well as corrective actions. Error codes not described here could fall within software errors.

If such an error is encountered, turn power off then on, and advise the service representative.

(1) Scan to SMB error codes

Code	Contents	Check procedures/corrective measures
1101	Host destined does not exist on the network.	<ol style="list-style-type: none"> 1. Confirm the destined host. 2. Confirm the device's network parameters. 3. Confirm the parameters of the network to which the device is connected are correct.
1102	Login to the host has failed.	<ol style="list-style-type: none"> 1. Confirm user name and password. 2. Confirm the parameters of the network to which the device is connected are correct. 3. Check the host if the folder is properly shared.
1103	Destined host, folder, and/or file names are invalid.	<ol style="list-style-type: none"> 1. Check illegal characters are not contained within these names. 2. Check the name of the folder and files conform with the naming syntax. 3. Confirm destined host and folder.
1105	SMB protocol is not enabled.	<ol style="list-style-type: none"> 1. Confirm device's SMB protocols.
2101	Login to the host has failed.	<ol style="list-style-type: none"> 1. Confirm the destined host. 2. Confirm that the LAN cable is properly connected to the device. 3. Check the SMB port number. 4. Confirm the device's network parameters. 5. Confirm the parameters of the network to which the device is connected are correct.
2201	Writing scanned data has failed.	<ol style="list-style-type: none"> 1. Check the file name to save the scanned data. 2. Confirm the device's network parameters. 3. Confirm the parameters of the network to which the device is connected are correct.

(2) Scan to FTP error codes

Code	Contents	Check procedures/corrective measures
1101	FTP server does not exist on the network.	<ol style="list-style-type: none"> 1. Check the FTP server name. 2. Confirm device's network parameters. 3. Confirm the parameters of the network to which the device is connected are correct.
1102	Login to the FTP server has failed.	<ol style="list-style-type: none"> 1. Confirm user name and password. 2. Check the FTP server name.
1103	Destined folder is invalid.	<ol style="list-style-type: none"> 1. Check that the illegal characters are not contained within these names. 2. Check the FTP server name.
1105	FTP protocol is not enabled.	<ol style="list-style-type: none"> 1. Confirm device's FTP protocols.
1131	Initializing TLS has failed.	<ol style="list-style-type: none"> 1. Confirm device's security parameters.
1132	TLS negotiation has failed.	<ol style="list-style-type: none"> 1. Confirm device's security parameters. 2. Check the FTP server name.
2101	Access to the FTP server has failed.	<ol style="list-style-type: none"> 1. Check the FTP server name. 2. Confirm that the LAN cable is properly connected to the device. 3. Check the FTP port number. 4. Confirm device's network parameters. 5. Confirm the network parameters the device is connected. 6. Check the FTP server name.
2102	Access to the FTP server has failed. (Connection timeout)	<ol style="list-style-type: none"> 1. Check the FTP server name. 2. Check the FTP port number. 3. Confirm device's network parameters. 4. Confirm the network parameters the device is connected. 5. Check the FTP server name.
2201	Connection with the FTP server has failed.	<ol style="list-style-type: none"> 1. Confirm device's network parameters. 2. Confirm the network parameters the device is connected. 3. Confirm destined folder. 4. Check the FTP server name.
2202	Connection with the FTP server has failed. (Timeout)	<ol style="list-style-type: none"> 1. Confirm device's network parameters. 2. Confirm the network parameters the device is connected.
2231	Connection with the FTP server has failed. (FTPS communication)	<ol style="list-style-type: none"> 1. Confirm device's network parameters. 2. Confirm the network parameters the device is connected.
3101	FTP server responded with an error.	<ol style="list-style-type: none"> 1. Confirm device's network parameters. 2. Confirm the network parameters the device is connected. 3. Check the FTP server.

(3) Scan to E-mail error codes

Code	Contents	Check procedures/corrective measures
1101	SMTP/POP3 server does not exist on the network.	<ol style="list-style-type: none"> 1. Check the SMTP/POP3 server name. 2. Confirm device's network parameters. 3. Confirm the parameters of the network to which the device is connected are correct.
1102	Login to the SMTP/POP3 server has failed.	<ol style="list-style-type: none"> 1. Confirm user name and password. 2. Check the SMTP/POP3 server.
1104	The domain the destined address belongs is prohibited by scanning restriction.	<ol style="list-style-type: none"> 1. Confirm device's SMTP parameters.
1105	SMTP protocol is not enabled.	<ol style="list-style-type: none"> 1. Confirm device's SMTP protocols.
1106	Sender's address is not specified.	<ol style="list-style-type: none"> 1. Confirm device's SMTP protocols.
2101	Connection to the SMTP/POP3 server has failed.	<ol style="list-style-type: none"> 1. Check the SMTP/POP3 server name. 2. Confirm that the LAN cable is properly connected to the device. 3. Check the SMTP/POP3 port number. 4. Confirm device's network parameters. 5. Confirm the network parameters the device is connected. 6. Check the SMTP/POP3 server.
2102	Connection to the SMTP/POP3 server has failed. (Connection timeout)	<ol style="list-style-type: none"> 1. Check the SMTP/POP3 server name. 2. Check the SMTP/POP3 port number. 3. Confirm device's network parameters. 4. Confirm the network parameters the device is connected. 5. Check the SMTP/POP3 server.
2201	Connection to the SMTP/POP3 server has failed.	<ol style="list-style-type: none"> 1. Confirm device's network parameters. 2. Confirm the network parameters the device is connected.
2202	Connection to the SMTP/POP3 server has failed. (Timeout)	<ol style="list-style-type: none"> 1. Confirm device's network parameters. 2. Confirm the network parameters the device is connected.
2204	The size of scanning exceeded its limit.	<ol style="list-style-type: none"> 1. Confirm device's network parameters.
3101	SMTP/POP3 server responded with an error.	<ol style="list-style-type: none"> 1. Confirm device's network parameters. 2. Confirm the network parameters the device is connected. 3. Check the SMTP/POP3 server.
3201	No SMTP authentication is found.	<ol style="list-style-type: none"> 1. Check the SMTP server. 2. The device supports SMTP authentication services including CRAM-MD5, DIGEST-MD5, PLAIN and LOGIN.

This page is intentionally left blank.

1-5-1 Precautions for assembly and disassembly

(1) Precautions

Before starting disassembly, press the Power key on the operation panel to off. Make sure that the Power lamp is off before turning off the main power switch. Unplug the power cable from the wall outlet.

When the fax kit is installed, be sure to disconnect the modular code before starting disassembly.

When handling PWBs (printed wiring boards), do not touch parts with bare hands.

The PWBs are susceptible to static charge.

Do not touch any PWB containing ICs with bare hands or any object prone to static charge.

When removing the hook of the connector, be sure to release the hook.

Take care not to get the cables caught.

To reassemble the parts, use the original screws. If the types and the sizes of screws are not known, refer to the PARTS LIST.

(2) Drum unit

Note the following when handling or storing the drum unit.

When removing the drum unit, never expose the drum surface to strong direct light.

Keep the drum unit at an ambient temperature between -20°C/-4°F and 40°C/104°F and at a relative humidity not higher than 85% RH. Avoid abrupt changes in temperature and humidity.

Avoid exposure to any substance which is harmful to or may affect the quality of the drum unit.

Do not touch the drum surface with any object. Should it be touched by hands or stained with oil, clean it.

(3) Toner

Store the toner containers in a cool, dark place.

Avoid exposing the toner containers to direct light and high humidity.

(4) How to tell a genuine Kyocera Mita toner container

As a means of brand protection, the Kyocera Mita toner container utilizes an optical security technology to enable visual validation. A validation viewer is required to accomplish this.

Hold the validation viewer over the left side part of the brand protection seal on the toner container. Through each window of the validation viewer, the left side part of the seal should be seen as follows:

A black-colored band when seen through the left side window (●)

A shiny or gold-colored band when seen through the right side window (☼)

The above will reveal that the toner container is a genuine Kyocera Mita branded toner container, otherwise, it is a counterfeit.




Figure 1-5-1

The brand protection seal has an incision as shown below to prohibit reuse.




Figure 1-5-2

1-5-2 Outer covers

(1) Detaching and refitting the front cover

Procedure

1. Remove the cassette.
(See page 1-5-10)
2. Open the front cover.




Figure 1-5-3

3. Unhitch the straps by squeezing the hooks inward as shown.




Figure 1-5-4

4. Remove two fulcrum axes of the front cover.
5. Remove the front cover.




Figure 1-5-5

(2) Detaching and refitting the rear cover

Procedure

1. Remove the power cord.
If the document feeder is installed, remove its interface connector.
2. Release four hooks and then remove the controller box cover.




Figure 1-5-6

3. Remove two screws of the DP interface connector and then remove the DP interface connector.
(See page 1-5-26)
4. Remove six screws.
5. Pull the rear cover upwards and then release three hooks.
6. Remove the rear cover.




Figure 1-5-7

(3) Detaching and refitting the inner tray

Procedure

1. Release the lock lever and then remove the job separator tray.

ATTENTION: When refitting the Job separator tray, be cautious of the position of a paper guide.





Figure 1-5-8

2. Remove the rear cover.
(See page 1-5-5)
3. Remove the cassette.
(See page 1-5-10)
4. Open the front cover. (See page 1-5-3)
5. Remove two screws.
6. Release three hooks A.
7. Pull the left lower cover upwards and then release ten hooks B.
8. Remove the left lower cover.




Figure 1-5-9

9. Release the hook of the front upper cover.
10. Tilt the front upper cover forward.




Figure 1-5-10

11. Remove the inner tray.




Figure 1-5-11

(4) Detaching and refitting the eject rear cover

Procedure

1. Release two hooks by using a flat screwdriver and then remove the tray left cover.




Figure 1-5-12

2. Pull the left upper cover downwards and then release two hooks A.
3. Pull the left upper cover upwards and then release three hooks B.
4. Remove the left upper cover.

ATTENTION: At the time of replace the left upper cover, confirm the position of the scanner lock lever .




Figure 1-5-13

5. Remove the eject rear cover.




Figure 1-5-14

1-5-3 Paper feed section

(1) Detaching and refitting the primary paper feed unit

Procedure

1. Remove the cassette.




Figure 1-5-15

2. Release the feed lever (yellow) and then remove the primary paper feed unit.
3. Check or replace the primary paper feed unit and refit all the removed parts.




Figure 1-5-16

(2) Detaching and refitting the MP paper feed roller and MP separation pad

Procedure

1. Open the right cover 1.




Figure 1-5-17

2. While squeezing the holder inward, remove the MP paper feed roller.




Figure 1-5-18

3. Tilt the MP separation pad forward and then remove it upwards.
4. Check or replace the MP paper feed roller and MP separation pad and refit all the removed parts.




Figure 1-5-19

(3) Detaching and refitting the registration roller

Procedure

1. Open the right cover 1
(See page 1-5-11).
2. Remove the transfer roller unit.
(See page 1-5-17)
3. Remove two springs at the front and back of the registration roller right.
4. Remove the cap and gear.
5. Slide and remove the registration roller right.
6. Check or replace the registration roller right and refit all the removed parts.




Figure 1-5-20

(4) Detaching and refitting the registration cleaner

Procedure

1. Open the front cover. (See page 1-5-3)
2. Open the duct cover. (See page 1-5-15)
3. Set the cleaner lever (yellow) up and draw the registration cleaner frontward.
4. Check or replace the registration cleaner and refit all the removed parts.




Figure 1-5-21

(5) Detaching and refitting the MP tray

Procedure

1. Open the MP tray.
2. Release two fulcrums of the MP tray by using a flat screwdriver.
3. Pull two straps upwards to remove.
4. Remove the MP tray.




Figure 1-5-22

1-5-4 Developing section

(1) Detaching and refitting the developing unit

Procedure

1. Open the front cover. (See page 1-5-3)
2. Release the lock lever and then remove the waste toner box.




Figure 1-5-23

3. Turn the lock lever (yellow) to the right and then knock down the duct cover forwards.




Figure 1-5-24

4. Lift the lever and turn the duct holder upwards.




Figure 1-5-25

5. Push the lock lever (yellow) of the development unit upwards and then remove the developer unit.
6. Check or replace the developer unit and refit all the removed parts.




Figure 1-5-26

CAUTION: Please don't store or transport the developing units in the state that are put on slant or lengthways.
Please carry the developing units and the main machine horizontally without the shock or vibration when relocating.

1-5-5 Drum section

(1) Detaching and refitting the drum unit

Procedure

1. Open the front cover. (See page 1-5-3)
2. Release the waste toner box. (See page 1-5-14)
3. Turn the lock lever to the right and then knock down the duct cover forwards. (See page 1-5-15)
4. Lift the lever and turn the duct holder upwards. (See page 1-5-11)
5. Push the lock lever (yellow) of the drum unit upwards and then remove the drum unit.
6. Check or replace the drum unit and refit all the removed parts.




Figure 1-5-27

(2) Detaching and refitting the charger roller unit

Procedure

1. Remove the drum unit. (See page 1-5-16)
2. Release two lock levers and then remove the charger roller unit.
3. Check or replace the charger roller unit and refit all the removed parts.




Figure 1-5-28

1-5-6 Transfer/separation section

(1) Detaching and refitting the intermediate transfer unit

Procedure

1. Open the right cover 1.
(See page 1-5-11)
2. Pull the intermediate transfer unit forwards by holding two knobs A(yellow)
3. Change to the knob B from the knob A and then remove the intermediate transfer unit.
4. Check or replace the intermediate transfer unit and refit all the removed parts.

CAUTION: When refitting the transfer roller unit, insert it in place until it clicks in.




Figure 1-5-29

(2) Detaching and refitting the secondary transfer roller unit

Procedure

1. Open the right cover 1.
(See page 1-5-11)
2. Release two lock levers (yellow) and then remove the secondary transfer roller unit.
3. Check or replace the secondary transfer roller unit and refit all the removed parts.

ATTENTION: When refitting the secondary transfer roller unit, insert it in place until it clicks in.




Figure 1-5-30

1-5-7 Fuser section

(1) Detaching and refitting the fuser unit

Procedure

1. Open the right cover 1.
(See page 1-5-11)
2. Release two mount levers (yellow) and then pull the fuser unit forwards




Figure 1-5-31

3. Grip two knobs (yellow) of the fuser unit.
4. Lift the fuser unit upwards and then remove the fuser unit.
5. Check or replace the fuser unit and refit all the removed parts.




Figure 1-5-32

1-5-8 Drive section

(1) Detaching and refitting the conveying motor

Procedure

1. Remove the rear cover.
(See page 1-5-5)
2. Remove the connector from the conveying motor PWB.
3. Remove three screws and then remove the conveying motor.
4. Check or replace the conveying motor and refit all the removed parts.




Figure 1-5-33

(2) Detaching and refitting the drive unit

Procedure

1. Remove the rear cover.
(See page 1-5-5)
2. Remove three connectors and then release the wires from the hooks.
3. Remove four screws and then remove the drive unit.
4. Check or replace the drive unit and refit all the removed parts.




Figure 1-5-34

1-5-9 Optical section

(1) Detaching and refitting the laser scanner unit

Procedure

1. Remove the cassette.
(See page 1-5-10)
2. Remove the rear cover and left lower cover.(See page 1-5-5,1-5-6)
3. Remove two connectors.
4. Remove four screws and then remove the laser scanner unit assy by pulling it forwards.




Figure 1-5-35

5. Release the clamp and then remove the FFC from the connector.
6. Remove two screws.
7. Remove the pin and spring and then remove the unit holder Y.
8. Lift the laser scanner unit Y upwards and then remove the laser scanner unit Y (LSU-Y).
9. Similarly, remove the laser scanner unit C/M/K(LSU-C/M/K).
10. Check or replace the laser scanner unit and refit all the removed parts.




Figure 1-5-36

(2) Detaching and refitting the image scanner unit

Procedure

1. Remove the DP or original cover.
(See page 1-5-26)
2. Remove two screws and then remove the scanner right cover.

ATTENTION: To reinstall the scanner right cover, position it close to the platen.




Figure 1-5-37

3. Remove the platen.




Figure 1-5-38

4. Remove four screws and then remove the scanner cover.




Figure 1-5-39

5. Remove the FFC from the connector.
6. Remove four screws and then remove the image scanner unit.




Figure 1-5-40

Refitting the ISU

7. When re-installation, fix the image scanner unit by matching to the scale of a former position.

When exchange, decide the fix position of ISU by the following.

The right and left of machine:

Confirm the number marked (a) and then match the line (c) of ISU to the positioning line (b) of same number on frame side.

(Line (c) is the one which is marked with the appropriate number.)

The rear and front of machine:

Match the edge (e) of ISU to the positioning line (d) on frame side.

8. Fix the ISU as before with four screws.
9. Check or replace the image scanner unit and refit all the removed parts.




Figure 1-5-41

(3) Detaching and refitting the LED unit

Procedure

1. Remove the DP or original cover.
(See page 1-5-26)
2. Remove the scanner right cover and platen.(See page 1-5-21)
3. Remove the ISU front cover.




Figure 1-5-42

4. Remove two screws and then remove the ISU rear cover.




Figure 1-5-43

5. Move the exposure unit to the cutting lack part.
6. Peel off the sheet.
7. Release the hook and then remove the FFC cover.




Figure 1-5-44

8. Remove the FFC from the connector.
9. Remove two screws and then remove the LED unit.
10. Check or replace the LED unit and refit all the removed parts.




Figure 1-5-45

1-5-10 Document processor

(1) Detaching and refitting the document processor

Procedure

1. Remove the restriction parts.
2. Open the document processor on vertically.




Figure 1-5-46

3. Remove two screws and then remove the DP interface connector.
4. Pull the document processor upwards out.




Figure 1-5-47

(2) Detaching and refitting the DP paper feed roller and DP separation pulley

Procedure

1. Open the DP top cover.




Figure 1-5-48

2. Pull the DP paper feed lever (yellow) down and then open it.
3. Knock the DP paper feed roller down forward.




Figure 1-5-49

4. Release the hook and then remove DP separation pulley cover.




Figure 1-5-50

5. Raise the DP separation pulley and remove it by pulling upward.
6. Check or replace the DP paper feed roller and DP separation pulley and refit all the removed parts.




Figure 1-5-51

(3) Detaching and refitting the DP main PWB

Procedure

1. Open the document processor.
2. Release three hooks of the DP rear cover.




Figure 1-5-52

3. Release two hooks of the DP rear cover and then remove it.




Figure 1-5-53

4. Remove all connectors from DP main PWB.
5. Remove five clamps and then remove the wires from holder.
6. Remove two screws and then remove the holder.




Figure 1-5-54

7. Remove six screws and then remove the DP main PWB.
8. Check or replace the DP main PWB and refit all the removed parts.

CAUTION: When replacing the DP main PWB, remove the EEPROM from the DP main PWB that has been removed and then reattach it to the new DP main PWB.




Figure 1-5-55

1-5-11 PWBs

(1) Detaching and refitting the main PWB

Procedure

1. Remove the rear cover.
(See page 1-5-5)
2. Remove the left lower cover.
(See page 1-5-6)
3. Remove the connector.
4. Remove the wire from the clamp.
5. Remove ten screws and then remove the controller box.




Figure 1-5-56

6. Remove all connectors and FFCs for the main PWB.
7. Remove eight screws and then remove the main PWB.
8. Check or replace the main PWB and refit all the removed parts.

CAUTION: When replacing the main board, perform a re-setup in maintenance mode with reference to "1-6-2 Remarks on PWB replacement (See page 1-6-4)".




Figure 1-5-57

(2) Detaching and refitting the engine PWB

Procedure

1. Remove the rear cover.
(See page 1-5-5)
2. Remove the main PWB.
(See page 1-5-5)
3. Remove fourteen screws and then remove the mount board for main PWB.




Figure 1-5-58

4. Remove all connectors from the engine PWB.
5. Remove four screws and then remove the engine PWB.
6. Check or replace the engine PWB and refit all the removed parts.

CAUTION: When replacing the engine PWB, remove the EEPROM (U15) from the engine PWB that has been removed and then reattach it to the new engine PWB.




Figure 1-5-59

(3) Detaching and refitting the power source PWB

Procedure

1. Remove the rear cover and inner tray. (See page 1-5-5, 1-5-6)
2. Remove the power source fan motor. (See page 1-5-20)
3. Remove all connectors from the power source PWB.
4. Remove four screws and then remove the power source PWB.
5. Check or replace the power source PWB and refit all the removed parts.




Figure 1-5-60

(4) Detaching and refitting the operation panel PWB main

Procedure

1. Remove the language sheets.
(See page 1-5-37)
2. Remove two screws.




Figure 1-5-61

3. Remove three connectors from the operation panel PWB main.
4. Remove the operation panel upper unit.




Figure 1-5-62

5. Remove four FFCs from the operation panel PWB main.
6. Remove four screws and then remove the operation panel PWB main.
7. Check or replace the operation panel PWB main and refit all the removed parts.




Figure 1-5-63

(5) Detaching and refitting the IH PWB

Procedure

1. Remove the scanner right cover.
(See page 1-5-5)
2. Remove the right upper cover.
3. Remove the right rear cover.




Figure 1-5-64

4. Remove two screws and then remove the IH box cover.
5. Remove all connectors from the IH PWB.
6. Remove six screws and then remove the IH PWB.
7. Check or replace the IH PWB and refit all the removed parts.




Figure 1-5-65

1-5-12 Others

(1) Detaching and refitting the language sheet

Procedure

1. Remove the upper cover by using a pen.
2. Remove the LCD cover.
3. Remove two operation panel covers
4. Remove two language sheets.
5. Check or replace the language sheet and refit all the removed parts.




Figure 1-5-66

(2) Detaching and refitting the conveying unit

Procedure

1. Remove the MP tray.(See page 1-5-13)
2. Remove the right cover 1.
(See page 1-5-11)




Figure 1-5-67

3. Remove two screws and then remove two straps.




Figure 1-5-68

4. Rotate the wire cover.
5. Remove two connectors.
6. Rotate the fulcrum axis and slide it forward.
7. Pull the right cover 1 backward and then remove it.




Figure 1-5-69

(3) Detaching and refitting the imaging fan motor

Procedure

1. Remove the rear cover.
(See page 1-5-5)
2. Remove four clamps and then remove the wires and the connector.
3. Unhook four hooks and then remove the imaging fan motor.




Figure 1-5-70

(4) Direction of installing the principal fan motors

When detaching or refitting the fan motor, be careful of the airflow direction (intake or exhaust).




Figure 1-5-71

1-6-1 Upgrading the firmware

Follow the procedure to upgrade the firmware below.

- * Main PWB (CTRL)
- * DP main PWB (DP)
- * PF main PWB (PF)
- * DF main PWB (DF)
- * Bridge PWB (AK)
- * Engine fuser PWB (IH)
- * Engine LSU PWB (LSU)
- * Engine IO PWB (IO)
- * Engine PWB (ENGN)
- * FAX PWB (FAX)
- * First color table (CLT1)
- * Second color table (CLT2)
- * Language data (OPT)
- * Dictionary data (DIC)
- * Operation panel PWB (PANL)

Preparation

Extract the file that has the download firmware and store them in a USB Memory.

NOTE: To improve Firmware Upgrade speed, a separate SKIP file can be added to the USB Memory Stick with the Firmware Upgrade package. The Skip file will allow ONLY the Firmware that has been Upgraded to a New Version to load, skipping duplicate Firmware Levels.

Procedure

1. Turn ON the main power switch and confirm if the screen shows "Ready to print" then, turn OFF the main power switch.
2. Insert USB memory that has the firmware in the USB memory slot.
3. Turn ON the main power switch.
4. About 50 seconds later, "Firmware Update" will be displayed (this shows that downloading is ready to start).
5. Select the firmware to upgrade by referring to the following codes:

CTRL → DP → PF → DF → AK → IH
 → LSU → IO → ENGN → FAX → CLT1
 → CLT2 → OPT → DIC → PANL




Figure 1-6-1

Example:

```
=====
Firmware Update
CTRL
xxx%
=====
```

First line: Status of upgrading.
 Second line: Firm ware for upgrading.
 Third line: The progress of upgrading in %.

Caution:

Never turn off the power switch or remove the USB flash device during upgrading.

6. Confirm that upgrading is completed.
7. Confirm that the version of the firmware is correctly displayed.
8. Turn OFF the main power switch and remove the USB memory.

Emergency-UPDATE

If the device is accidentally switched off and upgrading was incomplete, upgrade becomes impossible from a USB flash device.

In that case, retry upgrading after recovering the software by following the procedure below.

Preparation

The CF memory card must be formatted in FAT or FAT32 in advance.

Extract the main firmware to download from the file.

Rename the file which was extracted from the archive. [DL_CTRL.2MY] to [KM_EMRG.2MY]

Copy the all extracted files to the root of the CF memory.

Procedure

1. Turn the main power switch off.
2. Install the CF memory card which contains the firmware onto the main PWB.
3. Turn the main power switch on.
4. Rewriting of the PWB software will start for restoration.
The memory and attention LEDs will be blinking.
5. Only the Memory LED will be blinking when rewriting is successful.
* : Only the Attention LED will be blinking when rewriting is failed.
6. Turn the main power switch off.
7. Wait for several seconds and then remove the CF memory from the main PWB.
8. Extract the firmware to download from the archive and copy to the root of the USB flash device.

NOTE: Deletes the "ES_SKIP.on" file
When it is contained directly under the USB memory.

9. Insert the USB flash device in which the firmware was copied into the slot on the machine.
10. Perform steps 3 to 8 on the previous page.
11. Turn the main power switch on.
12. Perform maintenance item U000 (Print a maintenance report) to check that the version of ROM U109 has been upgraded.




Figure 1-6-2

1-6-2 Remarks on PWB replacement

(1) Engine PWB

NOTE: When replacing the PWB, remove the EEPROM from the PWB and then reattach it to the new PWB.




Figure 1-6-3

(2) DP main PWB

NOTE: When replacing the PWB, remove the EEPROM from the PWB and then reattach it to the new PWB.




Figure 1-6-4

(3) Main PWB

NOTE:The following operations are required when replacing the main board.

1. Execute maintenance mode U004 to resolve machine number mismatch that appears after replacing the main board.
2. Adjust the scanner image.
 - (1)Input the value in the auto scanner adjustment chart by using the maintenance mode U425.
 - (2)Execute the maintenance mode U411 with the auto scanner adjustment chart.
 - (3)Execute [Halftone adjustment] from the system menu
3. Reactivate the license for optional products if any were installed.
 - (1)Reactivate ID CARD AUTHENTICATION KIT B).
 - (2)Register an ID card again by using the maintenance mode U222.
4. Import data if any was exported from the machine before replacing the main board by using the maintenance mode U917. (The export and import is also available via KM-Net Viewer)
5. Register the initial user settings and FAX settings from the system menu or command center.
6. Execute the maintenance mode as below if necessary.

No.	Main machine related maintenance modes	No.	Fax related maintenance modes
U250	Checking/clearing the maintenance cycle	U603	Setting user data 1
U251	Checking/clearing the maintenance counter	U604	Setting user data 2
U253	Switching between double and single counts	U610	Setting system 1
U260	Selecting the timing for copy counting	U611	Setting system 2
U326	Setting the black line cleaning indication	U612	Setting system 3
U341	Specific paper feed location setting for printing function	U615	Setting system 6
U343	Switching between duplex/simplex copy mode	U625	Setting the transmission system 1
U345	Setting the value for maintenance due indication	U695	FAX function customize
U402	Adjusting margins of image printing		
U403	Adjusting margins for scanning an original on the contact glass		
U404	Adjusting margins for scanning an original from the DP		
U407	Adjusting the leading edge registration for memory image printing		
U425	Setting the target		
U429	Setting the offset for the color balance		
U432	Setting the center offset for the exposure		
U470	Setting the JPEG compression ratio		

2-1-1 Paper feed/conveying section

The paper feed/conveying section consists of the paper feed unit that feeds paper from the cassette and the MP tray paper feed unit that feeds paper from the MP tray, and the paper conveying section that conveys the fed paper to the transfer/separation section.

(1) Cassette paper feed section

The cassette can contain 500 sheets. The sheet from the cassette is pulled out by rotation of the pickup roller and sent to the paper conveying section by rotation of the paper feed roller. Also the retard roller prevents multiple feeding of paper.




Figure 2-1-1 Cassette paper feed section

- | | |
|----------------------|-----------------------------|
| 1. Pickup roller | 6. Paper length guide |
| 2. Paper feed roller | 7. Bottom plate |
| 3. Feed holder | 8. Lift work plate |
| 4. Retard roller | 9. Cassette base |
| 5. Retard holder | 10. Actuator (paper sensor) |




Figure 2-1-2 Cassette paper feed section block diagram

(2) MP tray paper feed section

The MP tray can contain 100 sheets. Feeding from the MP tray is performed by the rotation of the MP paper feed roller. Also, function of the MP separation pad prevents paper from multiple feeding.




Figure 2-1-3 MP tray paper feed section

- | | |
|-----------------------------------|---------------------------|
| 1. MP paper feed roller | 5. MP (multi purpose)tray |
| 2. MP separation pad | 6. MP tray extension |
| 3. MP bottom plate | 7. MP paper width guide |
| 4. Actuator(MP paper feed sensor) | |




Figure 2-1-4 MP tray paper feed section block diagram

(3) Conveying section

The conveying section conveys paper to the transfer/separation section as paper feeding from the cassette or MP tray, or as paper refeeding for duplex printing. Paper by feeding is conveyed by the paper feed roller to the position where the registration sensor (RS) is turned on, and then sent to the transfer/separation section by the right registration roller and left registration roller.




Figure 2-1-5 Conveying section

- | | |
|------------------------------|-----------------------------------|
| 1. Left registration roller | 4. Right feed roller |
| 2. Right registration roller | 5. Actuator (registration sensor) |
| 3. Left feed roller | 6. Registration cleaner |




Figure 2-1-6 Paper conveying section block diagram

2-1-2 Drum section

The drum section consists of the drum, the charger roller unit, and the cleaning unit, and the drum surface is uniformly charged in preparation for formation of residual image by laser beam.

After transfer is complete, toner remaining on the drum surface is chipped off with the cleaning blade and is collected to the waste toner box with the sweep roller. The cleaning lamp (CL) consists of LEDs and removes residual charge on the drum before main charging.




Figure 2-1-7 Drum section

- | | |
|----------------------------|-----------------------|
| 1. Drum | 6. Sweep roller |
| 2. Charger roller | 7. Drum frame |
| 3. Charger cleaning roller | 8. Cleaning lamp (CL) |
| 4. Charger case | |
| 5. Cleaning blade | |




Figure 2-1-8 Drum section block diagram

2-1-3 Developing section

The developing unit consists of the sleeve roller that forms the magnetic brush, the magnet roller, the developing blade and the developing screws that agitate the toner. Also, the toner sensor (TS) checks whether or not toner remains in the developing unit.




Figure 2-1-9 Developing section

- | | |
|-----------------------|----------------------|
| 1. Sleeve roller | 5. Developing blade |
| 2. Magnet roller | 6. Developer case |
| 3. Developing screw A | 7. Developer base |
| 4. Developing screw B | 8. Toner sensor (TS) |




Figure 2-1-10 Developing section block diagram

2-1-4 Optical section

The optical section consists of the image scanner section for scanning and the laser scanner section for printing.

(1) Image scanner section

The original image is illuminated by the exposure lamp (EL) and scanned by the CCD image sensor in the CCD PWB (CCDPWB) via the three mirrors and ISU lens, the reflected light being converted to an electrical signal.

If a document processor is used, the image scanner unit stops at the position of the DP contact glass and scans sequentially one row of the image on the original in synchronization with the moving timing of the original in the sub scan direction by driving the DP.




Figure 2-1-11 Scanner unit

- | | |
|----------------------------------|---------------------|
| 1. Platen | 4. ISU frame |
| 2. Original size indicator plate | 5. ISU motor (ISUM) |
| 3. DP contact glass | 6. ISU wire |




Figure 2-1-12 Image scanner unit (ISU)

- | | |
|----------------------------|----------------------|
| 1. The first mirror frame | 7. Mirror B |
| 2. Exposure lamp (EL) | 8. Mirror C |
| 3. Exposure lens | 9. ISU lens |
| 4. Reflector | 10. CCD PWB (CCDPWB) |
| 5. Mirror A | 11. Scanner cover |
| 6. The second mirror frame | |




Figure 2-1-13 Scanner unit block diagram

(2) Laser scanner section

The charged surface of the drum is then scanned by the laser beam from the laser scanner unit. The laser beam is dispersed as the polygon motor (PM) revolves to reflect the laser beam over the drum. Various lenses and mirror are housed in the laser scanner unit, adjust the diameter of the laser beam, and focalize it at the drum surface. Also the LSU cleaning motor (LSUCM) is activated to conduct automatically cleaning of the LSU dust shield glass.




Figure 2-1-14 Laser scanner unit (LSU)

- | | |
|-----------------------|--------------------------|
| 1. Polygon motor (PM) | 6. Mirrer B |
| 2. Porygon mirrer | 7. Mirrer C |
| 3. fθ lens A | 8. LSU dust shield glass |
| 4. fθ lens B | 9. LSU cleaning spiral |
| 5. Mirrer A | |

2-1-5 Transfer/Separation section

The transfer/separation section consists of the intermediate transfer unit section and the secondary transfer roller section.

(1) Intermediate transfer unit section

The intermediate transfer unit section consists of the transfer cleaning unit, the transfer belt, and the four primary transfer rollers for respective color drums, and forms a full-color toner image by superimposing and transferring single-color toner images formed on each drum onto the transfer belt. Also with the ID sensors (IDS) mounted on the machine frame, the toner density on the transfer belt is measured.

The transfer cleaning unit collects toner remaining on the transfer belt after secondary transfer and forwards it as waste toner to the waste toner box.




Figure 2-1-16 Inter mediate transfer unit section

- | | |
|------------------------------|-----------------------|
| 1. Tension roller | 7. Transfer belt |
| 2. Drive roller | 8. Cleaning fur brush |
| 3. Primary transfer roller K | 9. Cleaning roller |
| 4. Primary transfer roller M | 10. Cleaning blade |
| 5. Primary transfer roller C | 11. Cleaning screw |
| 6. Primary transfer roller Y | 12. ID sensors (IDS) |




Figure 2-1-17 Intermediate transfer unit section block diagram

(2) Secondary transfer roller section

The secondary transfer roller section consists of the secondary transfer roller mounted to the paper conveying unit and the separation needle. To the secondary transfer roller, DC bias is applied from the high voltage PWB (HVPWB). The toner image formed on the transfer belt is transferred to the paper by the potential difference. Paper after transfer is separated from the drum by applying separation charging that is output from the high voltage PWB (HVPWB) to the separation electrode.




Figure 2-1-18 Secondary transfer roller section

- 1. Secondary transfer roller
- 2. Separation needle holder
- 3. Paper chute guide
- 4. Separation needle
- 5. Fuser pre sensor




Figure 2-1-19 Secondary transfer roller section block diagram

2-1-6 Fuser section

The paper sent from the transfer/separation section is interleaved between the heat roller and the press roller. The heat roller is heated by the IH coil (IHC), and the toner is fused by heat and pressure and fixed onto the paper because the press roller is pressed by the fuser press spring. The surface temperature of heat roller is detected by the fuser thermistor1 (FTH1), fuser thermistor2 (FTH2) and the surface temperature of press roller is detected by the fuser thermistor3 (FTH3) and controlled by the engine PWB (EPWB). If the fuser section shows extremely high temperature, the power line will be shut off and the IH coil (IHC) is forced to turn off.




Figure 2-1-20 Fuser section

- | | |
|------------------------------|------------------------------|
| 1. Heat roller | 8. Fuser thermistor 2 (FTH2) |
| 2. Press roller | 9. Fuser thermistor 3 (FTH3) |
| 3. Uniformity heat roller | 10. Fuser thermostat (FTS) |
| 4. IH coil (IHC) | 11. Actuator (eject sensor) |
| 5. Core | 12. Eject roller |
| 6. Separate plate | 13. Eject pulley |
| 7. Fuser thermistor 1 (FTH1) | |




Figure 2-1-21 Fuser section block diagram

2-1-7 Eject/Feedshift section

The paper eject/feedshift section consists of the conveying path which sends the paper that has passed the fuser section to the inner tray, the job separator tray or the duplex conveying section.




Figure 2-1-22 Eject/Feedshift section

- | | |
|--------------------|--------------------------------------|
| 1. Eject roller A | 6. Actuator (paper full sensor) |
| 2. Eject pulley A | 7. Actuator |
| 3. Eject roller B | (job paper full sensor) |
| 4. Eject pulley B | 8. Actuator (job eject paper sensor) |
| 5. Feedshift guide | |




Figure 2-1-23 Eject/Feed shift section block diagram

2-1-8 Duplex conveying section

The duplex conveying section consists of conveying path which sends the paper sent from the eject/feedshift section to the paper feed/conveying section when duplex printing.




Figure 2-1-24 Duplex conveying section

- | | |
|-------------------------|------------------------------|
| 1. Right cover 1 | 6. Duplex feed roller C |
| 2. Duplex feed roller A | 7. Duplex feed pulley C |
| 3. Duplex feed pulley A | 8. Duplex feed roller D |
| 4. Duplex feed roller B | 9. Duplex feed pulley D |
| 5. Duplex feed pulley B | 10. Actuator (duplex sensor) |




Figure 2-1-25 Duplex conveying section block diagram

2-1-9 Document processor

(1) Original feed section

The original feed section consists of the parts shown in figure. An original placed on the original tray is conveyed to the original conveying section. Original is fed by the rotation of the DP forwarding pulley and DP paper feed roller.




Figure 2-1-26 Original feed section

- | | |
|-------------------------|----------------------------------|
| 1. DP forwarding pulley | 6. Actuator (DP original sensor) |
| 2. DP paper feed roller | 7. PF stopper |
| 3. DP feed holder | 8. Original tray |
| 4. DP separation pulley | |
| 5. Front separation pad | |




Figure 2-1-27 Original feed section block diagram

(2) Original conveying section

The original conveying section consists of the parts shown in figure. A conveyed original is scanned by the optical section (CCD) on the main machine when it passes through the slit glass of main machine.




Figure 2-1-28 Original conveying section

- | | |
|---------------------------|--------------------------------------|
| 1. DP top cover | 8. Actuator (DP paper feed sensor) |
| 2. DP registration roller | 9. Actuator (DP registration sensor) |
| 3. DP registration pulley | 10. Actuator (DP timing sensor) |
| 4. Conveying roller | 11. Switchback guide |
| 5. Conveying pulley | 12. Reading guide |
| 6. Eject roller | 13. Slit glass |
| 7. Eject pulley | |




Figure 2-1-29 Original conveying section block diagram

(3) Original switchback/eject sections

The original switchback/eject sections consists of the parts shown in figure. An original of which scanning is complete is ejected to the original eject table by the eject roller. In the case of duplex switchback scanning, an original is conveyed temporarily to the switchback tray and conveyed again to the original conveying section by the switchback roller.




Figure 2-1-30 Original switchback/eject sections

- | | |
|----------------------|-------------------------|
| 1. Feedshift guide | 5. Switchback pulley |
| 2. Eject roller | 6. Original eject table |
| 3. Eject pulley | 7. Switchback tray |
| 4. Switchback roller | |




Figure 2-1-31 Original switchback/eject sections block diagram

This page is intentionally left blank.

2-2-1 Electrical parts layout

(1) PWBs




Figure 2-2-1 PWBs

- 1. Main PWB (MPWB) Controls the software for print data processing and provides the interface with computers.
- 2. Engine PWB (EPWB)..... Controls printer hardware such as high voltage/bias output control, paper conveying system control, and fuser temperature control, etc.
- 3. High voltage PWB (HVPWB) Generates main charging, developing bias, secondary transfer bias.
- 4. High voltage PWB sub (HVPWB-S)..... Generates primary transfer bias, cleaning bias.
- 5. Power source PWB (PSPWB) After full-wave rectification of AC power source input, switching for converting to 24 V DC for output. Controls the fuser heater.
- 6. Power source PWB sub (PSPWB-S).... 5V output control when standing by.

7. Operation panel PWB main (OPPWB-M) Consists of the LCD, LED indicators and key switches.
8. Operation panel PWB left (OPPWB-L) Consists of the LED indicators and key switches.
9. Operation panel PWB right (OPPWB-R) Consists of the LED indicators and key switches.
10. LCD (LCD) LCD display.
11. LCD relay PWB (LCDRPWB) Consists of wiring relay circuits between the operation panel PWB main and the LCD PWB.
12. CCD PWB (CCDPWB) Scans the image of originals.
13. APC PWB Y (APCPWB-Y) Generates and controls the laser beam for yellow.
14. APC PWB C (APCPWB-C) Generates and controls the laser beam for cyan.
15. APC PWB M (APCPWB-M) Generates and controls the laser beam for magenta.
16. APC PWB K (APCPWB-K) Generates and controls the laser beam for black.
17. BD PWB Y (BDPWB-Y) Controls horizontal synchronizing timing of laser beam for yellow.
18. BD PWB C (BDPWB-C) Controls horizontal synchronizing timing of laser beam for cyan.
19. BD PWB M (BDPWB-M) Controls horizontal synchronizing timing of laser beam for magenta.
20. BD PWB K (BDPWB-K) Controls horizontal synchronizing timing of laser beam for black.
21. Drum PWB Y (DRPWB-Y) Relays wirings from electrical components on the drum unit for yellow.
Stores the drum's identifications a EEPROM.
22. Drum PWB C (DRPWB-C) Relays wirings from electrical components on the drum unit for cyan.
Stores the drum's identifications a EEPROM.
23. Drum PWB M (DRPWB-M) Relays wirings from electrical components on the drum unit for magenta.
Stores the drum's identifications a EEPROM.
24. Drum PWB K (DRPWB-K) Relays wirings from electrical components on the drum unit for black.
Stores the drum's identifications a EEPROM.
25. Drum connect PWB (DRCPWB) Consists of wiring relay circuit between engine PWB and the drum unit.
26. Developing PWB Y (DEVPWB-Y) Relays wirings from electrical components on the developing unit for yellow.
Stores the developer's identifications a EEPROM.
27. Developing PWB C (DEVPWB-C) Relays wirings from electrical components on the developing unit for cyan.
Stores the developer's identifications a EEPROM.
28. Developing PWB M (DEVPWB-M) Relays wirings from electrical components on the developing unit for magenta.
Stores the developer's identifications a EEPROM.
29. Developing PWB K (DEVPWB-K) Relays wirings from electrical components on the developing unit for black.
Stores the developer's identifications a EEPROM.
30. RFID PWB (RFPWB) Reads the container information.
31. LSU connect PWB (LSUCPWB) Consists of wiring relay circuit between main PWB, engine connect PWB and LSU unit.
32. Engine connect PWB (ECPWB) Consists of wiring relay circuit between engine PWB and drum connect PWB, transfer connect PWB, option unit.
33. IH PWB (IHPWB) Control of IH coil that heats fuser roller.
34. Fuser PWB (FUPWB) Relays wirings from electrical components on the fuser unit.
Fuser individual information in EEPROM storage.

35. Transfer PWB (TCPWB) Relays wirings from electrical components on the intermediate transfer unit.
Intermediate transfer individual information in EEPROM storage.
36. Transfer connect PWB (TCCPWB) Consists of wiring relay circuit between engine connect PWB and Transfer PWB.
37. DP main PWB (DPMPWB) Consists the motor and clutch driver circuit and wiring relay circuit.
38. DP LED PWB (DPLEDPWB) Displays the presence of the original.

PWB names conversion

No.	Name used in service manual	Name used in parts list
1	Main PWB (MPWB)	PARTS PWB MAIN ASSY SP
2	Engine PWB (EPWB)	PARTS PWB ENGINE ASSY SP
3	Engine connect PWB (ECPWB)	PARTS PWB ENGINE CONNECT ASSY SP
4	High voltage PWB (HVPWB)	PARTS HVU1 SP
5	High voltage PWB sub (HVPWB-S)	PARTS HVU2 SP
6	Power source PWB (PSPWB)	PARTS LVU MAIN 100 SP PARTS LVU MAIN 200 SP
7	Power source PWB sub(PSPWB-S)	PARTS LVU SUB 100 SP PARTS LVU SUB 200 SP
8	IH PWB (IHPWB)	PARTS PWB IH 100 ASSY SP PARTS PWB IH 200 ASSY SP
9	Operation panel PWB main(OPPWB-M)	PARTS PWB PANEL MAIN ASSY SP
10	Drum connect PWB (DRCPWB)	PARTS PWB DRUM DLP CONNECT ASSY SP
11	Transfer connect PWB (TCCPWB)	PARTS PWB TRANSFER CONNECT ASSY SP
12	LSU connect PWB (LSUCPWB)	PARTS PWB LSU CONNECT ASSY SP
13	RFID PWB (RFIDPWB)	PARTS PWB RFID ASSY SP
14	DP main PWB (DPMPWB)	PARTS PWB DRIVE ASSY SP

(2) Switches and sensors




Figure 2-2-2 Switches and sensors

- 1. Home position sensor (HPS) Detects the ISU in the home position.
- 2. Original detection switch (ODSW) Operates the original size detection sensor.
- 3. Original size sensor (OSS) Detects the size of the original.
- 4. Front cover switch (FCSW)..... Detects the opening and closing of the front cover.
- 5. Right cover switch (RCSW) Detects the opening and closing of the right cover.
- 6. Feed sensor (FS)..... Detects a paper misfeed in the vertical conveying section.
- 7. MP paper sensor (MPPS) Detects the presence of paper on the MP tray.
- 8. Registration sensor (RS)..... Controls the secondary paper feed start timing.
- 9. Duplex sensor (DUS)..... Detects a paper jam in the duplex section.
- 10. Eject sensor (ES)..... Detects a paper misfeed in the fuser or eject section.
- 11. Job paper full sensor (JPFS) Detects the paper full in the job separator tray.
- 12. Paper full sensor (PFS)..... Detects the paper full in the inner tray.
- 13. Paper sensor.1 (PS1) Detects the presence of paper in the cassette.

14. Paper sensor 2 (PS2) Detects the presence of paper in the cassette.
15. Lift sensor (LS)..... Detects activation of upper limit of the bottom plate.
16. Paper size width switch (PWSW)..... Detects the width of paper in the cassette.
17. Paper size length switch (PLSW) Detects the length of paper in the cassette.
18. ID shutter sensor (IDSS)..... Detects the position of the iD shutter.
19. ID sensor 1 (IDS1) Measurement of density of toner at calibration.
20. ID sensor 2 (IDS2) Measurement of density of toner at calibration.
21. Main power switch (MSW) Turns ON/OFF the AC power source.
22. Bridge detection switch (BRDSW) Detects the presence the bridge.
23. Job eject papersensor (JEPS) Detects the presence of paper in the job separator.
24. Temperature sensor (TEMS)..... Detects temperature and absolute humidity in machine.
25. Toner sensor Y (TS-Y) Detects the amount of toner remainder in the developing unit Y.
26. Toner sensor C (TS-C)..... Detects the amount of toner remainder in the developing unit C.
27. Toner sensor M (TS-M) Detects the amount of toner remainder in the developing unit M.
28. Toner sensor K (TS-K) Detects the amount of toner remainder in the developing unit K.
29. Fuser thermistor 1 (FTH1) Detects the heat roller temperature.(edge)
30. Fuser thermistor 2 (FTH2) Detects the heat roller temperature.(center)
31. Fuser thermistor 3 (FTH3) Detects the press roller temperature.
32. TC belt sensor 1 (TCBS1)..... Detects the position of the primary transfer belt.
33. TC belt sensor 2 (TCBS2)..... Detects the position of the primary transfer belt.
34. DP original size width sensor
(DPOWS)..... Detects the width of the original.
35. DP original sensor (DPOS)..... Detects the presence of an original.
36. DP original size length sensor
(DPOLS) Detects the length of the original.
37. DP paper feed sensor (DPPFS)..... Detects a paper misfeed.
38. DP registration sensor (DPRS) Controls the secondary paper feed start timing.
39. DP timing sensor (DPTS)..... Detects the original scanning timing.
40. DP open/close sensor (DPOCS)..... Detects the opening/closing of the DP.
41. DP switchback sensor (DPSBS) Detects the switchback guide in the home position.
42. DP interlock switch (DPILSW) Shuts off 24 V DC power line when the dp top cover is opened.
43. Fuser pre sensor (FUPS)..... Detects the JAM on this side of fuser.
44. Fuser roller rotation detection sensor
(FURDS) Detects the rotation of the fuser roller.
45. Waste toner sensor (WTS)..... Detects when the waste toner box is full.

(3) Motors





Figure 2-2-3 Motors

- 1. ISU motor (ISUM) Drives the ISU.
- 2. Fuser motor (FUM) Drives the fuser section.
- 3. Eject motor (EM) Drives the eject section.
- 4. Lift motor (LM)..... Operates the bottom plate.
- 5. Drum motor K (DRM-K) Drives the drum unit K.
- 6. Drum motor YCM (DRM-YCM) Drives the drum unit YCM.
- 7. Developer motor K (DEVM-K)..... Drives the developer unit K.
- 8. Developer motor YCM (DEVM-YCM) ... Drives the developer unit YCM.
- 9. Conveying motor (CM)..... Drives the paper feed section and conveying section.
- 10. Toner motor Y (TM-Y) Replenishes toner to the developer unit Y.
- 11. Toner motor C (TM-C) Replenishes toner to the developer unit C.
- 12. Toner motor M (TM-M) Replenishes toner to the developer unit M.
- 13. Toner motor K (TM-K) Replenishes toner to the developer unit K.



14. Polygon motor Y (PM-Y) Drives the polygon mirror Y.
15. Polygon motor C (PM-C)..... Drives the polygon mirror C.
16. Polygon motor M (PM-M)..... Drives the polygon mirror M.
17. Polygon motor K (PM-K)..... Drives the polygon mirror K.
18. Fuser press release motor (FPRM) Drives the pressure release system of the fuser.
19. Controller fan motor (CONFM)..... Cools the controller section.
20. Transfer belt motor (TCBM) Drives the transfer belt.
21. ID shutter motor (IDSM)..... Drives the ID sensor cleaning section.
22. LSU cleaning motor (LSUCM) Drives the LSU cleaning section.
23. IH fan motor (IJHFM) Cools the IH PWB.
24. Developer fan motor (DEVFM) Cools the developer section.
25. LSU fan motor (LSUFM) Cools the LSU section.
26. Power source fan motor (PSFM) Cools the power source PWB.
27. Fuser fan motor (FUFM) Cools the fuser and eject sections.
28. Container fan motor (CFM) Cools the toner container section.
29. IH coil fan motor (IHCFM)..... Cools the IH coil.
30. Imaging fan motor (IMGFM)..... Cools the imaging section.
31. DP paper feed motor (DPPFM)..... Drives the original feed section.
32. DP switchback motor (DPSBM)..... Drives the original switchback section.

(4) Others





Figure 2-2-4 Others

- 1. Paper feed clutch (PFCL) Controls the primary paper feed from cassette.
- 2. Mid clutch (MCL)..... Controls the paper conveying.
- 3. Registration clutch (RCL)..... Controls the secondary paper feed.
- 4. Duplex clutch (DUCL) Controls the drive of the duplex feed roller.
- 5. Developer stop clutch (DEVSCCL)..... Controls the drive of the developer.
- 6. MP solenoid (MPSOL) Controls the MP bottom plate.
- 7. Feedshift solenoid (FSSOL)..... Operates the feedshift guide.
- 8. Exposure lamp (EL) Exposes originals.
- 9. Cleaning lamp Y (CL-Y) Eliminates the residual electrostatic charge on the drum.
- 10. Cleaning lamp C (CL-C)..... Eliminates the residual electrostatic charge on the drum.
- 11. Cleaning lamp M (CL-M)..... Eliminates the residual electrostatic charge on the drum.
- 12. Cleaning lamp K (CL-K)..... Eliminates the residual electrostatic charge on the drum.
- 13. Fuser thermostat (FTS)..... Prevents overheating of the heat roller.
- 14. Cassette heater (CH)..... Dehumidifies the cassette section.



- 15. DP paper feed clutch (DPPFCL)..... Controls the drive of the DP forwarding pulley and DP paper feed roller.
- 16. DP registration clutch (DPRCL) Controls the secondary paper feed.

This page is intentionally left blank.

2-3-1 Main PWB




Figure 2-3-1 Main PWB silk-screen diagram

Connector	Pin	Signal	I/O	Voltage	Description
YC100 Connected to operation panel PWB main(USB)	1	VBUS	O	5 V DC	5 V DC power output
	2	DATA-	I/O	LVDS	USB data signal
	3	DATA+	I/O	LVDS	USB data signal
	4	ID	-	-	Not used
	5	SHIELD_GND	-	-	Ground
YC101 Connected to operation panel PWB main (control)	1	NC	-	-	Not used
	2	GND	-	-	Ground
	3	PANEL_STAT US	I	0/3.3 V DC	Operation panel status signal
	4	INT_POWER KEY	I	0/3.3 V DC	Power key: On/Off
	5	PANEL_RESE T	O	0/3.3 V DC	OPPWB-M reset signal
	6	AUDIO	O	Analog	Voice output signal
	7	LIGHTOFF_P OWER	O	0/3.3 V DC	Sleep return signal 1
	8	SHUTDOWN	O	0/3.3 V DC	24 V down signal
	9	LED_PROCE SSING	O	0/3.3 V DC	Processing LED control signal
	10	LED_ATTENT ION	O	0/3.3 V DC	Attention LED control signal
	11	LED_MEMOR Y	O	0/3.3 V DC	Memory LED control signal
	12	SUSPEND_P ower	O	5 V DC	5 V DC power output to OPPWB-M
	13	ENERGY_SA VE	O	0/3.3 V DC	Energy save signal
	14	BEEP_POWE RON	O	0/3.3 V DC	Sleep return signal 0
YC102 Connected to operation panel PWB main(power source)	1	5V2	O	5 V DC	5 V DC power output to OPPWB-M
	2	5V2	O	5 V DC	5 V DC power output to OPPWB-M
	3	GND	-	-	Ground
	4	GND	-	-	Ground

Connector	Pin	Signal	I/O	Voltage	Description
YC104 Connected to LSU connect PWB	1	VDN(K)	O	LVDS	Video data signal (-)
	2	VDP(K)	O	LVDS	Video data signal (+)
	3	SH(K)	O	0/3.3 V DC	Sample/hold signal
	4	BD(K)	I	0/3.3 V DC(pulse)	Horizontal synchronizing signal
	5	SGND	-	-	Ground
	6	VDN(M)	O	LVDS	Video data signal (-)
	7	VDP(M)	O	LVDS	Video data signal (+)
	8	SH(M)	O	0/3.3 V DC	Sample/hold signal
	9	BD(M)	I	0/3.3 V DC(pulse)	Horizontal synchronizing signal
	10	SGND	-	-	Ground
	11	VDN(C)	O	LVDS	Video data signal (-)
	12	VDP(C)	O	LVDS	Video data signal (+)
	13	SH(C)	O	0/3.3 V DC	Sample/hold signal
	14	BD(C)	I	0/3.3 V DC(pulse)	Horizontal synchronizing signal
	15	SGND	-	-	Ground
YC105 Connected to engine PWB	1	SLEEPOFF	I	0/3.3 V DC	Sleep Off signal
	2	ENG_HLD	O	0/3.3 V DC	Engine hold signal
	3	SCAN_HLD	O	0/3.3 V DC	Scan hold signal
	4	LIGHTSLEEP N	O	0/3.3 V DC	Light sleep shift signal
	5	24V4	I	24 V DC	24 V DC power input from EPWB
	6	24V4	I	24 V DC	24 V DC power input from EPWB
	7	5V4	I	5 V DC	5 V DC power input from EPWB
	8	3.3V0	I	3.3 V DC	3.3 V DC power input from EPWB
	9	3.3V4	I	3.3 V DC	3.3 V DC power input from EPWB
	10	3.3V4	I	3.3 V DC	3.3 V DC power input from EPWB
	11	24VDOWN	I	0/3.3 V DC	24 V down signal
	12	GND	-	-	Ground
	13	GND	-	-	Ground
	14	GND	-	-	Ground
	15	GND	-	-	Ground
	16	GND	-	-	Ground
	17	HYP_SCL	I	0/3.3 V DC(pulse)	Clock signal
	18	HYP_SDA	I	0/3.3 V DC(pulse)	Data signal
	19	HYP_INT	O	0/3.3 V DC	Interrupt signal
	20	AQUA_CLK	I	0/3.3 V DC(pulse)	Clock signal
	21	AQUA_SO	O	0/3.3 V DC(pulse)	Serial communication data signal output
	22	AQUA_SI	I	0/3.3 V DC(pulse)	Serial communication data signal input

Connector	Pin	Signal	I/O	Voltage	Description
YC105 Connected to engine PWB	23	AQUA_SEL	I	0/3.3 V DC	Select signal
	24	AQUA_RDY	O	0/3.3 V DC	Ready signal
	25	PVSYNC	I	0/3.3 V DC(pulse)	Vertical synchronizing signal
	26	OVSYNCMON	O	0/3.3 V DC	Sub-scanning monitor signal
	27	PAGEST	I	0/3.3 V DC	Sub-scanning standard signal
	28	EME_CLK	O	0/3.3 V DC(pulse)	Clock signal
	29	EME_SO	O	0/3.3 V DC(pulse)	Serial communication data signal output
	30	EME_SI	I	0/3.3 V DC(pulse)	Serial communication data signal input
	31	EME_BSY	I	0/3.3 V DC	Busy signal
	32	EME_DIR	I	0/3.3 V DC	Communication direction change signal
	33	EME_IRN	I	0/3.3 V DC	Interrupt signal
	34	5V4IL	-	DC5 V	5 V DC power input from EPWB
	35	BDN(K)	O	0/3.3 V DC(pulse)	Horizontal synchronizing signal (K)
	36	BDN(M)	I	0/3.3 V DC(pulse)	Horizontal synchronizing signal (M)
	37	BDN(C)	I	0/3.3 V DC(pulse)	Horizontal synchronizing signal (C)
38	BDN(Y)	-	0/3.3 V DC(pulse)	Horizontal synchronizing signal (Y)	
YC107 Connected to USB-HOST	1	VBUS	O	5 V DC	5 V DC power output
	2	DATA-	I/O	LVDS	USB data signal
	3	DATA+	I/O	LVDS	USB data signal
	4	ID	-	-	Not used
	5	SHIELD_GND	-	-	Ground
YC112 Connected to exposure lamp (LED PWB)	1	+24V4	O	24 V DC	24 V DC power output to LEDPWB
	2	+24V4	O	24 V DC	24 V DC power output to LEDPWB
	3	POW	O	0/3.3 V DC	LED driver: On/Off
	4	PWM	O	0/3.3 V DC	PWM signal
	5	PGND	-	-	Ground
	6	SGND	-	-	Ground
	7	VSET	O	Analog	Analog voltage
	8	SCL	O	0/3.3 V DC(pulse)	Clock signal
	9	SDA	I/O	0/3.3 V DC(pulse)	Data signal
	10	FAIL	I	0/3.3 V DC	Error signal
	11	5V4	O	5 V DC	5 V DC power output to LEDPWB

Connector	Pin	Signal	I/O	Voltage	Description
YC113 Connected to CCD PWB	1	CCDPWR	O	12 V DC	12 V DC power output to CCDPWB
	2	CCDPWR	O	12 V DC	12 V DC power output to CCDPWB
	3	+5V4	O	5 V DC	5 V DC power output to CCDPWB
	4	+5V4	O	5 V DC	5 V DC power output to CCDPWB
	5	+5V4	O	5 V DC	5 V DC power output to CCDPWB
	6	+3.3V4	O	3.3 V DC	3.3 V DC power output to CCDPWB
	7	CCD_SH	O	0/3.3 V DC	Shift gate signal
	8	GND	-	-	Ground
	9	RS	O	0/3.3 V DC	Reset signal
	10	GND	-	-	Ground
	11	CP	O	0/3.3 V DC	Clamping signal
	12	GND	-	-	Ground
	13	CCDCLK1	O	0/3.3 V DC(pulse)	Clock signal
	14	GND	-	-	Ground
	15	OS1(B)	I	Analog	CCD Image output signal(B)
	16	GND	-	-	Ground
	17	OS2(G)	I	Analog	CCD Image output signal(G)
	18	GND	-	-	Ground
	19	OS3(R)	I	Analog	CCD Image output signal(R)
YC115 Connected to power source PWB	1	DEEPSLEEP N	O	0/3.3 V DC	Sleep signal: On/Off
	2	GND	-	-	Ground
	3	GND	-	-	Ground
	4	GND	-	-	Ground
	5	GND	-	-	Ground
	6	GND	-	-	Ground
	7	GND	-	-	Ground
	8	GND	-	-	Ground
	9	5V2	I	5 V DC	5 V DC power input from PSPWB
	10	5V2	I	5 V DC	5 V DC power input from PSPWB
	11	5V2	I	5 V DC	5 V DC power input from PSPWB
	12	5V2	I	5 V DC	5 V DC power input from PSPWB
	13	5V2	I	5 V DC	5 V DC power input from PSPWB
	14	5V2	I	5 V DC	5 V DC power input from PSPWB
	15	5V2	I	5 V DC	5 V DC power input from PSPWB

Connector	Pin	Signal	I/O	Voltage	Description
YC118 Connected to main switch, power source PWB sub	1	5V0	O	5 V DC	5 V DC power output to MSW
	2	AUTODOWN	O	0/3.3 V DC	Auto down signal
	3	GND	-	-	Ground
	4	5V0	I	5 V DC	5 V DC power input from PSPWB-S
YC41 Connected to controller fan motor	1	+24V1	O	24 V DC	24 V DC power output to CONFM
	2	CONFANDR N	O	0/24 V DC	CONFM: On/Off
	3	N.C.	-	-	Not used

2-3-2 Engine PWB




Figure 2-3-2 Engine PWB silk-screen diagram

Connector	Pin	Signal	I/O	Voltage	Description
YC1 Connected to power source PWB	1	GND	-	-	GROUND
	2	GND	-	-	GROUND
	3	GND	-	-	GROUND
	4	24V2	O	24 V DC	24 V DC power input from PSPWB
	5	24V2	O	24 V DC	24 V DC power input from PSPWB
	6	24V2	O	24 V DC	24 V DC power input from PSPWB
YC2 Connected to MP solenoid, duplex clutch, registration clutch, mid clutch, feed clutch, conveying motor	1	24V4	O	24 V DC	24 V DC power output to MPSOL
	2	MPF_SOL_R EM	O	0/24 V DC	MPSOL: On/Off
	3	DU_CL_REM	O	0/24 V DC	DUCL: On/Off
	4	24V4	O	24 V DC	24 V DC power output to DUCL
	5	REG_CL_RE M	O	0/24 V DC	RCL: On/Off
	6	24V4	O	24 V DC	24 V DC power output to RCL
	7	MID_CL_REM	O	0/24 V DC	MCL: On/Off
	8	24V4	O	24 V DC	24 V DC power output to MCL
	9	CAS_CL_RE M	O	0/24 V DC	PFCL: On/Off
	10	24V4	O	24 V DC	24 V DC power output to PFCL
	11	FEED_MT_DI R	O	0/5 V DC	CM drive shift signal
	12	FEED_MT_R DY	I	0/3.3 V DC	CM ready signal
	13	FEED_MT_CL K	O	0/5 V DC (pulse)	CM clock signal
	14	FEED_MT_R EM	O	0/5 V DC	CM: On/Off
	15	GND	-	-	GROUND
	16	24VIL	O	24 V DC	24 V DC power output to CM

Connector	Pin	Signal	I/O	Voltage	Description
YC3	1	DLPC_MT_DI R	O	0/5V DC	DEVM-YCM drive shift signal
Connected to developer motor YCM, developer stop clutch, drum motor YCM, drum motor K	2	DLPC_MT_R DY	I	0/3.3 V DC	DEVM-YCM ready signal
	3	DLPC_MT_CL K	O	0/5 V DC (pulse)	DEVM-YCM clock signal
	4	DLPC_MT_R EM	O	0/5 V DC	DEVM-YCM: On/Off
	5	GND	-	-	GROUND
	6	24V4	O	24 V DC	24 V DC power output to DEVM-YCM
	7	24V4	O	24 V DC	24 V DC power output to DEVSCL
	8	DLP_CL_REM	O	0/3.3 V DC	DEVSCL: On/Off
	9	DRMC_MT_DI R	O	0/5 V DC	DRM-YCM drive shift signal
	10	DRMC_MT_R DY	I	0/3.3 V DC	DRM-YCM ready signal
	11	DRMC_MT_C LK	O	0/5 V DC (pulse)	DRM-YCM clock signal
	12	DRMC_MT_R EM	O	0/5 V DC	DRM-YCM: On/Off
	13	GND	-	-	GROUND
	14	24VIL	O	24 V DC	24 V DC power output to DRM-YCM
	15	DRMK_MT_DI R	O	0/5 V DC	DRM-K drive shift signal
	16	DRMK_MT_R DY	I	0/3.3 V DC	DRM-K ready signal
	17	DRMK_MT_C LK	O	0/5 V DC (pulse)	DRM-K clock signal
	18	DRMK_MT_R EM	O	0/5 V DC	DRM-K: On/Off
	19	GND	-	-	GROUND
	20	24VIL	O	24 V DC	24 V DC power output to DRM-K

Connector	Pin	Signal	I/O	Voltage	Description
YC4 Connected to developer motor K, fuser motor	1	DLPK_MT_DIR	O	0/5 V DC	DEVM-K drive shift signal
	2	DLPK_MT_RDY	I	0/3.3 V DC	DEVM-K ready signal
	3	DLPK_MT_CLK	O	0/5 V DC (pulse)	DEVM-K clock signal
	4	DLPK_MT_REM	O	0/5 V DC	DEVM-K: On/Off
	5	GND	-	-	GROUND
	6	24VIL	O	24 V DC	24 V DC power output to DEVM-K
	7	FUSER_MT_DIR	O	0/5 V DC	FUM drive shift signal
	8	FUSER_MT_RDY	I	0/3.3 V DC	FUM ready signal
	9	FUSER_MT_CLK	O	0/5 V DC (pulse)	FUM clock signal
	10	FUSER_MT_REM	O	0/5 V DC	FUM: On/Off
	11	GND	-	-	GROUND
	12	24VIL	O	24 V DC	24 V DC power output to FUM
YC5 Connected to duplex sensor, MP paper sensor, feed sensor	1	3.3V4	O	3.3 V DC	3.3 V DC power output to DUS
	2	GND	-	-	GROUND
	3	DUSW	I	0/3.3 V DC	DUS: On/Off
	4	GND	-	-	GROUND
	5	ROOP	-	-	FUPS: On/Off
	6	5V4	-	5 V DC	5 V DC power output to FUPS
	7	3.3V0	O	3.3 V DC	3.3 V DC power output to MPPS
	8	GND	-	-	GROUND
	9	MPF_SENSE	I	0/3.3 V DC	MPPS: On/Off
	10	3.3V4	O	3.3 V DC	3.3 V DC power output to FS
	11	GND	-	-	GROUND
	12	FEEDSW	I	0/3.3 V DC	FS: On/Off
YC6 Connected to sub PWB	1	SUB_SCL	O	3.3 V DC	Clock signal
	2	SUB_SDA	I/O	3.3 V DC	Data signal
	3	GND	-	-	GROUND
	4	3.3V4	O	3.3 V DC	3.3 V DC power output to SPW

Connector	Pin	Signal	I/O	Voltage	Description
YC7 Connected to IH PWB	1	RXD	I	3.3 V DC	Data input
	2	TXD	O	3.3 V DC	Data output
	3	ROTATION	O	3.3 V DC	Rotation detection
	4	IH_REM	O	3.3 V DC	Heater remote
	5	3.3V4			
	6	GND			
YC8 Connected to toner motor Y/C/M/K	1	24V4	O	24 V DC	24 V DC power output to TM-Y
	2	TNMYDRN	O	0/24 V DC	TM-Y: On/Off
	3	24V4	O	24 V DC	24 V DC power output to TM-C
	4	TNMCDRN	O	0/24 V DC	TM-C: On/Off
	5	24V4	O	24 V DC	24 V DC power output to TM-M
	6	TNMMDRN	O	0/24 V DC	TM-M: On/Off
	7	24V4	O	24 V DC	24 V DC power output to TM-K
	8	TNMKDRN	O	0/24 V DC	TM-K: On/Off
YC9 Connected to engine con- nect PWB	1	GND	-	-	GROUND
	2	GND	-	-	GROUND
	3	GND	-	-	GROUND
	4	ID2S	I	Analog	IDS2 detection signal
	5	ID2P	I	Analog	IDS2 detection signal
	6	ID1S	I	Analog	IDS1 detection signal
	7	ID1P	I	Analog	IDS1 detection signal
	8	LEDREF2	O	Analog	IDS2 control signal
	9	LEDREF1	O	Analog	IDS1 control signal
	10	RESIST	I	0/3.3 V DC	RS: On/Off
	11	NC	-	-	Not used
	12	PAPWSIZE1	I	0/3.3 V DC	PWSW: On/Off
	13	PAPLSIZE1	I	0/3.3 V DC	PLSW: On/Off
	14	PAPLSIZE2	I	0/3.3 V DC	PLSW: On/Off
	15	PAPLSIZE3	I	0/3.3 V DC	PLSW: On/Off
	16	LMOTOC	I	0/3.3 V DC	LM detection signal
	17	LMOTRE	O	0/3.3 V DC	LM: On/Off
	18	PAPEMP2	I	0/3.3 V DC	PS2: On/Off
	19	PAPEMP1	I	0/3.3 V DC	PS1: On/Off
	20	LIFTFULL	I	0/3.3 V DC	LS: On/Off
	21	FANHALF	O	0/3.3 V DC	FM drive shift signal
	22	FANBFULL	O	0/3.3 V DC	FM: On/Off

Connector	Pin	Signal	I/O	Voltage	Description
YC9	23	LIGHTSLEEP N	O	0/3.3 V DC	Sleep signal: On/Off
Connected to engine con- nect PWB	24	PFPAUSE	O	0/3.3 V DC	Paper feeder control signal
	25	PFSET	O	0/3.3 V DC	Paper feeder sleep return signal
	26	DFSET	O	0/3.3 V DC	Finisher set signal
	27	DFSEL	O	0/3.3 V DC	Finisher selection signal
	28	BRSEL	O	0/3.3 V DC	Bridge selection signal
	29	PFSEL	O	0/3.3 V DC	Paper feed selection signal
	30	EHRDY	I	0/3.3 V DC	Ready signal
	31	EHSO	O	0/3.3 V DC (pulse)	Serial communication data signal
	32	EHSI	I	0/3.3 V DC (pulse)	Serial communication data signal
	33	EHCLK	O	0/3.3 V DC (pulse)	Clock signal
	34	FANCHALF	O	0/3.3 V DC	FM drive shift signal
	35	FANCFULL	O	0/3.3 V DC	FM: On/Off
	36	NC	-	-	Not used
	37	ERASER_RE M(K)	O	0/24 V DC	CL-K: On/Off
	38	DLP_TH	I	Analog	DEVTH detection voltege
	39	TCSENSE(K)	I	0/3.3 V DC	TS-K: On/Off
	40	TCSENSE(M)	I	0/3.3 V DC	TS-M: On/Off
	41	TCSENSE(C)	I	0/3.3 V DC	TS-C: On/Off
	42	ERASER_RE M(COL)	O	0/3.3 V DC	CL-YCM: On/Off
	43	TCSENSE(Y)	I	0/3.3 V DC	TS-Y: On/Off
	44	GND	-	-	GROUND
	45	SDAC		0/3.3 V DC	Data
	46	GND	-	-	GROUND
	47	SCLC		0/3.3 V DC	Clock signal
	48	GND	-	-	GROUND
	49	SDAA		0/3.3 V DC	Data
	50	GND	-	-	GROUND
	51	SCLA		0/3.3 V DC	Clock signal
	52	GND	-	-	GROUND
	53	BLTHP2	I	0/3.3 V DC	BDS2: On/Off
	54	BLTHP1	I	0/3.3 V DC	BDS1: On/Off
	55	WTCFULLIN	I	Analog	WTDS detection voltage
	56	WTCFULLOU T	O	0/3.3 V DC	WTDS: On/Off

Connector	Pin	Signal	I/O	Voltage	Description
YC9 Connected to engine connect PWB	57	IDCLHP	I	0/3.3 V DC	IDS: On/Off
	58	3.3V0	O	3.3 V DC	3.3 V DC power output to ECPWB
	59	3.3V4	O	3.3 V DC	3.3 V DC power output to ECPWB
	60	3.3V4	O	3.3 V DC	3.3 V DC power output to ECPWB
YC10 Connected to engine connect PWB	1	IDMOTA	O	24 V DC	IDS: On/Off
	2	IDMOTB	O	24 V DC	IDS: On/Off
	3	BLTREMA	O	24 V DC	TCBM: On/Off
	4	BLTREMB	O	24 V DC	TCBM: On/Off
YC11 Connected to RFID PWB	1	3.3V4	O	3.3 V DC	3.3 V DC power output to RFPWB
	2	RFID_SCL	O	0/3.3 V DC (pulse)	RFPWB EEPROM clock signal
	3	RFID_SDA	I/O	0/3.3 V DC (pulse)	RFPWB EEPROM data signal
	4	GND	-	-	GROUND
YC12 Connected to LSU connect PWB	B1	LSUMOTB	O	0/24 V DC	LSUCM: Forward/Stop (Forward)
	B2	LSUMOTA	O	0/24 V DC	LSUCM: Forward/Stop (Reverse)
	B3	MP(K)_REM	O	0/3.3 V DC	PM: On/Off
	B4	24V4	O	24 V DC	24 V DC power output to PM
	B5	MP(K)_RDY	I	0/3.3 V DC	PM ready signal
	B6	MP(M)_REM	O	0/3.3 V DC	PM: On/Off
	B7	MP(C)_REM	O	0/3.3 V DC	PM: On/Off
	B8	MP(C)_RDY	I	0/3.3 V DC	PM ready signal
	B9	VCONT(K)	O	Analog	APCPWB laser power standard voltage
	B10	MP(Y)_RDY	I	0/3.3 V DC	PM ready signal
	B11	VCONT(M)	O	Analog	APCPWB laser power standard voltage
	B12	LSU_TH(Y)	I	Analog	LSU thermistor signal
	B13	VCONT(Y)	O	Analog	APCPWB laser power standard voltage
	B14	GND	-	-	GROUND
	B15	VCONT(C)	O	Analog	APCPWB laser power standard voltage
	A1	3.3VIL	O	3.3 V DC	3.3 V DC power output to BDPWB
	A2	GND	-	-	GROUND
	A3	LSU_TH(K)	I	Analog	LSU thermistor signal
	A4	EN(K)	O	0/3.3 V DC	APCPWB laser enable signal
	A5	EN?COL)	O	0/3.3 V DC	APCPWB laser enable signal
	A6	MP(Y)_CLK	O	0/3.3 V DC (pulse)	PM clock signal
A7	MP(Y)_REM	O	0/3.3 V DC	PM: On/Off	

Connector	Pin	Signal	I/O	Voltage	Description
YC12 Connected to LSU connect PWB	A8	MP(C)_CLK	O	0/3.3 V DC (pulse)	PM clock signal
	A9	MP(M)_RDY	I	0/3.3 V DC	PM ready signal
	A10	MP(M)_CLK	O	0/3.3 V DC (pulse)	PM clock signal
	A11	MP(K)_CLK	O	0/3.3 V DC (pulse)	PM clock signal
	A12	GND	-	-	GROUND
	A13	24V4	O	24 V DC	24 V DC power output to PM
	A14	GND	-	-	GROUND
	A15	24V4	O	24 V DC	24 V DC power output to PM
YC13 Connected to high voltage PWB sub	1	GND	-	-	GROUND
	2	T1KCNT	O	PWM	Primary transfer bias control voltage (Black)
	3	T1MCNT	O	PWM	Primary transfer bias control voltage (Magenta)
	4	CLCNT	O	PWM	Cleaning bias control signal
	5	HVREM	O	0/3.3 V DC (pulse)	Transfer bias remote signal
	6	T1YCNT	O	PWM	Primary transfer bias control voltage (Yellow)
	7	T1CCNT	O	PWM	Primary transfer bias control voltage (Cyan)
	8	24VIL	O	24 V DC	24 V DC power output to HVPWB-S
YC14 Connected to bridge detec- tion switch	1	BRSET	I	0/3.3 V DC	BRDSW: On/Off
	2	GND	-	-	GROUND
YC15 Connected to high voltage PWB	B1	GND	-	-	GROUND
	B2	GND	-	-	GROUND
	B3	SCNT	O	PWM	Separation control signal
	B4	T2CNT	O	PWM	Secondary transfer bias control voltage
	B5	MISENS	I	Analog	Chager roller AC current signal
	B6	HVREM	O	0/3.3 V DC (pulse)	Developing bias remote signal
	B7	BKSCNT	O	PWM	Developing sleeve roller bias control voltage (Black)
	B8	BMMCNT	O	PWM	Developing magnet roller bias control voltage (Magenta)
	B9	BKMCNT	O	PWM	Developing magnet roller bias control voltage (Black)
	B10	BMSCNT	O	PWM	Developing sleeve roller bias control voltage (Magenta)

Connector	Pin	Signal	I/O	Voltage	Description
YC15 Connected to high voltage PWB	B11	MKCNT	O	PWM	Chager roller control voltage (Black)
	B12	MMCNT	O	PWM	Chager roller control voltage (Magenta)
	B13	BKBACCNT	O	PWM	Developing AC bias control voltage (Black)
	B14	HVCLKK	O	0/3.3 V DC (pulse)	Developing bias clock signal (Black)
	B15	HVCLKM	O	0/3.3 V DC (pulse)	Developing bias clock signal (Magenta)
	B16	24VIL	O	24 V DC	24 V DC power output to HVPWB
	B17	24VIL	O	24 V DC	24 V DC power output to HVPWB
	A1	CBACCNT	O	PWM	Developing AC bias control voltage (Cyan)
	A2	MBACCNT	O	PWM	Developing AC bias control voltage (Magenta)
	A3	MCCNT	O	PWM	Chager roller control voltage (Cyan)
	A4	HVCLKC	O	0/3.3 V DC (pulse)	Developing bias clock signal (Cyan)
	A5	BCSCNT	O	PWM	Developing sleeve roller bias control voltage (Cyan)
	A6	BYMCNT	O	PWM	Developing magnet roller bias control voltage (Yellow)
	A7	BCMCNT	O	PWM	Developing magnet roller bias control voltage (Cyan)
	A8	BYSCNT	O	PWM	Developing sleeve roller bias control voltage (Yellow)
	A9	MYCNT	O	PWM	Chager roller control voltage (Yellow)
	A10	YBACCNT	O	PWM	Developing AC bias control voltage (Yellow)
A11	HVCLKY	O	0/3.3 V DC (pulse)	Developing bias clock signal (Yellow)	
A12	NC	-	-	Not used	
A13	NC	-	-	Not used	
A14	NC	-	-	Not used	
A15	NC	-	-	Not used	
A16	NC	-	-	Not used	
A17	NC	-	-	Not used	


Connector	Pin	Signal	I/O	Voltage	Description
YC17 Connected to ISU motor, home position sensor, original detection switch, original size sensor	1	SCANNER B1	O	0/24 V DC	ISUM drive controll signal
	2	SCANNER A2	O	0/24 V DC	ISUM drive controll signal
	3	SCANNER B2	O	0/24 V DC	ISUM drive controll signal
	4	SCANNER A1	O	0/24 V DC	ISUM drive controll signal
	5	3.3V4	O	3.3 V DC	3.3 V DC power output to HPS
	6	GND	-	-	GROUND
	7	SCA_HP	I	0/3.3 V DC	HPS: On/Off
	8	3.3V4	O	3.3 V DC	3.3 V DC power output to ODSW
	9	GND	-	-	GROUND
	10	SCA_COVER	I	0/3.3 V DC	ODSW: On/Off
	11	GND	-	-	GROUND
	12	SCA_SIZE	I	0/3.3 V DC	OSS: On/Off
	13	5V4	O	5 V DC	5 V DC power output to OSS
YC18 Connected to document processor	1	GND	-	-	GROUND
	2	GND	-	-	GROUND
	3	24V4	O	24 V DC	24 V DC power output to DP
	4	24V4	O	24 V DC	24 V DC power output to DP
	5	DP_CLK	O	0/3.3 V DC (pulse)	DP clock signal
	6	DP_SO	O	0/3.3 V DC (pulse)	Serial communication data signal
	7	DP_SEL	O	0/3.3 V DC	DP select signal
	8	DP_SI	I	0/3.3 V DC (pulse)	Serial communication data signal
	9	DP_RDY	I	0/3.3 V DC	DP ready signal
	10	DP_TMG	I	0/3.3 V DC	DPTS: On/Off
	11	DP_OPEN	I	0/3.3 V DC	DPOCS: On/Off
YC19 Connected to IH PWB	1	GND	-	-	GROUND
	2	RELAY	O	3.3 V DC	Relay remote
	3	24V4	O	24 V DC	24 V DC power output to IHPWB
YC20 Connected to shift solenoid, eject motor, paper full sensor, job paper full sensor	1	EJE_SOL_RE TURN	O	0/24 V DC	FSSOL: On/Off
	2	24V4	O	24 V DC	24 V DC power output to FSSOL
	3	EJECT_/B	O	0/24 V DC (pluse)	EM drive control signal
	4	EJECT_/A	O	0/24 V DC (pluse)	EM drive control signal
	5	EJECT_B	O	0/24 V DC (pluse)	EM drive control signal
	6	EJECT_A	O	0/24 V DC (pluse)	EM drive control signal
	7	3.3V4	O	3.3 V DC	3.3 V DC power output to PFS
	8	GND	-	-	GROUND

Connector	Pin	Signal	I/O	Voltage	Description
YC20 Connected to shift solenoid, eject motor, paper full sensor, job paper full sensor	9	EJE_FULL_UP	I	0/3.3 V DC	PFS: On/Off
	10	3.3V4	O	3.3 V DC	3.3 V DC power output to JEPS
	11	GND	-	-	GROUND
	12	EJE_FULL_DWN	I	0/3.3 V DC	JEPS: On/Off
YC21 Connected to IH coil fan motor, developer fan motor, container fan motor	1	IH_FAN2_REM	O	0/24 V DC	IHCFM: On/Off
	2	GND	-	-	GROUND
	3	IH_FAN2_ALM	I	0/3.3 V DC	IHCFM alarm signal
	4	DLP_FAN_REM	O	0/24 V DC	DEVFM: On/Off
	5	GND	-	-	GROUND
	6	CON_FAN_REM	O	0/24 V DC	TCFM: On/Off
	7	GND	-	-	GROUND
YC22 Connected to thermistor1, thermistor2, eject sensor, fuser press release motor	1	FUSREMA	O	0/24 V DC	PRM: On/Off
	2	FUSREMB	O	24 V DC	3.3 V DC power output to PRM
	3	3.3V4	O	3.3 V DC	3.3 V DC power output to ES
	4	GND	-	-	GROUND
	5	FUSER_JAM	I	0/3.3 V DC	ES: On/Off
	6	3.3V4	-	-	Not used
	7	GND	-	-	Not used
	8	FUSER_PRE	-	-	Not used
	9	SUBSDA	I/O	3.3 V DC	Data
	10	SUBSCL	O	3.3 V DC	Clock
	11	PR_TH	I	Analog	FTH detection voltage (Press roller)
	12	HR_NCTH1	I	Analog	FTH detection voltage (Center)
	13	HR_NCTH2	I	Analog	FTH detection voltage (Center)
	14	3.3V4	O	3.3 V DC	3.3 V DC power output to FTH
	15	EG_TH	I	Analog	FTH detection voltage (Edge)
	16	GND	-	-	GROUND
	17	ROTATION	I	3.3 V DC	Rotation detection

Connector	Pin	Signal	I/O	Voltage	Description	
YC24	1	IH_FAN1_RE M	O	0/24 V DC	IHFM: On/Off	
	Connected to IH fan motor	2	GND	-	-	GROUND
		3	IH_FAN1_AL M	I	0/3.3 V DC	IHFM alarm signal
YC25	1	24VIL2	I	24 V DC	24 V DC power input from RCSW	
	Connected to right cover switch, front cover switch	2	24VIL1	O	24 V DC	24 V DC power output to RCSW
		3	24VIL1	O	24 V DC	24 V DC power output to FCSW
		4	24V4	I	24 V DC	24 V DC power input from FCSW
		5	3.3V0	O	3.3 V DC	3.3 V DC power output to FCSW
YC26	1	BDY	O	0/3.3 V DC (pulse)	Horizontal synchronizing signal (Yellow)	
	Connected to main PWB	2	BDC	O	0/3.3 V DC (pulse)	Horizontal synchronizing signal (Cyan)
		3	BDM	O	0/3.3 V DC (pulse)	Horizontal synchronizing signal (Magenta)
		4	BDBK	O	0/3.3 V DC (pulse)	Horizontal synchronizing signal (Black)
		5	NC	-	-	Not used
		6	EME_IRN	O	0/3.3 V DC	Interruption signal
		7	EME_DIR	O	0/3.3 V DC	Communication direction change signal
		8	EME_BSY	O	0/3.3 V DC	Busy signal
		9	EME_SO	I	0/3.3 V DC (pulse)	Serial communication data signal input
		10	EME_SI	O	0/3.3 V DC (pulse)	Serial communication data signal output
		11	EME_CLK	I	0/3.3 V DC (pulse)	Clock signal
		12	PAGEST	O	0/3.3 V DC	Sub-scanning standard signal
		13	OVSYNCMON	I	0/3.3 V DC	Sub-scanning monitor signal
		14	PVSYNC	O	0/3.3 V DC (pulse)	Vertical synchronizing signal
		15	AQUA_RDY	I	0/3.3 V DC	Ready signal
		16	AQUA_SEL	O	0/3.3 V DC	Select signal
		17	AQUA_SO	I	0/3.3 V DC (pulse)	Serial communication data signal input
		18	AQUA_SI	O	0/3.3 V DC (pulse)	Serial communication data signal output
		19	AQUA_CLK	O	0/3.3 V DC (pulse)	Clock signal
		20	HYP_INT	I	0/3.3 V DC	Interruption signal
		21	HYP_SDA	O	0/3.3 V DC (pulse)	Data signal
		22	HYP_SCL	O	0/3.3 V DC (pulse)	Clock signal
		23	GND	-	-	GROUND
		24	GND	-	-	GROUND
		25	GND	-	-	GROUND
		26	GND	-	-	GROUND

Connector	Pin	Signal	I/O	Voltage	Description
YC26	27	GND	-	-	GROUND
Connected to main PWB	28	24VDOWN	I	24 V DC	24 V DC down signal
	29	3.3V4	O	0/3.3 V DC	3.3 V DC power output to MPWB
	30	3.3V4	O	0/3.3 V DC	3.3 V DC power output to MPWB
	31	3.3V0	O	0/3.3 V DC	3.3 V DC power output to MPWB
	32	5V4	O	5 V DC	5 V DC power output to MPWB
	33	24V4	O	24 V DC	24 V DC power output to MPWB
	34	24V4	O	24 V DC	24 V DC power output to MPWB
	35	LIGHT_SLEEP PN	I	0/3.3 V DC	Light sleep shift signal
	36	SCAN_HLD	I	0/3.3 V DC	Scan hold signal
	37	ENG_HLD	I	0/3.3 V DC	Engine hold signal
	38	SLEEPOFF	O	0/3.3 V DC	Sleep return signal
YC28	1	FUSER_FAN_ REM	O	0/24 V DC	FUFM1: On/Off
Connected to fuser fan motor	2	GND	-	-	GROUND
	3	FUSER_FAN_ REM	O	0/24 V DC	FUFM2: On/Off
	4	GND	-	-	GROUND
YC29	1	GND	-	-	GROUND
Connected to temperature sensor	2	TMPDATA	I	Analog	TEMS detection voltage (Temperature)
	3	WETCLK0	O	0/3.3 V DC (pulse)	TEMS clock signal
	4	WETCLK1	O	0/3.3 V DC (pulse)	TEMS clock signal
	5	HUMDATA	I	Analog	TEMS detection voltage (Humidity)

2-3-3 Power source PWB



TO

www.tonerplus.com.ua

Figure 2-3-3 Main PWB silk-screen diagram

Connector	Pin	Signal	I/O	Voltage	Description
TB Connected to AC inlet, main switch	TB1	LIVE	I	100 V AC	AC power input
	TB2	NEUTRAL	I	100 V AC	AC power input
	TB3	LIVE(SW)	O	100 V AC	AC power output to MSW
	TB4	LIVE(SW)	I	100 V AC	AC power input from MSW
YC2 Connected to cassette heater switch	1	CH_SW IN	O	100 V AC	AC power output to CHSW
	2	NC	-	-	Not used
	3	CH_SW OUT	I	100 V AC	AC power input from CHSW
YC3 Connected to paper feeder, cassette heater	1	LIVE	O	100 V AC	AC power output to PFCH
	2	LIVE	O	100 V AC	AC power output to CH
	3	NC	-	-	Not used
	4	NC	-	-	Not used
	5	NEUTRAL	O	100 V AC	AC power output to PFCH
	6	NEUTRAL	O	100 V AC	AC power output to CH
YC4 Connected to IH PWB	1	LIVE	O	100 V AC	AC power output to IHPWB
	2	NEUTRAL	O	100 V AC	AC power output to IHPWB
YC5 Connected to power source PWB sub	1	LIVE	O	100 V AC	AC power output to PSPWB-S
	2	NC	-	-	Not used
	3	NEUTRAL	O	100 V AC	AC power output to PSPWB-S
YC6 Connected to AC outlet	1	LIVE	O	100 V AC	Option AC power output
	2	NC	-	-	Not used
	3	NC	-	-	Not used
	4	NEUTRAL	O	100 V AC	Option AC power output

Connector	Pin	Signal	I/O	Voltage	Description
YC7 Connected to main PWB	1	+5V2	O	5 V DC	5 V DC power output to MPWB
	2	+5V2	O	5 V DC	5 V DC power output to MPWB
	3	+5V2	O	5 V DC	5 V DC power output to MPWB
	4	+5V2	O	5 V DC	5 V DC power output to MPWB
	5	+5V2	O	5 V DC	5 V DC power output to MPWB
	6	+5V2	O	5 V DC	5 V DC power output to MPWB
	7	+5V2	O	5 V DC	5 V DC power output to MPWB
	8	GND	-	-	GROUND
	9	GND	-	-	GROUND
	10	GND	-	-	GROUND
	11	GND	-	-	GROUND
	12	GND	-	-	GROUND
	13	GND	-	-	GROUND
	14	GND	-	-	GROUND
	15	SLEEP1	I	0/3.3 V DC	Sleep 1 control signal: On/Off
YC8 Connected to engine PWB, engine con- nect PWB	1	+24V2	O	24 V DC	24 V DC power output to ECPWB
	2	+24V2	O	24 V DC	24 V DC power output to ECPWB
	3	GND	-	-	GROUND
	4	GND	-	-	GROUND
	5	GND	-	-	GROUND
	6	GND	-	-	GROUND
	7	GND	-	-	GROUND
	8	+24V2	O	24 V DC	24 V DC power output to EPWB
	9	+24V2	O	24 V DC	24 V DC power output to EPWB
	10	+24V2	O	24 V DC	24 V DC power output to EPWB
YC9 Connected to engine con- nect PWB	1	NC	-	-	Not used
	2	SLEEP2	I	0/3.3 V DC	Sleep 2 control signal: On/Off

2-3-4 IH PWB




Figure 2-3-4 IH PWB silk-screen diagram

Connector	Pin	Signal	I/O	Voltage	Description
YC1 Connected to power source PWB	1	IH_NEUTRAL	I	220 V AC	AC power input
	2	IH_LIVE	I	220 V AC	AC power input
YC3 Connected to IH control PWB	1	TH2	-	Analog	Low side IGBT case temperature
	2	TH1	-	Analog	High side IGBT case temperature
	3	AC_CURRENT	-	Analog	AC input current
	4	AC_VOLTAGE	-	Analog	AC input voltage
	5	OUT_CURRENT	-	Analog	Output current
	6	IH_REM	-	0/5 V DC	IH: On/off
	7	ROTATION	-	0/5 V DC	TCBM control signal
	8	RXD	-	0/5 V DC (pulse)	Serial communication data signal input
	9	TXD	-	0/5 V DC (pulse)	Serial communication data signal output
	10	S1	-	0/5 V DC	For soft distinction
	11	IGBT1	-	0/5 V DC	gate output
	12	IGBT2	-	0/5 V DC	gate output
	13	S2	-	0/5 V DC	For soft distinction
	14	ERROR	-	0/5 V DC	Error signal
	15	5V	-	5 V DC	5 V DC power output to IHCPWB
	16	GND	-	-	Ground
YC4 Connected to engine PWB	1	SGND	-	-	Ground
	2	3.3V4	I	3.3 V DC	3.3 V DC power input from EPWB
	3	IH_REM	I	0/3.3 V DC	IH: On/off
	4	ROTATION	I	0/3.3 V DC	TCBM control signal
	5	RXD	I	0/3.3 V DC (pulse)	Serial communication data signal input
	6	TXD	O	0/3.3 V DC (pulse)	Serial communication data signal output
YC6 Connected to thermostat	1	+15V-1	O	15 V DC	Control power supply
	2	+15V-2	I	15 V DC	Gate drive power supply
YC8 Connected to engine PWB	1	24VIL	I	24 V DC	24 V DC power input from EPWB
	2	RELAY	I	0/3.3 V DC	RSW: On/Off
	3	PGND	-	-	Ground

Connector	Pin	Signal	I/O	Voltage	Description
YC9	1	IH_OUT1	O	390 V DC	Resonance circuit output
Connected to IH coil					
YC10	1	IH_OUT2	O	1000 V DC	Resonance circuit output
Connected to IH coil					

CAUTION: Connectors YC1, YC3, YC6, YC9 and YC10 are not grounded, therefore, use caution not to damage the connectors during measurement of voltages.

www.tonerplus.com.ua

2-3-5 Operation panel PWB main




Figure 2-3-5 Operation panel PWB main silk-screen diagram

Connector	Pin	Signal	I/O	Voltage	Description
YC1 Connected to main PWB	1	5V2	I	5 V DC	5 V DC power input from MPWB
	2	5V2	I	5 V DC	5 V DC power input from MPWB
	3	GND	-	-	Ground
	4	GND	-	-	Ground
YC2 Connected to main PWB	1	VBUS	I	5 V DC	5 V DC power input
	2	DN	I/O	LVDS	USB data signal
	3	DP	I/O	LVDS	USB data signal
	4	ID	-	-	Not used
	5	GND	-	-	Ground
YC3 Connected to main PWB	1	GND	-	-	Ground
	2	SECOND_TR AY_S	I	0/3.3 V DC	JEPS: On/Off
	3	BEEP_POWE RON	I	0/3.3 V DC	Sleep return signal 0
	4	ENERGY_SA VE	I	0/3.3 V DC	Energy save signal
	5	SUSPEND_P ower	I	3.3V DC	3.3 V DC power input from MPWB
	6	LED_MEMOR Y	I	0/3.3 V DC	Memory LED control signal
	7	LED_ATTENT ION	I	0/3.3 V DC	Attention LED control signal
	8	LED_PROCE SSING	I	0/3.3 V DC	Processing LED control signal
	9	SHUTDOWN	I	0/3.3 V DC	24 V down signal
	10	LIGHTOFF_P OWER	I	0/3.3 V DC	Sleep return signal 1
	11	AUDIO	I	Analog	Voice output signal
	12	PANEL_RESE T	I	0/3.3 V DC	Reset signal
	13	INT_POWER KEY	O	0/3.3 V DC	Power key: On/Off
	14	PANEL_STAT US	O	0/3.3 V DC	Operation panel status signal
	15	GND	-	-	Ground

Connector	Pin	Signal	I/O	Voltage	Description
YC4	1	GND	-	-	Ground
Connected to LCD relay PWB	2	GND	-	-	Ground
	3	CK	O	0/3.3 V DC(pulse)	Clock signal
	4	GND	-	-	Ground
	5	GND	-	-	Ground
	6	SC	O	0/3.3 V DC	LCD Control signal
	7	R0	O	0/3.3 V DC	LCD Control signal
	8	R1	O	0/3.3 V DC	LCD Control signal
	9	R2	O	0/3.3 V DC	LCD Control signal
	10	GND	-	-	Ground
	11	R3	O	0/3.3 V DC	LCD Control signal
	12	R4	O	0/3.3 V DC	LCD Control signal
	13	R5	O	0/3.3 V DC	LCD Control signal
	14	GND	-	-	Ground
	15	G1	O	0/3.3 V DC	LCD Control signal
	16	G1	O	0/3.3 V DC	LCD Control signal
	17	G2	O	0/3.3 V DC	LCD Control signal
	18	GND	-	-	Ground
	19	G3	O	0/3.3 V DC	LCD Control signal
	20	G4	O	0/3.3 V DC	LCD Control signal
	21	G5	O	0/3.3 V DC	LCD Control signal
	22	GND	-	-	Ground
	23	B0	O	0/3.3 V DC	LCD Control signal
	24	B1	O	0/3.3 V DC	LCD Control signal
	25	B2	O	0/3.3 V DC	LCD Control signal
	26	GND	-	-	Ground
	27	B3	O	0/3.3 V DC	LCD Control signal
	28	B4	O	0/3.3 V DC	LCD Control signal
	29	B5	O	0/3.3 V DC	LCD Control signal
	30	GND	-	-	Ground
	31	H_SYNC	O	0/3.3 V DC(pulse)	Horizontal synchronizing signal
	32	GND	-	-	Ground
	33	V_SYNC	O	0/3.3 V DC(pulse)	Vertical synchronizing signal
	34	GND	-	-	Ground
	35	ENB	O	0/3.3 V DC	LCD enable signal
	36	CM	O	0/3.3 V DC	LCD mode switch signal
	37	3.3V	O	3.3V DC	3.3 V DC power output to LCDRPWB

Connector	Pin	Signal	I/O	Voltage	Description	
YC4	38	3.3V	O	3.3 V DC	3.3 V DC power output to LCDRPWB	
	Connected to LCD relay PWB	39	3.3V	O	3.3 V DC	3.3 V DC power output to LCDRPWB
		40	3.3V	O	3.3 V DC	3.3 V DC power output to LCDRPWB
YC9	1	A_LED	O	0/3.3 V DC	Memory LED control signal	
	Connected to operation panel PWB left	2	M_LED	O	0/3.3 V DC	Attention LED control signal
		3	P_LED	O	0/3.3 V DC	Processing LED control signal
		4	KEY4	I	0/3.3 V DC(pulse)	Operation panel key scan return signal 4
		5	INT_POWER KEY_N	O	0/5 V DC	Power key: On/Off
		6	KEY3	I	0/3.3 V DC(pulse)	Operation panel key scan return signal 3
		7	KEY2	I	0/3.3 V DC(pulse)	Operation panel key scan return signal 2
		8	KEY1	I	0/3.3 V DC(pulse)	Operation panel key scan return signal 1
		9	LED1	O	0/3.3 V DC(pulse)	Operation panel LED display drive signal 1
		10	3.3V0	O	3.3V DC	3.3 V DC power output to OPPWB-L
		11	LED0	O	0/3.3 V DC(pulse)	Operation panel LED display drive signal 0
		12	KEY0	I	0/3.3 V DC(pulse)	Operation panel key scan return signal 0
		13	SCAN4	O	0/3.3 V DC(pulse)	Scan signal 4
		14	SCAN3	O	0/3.3 V DC(pulse)	Scan signal 3
		15	SCAN2	O	0/3.3 V DC(pulse)	Scan signal 2
		16	SCAN1	O	0/3.3 V DC(pulse)	Scan signal 1
		17	SCAN0	O	0/3.3 V DC(pulse)	Scan signal 0
		18	GND	-	-	Ground

Connector	Pin	Signal	I/O	Voltage	Description
YC10 Connected to operation panel PWB right	1	S_LED	O	0/3.3 V DC	Memory LED control signal
	2	LED4	O	0/3.3 V DC(pulse)	Operation panel LED display drive signal 4
	3	LED2	O	0/3.3 V DC(pulse)	Operation panel LED display drive signal 2
	4	KEY5	I	0/3.3 V DC(pulse)	Operation panel key scan return signal 5
	5	SCAN3	O	0/3.3 V DC(pulse)	Scan signal 3
	6	SCAN2	O	0/3.3 V DC(pulse)	Scan signal 2
	7	SCAN1	O	0/3.3 V DC(pulse)	Scan signal 1
	8	KEY7	I	0/3.3 V DC(pulse)	Operation panel key scan return signal 7
	9	LED3	O	0/3.3 V DC(pulse)	Operation panel LED display drive signal 3
	10	KEY6	I	0/3.3 V DC(pulse)	Operation panel key scan return signal 6
	11	SCAN0	O	0/3.3 V DC(pulse)	Scan signal 0
	12	GND	-	-	Ground
YC15 Connected to LCD relay PWB	1	GND	-	-	Ground
	2	SCK	O	0/3.3 V DC(pulse)	Clock signal
	3	SDI	O	0/3.3 V DC(pulse)	Serial communication data signal
	4	SPC_CS1N	O	0/3.3 V DC	LCD control signal
	5	SHUT	O	0/3.3 V DC	LCD control signal
	6	LCD_RESB	O	0/3.3 V DC	LCD control signal
	7	Y1(T)	I	Analog	Touch panel Y+Positional signal
	8	X2(L)	I	Analog	Touch panel X+Positional signal
	9	Y2(B)	I	Analog	Touch panel Y-Positional signal
	10	X1(R)	I	Analog	Touch panel X-Positional signal
	11	LED_A(+)	O	0/3.3 V DC	LED control signal
	12	LED_C(-)	I	0/3.3 V DC	LED control signal

2-3-6 DP main PWB




Figure 2-3-6 DP main PWB silk-screen diagram

Connector	Pin	Signal	I/O	Voltage	Description
YC1 Connected to engine PWB	1	FG	-	-	Ground
	2	ENG_TMG	O	0/3.3 V DC	DPTS: On/Off
	3	ENG_RDY	O	0/3.3 V DC	Ready signal
	4	ENG_SEL	I	0/3.3 V DC	Select signal
	5	ENG_CLK	I	0/3.3 V DC(pulse)	Clock signal
	6	ENG_SI	I	0/3.3 V DC(pulse)	Serial communication data signal
	7	ENG_SO	O	0/3.3 V DC(pulse)	Serial communication data signal
	8	ENG_OPEN	O	0/3.3 V DC	DPOCS: On/Off
	9	NC	-	-	Not used
	10	GND	-	-	Ground
	11	GND	-	-	Ground
	12	GND	-	-	Ground
	13	NC	-	-	Not used
	14	+24V	O	24 V DC	24 V DC power input from EPWB
	15	+24V	O	24 V DC	24 V DC power input from EPWB
	16	+24V	O	24 V DC	24 V DC power input from EPWB
YC2 Connected to DP original size length sensor	1	ANODE	O	3.3 V DC	3.3 V DC power output to DPOLS
	2	GND	-	-	Ground
	3	LS_SW	I	0/3.3 V DC	DPOLS: On/Off
YC3 Connected to DP original sensor	1	ANODE	O	3.3 V DC	3.3 V DC power output to DPOS
	2	GND	-	-	Ground
	3	SET_SW	I	0/3.3 V DC	DPOS: On/Off
YC4 Connected to DP original size width sensor	1	WID1	I	0/3.3 V DC	DPOWS: On/Off
	2	GND	-	-	Ground
	3	WID2	I	0/3.3 V DC	DPOWS: On/Off
	4	WID3	I	0/3.3 V DC	DPOWS: On/Off

Connector	Pin	Signal	I/O	Voltage	Description
YC5 Connected to DP paper feed sensor, DP registration sensor, DP open/close sensor, DP switchback sensor and DP timing sensor	1	ANODE	O	3.3 V DC	3.3 V DC power output to DPPFS
	2	GND	-	-	Ground
	3	FEED SW	I	0/3.3 V DC	DPPFS: On/Off
	4	ANODE	O	3.3 V DC	3.3 V DC power output to DPRS
	5	GND	-	-	Ground
	6	REGIST_SW	I	0/3.3 V DC	DPRS: On/Off
	7	ANODE	O	3.3 V DC	3.3 V DC power output to DPOCS
	8	GND	-	-	Ground
	9	DP_OPENSW	I	0/3.3 V DC	DPOCS: On/Off
	10	ANODE	O	3.3 V DC	3.3 V DC power output to DPSBS
	11	GND	-	-	Ground
	12	HP_SW	I	0/3.3 V DC	DPSBS: On/Off
	13	ANODE	O	3.3 V DC	3.3 V DC power output to DPTS
	14	GND	-	-	Ground
	15	TMG_SW	I	0/3.3 V DC	DPTS: On/Off
YC6 Connected to DP LED PWB	1	NC	-	-	Not used
	2	GND	-	-	Ground
	3	LED_REM	O	0/3.3 V DC	LED control signal
YC7 Connected to DP interlock switch	1	+24V	O	24 V DC	24 V DC power output to DPILSW
	2	GND	-	-	Ground
	3	+R24V	I	24 V DC	24 V DC power input from DPILSW
YC8 Connected to DP paper feed clutch and DP registration clutch	1	FEED_CL	O	0/24 V DC	DPPFCL: On/Off
	2	+R24V	O	24 V DC	24 V DC power output to DPPFCL
	3	REGIST_CL	O	0/24 V DC	DPRCL: On/Off
	4	+R24V	O	24 V DC	24 V DC power output to DPRCL
YC9 Connected to DP paper feed motor and DP switchback motor	1	CNVY_-BN	O	0/24 V DC(pulse)	DPPFM drive control signal
	2	CNVY_-AN	O	0/24 V DC(pulse)	DPPFM drive control signal
	3	CNVY_+A	O	0/24 V DC(pulse)	DPPFM drive control signal
	4	CNVY_+B	O	0/24 V DC(pulse)	DPPFM drive control signal
	5	JNC_-BN	O	0/24 V DC(pulse)	DPSBM drive control signal
	6	JNC_-AN	O	0/24 V DC(pulse)	DPSBM drive control signal
	7	JNC_+A	O	0/24 V DC(pulse)	DPSBM drive control signal
	8	JNC_+B	O	0/24 V DC(pulse)	DPSBM drive control signal


This page is intentionally left blank.

2-4-1 Appendixes

(1) Maintenance kits

Maintenance part name		Parts No.	Alternative part No.
Name used in service	Name used in parts list		
MK-896A/MAINTENANCE KIT (200,000 sheets)	MK-896A/MAINTENANCE KIT	1702MY0UN0	072MY0U0
Transfer roller unit	HOLDER TRANSFER ASSY	-	-
Drum unit	DRUM UNIT MK	-	-
Developer unit K	DLP UNIT BK MK	-	-
Intermediate transfer unit	IMAGE UNIT MK	-	-
Fuser unit	FUSER UNIT MK	-	-
Primary feed unit	PRIMARY FEED ASS'Y	-	-
MP separation pad	PAD SEPARATION ASSY SP	-	-
MP paper feed roller	ROLLER MPF ASSY SP	-	-
MK-896B/MAINTENANCE KIT (200,000 sheets)	MK-896B/MAINTENANCE KIT	1702K00UN2	072K00U2
Drum unit	DRUM UNIT	-	-
Developer unit C	DLP UNIT C	-	-
Developer unit M	DLP UNIT M	-	-
Developer unit Y	DLP UNIT Y	-	-
MK-470/MAINTENANCE KIT (150,000 sheets)	MK-470/MAINTENANCE KIT	1703M80UN0	073M80UN
DP paper feed roller	PAPER FEED ASSY SP	-	-
DP separation pullay cover	GUIDE RETARD ASSY SP	-	-
DP separation pullay	HOLDER RETARD ASSY SP	-	-

(2) Repetitive defects gauge



(3) Firmware environment commands

The printer maintains a number of printing parameters in its memory. These parameters may be changed permanently with the FRPO (Firmware RePrOgram) commands.

This section provides information on how to use the FRPO command and its parameters using examples.

Using FRPO commands for reprogramming the firmware

The current settings of the FRPO parameters are listed as the optional values on the service status page.

Note: Before changing any FRPO parameters, print out a service status page, so you will know the parameter values before the changes are made. To return FRPO parameters to their factory default values, send the FRPO INIT (FRPO-INITialize) command.(!R! FRPO INIT; EXIT;)

The FRPO command is sent to the printer in the following sequence:

!R! FRPO parameter, value; EXIT;

Example: Changing emulation mode to PC-PR201/65A

!R! FRPO P1, 11; EXIT;

FRPO parameters

Item	FRPO	Setting values	Factory setting
Default pattern resolution	B8	0: 300 dpi 1: 600 dpi	0
Copy count	C0	Number of copies to print: 1-999	1
Page orientation	C1	0: Portrait 1: Landscape	0
Default font No. *	C2 C3 C5	Middle two digits of power-up font Last two digits of power-up font First two digits of power-up font	0 0 0
PCL font switch	C8	0:HP compatibility mode (Characters higher than 127 are not printed.) 32:Conventional mode (Characters higher than 127 are printed. Supported symbol sets: ISO-60 Norway [00D], ISO-15 Italian [00I], ISO-11 Sweden [00S], ISO-6 ASCII [00U], ISO-4 U.K. [01E], ISO-69 France [01F], ISO-21 Germany [01G], ISO-17 Spain [02S], Symbol [19M]ª)	0
Total host buffer size	H8	0 to 99 in units of the size defined by FRPO S5	5
Form feed time-out value	H9	Value in units of 5 seconds (0 to 99).	6
Duplex binding	N4	0: Off 1: Long edge 2: Short edge	0
Sleep timer time-out time	N5	1 to 240 minutes [0: Off]	20 (20ppm) 30 (25ppm)
Ecoprint level	N6	0: Off 2: On	0

Item	FRPO	Setting values	Factory setting
Default emulation mode	P1	6: PCL 6 9: KPDL	9(U.S.A) or 6(Euro and other)
Carriage-return action *	P2	0: Ignores 0x0d 1: Carriage-return 2: Carriage-return+linefeed	1
Linefeed action *	P3	0: Ignores 0x0d 1: Linefeed 2: Linefeed+carriage-return	1
Automatic emulation sensing (For KPDL3)	P4	0: AES disabled 1: AES enabled	1(U.S.A) or 0(Euro and other)
Automatic emulation switching trigger (For KPDL3)	P7	0: Page eject commands 1: None 2: Page eject and prescribe EXIT 3: Prescribe EXIT 4: Formfeed (^L) 6: Page eject, prescribe EXIT and formfeed 10: Page eject commands; if AES fails, resolves to KPDL	11(U.S.A) or 10(Euro and other)
Command recognition character	P9	ASCII code of 33 to 126	82 (R)
Default stacker	R0	1 (inner tray) 3 5	1


Item	FRPO	Setting values	Factory setting
Default paper size	R2	0: Size of the default paper cassette (See R4.) 1: Monarch (3-7/8 × 7-1/2 inches) 2: Business (4-1/8 × 9-1/2 inches) 3: International DL (11 × 22 cm) 4: International C5 (16.2 × 22.9 cm) 5: Executive (7-1/4 × 10-1/2 inches) 6: US Letter (8-1/2 × 11 inches) 7: US Legal (8-1/2 × 14 inches) 8: A4 (21.0 × 29.7 cm) 9: JIS B5 (18.2 × 25.7 cm) 10: A3 (29.7 × 42 cm) 11: B4 (25.7 × 36.4 cm) 12: US Ledger (11 × 17 inches) 13: ISO A5 14: A6 (10.5 × 14.8 cm) 15: JIS B6 (12.8 × 18.2 cm) 16: Commercial #9 (3-7/8 × 8-7/8 inches) 17: Commercial #6 (3-5/8 × 6-1/2 inches) 18: ISO B5 (17.6 × 25 cm) 19: Custom (11.7 × 17.7 inches) 30: C4 (22.9 × 32.4 cm) 31: Hagaki (10 × 14.8 cm) 32: Ofuku-hagaki (14.8 × 20 cm) 33: Officio II 39: 8K 40: 16K 42: 8.5 × 13.5 inches 50: Statement 51: Folio 52: Youkei 2 53: Youkei 4	0
Default cassette	R4	0: MP tray 1: Cassette 1 2: Cassette 2 3: Cassette 3	1
MP tray paper size	R7	Same as the R2 values except: 0	6(U.S.A) or 8(Euro and other)
A4/letter equation	S4	0: Off 1: On	1
Host buffer size	S5	0: 10kB (x H8) 1: 100kB (x H8) 2: 1024kB (x H8)	1
RAM disk size	S6	1 to 1024 MB	400
RAM disk mode	S7	0: Off 1: On	0

Item	FRPO	Setting values	Factory setting
Wide A4	T6	0: Off 1: On	0
Line spacing *	U0	Lines per inch (integer value)	6
Line spacing *	U1	Lines per inch (fraction value)	0
Character spacing *	U2	Characters per inch (integer value)	10
Character spacing *	U3	Characters per inch (fraction value)	0
Country code	U6	0: US-ASCII 1: France 2: Germany 3: UK 4: Denmark 5: Sweden 6: Italy 7: Spain 8: Japan 9: US Legal 10: IBM PC-850 (Multilingual) 11: IBM PC-860 (Portuguese) 12: IBM PC-863 (Canadian French) 13: IBM PC-865 (Norwegian) 14: Norway 15: Denmark 2 16: Spain 2 17: Latin America 21: US ASCII (U7 = 50 SET) 77: HP Roman-8 (U7 = 52 SET)	41
Code set at power up in daisy-wheel emulation	U7	0: Same as the default emulation mode (P1) 1: IBM 6: IBM PC-8 50: US ASCII (U6 = 21 SET) 52: HP Roman-8 (U6 = 77 SET)	53
Font pitch for fixed pitch scalable font	U8	Integer value in cpi: 0 to 99	10
	U9	Fraction value in 1/100 cpi: 0 to 99	0
Font height for the default scalable font *	V0	Integer value in 100 points: 0 to 9	0
	V1	Integer value in points: 0 to 99	12
	V2	Fraction value in 1/100 points: 0, 25, 50, 75	0
Default scalable font *	V3	Name of typeface of up to 32 characters, enclosed with single or double quotation marks	Courier

Item	FRPO	Setting values	Factory setting
Default weight (courier and letter Gothic)	V9	0: Courier = darkness Letter Gothic = darkness 1: Courier = regular Letter Gothic = darkness 4: Courier = darkness Letter Gothic = regular 5: Courier = regular Letter Gothic = regular	5
Color mode	W1	0: Monochrome (grayscale) 1: Color (CMYK)	1
Gloss mode	W6	0: Low (normal) 1: High	0
Paper type for the MP tray	X0	1: Plain 1 2: Transparency 3: Preprinted 4: Label 5: Bond 6: Recycle 7: Vellum 9: Letterhead 10: Color 11: Prepunched 12: Envelope 13: Cardstock 16: Thick 17: High quality 21: Custom1 22: Custom2 23: Custom3 24: Custom4 25: Custom5 26: Custom6 27: Custom7 28: Custom8	1

Item	FRPO	Setting values	Factory setting
Paper type for paper cassettes 1	X1	1: Plain 3: Preprinted 5: Bond 6: Recycled 9: Letterhead 10: Color 11: Prepunched 17: High quality 21: Custom1 22: Custom2 23: Custom3 24: Custom4 25: Custom5 26: Custom6 27: Custom7 28: Custom8	1
Paper type for paper cassettes 2 to 4	X2 X3	1: Plain 3: Preprinted 5: Bond 6: Recycled 9: Letterhead 10: Color 11: Prepunched 17: High quality 21: Custom1 22: Custom2 23: Custom3 24: Custom4 25: Custom5 26: Custom6 27: Custom7 28: Custom8	1
PCL paper source	X9	0: Performs paper selection depending on media type. 1: Performs paper selection depending on paper sources.	0
Automatic continue for 'Press GO'	Y0	0: Off 1: On	0
Automatic continue timer	Y1	Number from 0 to 99 in increments of 5 seconds	6 (30 seconds)
Error message for device error	Y3	0: Not detect 1: Detect	0

Item	FRPO	Setting values	Factory setting
Duplex operation for specified paper type (Prepunched, Preprinted and Letterhead)	Y4	0: Off 1: On	0
Default operation for PDF direct printing	Y5	0: Enlarges or reduces the image to fit in the current paper size. Loads paper from the current paper cassette. 1: Through the image. Loads paper which is the same size as the image. 2: Enlarges or reduces the image to fit in the current paper size. Loads Letter, A4 size paper depending on the image size. 3: Through the image. Loads Letter, A4 size paper depending on the image size. 8: Through the image. Loads paper from the current paper cassette. 9: Through the image. Loads Letter, A4 size paper depending on the image size. 10: Enlarges or reduces the image to fit in the current paper size. Loads Letter, A4 size paper depending on the image size.	0
e-MPS error	Y6	0: Does not print the error report and display the error message. 1: Prints the error report. 2: Displays the error message. 3: Prints the error report and displays the error message.	3



- a. Characters higher than 127 are printed regardless of the C8 value. However, setting C8 to 0 does not print character code 160.

(4) System Error (Fxxxx) Outline

The document is subscribed to describe the outline of the factors of the Fxxx errors that are not described in the

service manual. Please utilize it to refer to checking the factors.

Please utilize it as the measures when the system is not recovered after power off/on or it frequently occurs.

* : It may be from the hardware factor while the error (Fxxx) is indicated.

Please initially check the following.

Check the DDR2 memory and neighboring parts:

Check the contact of YS1 or YS2 with the memory. Replace the memory if the error repeats.

Check the HDD if the error repeats after replacing the main board.

Take care, however, of handling the data when formatting or replacing the HDD.

Check the HDD : Replace the HDD if the error repeats after formatting the HDD.

No.	Content	Check procedure & check point	Remark 1	TASKalfa 256ci/FS-C8525MFP, TASKalfa 206ci/FS-C8520MFP, TASKalfa 306i/FS-6530MFP, TASKalfa 256i/FS-6525MFP
-	Lock-up at Welcome display (TASKalfa/Ecosys) (The display unchanges after a certain time (Note 1: *** seconds))	1) Check connection of the harness (Panel to Main board), (Main board to HDD) and connectors and check function. 2) Check contact of the DDR memory by detaching and reattaching. and check function. replace it if available and check function. 3) Format the HDD and check function. (U024 FULL formatting) (*1) 4) Execute the U021Memory initializing to initialize the controller backup memory and check function. 5) Replace the panelmain board and check function. 6) Replace the main board and check function. 7) Retrieve the USBLOG and contact the Service Administrative Division. (*1) For the HDD standard model only.	*User data and installed software is deleted if executing the U024. Reinstallation is required.	[Main - Panel Interface] Main board: YC100, YC101, YC102 Panel board: YC1, YC2, YC3 (Note 1) 70 seconds [Check the contact with the DDR2 memory] Main board: YS1 A certain part of the memory may be faulty. The frequency of failure occurrence is dependent on the frequency of access to the faulty bit. The memories except the DIMM are mounted on the main PWB. The mounted memories or the ASIC may be faulty if the DIMM is not sensitive.
F000	CF000 appears in a certain time (Note 2: *** seconds) after the Welcome display continues Panel—Main board communication error	1) Check connection of the harness (Panel to Main board), (Main board to HDD) and connectors and check function. 2) Check contact of the DDR memory by detaching and reattaching. and check function. replace it if available and check function. 3) Format the HDD and check function. (U024 FULL formatting) (*1) 4) Execute the U021 Memory initializing to initialize the controller backup memory and check function. 5) Replace the main board and check function. 6) Replace the panelmain board and check function. 7) Retrieve the USBLOG and contact the Service Administrative Division. (*1) For the HDD standard model only.		[Main-Panel Interface] Main board: YC100, YC101, YC102 Panel board: YC1, YC2, YC3 If the LEDs are in the state below when the F000 appears, the DDR2 memory failure may be the cause. Check contact of the YS1 with the memory. (DDR2 memory is the option item for the monochrome models, and is the standard item for the color models.) Memory LED turned on Attention LED turned on (Note 1) 70 seconds [Check the contact with the DDR2 memory] Main board: YS1 A certain part of the memory may be faulty. The frequency of failure occurrence is dependent on the frequency of access to the faulty bit. The memories except the DIMM are mounted on the main PWB. The mounted memories or the ASIC may be faulty if the DIMM is not sensitive.
F10X	An error is detected at OS or some of device drivers.	1) Format the HDD and check function. (U024 FULL formatting) (*1) 2) Execute the U021 Memory initializing to initialize the controller backup memory and check function. 3) Replace the main board and check function. 4) Replace the HDD and check function. (*1) 5) Retrieve the USBLOG and contact the Service Administrative Division. (*1) For the HDD standard model only.		
F11X				

No.	Content	Check procedure & check point	Remark 1	TASKalfa 256ci/FS-C8525MFP, TASKalfa 206ci/FS-C8520MFP, TASKalfa 306i/FS-6530MFP, TASKalfa 256i/FS-6525MFP
F12X	An error is detected at the Scan control section	1) Check connection of the harness (Scan/DP - Main board) and connectors and check function. 2) Format the HDD and check function. (U024 FULL formatting) (*1) 3) Execute the U021 Memory initializing to initialize the controller backup memory and check function. 4) Replace the Scan/DP board and check function. 5) Replace the main board and check function. 6) Retrieve the USBLOG and contact the Service Administrative Division. (*1) For the HDD standard model only.		[Main-Scan Interface] Main board: YC112, YC113 CCD board: YC1 LED board: YC1
F13X	An error is detected at the Panel control section	1) Check connection of the harness (Panel - Main board) and connectors and check function. 2) Format the HDD and check function. (U024 FULL formatting) (*1) 3) Execute the U021 Memory initializing to initialize the controller backup memory and check function. 4) Replace the panel board and check function. (*2) 5) Replace the main board and check function. 6) Retrieve the USBLOG and contact the Service Administrative Division. (*1) For the HDD standard model only. (*2) For the model separating the main/panel PWBs.		[Main-Panel Interface] Main board: YC100, YC101, YC102 Panel board: YC1, YC2, YC3
F14X	An error is detected at the FAX control section	1) Check connection of the harness (FAX - Main board) and connectors and check function. 2) Format the HDD and check function. (U024 FULL formatting) (*1) 3) Execute the U021 Memory initializing to initialize the controller backup memory and check function. 4) Execute the U671 Clear FAX back up data (FAX DIMM clear) and check function. (*3) (Take cae of the received data since it is cleared) 5) Replace the FAX_DIMM and check function. 6) Replace the FAX board and check function. 7) Replace the main board and check function. 8) Retrieve the USBLOG and contact the Service Administrative Division. (*1) For the HDD standard model only. (*3) For the models using the main PWB with the flash for the FAX data.		F14A, F14F: KUIO error Main board (USB hub) [Main-KUIO Interface] Main board: YC109 (Reference) YC16 is at the side where the IB-50 is inserted. <Note> 4) is not supported. 5) is unnecessary.
F15X	An error is detected at the authentication device control section	1) Check connection of the harness (Authentication device - Main board) and connectors and check function. 2) Format the HDD and check function. (U024 FULL formatting) (*1) 3) Execute the U021 Memory initializing to initialize the controller backup memory and check function. 4) Replace the main board and check function. 5) Replace the HDD and check function. (*1) 6) Retrieve the USBLOG and contact the Service Administrative Division. (*1) For the HDD standard model only.	Authentication device: Card Reader, etc.	[Main-USB Host Interface] Main board: YC107(USB Host where is at the side of the operation unit) YC108(USB Host where is at the back side of the main frame)

No.	Content	Check procedure & check point	Remark 1	TASKalfa 256ci/FS-C8525MFP, TASKalfa 206ci/FS-C8520MFP, TASKalfa 306i/FS-6530MFP, TASKalfa 256i/FS-6525MFP
F16X	An error is detected at the KMAS control section	1) Check connection of the harness (KMAS - Main board) and connectors and check function. 2) Format the HDD and check function. (U024 FULL formatting) (*1) 3) Execute the U021 Memory initializing to initialize the controller backup memory and check function. 3) Replace the main board and check function. 4) Replace the HDD and check function. (*1) 5) Retrieve the USBLOG and contact the Service Administrative Division. (*1) For the HDD standard model only.		
F17X	An error is detected at the print data control section	1) Format the HDD and check function. (U024 FULL formatting) (*1) 2) Execute the U021 Memory initializing to initialize the controller backup memory and check function. 3) Replace the main board and check function. 4) Replace the HDD and check function. (*1) 5) Retrieve the USBLOG and contact the Service Administrative Division. (*1) For the HDD standard model only.		
F18X	An error is detected at the Video control section	1) Check connection of the harness (Engine - Main board) and connectors and check function. 2) Format the HDD and check function. (U024 FULL formatting) (*1) 3) Execute the U021 Memory initializing to initialize the controller backup memory and check function. 4) Replace the engine board and check function. 5) Replace the main board and check function. 6) Retrieve the USBLOG and contact the Service Administrative Division. (*1) For the HDD standard model only.		<Monochrome models> [Main-LSU Interface] Main board: YC103 LSU(APC PWB): YC2 [Main-Engine Interface] Main board: YC105 Engine board: YC17 <Color models> [Main-LSU Interface] Main board: YC104 LSU relay board: YC10 [Main-Engine Interface] Main board: YC105 Engine board: YC26 [Relay connector] Between the main board and the LSU relay board.
F19X	An error is detected at the OS or some of device drivers	1) Format the HDD and check function. (U024 FULL formatting) (*1) 2) Execute the U021 Memory initializing to initialize the controller backup memory and check function. 3) Replace the main board and check function. 4) Replace the HDD and check function. (*1) 5) Retrieve the USBLOG and contact the Service Administrative Division. (*1) For the HDD standard model only.		
F1AX				
F1BX	An error is detected at the Security management section	1) Format the HDD and check function. (U024 FULL formatting) (*1) 2) Execute the U021 Memory initializing to initialize the controller backup memory and check function. 3) Replace the main board and check function. 4) Replace the HDD and check function. (*1) 5) Retrieve the USBLOG and contact the Service Administrative Division. (*1) For the HDD standard model only.		

No.	Content	Check procedure & check point	Remark 1	TASKalfa 256ci/FS-C8525MFP, TASKalfa 206ci/FS-C8520MFP, TASKalfa 306i/FS-6530MFP, TASKalfa 256i/FS-6525MFP
F1CX	An error is detected at the File System management section	1) Format the HDD and check function. (U024 FULL formatting) (*1) 2) Execute the U021 Memory initializing to initialize the controller backup memory and check function. 3) Replace the main board and check function. 4) Replace the HDD and check function. (*1) 5) Retrieve the USBLOG and contact the Service Administrative Division. (*1) For the HDD standard model only.	*The F1C4 error appears with the HDD security kit at work.	
F1DX	An error is detected at the Image memory management section	1) Format the HDD and check function. (U024 FULL formatting) (*1) 2) Execute the U021 Memory initializing to initialize the controller backup memory and check function. 3) Replace the main board and check function. 4) Replace the HDD and check function. (*1) 5) Retrieve the USBLOG and contact the Service Administrative Division. (*1) For the HDD standard model only.	*The F1D4 error is RAM allocation error. 1. Check it with the U340 2. Initialize the setting valued with the U021	
F1EX	An error is detected at the OS or some of device drivers	1) Format the HDD and check function. (U024 FULL formatting) (*1) 2) Execute the U021 Memory initializing to initialize the controller backup memory and check function.		
F1FX		3) Replace the main board and check function. 4) Replace the HDD and check function. (*1)		
F20X		5) Retrieve the USBLOG and contact the Service Administrative Division. (*1) For the HDD standard model only.		
F21X	An error is detected at the Image processing section	1) Check contact of the DDR memory and check function. 2) Format the HDD and check function. (U024 FULL formatting) (*1) 3) Execute the U021 Memory initializing to initialize the controller backup memory and check function.		[DIMM] <Monochrome models: Option> <Color models: Standard>
F22X		4) Replace the main board and check function. 5) Replace the HDD and check function. (*1)		[DDR2 memory contact check] Main board: YS1 A certain part of the memory may be faulty. The frequency of failure occurrence is dependent on the frequency of access to the faulty bit.
F23X		6) Retrieve the USBLOG and contact the Service Administrative Division. (*1) For the HDD standard model only.		The memories except the DIMM are mounted on the main PWB. The mounted memories or the ASIC may be faulty if the DIMM is not sensitive.
F24X	An error is detected at the System management section	1) Check contact of the DDR memory and check function. 2) Format the HDD and check function. (U024 FULL formatting) (*1) 3) Execute the U021 Memory initializing to initialize the controller backup memory and check function. 4) Replace the main board and check function. 5) Replace the HDD and check function. (*1) 6) Retrieve the USBLOG and contact the Service Administrative Division. (*1) For the HDD standard model only.	*The F248 error is printer process error. if it repeats with a certain print data, retrieve the capture data and USBLOG.	[DIMM] <Monochrome models: Option> <Color models: Standard>
				[DDR2 memory contact check] Main board: YS1 A certain part of the memory may be faulty. The frequency of failure occurrence is dependent on the frequency of access to the faulty bit. The memories except the DIMM are mounted on the main PWB. The mounted memories or the ASIC may be faulty if the DIMM is not sensitive.

No.	Content	Check procedure & check point	Remark 1	TASKalfa 256ci/FS-C8525MFP, TASKalfa 206ci/FS-C8520MFP, TASKalfa 306i/FS-6530MFP, TASKalfa 256i/FS-6525MFP
F25X	An error is detected at the Network management section	1) Format the HDD and check function. (U024 FULL formatting) (*1) 2) Execute the U021 Memory initializing to initialize the controller backup memory and check function. 3) Replace the main board and check function. 4) Retrieve the USBLOG and contact the Service Administrative Division. (or retrieve the packet capture data depending on the result of analysis) (*1) For the HDD standard model only.	*This may be owing to the users network environment.	
F26X	An error is detected at the System management section	1) Format the HDD and check function. (U024 FULL formatting) (*1) 2) Execute the U021 Memory initializing to initialize the controller backup memory and check function. 3) Replace the main board and check function. 4) Replace the HDD and check function. (*1) 5) Retrieve the USBLOG and contact the Service Administrative Division. (*1) For the HDD standard model only.		
F27X				
F28X				
F29X				
F2AX				
F2BX	An error is detected at the Network control section	1) Format the HDD and check function. (U024 FULL formatting) (*1) 2) Execute the U021 Memory initializing to initialize the controller backup memory and check function. 3) Replace the main board and check function. 4) Retrieve the USBLOG and contact the Service Administrative Division. (or retrieve the packet capture data depending on the result of analysis) (*1) For the HDD standard model only.		
F2CX				
F2DX				
F2EX				
F2FX				
F30X				
F31X				
F32X				
F33X	An error is detected at the Scan management section	1) Check connection of the harness (Scan/DP board - main board) and connectors and check function. 2) Format the HDD and check function. (U024 FULL formatting) (*1) 3) Execute the U021 Memory initializing to initialize the controller backup memory and check function. 4) Replace the Scan/DP board and check function. 5) Replace the main board and check function. 6) Retrieve the USBLOG and contact the Service Administrative Division. (*1) For the HDD standard model only.		[Main-Scan Interface] Main board: YC112, YC113 CCD PWB: YC1 LED PWB: YC1
F34X	An error is detected at the Panel management section	1) Check connection of the harness (Panel board - main board) and connectors and check function. 2) Format the HDD and check function. (U024 FULL formatting) (*1) 3) Execute the U021 Memory initializing to initialize the controller backup memory and check function. 4) Replace the panel board and check function. (*2) 5) Replace the main board and check function. 6) Retrieve the USBLOG and contact the Service Administrative Division. (*1) For the HDD standard model only. (*2) For the models separating the panel/main PWBs.		[Main-Panel Interface] Main board: YC100, YC101, YC102 Panel board: YC1, YC2, YC3
F35X	An error is detected at the Print control section	1) Format the HDD and check function. (U024 FULL formatting) (*1) 2) Execute the U021 Memory initializing to initialize the controller backup memory and check function. 3) Replace the main board and check function. 4) Replace the HDD and check function. (*1) 5) Retrieve the USBLOG and contact the Service Administrative Division. (*1) For the HDD standard model only.		

No.	Content	Check procedure & check point	Remark 1	TASKalfa 256ci/FS-C8525MFP, TASKalfa 206ci/FS-C8520MFP, TASKalfa 306i/FS-6530MFP, TASKalfa 256i/FS-6525MFP
F36X	An error is detected at the Print management section	1) Format the HDD and check function. (U024 FULL formatting) (*1) 2) Execute the U021 Memory initializing to initialize the controller backup memory and check function. 3) Replace the main board and check function. 4) Replace the HDD and check function. (*1) 5) Retrieve the USBLOG and contact the Service Administrative Division. (*1) For the HDD standard model only.		
F37X	An error is detected at the FAX management section	1) Format the HDD and check function. (U024 FULL formatting) (*1) 2) Execute the U021 Memory initializing to initialize the controller backup memory and check function. 3) Execute the U671 Clear FAX back up data (FAX DIMM clear) and check function. (*3) (Take care of the received data since it is cleared) 4) Replace the FAX_DIMM and check function. 5) Replace the main board and check function. 6) Replace the HDD and check function. (*1) 7) Retrieve the USBLOG and contact the Service Administrative Division. (*1) For the HDD standard model only. (*3) For the models using the main PWB with the flash for the FAX data.		F14A,F14F: KUIO error Main board (USB hub) [Main-KUIO Interface] Main board: YC109 (Reference) YC16 is at the side where IB-50 is inserted. <Note> 3) is not supported. 4) is unnecessary.
F38X	An error is detected at the Authentication/permit management section	1) Format the HDD and check function. (U024 FULL formatting) (*1) 2) Execute the U021 Memory initializing to initialize the controller backup memory and check function. 3) Replace the main board and check function. 4) Replace the HDD and check function. (*1) 5) Retrieve the USBLOG and contact the Service Administrative Division. (*1) For the HDD standard model only.		
F39X	An error is detected at the KMAS control section	1) Check connection of the harness (KMAS - Main board) and connectors and check function. 2) Format the HDD and check function. (U024 FULL formatting) (*1) 3) Execute the U021 Memory initializing to initialize the controller backup memory and check function. 3) Replace the main board and check function. 4) Replace the HDD and check function. (*1) 5) Retrieve the USBLOG and contact the Service Administrative Division. (*1) For the HDD standard model only.		
F3AX	An error is detected at the Entity management section	1) Format the HDD and check function. (U024 FULL formatting) (*1) 2) Execute the U021 Memory initializing to initialize the controller backup memory and check function. 3) Replace the main board and check function. 4) Replace the HDD and check function. (*1) 5) Retrieve the USBLOG and contact the Service Administrative Division. (*1) For the HDD standard model only.		
F3BX				
F3CX				
F3DX				
F3EX				
F3FX				
F40X				
F41X				
F42X				
F43X				
F44X				
F45X				









No.	Content	Check procedure & check point	Remark 1	TASKalfa 256ci/FS-C8525MFP, TASKalfa 206ci/FS-C8520MFP, TASKalfa 306i/FS-6530MFP, TASKalfa 256i/FS-6525MFP
F46X	An error is detected at the Print image process section	1) Replace the main board and check function. 2) Retrieve the USBLOG (or retrieve the print capture data by case)	*The F46F is printer process error. If it repeats with a certain print data, retrieve the capture data and USBLOG.	
F47X	An error is detected at the Image edit process control section	1) Format the HDD and check function. (U024 FULL formatting) (*1) 2) Execute the U021 Memory initializing to initialize the controller backup memory and check function.		
F48X		3) Replace the main board and check function. 4) Replace the HDD and check function. (*1)		
F49X		5) Retrieve the USBLOG and contact the Service Administrative Division. (*1) For the HDD standard model only.		
F4AX	An error is detected at the Print image process section	1) Format the HDD and check function. (U024 FULL formatting) (*1) 2) Execute the U021 Memory initializing to initialize the controller backup memory and check function.		
F4CX		3) Replace the main board and check function. 4) Replace the HDD and check function. (*1) 5) Retrieve the USBLOG and contact the Service Administrative Division. (*1) For the HDD standard model only.		
F4DX	An error is detected at the Entity control section	1) Format the HDD and check function. (U024 FULL formatting) (*1) 2) Execute the U021 Memory initializing to initialize the controller backup memory and check function.		
F4EX		3) Replace the main board and check function. 4) Replace the HDD and check function. (*1) 5) Retrieve the USBLOG and contact the Service Administrative Division. (*1) For the HDD standard model only.		
F4FX	An error is detected at the Job control section	1) Format the HDD and check function. (U024 FULL formatting) (*1) 2) Execute the U021 Memory initializing to initialize the controller backup memory and check function. 3) Replace the main board and check function. 4) Replace the HDD and check function. (*1) 5) Retrieve the USBLOG and contact the Service Administrative Division. (*1) For the HDD standard model only.		
F50X	An error is detected at the FAX control section	1) Format the HDD and check function. (U024 FULL formatting) (*1) 2) Execute the U021 Memory initializing to initialize the controller backup memory and check function. 3) Replace the main board and check function. 4) Replace the HDD and check function. (*1) 5) Retrieve the USBLOG and contact the Service Administrative Division. (*1) For the HDD standard model only.		
F51X	An error is detected at the Job execution section	1) Format the HDD and check function. (U024 FULL formatting) (*1)		
F52X		2) Execute the U021 Memory initializing to initialize the controller backup memory and check function.		
F53X		3) Replace the main board and check function.		
F55X		4) Replace the HDD and check function. (*1)		
F56X		5) Retrieve the USBLOG and contact the Service Administrative Division.		
F57X		(*1) For the HDD standard model only.		







No.	Content	Check procedure & check point	Remark 1	TASKalfa 256ci/FS-C8525MFP, TASKalfa 206ci/FS-C8520MFP, TASKalfa 306i/FS-6530MFP, TASKalfa 256i/FS-6525MFP
F58X	An error is detected at the Service management section	1) Format the HDD and check function. (U024 FULL formatting) (*1) 2) Execute the U021 Memory initializing to initialize the controller backup memory and check function. 3) Replace the main board and check function. 4) Replace the HDD and check function. (*1) 5) Retrieve the USBLOG and contact the Service Administrative Division. (*1) For the HDD standard model only.		
F59X				
F5AX				
F5BX				
F5CX				
F5DX				
F5EX				
F5FX	An error is detected at the Service execution section	1) Format the HDD and check function. (U024 FULL formatting) (*1) 2) Execute the U021 Memory initializing to initialize the controller backup memory and check function. 3) Replace the main board and check function. 4) Replace the HDD and check function. (*1) 5) Retrieve the USBLOG and contact the Service Administrative Division. (*1) For the HDD standard model only.		
F60X	An error is detected at the Maintenance mode management section	1) Format the HDD and check function. (U024 FULL formatting) (*1) 2) Execute the U021 Memory initializing to initialize the controller backup memory and check function. 3) Replace the main board and check function. 4) Replace the HDD and check function. (*1) 5) Retrieve the USBLOG and contact the Service Administrative Division. (*1) For the HDD standard model only.		
F61X	An error is detected at the Report compiling section	1) Format the HDD and check function. (U024 FULL formatting) (*1) 2) Execute the U021 Memory initializing to initialize the controller backup memory and check function. 3) Replace the main board and check function. 4) Replace the HDD and check function. (*1) 5) Retrieve the USBLOG and contact the Service Administrative Division. (*1) For the HDD standard model only.		
F62X	An error is detected at the Service execution section	1) Format the HDD and check function. (U024 FULL formatting) (*1) 2) Execute the U021 Memory initializing to initialize the controller backup memory and check function. 3) Replace the main board and check function. 4) Replace the HDD and check function. (*1) 5) Retrieve the USBLOG and contact the Service Administrative Division. (*1) For the HDD standard model only.		
F63X	An error is detected at the Device control section	1) Format the HDD and check function. (U024 FULL formatting) (*1) 2) Execute the U021 Memory initializing to initialize the controller backup memory and check function. 3) Replace the main board and check function. 4) Replace the HDD and check function. (*1) 5) Retrieve the USBLOG and contact the Service Administrative Division. (*1) For the HDD standard model only.		
F64X	An error is detected at the Print image process section	1) Format the HDD and check function. (U024 FULL formatting) (*1) 2) Execute the U021 Memory initializing to initialize the controller backup memory and check function. 3) Replace the main board and check function. 4) Replace the HDD and check function. (*1) 5) Retrieve the USBLOG and contact the Service Administrative Division. (*1) For the HDD standard model only.		
F65X				
F66X				
F67X				

No.	Content	Check procedure & check point	Remark 1	TASKalfa 256ci/FS-C8525MFP, TASKalfa 206ci/FS-C8520MFP, TASKalfa 306i/FS-6530MFP, TASKalfa 256i/FS-6525MFP
F68X	An error is detected at the Storage device control section	1) Format the HDD and check function. (U024 FULL formatting) (*1) 2) Execute the U021 Memory initializing to initialize the controller backup memory and check function. 3) Replace the main board and check function. 4) Replace the HDD and check function. (*1) 5) Retrieve the USBLOG and contact the Service Administrative Division. (*1) For the HDD standard model only.	*F684 is overwrite error with the HDD security kit	
F69X	An error is detected at the HyPAS control section	1) Format the HDD and check function. (U024 FULL formatting) (*1) 2) Execute the U021 Memory initializing to initialize the controller backup memory and check function. 3) Replace the main board and check function. 4) Replace the HDD and check function. (*1) 5) Retrieve the USBLOG and contact the Service Administrative Division. (*1) For the HDD standard model only.		[Check the using CF] Main board: YC4 (Where the CF is inserted.)
F6AX				A certain part of the CF may be faulty. The frequency of failure occurrence is dependent on the frequency of access to the faulty bit. The main PWB may be faulty if the CF is not sensitive.
F6BX				
F6CX				
F6DX	An error is detected at the External Server management section	1) Check the external server and check function. 2) Check the connection to the external server and check function. 3) Check the network settings and check function. 4) Replace the bridge board and check function. 5) Replace the main board and check function. 6) Retrieve the USBLOG and contact the Service Administrative Division.	*FieryOption related	
F6EX				
F6FX				
F70X				
F71X				
F72X				
F73X				
F74X				
F75X				

This page is intentionally left blank.

(5) Chart of image adjustment procedures

Adjusting order	Item	Image	Description	Maintenance mode		Original	Page	Remarks
				Item No.	Mode			
1	Adjusting the magnification in the main scanning direction (printing adjustment)		Polygon motor speed adjustment	U053	POLYGON	U053 test pattern	P.1-3-29	
2	Adjusting the magnification in the auxiliary scanning direction (printing adjustment)		Drive motor speed adjustment	U053	MAIN	U053 test pattern	P.1-3-29	
3	Adjusting the center line of the MP tray (printing adjustment)		Adjusting the LSU print start timing	U034	LSUOUT LEFT (MPT)	U034 test pattern	P.1-3-24	To make an adjustment for duplex copying, select LSUOUT LEFT (DUPLEX).
4	Adjusting the center line of the cassettes (printing adjustment)		Adjusting the LSU print start timing	U034	LSUOUT LEFT (CASSETTE 1) LSUOUT LEFT (CASSETTE 2) LSUOUT LEFT (CASSETTE 3)	U034 test pattern	P.1-3-24	Cassette 1: select Center (CASSETTE 1) Cassette 2: select Center (CASSETTE 2) Cassette 3: select Center (CASSETTE 3)
5	Adjusting the leading edge registration of the MP tray (printing adjustment)		Registration motor turning on timing (secondary paper feed start timing)	U034	LSUOUT TOP MPT(L) LSUOUT TOP MPT(S)	U034 test pattern	P.1-3-24	To make an adjustment for duplex copying, select LSUOUT TOP DUPLEX. L: PAPER WIDTH 218mm or more S: PAPER WIDTH less than 218mm
6	Adjusting the leading edge registration of the cassette (printing adjustment)		Registration motor turning on timing (secondary paper feed start timing)	U034	LSUOUT TOP CASSETTE(L) SUOUT TOP CASSETTE(S)	U034 test pattern	P.1-3-24	L: PAPER WIDTH 218mm or more S: PAPER WIDTH less than 218mm
7	Adjusting the leading edge margin (printing adjustment)		LSU illumination start timing	U402	LESD	U402 test pattern	P.1-3-77	
8	Adjusting the trailing edge margin (printing adjustment)		LSU illumination end timing	U402	TRAIL	U402 test pattern	P.1-3-77	
9	Adjusting the left and right margins (printing adjustment)		LSU illumination start/end timing	U402	A MARGIN C MARGIN	U402 test pattern	P.1-3-77	
10	Adjusting magnification of the scanner in the main scanning direction (scanning adjustment)		Data processing	U065 U070	Y SCAN ZOOM Y SCAN ZOOM	Test chart	P.1-3-31 P.1-3-37	U065: For copying an original placed on the platen. U070: For copying originals from the DP.

Adjusting order	Item	Image	Description	Maintenance mode		Original	Page	Remarks
				Item No.	Mode			
11	Adjusting magnification of the scanner in the auxiliary scanning direction (scanning adjustment)		Original scanning speed	U065	X SCAN ZOOM	Test chart	P.1-3-31	U065: For copying an original placed on the platen. U070: For copying originals from the DP.
				U070	X SCAN ZOOM		P.1-3-37	
12	Adjusting the center line (scanning adjustment)		Adjusting the original scan data (image adjustment)	U067	FRONT ROTATE	Test chart	P.1-3-34	U067: For copying an original placed on the platen. To make an adjustment for rotate copying, select ROTATE. U072: For copying originals from the DP. To make an adjustment for duplex copying, select BACK.
				U072	FRONT BACK		P.1-3-40	
13	Adjusting the leading edge registration (scanning adjustment)		Original scan start timing	U066	FRONT ROTATE	Test chart	P.1-3-33	U066: For copying an original placed on the platen. To make an adjustment for trailing edge registration, select ROTATE. U071: For copying originals from the DP. To make an adjustment for duplex copying, select BACK HEAD.
				U071	FRONT HEAD BACK HEAD		P.1-3-38	
14	Adjusting the leading edge margin (scanning adjustment)		Adjusting the original scan data (image adjustment)	U403	B MARGIN	Test chart	P.1-3-78	U403: For copying an original placed on the contact glass U404: For copying originals from the DP.
				U404	B MARGIN		P.1-3-79	
15	Adjusting the trailing edge margin (scanning adjustment)		Adjusting the original scan data (image adjustment)	U403	D MARGIN	Test chart	P.1-3-78	U403: For copying an original placed on the contact glass U404: For copying originals from the DP.
				U404	D MARGIN		P.1-3-79	
16	Adjusting the left and right margins (scanning adjustment)		Adjusting the original scan data (image adjustment)	U403	A MARGIN	Test chart	P.1-3-78	U403: For copying an original placed on the contact glass U404: For copying originals from the DP.
				U404	C MARGIN A MARGIN C MARGIN		P.1-3-79	

When maintenance item U411 (Automatic adjustment in the scanner) is run using the specified original (P/N 7505000005), the following adjustments are automatically made:
 Adjusting the scanner magnification (U065)
 Adjusting the scanner leading edge registration (U066)
 Adjusting the scanner center line (U067)

When maintenance item U411 (Automatic adjustment in the DP) is run using the specified original (P/N 302AC68243), the following adjustments are automatically made:

* : When running this test chart, you first must clean the feed rollers with alcohol and ensure the DP width guides are correctly positioned against the original.


Adjusting the DP magnification (U070)
 Adjusting the DP leading edge registration (U071)
 Adjusting the DP center line (U072)





Image quality

Item	Specifications
100% magnification	Machine: ±0.8% Using DP: ±1.5%
Enlargement/reduction	Machine: ±1.0% Using DP: ±1.5%
Lateral squareness	Machine: ±1.5 mm/375 mm Using DP: ±3.0 mm/375 mm
Leading edge registration	Cassette: ±2.5 mm MP tray: ±2.5 mm Duplex: ±2.5 mm
Skewed paper feed (left-right difference)	Cassette: 1.5 mm or less MP tray: 1.5 mm or less Duplex: 2.0 mm or less
Lateral image shifting	Cassette: ±2.0 mm MP tray: ±2.0 mm Duplex: ±3.0 mm


(6) Wiring diagram



















PF-470/471 (Paper feeder) Installation Guide


PF-470/471 PAPER FEEDER

PF-470



PF-471





(ENG)

Fix Paper Width Guide

You can fix the paper width guide using the supplied retaining pins. Follow the steps below as necessary.

(FR)

Fixation du guide de largeur du papier

Vous pouvez fixer le guide de largeur du papier en utilisant les goupilles de fixation fournies.

Suivez les étapes ci-dessous en fonction des besoins.

(ES)

Fijar la guía de anchura del papel

Puede fijar la guía de anchura del papel con los pernos de retén proporcionados. Siga los pasos siguientes según sea necesario.

(DE)

Papierbreitenführung befestigen

Sie können die Papierbreitenführung mit den gelieferten Haltebolzen befestigen. Folgen Sie den Schritten unten falls notwendig.

(IT)

Fissare la guida di larghezza carta

Per fissare la guida di larghezza carta, utilizzare i perni di fissaggio forniti. Eseguire i seguenti punti come necessario.

(CN)

固定纸张宽度导板

您可以使用附带的定位销固定纸张宽度导板。

必要时执行如下步骤。

(TW)

固定紙張寬度導板

您可以使用隨附的定位卡榫固定紙張寬度導板。

如有必要，請執行以下步驟。

(KO)

용지폭 가이드 고정

기기와 함께 제공된 핀으로 용지폭 가이드를 고정시킬 수 있습니다.



필요하면 아래의 작업을 하십시오.

(JP)

用紙幅ガイドの固定

用紙幅ガイドは同梱のピンで固定することが可能です。

必要に応じて、以下の作業を行って下さい。






DF-470/AK-470 (Document finisher) Installation Guide





DF-470 DOCUMENT FINISHER , AK-470 ATTACHMENT KIT

for

Black & White MFP 25/30

Color MFP 20/25





FAX System(U) Installation Guide










FAX System(U)

.....1


.....1
(100V0)

AU
JP US PJJWC0016Z (UL Listed, HUAN HSIN Type TL)

Black & White MFP 25/30




1	LINE connector	Connect the modular cord for the telephone line to this connector.
2	TEL connector	When using a commercially available telephone set, connect the modular cord to this connector.
1	Connecteur LINE	Brancher le cordon pour la ligne téléphonique sur cette prise.
2	Connecteur TEL	Lors de l'utilisation d'un téléphone standard, brancher le cordon téléphonique à cette prise.
1	Conector de LINEA	Conecte el cable modular de la línea telefónica a este conector.
2	Conector TEL	Si utiliza un aparato telefónico de los disponibles en el mercado, conecte el cable modular a este conector.
1	Leitungs-anschluss-buchse	Verbinden Sie diesen Anschluss mit der Telefondose.
2	Telefonanschlussbuchse	Hier kann ein Telefon angeschlossen werden.
1	Connettore LINEA	Collegare a questo connettore il cavo modulare della linea telefonica.
2	Connettore TEL	Se si desidera collegare al sistema un normale telefono, collegarlo a questo connettore.
1	LINHA conector	Conecte o cabo modular para a linha telefónica a este conector.
2	TEL conector	Ao usar um aparelho telefónico disponível comercialmente, conecte o cabo modular a este conector.
1	LINE接続コネクター	電話回線のモジュラーコードを接続してください。
2	TEL接続コネクター	市販の電話機を併用する場合は、ここに接続してください。



FAX Setup Wizard

ENG

The machine provides Quick Setup Wizard in System Menu to set the FAX. Follow the instructions on the operation panel.




BR

A máquina fornece o Assistente de Configuração Rápida no Menu de Sistema para configurar o FAX. Siga as instruções no painel de operação.




CZ

V systémové nabídce zařízení najdete Průvodce rychlým nastavením, pomocí něhož můžete nastavit FAX. Postupujte podle pokynů na provozním panelu.




DE

Die Maschine bietet den Schnelleinstieg Wizard im Systemmenü an, um das Fax einzustellen. Folgen Sie den Anweisungen auf dem Bedienfeld.




DK

Maskinen indeholder en Guide til hurtig opsætning i System menuen til indstilling af faxen. Følg anvisningerne på betjeningspanelet.




ES

La máquina dispone del Asistente de configuración rápida en el Menú Sistema para configurar el fax. Siga las instrucciones del panel de controles.




FI

Laitteen Järjestelmä-valikossa on ohjattu pika-asennustoiminto faksin asetusta varten. Noudata käyttöpaneelin ohjeita.




FR

L'appareil prévoit un Assistant de configuration rapide dans le menu système pour régler les paramètres du fax. Suivez les instructions sur le panneau de commande.




GR

Το μηχάνημα διαθέτει έναν Οδηγό Γρήγορης Εγκατάστασης στο Μενού Συστήματος για τη ρύθμιση του ΦΑΞ. Ακολουθήστε τις οδηγίες που εμφανίζονται στον πίνακα λειτουργίας.




HEB

המכשיר מספק אשף הגדרה מהירה בתפריט המערכת, להגדרת הפקס. פעל לפי ההוראות המופיעות בלוח המפעיל.



HU

A rendszeremenüben a gyors telepítő varázsló lehetővé teszi a FAX beállítását. Kövesse a kezelőpultján megjelenő utasításokat.



IT

È possibile utilizzare la procedura guidata di installazione rapida reperibile nel Menu Sistema per la configurazione del modulo FAX. Attenersi alle istruzioni visualizzate sul pannello comandi.




NL

In het Systeemmenu van het apparaat bevindt zich de wizard Snel installeren om de fax in te stellen. Volg de instructies op het bedieningspaneel van de fax.




NO

Maskinen har en Hurtigoppsettveiviser i Systemmenyen til innstilling av faksen. Følg veiledningen på betjeningspanelet.



PL

W menu systemowym urządzenia dostępny jest Przewodnik szybkiej instalacji, który pozwoli ustawić funkcję FAKSU. Wykonuj instrukcje z panelu operacyjnego.




PT

A máquina proporciona o Assistente de Configuração Rápida no Menu do Sistema para definir o FAX. Siga as instruções no painel de funcionamento.



RO

Echipamentul are un expert de configurare rapidă în meniul Sistem pentru configurarea faxului. Urmați instrucțiunile din panoul de utilizare.




RU

Аппарат позволяет запустить мастер быстрой установки из системного меню для настройки факса. Выполните инструкции на панели управления.



SV

Maskinen har en snabbstartguide i systemmenyn för att ställa in faxen. Följ instruktionerna som anges på kontrollpanelen.




TR

Cihaz FAKS ayarlamak için Sistem Menüsinde Hızlı Kurulum Sihirbazı sunar. İşletim panosundaki talimatları izleyin.



ARA

يوفر الجهاز معالج الإعداد السريع في قائمة النظام لإعداد الفاكس. اتبع التعليمات الموجودة على لوحة التشغيل.



CN

可通过机器系统菜单中的快速设置向导设置传真。请遵循操作面板上的指导说明。



TW

可透過系統選單中的快速設定精靈進行傳真設定。請依照操作面板上的指示說明。



KO

기기의 시스템 메뉴에서 팩스를 설정할 수 있도록 빠른 설정 방법을 제공합니다. 조작 패널에 표시된 지침을 따르십시오.



JP

本機は、システムメニューに簡単セットアップウィザードを搭載しております。画面にしたがってファクスを設定してください。



TONER

KYOCERA Document Solutions America, Inc.

Headquarters

225 Sand Road,
Fairfield, New Jersey 07004-0008, USA
Phone: +1-973-808-8444
Fax: +1-973-882-6000

Latin America

8240 NW 52nd Terrace Dawson Building, Suite 100
Miami, Florida 33166, USA
Phone: +1-305-421-6640
Fax: +1-305-421-6666

KYOCERA Document Solutions Canada, Ltd.

6120 Kestrel Rd., Mississauga, ON L5T 1S8,
Canada
Phone: +1-905-670-4425
Fax: +1-905-670-8116

KYOCERA Document Solutions Mexico, S.A. de C.V.

Calle Arquimedes No. 130, 4 Piso, Colonia Polanco
Chapultepec, Delegacion Miguel Hidalgo,
Distrito Federal, C.P. 11560, México
Phone: +52-555-383-2741
Fax: +52-555-383-7804

KYOCERA Document Solutions Brazil, Ltda.

Av. Tambore, 1180 Mod. B-09 CEP 06460-000
Tambore-Barueri-SP, Brazil
Phone: +55-11-4195-8496
Fax: +55-11-4195-6167

KYOCERA Document Solutions Australia Pty. Ltd.

Level 3, 6-10 Talavera Road North Ryde N.S.W, 2113,
Australia
Phone: +61-2-9888-9999
Fax: +61-2-9888-9588

KYOCERA Document Solutions New Zealand Ltd.

1-3 Parkhead Place, Albany, Auckland 1330,
New Zealand
Phone: +64-9-415-4517
Fax: +64-9-415-4597

KYOCERA Document Solutions Asia Limited

16/F., Mita Centre, 552-566, Castle Peak Road
Tsuenwan, NT, Hong Kong
Phone: +852-2610-2181
Fax: +852-2610-2063

KYOCERA Document Solutions (Thailand) Corp., Ltd.

335 Ratchadapisek Road, Bangsue, Bangkok 10800,
Thailand
Phone: +66-2-586-0333
Fax: +66-2-586-0278

KYOCERA Document Solutions Singapore Pte. Ltd.

12 Tai Seng Street #04-01A,
Luxasia Building, Singapore 534118
Phone: +65-6741-8733
Fax: +65-6748-3788

KYOCERA Document Solutions Hong Kong Limited

16/F., Mita Centre, 552-566, Castle Peak Road
Tsuenwan, NT, Hong Kong
Phone: +852-2429-7422
Fax: +852-2423-2159

KYOCERA Document Solutions Taiwan Corporation

6F., No.37, Sec. 3, Minquan E. Rd.,
Zhongshan Dist., Taipei 104, Taiwan R.O.C.
Phone: +886-2-2507-6709
Fax: +886-2-2507-8432

KYOCERA Document Solutions Korea Co., Ltd.

18F, Kangnam bldg, 1321-1,
Seocho-Dong, Seocho-Gu, Seoul, Korea
Phone: +822-6933-4050
Fax: +822-747-0084

KYOCERA Document Solutions India Private Limited

First Floor, ORCHID CENTRE
Sector-53, Golf Course Road, Gurgaon 122 002,
India
Phone: +91-0124-4671000
Fax: +91-0124-4671001

KYOCERA Document Solutions Europe B.V.

Bloemlaan 4, 2132 NP Hoofddorp,
The Netherlands
Phone: +31-20-654-0000
Fax: +31-20-653-1256

KYOCERA Document Solutions Nederland B.V.

Beechavenue 25, 1119 RA Schiphol-Rijk,
The Netherlands
Phone: +31-20-5877200
Fax: +31-20-5877260

KYOCERA Document Solutions (U.K.) Limited

8 Beacontree Plaza,
Gillette Way Reading, Berkshire RG2 0BS,
United Kingdom
Phone: +44-118-931-1500
Fax: +44-118-931-1108

KYOCERA Document Solutions Italia S.p.A.

Via Verdi, 89/91 20063 Cernusco s/N.(MI),
Italy
Phone: +39-02-921791
Fax: +39-02-92179-600

KYOCERA Document Solutions Belgium N.V.

Sint-Martinusweg 199-201 1930 Zaventem,
Belgium
Phone: +32-2-7209270
Fax: +32-2-7208748

KYOCERA Document Solutions France S.A.S.

Espace Technologique de St Aubin
Route de l'Orme 91195 Gif-sur-Yvette CEDEX,
France
Phone: +33-1-69852600
Fax: +33-1-69853409

KYOCERA Document Solutions Espana, S.A.

Edificio Kyocera, Avda. de Manacor No.2,
28290 Las Matas (Madrid), Spain
Phone: +34-91-6318392
Fax: +34-91-6318219

KYOCERA Document Solutions Finland Oy

Atomitie 5C, 00370 Helsinki,
Finland
Phone: +358-9-47805200
Fax: +358-9-47805390

KYOCERA Document Solutions**Europe B.V., Amsterdam (NL) Zürich Branch**

Hohlstrasse 614, 8048 Zürich,
Switzerland
Phone: +41-44-9084949
Fax: +41-44-9084950

**KYOCERA Document Solutions
Deutschland GmbH**

Otto-Hahn-Strasse 12, 40670 Meerbusch,
Germany
Phone: +49-2159-9180
Fax: +49-2159-918100

KYOCERA Document Solutions Austria GmbH

Eduard-Kittenberger-Gasse 95, 1230 Vienna,
Austria
Phone: +43-1-863380
Fax: +43-1-86338-400

KYOCERA Document Solutions Nordic AB

Esbogatan 16B 164 75 Kista, Sweden
Phone: +46-8-546-550-00
Fax: +46-8-546-550-10

KYOCERA Document Solutions Norge NUF

Postboks 150 Oppsal, 0619 Oslo,
Norway
Phone: +47-22-62-73-00
Fax: +47-22-62-72-00

KYOCERA Document Solutions Danmark A/S

Ejby Industrivej 60, DK-2600 Glostrup,
Denmark
Phone: +45-70223880
Fax: +45-45765850

KYOCERA Document Solutions Portugal Lda.

Rua do Centro Cultural, 41 (Alvalade) 1700-106 Lisboa,
Portugal
Phone: +351-21-843-6780
Fax: +351-21-849-3312

KYOCERA Document Solutions**South Africa (Pty) Ltd.**

49 Kyalami Boulevard,
Kyalami Business Park 1685 Midrand, South Africa
Phone: +27-11-540-2600
Fax: +27-11-466-3050

KYOCERA Document Solutions Russia LLC

Botanichesky pereulok 5, Moscow, 129090,
Russia
Phone: +7(495)741-0004
Fax: +7(495)741-0018

KYOCERA Document Solutions Middle East

Dubai Internet City, Bldg. 17,
Office 157 P.O. Box 500817, Dubai,
United Arab Emirates
Phone: +971-04-433-0412

KYOCERA Document Solutions Inc.

2-28, 1-chome, Tamatsukuri, Chuo-ku
Osaka 540-8585, Japan
Phone: +81-6-6764-3555
<http://www.kyoceradocumentsolutions.com>