



1: From the “Command Interface” select the “Basic” tab and click “Addressbook => Contacts”.



2: Click “Add Contact” to add a new user.



- 3: In the new window enter a name for the user.
- 4: If appropriate, enter the users email address.
- 5: Enter the Hostname or IP address of the PC where the files are to be sent to.
- 6: Enter the name of the shared folder on the PC where the files are sent to.
- 7: Enter the Hostname or IP address of the FTP server.
- 8: Enter the name of the folder on the FTP server where files are to be sent to.



- 9: Click “Submit” on the bottom of the page to confirm these settings.

IMPORTANT:

- SMB:**
- Shared folder path entered at step 6 starts with the shared folder name, see sample image.
 - On the PC with the shared folder make sure a user is created whom has ALL rights, read and write, to access this folder.
 - If the PC is member of a domain you need to add this user on the domain controller.
 - Test the share by attempting access from another PC using set username and password.
- FTP:**
- Shared folder path entered at step 8 starts with the shared folder name, see sample image.