



FS-720/820/920

PARTS LIST

Published in June 2005

2GLPL071

842GL121

Version 2.0

NOTES

1.Indicate parts number and machine model when placing an order.

e.g.	Parts Number	Parts Name	Machine Model	Cycle	Quantity
	302GL04010	COVER LID TOP	FS-720	50Hz/60Hz	1
	5MVB872SH033	COVER LID TOP	FS-820	50Hz/60Hz	1
	5MVB872SH034	COVER LID TOP	FS-920	50Hz/60Hz	1

2.Service calls and freight will be charged separately.

3.Symbols in the "Parts Number" column.

- Parts with "•" are component parts or sub-assemblies of the assembly appearing immediately above them.

e.g.	Parts Number	Parts Name	Parts Number	Parts Name
	302FV93080	CT-110	•2DC07010	STOPPER PAPER
			•5MVX541DG003	LEVER SIDE

- Parts with "⊙" indicates the spare parts and the parts without "⊙" can not be supplied.

CONTENTS

FIG. 1	EXTERIOR COVERS.....	2
FIG. 2	FRAMES I.....	4
FIG. 3	FRAMES II.....	6
FIG. 4	CASSETTE SECTION.....	8
FIG. 5	DRIVING, COOLING SECTION.....	10
FIG. 6	IMAGE FORMATION SECTION.....	12
FIG. 7	DEVELOPING UNIT.....	14
FIG. 8	FIXING SECTION.....	16
FIG. 9	PARTS PACKAGES.....	18
	• INDEX.....	19




FIG. 1 EXTERIOR COVERS

2GL/2FV/2FW-Ver2.0

SP	Ref. No.	Part.No.	Alternative.	Description	Quantity		
					110	120	230
⊙	1	5MVB877SB011	2FV04100	BASE LID	1	1	1
⊙	2	5MVB771SH002	2FV04090	COVER LID L	1	1	1
⊙	3	5MVB771SH003	2FV04080	COVER LID R	1	1	1
	4	302FV04180	2FV04180	PLATE TRAY L	1	1	1
	5	302FV04190	2FV04190	PLATE TRAY R	1	1	1
⊙	6	5AAPRCZC1015AHR	2FV01050	P.W.BOARD ASSY KP-1111	1	1	1
⊙	7	5MVB886SB013	2FV04010	BASE TOP	1	1	1
	8	5MMW126SD001	2FV04130	SPRING COVER REAR	1	1	1
⊙	9	5MMW603LD002	2FV04120	SPRING PULLEY FD	2	2	2
⊙	10	5MVB652SB015	2FV04110	TRAY FD	1	1	1
	11	5MVX664SB003	2FV02140	GUIDE CF	1	1	1
⊙	12	302GL04010	2GL04010	COVER LID TOP (FS-720)	1	1	1
⊙	12	5MVB872SH033	2FV04070	COVER LID TOP (FS-820)	1	1	1
⊙	12	5MVB872SH034	2FW04010	COVER LID TOP (FS-920)	1	1	1
⊙	13	5MVB874SB011	2FV04060	COVER REAR	1	1	1
⊙	14	5MVB882SH007	2FV04050	COVER RIGHT SUB	1	1	1
⊙	15	5MVB882SH008	2FV04040	COVER TOP	1	1	1
⊙	16	5MVB883SH033	2FV04030	COVER LEFT	1	1	1
⊙	17	5MVB885SH029	2FV04020	COVER RIGHT	1	1	1
⊙	18	5MVM363DB001	2FV04150	PULLEY FD	2	2	2
⊙	19	5MVS625XF001	2FV04140	DISCHARGER FD	2	2	2
⊙	20	5MVX321AC002	2FV04170	LENS LED	1	1	1
⊙	21	5MVX662SH006	2FV04160	BUTTON	1	1	1
	22	302FV04200	2FV04200	SPRING COVER REAR R	1	1	1
⊙	23	302FV04210	2FV04210	SHEET FD	2		

- Parts with "*" are component parts or sub-assemblies of the assembly appearing immediately above them.
- Parts with "⊙" indicates the spare parts.




FIG. 2 FRAMES I

2GL/2FV/2FW-Ver2.0

SP	Ref. No.	Part.No.	Alternative.	Description	Quantity		
					110	120	230
⊙	1	5MVX888CB001	2FV02170	FRAME BASE	1	1	1
	2	302FV00030	2FV00030	TE SENSOR ASY	1	1	1
	5	5MVX431DN005	2FV02100	LEVER LOCK DLP	2	2	2
	6	5MMW261LD067	2FV02270	SPRING LEVER LOCK L	1	1	1
	7	5MMW261LD068	2FV02280	SPRING LEVER LOCK R	1	1	1
	8	5MMW261LD036	2A814570	SPRING TE SENSOR	1	1	1
	9	5MVX865SB008	2FV02160	GUIDE FEED	1	1	1
	10	5MMU862SL001	2FV02250	PLATE EARTH GUIDE	1	1	1
	11	5MVS812XF003	2A816120	TAPE BRUSH	1	1	1
	12	5MMS821LD014	2A816080	BRUSH DISCHARGER	1	1	1
	13	5MVS812KF006	2A816090	SHEET DISCHARGER	1	1	1
	14	302FV02510	2FV02510	LABEL JAM OPERATION	1	1	1
⊙	15	5MMT876SN104	2FV02230	ROLLER TRANSFER	1	1	1
⊙	16	5MVG127DN131	2FV02030	GEAR TC Z17	1	1	1
⊙	17	5MVX221DB023	2A816020	BUSH TC L	1	1	1
⊙	18	5MMW251LD043	2A816040	SPRING TC L	1	1	1
⊙	19	5MVX221DW008	2A816030	BUSH TC R	1	1	1
⊙	20	302FV02490	2FV02490	SPRING TC R	1	1	1
	21	302FV02480	2FV02480	SPRING ROLL	2	2	2
	22	302FV14500	2FV14500	LABEL GUIDE DLP	1	1	1
	23	5MMX331LD005	2FV02330	PLATE CONTACT TC	1	1	1
⊙	24	5MVS721KF007	2FV02390	SHEET REGIST	2	2	2
	25	5MMT875SN016	2FV02220	ROLLER FD	1	1	1
	26	302FV02470	2FV02470	BUSH FD	1	1	1
⊙	27	302FV45010	2FV45010	FAN MOTOR	1	1	1
	28	302FV02500	2FV02500	SHEET FAN	1	1	1
	29	5MVB763CB001	2FV02010	COVER MC	1	1	1
	30	5MMX763LD007	2FV02370	PLATE CONTACT MC	1	1	1
	31	5MVX763SB011	2FV02150	ROD INTERLOCK	1	1	1
	32	5MMW451LD001	2B700570	SPRING INTERLOCK	1	1	1
⊙	33	5MVX221DB019	2A806420	BUSH REGIST LEFT	1	1	1
⊙	34	5MMW261LD023	2A806410	SPRING REGIST R	2	2	2
⊙	35	5MMT865SN010	2A806050	ROLLER REGIST UP	1	1	1
⊙	36	5MMT876SN105	2FV02240	ROLLER REGIST LOW	1	1	1
⊙	37	2FM02180		BUSH REGIST C	1	1	1
⊙	38	5MVX221DW006	2A806430	BUSH REGIST RIGHT	1	1	1
⊙	39	5MVG127DB047	2A806230	GEAR REGIST Z20	1	1	1
⊙	40	5MVG126DB025	2A806240	GEAR REGIDT Z13	1	1	1
⊙	41	5MVM776DB001	2FV02090	PULLEY FEED	1	1	1
⊙	42	5AAVR0LL+044	2A806010	ROLLER FEED ASSY	1	1	1
	43	5MVM176DN016	2BR20170	BUSH A	2	2	2
	44	5MMT365SN003	2A815020	PIN CONTACT BIAS	1	1	1
	45	5MMW361LD028	2FV02310	SPRING PIN BIAS	1	1	1
	46	5MVX552DB001	2FV02130	ACTUATOR EMPTY	1	1	1
⊙	47	5MVX441SB006	2FV02110	ACTUATOR REGIST	1	1	1
	48	5MMW261LD066	2FV02260	SPRING ACTUATOR	1	1	1
	49	5MVX432SB014	2FV02460	BKT ACTUATOR EXIT	1	1	1
⊙	50	5MVX442SB011	2FV02120	ACTUATOR EXIT	1	1	1
	51	5MMW261LD069	2FV02290	SPRING EXIT	1	1	1
	52	5MMT766SN011	2FV02210	SHAFT FEED	1	1	1

SP	Ref. No.	Part.No.	Alternative.	Description	Quantity		
					110	120	230
⊙	53	5AAVCLTCH032	2FV02180	CLUTCH REGIST	1	1	1
⊙	54	5AAVCLTCH028	2BY02020	CLUTCH FEED	1	1	1
	55	5MMX643LD006	2FV02360	PLATE EARTH B	1	1	1
⊙	56	5MMT463SN002	2FV02200	PIN DRIVE	2	2	2
⊙	57	5MVG138DN088	2FV02040	GEAR FREE Z28S	1	1	1
⊙	58	5MVG158DN059	2FV02060	GEAR FREE Z46H	1	1	1
	59	5MMW371LD006	2FV02320	SPRING FREE	1	1	1
⊙	60	5MVG148DN107	2FV02050	GEAR Z34S	1	1	1
⊙	61	5MVG158DN060	2FV02070	GEAR FD Z42S	1	1	1
⊙	62	5MVG158DN061	2FV02080	GEAR FD Z45S	1	1	1
⊙	63	5MVG127DN130	2FV02020	GEAR FD Z19S	1	1	1
	64	302GL03010	2GL03010	LID CONTROLLER (FS-720)	1	1	1
	64	5MMX774SL002	2FV03010	LID CONTROLLER (FS-820/920)	1	1	1
⊙	65	5AAPRLGC2029AHR	2GL01000	P.W.BOARD ASSY (FS-720)	1	1	1
⊙	65	5AAPRLGR2010AHR	2FV01180	P.W.BOARD ASSY (FS-820)	1	1	1
⊙	65	5AAPRLGR2010BHR	2FV01000	P.W.BOARD ASSY (FS-920)	1	1	1
	66	302FV03020	2FV03020	BOX COCONTROLLER	1	1	1
	67	5MMX522LD013	2FV02340	PLATE EARTH FEED	2	2	2
	68	2FM02580		SPRING REGIST C	1	1	1
	69	5MVX111DN003	2A806250	RING STOPPER	5	5	5
	70	5MBSPP3006NW++R	B0B03060	PAN HEAD SCREW(+)/ M3 X 6 (FS-720)	1	1	1
	70	5MBSPP3006NW++R	B0B03060	PAN HEAD SCREW(+)/ M3 X 6 (FS-820/920)	3	3	3
	71	5MBTPB4010WW	B8204100	BIND T.T SCREW(+)/ M4 X 10	9	9	9
	72	B4B74100		+TP T.T SCREW(+)/ M4 X 10 CRFREE B-T	6	6	6
⊙	73	5MBWK41A03NN	C2891100	POLY-SLIDER WASHER 4.1X10X0.3T	2	2	2
⊙	74	5MBWW43802SP++R	C3790080	WAVE WASHER / M4X8.0X0.2T	1	1	1
⊙	75	5MBWK4165+NN	C2894650	POLY SLIDER / M4.1X6.5X0.25T	1	1	1
⊙	76	5MBP2008WWLD	E1120080	SPRING PIN / M2 X 8	1	1	1
	77	5MBTPB3006TW++R	B1A53060	BIND T.T SCREW(+)/ M3 X 6	4	4	4

• Parts with "*" are component parts or sub-assemblies of the assembly appearing immediately above them.

• Parts with "⊙" indicates the spare parts.




FIG. 3 FRAMES II

2GL/2FV/2FW-Ver2.0

SP	Ref. No.	Part.No.	Alternative.	Description	Quantity		
					110	120	230
⊙	1	302FV01241	2FV01241	P.W.B.ASSY E SERVICE	1	1	1
	2	5MVS777CB001	2FV02000	COVER PWB	1	1	1
	3	5MMX884SL002	2FV02380	PLATE BOTTOM FRAME	1	1	1
⊙	4	5AAEZB12E++1++P	2FV28010	SWITCHING REGULATOR			1
⊙	4	5AAEZB12U++1++P	2FV28020	SWITCHING REGULATOR	1	1	
	5	5MMX541LD002	2FV02350	PLATE EARTH A	1	1	1
	6	5MMS875SL007	2FV12020	COVER SCANNER	1	1	1
⊙	7	302FV93092	2FV93092	LK-110	1	1	1
	8	5AACCNWSW2GEA++R	2FV26020	CONN CORD ASSY	1	1	1
	9	302FV26052	2FV26052	CONN. CORD ASSY ENGINE-LSU	1	1	1
	10	302FV12080	2FV12080	LABEL LASER CAUTION	1	1	1
	11	5MVX876XB002	2FV12060	FRAME MID	1	1	1
	12	5MVX821SB014	2FV12050	SHUTTER LSU	1	1	1
	13	302FV12070	2FV12070	SHEET ERASER	1	1	1
⊙	14	5AAPRELC1008AHR	2FV01100	P.W.B ASSY KP-5157	1	1	1
	15	2DC13030		MIRROR LSU	1	1	1
	16	5MMX221LD034	2FV12030	SPRING MIRROR	2	2	2
	17	5MVX631SB006	2FV02420	LEVER STOPPER L	1	1	1
	18	5MMW165SD001	2FV02400	SPRING STOPPER L	1	1	1
	19	5MVX631SB007	2FV02430	LEVER STOPPER R	1	1	1
	20	5MMW165SD002	2FV02410	SPRING STOPPER R	1	1	1
	21	5MMW261LD070	2FV12010	SPRING FULL SENSOR	1	1	1
⊙	22	302FV00040	2FV00040	FULL SENSOR ASSY	1	1	1
	25	5MVX431SB012	2FV02450	RAIL FRAME	4	4	4
	26	5MVX221RB014	2BS03110	FOOT	4	4	4
	27	5MBTPB3008PW++R	B1A63080	BIND T.T SCREW(+) / M3 X 8	2	2	2
	28	5MBTPB3012PW++R	B1A63120	BIND T.T SCREW(+) / M3 X 12	3	3	3
	29	5MBTPB4010WW	B8204100	BIND T.T SCREW(+) / M4 X 10	6	6	6
	30	BAB53060	B1A53060	+TP TAP-TITE S SCREW M3X06	7	7	7
	31	5MBTPB4006TW++R	B1A54060	BIND T.T SCREW(+) / M4 X 6	1	1	1
	32	BAA63080		+TP TAP-TITE P SCREW M3X08	1	1	1
	33	B4B74100		+TP T.T SCREW(+) / M4 X 10 CRFREE B-T	8	8	8
	34	5MBWG40854LD	CP003020	OT.LOCK WASHER / M4X8.5X0.4T	1	1	1
	35	302FW02050	2FW02050	SHEET PAPER CHUTE	1	1	1

• Parts with "*" are component parts or sub-assemblies of the assembly appearing immediately above them.

• Parts with "⊙" indicates the spare parts.




FIG. 4 CASSETTE SECTION

2GL/2FV/2FW-Ver2.0

SP	Ref. No.	Part.No.	Alternative.	Description	Quantity		
					110	120	230
⊙		302FV93080	2FV93080	CT-110	1	1	1
	1	*2DC07010		STOPPER PAPER	1	1	1
	2	*5MVX541DG003	2A807161	LEVER SIDE	1	1	1
	3	*5MVX642SH010	2A807100	SEPARATOR PAPER	1	1	1
	4	*2DC07020		POSITIONING FOLIO PAPER	1	1	1
	5	*5MMX631LD003	2A807180	GUIDE SEPARATOR	1	1	1
	6	*2FV06180		BOTTOM CASSETTE	1	1	1
	7	*5MVG127DN071	2A807050	GEAR CASSETTE	2	2	2
	8	*5MMP141LD002	2A807510	PLATE SIDE GUIDE	1	1	1
	9	*5MMP141LD003	2A807520	PLATE STOPPER	1	1	1
	10	*5MVB864SB024	2FV06100	TRAY MULTI	1	1	1
	11	*5MVB887SB002	2FV06010	BASE CASSETTE	1	1	1
	12	*5MVX321SG002	2FV06090	MARKER INDICATOR	1	1	1
	13	*5MVX664SH005	2FV06070	LEVER PAPER INDICATOR	1	1	1
	14	*5MVX762SB019	2FV06040	GUIDE MULTI L	1	1	1
	15	*5MVX762SB020	2FV06050	GUIDE MULTI R	1	1	1
	16	*5MVX864SB013	2FV06060	GUIDE TURN	1	1	1
	17	*5MVX876SB010	2FV06020	COVER CASSETTE	1	1	1
	18	*5MVX541DG002	2A807191	LEVER REAR	1	1	1
	19	*5MVX631DN001	2FV06030	LOCK CASSETTE	2	2	2
	20	*302A807031	2A807031	GUIDE SIDE L	1	1	1
	21	*302A807021	2A807021	GUIDE SIDE R	1	1	1
	22	*5MMS856SL001	2A807170	PLATE BOTTOM	1	1	1
	23	*5MVS616XN001	2A807080	PAD BOTTOM	1	1	1
	24	*302FV06190	2FV06190	PAD SEPARATOR	1	1	1
	25	*2DC07040		FILM SEPARATOR	1	1	1
⊙	26	*5MMW552LD004	2FV06120	SPRING CASSETTE	2	2	2
	27	*5MMW251LD047	2A807110	SPRING SEPARATOR C	1	1	1
	28	*5MVS631TX001	3BW07040	TAPE SEPARATOR OP	1	1	1
	29	*5MMW251LD045	2A807140	SPRING LOCK	2	2	2
	30	*5MMW171LD006	2A807530	SPRING STOPPER	1	1	1
	31	*302FV06210	2FV06210	LABEL MANUAL FEED	1	1	1

- Parts with "*" are component parts or sub-assemblies of the assembly appearing immediately above them.
- Parts with "⊙" indicates the spare parts.




FIG. 5 DRIVING, COOLING SECTION

2GL/2FV/2FW-Ver2.0

SP	Ref. No.	Part.No.	Alternative.	Description	Quantity		
					110	120	230
⊙		302FV93061	2FV93061	DR-110	1	1	1
	1	*5MMW261LD071	2FV22010	SPRING REVERSE	1	1	1
⊙	2	*5AAPRIFC1037AHR	2FV01080	P.W.B ASSY KP-1113	1	1	1
⊙	3	*5AAXMT074GEA	2FV27000	MOTOR MAIN	1	1	1
	4	*302FV22160	2FV22160	SPRING GEAR	1	1	1
	5	*5MMX874SL005	2FV22030	PLATE DRIVE	1	1	1
	6	*5MVG127DN132	2FV22040	GEAR FREE Z26H A	1	1	1
	7	*5MVG127DN133	2FV22050	GEAR Z18H	1	1	1
	8	*5MVG138DN089	2FV22060	GEAR FREE Z26H B	1	1	1
	9	*5MVG138DN090	2FV22070	GEAR Z29H	1	1	1
	10	*5MVG148DN108	2FV22080	GEAR Z33H	1	1	1
	11	*5MVG148DN109	2FV22090	GEAR Z39H	1	1	1
	12	*5MVG148DN110	2FV22100	GEAR Z31H-Z25H	1	1	1
	13	*5MVG148DN111	2FV22110	GEAR Z38H-Z26H	1	1	1
	14	*5MVG158DN062	2FV22120	GEAR Z45H-Z27H	1	1	1
	15	*5MVG168DN022	2FV22130	GEAR Z76H-Z27H	1	1	1
	16	*5MVG168DN023	2FV22140	GEAR Z70H-Z34H	1	1	1
	17	*5MVX652SB015	2FV22150	BRACKET DRIVE	1	1	1
	18	*5MMX321LD040	2FV22020	PLATE EARTH DRUM	1	1	1
	19	*5MVS217SN002	2A806280	PAD SOLENOID	1	1	1
	20	*5MBTPB3006TW++R	B1A53060	BIND T.T SCREW(+)/ M3 X 6	7	7	7
	21	*5MBWL5280+NN	C2891080	POLY CUT WASHER / M5.2X8.0X0.25T	2	2	2
⊙	22	*302GM44020	2GM44020	SOLENOIDE REGIST	1	1	1
⊙	23	*302GM44010	2GM44010	SOLENOID FEED	1	1	1
	24	*C2895950		SHIM 6.2-1.0T	2	2	2

- Parts with "*" are component parts or sub-assemblies of the assembly appearing immediately above them.
- Parts with "⊙" indicates the spare parts.




FIG. 6 IMAGE FORMATION SECTION

SP	Ref. No.	Part.No.	Alternative.	Description	Quantity		
					110	120	230
⊙	1	302FV93011	2FV93011	DK-110	1	1	1
⊙		*302FV93070	2FV93070	MC-110	1	1	1

- Parts with "*" are component parts or sub-assemblies of the assembly appearing immediately above them.
- Parts with "⊙" indicates the spare parts.




FIG. 7 DEVELOPING UNIT

2GL/2FV/2FW

SP	Ref. No.	Part.No.	Alternative.	Description	Quantity		
					110	120	230
⊙		302FV93020	2FV93020	DV-110	1		1
⊙		302FV93030	2FV93030	DV-112		1	

- Parts with "*" are component parts or sub-assemblies of the assembly appearing immediately above them.
- Parts with "⊙" indicates the spare parts.




FIG. 8 FIXING SECTION

2GL/2FV/2FW-Ver2.0

SP	Ref. No.	Part.No.	Alternative.	Description	Quantity		
					110	120	230
⊙		302FV93040	2FV93040	FK-110(E)			1
⊙		302FV93050	2FV93050	FK-110(U)	1	1	
⊙	1	*5MVM188XN016	2A820131	BUSH HEAT L	1	1	1
⊙	2	*2BY20070		BUSH PRESS	2	2	2
⊙	3	*5MVM188XN015	2A820120	BUSH HEAT R	1	1	1
⊙	4	*302A820161	2A820161	GEAR HEAT Z33	1	1	1
⊙	5	*2DC20060		ROLLER PRESS	1	1	1
⊙	6	*5HZPB2413120103	2FV27020	HEATER LAMP E			1
⊙	6	*5HZPB1216320103	2FV27010	HEATER LAMP U	1	1	
⊙	7	*5MMW261SD016	2FV20070	SPRING PRESS	2	2	2
	8	*5MMX533LD003	2FV20040	PLATE EARTH FUSER	1	1	1
	9	*5MVB864KB009	2FV20020	FRAME FUSER UP	1	1	1
	10	*5MVG138XN010	2FV20090	GEAR IDLE Z25	1	1	1
⊙	11	*5MVX531CB002	2FV20030	ACTUATOR FUSER	1	1	1
⊙	12	*5MMT876AX002	2BY20010	ROLLER HEAT	1	1	1
	13	*5MMX611RD001	2FV20080	PLATE CORD	1	1	1
	14	*5MVB866KB003	2FV20010	FRAME FUSER LOW	1	1	1
	15	*5MMW261LD073	2FV20060	SPRING ACTUATOR	1	1	1
	16	*5AACNSX3GEA++R	2FV26060	CONN CORD ASSY			1
	16	*5AACNSX4GEA++R	2FV26070	CONN CORD ASSY	1	1	
⊙	17	*5AAXTM017GEA++R	2FV27040	THERMISTOR ASSY	1	1	1
⊙	18	*302FV27060	2FV27060	THERMOSTAT 250V170C	1	1	1
	19	*5AAVSEPR015	2A820360	SEPARATOR ASSY	4	4	4
	20	*5MMW261LD072	2FV20050	SPRING SEPARATOR	4	4	4
	21	*5MMS111SL002	2BY20050	NUT FUSER A	3	3	3
	22	*5MVVL611WN06	2FV20100	LABEL FUSER CAUTION	1	1	1
	23	*5MBTPB3012PW++R	B1A63120	BIND T.T SCREW(+) / M3 X 12	5	5	5
	24	*5MBTPB4010PW++R	B1A64100	BIND T.T SCREW(+) / M4 X 10	2	2	2
	25	*5MBSP43006NW++R	B4A03060	TP HEAD SCREW(+) / M3 X 6	4	4	4
	26	*302FV20130	2FV20130	PULLEY EXIT	4	4	4
	27	*5MBP2012WPLD	E5120120	PARALLEL PIN / M2 X 12	2	2	2
	28	*7BP512016+++H01	BP010450	PARALLEL PIN / M2X16	2	2	2

• Parts with "*" are component parts or sub-assemblies of the assembly appearing immediately above them.

• Parts with "⊙" indicates the spare parts.

FIG. 9 PARTS PACKAGE

2GL/2FV/2FW

SP	Ref. No.	Part.No.	Alternative.	Description	Quantity		
					110	120	230
⊙		302GLP1010	2GLP1010	PACKING MATTERS 2GL(E) (FS-720)			1
⊙		302GLP1020	2GLP1020	PACKING MATTERS 2GL(U) (FS-720)	1	1	
⊙		302FVP1010	2FVP1010	PACKING MATTERS 2FV(E) (FS-820)			1
⊙		302FVP1020	2FVP1020	PACKING MATTERS 2FV(U) (FS-820)	1	1	
⊙		302FWP1010	2FWP1010	PACKING MATTERS 2FW(E) (FS-920)			1
⊙		302FWP1020	2FWP1020	PACKING MATTERS 2FW(U) (FS-920)	1	1	
⊙		302FP50330	2FP50330	POLY BAG	1	1	1
⊙		302FV50010	2FV50010	POLY BAG	1	1	1
⊙		302FV50020	2FV50020	POLY BAG	1	1	1

• Parts with "*" are component parts or sub-assemblies of the assembly appearing immediately above them.

• Parts with "⊙" indicates the spare parts.

INDEX

SP	Part.No.	Alternative.	Description	Fig.No.	SP	Part.No.	Alternative.	Description	Fig.No.
⊙	2BY20070		BUSH PRESS	8	⊙	302FWP1010	2FWP1010	PACKING MATTERS 2FW(E)	9
	2DC07010		STOPPER PAPER	4	⊙	302FWP1020	2FWP1020	PACKING MATTERS 2FW(U)	9
	2DC07020		POSITIONING FOLIO PAPER	4		302GL03010	2GL03010	LID CONTROLLER	2
	2DC07040		FILM SEPARATOR	4	⊙	302GL04010	2GL04010	COVER LID TOP	1
	2DC13030		MIRROR LSU	3	⊙	302GLP1010	2GLP1010	PACKING MATTERS 2GL(E)	9
⊙	2DC20060		ROLLER PRESS	8	⊙	302GLP1020	2GLP1020	PACKING MATTERS 2GL(U)	9
⊙	2FM02180		BUSH REGIST C	2	⊙	302GM44010	2GM44010	SOLENOID FEED	5
	2FM02580		SPRING REGIST C	2	⊙	302GM44020	2GM44020	SOLENOIDE REGIST	5
	2FV06180		BOTTOM CASSETTE	4		5AACCNWSW2GEA++R	2FV26020	CONN CORD ASSY	3
	302A807021	2A807021	GUIDE SIDE R	4		5AACCNWSW3GEA++R	2FV26060	CONN CORD ASSY	8
	302A807031	2A807031	GUIDE SIDE L	4		5AACCNWSX4GEA++R	2FV26070	CONN CORD ASSY	8
⊙	302A820161	2A820161	GEAR HEAT Z33	8	⊙	5AAEZB12E+++1+P	2FV28010	SWITCHING REGULATOR	3
⊙	302FP50330	2FP50330	POLY BAG	9	⊙	5AAEZB12U+++1+P	2FV28020	SWITCHING REGULATOR	3
⊙	302FV00030	2FV00030	TE SENSOR ASY	2	⊙	5AAPRCZC1015AHR	2FV01050	P.W.BOARD ASSY KP-1111	1
⊙	302FV00040	2FV00040	FULL SENSOR ASSY	3	⊙	5AAPREL1008AHR	2FV01100	P.W.B ASSY KP-5157	3
⊙	302FV01241	2FV01241	P.W.B.ASSY E SERVICE	3	⊙	5AAPRIFC1037AHR	2FV01080	P.W.B ASSY KP-1113	5
	302FV02470	2FV02470	BUSH FD	2	⊙	5AAPRLGC2029AHR	2GL01000	P.W.BOARD ASSY	2
	302FV02480	2FV02480	SPRING ROLL	2	⊙	5AAPRLGR2010AHR	2FV01180	P.W.BOARD ASSY	2
⊙	302FV02490	2FV02490	SPRING TC R	2	⊙	5AAPRLGR2010BHR	2FV01000	P.W.BOARD ASSY	2
	302FV02500	2FV02500	SHEET FAN	2	⊙	5AAVCLTCH028	2BY02020	CLUTCH FEED	2
	302FV02510	2FV02510	LABEL JAM OPERATION	2	⊙	5AAVCLTCH032	2FV02180	CLUTCH REGIST	2
	302FV03020	2FV03020	BOX COCNTROLLER	2	⊙	5AAVR0LL+044	2A806010	ROLLER FEED ASSY	2
	302FV04180	2FV04180	PLATE TRAY L	1	⊙	5AAVSEPR015	2A820360	SEPARATOR ASSY	8
	302FV04190	2FV04190	PLATE TRAY R	1	⊙	5AAXMT074GEA	2FV27000	MOTOR MAIN	5
	302FV04200	2FV04200	SPRING COVER REAR R	1	⊙	5AAXTM017GEA++R	2FV27040	THERMISTOR ASSY	8
⊙	302FV04210	2FV04210	SHEET FD	1	⊙	5HZPB1216320103	2FV27010	HEATER LAMP U	8
	302FV06190	2FV06190	PAD SEPARATOR	4	⊙	5HZPB2413120103	2FV27020	HEATER LAMP E	8
	302FV06210	2FV06210	LABEL MANUAL FEED	4		5MMP141LD002	2A807510	PLATE SIDE GUIDE	4
	302FV12070	2FV12070	SHEET ERASER	3		5MMP141LD003	2A807520	PLATE STOPPER	4
	302FV12080	2FV12080	LABEL LASER CAUTION	3		5MMS111SL002	2BY20050	NUT FUSER A	8
	302FV14500	2FV14500	LABEL GUIDE DLP	2		5MMS821LD014	2A816080	BRUSH DISCHARGER	2
	302FV20130	2FV20130	PULLEY EXIT	8		5MMS856SL001	2A807170	PLATE BOTTOM	4
	302FV22160	2FV22160	SPRING GEAR	5		5MMS875SL007	2FV12020	COVER SCANNER	3
	302FV26052	2FV26052	CONN. CORD ASSY ENGINE-LSU	3	⊙	5MMT365SN003	2A815020	PIN CONTACT BIAS	2
⊙	302FV27060	2FV27060	THERMOSTAT 250V170C	8	⊙	5MMT463SN002	2FV02200	PIN DRIVE	2
⊙	302FV45010	2FV45010	FAN MOTOR	2		5MMT766SN011	2FV02210	SHAFT FEED	2
⊙	302FV50010	2FV50010	POLY BAG	9	⊙	5MMT865SN010	2A806050	ROLLER REGIST UP	2
⊙	302FV50020	2FV50020	POLY BAG	9		5MMT875SN016	2FV02220	ROLLER FD	2
⊙	302FV93011	2FV93011	DK-110	6	⊙	5MMT876AX002	2BY20010	ROLLER HEAT	8
⊙	302FV93020	2FV93020	DV-110	7	⊙	5MMT876SN104	2FV02230	ROLLER TRANSFER	2
⊙	302FV93030	2FV93030	DV-112	7	⊙	5MMT876SN105	2FV02240	ROLLER REGIST LOW	2
⊙	302FV93040	2FV93040	FK-110(E)	8	⊙	5MMU862SL001	2FV02250	PLATE EARTH GUIDE	2
⊙	302FV93050	2FV93050	FK-110(U)	8		5MMW126SD001	2FV04130	SPRING COVER REAR	1
⊙	302FV93061	2FV93061	DR-110	5		5MMW165SD001	2FV02400	SPRING STOPPER L	3
⊙	302FV93070	2FV93070	MC-110	6		5MMW165SD002	2FV02410	SPRING STOPPER R	3
⊙	302FV93080	2FV93080	CT-110	4		5MMW171LD006	2A807530	SPRING STOPPER	4
⊙	302FV93092	2FV93092	LK-110	3	⊙	5MMW251LD043	2A816040	SPRING TC L	2
⊙	302FVP1010	2FVP1010	PACKING MATTERS 2FV(E)	9		5MMW251LD045	2A807140	SPRING LOCK	4
⊙	302FVP1020	2FVP1020	PACKING MATTERS 2FV(U)	9		5MMW251LD047	2A807110	SPRING SEPARATOR C	4
	302FW02050	2FW02050	SHEET PAPER CHUTE	3	⊙	5MMW261LD023	2A806410	SPRING REGIST R	2

• Parts with "⊙" indicates the spare parts.

SP	Part.No.	Alternative.	Description	Fig.No.	SP	Part.No.	Alternative.	Description	Fig.No.
	5MMW261LD036	2A814570	SPRING TE SENSOR	2		5MVG127DN132	2FV22040	GEAR FREE Z26H A	5
	5MMW261LD066	2FV02260	SPRING ACTUATOR	2		5MVG127DN133	2FV22050	GEAR Z18H	5
	5MMW261LD067	2FV02270	SPRING LEVER LOCK L	2	⊙	5MVG138DN088	2FV02040	GEAR FREE Z28S	2
	5MMW261LD068	2FV02280	SPRING LEVER LOCK R	2		5MVG138DN089	2FV22060	GEAR FREE Z26H B	5
	5MMW261LD069	2FV02290	SPRING EXIT	2		5MVG138DN090	2FV22070	GEAR Z29H	5
	5MMW261LD070	2FV12010	SPRING FULL SENSOR	3		5MVG138XN010	2FV20090	GEAR IDLE Z25	8
	5MMW261LD071	2FV22010	SPRING REVERSE	5	⊙	5MVG148DN107	2FV02050	GEAR Z34S	2
	5MMW261LD072	2FV20050	SPRING SEPARATOR	8		5MVG148DN108	2FV22080	GEAR Z33H	5
	5MMW261LD073	2FV20060	SPRING ACTUATOR	8		5MVG148DN109	2FV22090	GEAR Z39H	5
⊙	5MMW261SD016	2FV20070	SPRING PRESS	8		5MVG148DN110	2FV22100	GEAR Z31H-Z25H	5
	5MMW361LD028	2FV02310	SPRING PIN BIAS	2		5MVG148DN111	2FV22110	GEAR Z38H-Z26H	5
	5MMW371LD006	2FV02320	SPRING FREE	2	⊙	5MVG158DN059	2FV02060	GEAR FREE Z46H	2
	5MMW451LD001	2B700570	SPRING INTERLOCK	2	⊙	5MVG158DN060	2FV02070	GEAR FD Z42S	2
⊙	5MMW552LD004	2FV06120	SPRING CASSETTE	4	⊙	5MVG158DN061	2FV02080	GEAR FD Z45S	2
⊙	5MMW603LD002	2FV04120	SPRING PULLEY FD	1	⊙	5MVG158DN062	2FV22120	GEAR Z45H-Z27H	5
	5MMX221LD034	2FV12030	SPRING MIRROR	3		5MVG168DN022	2FV22130	GEAR Z76H-Z27H	5
	5MMX321LD040	2FV22020	PLATE EARTH DRUM	5		5MVG168DN023	2FV22140	GEAR Z70H-Z34H	5
	5MMX331LD005	2FV02330	PLATE CONTACT TC	2		5MVM176DN016	2BR20170	BUSH A	2
	5MMX522LD013	2FV02340	PLATE EARTH FEED	2	⊙	5MVM188XN015	2A820120	BUSH HEAT R	8
	5MMX533LD003	2FV20040	PLATE EARTH FUSER	8	⊙	5MVM188XN016	2A820131	BUSH HEAT L	8
	5MMX541LD002	2FV02350	PLATE EARTH A	3	⊙	5MVM363DB001	2FV04150	PULLEY FD	1
	5MMX611RD001	2FV20080	PLATE CORD	8	⊙	5MVM776DB001	2FV02090	PULLEY FEED	2
	5MMX631LD003	2A807180	GUIDE SEPARATOR	4		5MVS217SN002	2A806280	PAD SOLENOID	5
	5MMX643LD006	2FV02360	PLATE EARTH B	2		5MVS616XN001	2A807080	PAD BOTTOM	4
	5MMX763LD007	2FV02370	PLATE CONTACT MC	2	⊙	5MVS625XF001	2FV04140	DISCHARGER FD	1
	5MMX774SL002	2FV03010	LID CONTROLLER	2		5MVS631TX001	3BW07040	TAPE SEPARATOR OP	4
	5MMX874SL005	2FV22030	PLATE DRIVE	5	⊙	5MVS721KF007	2FV02390	SHEET REGIST	4
	5MMX884SL002	2FV02380	PLATE BOTTOM FRAME	3		5MVS777CB001	2FV02000	COVER PWB	2
⊙	5MVB652SB015	2FV04110	TRAY FD	1		5MVS812KF006	2A816090	SHEET DISCHARGER	2
	5MVB763CB001	2FV02010	COVER MC	2		5MVS812XF003	2A816120	TAPE BRUSH	2
⊙	5MVB771SH002	2FV04090	COVER LID L	1		5MVL611WN06	2FV20100	LABEL FUSER CAUTION	8
⊙	5MVB771SH003	2FV04080	COVER LID R	1		5MVX111DN003	2A806250	RING STOPPER	2
	5MVB864KB009	2FV20020	FRAME FUSER UP	8	⊙	5MVX221DB019	2A806420	BUSH REGIST LEFT	2
	5MVB864SB024	2FV06100	TRAY MULTI	4	⊙	5MVX221DB023	2A816020	BUSH TC L	2
	5MVB866KB003	2FV20010	FRAME FUSER LOW	8	⊙	5MVX221DW006	2A806430	BUSH REGIST RIGHT	2
⊙	5MVB872SH033	2FV04070	COVER LID TOP	1	⊙	5MVX221DW008	2A816030	BUSH TC R	2
⊙	5MVB872SH034	2FV04010	COVER LID TOP	1		5MVX221RB014	2BS03110	FOOT	3
⊙	5MVB874SB011	2FV04060	COVER REAR	1	⊙	5MVX321AC002	2FV04170	LENS LED	1
⊙	5MVB877SB011	2FV04100	BASE LID	1		5MVX321SG002	2FV06090	MARKER INDICATOR	4
⊙	5MVB882SH007	2FV04050	COVER RIGHT SUB	1		5MVX431DN005	2FV02100	LEVER LOCK DLP	2
⊙	5MVB882SH008	2FV04040	COVER TOP	1		5MVX431SB012	2FV02450	RAIL FRAME	3
⊙	5MVB883SH033	2FV04030	COVER LEFT	1		5MVX432SB014	2FV02460	BKT ACTUATOR EXIT	2
⊙	5MVB885SH029	2FV04020	COVER RIGHT	1	⊙	5MVX441SB006	2FV02110	ACTUATOR REGIST	2
⊙	5MVB886SB013	2FV04010	BASE TOP	1	⊙	5MVX442SB011	2FV02120	ACTUATOR EXIT	2
	5MVB887SB002	2FV06010	BASE CASSETTE	4	⊙	5MVX531CB002	2FV20030	ACTUATOR FUSER	8
⊙	5MVG126DB025	2A806240	GEAR REGIDT Z13	2		5MVX541DG002	2A807191	LEVER REAR	4
⊙	5MVG127DB047	2A806230	GEAR REGIST Z20	2		5MVX541DG003	2A807161	LEVER SIDE	4
	5MVG127DN071	2A807050	GEAR CASSETTE	4		5MVX552DB001	2FV02130	ACTUATOR EMPTY	2
⊙	5MVG127DN130	2FV02020	GEAR FD Z19S	2		5MVX631DN001	2FV06030	LOCK CASSETTE	4
⊙	5MVG127DN131	2FV02030	GEAR TC Z17	2		5MVX631SB006	2FV02420	LEVER STOPPER L	3

• Parts with "⊙" indicates the spare parts.

SP	Part.No.	Alternative.	Description	Fig.No.
	5MVX631SB007	2FV02430	LEVER STOPPER R	3
	5MVX642SH010	2A807100	SEPARATOR PAPER	4
	5MVX652SB015	2FV22150	BRACKET DRIVE	5
⊙	5MVX662SH006	2FV04160	BUTTON	1
	5MVX664SB003	2FV02140	GUIDE CF	1
	5MVX664SH005	2FV06070	LEVER PAPER INDICATOR	4
	5MVX762SB019	2FV06040	GUIDE MULTI L	4
	5MVX762SB020	2FV06050	GUIDE MULTI R	4
	5MVX763SB011	2FV02150	ROD INTERLOCK	2
	5MVX821SB014	2FV12050	SHUTTER LSU	3
	5MVX864SB013	2FV06060	GUIDE TURN	4
	5MVX865SB008	2FV02160	GUIDE FEED	2
	5MVX876SB010	2FV06020	COVER CASSETTE	4
	5MVX876XB002	2FV12060	FRAME MID	3
	5MVX888CB001	2FV02170	FRAME BASE	2

• Parts with "⊙" indicates the spare parts.

KYOCERA MITA EUROPE B.V.

Hoeksteen 40, 2132 MS Hoofddorp,
The Netherlands
Phone: +31.(0)20.654.0000
Home page: <http://www.kyoceramita-europe.com>
Email: info@kyoceramita-europe.com

KYOCERA MITA NEDERLAND B.V.
Hoeksteen 40 2132 MS Hoofddorp,
The Netherlands
Phone: +31.(0)20.587.7200

KYOCERA MITA (UK) LTD.
8 Beacontree Plaza
Gillette Way, Reading Berks RG2 0BS,
UK
Phone: +44.(0)118.931.1500

KYOCERA MITA ITALIA S.P.A.
Via Verdi 89 / 91 20063 Cernusco sul Naviglio,
(Milano), Italy
Phone: +39.02.92179.1

S.A. KYOCERA MITA BELGIUM N.V.
Hermesstraat 8A 1930 Zaventem,
Belgium
Phone: +32.(0)2.720.9270

KYOCERA MITA FRANCE S.A.
Parc Les Algorithmes, Saint Aubin
91194 GIF-SUR-YVETTE,
France
Phone: +33.(0)1.6985.2600

KYOCERA MITA ESPAÑA S.A.
Edificio Kyocera, Avda de Manacor N. 2,
Urb. Parque Rozas 28290 Las Rozas, Madrid,
Spain
Phone: +34.(0)91.631.8392

KYOCERA MITA FINLAND OY
Kirvesmiehenkatu 4 00810 Helsinki,
Finland
Phone: +358.(0)9.4780.5200

KYOCERA MITA (SCHWEIZ) AG
Industriestrasse 28, 8604 Volketswil,
Switzerland
Phone: +41.(0)1.908.4949

KYOCERA MITA DEUTSCHLAND GMBH
Mollsfeld 12-40670 Meerbusch,
Germany
Phone: +49.(0)2159.918.0

KYOCERA MITA GMBH AUSTRIA
Eduard-Kittenberger Gasse 95
A-1230 Wien,
Austria
Phone: +43.(0)1.86338.401

KYOCERA MITA SVENSKA AB
Vretenragen 2, 6tr 171 54 Solna,
Sweden
Phone: +46.(0)8.546.550.00

KYOCERA MITA NORGE
Postboks 150 Oppsal, NO 0619 Oslo
Olaf Helsettsvei 6, NO 0694 Oslo,
Norway
Phone: +47.(0)22.62.73.00

KYOCERA MITA DANMARK A/S
Slotsmarken 11, 2 DK-2970 Hørsholm,
Denmark
Phone: +45.7022.3880

KYOCERA MITA PORTUGAL LDA.
Rua do Centro Cultural, no 41 1700-106 Lisbon,
Portugal
Phone: +351.(0)21.843.6780

KYOCERA MITA SOUTH AFRICA (PTY) LTD.
527 Kyalami Boulevard,
Kyalami Business Park Midrand,
South Africa
Phone: +27.(0)11.540.2600

KYOCERA MITA AMERICA, INC.

Headquarters:
225 Sand Road,
Fairfield, New Jersey 07004-0008,
U.S.A.
Phone: (973) 808-8444

KYOCERA MITA AUSTRALIA PTY. LTD.
Level 3, 6-10 Talavera Road, North Ryde,
N.S.W. 2113 Australia
Phone: (02) 9888-9999

KYOCERA MITA NEW ZEALAND LTD.
1-3 Parkhead Place, Albany
P.O. Box 302 125 NHPC, Auckland,
New Zealand
Phone: (09) 415-4517

KYOCERA MITA (THAILAND) CORP., LTD.
9/209 Ratchada-Prachachem Road,
Bang Sue, Bangkok 10800, Thailand
Phone: (02) 586-0320

KYOCERA MITA SINGAPORE PTE LTD.
121 Genting Lane, 3rd Level,
Singapore 349572
Phone: 67418733

KYOCERA MITA HONG KONG LIMITED
11/F., Mita Centre,
552-566, Castle Peak Road,
Tsuen Wan, New Territories,
Hong Kong
Phone: 24297422

KYOCERA MITA TAIWAN Corporation.
7F-1~2, No.41, Lane 221, Gangchi Rd.
Neihu District, Taipei, Taiwan, 114. R.O.C.
Phone: (02) 87511560

KYOCERA MITA Corporation

2-28, 1-chome, Tamatsukuri, Chuo-ku
Osaka 540-8585, Japan
Phone: (06) 6764-3555
<http://www.kyoceramita.com>

© 2005 KYOCERA MITA Corporation

 **KYOCERA** is a trademark of Kyocera Corporation

Printed in Holland

KYOCERA MITA AMERICA, INC.

Headquarters:

225 Sand Road,
Fairfield, New Jersey 07004-0008
TEL : (973) 808-8444
FAX : (973) 882-6000

New York Branch:

1410 Broadway 23rd floor
New York, NY 10018
TEL : (917) 286-5400
FAX : (917) 286-5402

Northeastern Region:

225 Sand Road,
Fairfield, New Jersey 07004-0008
TEL : (973) 808-8444
FAX : (973) 882-4401

Midwestern Region:

201 Hansen Court Suite 119
Wood Dale, Illinois 60191
TEL : (630) 238-9982
FAX : (630) 238-9487

Western Region:

14101 Alton Parkway,
Irvine, California 92618-7006
TEL : (949) 457-9000
FAX : (949) 457-9119

Southeastern Region:

1500 Oakbrook Drive,
Norcross, Georgia 30093
TEL : (770) 729-9786
FAX : (770) 729-9873

Southwestern Region:

2825 West Story Road,
Irving, Texas 75038-5299
TEL : (972) 550-8987
FAX : (972) 252-9786

National Operation Center & National Training Center:

2825 West Story Road,
Irving, Texas 75038-5299
TEL : (972) 659-0055
FAX : (972) 570-5816

Latin America Division:

8240 N.W. 52nd. Terrace Dawson Building,
Suite 108 Miami, Florida 33166
TEL : (305) 421-6640
FAX : (305) 421-6666

KYOCERA MITA CANADA, LTD.

6120 Kestrel Road, Mississauga,
Ontario L5T 1S8, Canada
TEL : (905) 670-4425
FAX : (905) 670-8116

KYOCERA MITA MEXICO, S.A. DE C.V.

Av. 16 de Septiembre #407
Col. Santa Inés,
Azcapotzalco México,
D.F. 02130, México
TEL : (55) 5383-2741
FAX : (55) 5383-7804

© 2005 KYOCERA MITA Corporation
<http://www.kyoceramita.com>

Printed in U.S.A.