



FS-C2026MFP

FS-C2126MFP

SERVICE MANUAL

Published in July 2010
842KX111
2KXSM061
Rev. 1



CAUTION

RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE. DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS.

It may be illegal to dispose of this battery into the municipal waste stream. Check with your local solid waste officials for details in your area for proper disposal.

ATTENTION

IL Y A UN RISQUE D'EXPLOSION SI LA BATTERIE EST REMPLACÉE PAR UN MODÈLE DE TYPE INCORRECT. METTRE AU REBUT LES BATTERIES UTILISÉES SELON LES INSTRUCTIONS DONNÉES.

Il peut être illégal de jeter les batteries dans des eaux d'égout municipales. Vérifiez avec les fonctionnaires municipaux de votre région pour les détails concernant des déchets solides et une mise au rebut appropriée.

Revision history

Revision	Date	Replaced pages	Remarks
1	July 7, 2010	1-1-1, 1-1-2, 1-1-4, 1-3-1, 1-3-4, 1-3-18, 1-3-55, 1-3-59 to 1-3-63	-

This page is intentionally left blank.

Safety precautions

This booklet provides safety warnings and precautions for our service personnel to ensure the safety of their customers, their machines as well as themselves during maintenance activities. Service personnel are advised to read this booklet carefully to familiarize themselves with the warnings and precautions described here before engaging in maintenance activities.

Safety warnings and precautions

Various symbols are used to protect our service personnel and customers from physical danger and to prevent damage to their property. These symbols are described below:

⚠ DANGER: High risk of serious bodily injury or death may result from insufficient attention to or incorrect compliance with warning messages using this symbol.

⚠ WARNING: Serious bodily injury or death may result from insufficient attention to or incorrect compliance with warning messages using this symbol.

⚠ CAUTION: Bodily injury or damage to property may result from insufficient attention to or incorrect compliance with warning messages using this symbol.

Symbols

The triangle (\triangle) symbol indicates a warning including danger and caution. The specific point of attention is shown inside the symbol.



General warning.



Warning of risk of electric shock.



Warning of high temperature.

⊘ indicates a prohibited action. The specific prohibition is shown inside the symbol.



General prohibited action.



Disassembly prohibited.

● indicates that action is required. The specific action required is shown inside the symbol.



General action required.



Remove the power plug from the wall outlet.



Always ground the copier.

1. Installation Precautions

WARNING

- Do not use a power supply with a voltage other than that specified. Avoid multiple connections to one outlet: they may cause fire or electric shock. When using an extension cable, always check that it is adequate for the rated current. 
- Connect the ground wire to a suitable grounding point. Not grounding the copier may cause fire or electric shock. Connecting the earth wire to an object not approved for the purpose may cause explosion or electric shock. Never connect the ground cable to any of the following: gas pipes, lightning rods, ground cables for telephone lines and water pipes or faucets not approved by the proper authorities. 

CAUTION:

- Do not place the copier on an infirm or angled surface: the copier may tip over, causing injury. 
- Do not install the copier in a humid or dusty place. This may cause fire or electric shock. 
- Do not install the copier near a radiator, heater, other heat source or near flammable material. This may cause fire. 
- Allow sufficient space around the copier to allow the ventilation grills to keep the machine as cool as possible. Insufficient ventilation may cause heat buildup and poor copying performance. 
- Always handle the machine by the correct locations when moving it. 
- Always use anti-toppling and locking devices on copiers so equipped. Failure to do this may cause the copier to move unexpectedly or topple, leading to injury. 
- Avoid inhaling toner or developer excessively. Protect the eyes. If toner or developer is accidentally ingested, drink a lot of water to dilute it in the stomach and obtain medical attention immediately. If it gets into the eyes, rinse immediately with copious amounts of water and obtain medical attention. 
- Advice customers that they must always follow the safety warnings and precautions in the copier's instruction handbook. 

2. Precautions for Maintenance

WARNING

- Always remove the power plug from the wall outlet before starting machine disassembly. 
- Always follow the procedures for maintenance described in the service manual and other related brochures. 
- Under no circumstances attempt to bypass or disable safety features including safety mechanisms and protective circuits. 
- Always use parts having the correct specifications. 
- Always use the thermostat or thermal fuse specified in the service manual or other related brochure when replacing them. Using a piece of wire, for example, could lead to fire or other serious accident. 
- When the service manual or other serious brochure specifies a distance or gap for installation of a part, always use the correct scale and measure carefully. 
- Always check that the copier is correctly connected to an outlet with a ground connection. 
- Check that the power cable covering is free of damage. Check that the power plug is dust-free. If it is dirty, clean it to remove the risk of fire or electric shock. 
- Never attempt to disassemble the optical unit in machines using lasers. Leaking laser light may damage eyesight. 
- Handle the charger sections with care. They are charged to high potentials and may cause electric shock if handled improperly. 

CAUTION

- Wear safe clothing. If wearing loose clothing or accessories such as ties, make sure they are safely secured so they will not be caught in rotating sections. 
- Use utmost caution when working on a powered machine. Keep away from chains and belts. 
- Handle the fixing section with care to avoid burns as it can be extremely hot. 
- Check that the fixing unit thermistor, heat and press rollers are clean. Dirt on them can cause abnormally high temperatures. 

- Do not remove the ozone filter, if any, from the copier except for routine replacement. 
- Do not pull on the AC power cord or connector wires on high-voltage components when removing them; always hold the plug itself. 
- Do not route the power cable where it may be stood on or trapped. If necessary, protect it with a cable cover or other appropriate item. 
- Treat the ends of the wire carefully when installing a new charger wire to avoid electric leaks. 
- Remove toner completely from electronic components. 
- Run wire harnesses carefully so that wires will not be trapped or damaged. 
- After maintenance, always check that all the parts, screws, connectors and wires that were removed, have been refitted correctly. Special attention should be paid to any forgotten connector, trapped wire and missing screws. 
- Check that all the caution labels that should be present on the machine according to the instruction handbook are clean and not peeling. Replace with new ones if necessary. 
- Handle greases and solvents with care by following the instructions below: 
- Use only a small amount of solvent at a time, being careful not to spill. Wipe spills off completely.
- Ventilate the room well while using grease or solvents.
- Allow applied solvents to evaporate completely before refitting the covers or turning the power switch on.
- Always wash hands afterwards.
- Never dispose of toner or toner bottles in fire. Toner may cause sparks when exposed directly to fire in a furnace, etc. 
- Should smoke be seen coming from the copier, remove the power plug from the wall outlet immediately. 

3. Miscellaneous

WARNING

- Never attempt to heat the drum or expose it to any organic solvents such as alcohol, other than the specified refiner; it may generate toxic gas. 

This page is intentionally left blank.

CONTENTS

1-1 Specifications

1-1-1 Specifications	1-1-1
1-1-2 Parts names	1-1-6
(1) Machine (front side).....	1-1-6
(2) Machine (rear side).....	1-1-7
(3) Document processor	1-1-8
(4) Operation panel	1-1-9
1-1-3 Machine cross section	1-1-10

1-2 Installation

1-2-1 Installation environment.....	1-2-1
1-2-2 Unpacking.....	1-2-2
(1) Unpacking.....	1-2-2
(2) Removing the tapes.....	1-2-4
1-2-3 Installing the expansion memory (option).....	1-2-8

1-3 Maintenance Mode

1-3-1 Maintenance mode	1-3-1
(1) Executing a maintenance item	1-3-1
(2) Maintenance modes item list	1-3-2
(3) Contents of the maintenance mode items	1-3-5
1-3-2 Service mode.....	1-3-56
(1) Executing a service mode	1-3-56
(2) Description of service mode	1-3-57

1-4 Troubleshooting

1-4-1 Paper misfeed detection	1-4-1
(1) Paper misfeed indication	1-4-1
(2) Paper misfeed detection condition	1-4-2
1-4-2 Self-diagnostic function	1-4-6
(1) Self-diagnostic function	1-4-6
(2) Self diagnostic codes.....	1-4-7
1-4-3 Image formation problems	1-4-28
(1) No image appears (entirely white).....	1-4-29
(2) No image appears (entirely black).....	1-4-29
(3) A specific color is printed solid.	1-4-30
(4) The back side gets dirty.....	1-4-30
(5) Image is too light.	1-4-30
(6) The background is colored.	1-4-31
(7) White streaks are printed vertically.....	1-4-31
(8) Black streaks are printed vertically.	1-4-31
(9) Streaks are printed horizontally.	1-4-32
(10) Spots are printed.	1-4-32
(11) The leading edge of image begins to print too early or too late.....	1-4-32
(12) Paper is wrinkled.	1-4-32
(13) Offset occurs.	1-4-33
(14) Part of image is missing.	1-4-33
(15) Fusing is loose.....	1-4-33
(16) Colors are printed offset to each other.	1-4-34
1-4-4 Electric problems	1-4-35
1-4-5 Mechanical problems.....	1-4-40

1-4-6 Send error code	1-4-42
(1) Scan to SMB error codes	1-4-42
(2) Scan to FTP error codes	1-4-43
(3) Scan to E-mail error codes	1-4-44
(4) Software trouble error codes	1-4-45
1-4-7 Error codes	1-4-46
(1) Error code	1-4-46
(2) Table of general classification	1-4-47
(2-1) U004XX error code table: Interrupted phase B	1-4-49
(2-2) U006XX error code table: Problems with the unit	1-4-49
(2-3) U008XX error code table: Page transmission error	1-4-49
(2-4) U009XX error code table: Page reception error	1-4-49
(2-5) U010XX error code table: G3 transmission	1-4-50
(2-6) U011XX error code table: G3 reception	1-4-51
(2-7) U017XX error code table: V.34 transmission	1-4-52
(2-8) U018XX error code table: V.34 reception	1-4-52

1-5 Assembly and disassembly

1-5-1 Precautions for assembly and disassembly	1-5-1
(1) Precautions	1-5-1
(2) Drum	1-5-1
(3) Toner	1-5-1
(4) How to tell a genuine Kyocera Mita toner container	1-5-2
1-5-2 Outer covers	1-5-3
(1) Detaching and refitting the rear upper cover, right upper cover, left upper cover and front cover	1-5-3
(2) Detaching and refitting the right rear cover, right cover and right lower cover	1-5-6
(3) Detaching and refitting the left rear cover, left cover and left lower cover	1-5-9
(4) Detaching and refitting the inner cover	1-5-11
1-5-3 Paper feed section	1-5-12
(1) Detaching and refitting the retard roller unit	1-5-12
(2) Detaching and refitting the paper feed roller unit	1-5-14
(3) Detaching and refitting the MP paper feed roller	1-5-16
1-5-4 Developing section	1-5-18
(1) Detaching and refitting the developing unit	1-5-18
1-5-5 Drum section	1-5-20
(1) Detaching and refitting the drum unit	1-5-20
1-5-6 Transfer/Separation section	1-5-21
(1) Detaching and refitting the intermediate transfer unit	1-5-21
(2) Detaching and refitting the transfer roller unit	1-5-24
1-5-7 Fuser section	1-5-25
(1) Detaching and refitting the fuser unit	1-5-25
1-5-8 PWBs	1-5-26
(1) Detaching and refitting the engine PWB	1-5-26
(2) Detaching and refitting the power source PWB	1-5-28
(3) Detaching and refitting the main PWB	1-5-29
(4) Detaching and refitting the high voltage PWB	1-5-34
(5) Detaching and refitting the FAX control PWB (4 in 1 model (with FAX) only)	1-5-35
1-5-9 Drive section	1-5-36
(1) Detaching and refitting the MP feed drive unit	1-5-36
(2) Detaching and refitting the drum/developing drive unit	1-5-37
(3) Detaching and refitting the paper feed drive unit	1-5-39
(4) Detaching and refitting the fuser pressure drive unit	1-5-40

(5) Detaching and refitting the middle transfer drive unit	1-5-42
1-5-10 Optical section	1-5-44
(1) Detaching and refitting the laser scanner unit	1-5-44
(2) Detaching and refitting the scanner unit	1-5-47
1-5-11 Document processor	1-5-51
(1) Detaching and refitting the document processor	1-5-51
(2) Detaching and refitting the DP paper feed pulley unit	1-5-55
(3) Detaching and refitting the DP separation pad	1-5-59
(4) Detaching and refitting the DP drive PWB	1-5-60
1-5-12 Others	1-5-61
(1) Detaching and refitting the paper conveying unit	1-5-61
(2) Detaching and refitting the operation panel	1-5-63
(3) Direction of installing the principal fan motors	1-5-64

1-6 Requirements on PWB Replacement

1-6-1 Upgrading the firmware	1-6-1
1-6-2 Remarks on engine PWB replacement	1-6-2

2-1 Mechanical Construction

2-1-1 Paper feed/conveying section	2-1-1
(1) Cassette paper feed section	2-1-1
(2) MP tray paper feed section	2-1-3
(3) Paper conveying section	2-1-5
2-1-2 Drum section	2-1-7
2-1-3 Developing section	2-1-9
2-1-4 Optical section	2-1-11
(1) Image scanner section	2-1-11
(2) Laser scanner section	2-1-14
2-1-5 Transfer/Separation section	2-1-16
(1) Intermediate transfer unit section	2-1-16
(2) Secondary transfer roller section	2-1-18
2-1-6 Fuser section	2-1-19
2-1-7 Eject/Feedshift section	2-1-21
2-1-8 Duplex conveying section	2-1-23
2-1-9 Document processor	2-1-25
(1) Original feed section	2-1-25
(2) Original conveying section	2-1-27
(3) Original switchback/eject sections	2-1-29

2-2 Electrical Parts Layout

2-2-1 Electrical parts layout	2-2-1
(1) PWBs	2-2-1
(2) Switches and sensors	2-2-4
(3) Motors	2-2-6
(4) Others	2-2-8
(5) Document processor	2-2-9

2-3 Operation of the PWBs

2-3-1 Power source PWB	2-3-1
2-3-2 Engine PWB	2-3-3
2-3-3 Main PWB	2-3-13
2-3-4 Drum relay PWB	2-3-20
2-3-5 DP drive PWB	2-3-23

2-4 Appendixes

2-4-1 Appendixes	2-4-1
(1) Repetitive defects gauge	2-4-1
(2) Firmware environment commands	2-4-2
(3) Wiring diagram	2-4-9

1-1-1 Specifications

Machine

Item	Specifications	
	3 in 1 model (without FAX)	4 in 1 model (with FAX)
Type	Desktop	
Printing method	Electrophotography by semiconductor laser, tandem (4) drum system	
Originals	Sheet, Book, 3-dimensional objects (maximum original size: Folio/Legal)	
Original feed system	Fixed	
Paper weight	Cassette	60 to 163 g/m ² (Duplex: 60 to 163 g/m ²)
	MP tray	60 to 220 g/m ²
Paper type	Cassette	Plain, Recycled, Preprinted, Bond, Color (Colour), Prepunched, Letterhead, Thick, High quality, Custom 1 to 8 (Duplex: Same as simplex)
	MP tray	Plain, Transparency, Vellum, Labels, Recycled, Preprinted, Bond, Cardstock, Color (Colour), Prepunched, Letterhead, Thick, Envelope, Coated, High quality, Custom 1 to 8
Paper size	Cassette	A4, A5, A6, B5, Letter, Legal, Statement, Executive, Oficio II, Folio, 16K, Envelope C5, Custom
	MP tray	A4, A5, A6, B5, ISO B5, B6, Letter, Legal, Statement, Executive, Oficio II, Folio, 16K, Envelope #10, Envelope #9, Envelope #6, Envelope Monarch, Envelope DL, Envelope C5, Postcards, Return postcard, Youkei 2, Youkei 4, Custom
Zoom level	Manual mode : 25 to 400%, 1% increments Auto mode : 400%, 200%, 141%, 129%, 115%, 90%, 86%, 78%, 70%, 64%, 50%, 25%	
Copying speed	Simplex	A4R : 26 sheets/min LetterR : 28 sheets/min Legal : 23 sheets/min B5R : 28 sheets/min A5R : 28 sheets/min A6R : 28 sheets/min
	Duplex	A4R : 13 sheets/min LetterR : 13 sheets/min Legal : 12 sheets/min
First copy time (A4, feed from cassette)	B/W	When using the DP : 11.0 s or less When the DP is not used: 10.0 s or less
	Color	When using the DP : 13.0 s or less When the DP is not used: 12.0 s or less
Warm-up time (22 °C/71.6 °F, 60% RH)	Power on : 28 s or less Sleep mode: 20 s or less	
Paper capacity	Cassette	250 sheets (80g/m ²)
	MP tray	50 sheets (80 g/m ² , plain paper, A4/Letter or less)
Output tray capacity	150 sheets (80g/m ²)	
Continuous copying	1 to 999 sheets	

Item	Specifications	
	3 in 1 model (without FAX)	4 in 1 model (with FAX)
Light source	Exposure lamp	
Scanning system	Flat bed scanning by CCD image sensor	
Photoconductor	OPC drum (diameter 30 mm)	
Image write system	Semiconductor laser	
Charging system	Charger roller	
Developing system	Touch down developing system Developer: 2-component Toner replenishing: Automatic from the toner container	
Transfer system	Primary: Transfer belt Secondary: Transfer roller	
Separation system	Small diameter separation	
Cleaning system	Drum: Counter blade	
Charge erasing system	Exposure by cleaning lamp (LED)	
Fusing system	Heat and pressure fusing with the heat roller and the press roller Heat source: halogen heater Abnormally high temperature protection devices: thermostat	
CPU	PowerPC464 (667MHz)	
Main memory	Standard	768 MB
	Maximum	1792 MB
Interface	Standard	USB interface connector: 1 (USB Hi-speed) USB host: 2 Network interface: 1 (10BASE-T/100BASE-TX)
	Option	KUIO/W slot: 1
Resolution	600 × 600 dpi	
Operating environment	Temperature	0 to 32.5 °C/50 to 90.5 °F
	Humidity	15 to 80% RH
	Altitude	2,500 m/8,202 ft or less
	Brightness	1,500 lux or less
Dimensions (W × D × H)	514 × 550 × 580 mm 20 1/4 × 21 5/8 × 22 13/16"	
Weight	36.5 kg / 80.3 lb (with toner container)	
Space required (W × D)	514 × 1020 mm (using MP tray) 20 1/4 × 40 3/16" (using MP tray)	
Power source	120 V AC, 60 Hz, more than 8.9 A 220 - 240 V AC, 50/60 Hz, more than 4.7 A	
Options	Paper feeder × 2, Expanded memory	

Document processor

Item	Specifications
Original feed method	Automatic feed
Supported original types	Sheet originals
Original sizes	Maximum: A4/Legal Minimum : A5/Statement
Original weights	Simplex: 50 to 120 g/m ² Duplex : 50 to 110 g/m ²
Loading capacity	50 sheets (50 to 80 g/m ²) or less
Dimensions (W × D × H)	490 × 338 × 104 mm 19 5/16 × 13 5/16 × 4 1/8"
Weight	3 kg/ 6.6 lb or less

Printer

Item	Specifications
Printing speed	Same as copying speed.
First print time (A4, feed from cassette)	B/W : 9.0 s or less Color: 10.5 s or less
Resolution	600 dpi
Operating system	Windows 2000, Windows XP, Windows XP Professional, Windows Server 2003, Windows Server 2003 x64 Edition, Windows Vista x86 Edition, Windows Vista x64 Edition, Windows 7 x86 Edition, Windows 7 x64 Edition, Windows Server 2008, Windows Server 2008 x64 Edition, Apple Macintosh OS 10.x
Interface	USB interface connector: 1 (USB Hi-speed) USB host: 2 Network interface: 1 (10BASE-T/100BASE-TX)
Page description language	PRESCRIBE

Scanner

Item		Specifications
Operating system		Windows 2000 (Service Pack 4), Windows XP, Windows Vista, Windows 7, Windows Server 2003, Windows Server 2008
System requirements		IBM PC/AT compatible CPU: Celeron 600 MHz or higher RAM: 128 MB or more HDD free space: 20 MB or more Interface: Ethernet
Resolution		600 dpi, 400 dpi, 300 dpi, 200 dpi
File format		JPEG, TIFF, PDF, XPS
Scanning speed	Simplex	B/W : 35 images/min Color: 25 images/min (A4 landscape, 300 dpi, Image quality: Text/Photo original)
	Duplex	B/W : 18 images/min Color: 13 images/min (A4 landscape, 300 dpi, Image quality: Text/Photo original)
Interface		Ethernet (10 BASE-T/100 BASE-TX)
Network protocol		TCP/IP
Transmission system		PC transmission SMB Scan to SMB FTP Scan to FTP, FTP over SSL E-mail transmission SNTP Scan to E-mail TWAIN scan*1 WIA scan*2

*1 Available operating system: Windows 2000 (Service Pack 4), Windows XP, Windows Vista, Windows Server 2008, Windows 7

*2 Available operating system: Windows Vista, Windows Server 2008, Windows 7

FAX (4 in 1 model (with FAX) only)

Item	Specifications
Compatibility	G3
Communication line	Subscriber telephone line
Transmission time	3 s or less (33600 bps, JBIG, ITU-T A4 #1 chart)
Transmission speed	33600/31200/28800/26400/24000/21600/19200/16800/14400/12000/9600/ 7200/4800/2400 bps
Coding scheme	JBIG/MMR/MR/MH
Error correction	ECM
Original size	Max. width: 8 1/2"/216 mm Max. length: 14"/356 mm
Automatic document feed	Max. 50 sheets
Scanner resolution	Horizontal × Vertical 200 × 100 dpi Normal (8 dot/mm × 3.85 line/mm) 200 × 200 dpi Fine (8 dot/mm × 7.7 line/mm) 200 × 400 dpi Super fine (8 dot/mm × 15.4 line/mm) 400 × 400 dpi Ultra fine (16 dot/mm × 15.4 line/mm)
Printing resolution	600 × 600 dpi
Gradations	256 shades (Error diffusion)
One-Touch key	22 keys
Multi-Station transmission	Max. 100 destinations
Substitute memory reception	256 sheets or more (when using ITU-T A4 #1 chart)
Image memory capacity	3.5 MB (standard) (for incoming faxed originals)
Report output	Sent result report, FAX RX result report, Report for job canceled before sending, Activity report, Status page

NOTE: These specifications are subject to change without notice.

1-1-2 Parts names

(1) Machine (front side)




Figure 1-1-1

- | | |
|----------------------------------|-------------------------|
| 1. Document processor (DP) | 10. USB memory slot |
| 2. Contact glass | 11. Main power switch |
| 3. Original size Indicator plate | 12. Toner container K |
| 4. Operation panel | 13. Toner container M |
| 5. Top tray lever | 14. Toner container C |
| 6. Paper stopper | 15. Toner container Y |
| 7. Top tray | 16. Waste toner cover |
| 8. MP (Multi-Purpose) tray | 17. Waste toner box |
| 9. Cassette | 18. Lock release button |

(2) Machine (rear side)





Figure 1-1-2

- 19. Rear cover
 - 20. Rear cover lever
 - 21. Memory cover
 - 22. Power source cover
 - 23. Paper conveying unit
 - 24. Power cord connector
 - 25. Network indicators
 - 26. Network interface connector
 - 27. USB interface connector
 - 28. USB memory slot
 - 29. LINE connector*
 - 30. TEL connector*
- *: 4 in 1 model (with FAX) only

(3) Document processor**Figure 1-1-3**

- 31. DP top cover
- 32. Original width guides
- 33. Original table
- 34. Original eject table
- 35. Switchback table
- 36. Original stopper
- 37. Opening Handle

(4) Operation panel





Figure 1-1-4

- | | | |
|--------------------------------|--------------------------|-----------------------|
| 1. System menu/Counter key | 13. Auto color key | 25. Function Menu key |
| 2. Document box key | 14. Full color key | 26. Numeric keys |
| 3. Status/Job cancel key | 15. Black and White key | 27. Clear key |
| 4. Copy key | 16. Message display | 28. Reset key |
| 5. Send key | 17. Left Select key | 29. Stop key |
| 6. FAX key* | 18. Right Select key | 30. Start key |
| 7. Address book key | 19. Processing indicator | 31. Program keys |
| 8. Address recall/Pause key* | 20. Memory indicator | 32. Main power LED |
| 9. Confirm/Add destination key | 21. Attention indicator | 33. Power key |
| 10. On Hook key* | 22. Back key | 34. Logout key |
| 11. One-touch keys | 23. Cursor keys | |
| 12. Shift Lock key | 24. OK key | |

*: 4 in 1 model (with FAX) only



1-1-3 Machine cross section




Figure 1-1-5

- | | | |
|--------------------------------|------------------------------|--|
| 1. Cassette paper feed section | 9. Drum unit Y | 16. Secondary transfer/Separation sections |
| 2. MP tray paper feed section | 10. Developing unit K | 17. Fuser section |
| 3. Paper conveying section | 11. Developing unit M | 18. Eject/Feed shift sections |
| 4. Laser scanner unit KM | 12. Developing unit C | 19. Duplex section |
| 5. Laser scanner unit CY | 13. Developing unit Y | 20. Image scanner unit |
| 6. Drum unit K | 14. Toner container section | 21. Document processor |
| 7. Drum unit M | 15. Primary transfer section | |
| 8. Drum unit C | | |



1-2-1 Installation environment

1. Temperature: 10 to 32.5°C/50 to 90.5°F
2. Humidity: 15 to 80% RH
3. Power supply: 120 V AC, 8.9 A
220 - 240 V AC, 4.7 A
4. Power source frequency: 50 Hz \pm 2%/60 Hz \pm 2%
5. Installation location

Avoid direct sunlight or bright lighting. Ensure that the photoconductor will not be exposed to direct sunlight or other strong light when removing paper jams.

Avoid locations subject to high temperature and high humidity or low temperature and low humidity; an abrupt change in the environmental temperature; and cool or hot, direct air.

Avoid places subject to dust and vibrations.

Choose a surface capable of supporting the weight of the machine.

Place the machine on a level surface (maximum allowance inclination: 1°).

Avoid air-borne substances that may adversely affect the machine or degrade the photoconductor, such as mercury, acidic or alkaline vapors, inorganic gasses, NO_x, SO_x gases and chlorine-based organic solvents.

Select a well-ventilated location.

6. Allow sufficient access for proper operation and maintenance of the machine.




Figure 1-2-1

1-2-2 Unpacking

(1) Unpacking

220-240V AC model




Figure 1-2-2

- | | | |
|------------------------------|-----------------------------|---------------------------------|
| 1. Machine | 10. Top spacer | 19. Toner containers |
| 2. Outer case | 11. Top pad L | 20. Plastic bags (200 × 450) |
| 3. Machine cover (620 × 580) | 12. Top pad R | 21. Plastic bag (250 × 600) |
| 4. Bottom spacer | 13. Plastic bag (240 × 350) | 22. Operation labels |
| 5. Plastic bag (650 × 650) | 14. Installation guide etc. | 23. Operation label pad |
| 6. Left spacer | 15. CD-ROM* | 24. Modular cable** |
| 7. Bottom pads | 16. Middle spacer | 25. Hinge joints |
| 8. Bottom case | 17. Power cord | *: 240V AC model only. |
| 9. Front pad | 18. Waste toner box | **: 4in1 model (with FAX) only. |

120V AC model




Figure 1-2-3

- | | | |
|------------------------------|-----------------------------|--------------------------------|
| 1. Machine | 10. Front pad | 19. Waste toner box |
| 2. Outer case | 11. Top spacer | 20. Toner containers |
| 3. Machine cover (620 × 580) | 12. Top pad L | 21. Plastic bags (200 × 450) |
| 4. Bottom spacer | 13. Top pad R | 22. Plastic bag (250 × 600) |
| 5. Plastic bag (650 × 650) | 14. Plastic bag (240 × 350) | 23. Operation labels |
| 6. Left spacer | 15. Installation guide etc. | 24. Operation label pad |
| 7. Bottom pads A | 16. CD-ROM | 25. Modular cable* |
| 8. Bottom pads B | 17. Middle spacer | 26. Plastic bag* |
| 9. Bottom case | 18. Power cord | 27. Hinge joints |
| | | *: 4in1 model (with FAX) only. |

TONER
 Place the machine on a level surface.
www.tonerplus.com.ua

(2) Removing the tapes

Procedure

1. Open the DP.
2. Remove two tapes.
3. Remove two sheets.




Figure 1-2-4

4. Remove the paper.




Figure 1-2-5

5. Remove tape A and pad.
6. Remove tape B.
7. Close the DP.




Figure 1-2-6

8. Remove three tapes.




Figure 1-2-7

- 9. Open the DP top cover.
- 10. Remove two tapes.
- 11. Close the DP top cover.




Figure 1-2-8

- 12. Remove five tapes.




Figure 1-2-9

13. Remove four tapes.




Figure 1-2-10

14. Open the top tray.
15. Remove pads A and B.
16. Close the top tray.




Figure 1-2-11

1-2-3 Installing the expansion memory (option)

Procedure

1. Turn off the main power switch.
Caution: Do not insert or remove expansion memory while machine power is on.
 Doing so may cause damage to the machine and the expansion memory.
2. Remove the memory cover.




Figure 1-2-12

3. Unlock the lock and then open the fan holder.




Figure 1-2-13

4. Insert the expansion memory into the memory socket so that the notches on the memory align with the corresponding protrusions in the slot.
5. Close the fan holder.
6. Refit the memory cover.
7. Print a status page to check the memory expansion (see page 1-3-57).
If memory expansion has been properly performed, information on the installed memory is printed with the total memory capacity has been increased. Standard memory capacity 768 MB.





Figure 1-2-14

This page is intentionally left blank.

1-3-1 Maintenance mode

The machine is equipped with a maintenance function which can be used to maintain and service the machine.

(1) Executing a maintenance item



(2) Maintenance modes item list

Section	Item No.	Content of maintenance item	Initial setting
General	U000	Outputting an own-status report	-
	U002	Setting the factory default data	-
Operation panel and support equipment	U203	Checking DP operation	-
	U222	Setting the IC card type	Other
Mode setting	U250	Setting the maintenance cycle	100000
	U251	Checking/clearing the maintenance count	0
	U253	Switching between double and single counts	Double count
	U260	Selecting the timing for copy counting	Eject
	U285	Setting service status page	On
	U332	Setting the size conversion factor	1.0
	U345	Setting the value for maintenance due indication	0
Image processing	U410	Adjusting the halftone automatically	-
	U411	Adjusting the scanner automatically	-
	U425	Setting the target	-
Fax	U600	Initializing all data	-
	U601	Initializing permanent data	-
	U603	Setting user data 1	DTMF
	U604	Setting user data 2	2 (120 V) 1 (220-240 V)
	U605	Clearing data	-
	U610	Setting system 1	3
		Setting the number of lines to be ignored when receiving a fax at 100% magnification	0
		Setting the number of lines to be ignored when receiving a fax in the auto reduction mode	0
U611	Setting system 2	7	
	Setting the number of adjustment lines for automatic reduction	22	
	Setting the number of adjustment lines for automatic reduction when A4 paper is set	26	
U612	Setting system 3	On	
	Selecting if auto reduction in the auxiliary direction is to be performed	Off	
	Setting the automatic printing of the protocol list	On	
	Setting how trailing edge margins are detected		

Section	Item No.	Content of maintenance item	Initial setting
Fax	U620	Setting the remote switching mode	One
	U625	Setting the transmission system 1 Setting the auto redialing interval Setting the number of times of auto redialing	3 (120 V) 2 (220-240 V) 2 (120 V) 3 (220-240 V)
	U630	Setting communication control 1 Setting the communication starting speed Setting the reception speed Setting the waiting period to prevent echo problems at the sender Setting the waiting period to prevent echo problems at the receiver	14400bps/V17 14400bps 300 75
	U631	Setting communication control 2 Setting ECM transmission Setting ECM reception Setting the frequency of the CED signal	On On 2100
	U632	Setting communication control 3 Setting the DIS signal to 4 bytes Setting the CNG detection times in the fax/telephone auto select mode	Off 2Time
	U633	Setting communication control 4 Enabling/disabling V.34 communication Setting the number of times of DIS signal reception Setting the number of times of DIS signal reception Setting the reference for RTN signal output	On On Once 15%
	U634	Setting communication control 5	0
	U640	Setting communication time 1 Setting the one-shot detection time for remote switching Setting the continuous detection time for remote switching	7 80
	U641	Setting communication time 2 Setting the T0 time-out time Setting the T1 time-out time Setting the T2 time-out time Setting the Ta time-out time Setting the Tb1 time-out time Setting the Tb2 time-out time Setting the Tc time-out time Setting the Td time-out time	56 36 69 30 20 80 60 9 (120 V) 6 (220-240 V)
	U650	Setting modem 1 Setting the G3 transmission cable equalizer Setting the G3 reception cable equalizer Setting the modem detection level	0dB 0dB -43dBm



Section	Item No.	Content of maintenance item	Initial setting
Fax	U651	Setting modem 2	9 (120 V)
		Modem output level	10 (220-240 V)
		DTMF output level (main value)	5 (120 V)
		DTMF output level (level difference)	10.5 (220-240 V)
	U660	Setting the NCU	PSTN
		Setting the connection to PBX/PSTN	On
U670	Setting PSTN dial tone detection	On	
	Setting busy tone detection	Loop	
	Setting for a PBX	On	
U670	Outputting lists	-	
U695	FAX function customize	On/Off	
U699	Setting the software switches	-	
Others	U910	Clearing the digital dot coverage data	-
	U917	Setting backup data reading/writing	-
	U920	Checking the copy counts	-
	U927	Clearing the all copy counts and machine life counts (one time only)	-
	U928	Checking machine life counts	-
	U977	Data capture mode	-
	U995	Memory data Individual setting	-

(3) Contents of the maintenance mode items

Item No.	Description																
U000	<p data-bbox="288 293 703 322">Outputting an own-status report</p> <p data-bbox="288 360 440 389">Description Outputs lists of the current settings of the maintenance items and paper jam and service call occurrences. Outputs the event log. Also sends output data to the USB memory.</p> <p data-bbox="288 465 400 495">Purpose To check the current setting of the maintenance items, or paper jam or service call occurrences. Before initializing or replacing the backup RAM, output a list of the current settings of the maintenance items to reenter the settings after initialization or replacement.</p> <p data-bbox="288 640 387 669">Method</p> <ol data-bbox="308 674 1038 736" style="list-style-type: none"> 1. Press the start key. 2. Select the item to be output using the cursor up/down keys. <table border="1" data-bbox="336 748 1401 943"> <thead> <tr> <th data-bbox="336 748 639 792">Display</th> <th data-bbox="639 748 1401 792">Output list</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 792 639 837">Maintenance</td> <td data-bbox="639 792 1401 837">List of the current settings of the maintenance modes</td> </tr> <tr> <td data-bbox="336 837 639 882">Event</td> <td data-bbox="639 837 1401 882">Outputs the event log</td> </tr> <tr> <td data-bbox="336 882 639 943">All</td> <td data-bbox="639 882 1401 943">Outputs the all reports</td> </tr> </tbody> </table> <ol data-bbox="308 954 746 983" style="list-style-type: none"> 3. Press the start key. A list is output. <p data-bbox="288 1021 724 1050">Method: Send to the USB memory</p> <ol data-bbox="308 1055 1426 1330" style="list-style-type: none"> 1. Press the power key on the operation panel, and after verifying the main power indicator has gone off, switch off the main power switch. 2. Insert USB memory in USB memory slot. 3. Turn the main power switch on. 4. Enter the maintenance item. 5. Press the start key. 6. Select the item to be send. 7. Select [Text] or [HTML]. <table border="1" data-bbox="336 1341 1401 1536"> <thead> <tr> <th data-bbox="336 1341 639 1386">Display</th> <th data-bbox="639 1341 1401 1386">Output list</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1386 639 1431">Print</td> <td data-bbox="639 1386 1401 1431">Outputs the report</td> </tr> <tr> <td data-bbox="336 1431 639 1476">USB (Text)</td> <td data-bbox="639 1431 1401 1476">Sends output data to the USB memory (text type)</td> </tr> <tr> <td data-bbox="336 1476 639 1536">USB (HTML)</td> <td data-bbox="639 1476 1401 1536">Sends output data to the USB memory (HTML type)</td> </tr> </tbody> </table> <ol data-bbox="308 1547 804 1610" style="list-style-type: none"> 8. Press the start key. Output will be sent to the USB memory. <p data-bbox="288 1648 440 1677">Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Output list	Maintenance	List of the current settings of the maintenance modes	Event	Outputs the event log	All	Outputs the all reports	Display	Output list	Print	Outputs the report	USB (Text)	Sends output data to the USB memory (text type)	USB (HTML)	Sends output data to the USB memory (HTML type)
Display	Output list																
Maintenance	List of the current settings of the maintenance modes																
Event	Outputs the event log																
All	Outputs the all reports																
Display	Output list																
Print	Outputs the report																
USB (Text)	Sends output data to the USB memory (text type)																
USB (HTML)	Sends output data to the USB memory (HTML type)																

Item No.	Description																																																																																																																																																																																							
U000	<p data-bbox="287 235 414 280">Event log</p> <div data-bbox="327 302 1396 1601" style="border: 1px solid black; padding: 10px;"> <h3 data-bbox="351 324 574 380">Event Log</h3> <p data-bbox="351 380 414 414">MFP</p> <p data-bbox="1149 380 1364 414">(2) 06/Apr/2010 08:40</p> <p data-bbox="343 436 829 470">(1) Firmware version 2KX_2000.000.000 2010.04.06</p> <p data-bbox="981 414 1364 470">(3) [XXXXXXXX] (4) [XXXXXXXX] (5) [XXXXXXXX]</p> <hr/> <div style="display: flex; justify-content: space-between;"> <div data-bbox="351 504 790 940"> <p data-bbox="351 504 558 537">(7) Paper Jam Log</p> <table border="1"> <thead> <tr> <th>#</th> <th>Count.</th> <th>Event Descriptions</th> </tr> </thead> <tbody> <tr><td>16</td><td>1876543</td><td>501.01.08.01.01</td></tr> <tr><td>15</td><td>166554</td><td>4020.01.08.01.01</td></tr> <tr><td>14</td><td>4988</td><td>501.01.08.01.01</td></tr> <tr><td>13</td><td>4988</td><td>4020.01.08.01.01</td></tr> <tr><td>12</td><td>4988</td><td>501.01.08.01.01</td></tr> <tr><td>11</td><td>4988</td><td>4020.01.08.01.01</td></tr> <tr><td>10</td><td>1103</td><td>501.01.08.01.01</td></tr> <tr><td>9</td><td>1103</td><td>4020.01.08.01.01</td></tr> <tr><td>8</td><td>1103</td><td>501.01.08.01.01</td></tr> <tr><td>7</td><td>1103</td><td>4020.01.08.01.01</td></tr> <tr><td>6</td><td>1027</td><td>501.01.08.01.01</td></tr> <tr><td>5</td><td>1027</td><td>4020.01.08.01.01</td></tr> <tr><td>4</td><td>1027</td><td>501.01.08.01.01</td></tr> <tr><td>3</td><td>1027</td><td>4020.01.08.01.01</td></tr> <tr><td>2</td><td>406</td><td>501.01.08.01.01</td></tr> <tr><td>1</td><td>36</td><td>4020.01.08.01.01</td></tr> </tbody> </table> </div> <div data-bbox="893 504 1276 750"> <p data-bbox="893 504 1117 537">(8) Service Call Log</p> <table border="1"> <thead> <tr> <th>#</th> <th>Count.</th> <th>Service Code</th> </tr> </thead> <tbody> <tr><td>8</td><td>1881214</td><td>01.6000</td></tr> <tr><td>7</td><td>178944</td><td>01.2100</td></tr> <tr><td>6</td><td>5296</td><td>01.4000</td></tr> <tr><td>5</td><td>5295</td><td>01.6000</td></tr> <tr><td>4</td><td>2099</td><td>01.2100</td></tr> <tr><td>3</td><td>1054</td><td>01.4000</td></tr> <tr><td>2</td><td>809</td><td>01.6000</td></tr> <tr><td>1</td><td>30</td><td>01.2100</td></tr> </tbody> </table> </div> <div data-bbox="893 761 1197 996"> <p data-bbox="893 761 1117 795">(9) Maintenance Log</p> <table border="1"> <thead> <tr> <th>#</th> <th>Count.</th> <th>Item</th> </tr> </thead> <tbody> <tr><td>8</td><td>1045571</td><td>01.00</td></tr> <tr><td>7</td><td>104511</td><td>01.00</td></tr> <tr><td>6</td><td>7045</td><td>01.00</td></tr> <tr><td>5</td><td>3454</td><td>01.00</td></tr> <tr><td>4</td><td>3454</td><td>01.01</td></tr> <tr><td>3</td><td>3454</td><td>01.01</td></tr> <tr><td>2</td><td>417</td><td>01.01</td></tr> <tr><td>1</td><td>34</td><td>01.01</td></tr> </tbody> </table> </div> <div data-bbox="893 1008 1197 1187"> <p data-bbox="893 1008 1149 1041">(10) Unknown toner Log</p> <table border="1"> <thead> <tr> <th>#</th> <th>Count.</th> <th>Item</th> </tr> </thead> <tbody> <tr><td>5</td><td>3454</td><td>01.00</td></tr> <tr><td>4</td><td>3454</td><td>01.00</td></tr> <tr><td>3</td><td>3454</td><td>01.00</td></tr> <tr><td>2</td><td>406</td><td>01.00</td></tr> <tr><td>1</td><td>32</td><td>01.00</td></tr> </tbody> </table> </div> </div> <div style="margin-top: 20px;"> <p data-bbox="510 985 829 1075" style="border: 1px solid black; padding: 5px; text-align: center;"> 501.01.08.01.01 (a) (b) (c) (d) (e) </p> </div> <div style="margin-top: 20px;"> <p data-bbox="335 1198 526 1232">(11) Counter Log</p> <table border="0"> <tr> <td data-bbox="351 1232 478 1265">(f) J100: 0</td> <td data-bbox="494 1232 622 1265">J512: 0</td> <td data-bbox="638 1232 766 1265">J4201: 0</td> <td data-bbox="798 1232 925 1265">(g) C0030: 1</td> <td data-bbox="957 1232 1085 1265">C2100: 1</td> <td data-bbox="1149 1232 1276 1265">(h) T00: 1</td> </tr> <tr> <td>J105: 0</td> <td>J513: 0</td> <td>J4202: 0</td> <td>C0070: 1</td> <td>C2200: 1</td> <td>T01: 1</td> </tr> <tr> <td>J106: 0</td> <td>J518: 0</td> <td>J4203: 0</td> <td>C0100: 1</td> <td>C2300: 1</td> <td></td> </tr> <tr> <td>J110: 0</td> <td>J519: 0</td> <td>J4208: 0</td> <td>C0120: 1</td> <td>C2330: 1</td> <td></td> </tr> <tr> <td>J111: 0</td> <td>J1020: 0</td> <td>J4209: 0</td> <td>C0130: 1</td> <td>C2340: 1</td> <td></td> </tr> <tr> <td>.</td> <td>.</td> <td>.</td> <td>.</td> <td>.</td> <td></td> </tr> </table> </div> <p data-bbox="1085 1545 1356 1579" style="text-align: right;">(6) [XXXXXXXXXXXXXXXXXXXX]</p> </div>	#	Count.	Event Descriptions	16	1876543	501.01.08.01.01	15	166554	4020.01.08.01.01	14	4988	501.01.08.01.01	13	4988	4020.01.08.01.01	12	4988	501.01.08.01.01	11	4988	4020.01.08.01.01	10	1103	501.01.08.01.01	9	1103	4020.01.08.01.01	8	1103	501.01.08.01.01	7	1103	4020.01.08.01.01	6	1027	501.01.08.01.01	5	1027	4020.01.08.01.01	4	1027	501.01.08.01.01	3	1027	4020.01.08.01.01	2	406	501.01.08.01.01	1	36	4020.01.08.01.01	#	Count.	Service Code	8	1881214	01.6000	7	178944	01.2100	6	5296	01.4000	5	5295	01.6000	4	2099	01.2100	3	1054	01.4000	2	809	01.6000	1	30	01.2100	#	Count.	Item	8	1045571	01.00	7	104511	01.00	6	7045	01.00	5	3454	01.00	4	3454	01.01	3	3454	01.01	2	417	01.01	1	34	01.01	#	Count.	Item	5	3454	01.00	4	3454	01.00	3	3454	01.00	2	406	01.00	1	32	01.00	(f) J100: 0	J512: 0	J4201: 0	(g) C0030: 1	C2100: 1	(h) T00: 1	J105: 0	J513: 0	J4202: 0	C0070: 1	C2200: 1	T01: 1	J106: 0	J518: 0	J4203: 0	C0100: 1	C2300: 1		J110: 0	J519: 0	J4208: 0	C0120: 1	C2330: 1		J111: 0	J1020: 0	J4209: 0	C0130: 1	C2340: 1		
#	Count.	Event Descriptions																																																																																																																																																																																						
16	1876543	501.01.08.01.01																																																																																																																																																																																						
15	166554	4020.01.08.01.01																																																																																																																																																																																						
14	4988	501.01.08.01.01																																																																																																																																																																																						
13	4988	4020.01.08.01.01																																																																																																																																																																																						
12	4988	501.01.08.01.01																																																																																																																																																																																						
11	4988	4020.01.08.01.01																																																																																																																																																																																						
10	1103	501.01.08.01.01																																																																																																																																																																																						
9	1103	4020.01.08.01.01																																																																																																																																																																																						
8	1103	501.01.08.01.01																																																																																																																																																																																						
7	1103	4020.01.08.01.01																																																																																																																																																																																						
6	1027	501.01.08.01.01																																																																																																																																																																																						
5	1027	4020.01.08.01.01																																																																																																																																																																																						
4	1027	501.01.08.01.01																																																																																																																																																																																						
3	1027	4020.01.08.01.01																																																																																																																																																																																						
2	406	501.01.08.01.01																																																																																																																																																																																						
1	36	4020.01.08.01.01																																																																																																																																																																																						
#	Count.	Service Code																																																																																																																																																																																						
8	1881214	01.6000																																																																																																																																																																																						
7	178944	01.2100																																																																																																																																																																																						
6	5296	01.4000																																																																																																																																																																																						
5	5295	01.6000																																																																																																																																																																																						
4	2099	01.2100																																																																																																																																																																																						
3	1054	01.4000																																																																																																																																																																																						
2	809	01.6000																																																																																																																																																																																						
1	30	01.2100																																																																																																																																																																																						
#	Count.	Item																																																																																																																																																																																						
8	1045571	01.00																																																																																																																																																																																						
7	104511	01.00																																																																																																																																																																																						
6	7045	01.00																																																																																																																																																																																						
5	3454	01.00																																																																																																																																																																																						
4	3454	01.01																																																																																																																																																																																						
3	3454	01.01																																																																																																																																																																																						
2	417	01.01																																																																																																																																																																																						
1	34	01.01																																																																																																																																																																																						
#	Count.	Item																																																																																																																																																																																						
5	3454	01.00																																																																																																																																																																																						
4	3454	01.00																																																																																																																																																																																						
3	3454	01.00																																																																																																																																																																																						
2	406	01.00																																																																																																																																																																																						
1	32	01.00																																																																																																																																																																																						
(f) J100: 0	J512: 0	J4201: 0	(g) C0030: 1	C2100: 1	(h) T00: 1																																																																																																																																																																																			
J105: 0	J513: 0	J4202: 0	C0070: 1	C2200: 1	T01: 1																																																																																																																																																																																			
J106: 0	J518: 0	J4203: 0	C0100: 1	C2300: 1																																																																																																																																																																																				
J110: 0	J519: 0	J4208: 0	C0120: 1	C2330: 1																																																																																																																																																																																				
J111: 0	J1020: 0	J4209: 0	C0130: 1	C2340: 1																																																																																																																																																																																				
.																																																																																																																																																																																				
.																																																																																																																																																																																				
.																																																																																																																																																																																				
.																																																																																																																																																																																				
.																																																																																																																																																																																				

Figure 1-3-1



Item No.	Description				
U000	Detail of event log				
	No.	Items	Description		
	(1)	System version			
	(2)	System date			
	(3)	Engine soft version			
	(4)	Engine boot version			
	(5)	Operation panel mask version			
	(6)	Machine serial number			
	(7)	Paper Jam Log	<p>#</p> <p>Remembers 1 to 16 of occurrence. If the occurrence of the previous paper jam is less than 16, all of the paper jams are logged. When the occurrence exceeds 16, the oldest occurrence is removed.</p> <p>(a) Cause of paper jam (Hexadecimal)</p> <p>Refer to P.1-4-1 for paper jam location</p> <p>0100: Controller sequence error 0105: Registration sensor not detected 0106: Controller sequence error 0110: Top tray open 0111: Rear cover open 0112: Front cover open 0113: MP tray open 0120: Controller sequence error 0121: Controller sequence error 0211: Rear cover open (paper feeder 1) 0212: Rear cover open (paper feeder 2) 0501: No paper feed from cassette 1 0502: No paper feed from cassette 2 0503: No paper feed from cassette 3 0508: No paper feed from duplex section 0509: No paper feed from MP tray 0511: Multiple sheets in cassette 1 0512: Multiple sheets in cassette 2 0513: Multiple sheets in cassette 3 0518: Multiple sheets in duplex section 0519: Multiple sheets in MP tray 1020: MP feed sensor is turned ON 1403: PF feed sensor 1 does not turn ON 1413: PF feed sensor 1 does not turn OFF 1420: PF feed sensor 1 is turned ON 1620: PF feed sensor 2 is turned ON</p>	<p>Count.</p> <p>The total page count at the time of the paper jam.</p>	<p>Event</p> <p>Log code (2 digit, hexadecimal, 5 categories)</p> <p>(a) Cause of a paper jam (b) Paper source (c) Paper size (d) Paper type (e) Paper eject</p>


www.tonerplus.com.ua

Item No.	Description																			
U000	<table border="1"> <thead> <tr> <th data-bbox="295 277 375 322">No.</th> <th data-bbox="375 277 574 322">Items</th> <th data-bbox="574 277 1417 322">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="295 322 375 1137">(7) cont.</td> <td data-bbox="375 322 574 1137">Paper Jam Log</td> <td data-bbox="574 322 1417 1137"> 4002: Registration sensor does not turn ON (Paper feeder 1) 4003: Registration sensor does not turn ON (Paper feeder 2) 4009: Registration sensor does not turn ON (MP tray) 4012: Registration sensor does not turn OFF (Paper feeder 1) 4013: Registration sensor does not turn OFF (Paper feeder 2) 4019: Registration sensor does not turn OFF (MP tray) 4020: Registration sensor is turned ON 4201: Eject sensor does not turn ON (Cassette) 4202: Eject sensor does not turn ON (Paper feeder 1) 4203: Eject sensor does not turn ON (Paper feeder 2) 4208: Eject sensor does not turn ON (Duplex) 4209: Eject sensor does not turn ON (MP tray) 4211: Eject sensor does not turn OFF (Cassette) 4212: Eject sensor does not turn OFF (Paper feeder 1) 4213: Eject sensor does not turn OFF (Paper feeder 2) 4218: Eject sensor does not turn OFF (Duplex) 4219: Eject sensor does not turn OFF (MP tray) 4220: Eject sensor is turned ON 9010: DP top cover open 9400: No original feed 9401: An original jam in the original switchback section 2 9410: An original jam in the original conveying section 9411: An original jam in the original switchback section 1 </td> </tr> <tr> <td colspan="3" data-bbox="574 1137 1417 1182">(b) Detail of paper source (Hexadecimal)</td> </tr> <tr> <td colspan="3" data-bbox="574 1182 1417 1373"> 00: MP tray 01: Cassette 1 02: Cassette 2 (paper feeder 1) 03: Cassette 3 (paper feeder 2) 04 to 09: Reserved </td> </tr> <tr> <td colspan="3" data-bbox="574 1373 1417 1417">(c) Detail of paper size (Hexadecimal)</td> </tr> <tr> <td data-bbox="574 1417 853 1989"> 00: (Not specified) 01: Monarch 02: Business 03: International DL 04: International C5 05: Executive 06: Letter-R 86: Letter-E 07: Legal 08: A4R 88: A4E 09: B5R 89: B5E 0A: A3 </td> <td data-bbox="853 1417 1133 1989"> 0B: B4 0C: Ledger 0D: A5R 0E: A6 0F: B6 10: Commercial #9 11: Commercial #6 12: ISO B5 13: Custom size 1E: C4 1F: Postcard 20: Reply-paid post-card 21: Oficio II </td> <td data-bbox="1133 1417 1417 1989"> 22: Special 1 23: Special 2 24: A3 wide 25: Ledger wide 26: Full bleed paper (12 x 8) 27: 8K 28: 16K-R A8: 16K-E 32: Statement-R B2: Statement-E 33: Folio 34: Western type 2 35: Western type 4 </td> </tr> </tbody> </table>		No.	Items	Description	(7) cont.	Paper Jam Log	4002: Registration sensor does not turn ON (Paper feeder 1) 4003: Registration sensor does not turn ON (Paper feeder 2) 4009: Registration sensor does not turn ON (MP tray) 4012: Registration sensor does not turn OFF (Paper feeder 1) 4013: Registration sensor does not turn OFF (Paper feeder 2) 4019: Registration sensor does not turn OFF (MP tray) 4020: Registration sensor is turned ON 4201: Eject sensor does not turn ON (Cassette) 4202: Eject sensor does not turn ON (Paper feeder 1) 4203: Eject sensor does not turn ON (Paper feeder 2) 4208: Eject sensor does not turn ON (Duplex) 4209: Eject sensor does not turn ON (MP tray) 4211: Eject sensor does not turn OFF (Cassette) 4212: Eject sensor does not turn OFF (Paper feeder 1) 4213: Eject sensor does not turn OFF (Paper feeder 2) 4218: Eject sensor does not turn OFF (Duplex) 4219: Eject sensor does not turn OFF (MP tray) 4220: Eject sensor is turned ON 9010: DP top cover open 9400: No original feed 9401: An original jam in the original switchback section 2 9410: An original jam in the original conveying section 9411: An original jam in the original switchback section 1	(b) Detail of paper source (Hexadecimal)			00: MP tray 01: Cassette 1 02: Cassette 2 (paper feeder 1) 03: Cassette 3 (paper feeder 2) 04 to 09: Reserved			(c) Detail of paper size (Hexadecimal)			00: (Not specified) 01: Monarch 02: Business 03: International DL 04: International C5 05: Executive 06: Letter-R 86: Letter-E 07: Legal 08: A4R 88: A4E 09: B5R 89: B5E 0A: A3	0B: B4 0C: Ledger 0D: A5R 0E: A6 0F: B6 10: Commercial #9 11: Commercial #6 12: ISO B5 13: Custom size 1E: C4 1F: Postcard 20: Reply-paid post-card 21: Oficio II	22: Special 1 23: Special 2 24: A3 wide 25: Ledger wide 26: Full bleed paper (12 x 8) 27: 8K 28: 16K-R A8: 16K-E 32: Statement-R B2: Statement-E 33: Folio 34: Western type 2 35: Western type 4
No.	Items	Description																		
(7) cont.	Paper Jam Log	4002: Registration sensor does not turn ON (Paper feeder 1) 4003: Registration sensor does not turn ON (Paper feeder 2) 4009: Registration sensor does not turn ON (MP tray) 4012: Registration sensor does not turn OFF (Paper feeder 1) 4013: Registration sensor does not turn OFF (Paper feeder 2) 4019: Registration sensor does not turn OFF (MP tray) 4020: Registration sensor is turned ON 4201: Eject sensor does not turn ON (Cassette) 4202: Eject sensor does not turn ON (Paper feeder 1) 4203: Eject sensor does not turn ON (Paper feeder 2) 4208: Eject sensor does not turn ON (Duplex) 4209: Eject sensor does not turn ON (MP tray) 4211: Eject sensor does not turn OFF (Cassette) 4212: Eject sensor does not turn OFF (Paper feeder 1) 4213: Eject sensor does not turn OFF (Paper feeder 2) 4218: Eject sensor does not turn OFF (Duplex) 4219: Eject sensor does not turn OFF (MP tray) 4220: Eject sensor is turned ON 9010: DP top cover open 9400: No original feed 9401: An original jam in the original switchback section 2 9410: An original jam in the original conveying section 9411: An original jam in the original switchback section 1																		
(b) Detail of paper source (Hexadecimal)																				
00: MP tray 01: Cassette 1 02: Cassette 2 (paper feeder 1) 03: Cassette 3 (paper feeder 2) 04 to 09: Reserved																				
(c) Detail of paper size (Hexadecimal)																				
00: (Not specified) 01: Monarch 02: Business 03: International DL 04: International C5 05: Executive 06: Letter-R 86: Letter-E 07: Legal 08: A4R 88: A4E 09: B5R 89: B5E 0A: A3	0B: B4 0C: Ledger 0D: A5R 0E: A6 0F: B6 10: Commercial #9 11: Commercial #6 12: ISO B5 13: Custom size 1E: C4 1F: Postcard 20: Reply-paid post-card 21: Oficio II	22: Special 1 23: Special 2 24: A3 wide 25: Ledger wide 26: Full bleed paper (12 x 8) 27: 8K 28: 16K-R A8: 16K-E 32: Statement-R B2: Statement-E 33: Folio 34: Western type 2 35: Western type 4																		

Item No.	Description				
U000					
	No.	Items	Description		
	(7) cont.	Paper Jam Log	(d) Detail of paper type (Hexadecimal)		
	01: Plain 02: Transparency 03: Preprinted 04: Labels 05: Bond 06: Recycled 07: Vellum 08: Rough 09: Letterhead		0A: Color 0B: Prepunched 0C: Envelope 0D: Cardstock 0E: Coated 0F: 2nd side 10: Media 16 11: High quality	15: Custom 1 16: Custom 2 17: Custom 3 18: Custom 4 19: Custom 5 1A: Custom 6 1B: Custom 7 1C: Custom 8	
	(e) Detail of paper eject location (Hexadecimal)				
	01: Face down (FD)				
	(8)	Service Call Log	#	Count.	Service Code
	Remembers 1 to 8 of occurrence of self diagnostics error. If the occurrence of the previous diagnostics error is less than 8, all of the diagnostics errors are logged.		The total page count at the time of the self diagnostics error.	Self diagnostic error code (See page 1-4-7) Example: 01.6000 01: Self diagnostic error 6000: Self diagnostic error code number	
	(9)	Maintenance Log	#	Count.	Item
	Remembers 1 to 8 of occurrence of replacement. If the occurrence of the previous replacement of toner container is less than 8, all of the occurrences of replacement are logged.		The total page count at the time of the replacement of the toner container.	Code of maintenance replacing item (1 byte, 2 categories) First byte (Replacing item) 01: Toner container Second byte (Type of replacing item) 00: Black 01: Cyan 02: Magenta 03: Yellow First byte (Replacing item) 02: Maintenance kit Second byte (Type of replacing item) 00: - 01: -	

Item No.	Description			
U000			Description	
	(10)	Unknown Toner Log	#	Count. Item
			Remembers 1 to 5 of occurrence of unknown toner detection. If the occurrence of the previous unknown toner detection is less than 5, all of the unknown toner detection are logged.	The total page count at the time of the toner empty error with using an unknown toner container.
(11)	Counter Log	(f) Paper jam	(g) Self diagnostic error	(h) Maintenance item replacing
	Comprised of three log counters including paper jams, self diagnostics errors, and replacement of the toner container.	Indicates the log counter of paper jams depending on location. Refer to Paper Jam Log. All instances including those are not occurred are displayed.	Indicates the log counter of self diagnostics errors depending on cause. (See page 1-4-7) Example: C6000: 4 Self diagnostics error 6000 has happened four times.	Indicates the log counter depending on the maintenance item for maintenance. T: Toner container 00: Black 01: Cyan 02: Magenta 03: Yellow M: Maintenance kit 00: - 01: - Example: T00: 1 The toner container has been replaced once.

Item No.	Description								
U002	<p data-bbox="288 241 686 275">Setting the factory default data</p> <p data-bbox="288 313 438 342">Description</p> <p data-bbox="288 347 1037 376">Restores the machine conditions to the factory default settings.</p> <p data-bbox="288 383 399 412">Purpose</p> <p data-bbox="288 416 1426 481">To move the mirror frame of the scanner to the position for transport (position in which the frame can be fixed).</p> <p data-bbox="288 519 387 548">Method</p> <ol data-bbox="308 555 941 651" style="list-style-type: none"> 1. Press the start key. 2. Select [Mode1(All)] using the cursor up/down keys. 3. Press the start key. <p data-bbox="336 658 1137 687">The mirror frame of the scanner returns to the position for transport.</p> <ol data-bbox="308 694 798 723" style="list-style-type: none"> 4. Turn the main power switch off and on. <p data-bbox="336 730 1059 759">* : An error code is displayed in case of an initialization error.</p> <p data-bbox="371 766 1426 831">When errors occurred, turn main power switch off then on, and execute initialization using maintenance item U002.</p> <p data-bbox="288 869 443 898">Error codes</p> <table border="1" data-bbox="336 909 1401 1104"> <thead> <tr> <th data-bbox="336 909 639 958">Codes</th> <th data-bbox="639 909 1401 958">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 958 639 1003">0001</td> <td data-bbox="639 958 1401 1003">Controller error</td> </tr> <tr> <td data-bbox="336 1003 639 1048">0020</td> <td data-bbox="639 1003 1401 1048">Engine error</td> </tr> <tr> <td data-bbox="336 1048 639 1104">0040</td> <td data-bbox="639 1048 1401 1104">Scanner error</td> </tr> </tbody> </table>	Codes	Description	0001	Controller error	0020	Engine error	0040	Scanner error
Codes	Description								
0001	Controller error								
0020	Engine error								
0040	Scanner error								

Item No.	Description																
U203	<p data-bbox="288 241 587 271">Checking DP operation</p> <p data-bbox="288 311 440 340">Description</p> <p data-bbox="288 344 1046 374">Simulates the original conveying operation separately in the DP.</p> <p data-bbox="288 380 400 409">Purpose</p> <p data-bbox="288 414 612 443">To check the DP operation.</p> <p data-bbox="288 483 387 512">Method</p> <ol data-bbox="308 517 1091 618" style="list-style-type: none"> 1. Press the start key. 2. Place an original in the DP if running this simulation with paper. 3. Select the speed to be operated using the cursor up/down keys. <table border="1" data-bbox="336 631 1399 775"> <thead> <tr> <th data-bbox="336 631 639 676">Display</th> <th data-bbox="639 631 1399 676">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 676 639 721">Normal Speed</td> <td data-bbox="639 676 1399 721">Normal reading (600 dpi)</td> </tr> <tr> <td data-bbox="336 721 639 775">High Speed</td> <td data-bbox="639 721 1399 775">High-speed reading</td> </tr> </tbody> </table> <ol data-bbox="308 786 1069 851" style="list-style-type: none"> 4. Press the start key. 5. Select the item to be operated using the cursor up/down keys. <table border="1" data-bbox="336 864 1399 1171"> <thead> <tr> <th data-bbox="336 864 639 909">Display</th> <th data-bbox="639 864 1399 909">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 909 639 987">CCD ADP (Non-P)</td> <td data-bbox="639 909 1399 987">Without paper, single-sided original of CCD (continuous operation)</td> </tr> <tr> <td data-bbox="336 987 639 1032">CCD ADP</td> <td data-bbox="639 987 1399 1032">With paper, single-sided original of CCD</td> </tr> <tr> <td data-bbox="336 1032 639 1111">CCD RADP (Non-P)</td> <td data-bbox="639 1032 1399 1111">Without paper, double-sided original of CCD (continuous operation)</td> </tr> <tr> <td data-bbox="336 1111 639 1171">CCD RADP</td> <td data-bbox="639 1111 1399 1171">With paper, double-sided original of CCD</td> </tr> </tbody> </table> <ol data-bbox="308 1184 916 1249" style="list-style-type: none"> 6. Press the start key. The operation starts. 7. To stop continuous operation, press the stop key. <p data-bbox="288 1290 440 1319">Completion</p> <p data-bbox="288 1323 1254 1352">Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Normal Speed	Normal reading (600 dpi)	High Speed	High-speed reading	Display	Description	CCD ADP (Non-P)	Without paper, single-sided original of CCD (continuous operation)	CCD ADP	With paper, single-sided original of CCD	CCD RADP (Non-P)	Without paper, double-sided original of CCD (continuous operation)	CCD RADP	With paper, double-sided original of CCD
Display	Description																
Normal Speed	Normal reading (600 dpi)																
High Speed	High-speed reading																
Display	Description																
CCD ADP (Non-P)	Without paper, single-sided original of CCD (continuous operation)																
CCD ADP	With paper, single-sided original of CCD																
CCD RADP (Non-P)	Without paper, double-sided original of CCD (continuous operation)																
CCD RADP	With paper, double-sided original of CCD																

Item No.	Description						
U222	<p>Setting the IC card type</p> <p>Description Sets the type of IC card.</p> <p>Purpose To change the type of IC card.</p> <p>Setting</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select the item using the cursor up/down keys. <table border="1" data-bbox="336 598 1401 741"> <thead> <tr> <th data-bbox="336 598 639 642">Display</th> <th data-bbox="639 598 1401 642">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 642 639 687">Other</td> <td data-bbox="639 642 1401 687">The type of IC card is SSFC.</td> </tr> <tr> <td data-bbox="336 687 639 741">SSFC</td> <td data-bbox="639 687 1401 741">The type of IC card is not SSFC.</td> </tr> </tbody> </table> <p>* : Initial setting: Other</p> <ol style="list-style-type: none"> 3. Press the start key. The setting is set. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Other	The type of IC card is SSFC.	SSFC	The type of IC card is not SSFC.
Display	Description						
Other	The type of IC card is SSFC.						
SSFC	The type of IC card is not SSFC.						
U250	<p>Setting the maintenance cycle</p> <p>Description Displays, clears and changes the maintenance cycle.</p> <p>Purpose To check and change the maintenance cycle.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. The currently set maintenance cycle is displayed. <p>Setting</p> <ol style="list-style-type: none"> 1. Select [M.Cnt A] using the cursor up/down keys. 2. Change the setting using the cursor left/right keys or numeric keys. <table border="1" data-bbox="336 1397 1401 1491"> <thead> <tr> <th data-bbox="336 1397 868 1442">Description</th> <th data-bbox="868 1397 1134 1442">Setting range</th> <th data-bbox="1134 1397 1401 1442">Initial setting</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1442 868 1491">Maintenance cycle</td> <td data-bbox="868 1442 1134 1491">0 to 9999999</td> <td data-bbox="1134 1442 1401 1491">100000</td> </tr> </tbody> </table> <ol style="list-style-type: none"> 3. Press the start key. The value is set. <p>Clearing</p> <ol style="list-style-type: none"> 1. Select [Clear] using the cursor up/down keys. 2. Press the start key. The count is cleared. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Description	Setting range	Initial setting	Maintenance cycle	0 to 9999999	100000
Description	Setting range	Initial setting					
Maintenance cycle	0 to 9999999	100000					

Item No.	Description						
U251	<p data-bbox="290 241 823 273">Checking/clearing the maintenance count</p> <p data-bbox="290 311 440 342">Description Displays, clears and changes the maintenance count.</p> <p data-bbox="290 380 400 412">Purpose To check the maintenance count. Also to clear the count during maintenance service (replacing the maintenance kit).</p> <p data-bbox="290 512 387 544">Method 1. Press the start key. The maintenance count is displayed.</p> <p data-bbox="290 618 384 649">Setting 1. Select [M.Cnt A] using the cursor up/down keys. 2. Change the setting using the cursor left/right keys or numeric keys.</p> <table border="1" data-bbox="338 730 1401 826"> <thead> <tr> <th data-bbox="338 730 868 775">Description</th> <th data-bbox="868 730 1134 775">Setting range</th> <th data-bbox="1134 730 1401 775">Initial setting</th> </tr> </thead> <tbody> <tr> <td data-bbox="338 775 868 826">Maintenance count</td> <td data-bbox="868 775 1134 826">0 to 9999999</td> <td data-bbox="1134 775 1401 826">0</td> </tr> </tbody> </table> <p data-bbox="290 837 767 869">3. Press the start key. The count is set.</p> <p data-bbox="290 907 400 938">Clearing 1. Select [Clear] using the cursor up/down keys. 2. Press the start key. The count is cleared.</p> <p data-bbox="290 1043 440 1075">Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Description	Setting range	Initial setting	Maintenance count	0 to 9999999	0
Description	Setting range	Initial setting					
Maintenance count	0 to 9999999	0					

Item No.	Description												
U253	<p>Switching between double and single counts</p> <p>Description Switches the count system for the total counter and other counters.</p> <p>Purpose Used to select, according to the preference of the user (copy service provider), if folio size paper is to be counted as one sheet (single count) or two sheets (double count).</p> <p>Setting</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select the item using the cursor up/down keys. <table border="1" data-bbox="336 631 1401 777"> <thead> <tr> <th>Display</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>Color</td> <td>Count system of color mode</td> </tr> <tr> <td>B/W</td> <td>Count system of black/white mode</td> </tr> </tbody> </table> <ol style="list-style-type: none"> 3. Press the start key. 4. Select the count system using the cursor up/down keys. <table border="1" data-bbox="336 866 1401 1012"> <thead> <tr> <th>Display</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>SGL Count(All)</td> <td>Single count for all size paper</td> </tr> <tr> <td>DBL Count(Folio)</td> <td>Double count for Folio size or larger</td> </tr> </tbody> </table> <p>* : Initial setting: DBL Count(Folio)</p> <ol style="list-style-type: none"> 5. Press the start key. The setting is set. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Color	Count system of color mode	B/W	Count system of black/white mode	Display	Description	SGL Count(All)	Single count for all size paper	DBL Count(Folio)	Double count for Folio size or larger
Display	Description												
Color	Count system of color mode												
B/W	Count system of black/white mode												
Display	Description												
SGL Count(All)	Single count for all size paper												
DBL Count(Folio)	Double count for Folio size or larger												
U260	<p>Selecting the timing for copy counting</p> <p>Description Changes the copy count timing for the total counter and other counters.</p> <p>Purpose To be set according to user request.</p> <p>Setting</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select the copy count timing using the cursor up/down keys. <table border="1" data-bbox="336 1563 1401 1709"> <thead> <tr> <th>Display</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>Feed</td> <td>When secondary paper feed starts</td> </tr> <tr> <td>Eject</td> <td>When the paper is ejected</td> </tr> </tbody> </table> <p>* : Initial setting: Eject</p> <ol style="list-style-type: none"> 3. Press the start key. The setting is set. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Feed	When secondary paper feed starts	Eject	When the paper is ejected						
Display	Description												
Feed	When secondary paper feed starts												
Eject	When the paper is ejected												

Item No.	Description								
U285	<p>Setting service status page</p> <p>Description Determines displaying the digital dot coverage report on reporting.</p> <p>Purpose According to user request, changes the setting.</p> <p>Setting</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select On or Off using the cursor up/down keys. <table border="1" data-bbox="336 595 1401 741"> <thead> <tr> <th>Display</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>On</td> <td>Displays the digital dot coverage</td> </tr> <tr> <td>Off</td> <td>Not to display the digital dot coverage</td> </tr> </tbody> </table> <p>* : Initial setting: On</p> <ol style="list-style-type: none"> 3. Press the start key. The setting is set. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	On	Displays the digital dot coverage	Off	Not to display the digital dot coverage		
Display	Description								
On	Displays the digital dot coverage								
Off	Not to display the digital dot coverage								
U332	<p>Setting the size conversion factor</p> <p>Description Sets the coefficient of nonstandard sizes in relation to the A4/Letter size. The coefficient set here is used to convert the black ratio in relation to the A4/Letter size and to display the result in user simulation.</p> <p>Purpose To set the coefficient for converting the black ratio for nonstandard sizes in relation to the A4/Letter size.</p> <p>Setting</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Change the setting using the cursor left/right keys or numeric keys. <table border="1" data-bbox="336 1397 1385 1491"> <thead> <tr> <th>Display</th> <th>Description</th> <th>Setting range</th> <th>Initial setting</th> </tr> </thead> <tbody> <tr> <td>Rate</td> <td>Size parameter</td> <td>0.1 to 3.0</td> <td>1.0</td> </tr> </tbody> </table> <ol style="list-style-type: none"> 3. Press the start key. The value is set. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Setting range	Initial setting	Rate	Size parameter	0.1 to 3.0	1.0
Display	Description	Setting range	Initial setting						
Rate	Size parameter	0.1 to 3.0	1.0						

Item No.	Description						
U345	<p data-bbox="292 244 911 271">Setting the value for maintenance due indication</p> <p data-bbox="292 315 440 342">Description</p> <p data-bbox="292 344 1417 456">Sets when to display a message notifying that the time for maintenance is about to be reached, by setting the number of copies that can be made before the current maintenance cycle ends. When the difference between the number of copies of the maintenance cycle and that of the maintenance count reaches the set value, the message is displayed.</p> <p data-bbox="292 459 400 486">Purpose</p> <p data-bbox="292 488 898 515">To change the time for maintenance due indication.</p> <p data-bbox="292 560 384 586">Setting</p> <ol data-bbox="308 589 932 696" style="list-style-type: none"> 1. Press the start key. 2. Select [Cnt] using the cursor up/down keys. 3. Change the setting using the cursor left/right keys. <table border="1" data-bbox="338 707 1401 875"> <thead> <tr> <th data-bbox="338 707 975 752">Description</th> <th data-bbox="975 707 1189 752">Setting range</th> <th data-bbox="1189 707 1401 752">Initial setting</th> </tr> </thead> <tbody> <tr> <td data-bbox="338 752 975 875">Time for maintenance due indication (Remaining number of copies that can be made before the current maintenance cycle ends)</td> <td data-bbox="975 752 1189 875">0 to 9999</td> <td data-bbox="1189 752 1401 875">0</td> </tr> </tbody> </table> <ol data-bbox="308 887 767 913" style="list-style-type: none"> 4. Press the start key. The value is set. <p data-bbox="292 958 400 985">Clearing</p> <ol data-bbox="308 987 874 1050" style="list-style-type: none"> 1. Select [Clear] using the cursor up/down keys. 2. Press the start key. The value is cleared. <p data-bbox="292 1095 440 1122">Completion</p> <p data-bbox="292 1124 1254 1151">Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Description	Setting range	Initial setting	Time for maintenance due indication (Remaining number of copies that can be made before the current maintenance cycle ends)	0 to 9999	0
Description	Setting range	Initial setting					
Time for maintenance due indication (Remaining number of copies that can be made before the current maintenance cycle ends)	0 to 9999	0					

Item No.	Description																																
U410	<p data-bbox="288 241 751 275">Adjusting the halftone automatically</p> <p data-bbox="288 311 440 340">Description</p> <p data-bbox="288 344 1390 412">Carries out processing for the data acquisition that is required in order to perform either automatic adjustment of the halftone or the ID correction operation.</p> <p data-bbox="288 416 400 445">Purpose</p> <p data-bbox="288 450 1067 479">Performed when the quality of reproduced halftones has dropped.</p> <p data-bbox="288 517 387 546">Method</p> <ol data-bbox="304 553 1292 965" style="list-style-type: none"> 1. Select [Normal Mode]. 2. Press the start key. A test patterns 1 and 2 are outputted. 3. Place the output test pattern 1 as the original. Place approximately 20 sheets of white paper on the test pattern 1 and set them. 4. Press the start key. Adjustment is made (first time). 5. Place the output test pattern 2 as the original. Place approximately 20 sheets of white paper on the test pattern 2 and set them. 6. Press the start key. Adjustment is made (second time). 7. When normally completed, [Finish] is displayed. If a problem occurs during auto adjustment, error code is displayed. <p data-bbox="288 1003 440 1032">Error codes</p> <table border="1" data-bbox="336 1048 1401 1480"> <thead> <tr> <th data-bbox="336 1048 491 1093">Codes</th> <th data-bbox="491 1048 871 1093">Description</th> <th data-bbox="871 1048 1023 1093">Codes</th> <th data-bbox="1023 1048 1401 1093">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1093 491 1137">S001</td> <td data-bbox="491 1093 871 1137">Patch not detected</td> <td data-bbox="871 1093 1023 1137">E001</td> <td data-bbox="1023 1093 1401 1137">Engine status error</td> </tr> <tr> <td data-bbox="336 1137 491 1227">S002</td> <td data-bbox="491 1137 871 1227">Original deviation in the main scanning direction</td> <td data-bbox="871 1137 1023 1182">E002</td> <td data-bbox="1023 1137 1401 1182">Engine sensor error</td> </tr> <tr> <td data-bbox="336 1227 491 1317">S003</td> <td data-bbox="491 1227 871 1317">Original deviation in the auxiliary scanning direction</td> <td data-bbox="871 1182 1023 1227">EFFF</td> <td data-bbox="1023 1182 1401 1227">Engine other error</td> </tr> <tr> <td data-bbox="336 1317 491 1361">S004</td> <td data-bbox="491 1317 871 1361">Original inclination error</td> <td data-bbox="871 1227 1023 1272">C001</td> <td data-bbox="1023 1227 1401 1272">Controller error</td> </tr> <tr> <td data-bbox="336 1361 491 1406">S005</td> <td data-bbox="491 1361 871 1406">Original type error</td> <td data-bbox="871 1272 1023 1317">C100</td> <td data-bbox="1023 1272 1401 1317">Adjustment value error</td> </tr> <tr> <td data-bbox="336 1406 491 1451">SFFF</td> <td data-bbox="491 1406 871 1451">Scanner other error</td> <td data-bbox="871 1317 1023 1361">C200</td> <td data-bbox="1023 1317 1401 1361">Adjustment value error</td> </tr> <tr> <td data-bbox="336 1451 491 1480"></td> <td data-bbox="491 1451 871 1480"></td> <td data-bbox="871 1361 1023 1406">CFFF</td> <td data-bbox="1023 1361 1401 1406">Controller other error</td> </tr> </tbody> </table> <p data-bbox="288 1525 440 1554">Completion</p> <p data-bbox="288 1559 1206 1588">Press the stop key. The screen for selecting a maintenance item is displayed.</p>	Codes	Description	Codes	Description	S001	Patch not detected	E001	Engine status error	S002	Original deviation in the main scanning direction	E002	Engine sensor error	S003	Original deviation in the auxiliary scanning direction	EFFF	Engine other error	S004	Original inclination error	C001	Controller error	S005	Original type error	C100	Adjustment value error	SFFF	Scanner other error	C200	Adjustment value error			CFFF	Controller other error
Codes	Description	Codes	Description																														
S001	Patch not detected	E001	Engine status error																														
S002	Original deviation in the main scanning direction	E002	Engine sensor error																														
S003	Original deviation in the auxiliary scanning direction	EFFF	Engine other error																														
S004	Original inclination error	C001	Controller error																														
S005	Original type error	C100	Adjustment value error																														
SFFF	Scanner other error	C200	Adjustment value error																														
		CFFF	Controller other error																														

Item No.	Description												
U411	<p data-bbox="287 241 753 275">Adjusting the scanner automatically</p> <p data-bbox="287 309 440 342">Description</p> <p data-bbox="287 344 1431 412">Uses the adjustment original supplied with DP and automatically adjusts the following items in the scanner and the DP scanning sections.</p> <p data-bbox="287 414 1431 481">Scanner section: Original size magnification, leading edge timing, center line, input gamma, input gamma in monochrome mode and matrix</p> <p data-bbox="287 483 1249 517">DP scanning section: Original size magnification, leading edge timing, center line</p> <p data-bbox="287 519 400 553">Purpose</p> <p data-bbox="287 555 1423 589">To perform automatic adjustment of various items in the scanner and the DP scanning sections.</p> <p data-bbox="287 622 387 656">Method</p> <ol data-bbox="308 658 978 725" style="list-style-type: none"> 1. Press the start key. 2. Select the item. The screen for executing is displayed. <table border="1" data-bbox="336 734 1399 1099"> <thead> <tr> <th data-bbox="336 734 564 813">Display</th> <th data-bbox="564 734 1096 813">Description</th> <th data-bbox="1096 734 1399 813">Original to be used for adjustment (P/N)</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 813 564 936">All</td> <td data-bbox="564 813 1096 936">Performs automatic adjustment in the DP scanning section following automatic adjustment in the scanner section</td> <td data-bbox="1096 813 1399 936">302FZ56990/ 303LJ57010</td> </tr> <tr> <td data-bbox="336 936 564 1014">Table</td> <td data-bbox="564 936 1096 1014">Automatic adjustment in the scanner section</td> <td data-bbox="1096 936 1399 1014">302FZ56990</td> </tr> <tr> <td data-bbox="336 1014 564 1099">DP</td> <td data-bbox="564 1014 1096 1099">Automatic adjustment in the DP scanning section:</td> <td data-bbox="1096 1014 1399 1099">303LJ57010</td> </tr> </tbody> </table> <p data-bbox="287 1144 472 1178">Method: Table</p> <ol data-bbox="308 1180 1431 1561" style="list-style-type: none"> 1. Enter the target values which are shown on the specified original (P/N: 302FZ56990) executing maintenance item U425. 2. Set a specified original (P/N: 302FZ56990) on the platen. 3. Enter maintenance item U411. 4. Select [Table] using the cursor up/down keys. 5. Press the start key. Auto adjustment starts. 6. When automatic adjustment has normally completed, [OK] is displayed. If a problem occurs during auto adjustment, [NG XX] (XX is replaced by an error code) is displayed and operation stops. Should this happen, determine the details of the problem and repeat the procedure from the beginning. 7. To return to the screen for selecting an item, press the stop key. <p data-bbox="287 1594 440 1628">Method: DP</p> <ol data-bbox="308 1630 1431 1906" style="list-style-type: none"> 1. Select [DP] using the cursor up/down keys. 2. Set a specified original (P/N: 303LJ57010) in the DP. 3. Press the start key. Auto adjustment starts. 4. When automatic adjustment has normally completed, [OK] is displayed. If a problem occurs during auto adjustment, [NG XX] (XX is replaced by an error code) is displayed and operation stops. Should this happen, determine the details of the problem and repeat the procedure from the beginning. 5. To return to the screen for selecting an item, press the stop key. 	Display	Description	Original to be used for adjustment (P/N)	All	Performs automatic adjustment in the DP scanning section following automatic adjustment in the scanner section	302FZ56990/ 303LJ57010	Table	Automatic adjustment in the scanner section	302FZ56990	DP	Automatic adjustment in the DP scanning section:	303LJ57010
Display	Description	Original to be used for adjustment (P/N)											
All	Performs automatic adjustment in the DP scanning section following automatic adjustment in the scanner section	302FZ56990/ 303LJ57010											
Table	Automatic adjustment in the scanner section	302FZ56990											
DP	Automatic adjustment in the DP scanning section:	303LJ57010											

Item No.	Description																																																						
U411	Error Codes																																																						
	<table border="1"> <thead> <tr> <th data-bbox="336 277 491 322">Codes</th> <th data-bbox="491 277 1399 322">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 322 491 367">01</td> <td data-bbox="491 322 1399 367">Black band detection error (scanner leading edge registration)</td> </tr> <tr> <td data-bbox="336 367 491 412">02</td> <td data-bbox="491 367 1399 412">Black band detection error (scanner center line)</td> </tr> <tr> <td data-bbox="336 412 491 456">03</td> <td data-bbox="491 412 1399 456">Black band detection error (scanner main scanning direction magnification)</td> </tr> <tr> <td data-bbox="336 456 491 501">04</td> <td data-bbox="491 456 1399 501">Black band is not detected (scanner leading edge registration)</td> </tr> <tr> <td data-bbox="336 501 491 546">05</td> <td data-bbox="491 501 1399 546">Black band is not detected (scanner center line)</td> </tr> <tr> <td data-bbox="336 546 491 591">06</td> <td data-bbox="491 546 1399 591">Black band is not detected (scanner main scanning direction magnification)</td> </tr> <tr> <td data-bbox="336 591 491 636">07</td> <td data-bbox="491 591 1399 636">Black band is not detected (scanner auxiliary scanning direction magnification)</td> </tr> <tr> <td data-bbox="336 636 491 680">08</td> <td data-bbox="491 636 1399 680">Black band is not detected (DP main scanning direction magnification far end)</td> </tr> <tr> <td data-bbox="336 680 491 725">09</td> <td data-bbox="491 680 1399 725">Black band is not detected (DP main scanning direction magnification near end)</td> </tr> <tr> <td data-bbox="336 725 491 770">0a</td> <td data-bbox="491 725 1399 770">Black band is not detected (DP auxiliary scanning direction magnification leading edge)</td> </tr> <tr> <td data-bbox="336 770 491 815">0b</td> <td data-bbox="491 770 1399 815">Black band is not detected (DP auxiliary scanning direction magnification leading edge original check)</td> </tr> <tr> <td data-bbox="336 815 491 860">0c</td> <td data-bbox="491 815 1399 860">Black band is not detected (DP auxiliary scanning direction trailing edge)</td> </tr> <tr> <td data-bbox="336 860 491 904">0d</td> <td data-bbox="491 860 1399 904">Black band is not detected (DP auxiliary scanning direction trailing edge 2)</td> </tr> <tr> <td data-bbox="336 904 491 949">0e</td> <td data-bbox="491 904 1399 949">DMA time out</td> </tr> <tr> <td data-bbox="336 949 491 994">0f</td> <td data-bbox="491 949 1399 994">Auxiliary scanning direction magnification error</td> </tr> <tr> <td data-bbox="336 994 491 1039">10</td> <td data-bbox="491 994 1399 1039">Auxiliary scanning direction leading edge detection error</td> </tr> <tr> <td data-bbox="336 1039 491 1084">11</td> <td data-bbox="491 1039 1399 1084">Auxiliary scanning direction trailing edge detection error</td> </tr> <tr> <td data-bbox="336 1084 491 1128">12</td> <td data-bbox="491 1084 1399 1128">Auxiliary scanning direction skew 1.5 error</td> </tr> <tr> <td data-bbox="336 1128 491 1173">13</td> <td data-bbox="491 1128 1399 1173">Maintenance request error</td> </tr> <tr> <td data-bbox="336 1173 491 1218">14</td> <td data-bbox="491 1173 1399 1218">Main scanning direction center line error</td> </tr> <tr> <td data-bbox="336 1218 491 1263">15</td> <td data-bbox="491 1218 1399 1263">Main scanning direction skew 1.5 error</td> </tr> <tr> <td data-bbox="336 1263 491 1308">16</td> <td data-bbox="491 1263 1399 1308">Main scanning direction magnification error</td> </tr> <tr> <td data-bbox="336 1308 491 1352">17</td> <td data-bbox="491 1308 1399 1352">Service call error</td> </tr> <tr> <td data-bbox="336 1352 491 1397">18</td> <td data-bbox="491 1352 1399 1397">DP paper misfeed error</td> </tr> <tr> <td data-bbox="336 1397 491 1442">19</td> <td data-bbox="491 1397 1399 1442">PWB replacement error</td> </tr> <tr> <td data-bbox="336 1442 491 1487">1a</td> <td data-bbox="491 1442 1399 1487">Original error</td> </tr> </tbody> </table>	Codes	Description	01	Black band detection error (scanner leading edge registration)	02	Black band detection error (scanner center line)	03	Black band detection error (scanner main scanning direction magnification)	04	Black band is not detected (scanner leading edge registration)	05	Black band is not detected (scanner center line)	06	Black band is not detected (scanner main scanning direction magnification)	07	Black band is not detected (scanner auxiliary scanning direction magnification)	08	Black band is not detected (DP main scanning direction magnification far end)	09	Black band is not detected (DP main scanning direction magnification near end)	0a	Black band is not detected (DP auxiliary scanning direction magnification leading edge)	0b	Black band is not detected (DP auxiliary scanning direction magnification leading edge original check)	0c	Black band is not detected (DP auxiliary scanning direction trailing edge)	0d	Black band is not detected (DP auxiliary scanning direction trailing edge 2)	0e	DMA time out	0f	Auxiliary scanning direction magnification error	10	Auxiliary scanning direction leading edge detection error	11	Auxiliary scanning direction trailing edge detection error	12	Auxiliary scanning direction skew 1.5 error	13	Maintenance request error	14	Main scanning direction center line error	15	Main scanning direction skew 1.5 error	16	Main scanning direction magnification error	17	Service call error	18	DP paper misfeed error	19	PWB replacement error	1a	Original error
	Codes	Description																																																					
	01	Black band detection error (scanner leading edge registration)																																																					
	02	Black band detection error (scanner center line)																																																					
	03	Black band detection error (scanner main scanning direction magnification)																																																					
	04	Black band is not detected (scanner leading edge registration)																																																					
	05	Black band is not detected (scanner center line)																																																					
	06	Black band is not detected (scanner main scanning direction magnification)																																																					
	07	Black band is not detected (scanner auxiliary scanning direction magnification)																																																					
	08	Black band is not detected (DP main scanning direction magnification far end)																																																					
	09	Black band is not detected (DP main scanning direction magnification near end)																																																					
	0a	Black band is not detected (DP auxiliary scanning direction magnification leading edge)																																																					
	0b	Black band is not detected (DP auxiliary scanning direction magnification leading edge original check)																																																					
	0c	Black band is not detected (DP auxiliary scanning direction trailing edge)																																																					
	0d	Black band is not detected (DP auxiliary scanning direction trailing edge 2)																																																					
	0e	DMA time out																																																					
	0f	Auxiliary scanning direction magnification error																																																					
	10	Auxiliary scanning direction leading edge detection error																																																					
	11	Auxiliary scanning direction trailing edge detection error																																																					
	12	Auxiliary scanning direction skew 1.5 error																																																					
	13	Maintenance request error																																																					
	14	Main scanning direction center line error																																																					
	15	Main scanning direction skew 1.5 error																																																					
	16	Main scanning direction magnification error																																																					
	17	Service call error																																																					
	18	DP paper misfeed error																																																					
	19	PWB replacement error																																																					
1a	Original error																																																						
Completion	Press the stop key. The screen for selecting a maintenance item is displayed.																																																						

Item No.	Description																																		
U425	<p data-bbox="290 241 512 275">Setting the target</p> <p data-bbox="290 311 440 340">Description Enters the lab values that is indicated on the back of the chart (P/N: 302FZ56990) used for adjustment.</p> <p data-bbox="290 416 400 445">Purpose Performs data input in order to correct for differences in originals during automatic adjustment.</p> <p data-bbox="290 521 387 551">Method</p> <ol data-bbox="308 555 999 618" style="list-style-type: none"> 1. Press the start key. 2. Select the item to be set using the cursor up/down keys. <table border="1" data-bbox="336 631 1399 1160"> <thead> <tr> <th data-bbox="336 631 639 676">Display</th> <th data-bbox="639 631 1399 676">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 676 639 721">N875</td> <td data-bbox="639 676 1399 721">Setting the N875 patch for the original for adjustment</td> </tr> <tr> <td data-bbox="336 721 639 766">N475</td> <td data-bbox="639 721 1399 766">Setting the N475 patch for the original for adjustment</td> </tr> <tr> <td data-bbox="336 766 639 810">N125</td> <td data-bbox="639 766 1399 810">Setting the N125 patch for the original for adjustment</td> </tr> <tr> <td data-bbox="336 810 639 855">C</td> <td data-bbox="639 810 1399 855">Setting the cyan patch for the original for adjustment</td> </tr> <tr> <td data-bbox="336 855 639 900">M</td> <td data-bbox="639 855 1399 900">Setting the magenta patch for the original for adjustment</td> </tr> <tr> <td data-bbox="336 900 639 945">Y</td> <td data-bbox="639 900 1399 945">Setting the yellow patch for the original for adjustment</td> </tr> <tr> <td data-bbox="336 945 639 990">R</td> <td data-bbox="639 945 1399 990">Setting the red patch for the original for adjustment</td> </tr> <tr> <td data-bbox="336 990 639 1034">G</td> <td data-bbox="639 990 1399 1034">Setting the green patch for the original for adjustment</td> </tr> <tr> <td data-bbox="336 1034 639 1079">B</td> <td data-bbox="639 1034 1399 1079">Setting the blue patch for the original for adjustment</td> </tr> <tr> <td data-bbox="336 1079 639 1160">Adjust Original</td> <td data-bbox="639 1079 1399 1160">Setting the main and auxiliary scanning directions</td> </tr> </tbody> </table> <ol data-bbox="308 1169 999 1198" style="list-style-type: none"> 3. Select the item to be set using the cursor up/down keys. <table border="1" data-bbox="336 1211 1399 1406"> <thead> <tr> <th data-bbox="336 1211 639 1256">Display</th> <th data-bbox="639 1211 1018 1256">Description</th> <th data-bbox="1018 1211 1399 1256">Setting range</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1256 639 1301">L</td> <td data-bbox="639 1256 1018 1301">Setting the L value</td> <td data-bbox="1018 1256 1399 1301">0.0 to 100.0</td> </tr> <tr> <td data-bbox="336 1301 639 1346">a</td> <td data-bbox="639 1301 1018 1346">Setting the a value</td> <td data-bbox="1018 1301 1399 1346">-200.0 to 200.0</td> </tr> <tr> <td data-bbox="336 1346 639 1406">b</td> <td data-bbox="639 1346 1018 1406">Setting the b value</td> <td data-bbox="1018 1346 1399 1406">-200.0 to 200.0</td> </tr> </tbody> </table> <ol data-bbox="308 1415 1406 1514" style="list-style-type: none"> 4. Enters the value that is indicated on the back of the chart using the cursor left/right keys or numeric keys. 5. Press the start key. The value is set. 	Display	Description	N875	Setting the N875 patch for the original for adjustment	N475	Setting the N475 patch for the original for adjustment	N125	Setting the N125 patch for the original for adjustment	C	Setting the cyan patch for the original for adjustment	M	Setting the magenta patch for the original for adjustment	Y	Setting the yellow patch for the original for adjustment	R	Setting the red patch for the original for adjustment	G	Setting the green patch for the original for adjustment	B	Setting the blue patch for the original for adjustment	Adjust Original	Setting the main and auxiliary scanning directions	Display	Description	Setting range	L	Setting the L value	0.0 to 100.0	a	Setting the a value	-200.0 to 200.0	b	Setting the b value	-200.0 to 200.0
Display	Description																																		
N875	Setting the N875 patch for the original for adjustment																																		
N475	Setting the N475 patch for the original for adjustment																																		
N125	Setting the N125 patch for the original for adjustment																																		
C	Setting the cyan patch for the original for adjustment																																		
M	Setting the magenta patch for the original for adjustment																																		
Y	Setting the yellow patch for the original for adjustment																																		
R	Setting the red patch for the original for adjustment																																		
G	Setting the green patch for the original for adjustment																																		
B	Setting the blue patch for the original for adjustment																																		
Adjust Original	Setting the main and auxiliary scanning directions																																		
Display	Description	Setting range																																	
L	Setting the L value	0.0 to 100.0																																	
a	Setting the a value	-200.0 to 200.0																																	
b	Setting the b value	-200.0 to 200.0																																	

Item No.	Description
U425	<p>Setting: [Adjust Original]</p> <ol style="list-style-type: none"> 1. Measure the distance from the left edge to the black belt (a) of the original at A, B and C. Measurement procedure <ol style="list-style-type: none"> 1) Measure the distance from the edge to the black belt (a) of the original at A (30 mm from the leading edge), B (148.5 mm from the leading edge) and C (267 mm from the leading edge), respectively. 2) Apply the following formula for the values obtained: $((A + C) / 2 + B) / 2$ 2. Enter the values solved using the cursor left/right keys or numeric keys in [Main]. 3. Press the start key. The value is set. 4. Measure the distance from the leading edge to the black belt (b) of the original at D, E and F. Measurement procedure <ol style="list-style-type: none"> 1) Measure the distance from the edge to the black belt (b) of the original at D (35 mm from the left edge), E (110 mm from the left edge) and F (185 mm from the left edge), respectively. 2) Apply the following formula for the values obtained: $((D + F) / 2 + E) / 2$ 5. Enter the values solved using the cursor left/right keys or numeric keys in [Sub Lead]. 6. Press the start key. The value is set. 7. Measure the length (G) from the edge of the black belt (b) to edge of the black belt (c) of the original. 8. Enter the measured value using the cursor left/right keys or numeric keys in [Sub Tail]. 9. Press the start key. The value is set. <div data-bbox="287 1030 1197 1657" style="text-align: center;"> <p>Original for adjustment (P/N: 302FZ56990)</p> </div> <div data-bbox="1212 1355 1436 1612" style="border: 1px solid black; padding: 5px; margin-top: 10px;"> <p>[Main] = $((A + C) / 2 + B) / 2$</p> <p>[Sub Lead] = $((D + F) / 2 + E) / 2$</p> <p>[Sub Tail] = G</p> </div>

Figure 1-3-2

Completion

Press the stop key. The screen for selecting a maintenance item No. is displayed.

Item No.	Description																																																																												
U600	<p>Initializing all data</p> <p>Description Initializes software switches and all data in the backup data on the FAX control PWB, according to the destination and OEM. Executes the check of the file system, when abnormality of the file system is detected, initializes the file system, communication past record and register setting contents.</p> <p>Purpose To initialize the FAX control PWB.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select [Execute]. The screen for entering the destination code and OEM code is displayed. 3. Select [Country Code] and enter a destination code using the numeric keys (refer to the destination code list on following for the destination code). 4. Press the start key. There is no operation necessary on this screen. The destination code and the OEM code are displayed with the values currently set. 5. Press the start key. Data initialization starts. To cancel data initialization, press the stop key. 6. After data initialization, the entered destination, OEM codes and ROM version are displayed. A ROM version displays three kinds, application, boot, and IPL. <p>Destination code list</p> <table border="1" data-bbox="336 1048 1401 1957"> <thead> <tr> <th>Code</th> <th>Destination</th> <th>Code</th> <th>Destination</th> </tr> </thead> <tbody> <tr> <td>000</td> <td>Japan</td> <td>253</td> <td>CTR21 (European nations)</td> </tr> <tr> <td>009</td> <td>Australia</td> <td></td> <td>Italy</td> </tr> <tr> <td>038</td> <td>China</td> <td></td> <td>Germany</td> </tr> <tr> <td>080</td> <td>Hong Kong</td> <td></td> <td>Spain</td> </tr> <tr> <td>084</td> <td>Indonesia</td> <td></td> <td>U.K.</td> </tr> <tr> <td>088</td> <td>Israel</td> <td></td> <td>Netherlands</td> </tr> <tr> <td>097</td> <td>Korea</td> <td></td> <td>Sweden</td> </tr> <tr> <td>108</td> <td>Malaysia</td> <td></td> <td>France</td> </tr> <tr> <td>126</td> <td>New Zealand</td> <td></td> <td>Austria</td> </tr> <tr> <td>136</td> <td>Peru</td> <td></td> <td>Switzerland</td> </tr> <tr> <td>137</td> <td>Philippines</td> <td></td> <td>Belgium</td> </tr> <tr> <td>152</td> <td>Middle East</td> <td></td> <td>Denmark</td> </tr> <tr> <td>156</td> <td>Singapore</td> <td></td> <td>Finland</td> </tr> <tr> <td>159</td> <td>South Africa</td> <td></td> <td>Portugal</td> </tr> <tr> <td>169</td> <td>Thailand</td> <td></td> <td>Ireland</td> </tr> <tr> <td>181</td> <td>U.S.A.</td> <td></td> <td>Norway</td> </tr> <tr> <td>242</td> <td>South America</td> <td>254</td> <td>Taiwan</td> </tr> <tr> <td>243</td> <td>Saudi Arabia</td> <td></td> <td></td> </tr> </tbody> </table>	Code	Destination	Code	Destination	000	Japan	253	CTR21 (European nations)	009	Australia		Italy	038	China		Germany	080	Hong Kong		Spain	084	Indonesia		U.K.	088	Israel		Netherlands	097	Korea		Sweden	108	Malaysia		France	126	New Zealand		Austria	136	Peru		Switzerland	137	Philippines		Belgium	152	Middle East		Denmark	156	Singapore		Finland	159	South Africa		Portugal	169	Thailand		Ireland	181	U.S.A.		Norway	242	South America	254	Taiwan	243	Saudi Arabia		
Code	Destination	Code	Destination																																																																										
000	Japan	253	CTR21 (European nations)																																																																										
009	Australia		Italy																																																																										
038	China		Germany																																																																										
080	Hong Kong		Spain																																																																										
084	Indonesia		U.K.																																																																										
088	Israel		Netherlands																																																																										
097	Korea		Sweden																																																																										
108	Malaysia		France																																																																										
126	New Zealand		Austria																																																																										
136	Peru		Switzerland																																																																										
137	Philippines		Belgium																																																																										
152	Middle East		Denmark																																																																										
156	Singapore		Finland																																																																										
159	South Africa		Portugal																																																																										
169	Thailand		Ireland																																																																										
181	U.S.A.		Norway																																																																										
242	South America	254	Taiwan																																																																										
243	Saudi Arabia																																																																												

Item No.	Description								
U601	<p>Initializing permanent data</p> <p>Description Initializes software switches on the FAX control PWB according to the destination and OEM.</p> <p>Purpose To initialize the FAX control PWB without changing user registration data.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select [Execute]. The screen for entering the destination code and OEM code is displayed. 3. Select [Country Code] and enter a destination code using the numeric keys (refer to the destination code list on page 1-3-23 for the destination code). 4. Press the start key. There is no operation necessary on this screen. The destination code and the OEM code are displayed with the values currently set. 5. Press the start key. Data initialization starts. To cancel data initialization, press the back key. 6. After data initialization, the entered destination, OEM codes and ROM version are displayed. A ROM version displays three kinds, application, boot, and IPL. 								
U603	<p>Setting user data 1</p> <p>Description Makes user settings to enable the use of the machine as a fax.</p> <p>Purpose To be executed as required.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select [Line Type] and press the start key. 3. Select the setting using the cursor up/down keys. <table border="1" data-bbox="336 1301 1401 1496"> <thead> <tr> <th data-bbox="336 1301 639 1350">Display</th> <th data-bbox="639 1301 1401 1350">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1350 639 1400">DTMF</td> <td data-bbox="639 1350 1401 1400">DTMF</td> </tr> <tr> <td data-bbox="336 1400 639 1449">10PPS</td> <td data-bbox="639 1400 1401 1449">10 PPS</td> </tr> <tr> <td data-bbox="336 1449 639 1496">20PPS</td> <td data-bbox="639 1449 1401 1496">20 PPS</td> </tr> </tbody> </table> <p>* : Initial setting: DTMF</p> <ol style="list-style-type: none"> 4. Press the start key. The setting is set. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	DTMF	DTMF	10PPS	10 PPS	20PPS	20 PPS
Display	Description								
DTMF	DTMF								
10PPS	10 PPS								
20PPS	20 PPS								

Item No.	Description						
U604	<p>Setting user data 2</p> <p>Description Makes user settings to enable the use of the machine as a fax.</p> <p>Purpose Use this if the user wishes to adjust the number of rings that occur before the unit switches into fax receiving mode when fax/telephone auto-select is enabled.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Change the setting using the cursor left/right keys or numeric keys. <table border="1" data-bbox="338 633 1401 728"> <thead> <tr> <th data-bbox="338 633 866 678">Description</th> <th data-bbox="866 633 1098 678">Setting range</th> <th data-bbox="1098 633 1401 678">Initial setting</th> </tr> </thead> <tbody> <tr> <td data-bbox="338 678 866 728">Number of fax/telephone rings</td> <td data-bbox="866 678 1098 728">0 to 15</td> <td data-bbox="1098 678 1401 728">2 (120 V)/1 (220-240 V)</td> </tr> </tbody> </table> <p>* : If you set this to 0, the unit will start fax reception without any ringing.</p> <ol style="list-style-type: none"> 3. Press the start key. The value is set. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Description	Setting range	Initial setting	Number of fax/telephone rings	0 to 15	2 (120 V)/1 (220-240 V)
Description	Setting range	Initial setting					
Number of fax/telephone rings	0 to 15	2 (120 V)/1 (220-240 V)					
U605	<p>Clearing data</p> <p>Description Initializes data related to the fax transmission such as transmission history.</p> <p>Purpose To clear the transmission history.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select [Comm REC]. 3. Press the start key. Initialization processing starts. When processing is finished, [Completed] is displayed. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>						

Item No.	Description																								
U610	<p data-bbox="290 241 502 273">Setting system 1</p> <p data-bbox="290 311 438 342">Description</p> <p data-bbox="290 344 1404 412">Makes settings for fax reception regarding the sizes of the fax paper and received images and automatic printing of the protocol list.</p> <p data-bbox="290 450 386 481">Method</p> <ol data-bbox="308 486 997 548" style="list-style-type: none"> 1. Press the start key. 2. Select the item to be set using the cursor up/down keys. <table border="1" data-bbox="336 562 1401 857"> <thead> <tr> <th data-bbox="336 562 639 607">Display</th> <th data-bbox="639 562 1401 607">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 607 639 689">Cut Line:100%</td> <td data-bbox="639 607 1401 689">Sets the number of lines to be ignored when receiving a fax at 100% magnification.</td> </tr> <tr> <td data-bbox="336 689 639 772">Cut Line:Auto</td> <td data-bbox="639 689 1401 772">Sets the number of lines to be ignored when receiving a fax in the auto reduction mode.</td> </tr> <tr> <td data-bbox="336 772 639 857">Cut Line:A4</td> <td data-bbox="639 772 1401 857">Sets the number of lines to be ignored when receiving a fax (A4R/LetterR) in the auto reduction mode.</td> </tr> </tbody> </table> <p data-bbox="290 904 1372 936">Setting the number of lines to be ignored when receiving a fax at 100% magnification</p> <p data-bbox="290 938 1431 1039">Sets the maximum number of lines to be ignored if the received data volume exceeds the recording capacity when recording the data at 100% magnification. If the number of excess lines is below the setting, those lines are ignored. If over the setting, they are recorded on the next page.</p> <ol data-bbox="308 1041 1125 1072" style="list-style-type: none"> 1. Change the setting using the cursor left/right keys or numeric keys. <table border="1" data-bbox="336 1086 1401 1249"> <thead> <tr> <th data-bbox="336 1086 823 1169">Description</th> <th data-bbox="823 1086 1003 1169">Setting range</th> <th data-bbox="1003 1086 1187 1169">Initial setting</th> <th data-bbox="1187 1086 1401 1169">Change in value per step</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1169 823 1249">Number of lines to be ignored when receiving at 100%</td> <td data-bbox="823 1169 1003 1249">0 to 22</td> <td data-bbox="1003 1169 1187 1249">3</td> <td data-bbox="1187 1169 1401 1249">16 lines</td> </tr> </tbody> </table> <p data-bbox="336 1258 1362 1326">* : Increase the setting if a blank second page is output, and decrease it if the received image does not include the entire transmitted data.</p> <ol data-bbox="308 1328 766 1359" style="list-style-type: none"> 2. Press the start key. The value is set. <p data-bbox="290 1397 1431 1429">Setting the number of lines to be ignored when receiving a fax in the auto reduction mode</p> <p data-bbox="290 1431 1431 1565">Sets the maximum number of lines to be ignored if the received data volume exceeds the recording capacity when the data is recorded in the auto reduction mode. If the number of excess lines is below the setting, those lines are ignored. If over the setting, the entire data on a page is further reduced so that it can be recorded on the same page.</p> <ol data-bbox="308 1568 1125 1599" style="list-style-type: none"> 1. Change the setting using the cursor left/right keys or numeric keys. <table border="1" data-bbox="336 1612 1401 1776"> <thead> <tr> <th data-bbox="336 1612 823 1695">Description</th> <th data-bbox="823 1612 1003 1695">Setting range</th> <th data-bbox="1003 1612 1187 1695">Initial setting</th> <th data-bbox="1187 1612 1401 1695">Change in value per step</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1695 823 1776">Number of lines to be ignored when receiving in the auto reduction mode</td> <td data-bbox="823 1695 1003 1776">0 to 22</td> <td data-bbox="1003 1695 1187 1776">0</td> <td data-bbox="1187 1695 1401 1776">16 lines</td> </tr> </tbody> </table> <p data-bbox="336 1785 1394 1886">* : Increase the setting if a page received in the reduction mode is over-reduced and too much trailing edge margin is left. Decrease it if the received image does not include all transmitted data.</p> <ol data-bbox="308 1888 766 1919" style="list-style-type: none"> 2. Press the start key. The value is set. 	Display	Description	Cut Line:100%	Sets the number of lines to be ignored when receiving a fax at 100% magnification.	Cut Line:Auto	Sets the number of lines to be ignored when receiving a fax in the auto reduction mode.	Cut Line:A4	Sets the number of lines to be ignored when receiving a fax (A4R/LetterR) in the auto reduction mode.	Description	Setting range	Initial setting	Change in value per step	Number of lines to be ignored when receiving at 100%	0 to 22	3	16 lines	Description	Setting range	Initial setting	Change in value per step	Number of lines to be ignored when receiving in the auto reduction mode	0 to 22	0	16 lines
Display	Description																								
Cut Line:100%	Sets the number of lines to be ignored when receiving a fax at 100% magnification.																								
Cut Line:Auto	Sets the number of lines to be ignored when receiving a fax in the auto reduction mode.																								
Cut Line:A4	Sets the number of lines to be ignored when receiving a fax (A4R/LetterR) in the auto reduction mode.																								
Description	Setting range	Initial setting	Change in value per step																						
Number of lines to be ignored when receiving at 100%	0 to 22	3	16 lines																						
Description	Setting range	Initial setting	Change in value per step																						
Number of lines to be ignored when receiving in the auto reduction mode	0 to 22	0	16 lines																						

Item No.	Description								
U610	<p data-bbox="288 241 1409 304">Setting the number of lines to be ignored when receiving a fax (A4R/LetterR) in the auto reduction mode</p> <p data-bbox="288 311 1433 409">Sets the maximum number of lines to be ignored if the received data volume exceeds the recording capacity when the data is recorded in the auto reduction mode onto A4R or LetterR paper under the conditions below.</p> <p data-bbox="288 416 1425 479">If the number of excess lines is below the setting, those lines are ignored. If over the setting, the entire data on a page is further reduced so that it can be recorded on the same page.</p> <p data-bbox="308 486 1126 517">1. Change the setting using the cursor left/right keys or numeric keys.</p> <table border="1" data-bbox="336 526 1401 728"> <thead> <tr> <th data-bbox="336 526 823 607">Description</th> <th data-bbox="823 526 1003 607">Setting range</th> <th data-bbox="1003 526 1187 607">Initial setting</th> <th data-bbox="1187 526 1401 607">Change in value per step</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 607 823 728">Number of lines to be ignored when receiving a fax (A4R, letter) in the auto reduction mode</td> <td data-bbox="823 607 1003 728">0 to 22</td> <td data-bbox="1003 607 1187 728">0</td> <td data-bbox="1187 607 1401 728">16 lines</td> </tr> </tbody> </table> <p data-bbox="336 739 1393 837">* : Increase the setting if a page received in the reduction mode is over-reduced and too much trailing edge margin is left. Decrease it if the received image does not include all transmitted data.</p> <p data-bbox="308 844 767 875">2. Press the start key. The value is set.</p> <p data-bbox="288 913 440 945">Completion</p> <p data-bbox="288 952 1254 983">Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Description	Setting range	Initial setting	Change in value per step	Number of lines to be ignored when receiving a fax (A4R, letter) in the auto reduction mode	0 to 22	0	16 lines
Description	Setting range	Initial setting	Change in value per step						
Number of lines to be ignored when receiving a fax (A4R, letter) in the auto reduction mode	0 to 22	0	16 lines						

Item No.	Description																										
U611	<p data-bbox="290 241 507 275">Setting system 2</p> <p data-bbox="290 311 440 340">Description</p> <p data-bbox="290 344 1005 374">Sets the number of adjustment lines for automatic reduction.</p> <p data-bbox="290 414 387 443">Method</p> <ol data-bbox="308 450 999 515" style="list-style-type: none"> 1. Press the start key. 2. Select the item to be set using the cursor up/down keys. <table border="1" data-bbox="336 526 1401 790"> <thead> <tr> <th data-bbox="336 526 639 571">Display</th> <th data-bbox="639 526 1401 571">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 571 639 616">Adj Lines</td> <td data-bbox="639 571 1401 616">Sets the number of adjustment lines for automatic reduction.</td> </tr> <tr> <td data-bbox="336 616 639 705">Adj Lines(A4)</td> <td data-bbox="639 616 1401 705">Sets the number of adjustment lines for automatic reduction when A4 paper is set.</td> </tr> <tr> <td data-bbox="336 705 639 790">Adj Lines(LT)</td> <td data-bbox="639 705 1401 790">Sets the number of adjustment lines for automatic reduction when letter size paper is set.</td> </tr> </tbody> </table> <p data-bbox="290 831 1094 860">Setting the number of adjustment lines for automatic reduction</p> <p data-bbox="290 864 1005 893">Sets the number of adjustment lines for automatic reduction.</p> <ol data-bbox="308 900 1126 929" style="list-style-type: none"> 1. Change the setting using the cursor left/right keys or numeric keys. <table border="1" data-bbox="336 943 1401 1039"> <thead> <tr> <th data-bbox="336 943 975 987">Description</th> <th data-bbox="975 943 1187 987">Setting range</th> <th data-bbox="1187 943 1401 987">Initial setting</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 987 975 1039">Number of adjustment lines for automatic reduction</td> <td data-bbox="975 987 1187 1039">0 to 22</td> <td data-bbox="1187 987 1401 1039">7</td> </tr> </tbody> </table> <ol data-bbox="308 1050 766 1079" style="list-style-type: none"> 2. Press the start key. The value is set. <p data-bbox="290 1120 1366 1149">Setting the number of adjustment lines for automatic reduction when A4 paper is set</p> <p data-bbox="290 1153 1260 1182">Sets the number of adjustment lines for automatic reduction when A4 paper is set.</p> <ol data-bbox="308 1189 1126 1218" style="list-style-type: none"> 1. Change the setting using the cursor left/right keys or numeric keys. <table border="1" data-bbox="336 1232 1401 1364"> <thead> <tr> <th data-bbox="336 1232 975 1276">Description</th> <th data-bbox="975 1232 1187 1276">Setting range</th> <th data-bbox="1187 1232 1401 1276">Initial setting</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1276 975 1364">Number of adjustment lines for automatic reduction when A4 paper is set</td> <td data-bbox="975 1276 1187 1364">0 to 22</td> <td data-bbox="1187 1276 1401 1364">22</td> </tr> </tbody> </table> <ol data-bbox="308 1375 766 1404" style="list-style-type: none"> 2. Press the start key. The value is set. <p data-bbox="290 1444 1409 1505">Setting the number of adjustment lines for automatic reduction when letter size paper is set</p> <p data-bbox="290 1509 1342 1538">Sets the number of adjustment lines for automatic reduction when letter size paper is set.</p> <ol data-bbox="308 1545 1126 1574" style="list-style-type: none"> 1. Change the setting using the cursor left/right keys or numeric keys. <table border="1" data-bbox="336 1588 1401 1720"> <thead> <tr> <th data-bbox="336 1588 975 1632">Description</th> <th data-bbox="975 1588 1187 1632">Setting range</th> <th data-bbox="1187 1588 1401 1632">Initial setting</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1632 975 1720">Number of adjustment lines for automatic reduction when letter size paper is set</td> <td data-bbox="975 1632 1187 1720">0 to 26</td> <td data-bbox="1187 1632 1401 1720">26</td> </tr> </tbody> </table> <ol data-bbox="308 1731 766 1760" style="list-style-type: none"> 2. Press the start key. The value is set. <p data-bbox="290 1800 440 1830">Completion</p> <p data-bbox="290 1834 1254 1863">Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Adj Lines	Sets the number of adjustment lines for automatic reduction.	Adj Lines(A4)	Sets the number of adjustment lines for automatic reduction when A4 paper is set.	Adj Lines(LT)	Sets the number of adjustment lines for automatic reduction when letter size paper is set.	Description	Setting range	Initial setting	Number of adjustment lines for automatic reduction	0 to 22	7	Description	Setting range	Initial setting	Number of adjustment lines for automatic reduction when A4 paper is set	0 to 22	22	Description	Setting range	Initial setting	Number of adjustment lines for automatic reduction when letter size paper is set	0 to 26	26
Display	Description																										
Adj Lines	Sets the number of adjustment lines for automatic reduction.																										
Adj Lines(A4)	Sets the number of adjustment lines for automatic reduction when A4 paper is set.																										
Adj Lines(LT)	Sets the number of adjustment lines for automatic reduction when letter size paper is set.																										
Description	Setting range	Initial setting																									
Number of adjustment lines for automatic reduction	0 to 22	7																									
Description	Setting range	Initial setting																									
Number of adjustment lines for automatic reduction when A4 paper is set	0 to 22	22																									
Description	Setting range	Initial setting																									
Number of adjustment lines for automatic reduction when letter size paper is set	0 to 26	26																									

Item No.	Description																						
U612	<p data-bbox="290 241 507 273">Setting system 3</p> <p data-bbox="290 309 440 340">Description</p> <p data-bbox="290 344 1428 443">Makes settings for fax transmission regarding operation and automatic printing of the protocol list. This determines how trailing edge margin is detected (to prevent image from being mutilated) while printing a received Fax.</p> <p data-bbox="290 483 386 515">Method</p> <ol data-bbox="306 519 999 582" style="list-style-type: none"> 1. Press the start key. 2. Select the item to be set using the cursor up/down keys. <table border="1" data-bbox="338 595 1401 824"> <thead> <tr> <th data-bbox="338 595 641 640">Display</th> <th data-bbox="641 595 1401 640">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="338 640 641 730">Auto Reduction</td> <td data-bbox="641 640 1401 730">Selects if auto reduction in the auxiliary direction is to be performed.</td> </tr> <tr> <td data-bbox="338 730 641 775">Protocol List</td> <td data-bbox="641 730 1401 775">Sets the automatic printing of the protocol list.</td> </tr> <tr> <td data-bbox="338 775 641 824">Detect Trail</td> <td data-bbox="641 775 1401 824">Sets how trailing edge margins are detected</td> </tr> </tbody> </table> <p data-bbox="290 869 1184 900">Selecting if auto reduction in the auxiliary direction is to be performed</p> <p data-bbox="290 904 1428 967">Sets whether to receive a long document by automatically reducing it in the auxiliary direction or at 100% magnification.</p> <ol data-bbox="306 972 912 1003" style="list-style-type: none"> 1. Select the setting using the cursor left/right keys. <table border="1" data-bbox="338 1016 1401 1196"> <thead> <tr> <th data-bbox="338 1016 641 1061">Display</th> <th data-bbox="641 1016 1401 1061">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="338 1061 641 1151">On</td> <td data-bbox="641 1061 1401 1151">Auto reduction is performed if the received document is longer than the fax paper.</td> </tr> <tr> <td data-bbox="338 1151 641 1196">Off</td> <td data-bbox="641 1151 1401 1196">Auto reduction is not performed.</td> </tr> </tbody> </table> <p data-bbox="338 1205 577 1236">* : Initial setting: On</p> <ol data-bbox="306 1240 785 1272" style="list-style-type: none"> 2. Press the start key. The setting is set. <p data-bbox="290 1308 912 1339">Setting the automatic printing of the protocol list</p> <p data-bbox="290 1344 887 1375">Sets if the protocol list is automatically printed out.</p> <ol data-bbox="306 1379 912 1411" style="list-style-type: none"> 1. Select the setting using the cursor left/right keys. <table border="1" data-bbox="338 1424 1401 1684"> <thead> <tr> <th data-bbox="338 1424 641 1469">Display</th> <th data-bbox="641 1424 1401 1469">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="338 1469 641 1559">On</td> <td data-bbox="641 1469 1401 1559">The protocol list is automatically printed out after communication.</td> </tr> <tr> <td data-bbox="338 1559 641 1648">Err</td> <td data-bbox="641 1559 1401 1648">The protocol list is automatically printed out after communication only if a communication error occurs.</td> </tr> <tr> <td data-bbox="338 1648 641 1684">Off</td> <td data-bbox="641 1648 1401 1684">The protocol list is not printed out automatically.</td> </tr> </tbody> </table> <p data-bbox="338 1693 577 1724">* : Initial setting: Off</p> <ol data-bbox="306 1729 785 1760" style="list-style-type: none"> 2. Press the start key. The setting is set. 	Display	Description	Auto Reduction	Selects if auto reduction in the auxiliary direction is to be performed.	Protocol List	Sets the automatic printing of the protocol list.	Detect Trail	Sets how trailing edge margins are detected	Display	Description	On	Auto reduction is performed if the received document is longer than the fax paper.	Off	Auto reduction is not performed.	Display	Description	On	The protocol list is automatically printed out after communication.	Err	The protocol list is automatically printed out after communication only if a communication error occurs.	Off	The protocol list is not printed out automatically.
Display	Description																						
Auto Reduction	Selects if auto reduction in the auxiliary direction is to be performed.																						
Protocol List	Sets the automatic printing of the protocol list.																						
Detect Trail	Sets how trailing edge margins are detected																						
Display	Description																						
On	Auto reduction is performed if the received document is longer than the fax paper.																						
Off	Auto reduction is not performed.																						
Display	Description																						
On	The protocol list is automatically printed out after communication.																						
Err	The protocol list is automatically printed out after communication only if a communication error occurs.																						
Off	The protocol list is not printed out automatically.																						

Item No.	Description						
U612	<p>Setting how trailing edge margins are detected</p> <p>This determines whether trailing edge margin is detected (to prevent image from being mutilated) while printing a received Fax.</p> <ol style="list-style-type: none"> 1. Select On or Off using the cursor left/right keys. <table border="1" data-bbox="336 389 1401 533"> <thead> <tr> <th data-bbox="336 389 639 434">Display</th> <th data-bbox="639 389 1401 434">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 434 639 479">On</td> <td data-bbox="639 434 1401 479">Detects trailing edge margin</td> </tr> <tr> <td data-bbox="336 479 639 524">Off</td> <td data-bbox="639 479 1401 524">Does not detect trailing edge margin</td> </tr> </tbody> </table> <p>* : Initial setting: On</p> <ol style="list-style-type: none"> 2. Press the start key. The setting is set. <p>Completion</p> <p>Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	On	Detects trailing edge margin	Off	Does not detect trailing edge margin
Display	Description						
On	Detects trailing edge margin						
Off	Does not detect trailing edge margin						
U620	<p>Setting the remote switching mode</p> <p>Description</p> <p>Sets the signal detection method for remote switching. Be sure to change the setting according to the type of telephone connected to the machine.</p> <p>Setting</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select [Remort Mode] and press the start key. 3. Select the mode using the cursor up/down keys. <table border="1" data-bbox="336 1084 1401 1227"> <thead> <tr> <th data-bbox="336 1084 639 1128">Display</th> <th data-bbox="639 1084 1401 1128">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1128 639 1173">One</td> <td data-bbox="639 1128 1401 1173">One-shot detection</td> </tr> <tr> <td data-bbox="336 1173 639 1218">Cont</td> <td data-bbox="639 1173 1401 1218">Continuous detection</td> </tr> </tbody> </table> <p>* : Initial setting: One</p> <ol style="list-style-type: none"> 4. Press the start key. The setting is set. <p>Completion</p> <p>Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	One	One-shot detection	Cont	Continuous detection
Display	Description						
One	One-shot detection						
Cont	Continuous detection						

Item No.	Description																		
U625	<p data-bbox="290 241 724 273">Setting the transmission system 1</p> <p data-bbox="290 309 440 340">Description Makes settings for the auto redialing interval and the number of times of auto redialing.</p> <p data-bbox="290 376 400 407">Purpose Change the setting to prevent the following problems: fax transmission is not possible due to too short redial interval, or fax transmission takes too much time to complete due to too long redial interval.</p> <p data-bbox="290 555 387 586">Method</p> <ol data-bbox="308 591 999 654" style="list-style-type: none"> 1. Press the start key. 2. Select the item to be set using the cursor up/down keys. <table border="1" data-bbox="336 667 1401 810"> <thead> <tr> <th data-bbox="336 667 639 712">Display</th> <th data-bbox="639 667 1401 712">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 712 639 757">Interval</td> <td data-bbox="639 712 1401 757">Setting the auto redialing interval</td> </tr> <tr> <td data-bbox="336 757 639 810">Times</td> <td data-bbox="639 757 1401 810">Setting the number of times of auto redialing</td> </tr> </tbody> </table> <p data-bbox="290 855 715 887">Setting the auto redialing interval</p> <ol data-bbox="308 891 932 922" style="list-style-type: none"> 1. Change the setting using the cursor left/right keys. <table border="1" data-bbox="336 931 1401 1025"> <thead> <tr> <th data-bbox="336 931 868 976">Description</th> <th data-bbox="868 931 1098 976">Setting range</th> <th data-bbox="1098 931 1401 976">Initial setting</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 976 868 1025">Redialing interval</td> <td data-bbox="868 976 1098 1025">1 to 9 (min.)</td> <td data-bbox="1098 976 1401 1025">3 (120 V)/2 (220-240 V)</td> </tr> </tbody> </table> <ol data-bbox="308 1034 766 1066" style="list-style-type: none"> 2. Press the start key. The value is set. <p data-bbox="290 1111 858 1142">Setting the number of times of auto redialing</p> <ol data-bbox="308 1146 1126 1178" style="list-style-type: none"> 1. Change the setting using the cursor left/right keys or numeric keys. <table border="1" data-bbox="336 1187 1401 1281"> <thead> <tr> <th data-bbox="336 1187 868 1232">Description</th> <th data-bbox="868 1187 1098 1232">Setting range</th> <th data-bbox="1098 1187 1401 1232">Initial setting</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1232 868 1281">Number of redialing</td> <td data-bbox="868 1232 1098 1281">0 to 15</td> <td data-bbox="1098 1232 1401 1281">2 (120 V)/3 (220-240 V)</td> </tr> </tbody> </table> <ol data-bbox="308 1290 766 1321" style="list-style-type: none"> 2. Press the start key. The value is set. <p data-bbox="290 1357 440 1388">Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Interval	Setting the auto redialing interval	Times	Setting the number of times of auto redialing	Description	Setting range	Initial setting	Redialing interval	1 to 9 (min.)	3 (120 V)/2 (220-240 V)	Description	Setting range	Initial setting	Number of redialing	0 to 15	2 (120 V)/3 (220-240 V)
Display	Description																		
Interval	Setting the auto redialing interval																		
Times	Setting the number of times of auto redialing																		
Description	Setting range	Initial setting																	
Redialing interval	1 to 9 (min.)	3 (120 V)/2 (220-240 V)																	
Description	Setting range	Initial setting																	
Number of redialing	0 to 15	2 (120 V)/3 (220-240 V)																	

Item No.	Description																														
U630	<p data-bbox="288 241 707 271">Setting communication control 1</p> <p data-bbox="288 311 440 340">Description</p> <p data-bbox="288 344 1069 374">Makes settings for fax transmission regarding the communication.</p> <p data-bbox="288 414 387 443">Method</p> <ol data-bbox="308 448 999 515" style="list-style-type: none"> 1. Press the start key. 2. Select the item to be set using the cursor up/down keys. <table border="1" data-bbox="336 526 1401 837"> <thead> <tr> <th data-bbox="336 526 639 571">Display</th> <th data-bbox="639 526 1401 571">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 571 639 616">TX Speed</td> <td data-bbox="639 571 1401 616">Sets the communication starting speed.</td> </tr> <tr> <td data-bbox="336 616 639 660">RX Speed</td> <td data-bbox="639 616 1401 660">Sets the reception speed.</td> </tr> <tr> <td data-bbox="336 660 639 750">TX Echo</td> <td data-bbox="639 660 1401 750">Sets the waiting period to prevent echo problems at the sender.</td> </tr> <tr> <td data-bbox="336 750 639 837">RX Echo</td> <td data-bbox="639 750 1401 837">Sets the waiting period to prevent echo problems at the receiver.</td> </tr> </tbody> </table> <p data-bbox="288 882 826 911">Setting the communication starting speed</p> <p data-bbox="288 916 1418 983">Sets the initial communication speed when starting transmission. When the destination unit has V.34 capability, V.34 is selected for transmission, regardless of this setting.</p> <ol data-bbox="308 987 919 1016" style="list-style-type: none"> 1. Select the setting using the cursor up/down keys. <table border="1" data-bbox="336 1028 1401 1267"> <thead> <tr> <th data-bbox="336 1028 639 1072">Display</th> <th data-bbox="639 1028 1401 1072">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1072 639 1117">14400bps/V17</td> <td data-bbox="639 1072 1401 1117">V.17, 14400 bps</td> </tr> <tr> <td data-bbox="336 1117 639 1162">9600bps/V29</td> <td data-bbox="639 1117 1401 1162">V.17, 9600 bps</td> </tr> <tr> <td data-bbox="336 1162 639 1207">4800bps/V27ter</td> <td data-bbox="639 1162 1401 1207">V.27ter, 4800 bps</td> </tr> <tr> <td data-bbox="336 1207 639 1267">2400bps/V27ter</td> <td data-bbox="639 1207 1401 1267">V.27ter, 2400 bps</td> </tr> </tbody> </table> <p data-bbox="336 1279 711 1308">* : Initial setting: 14400bps/V17</p> <ol data-bbox="308 1312 782 1341" style="list-style-type: none"> 2. Press the start key. The setting is set. <p data-bbox="288 1382 643 1411">Setting the reception speed</p> <p data-bbox="288 1415 1409 1482">Sets the reception speed that the sender is informed of using the DIS or NSF signal. When the destination unit has V.34 capability, V.34 is selected, regardless of the setting.</p> <ol data-bbox="308 1487 919 1516" style="list-style-type: none"> 1. Select the setting using the cursor up/down keys. <table border="1" data-bbox="336 1527 1401 1769"> <thead> <tr> <th data-bbox="336 1527 639 1572">Display</th> <th data-bbox="639 1527 1401 1572">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1572 639 1617">14400bps</td> <td data-bbox="639 1572 1401 1617">V.17, V.33, V.29, V.27ter</td> </tr> <tr> <td data-bbox="336 1617 639 1662">9600bps</td> <td data-bbox="639 1617 1401 1662">V.29, V.27ter</td> </tr> <tr> <td data-bbox="336 1662 639 1706">4800bps</td> <td data-bbox="639 1662 1401 1706">V.27ter</td> </tr> <tr> <td data-bbox="336 1706 639 1769">2400bps</td> <td data-bbox="639 1706 1401 1769">V.27ter (fallback only)</td> </tr> </tbody> </table> <p data-bbox="336 1780 657 1809">* : Initial setting: 14400bps</p> <ol data-bbox="308 1814 782 1843" style="list-style-type: none"> 2. Press the start key. The setting is set. 	Display	Description	TX Speed	Sets the communication starting speed.	RX Speed	Sets the reception speed.	TX Echo	Sets the waiting period to prevent echo problems at the sender.	RX Echo	Sets the waiting period to prevent echo problems at the receiver.	Display	Description	14400bps/V17	V.17, 14400 bps	9600bps/V29	V.17, 9600 bps	4800bps/V27ter	V.27ter, 4800 bps	2400bps/V27ter	V.27ter, 2400 bps	Display	Description	14400bps	V.17, V.33, V.29, V.27ter	9600bps	V.29, V.27ter	4800bps	V.27ter	2400bps	V.27ter (fallback only)
Display	Description																														
TX Speed	Sets the communication starting speed.																														
RX Speed	Sets the reception speed.																														
TX Echo	Sets the waiting period to prevent echo problems at the sender.																														
RX Echo	Sets the waiting period to prevent echo problems at the receiver.																														
Display	Description																														
14400bps/V17	V.17, 14400 bps																														
9600bps/V29	V.17, 9600 bps																														
4800bps/V27ter	V.27ter, 4800 bps																														
2400bps/V27ter	V.27ter, 2400 bps																														
Display	Description																														
14400bps	V.17, V.33, V.29, V.27ter																														
9600bps	V.29, V.27ter																														
4800bps	V.27ter																														
2400bps	V.27ter (fallback only)																														

Item No.	Description												
U630	<p>Setting the waiting period to prevent echo problems at the sender Sets the period before a DCS signal is sent after a DIS signal is received. Used when problems occur due to echoes at the sender.</p> <p>1. Select the setting using the cursor up/down keys.</p> <table border="1" data-bbox="336 389 1401 533"> <thead> <tr> <th data-bbox="336 389 639 434">Display</th> <th data-bbox="639 389 1401 434">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 434 639 479">500</td> <td data-bbox="639 434 1401 479">Sends a DCS 500 ms after receiving a DIS.</td> </tr> <tr> <td data-bbox="336 479 639 533">300</td> <td data-bbox="639 479 1401 533">Sends a DCS 300 ms after receiving a DIS.</td> </tr> </tbody> </table> <p>* : Initial setting: 300</p> <p>2. Press the start key. The setting is set.</p> <p>Setting the waiting period to prevent echo problems at the receiver Sets the period before an NSF, CSI or DIS signal is sent after a CED signal is received. Used when problems occur due to echoes at the receiver.</p> <p>1. Select the setting using the cursor up/down keys.</p> <table border="1" data-bbox="336 792 1401 936"> <thead> <tr> <th data-bbox="336 792 639 837">Display</th> <th data-bbox="639 792 1401 837">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 837 639 882">500</td> <td data-bbox="639 837 1401 882">Sends an NSF, CSI or DIS 500 ms after receiving a CED.</td> </tr> <tr> <td data-bbox="336 882 639 936">75</td> <td data-bbox="639 882 1401 936">Sends an NSF, CSI or DIS 75 ms after receiving a CED.</td> </tr> </tbody> </table> <p>* : Initial setting: 75</p> <p>2. Press the start key. The setting is set.</p> <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	500	Sends a DCS 500 ms after receiving a DIS.	300	Sends a DCS 300 ms after receiving a DIS.	Display	Description	500	Sends an NSF, CSI or DIS 500 ms after receiving a CED.	75	Sends an NSF, CSI or DIS 75 ms after receiving a CED.
Display	Description												
500	Sends a DCS 500 ms after receiving a DIS.												
300	Sends a DCS 300 ms after receiving a DIS.												
Display	Description												
500	Sends an NSF, CSI or DIS 500 ms after receiving a CED.												
75	Sends an NSF, CSI or DIS 75 ms after receiving a CED.												

Item No.	Description																										
U631	<p data-bbox="288 241 710 271">Setting communication control 2</p> <p data-bbox="288 311 440 340">Description</p> <p data-bbox="288 344 799 374">Makes settings regarding fax transmission.</p> <p data-bbox="288 414 387 443">Method</p> <ol data-bbox="308 450 999 515" style="list-style-type: none"> <li data-bbox="308 450 564 479">1. Press the start key. <li data-bbox="308 483 999 515">2. Select the item to be set using the cursor up/down keys. <table border="1" data-bbox="336 526 1401 719"> <thead> <tr> <th data-bbox="336 526 639 571">Display</th> <th data-bbox="639 526 1401 571">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 571 639 616">ECM TX</td> <td data-bbox="639 571 1401 616">Sets ECM transmission.</td> </tr> <tr> <td data-bbox="336 616 639 660">ECM RX</td> <td data-bbox="639 616 1401 660">Sets ECM reception.</td> </tr> <tr> <td data-bbox="336 660 639 719">CED Freq</td> <td data-bbox="639 660 1401 719">Sets the frequency of the CED signal.</td> </tr> </tbody> </table> <p data-bbox="288 761 624 790">Setting ECM transmission</p> <p data-bbox="288 795 1374 860">To be set to Off when reduction of transmission costs is of higher priority than image quality. This should not be set to Off when connecting to the IP (Internet Protocol) telephone line.</p> <ol data-bbox="308 864 919 896" style="list-style-type: none"> <li data-bbox="308 864 919 896">1. Select the setting using the cursor up/down keys. <table border="1" data-bbox="336 907 1401 1055"> <thead> <tr> <th data-bbox="336 907 639 952">Display</th> <th data-bbox="639 907 1401 952">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 952 639 996">On</td> <td data-bbox="639 952 1401 996">ECM transmission is enabled.</td> </tr> <tr> <td data-bbox="336 996 639 1055">Off</td> <td data-bbox="639 996 1401 1055">ECM transmission is disabled.</td> </tr> </tbody> </table> <p data-bbox="336 1059 576 1088">* : Initial setting: On</p> <ol data-bbox="308 1093 780 1124" style="list-style-type: none"> <li data-bbox="308 1093 780 1124">2. Press the start key. The setting is set. <p data-bbox="288 1164 576 1193">Setting ECM reception</p> <p data-bbox="288 1198 1374 1263">To be set to Off when reduction of transmission costs is of higher priority than image quality. This should not be set to Off when connecting to the IP (Internet Protocol) telephone line.</p> <ol data-bbox="308 1267 919 1299" style="list-style-type: none"> <li data-bbox="308 1267 919 1299">1. Select the setting using the cursor up/down keys. <table border="1" data-bbox="336 1310 1401 1458"> <thead> <tr> <th data-bbox="336 1310 639 1355">Display</th> <th data-bbox="639 1310 1401 1355">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1355 639 1400">On</td> <td data-bbox="639 1355 1401 1400">ECM reception is enabled.</td> </tr> <tr> <td data-bbox="336 1400 639 1458">Off</td> <td data-bbox="639 1400 1401 1458">ECM reception is disabled.</td> </tr> </tbody> </table> <p data-bbox="336 1462 576 1491">* : Initial setting: On</p> <ol data-bbox="308 1496 780 1527" style="list-style-type: none"> <li data-bbox="308 1496 780 1527">2. Press the start key. The setting is set. <p data-bbox="288 1568 796 1597">Setting the frequency of the CED signal</p> <p data-bbox="288 1601 1433 1666">Sets the frequency of the CED signal. Used as one of the measures to improve transmission performance for international communications.</p> <ol data-bbox="308 1671 919 1702" style="list-style-type: none"> <li data-bbox="308 1671 919 1702">1. Select the setting using the cursor up/down keys. <table border="1" data-bbox="336 1713 1401 1861"> <thead> <tr> <th data-bbox="336 1713 639 1758">Display</th> <th data-bbox="639 1713 1401 1758">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1758 639 1803">2100</td> <td data-bbox="639 1758 1401 1803">2100 Hz</td> </tr> <tr> <td data-bbox="336 1803 639 1861">1100</td> <td data-bbox="639 1803 1401 1861">1100 Hz</td> </tr> </tbody> </table> <p data-bbox="336 1865 600 1895">* : Initial setting: 2100</p> <ol data-bbox="308 1899 780 1930" style="list-style-type: none"> <li data-bbox="308 1899 780 1930">2. Press the start key. The setting is set. <p data-bbox="288 1971 440 2000">Completion</p> <p data-bbox="288 2004 1254 2033">Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	ECM TX	Sets ECM transmission.	ECM RX	Sets ECM reception.	CED Freq	Sets the frequency of the CED signal.	Display	Description	On	ECM transmission is enabled.	Off	ECM transmission is disabled.	Display	Description	On	ECM reception is enabled.	Off	ECM reception is disabled.	Display	Description	2100	2100 Hz	1100	1100 Hz
Display	Description																										
ECM TX	Sets ECM transmission.																										
ECM RX	Sets ECM reception.																										
CED Freq	Sets the frequency of the CED signal.																										
Display	Description																										
On	ECM transmission is enabled.																										
Off	ECM transmission is disabled.																										
Display	Description																										
On	ECM reception is enabled.																										
Off	ECM reception is disabled.																										
Display	Description																										
2100	2100 Hz																										
1100	1100 Hz																										

Item No.	Description																		
U632	<p data-bbox="288 241 708 271">Setting communication control 3</p> <p data-bbox="288 311 440 340">Description</p> <p data-bbox="288 344 1069 374">Makes settings for fax transmission regarding the communication.</p> <p data-bbox="288 414 387 443">Method</p> <ol data-bbox="308 448 999 515" style="list-style-type: none"> 1. Press the start key. 2. Select the item to be set using the cursor up/down keys. <table border="1" data-bbox="336 526 1399 705"> <thead> <tr> <th data-bbox="336 526 639 571">Display</th> <th data-bbox="639 526 1399 571">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 571 639 616">DIS 4Byte</td> <td data-bbox="639 571 1399 616">Sets the DIS signal to 4 bytes.</td> </tr> <tr> <td data-bbox="336 616 639 705">Num OF CNG(F/T)</td> <td data-bbox="639 616 1399 705">Sets the CNG detection times in the fax/telephone auto select mode.</td> </tr> </tbody> </table> <p data-bbox="288 748 699 777">Setting the DIS signal to 4 bytes</p> <p data-bbox="288 781 975 810">Sets if bit 33 and later bits of the DIS/DTC signal are sent.</p> <ol data-bbox="308 815 919 844" style="list-style-type: none"> 1. Select the setting using the cursor up/down keys. <table border="1" data-bbox="336 862 1399 1005"> <thead> <tr> <th data-bbox="336 862 639 907">Display</th> <th data-bbox="639 862 1399 907">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 907 639 952">On</td> <td data-bbox="639 907 1399 952">Bit 33 and later bits of the DIS/DTC signal are not sent.</td> </tr> <tr> <td data-bbox="336 952 639 1005">Off</td> <td data-bbox="639 952 1399 1005">Bit 33 and later bits of the DIS/DTC signal are sent.</td> </tr> </tbody> </table> <p data-bbox="336 1012 576 1041">* : Initial setting: Off</p> <ol data-bbox="308 1046 782 1075" style="list-style-type: none"> 2. Press the start key. The setting is set. <p data-bbox="288 1117 1185 1146">Setting the CNG detection times in the fax/telephone auto select mode</p> <p data-bbox="288 1151 1101 1180">Sets the CNG detection times in the fax/telephone auto select mode.</p> <ol data-bbox="308 1184 919 1214" style="list-style-type: none"> 1. Select the setting using the cursor up/down keys. <table border="1" data-bbox="336 1227 1399 1370"> <thead> <tr> <th data-bbox="336 1227 639 1272">Display</th> <th data-bbox="639 1227 1399 1272">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1272 639 1317">1Time</td> <td data-bbox="639 1272 1399 1317">Detects CNG once.</td> </tr> <tr> <td data-bbox="336 1317 639 1370">2Time</td> <td data-bbox="639 1317 1399 1370">Detects CNG twice.</td> </tr> </tbody> </table> <p data-bbox="336 1377 612 1406">* : Initial setting: 2Time</p> <ol data-bbox="308 1411 782 1440" style="list-style-type: none"> 2. Press the start key. The setting is set. <p data-bbox="288 1482 440 1512">Completion</p> <p data-bbox="288 1516 1254 1545">Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	DIS 4Byte	Sets the DIS signal to 4 bytes.	Num OF CNG(F/T)	Sets the CNG detection times in the fax/telephone auto select mode.	Display	Description	On	Bit 33 and later bits of the DIS/DTC signal are not sent.	Off	Bit 33 and later bits of the DIS/DTC signal are sent.	Display	Description	1Time	Detects CNG once.	2Time	Detects CNG twice.
Display	Description																		
DIS 4Byte	Sets the DIS signal to 4 bytes.																		
Num OF CNG(F/T)	Sets the CNG detection times in the fax/telephone auto select mode.																		
Display	Description																		
On	Bit 33 and later bits of the DIS/DTC signal are not sent.																		
Off	Bit 33 and later bits of the DIS/DTC signal are sent.																		
Display	Description																		
1Time	Detects CNG once.																		
2Time	Detects CNG twice.																		

Item No.	Description																										
U633	<p data-bbox="288 241 710 271">Setting communication control 4</p> <p data-bbox="288 311 440 340">Description</p> <p data-bbox="288 344 1069 374">Makes settings for fax transmission regarding the communication.</p> <p data-bbox="288 380 400 409">Purpose</p> <p data-bbox="288 414 1018 443">To reduce transmission errors when a low quality line is used.</p> <p data-bbox="288 483 387 512">Method</p> <ol data-bbox="308 517 999 582" style="list-style-type: none"> 1. Press the start key. 2. Select the item to be set using the cursor up/down keys. <table border="1" data-bbox="336 595 1399 835"> <thead> <tr> <th data-bbox="336 595 639 640">Display</th> <th data-bbox="639 595 1399 640">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 640 639 685">V.34</td> <td data-bbox="639 640 1399 685">Enables or disables V.34 communication.</td> </tr> <tr> <td data-bbox="336 685 639 730">V.34-3429Hz</td> <td data-bbox="639 685 1399 730">Sets the V.34 symbol speed (3429 Hz).</td> </tr> <tr> <td data-bbox="336 730 639 775">DIS 2Res</td> <td data-bbox="639 730 1399 775">Sets the number of times of DIS signal reception.</td> </tr> <tr> <td data-bbox="336 775 639 835">RTN Check</td> <td data-bbox="639 775 1399 835">Sets the reference for RTN signal output.</td> </tr> </tbody> </table> <p data-bbox="288 882 798 911">Enabling/disabling V.34 communication</p> <p data-bbox="288 916 1303 945">Sets whether V.34 communication is enabled/disabled for transmission and reception.</p> <ol data-bbox="308 949 919 978" style="list-style-type: none"> 1. Select the setting using the cursor up/down keys. <table border="1" data-bbox="336 992 1399 1232"> <thead> <tr> <th data-bbox="336 992 563 1037">Display</th> <th data-bbox="563 992 1399 1037">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1037 563 1081">On</td> <td data-bbox="563 1037 1399 1081">V.34 communication is enabled for both transmission and reception.</td> </tr> <tr> <td data-bbox="336 1081 563 1126">TX</td> <td data-bbox="563 1081 1399 1126">V.34 communication is enabled for transmission only.</td> </tr> <tr> <td data-bbox="336 1126 563 1171">RX</td> <td data-bbox="563 1126 1399 1171">V.34 communication is enabled for reception only.</td> </tr> <tr> <td data-bbox="336 1171 563 1232">Off</td> <td data-bbox="563 1171 1399 1232">V.34 communication is disabled for both transmission and reception.</td> </tr> </tbody> </table> <p data-bbox="336 1243 576 1272">* : Initial setting: On</p> <ol data-bbox="308 1276 782 1305" style="list-style-type: none"> 2. Press the start key. The setting is set. <p data-bbox="288 1346 802 1375">Setting the V.34 symbol speed (3429 Hz)</p> <p data-bbox="288 1379 849 1408">Sets if the V.34 symbol speed 3429 Hz is used.</p> <ol data-bbox="308 1413 919 1442" style="list-style-type: none"> 1. Select the setting using the cursor up/down keys. <table border="1" data-bbox="336 1456 1399 1603"> <thead> <tr> <th data-bbox="336 1456 639 1500">Display</th> <th data-bbox="639 1456 1399 1500">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1500 639 1545">On</td> <td data-bbox="639 1500 1399 1545">V.34 symbol speed 3429 Hz is used.</td> </tr> <tr> <td data-bbox="336 1545 639 1603">Off</td> <td data-bbox="639 1545 1399 1603">V.34 symbol speed 3429 Hz is not used.</td> </tr> </tbody> </table> <p data-bbox="336 1615 576 1644">* : Initial setting: On</p> <ol data-bbox="308 1648 782 1677" style="list-style-type: none"> 2. Press the start key. The setting is set. 	Display	Description	V.34	Enables or disables V.34 communication.	V.34-3429Hz	Sets the V.34 symbol speed (3429 Hz).	DIS 2Res	Sets the number of times of DIS signal reception.	RTN Check	Sets the reference for RTN signal output.	Display	Description	On	V.34 communication is enabled for both transmission and reception.	TX	V.34 communication is enabled for transmission only.	RX	V.34 communication is enabled for reception only.	Off	V.34 communication is disabled for both transmission and reception.	Display	Description	On	V.34 symbol speed 3429 Hz is used.	Off	V.34 symbol speed 3429 Hz is not used.
Display	Description																										
V.34	Enables or disables V.34 communication.																										
V.34-3429Hz	Sets the V.34 symbol speed (3429 Hz).																										
DIS 2Res	Sets the number of times of DIS signal reception.																										
RTN Check	Sets the reference for RTN signal output.																										
Display	Description																										
On	V.34 communication is enabled for both transmission and reception.																										
TX	V.34 communication is enabled for transmission only.																										
RX	V.34 communication is enabled for reception only.																										
Off	V.34 communication is disabled for both transmission and reception.																										
Display	Description																										
On	V.34 symbol speed 3429 Hz is used.																										
Off	V.34 symbol speed 3429 Hz is not used.																										

Item No.	Description																
U633	<p>Setting the number of times of DIS signal reception Sets the number of times to receive the DIS signal to once or twice. Used as one of the correction measures for transmission errors and other problems.</p> <ol style="list-style-type: none"> Select the setting using the cursor up/down keys. <table border="1" data-bbox="336 389 1401 533"> <thead> <tr> <th>Display</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>Once</td> <td>Responds to the first signal.</td> </tr> <tr> <td>Twice</td> <td>Responds to the second signal.</td> </tr> </tbody> </table> <p>* : Initial setting: Once</p> <ol style="list-style-type: none"> Press the start key. The setting is set. <p>Setting the reference for RTN signal output Sets the error line rate as the reference for RTN signal output. If transmission errors occur frequently due to the quality of the line, they can be reduced by lowering this setting.</p> <ol style="list-style-type: none"> Select the setting using the cursor up/down keys. <table border="1" data-bbox="336 795 1401 1032"> <thead> <tr> <th>Display</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>5%</td> <td>Error line rate of 5%</td> </tr> <tr> <td>10%</td> <td>Error line rate of 10%</td> </tr> <tr> <td>15%</td> <td>Error line rate of 15%</td> </tr> <tr> <td>20%</td> <td>Error line rate of 20%</td> </tr> </tbody> </table> <p>* : Initial setting: 15%</p> <ol style="list-style-type: none"> Press the start key. The setting is set. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Once	Responds to the first signal.	Twice	Responds to the second signal.	Display	Description	5%	Error line rate of 5%	10%	Error line rate of 10%	15%	Error line rate of 15%	20%	Error line rate of 20%
Display	Description																
Once	Responds to the first signal.																
Twice	Responds to the second signal.																
Display	Description																
5%	Error line rate of 5%																
10%	Error line rate of 10%																
15%	Error line rate of 15%																
20%	Error line rate of 20%																
U634	<p>Setting communication control 5</p> <p>Description Sets the maximum number of error bytes judged acceptable when receiving a TCF signal. Used as a measure to ease transmission conditions if transmission errors occur.</p> <p>Setting</p> <ol style="list-style-type: none"> Press the start key. Change the setting using the cursor left/right keys or numeric keys. <table border="1" data-bbox="336 1552 1401 1646"> <thead> <tr> <th>Description</th> <th>Setting range</th> <th>Initial setting</th> </tr> </thead> <tbody> <tr> <td>Number of allowed error bytes when detecting TCF</td> <td>0 to 255</td> <td>0</td> </tr> </tbody> </table> <ol style="list-style-type: none"> Press the start key. The value is set. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Description	Setting range	Initial setting	Number of allowed error bytes when detecting TCF	0 to 255	0										
Description	Setting range	Initial setting															
Number of allowed error bytes when detecting TCF	0 to 255	0															

Item No.	Description																		
U640	<p data-bbox="288 244 671 271">Setting communication time 1</p> <p data-bbox="288 315 440 342">Description</p> <p data-bbox="288 349 1406 412">Sets the detection time when one-shot detection is selected for remote switching. (This setting item will be displayed, but the setting made is ineffective.)</p> <p data-bbox="288 418 1426 481">Sets the detection time when continuous detection is selected for remote switching. (This setting item will be displayed, but the setting made is ineffective.)</p> <p data-bbox="288 521 387 548">Method</p> <ol data-bbox="308 555 999 618" style="list-style-type: none"> 1. Press the start key. 2. Select the item to be set using the cursor up/down keys. <table border="1" data-bbox="336 633 1401 777"> <thead> <tr> <th data-bbox="336 633 639 678">Display</th> <th data-bbox="639 633 1401 678">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 678 639 723">Time (One)</td> <td data-bbox="639 678 1401 723">Sets the one-shot detection time for remote switching.</td> </tr> <tr> <td data-bbox="336 723 639 777">Time (Cont)</td> <td data-bbox="639 723 1401 777">Sets the continuous detection time for remote switching.</td> </tr> </tbody> </table> <p data-bbox="288 817 1010 844">Setting the one-shot detection time for remote switching</p> <ol data-bbox="308 851 932 878" style="list-style-type: none"> 1. Change the setting using the cursor left/right keys. <table border="1" data-bbox="336 896 1401 990"> <thead> <tr> <th data-bbox="336 896 975 940">Description</th> <th data-bbox="975 896 1190 940">Setting range</th> <th data-bbox="1190 896 1401 940">Initial setting</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 940 975 990">One-shot detection time for remote switching</td> <td data-bbox="975 940 1190 990">0 to 255</td> <td data-bbox="1190 940 1401 990">7</td> </tr> </tbody> </table> <ol data-bbox="308 1001 767 1028" style="list-style-type: none"> 2. Press the start key. The value is set. <p data-bbox="288 1068 1042 1095">Setting the continuous detection time for remote switching</p> <ol data-bbox="308 1102 932 1128" style="list-style-type: none"> 1. Change the setting using the cursor left/right keys. <table border="1" data-bbox="336 1146 1401 1240"> <thead> <tr> <th data-bbox="336 1146 975 1191">Description</th> <th data-bbox="975 1146 1190 1191">Setting range</th> <th data-bbox="1190 1146 1401 1191">Initial setting</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1191 975 1240">Continuous detection time for remote switching</td> <td data-bbox="975 1191 1190 1240">0 to 255</td> <td data-bbox="1190 1191 1401 1240">80</td> </tr> </tbody> </table> <ol data-bbox="308 1252 767 1279" style="list-style-type: none"> 2. Press the start key. The value is set. <p data-bbox="288 1319 440 1346">Completion</p> <p data-bbox="288 1352 1254 1379">Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Time (One)	Sets the one-shot detection time for remote switching.	Time (Cont)	Sets the continuous detection time for remote switching.	Description	Setting range	Initial setting	One-shot detection time for remote switching	0 to 255	7	Description	Setting range	Initial setting	Continuous detection time for remote switching	0 to 255	80
Display	Description																		
Time (One)	Sets the one-shot detection time for remote switching.																		
Time (Cont)	Sets the continuous detection time for remote switching.																		
Description	Setting range	Initial setting																	
One-shot detection time for remote switching	0 to 255	7																	
Description	Setting range	Initial setting																	
Continuous detection time for remote switching	0 to 255	80																	

Item No.	Description																														
U641	<p data-bbox="288 241 673 271">Setting communication time 2</p> <p data-bbox="288 311 440 340">Description</p> <p data-bbox="288 344 799 374">Sets the time-out time for fax transmission.</p> <p data-bbox="288 380 400 409">Purpose</p> <p data-bbox="288 414 1222 443">To improve transmission performance for international communications mainly.</p> <p data-bbox="288 483 387 512">Method</p> <ol data-bbox="304 517 999 584" style="list-style-type: none"> 1. Press the start key. 2. Select the item to be set using the cursor up/down keys. <table border="1" data-bbox="336 595 1399 1028"> <thead> <tr> <th data-bbox="336 595 639 640">Display</th> <th data-bbox="639 595 1399 640">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 640 639 685">T0 Time Out</td> <td data-bbox="639 640 1399 685">Sets the T0 time-out time.</td> </tr> <tr> <td data-bbox="336 685 639 730">T1 Time Out</td> <td data-bbox="639 685 1399 730">Sets the T1 time-out time.</td> </tr> <tr> <td data-bbox="336 730 639 775">T2 Time Out</td> <td data-bbox="639 730 1399 775">Sets the T2 time-out time.</td> </tr> <tr> <td data-bbox="336 775 639 819">Ta Time Out</td> <td data-bbox="639 775 1399 819">Sets the Ta time-out time.</td> </tr> <tr> <td data-bbox="336 819 639 864">Tb1 Time Out</td> <td data-bbox="639 819 1399 864">Sets the Tb1 time-out time.</td> </tr> <tr> <td data-bbox="336 864 639 909">Tb2 Time Out</td> <td data-bbox="639 864 1399 909">Sets the Tb2 time-out time.</td> </tr> <tr> <td data-bbox="336 909 639 954">Tc Time Out</td> <td data-bbox="639 909 1399 954">Sets the Tc time-out time.</td> </tr> <tr> <td data-bbox="336 954 639 1028">Td Time Out</td> <td data-bbox="639 954 1399 1028">Sets the Td time-out time.</td> </tr> </tbody> </table> <p data-bbox="288 1070 644 1099">Setting the T0 time-out time</p> <p data-bbox="288 1104 1230 1133">Sets the time before detecting a CED or DIS signal after a dialing signal is sent.</p> <p data-bbox="288 1137 1388 1205">Depending on the quality of the exchange, or when the auto select function is selected at the destination unit, a line can be disconnected. Change the setting to prevent this problem.</p> <ol data-bbox="304 1209 932 1238" style="list-style-type: none"> 1. Change the setting using the cursor left/right keys. <table border="1" data-bbox="336 1249 1399 1348"> <thead> <tr> <th data-bbox="336 1249 975 1294">Description</th> <th data-bbox="975 1249 1187 1294">Setting range</th> <th data-bbox="1187 1249 1399 1294">Initial setting</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1294 975 1348">T0 time-out time</td> <td data-bbox="975 1294 1187 1348">30 to 90 s</td> <td data-bbox="1187 1294 1399 1348">56</td> </tr> </tbody> </table> <ol data-bbox="304 1352 767 1382" style="list-style-type: none"> 2. Press the start key. The value is set. <p data-bbox="288 1424 644 1453">Setting the T1 time-out time</p> <p data-bbox="288 1458 1425 1525">Sets the time before receiving the correct signal after call reception. No change is necessary for this maintenance item.</p> <ol data-bbox="304 1529 932 1559" style="list-style-type: none"> 1. Change the setting using the cursor left/right keys. <table border="1" data-bbox="336 1570 1399 1668"> <thead> <tr> <th data-bbox="336 1570 975 1615">Description</th> <th data-bbox="975 1570 1187 1615">Setting range</th> <th data-bbox="1187 1570 1399 1615">Initial setting</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1615 975 1668">T1 time-out time</td> <td data-bbox="975 1615 1187 1668">30 to 90 s</td> <td data-bbox="1187 1615 1399 1668">36</td> </tr> </tbody> </table> <ol data-bbox="304 1673 767 1702" style="list-style-type: none"> 2. Press the start key. The value is set. 	Display	Description	T0 Time Out	Sets the T0 time-out time.	T1 Time Out	Sets the T1 time-out time.	T2 Time Out	Sets the T2 time-out time.	Ta Time Out	Sets the Ta time-out time.	Tb1 Time Out	Sets the Tb1 time-out time.	Tb2 Time Out	Sets the Tb2 time-out time.	Tc Time Out	Sets the Tc time-out time.	Td Time Out	Sets the Td time-out time.	Description	Setting range	Initial setting	T0 time-out time	30 to 90 s	56	Description	Setting range	Initial setting	T1 time-out time	30 to 90 s	36
Display	Description																														
T0 Time Out	Sets the T0 time-out time.																														
T1 Time Out	Sets the T1 time-out time.																														
T2 Time Out	Sets the T2 time-out time.																														
Ta Time Out	Sets the Ta time-out time.																														
Tb1 Time Out	Sets the Tb1 time-out time.																														
Tb2 Time Out	Sets the Tb2 time-out time.																														
Tc Time Out	Sets the Tc time-out time.																														
Td Time Out	Sets the Td time-out time.																														
Description	Setting range	Initial setting																													
T0 time-out time	30 to 90 s	56																													
Description	Setting range	Initial setting																													
T1 time-out time	30 to 90 s	36																													

Item No.	Description																						
U641	<p data-bbox="290 241 646 271">Setting the T2 time-out time</p> <p data-bbox="290 277 801 306">The T2 time-out time decides the following.</p> <p data-bbox="290 313 863 342">From CFR signal output to image data reception</p> <p data-bbox="290 349 940 378">From image data reception to the next signal reception</p> <p data-bbox="290 385 1035 414">In ECM, from RNR signal detection to the next signal reception</p> <p data-bbox="308 421 932 450">1. Change the setting using the cursor left/right keys.</p> <table border="1" data-bbox="336 459 1399 589"> <thead> <tr> <th data-bbox="336 459 807 539">Description</th> <th data-bbox="807 459 991 539">Setting range</th> <th data-bbox="991 459 1171 539">Initial setting</th> <th data-bbox="1171 459 1399 539">Change in value per step</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 539 807 589">T2 time-out time</td> <td data-bbox="807 539 991 589">1 to 255</td> <td data-bbox="991 539 1171 589">69</td> <td data-bbox="1171 539 1399 589">100 ms</td> </tr> </tbody> </table> <p data-bbox="308 600 766 629">2. Press the start key. The value is set.</p> <p data-bbox="290 667 643 696">Setting the Ta time-out time</p> <p data-bbox="290 703 1423 871">In the fax/telephone auto select mode, sets the time to continue ringing an operator through the connected telephone after receiving a call as a fax machine (see figure 1-3-3). A fax signal is received within the Ta set time, or the fax mode is selected automatically when the time elapses. In fax/telephone auto select mode, change the setting when fax reception is unsuccessful or a telephone fails to receive a call.</p> <p data-bbox="308 878 932 907">1. Change the setting using the cursor left/right keys.</p> <table border="1" data-bbox="336 916 1399 1014"> <thead> <tr> <th data-bbox="336 916 975 965">Description</th> <th data-bbox="975 916 1187 965">Setting range</th> <th data-bbox="1187 916 1399 965">Initial setting</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 965 975 1014">Ta time-out time</td> <td data-bbox="975 965 1187 1014">1 to 255</td> <td data-bbox="1187 965 1399 1014">30</td> </tr> </tbody> </table> <p data-bbox="308 1025 766 1055">2. Press the start key. The value is set.</p> <div data-bbox="518 1084 1220 1458" style="text-align: center;"> </div> <p data-bbox="619 1494 1102 1523">Figure 1-3-3 Ta/Tb1/Tb2 time-out time</p> <p data-bbox="290 1563 662 1592">Setting the Tb1 time-out time</p> <p data-bbox="290 1599 1412 1697">In the fax/telephone auto select mode, sets the time to start sending the ring back tone after receiving a call as a fax machine (see figure 1-3-3). In fax/telephone auto select mode, change the setting when fax reception is unsuccessful or a telephone fails to receive a call.</p> <p data-bbox="308 1704 932 1733">1. Change the setting using the cursor left/right keys.</p> <table border="1" data-bbox="336 1742 1399 1872"> <thead> <tr> <th data-bbox="336 1742 807 1823">Description</th> <th data-bbox="807 1742 991 1823">Setting range</th> <th data-bbox="991 1742 1171 1823">Initial setting</th> <th data-bbox="1171 1742 1399 1823">Change in value per step</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1823 807 1872">Tb1 time-out time</td> <td data-bbox="807 1823 991 1872">1 to 255</td> <td data-bbox="991 1823 1171 1872">20</td> <td data-bbox="1171 1823 1399 1872">100 ms</td> </tr> </tbody> </table> <p data-bbox="308 1883 766 1912">2. Press the start key. The value is set.</p>	Description	Setting range	Initial setting	Change in value per step	T2 time-out time	1 to 255	69	100 ms	Description	Setting range	Initial setting	Ta time-out time	1 to 255	30	Description	Setting range	Initial setting	Change in value per step	Tb1 time-out time	1 to 255	20	100 ms
Description	Setting range	Initial setting	Change in value per step																				
T2 time-out time	1 to 255	69	100 ms																				
Description	Setting range	Initial setting																					
Ta time-out time	1 to 255	30																					
Description	Setting range	Initial setting	Change in value per step																				
Tb1 time-out time	1 to 255	20	100 ms																				

Item No.	Description																				
U641	<p data-bbox="288 241 662 271">Setting the Tb2 time-out time</p> <p data-bbox="288 277 1430 409">In the fax/telephone auto select mode, sets the time to start ringing an operator through the connected telephone after receiving a call as a fax machine (see figure 1-3-3). In the fax/telephone auto select mode, change the setting when fax reception is unsuccessful or a telephone fails to receive a call.</p> <p data-bbox="308 416 930 445">1. Change the setting using the cursor left/right keys.</p> <table border="1" data-bbox="336 456 1401 589"> <thead> <tr> <th data-bbox="336 456 807 539">Description</th> <th data-bbox="807 456 991 539">Setting range</th> <th data-bbox="991 456 1171 539">Initial setting</th> <th data-bbox="1171 456 1401 539">Change in value per step</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 539 807 589">Tb2 time-out time</td> <td data-bbox="807 539 991 589">1 to 255</td> <td data-bbox="991 539 1171 589">80</td> <td data-bbox="1171 539 1401 589">100 ms</td> </tr> </tbody> </table> <p data-bbox="308 600 766 629">2. Press the start key. The value is set.</p> <p data-bbox="288 667 643 696">Setting the Tc time-out time</p> <p data-bbox="288 703 1426 799">In the TAD mode, set the time to check if there are any triggers for shifting to fax reception after a connected telephone receives a call. Only the telephone function is available if shifting is not made within the set Tc time.</p> <p data-bbox="288 806 1410 871">In the TAD mode, change the setting when fax reception is unsuccessful or a telephone fails to receive a call.</p> <p data-bbox="308 878 930 907">1. Change the setting using the cursor left/right keys.</p> <table border="1" data-bbox="336 918 1401 1014"> <thead> <tr> <th data-bbox="336 918 975 965">Description</th> <th data-bbox="975 918 1187 965">Setting range</th> <th data-bbox="1187 918 1401 965">Initial setting</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 965 975 1014">Tc time-out time</td> <td data-bbox="975 965 1187 1014">1 to 255</td> <td data-bbox="1187 965 1401 1014">60</td> </tr> </tbody> </table> <p data-bbox="308 1025 766 1055">2. Press the start key. The value is set.</p> <p data-bbox="288 1093 646 1122">Setting the Td time-out time</p> <p data-bbox="288 1128 1426 1261">Sets the length of the time required to determine silent status (fax), one of the triggers for Tc time check. In the TAD mode, change the setting when fax reception is unsuccessful or a telephone fails to receive a call. Be sure not to set it too short; otherwise, the mode may be shifted to fax while the unit is being used as a telephone.</p> <p data-bbox="308 1267 930 1296">1. Change the setting using the cursor left/right keys.</p> <table border="1" data-bbox="336 1308 1401 1404"> <thead> <tr> <th data-bbox="336 1308 868 1355">Description</th> <th data-bbox="868 1308 1096 1355">Setting range</th> <th data-bbox="1096 1308 1401 1355">Initial setting</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1355 868 1404">Td time-out time</td> <td data-bbox="868 1355 1096 1404">1 to 255</td> <td data-bbox="1096 1355 1401 1404">9 (120 V)/6 (220-240 V)</td> </tr> </tbody> </table> <p data-bbox="308 1415 766 1444">2. Press the start key. The value is set.</p> <p data-bbox="288 1482 440 1512">Completion</p> <p data-bbox="288 1518 1254 1547">Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Description	Setting range	Initial setting	Change in value per step	Tb2 time-out time	1 to 255	80	100 ms	Description	Setting range	Initial setting	Tc time-out time	1 to 255	60	Description	Setting range	Initial setting	Td time-out time	1 to 255	9 (120 V)/6 (220-240 V)
Description	Setting range	Initial setting	Change in value per step																		
Tb2 time-out time	1 to 255	80	100 ms																		
Description	Setting range	Initial setting																			
Tc time-out time	1 to 255	60																			
Description	Setting range	Initial setting																			
Td time-out time	1 to 255	9 (120 V)/6 (220-240 V)																			

Item No.	Description								
U650	<p>Setting modem 1</p> <p>Description Sets the G3 cable equalizer. Sets the modem detection level.</p> <p>Purpose Perform the following adjustment to make the equalizer compatible with the line characteristics. To improve the transmission performance when a low quality line is used.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select the item to be set using the cursor up/down keys. <table border="1" data-bbox="336 633 1401 824"> <thead> <tr> <th>Display</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>Reg G3 TX Eqr</td> <td>Sets the G3 transmission cable equalizer.</td> </tr> <tr> <td>Reg G3 RX Eqr</td> <td>Sets the G3 reception cable equalizer.</td> </tr> <tr> <td>RX Mdm Level</td> <td>Sets the modem detection level.</td> </tr> </tbody> </table> <p>Setting the G3 transmission cable equalizer</p> <ol style="list-style-type: none"> 1. Select [0dB], [4dB], [8dB] or [12dB] using the cursor up/down keys. * : Initial setting: 0dB 2. Press the start key. The setting is set. <p>Setting the G3 reception cable equalizer</p> <ol style="list-style-type: none"> 1. Select [0dB], [4dB], [8dB] or [12dB] using the cursor up/down keys. * : Initial setting: 0dB 2. Press the start key. The setting is set. <p>Setting the modem detection level</p> <ol style="list-style-type: none"> 1. Select [-33dBm], [-38dBm], [-43dBm] or [-48dBm] using the cursor up/down keys. * : Initial setting: -43dBm 2. Press the start key. The setting is set. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Reg G3 TX Eqr	Sets the G3 transmission cable equalizer.	Reg G3 RX Eqr	Sets the G3 reception cable equalizer.	RX Mdm Level	Sets the modem detection level.
Display	Description								
Reg G3 TX Eqr	Sets the G3 transmission cable equalizer.								
Reg G3 RX Eqr	Sets the G3 reception cable equalizer.								
RX Mdm Level	Sets the modem detection level.								

Item No.	Description																
U651	<p>Setting modem 2</p> <p>Description Sets the modem output level. Sets the DTMF output level of a push-button dial telephone.</p> <p>Purpose Used if problems occur when sending a signal with a push-button dial telephone.</p> <p>Setting</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select the item to be set using the cursor up/down keys. 3. Change the setting using the cursor left/right keys or numeric keys. <table border="1" data-bbox="336 667 1385 963"> <thead> <tr> <th>Display</th> <th>Description</th> <th>Setting range</th> <th>Initial setting</th> </tr> </thead> <tbody> <tr> <td>Sgl LV Mdm</td> <td>Modem output level</td> <td>1 to 15</td> <td>9 (120 V) 10 (220-240 V)</td> </tr> <tr> <td>DTMF LV(C)</td> <td>DTMF output level (main value)</td> <td>0 to 15.0</td> <td>5 (120 V) 10.5 (220-240 V)</td> </tr> <tr> <td>DTMF LV(D)</td> <td>DTMF output level (level difference)</td> <td>0 to 5.5</td> <td>2 (120 V) 2.5 (220-240 V)</td> </tr> </tbody> </table> <ol style="list-style-type: none"> 4. Press the start key. The setting is set. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Setting range	Initial setting	Sgl LV Mdm	Modem output level	1 to 15	9 (120 V) 10 (220-240 V)	DTMF LV(C)	DTMF output level (main value)	0 to 15.0	5 (120 V) 10.5 (220-240 V)	DTMF LV(D)	DTMF output level (level difference)	0 to 5.5	2 (120 V) 2.5 (220-240 V)
Display	Description	Setting range	Initial setting														
Sgl LV Mdm	Modem output level	1 to 15	9 (120 V) 10 (220-240 V)														
DTMF LV(C)	DTMF output level (main value)	0 to 15.0	5 (120 V) 10.5 (220-240 V)														
DTMF LV(D)	DTMF output level (level difference)	0 to 5.5	2 (120 V) 2.5 (220-240 V)														

Item No.	Description																								
U660	<p data-bbox="288 241 496 271">Setting the NCU</p> <p data-bbox="288 311 440 340">Description Makes setting regarding the network control unit (NCU).</p> <p data-bbox="288 380 400 409">Purpose To be executed as required.</p> <p data-bbox="288 486 387 515">Method</p> <ol data-bbox="308 519 999 584" style="list-style-type: none"> 1. Press the start key. 2. Select the item to be set using the cursor up/down keys. <table border="1" data-bbox="336 595 1399 884"> <thead> <tr> <th data-bbox="336 595 639 640">Display</th> <th data-bbox="639 595 1399 640">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 640 639 685">Exchange</td> <td data-bbox="639 640 1399 685">Sets the connection to PBX/PSTN.</td> </tr> <tr> <td data-bbox="336 685 639 730">Dial Tone</td> <td data-bbox="639 685 1399 730">Sets PSTN dial tone detection.</td> </tr> <tr> <td data-bbox="336 730 639 775">Busy Tone</td> <td data-bbox="639 730 1399 775">Sets busy tone detection.</td> </tr> <tr> <td data-bbox="336 775 639 819">PBX Setting</td> <td data-bbox="639 775 1399 819">Setting for a PBX.</td> </tr> <tr> <td data-bbox="336 819 639 884">DC Loop</td> <td data-bbox="639 819 1399 884">Sets the loop current detection before dialing.</td> </tr> </tbody> </table> <p data-bbox="288 929 754 958">Setting the connection to PBX/PSTN</p> <p data-bbox="288 963 1331 992">Selects if a fax is to be connected to either a PBX or public switched telephone network.</p> <ol data-bbox="308 996 919 1025" style="list-style-type: none"> 1. Select the setting using the cursor up/down keys. <table border="1" data-bbox="336 1039 1399 1184"> <thead> <tr> <th data-bbox="336 1039 639 1084">Display</th> <th data-bbox="639 1039 1399 1084">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1084 639 1128">PSTN</td> <td data-bbox="639 1084 1399 1128">Connected to the public switched telephone network.</td> </tr> <tr> <td data-bbox="336 1128 639 1184">PBX</td> <td data-bbox="639 1128 1399 1184">Connected to a PBX.</td> </tr> </tbody> </table> <p data-bbox="336 1196 611 1225">* : Initial setting: PSTN</p> <ol data-bbox="308 1229 782 1258" style="list-style-type: none"> 2. Press the start key. The setting is set. <p data-bbox="288 1299 705 1328">Setting PSTN dial tone detection</p> <p data-bbox="288 1332 1426 1397">Selects if the dial tone is detected to check the telephone is off the hook when a fax is connected to a public switched telephone network.</p> <ol data-bbox="308 1402 919 1431" style="list-style-type: none"> 1. Select the setting using the cursor up/down keys. <table border="1" data-bbox="336 1444 1399 1590"> <thead> <tr> <th data-bbox="336 1444 639 1489">Display</th> <th data-bbox="639 1444 1399 1489">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1489 639 1534">On</td> <td data-bbox="639 1489 1399 1534">Detects the dial tone.</td> </tr> <tr> <td data-bbox="336 1534 639 1590">Off</td> <td data-bbox="639 1534 1399 1590">Does not detect the dial tone.</td> </tr> </tbody> </table> <p data-bbox="336 1601 576 1630">* : Initial setting: On</p> <ol data-bbox="308 1635 782 1664" style="list-style-type: none"> 2. Press the start key. The setting is set. 	Display	Description	Exchange	Sets the connection to PBX/PSTN.	Dial Tone	Sets PSTN dial tone detection.	Busy Tone	Sets busy tone detection.	PBX Setting	Setting for a PBX.	DC Loop	Sets the loop current detection before dialing.	Display	Description	PSTN	Connected to the public switched telephone network.	PBX	Connected to a PBX.	Display	Description	On	Detects the dial tone.	Off	Does not detect the dial tone.
Display	Description																								
Exchange	Sets the connection to PBX/PSTN.																								
Dial Tone	Sets PSTN dial tone detection.																								
Busy Tone	Sets busy tone detection.																								
PBX Setting	Setting for a PBX.																								
DC Loop	Sets the loop current detection before dialing.																								
Display	Description																								
PSTN	Connected to the public switched telephone network.																								
PBX	Connected to a PBX.																								
Display	Description																								
On	Detects the dial tone.																								
Off	Does not detect the dial tone.																								

Item No.	Description																		
U660	<p data-bbox="288 241 644 271">Setting busy tone detection</p> <p data-bbox="288 277 1431 443">When a fax signal is sent, sets whether the line is disconnected immediately after a busy tone is detected, or the busy tone is not detected and the line remains connected until T0 time-out time. Fax transmission may fail due to incorrect busy tone detection. When set to 2, this problem may be prevented. However, the line is not disconnected within the T0 time-out time even if the destination line is busy.</p> <p data-bbox="308 450 919 479">1. Select the setting using the cursor up/down keys.</p> <table border="1" data-bbox="336 495 1401 636"> <thead> <tr> <th data-bbox="336 495 639 539">Display</th> <th data-bbox="639 495 1401 539">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 539 639 584">On</td> <td data-bbox="639 539 1401 584">Detects busy tone.</td> </tr> <tr> <td data-bbox="336 584 639 636">Off</td> <td data-bbox="639 584 1401 636">Does not detect busy tone.</td> </tr> </tbody> </table> <p data-bbox="336 647 576 676">* : Initial setting: On</p> <p data-bbox="308 683 782 712">2. Press the start key. The setting is set.</p> <p data-bbox="288 750 512 779">Setting for a PBX</p> <p data-bbox="288 786 1129 815">Selects the mode to connect an outside call when connected to a PBX.</p> <p data-bbox="288 822 1329 851">According to the type of the PBX connected, select the mode to connect an outside call.</p> <p data-bbox="308 857 919 887">1. Select the setting using the cursor up/down keys.</p> <table border="1" data-bbox="336 902 1401 1043"> <thead> <tr> <th data-bbox="336 902 639 947">Display</th> <th data-bbox="639 902 1401 947">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 947 639 992">Flash</td> <td data-bbox="639 947 1401 992">Flashing mode</td> </tr> <tr> <td data-bbox="336 992 639 1043">Loop</td> <td data-bbox="639 992 1401 1043">Code number mode</td> </tr> </tbody> </table> <p data-bbox="336 1055 600 1084">* : Initial setting: Loop</p> <p data-bbox="308 1090 782 1120">2. Press the start key. The setting is set.</p> <p data-bbox="288 1158 903 1187">Setting the loop current detection before dialing</p> <p data-bbox="288 1193 1005 1223">Sets if the loop current detection is performed before dialing.</p> <p data-bbox="308 1229 919 1258">1. Select the setting using the cursor up/down keys.</p> <table border="1" data-bbox="336 1274 1401 1415"> <thead> <tr> <th data-bbox="336 1274 639 1319">Display</th> <th data-bbox="639 1274 1401 1319">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1319 639 1364">On</td> <td data-bbox="639 1319 1401 1364">Performs loop current detection before dialing.</td> </tr> <tr> <td data-bbox="336 1364 639 1415">Off</td> <td data-bbox="639 1364 1401 1415">Does not perform loop current detection before dialing.</td> </tr> </tbody> </table> <p data-bbox="336 1426 576 1456">* : Initial setting: On</p> <p data-bbox="308 1462 782 1491">2. Press the start key. The setting is set.</p> <p data-bbox="288 1529 440 1559">Completion</p> <p data-bbox="288 1565 1254 1594">Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	On	Detects busy tone.	Off	Does not detect busy tone.	Display	Description	Flash	Flashing mode	Loop	Code number mode	Display	Description	On	Performs loop current detection before dialing.	Off	Does not perform loop current detection before dialing.
Display	Description																		
On	Detects busy tone.																		
Off	Does not detect busy tone.																		
Display	Description																		
Flash	Flashing mode																		
Loop	Code number mode																		
Display	Description																		
On	Performs loop current detection before dialing.																		
Off	Does not perform loop current detection before dialing.																		

Item No.	Description																				
U670	<p data-bbox="290 241 491 273">Outputting lists</p> <p data-bbox="290 309 440 340">Description</p> <p data-bbox="290 344 877 376">Outputs a list of data regarding fax transmissions.</p> <p data-bbox="290 380 1385 443">Printing a list is disabled either when a job is remaining in the buffer or when [Pause All Print Jobs] is pressed to halt printing.</p> <p data-bbox="290 448 399 479">Purpose</p> <p data-bbox="290 483 1187 515">To check conditions of use, settings and transmission procedures of the fax.</p> <p data-bbox="290 551 386 582">Method</p> <ol data-bbox="306 586 1037 685" style="list-style-type: none"> 1. Press the start key. 2. Select the item to be output using the cursor up/down keys. 3. Press the start key. The selected list is output. <table border="1" data-bbox="338 698 1401 1281"> <thead> <tr> <th data-bbox="346 710 641 754">Display</th> <th data-bbox="641 710 1393 754">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="346 754 641 833">Sys Conf Report</td> <td data-bbox="641 754 1393 833">Outputs a list of software switches, self telephone number, confidential boxes, ROM versions and other information.</td> </tr> <tr> <td data-bbox="346 833 641 911">Action List</td> <td data-bbox="641 833 1393 911">Outputs a list of error history, transmission line details and other information.</td> </tr> <tr> <td data-bbox="346 911 641 990">Self Sts Report</td> <td data-bbox="641 911 1393 990">Outputs a list of settings in maintenance mode (own-status report) regarding fax transmission only.</td> </tr> <tr> <td data-bbox="346 990 641 1034">Protocol List</td> <td data-bbox="641 990 1393 1034">Outputs a list of transmission procedures.</td> </tr> <tr> <td data-bbox="346 1034 641 1079">Error List</td> <td data-bbox="641 1034 1393 1079">Outputs a list of error.</td> </tr> <tr> <td data-bbox="346 1079 641 1124">Addr List(No.)</td> <td data-bbox="641 1079 1393 1124">Outputs address book in order IDs were added</td> </tr> <tr> <td data-bbox="346 1124 641 1169">Addr List(Idx)</td> <td data-bbox="641 1124 1393 1169">Outputs address book in order of names</td> </tr> <tr> <td data-bbox="346 1169 641 1214">One-touch List</td> <td data-bbox="641 1169 1393 1214">Outputs a list of one-touch.</td> </tr> <tr> <td data-bbox="346 1214 641 1258">Group List</td> <td data-bbox="641 1214 1393 1258">Outputs a list of group.</td> </tr> </tbody> </table> <p data-bbox="290 1326 440 1357">Completion</p> <p data-bbox="290 1361 1254 1393">Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Sys Conf Report	Outputs a list of software switches, self telephone number, confidential boxes, ROM versions and other information.	Action List	Outputs a list of error history, transmission line details and other information.	Self Sts Report	Outputs a list of settings in maintenance mode (own-status report) regarding fax transmission only.	Protocol List	Outputs a list of transmission procedures.	Error List	Outputs a list of error.	Addr List(No.)	Outputs address book in order IDs were added	Addr List(Idx)	Outputs address book in order of names	One-touch List	Outputs a list of one-touch.	Group List	Outputs a list of group.
Display	Description																				
Sys Conf Report	Outputs a list of software switches, self telephone number, confidential boxes, ROM versions and other information.																				
Action List	Outputs a list of error history, transmission line details and other information.																				
Self Sts Report	Outputs a list of settings in maintenance mode (own-status report) regarding fax transmission only.																				
Protocol List	Outputs a list of transmission procedures.																				
Error List	Outputs a list of error.																				
Addr List(No.)	Outputs address book in order IDs were added																				
Addr List(Idx)	Outputs address book in order of names																				
One-touch List	Outputs a list of one-touch.																				
Group List	Outputs a list of group.																				

Item No.	Description																		
U695	<p data-bbox="288 241 596 271">FAX function customize</p> <p data-bbox="288 311 440 340">Description</p> <p data-bbox="288 344 1428 409">Sets fax batch transmission ON/OFF. Also changes the print size priority at the time of small size reception.</p> <p data-bbox="288 414 400 443">Purpose</p> <p data-bbox="288 448 622 477">To be executed as required.</p> <p data-bbox="288 517 384 546">Setting</p> <p data-bbox="304 551 919 580">1. Select the setting using the cursor up/down keys.</p> <table border="1" data-bbox="336 595 1399 741"> <thead> <tr> <th data-bbox="336 595 639 640">Display</th> <th data-bbox="639 595 1399 640">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 640 639 685">FAX Bulk TX</td> <td data-bbox="639 640 1399 685">fax batch transmission On/Off</td> </tr> <tr> <td data-bbox="336 685 639 741">A5 Pt Pri Chg</td> <td data-bbox="639 685 1399 741">Change of print size priority at the time of small size reception</td> </tr> </tbody> </table> <p data-bbox="288 786 576 815">Setting: [FAX Bulk TX]</p> <p data-bbox="304 819 898 848">1. Select On or Off using the cursor left/right keys.</p> <table border="1" data-bbox="336 864 1399 1010"> <thead> <tr> <th data-bbox="336 864 639 909">Display</th> <th data-bbox="639 864 1399 909">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 909 639 954">On</td> <td data-bbox="639 909 1399 954">Fax batch transmission is enabled.</td> </tr> <tr> <td data-bbox="336 954 639 1010">Off</td> <td data-bbox="639 954 1399 1010">Fax batch transmission is disabled.</td> </tr> </tbody> </table> <p data-bbox="336 1016 576 1046">* : Initial setting: On</p> <p data-bbox="304 1050 782 1079">2. Press the start key. The setting is set.</p> <p data-bbox="288 1124 587 1153">Setting: [A5 Pt Pri Chg]</p> <p data-bbox="304 1158 922 1187">1. Select ON or OFF using the cursor left/right keys.</p> <table border="1" data-bbox="336 1202 1399 1348"> <thead> <tr> <th data-bbox="336 1202 639 1247">Display</th> <th data-bbox="639 1202 1399 1247">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1247 639 1292">On</td> <td data-bbox="639 1247 1399 1292">At the time of A5 size reception: A5→B5→A4</td> </tr> <tr> <td data-bbox="336 1292 639 1348">Off</td> <td data-bbox="639 1292 1399 1348">At the time of A5 size reception: A5→A4→B5</td> </tr> </tbody> </table> <p data-bbox="336 1355 576 1384">* : Initial setting: Off</p> <p data-bbox="304 1388 782 1417">2. Press the start key. The setting is set.</p> <p data-bbox="288 1462 440 1491">Completion</p> <p data-bbox="288 1496 1254 1525">Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	FAX Bulk TX	fax batch transmission On/Off	A5 Pt Pri Chg	Change of print size priority at the time of small size reception	Display	Description	On	Fax batch transmission is enabled.	Off	Fax batch transmission is disabled.	Display	Description	On	At the time of A5 size reception: A5→B5→A4	Off	At the time of A5 size reception: A5→A4→B5
Display	Description																		
FAX Bulk TX	fax batch transmission On/Off																		
A5 Pt Pri Chg	Change of print size priority at the time of small size reception																		
Display	Description																		
On	Fax batch transmission is enabled.																		
Off	Fax batch transmission is disabled.																		
Display	Description																		
On	At the time of A5 size reception: A5→B5→A4																		
Off	At the time of A5 size reception: A5→A4→B5																		

Item No.	Description																																														
U699	<p data-bbox="288 241 667 271">Setting the software switches</p> <p data-bbox="288 311 440 340">Description</p> <p data-bbox="288 344 1046 374">Sets the software switches on the FAX control PWB individually.</p> <p data-bbox="288 380 400 409">Purpose</p> <p data-bbox="288 414 1366 515">To change the setting when a problem such as split output of received originals occurs. Since the communication performance is largely affected, normally this setting need not be changed.</p> <p data-bbox="288 555 387 584">Method</p> <ol data-bbox="304 589 1390 790" style="list-style-type: none"> 1. Press the start key. 2. Press [SW No.]. 3. Enter the desired software switch number (3 digits) using the numeric keys and press the enter key. 4. Use numeric keys 7 to 0 to switch each bit between 0 and 1. 5. Press the start key to set the value. <p data-bbox="288 831 440 860">Completion</p> <p data-bbox="288 864 1254 893">Press the stop key. The screen for selecting a maintenance item No. is displayed.</p> <p data-bbox="288 934 1102 963">List of Software Switches of Which the Setting Can Be Changed</p> <p data-bbox="288 1003 762 1032"><Communication control procedure></p> <table border="1" data-bbox="336 1046 1399 2004"> <thead> <tr> <th data-bbox="336 1046 427 1090">No.</th> <th data-bbox="427 1046 592 1090">Bit</th> <th data-bbox="592 1046 1399 1090">Item</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1090 427 1189" rowspan="2">36</td> <td data-bbox="427 1090 592 1144">7654</td> <td data-bbox="592 1090 1399 1144">Coding format in transmission</td> </tr> <tr> <td data-bbox="427 1144 592 1189">3210</td> <td data-bbox="592 1144 1399 1189">Coding format in reception</td> </tr> <tr> <td data-bbox="336 1189 427 1480" rowspan="6">37</td> <td data-bbox="427 1189 592 1243">5</td> <td data-bbox="592 1189 1399 1243">33600 bps/V34</td> </tr> <tr> <td data-bbox="427 1243 592 1296">4</td> <td data-bbox="592 1243 1399 1296">31200 bps/V34</td> </tr> <tr> <td data-bbox="427 1296 592 1350">3</td> <td data-bbox="592 1296 1399 1350">28800 bps/V34</td> </tr> <tr> <td data-bbox="427 1350 592 1404">2</td> <td data-bbox="592 1350 1399 1404">26400 bps/V34</td> </tr> <tr> <td data-bbox="427 1404 592 1458">1</td> <td data-bbox="592 1404 1399 1458">24000 bps/V34</td> </tr> <tr> <td data-bbox="427 1458 592 1480">0</td> <td data-bbox="592 1458 1399 1480">21600 bps/V34</td> </tr> <tr> <td data-bbox="336 1480 427 1861" rowspan="8">38</td> <td data-bbox="427 1480 592 1534">7</td> <td data-bbox="592 1480 1399 1534">19200 bps/V34</td> </tr> <tr> <td data-bbox="427 1534 592 1588">6</td> <td data-bbox="592 1534 1399 1588">16800 bps/V34</td> </tr> <tr> <td data-bbox="427 1588 592 1641">5</td> <td data-bbox="592 1588 1399 1641">14400 bps/V34</td> </tr> <tr> <td data-bbox="427 1641 592 1695">4</td> <td data-bbox="592 1641 1399 1695">12000 bps/V34</td> </tr> <tr> <td data-bbox="427 1695 592 1749">3</td> <td data-bbox="592 1695 1399 1749">9600 bps/V34</td> </tr> <tr> <td data-bbox="427 1749 592 1803">2</td> <td data-bbox="592 1749 1399 1803">7200 bps/V34</td> </tr> <tr> <td data-bbox="427 1803 592 1856">1</td> <td data-bbox="592 1803 1399 1856">4800 bps/V34</td> </tr> <tr> <td data-bbox="427 1856 592 1861">0</td> <td data-bbox="592 1856 1399 1861">2400 bps/V34</td> </tr> <tr> <td data-bbox="336 1861 427 1915">41</td> <td data-bbox="427 1861 592 1915">3</td> <td data-bbox="592 1861 1399 1915">FSK detection in V.8</td> </tr> <tr> <td data-bbox="336 1915 427 1968" rowspan="2">42</td> <td data-bbox="427 1915 592 1968">4</td> <td data-bbox="592 1915 1399 1968">4800 bps when low-speed setting is active</td> </tr> <tr> <td data-bbox="427 1968 592 2004">2</td> <td data-bbox="592 1968 1399 2004">FIF length in transmission of more than 4 times of DIS/DTC signal</td> </tr> </tbody> </table>	No.	Bit	Item	36	7654	Coding format in transmission	3210	Coding format in reception	37	5	33600 bps/V34	4	31200 bps/V34	3	28800 bps/V34	2	26400 bps/V34	1	24000 bps/V34	0	21600 bps/V34	38	7	19200 bps/V34	6	16800 bps/V34	5	14400 bps/V34	4	12000 bps/V34	3	9600 bps/V34	2	7200 bps/V34	1	4800 bps/V34	0	2400 bps/V34	41	3	FSK detection in V.8	42	4	4800 bps when low-speed setting is active	2	FIF length in transmission of more than 4 times of DIS/DTC signal
No.	Bit	Item																																													
36	7654	Coding format in transmission																																													
	3210	Coding format in reception																																													
37	5	33600 bps/V34																																													
	4	31200 bps/V34																																													
	3	28800 bps/V34																																													
	2	26400 bps/V34																																													
	1	24000 bps/V34																																													
	0	21600 bps/V34																																													
38	7	19200 bps/V34																																													
	6	16800 bps/V34																																													
	5	14400 bps/V34																																													
	4	12000 bps/V34																																													
	3	9600 bps/V34																																													
	2	7200 bps/V34																																													
	1	4800 bps/V34																																													
	0	2400 bps/V34																																													
41	3	FSK detection in V.8																																													
42	4	4800 bps when low-speed setting is active																																													
	2	FIF length in transmission of more than 4 times of DIS/DTC signal																																													

Item No.	Description		
U699	<Communication time setting>		
	No.	Bit	Item
	53	76543210	T3 timeout setting
	54	76543210	T4 timeout setting (automatic equipment)
	55	76543210	T5 timeout setting
	60	76543210	Time before transmission of CNG (1100 Hz) signal
	63	76543210	T0 timeout setting (manual equipment)
	64	7	Phase C timeout in ECM reception
	66	76543210	Timeout 1 in countermeasures against echo
	68	76543210	Timeout for FSK detection start in V.8
	<Modem setting>		
	No.	Bit	Item
	89	76543	RX gain adjust
	<NCU setting>		
	No.	Bit	Item
	121	7654	Dial tone/busy tone detection pattern
	122	7654	Busy tone detection pattern
		1	Busy tone detection in automatic FAX/TEL switching
	125	76543210	Access code registration for connection to PSTN
126	7654	FAX/TEL automatic switching ringback tone ON/OFF cycle	
<Calling time setting>			
No.	Bit	Item	
133	76543210	DTMF signal transmission time	
134	76543210	DTMF signal pause time	
141	76543210	Ringer detection cycle (minimum)	
142	76543210	Ringer detection cycle (maximum)	
143	76543210	Ringer ON time detection	
144	76543210	Ringer OFF time detection	
145	76543210	Ringer OFF non-detection time	
147	76543210	Dial tone detection time (continuous tone)	
148	76543210	Allowable dial tone interruption time	
149	76543210	Time for transmitting selection signal after closing the DC circuit	
151	76543210	Ringer frequency detection invalid time	

Item No.	Description						
U699	<p data-bbox="288 241 531 271"><Function setting></p> <table border="1" data-bbox="336 284 1401 383"> <thead> <tr> <th data-bbox="336 284 427 329">No.</th> <th data-bbox="427 284 596 329">Bit</th> <th data-bbox="596 284 1401 329">Item</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 329 427 383">217</td> <td data-bbox="427 329 596 383">7</td> <td data-bbox="596 329 1401 383">Setting the output priority when A5 size reception</td> </tr> </tbody> </table>	No.	Bit	Item	217	7	Setting the output priority when A5 size reception
No.	Bit	Item					
217	7	Setting the output priority when A5 size reception					
U910	<p data-bbox="288 436 767 465">Clearing the digital dot coverage data</p> <p data-bbox="288 506 440 535">Description</p> <p data-bbox="288 539 1177 568">Clears the accumulated data for the digital dot coverage per A4 size paper.</p> <p data-bbox="288 575 400 604">Purpose</p> <p data-bbox="288 609 1129 638">To clear data as required at times such as during maintenance service.</p> <p data-bbox="288 678 387 707">Method</p> <ol data-bbox="304 712 1046 813" style="list-style-type: none"> <li data-bbox="304 712 564 741">1. Press the start key. <li data-bbox="304 745 906 775">2. Select [Execute] using the cursor up/down keys. <li data-bbox="304 779 1046 808">3. Press the start key. The digital dot coverage data is cleared. <p data-bbox="288 853 440 882">Completion</p> <p data-bbox="288 887 1257 916">Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>						

Item No.	Description																														
U917	<p data-bbox="288 241 746 275">Setting backup data reading/writing</p> <p data-bbox="288 309 440 342">Description</p> <p data-bbox="288 344 1423 409">Retrieves the backup data to a USB memory from the machine; or writes the data from the USB memory to the machine.</p> <p data-bbox="288 412 400 445">Purpose</p> <p data-bbox="288 448 866 481">To store and write data when replacing the HDD.</p> <p data-bbox="288 515 387 548">Method</p> <ol data-bbox="304 551 1423 824" style="list-style-type: none"> Press the power key on the operation panel, and after verifying the power indicator has gone off, switch off the main power switch. Insert USB memory in USB memory slot. Turn the main power switch on. Wait for 10 seconds to allow the machine to recognize the USB memory. Enter the maintenance item. Press the start key. Select [Export] or [Import] using the cursor up/down keys and press the start key. <table border="1" data-bbox="336 837 1399 981"> <thead> <tr> <th data-bbox="336 837 639 882">Display</th> <th data-bbox="639 837 1399 882">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 882 639 927">Import</td> <td data-bbox="639 882 1399 927">Writing data from the USB memory to the machine</td> </tr> <tr> <td data-bbox="336 927 639 981">Export</td> <td data-bbox="639 927 1399 981">Retrieving from the machine to a USB memory</td> </tr> </tbody> </table> <ol data-bbox="304 992 890 1025" style="list-style-type: none"> Select the item using the cursor up/down keys. <table border="1" data-bbox="336 1037 1399 1525"> <thead> <tr> <th data-bbox="336 1037 549 1081">Display</th> <th data-bbox="549 1037 927 1081">Description</th> <th data-bbox="927 1037 1399 1081">Depending data</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 1081 549 1126">Address Book</td> <td data-bbox="549 1081 927 1126">Address book</td> <td data-bbox="927 1081 1399 1126">-</td> </tr> <tr> <td data-bbox="336 1126 549 1171">Job Account</td> <td data-bbox="549 1126 927 1171">Job accounting</td> <td data-bbox="927 1126 1399 1171">-</td> </tr> <tr> <td data-bbox="336 1171 549 1216">One Touch</td> <td data-bbox="549 1171 927 1216">Information on one-touch key</td> <td data-bbox="927 1171 1399 1216">Address book</td> </tr> <tr> <td data-bbox="336 1216 549 1261">User</td> <td data-bbox="549 1216 927 1261">User managements</td> <td data-bbox="927 1216 1399 1261">Job accounting</td> </tr> <tr> <td data-bbox="336 1261 549 1305">Program</td> <td data-bbox="549 1261 927 1305">Program information</td> <td data-bbox="927 1261 1399 1305">Job accountings and user managements</td> </tr> <tr> <td data-bbox="336 1305 549 1350">Document Box</td> <td data-bbox="549 1305 927 1350">Document box information</td> <td data-bbox="927 1305 1399 1350">Job accountings and user managements</td> </tr> <tr> <td data-bbox="336 1350 549 1395">Fax Forward</td> <td data-bbox="549 1350 927 1395">FAX transfer information</td> <td data-bbox="927 1350 1399 1395">Job accountings, user managements and document box information</td> </tr> </tbody> </table> <p data-bbox="336 1536 1356 1601">* : Since data are dependent with each other, data other than those assigned are also retrieved or written in.</p> <ol data-bbox="304 1603 1361 1809" style="list-style-type: none"> Select [On] using the cursor left/right keys. Press the start key. Starts reading or writing. The progress of selected item is displayed in %. When an error occurs, the operation is canceled and an error code is displayed. When normally completed, [Fin] is displayed. Turn the main power switch off and on after completing writing when selecting [Import]. 	Display	Description	Import	Writing data from the USB memory to the machine	Export	Retrieving from the machine to a USB memory	Display	Description	Depending data	Address Book	Address book	-	Job Account	Job accounting	-	One Touch	Information on one-touch key	Address book	User	User managements	Job accounting	Program	Program information	Job accountings and user managements	Document Box	Document box information	Job accountings and user managements	Fax Forward	FAX transfer information	Job accountings, user managements and document box information
Display	Description																														
Import	Writing data from the USB memory to the machine																														
Export	Retrieving from the machine to a USB memory																														
Display	Description	Depending data																													
Address Book	Address book	-																													
Job Account	Job accounting	-																													
One Touch	Information on one-touch key	Address book																													
User	User managements	Job accounting																													
Program	Program information	Job accountings and user managements																													
Document Box	Document box information	Job accountings and user managements																													
Fax Forward	FAX transfer information	Job accountings, user managements and document box information																													

Item No.	Description			
U917	Error Codes			
	Codes	Description	Codes	Description
	e002	Parameter error	e31e	User managements error
	e003	File write error	e31f	User managements open error
	e004	File initialization error	e320	User managements error
	e005	File error	e410	Box file open error
	e006	Processing error	e411	Box error in writing
	e010	Address book clear error (contact)	e412	Box error in reading
	e011	Address book open error (contact)	e413	Box list error
	e012	Address book list error (contact)	e414	Box list error
	e013	Address book list error (contact)	e415	Box error
	e014	Address book clear error (group)	e416	Box error
	e015	Address book open error (group)	e417	Box open error
	e016	Address book list error (group)	e418	Box close error
	e017	Address book list error (group)	e419	Box creation error
	e110	Job accounting clear error	e41a	Box creation error
	e111	Job accounting open error	e41b	Box deletion error
	e112	Job accounting open error	e41c	Box movement error
	e113	Job accounting error in writing	e510	Program error in writing
	e114	Job accounting list error	e511	Program error in reading
	e115	Job accounting list error	e710	Fax memory open error
	e210	One-touch open error	e711	Fax memory initialization error
	e211	One-touch list error	e712	Fax memory list error
	e212	One-touch list error	e713	Fax memory error
	e310	User managements backup error	e714	Fax memory error
	e311	User managements clear error	e715	Fax memory mode error
	e312	User managements open error	e716	Fax memory error
	e313	User managements open error	e717	Fax memory error
	e314	User managements open error	e718	Fax memory mode error
	e315	User managements error in writing	e910	File reading error
	e316	User managements list error	e911	File writing error
	e317	User managements list error	e912	Data mismatch
	e318	User managements list error	e913	Log file open error
	e319	User managements list error	e914	Log file error in writing
	e31a	User managements open error	e915	Directory open error
	e31b	User managements error	e916	Directory error in reading
	e31c	User managements error	e917	Synchronization error
	e31d	User managements open error	e918	Synchronization error

Item No.	Description			
U917	Error Codes			
	Codes	Description	Codes	Description
	d000	Unspecified error	d00b	File reading error
	d001	HDD unavailable	d00c	File writing error
	d002	USB memory is not inserted	d00d	File copy error
	d003	File for writing is not found in the USB	d00e	File compressed error
	d004	File for reading is not found in the HDD	d00f	File decompressed error
	d005	USB error in writing	d010	Directory open error
	d006	USB error in reading	d011	Directory creation error
	d007	USB unmount error	d012	File writing error
	d008	File rename error	d013	File reading error
	d009	File open error	d014	File deletion error
	d00a	File close error	d015	File copy error to the USB
	Supplement			
	The following restrictions apply to the data which were imported from 4 in 1 models (with FAX) to 3 in 1 models (without FAX).			
Personal address book: FAX-related data are not imported.				
Group address book: Group addresses including FAX addresses are not imported.				
Job accounting data: Initial values are added for FAX-related data.				
One-touch data: Groups assigned with FAX addresses or those including FAX are not imported.				
User management data: Initial values are added for out-going FAXes of authentication.				
Program data: Not imported. (The same applies when data are imported from 3 in 1 to 4 in 1 models.)				
Completion				
Press the stop key. The screen for selecting a maintenance item No. is displayed.				


Item No.	Description												
U920	<p>Checking the copy counts</p> <p>Description Checks the copy counts.</p> <p>Purpose To check the copy counts.</p> <p>Method 1. Press the start key. The current counts are displayed.</p> <table border="1" data-bbox="336 562 1401 851"> <thead> <tr> <th data-bbox="336 562 639 607">Display</th> <th data-bbox="639 562 1401 607">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="336 607 639 651">Color Copy</td> <td data-bbox="639 607 1401 651">Count value of color copy</td> </tr> <tr> <td data-bbox="336 651 639 696">B/W Copy</td> <td data-bbox="639 651 1401 696">Count value of black/white copy</td> </tr> <tr> <td data-bbox="336 696 639 741">Color Prn</td> <td data-bbox="639 696 1401 741">Count value of color print</td> </tr> <tr> <td data-bbox="336 741 639 786">B/W Prn</td> <td data-bbox="639 741 1401 786">Count value of black/white print</td> </tr> <tr> <td data-bbox="336 786 639 831">B/W Fax</td> <td data-bbox="639 786 1401 831">Count value of black/white FAX</td> </tr> </tbody> </table> <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Color Copy	Count value of color copy	B/W Copy	Count value of black/white copy	Color Prn	Count value of color print	B/W Prn	Count value of black/white print	B/W Fax	Count value of black/white FAX
Display	Description												
Color Copy	Count value of color copy												
B/W Copy	Count value of black/white copy												
Color Prn	Count value of color print												
B/W Prn	Count value of black/white print												
B/W Fax	Count value of black/white FAX												
U927	<p>Clearing the all copy counts and machine life counts (one time only)</p> <p>Description Resets all of the counts back to zero.</p> <p>Supplement The total account counter and the machine life counter can be cleared only once if all count values are 1000 or less.</p> <p>Method 1. Press the start key. 2. Select [Execute] using the cursor up/down keys. 3. Press the start key. All copy counts and machine life counts are cleared.</p> <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>												

Item No.	Description				
U928	<p>Checking machine life counts</p> <p>Description Displays the machine life counts.</p> <p>Purpose To check the machine life counts.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. The current machine life counts is displayed. <table border="1" data-bbox="338 562 1401 658"> <thead> <tr> <th data-bbox="338 562 639 607">Display</th> <th data-bbox="639 562 1401 607">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="338 607 639 658">Life Cont</td> <td data-bbox="639 607 1401 658">Machine life counts</td> </tr> </tbody> </table> <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Life Cont	Machine life counts
Display	Description				
Life Cont	Machine life counts				
U977	<p>Data capture mode</p> <p>Description Store the print data sent to the machine into USB memory.</p> <p>Purpose In case to occur the error at printing, check the print data sent to the machine.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Insert USB memory in USB memory slot. 2. Turn the main power switch on. 3. Enter the maintenance item. 4. Press the start key. 5. Select [Execute]. 6. Press the start key. 7. Send the print data to the machine. <p>Once the print data is stored into USB memory, [OK] will be displayed.</p> <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>				
U995	<p>Memory data Individual setting</p> <p>Description Displays the memory data.</p> <p>Purpose This mode need not be executed. When the status report is output, the setting is displayed.</p> <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>				

1-3-2 Service mode

The machine is equipped with a maintenance function which can be used to maintain and service the machine.

(1) Executing a service mode



(2) Description of service mode

Service items	Description
Service Status	<p>Printing a status page for service purpose</p> <p>Description Prints a status page for service purpose. The status page includes various settings and service cumulative.</p> <p>Purpose To acquire the current printing environmental parameters and cumulative information.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Enter the Service Setting menu. 2. Select [Service Status] using the cursor up/down keys. 3. Press the start key. 4. Press [Yes] (the Left Select key). Two pages will be printed. <p>Completion Press the stop key.</p>

Service items	Description															
	<p>Service status page (1)</p> <div style="border: 1px solid black; padding: 10px;"> <h3 style="text-align: center;">Service Status Page</h3> <p>MFP (2) 06/04/2010 12:00</p> <p>(1) Firmware version 2KX_2000.000.000 2010.04.06 (3) [XXXXXXXX] (4) [XXXXXXXX] (5) [XXXXXXXX]</p> <hr/> <p>Controller Information</p> <p>Memory status</p> <table style="width: 100%;"> <tr> <td>(7) Standard Size</td> <td>128.0 KB</td> <td>(26) FRPO Status</td> <td></td> <td></td> </tr> <tr> <td>(8) Option Slot</td> <td>128.0 KB</td> <td>User Top Margin</td> <td>A1+A2/100</td> <td>0.00</td> </tr> <tr> <td>(9) Total Size</td> <td>256.0 KB</td> <td>User Left Margin</td> <td>A3+A4/100</td> <td>0.00</td> </tr> </table> <p>Time</p> <p>(10) Local Time Zone +01:00 Tokio</p> <p>(11) Date and Time 06/04/2010 12:00</p> <p>(12) Time Server 10.183.53.13</p> <p>Installed Options</p> <p>(13) Paper feeder Cassette</p> <p>(14) Card Authentication Kit (B) Installed</p> <p>Digital Dot Coverage</p> <p>(15) Average(%) / Usage Page(A4/Letter Conversion)</p> <p>(16) Total</p> <p style="margin-left: 20px;">K: 1.10 / 1111111.11</p> <p style="margin-left: 20px;">C: 2.20 / 2222222.22</p> <p style="margin-left: 20px;">M: 3.30 / 3333333.33</p> <p style="margin-left: 20px;">Y: 4.40 / 4444444.44</p> <p>(17) Copy</p> <p style="margin-left: 20px;">K: 1.10 / 1111111.11</p> <p style="margin-left: 20px;">C: 2.20 / 2222222.22</p> <p style="margin-left: 20px;">M: 3.30 / 3333333.33</p> <p style="margin-left: 20px;">Y: 4.40 / 4444444.44</p> <p>(18) Printer</p> <p style="margin-left: 20px;">K: 1.10 / 1111111.11 PDF mode Y5 00</p> <p style="margin-left: 20px;">C: 2.20 / 2222222.22</p> <p style="margin-left: 20px;">M: 3.30 / 3333333.33</p> <p style="margin-left: 20px;">Y: 4.40 / 4444444.44</p> <p>(19) FAX</p> <p style="margin-left: 20px;">K: 1.10 / 1111111.11</p> <p>(20) Period (27/10/2009 - 03/11/2009 08:40)</p> <p>(21) Last Page K/C/M/Y(%) 1.00 / 2.22 / 3.33 / 4.44</p> <p>FAX Information</p> <p>(22) Rings (Normal) 3</p> <p>(23) Rings (FAX/TEL) 3</p> <p>(24) Rings (TAD) 3</p> <p>(25) Option DIMM Size 16 MB</p> <hr/> <p style="text-align: center;">1 (6) [XXXXXXXXXXXXXXXXXXXX]</p> </div>	(7) Standard Size	128.0 KB	(26) FRPO Status			(8) Option Slot	128.0 KB	User Top Margin	A1+A2/100	0.00	(9) Total Size	256.0 KB	User Left Margin	A3+A4/100	0.00
(7) Standard Size	128.0 KB	(26) FRPO Status														
(8) Option Slot	128.0 KB	User Top Margin	A1+A2/100	0.00												
(9) Total Size	256.0 KB	User Left Margin	A3+A4/100	0.00												

Figure 1-3-4



Service items	Description	
	Detail of service status page	
No.	Description	Supplement
(1)	Firmware version	-
(2)	System date	-
(3)	Engine soft version	-
(4)	Engine boot version	-
(5)	Operation panel mask version	-
(6)	Machine serial number	-
(7)	Standard memory size	-
(8)	Optional memory size	-
(9)	Total memory size	-
(10)	Local time zone	-
(11)	Report output date	Day/Month/Year hour:minute
(12)	NTP server name	-
(13)	Presence or absence of the optional paper feeder	Paper feeder 1/Paper feeder 2/Not Installed
(14)	Presence or absence of the optional IC card authentication kit	Installed/Not Installed/Trial
(15)	Page of relation to the A4/Letter	-
(16)	Average coverage for total	Black/Cyan/Magenta/Yellow
(17)	Average coverage for copy	Black/Cyan/Magenta/Yellow
(18)	Average coverage for printer	Black/Cyan/Magenta/Yellow
(19)	Average coverage for fax	Black/Cyan/Magenta/Yellow
(20)	Cleared date and output date	-
(21)	Coverage on the final output page	-
(22)	Number of rings	0 to 15
(23)	Number of rings before auto-automatic switching	0 to 15
(24)	Number of rings before connecting to answering machine	0 to 15
(25)	Optional DIMM size	-
(26)	FRPO setting	-


Service items	Description				
	<table border="1"> <thead> <tr> <th data-bbox="295 286 386 331">No.</th> <th data-bbox="386 286 794 331">Description</th> <th data-bbox="794 286 1417 331">Supplement</th> </tr> </thead> </table>	No.	Description	Supplement	
No.	Description	Supplement			
	(27) NV RAM version	<p>_ 1F3 1225 _ 1F3 1225 (a) (b) (c) (d) (e) (f)</p> <p>(a) Consistency of the present software version and the database _ (underscore): OK * (Asterisk): NG</p> <p>(b) Database version</p> <p>(c) The oldest time stamp of database version</p> <p>(d) Consistency of the present software version and the ME firmware version _ (underscore): OK * (Asterisk): NG</p> <p>(e) ME firmware version</p> <p>(f) The oldest time stamp of the ME database version</p> <p>Normal if (a) and (d) are underscored, and (b) and (e) are identical with (c) and (f).</p>			
	(28) Scanner firmware version	-			
	(29) Fax firmware version	-			
	(30) Mac address	-			
	(31) Number of original feed from DP	-			
	(32) The last sent date and time	-			
	(33) Transmission address	-			
	(34) Destination information	-			
	(35) Area information	-			
	(36) Margin settings	Top margin/Left margin			
	(37) Top offset for each paper source	MP tray/Cassette 2/Cassette 3/Duplex/ Page rotation			
	(38) Left offset for each paper source	MP tray/Cassette 2/Cassette 3/Duplex/ Page rotation			
	(39) Margin/Page length/Page width settings	Top margin integer part/Top margin decimal part/ Left margin integer part/Left margin decimal part/ Page length integer part/Page length decimal part/ Page width integer part/Page width decimal part			
	(40) Life counter (The first line)	Machine life/MP tray/Cassette 1/Cassette 2/ Cassette 3 /Duplex			
	Life counter (The second line)	Maintenance kit			

Service items	Description																			
	No.	Description																		
		Supplement																		
(41)	Panel lock information	0: OFF/1: Partial lock/2: Full lock																		
(42)	USB information	U00: Not installed/U01: Full speed/U02: Hi speed																		
(43)	Paper handling information	0: Paper source unit select/1: Paper source unit																		
(44)	Color printing double count mode	0: All single counts 3: Folio, Single count, Less than 330 mm (length)																		
(45)	Black and white printing double count mode	0: All single counts 3: Folio, Single count, Less than 330 mm (length)																		
(46)	Billing counting timing	-																		
(47)	Temperature (machine inside)	-																		
(48)	Temperature (machine outside)	-																		
(49)	Relative temperature (machine outside)	-																		
(50)	Absolute temperature (machine outside)	-																		
(51)	Fixed assets number	-																		
(52)	Job end judgment time-out time	-																		
(53)	Job end detection mode	-																		
(54)	Media type attributes 1 to 28 (Not used: 18, 19, 20)	<table border="0"> <tr> <td>Weight settings</td> <td>Fuser settings</td> </tr> <tr> <td>0: Light</td> <td>0: High</td> </tr> <tr> <td>1: Normal 1</td> <td>1: Middle</td> </tr> <tr> <td>2: Normal 2</td> <td>2: Low</td> </tr> <tr> <td>3: Normal 3</td> <td>3: Vellum</td> </tr> <tr> <td>4: Heavy 1</td> <td>Duplex settings</td> </tr> <tr> <td>5: Heavy 2</td> <td>0: Disable</td> </tr> <tr> <td>6: Heavy 3</td> <td>1: Enable</td> </tr> <tr> <td>7: Extra Heavy</td> <td></td> </tr> </table>	Weight settings	Fuser settings	0: Light	0: High	1: Normal 1	1: Middle	2: Normal 2	2: Low	3: Normal 3	3: Vellum	4: Heavy 1	Duplex settings	5: Heavy 2	0: Disable	6: Heavy 3	1: Enable	7: Extra Heavy	
Weight settings	Fuser settings																			
0: Light	0: High																			
1: Normal 1	1: Middle																			
2: Normal 2	2: Low																			
3: Normal 3	3: Vellum																			
4: Heavy 1	Duplex settings																			
5: Heavy 2	0: Disable																			
6: Heavy 3	1: Enable																			
7: Extra Heavy																				
(55)	Calibration information	Black/Cyan/Magenta/Yellow																		
(56)	RFID information	-																		
(57)	RFID reader/writer version information	-																		
(58)	Toner install mode information	0: Off t: On																		
(59)	Soft version of the optional paper feeder	Cassette 2/Cassette 3																		
(60)	Version of the optional message	-																		
(61)	Color table version	-																		
(62)	Maintenance information	-																		

Service items	Description																																																																															
	<table border="1"> <thead> <tr> <th data-bbox="296 288 384 331">No.</th> <th data-bbox="389 288 796 331">Description</th> <th colspan="8" data-bbox="801 288 1422 331">Supplement</th> </tr> </thead> <tbody> <tr> <td data-bbox="296 338 384 454">(63)</td> <td data-bbox="389 338 796 454">Altitude</td> <td colspan="8" data-bbox="801 338 1422 454">0: Standard 1: High altitude 1 2: High altitude 2</td> </tr> <tr> <td data-bbox="296 461 384 501">(64)</td> <td data-bbox="389 461 796 501">Main charger correction</td> <td colspan="8" data-bbox="801 461 1422 501">1 to 5</td> </tr> <tr> <td data-bbox="296 508 384 548">(65)</td> <td data-bbox="389 508 796 548">Drum serial number</td> <td colspan="8" data-bbox="801 508 1422 548">Black/Cyan/Magenta/Yellow</td> </tr> <tr> <td colspan="2" data-bbox="296 555 796 792" style="text-align: center;">Code conversion</td> <td colspan="8" data-bbox="539 633 1222 730"> <table border="1"> <thead> <tr> <th data-bbox="539 633 608 674">A</th> <th data-bbox="612 633 681 674">B</th> <th data-bbox="686 633 754 674">C</th> <th data-bbox="759 633 828 674">D</th> <th data-bbox="833 633 901 674">E</th> <th data-bbox="906 633 975 674">F</th> <th data-bbox="979 633 1048 674">G</th> <th data-bbox="1053 633 1121 674">H</th> <th data-bbox="1126 633 1195 674">I</th> <th data-bbox="1200 633 1268 674">J</th> </tr> </thead> <tbody> <tr> <td data-bbox="539 680 608 721">0</td> <td data-bbox="612 680 681 721">1</td> <td data-bbox="686 680 754 721">2</td> <td data-bbox="759 680 828 721">3</td> <td data-bbox="833 680 901 721">4</td> <td data-bbox="906 680 975 721">5</td> <td data-bbox="979 680 1048 721">6</td> <td data-bbox="1053 680 1121 721">7</td> <td data-bbox="1126 680 1195 721">8</td> <td data-bbox="1200 680 1268 721">9</td> </tr> </tbody> </table> </td> </tr> </tbody> </table>										No.	Description	Supplement								(63)	Altitude	0: Standard 1: High altitude 1 2: High altitude 2								(64)	Main charger correction	1 to 5								(65)	Drum serial number	Black/Cyan/Magenta/Yellow								Code conversion		<table border="1"> <thead> <tr> <th data-bbox="539 633 608 674">A</th> <th data-bbox="612 633 681 674">B</th> <th data-bbox="686 633 754 674">C</th> <th data-bbox="759 633 828 674">D</th> <th data-bbox="833 633 901 674">E</th> <th data-bbox="906 633 975 674">F</th> <th data-bbox="979 633 1048 674">G</th> <th data-bbox="1053 633 1121 674">H</th> <th data-bbox="1126 633 1195 674">I</th> <th data-bbox="1200 633 1268 674">J</th> </tr> </thead> <tbody> <tr> <td data-bbox="539 680 608 721">0</td> <td data-bbox="612 680 681 721">1</td> <td data-bbox="686 680 754 721">2</td> <td data-bbox="759 680 828 721">3</td> <td data-bbox="833 680 901 721">4</td> <td data-bbox="906 680 975 721">5</td> <td data-bbox="979 680 1048 721">6</td> <td data-bbox="1053 680 1121 721">7</td> <td data-bbox="1126 680 1195 721">8</td> <td data-bbox="1200 680 1268 721">9</td> </tr> </tbody> </table>								A	B	C	D	E	F	G	H	I	J	0	1	2	3	4	5	6	7	8	9
No.	Description	Supplement																																																																														
(63)	Altitude	0: Standard 1: High altitude 1 2: High altitude 2																																																																														
(64)	Main charger correction	1 to 5																																																																														
(65)	Drum serial number	Black/Cyan/Magenta/Yellow																																																																														
Code conversion		<table border="1"> <thead> <tr> <th data-bbox="539 633 608 674">A</th> <th data-bbox="612 633 681 674">B</th> <th data-bbox="686 633 754 674">C</th> <th data-bbox="759 633 828 674">D</th> <th data-bbox="833 633 901 674">E</th> <th data-bbox="906 633 975 674">F</th> <th data-bbox="979 633 1048 674">G</th> <th data-bbox="1053 633 1121 674">H</th> <th data-bbox="1126 633 1195 674">I</th> <th data-bbox="1200 633 1268 674">J</th> </tr> </thead> <tbody> <tr> <td data-bbox="539 680 608 721">0</td> <td data-bbox="612 680 681 721">1</td> <td data-bbox="686 680 754 721">2</td> <td data-bbox="759 680 828 721">3</td> <td data-bbox="833 680 901 721">4</td> <td data-bbox="906 680 975 721">5</td> <td data-bbox="979 680 1048 721">6</td> <td data-bbox="1053 680 1121 721">7</td> <td data-bbox="1126 680 1195 721">8</td> <td data-bbox="1200 680 1268 721">9</td> </tr> </tbody> </table>								A	B	C	D	E	F	G	H	I	J	0	1	2	3	4	5	6	7	8	9																																																			
A	B	C	D	E	F	G	H	I	J																																																																							
0	1	2	3	4	5	6	7	8	9																																																																							
Network Status	<p data-bbox="384 848 823 882">Printing a status page for network</p> <p data-bbox="384 920 539 949">Description</p> <p data-bbox="384 956 772 985">Prints a status page for network.</p> <p data-bbox="384 992 497 1021">Purpose</p> <p data-bbox="384 1028 994 1057">To acquire the detailed network setting information.</p> <p data-bbox="384 1095 485 1124">Method</p> <ol data-bbox="405 1131 1251 1263" style="list-style-type: none"> 1. Enter the Service Setting menu. 2. Select [Network Status] using the cursor up/down keys. 3. Press the start key. 4. Press [Yes] (the Left Select key). Network status page will be printed. <p data-bbox="384 1301 539 1330">Completion</p> <p data-bbox="384 1337 616 1366">Press the stop key.</p>																																																																															

Service items	Description
Test Page	<p>Printing a test page</p> <p>Description Four colors are printed respectively with halftones of three different levels.</p> <p>Purpose To check the activation of the developer and drum units of four colors.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Enter the Service Setting menu. 2. Select [Test Page] using the cursor up/down keys. 3. Press the start key. 4. Press [Yes] (the Left Select key). Test page will be printed. <div data-bbox="507 712 1316 1288" style="text-align: center;"> </div> <p>*1: Since focusing in yellow is hardly readable, yellow is mixed with cyan for more readability, resulting in green.</p> <p>*2: Each portion of colors has three different magnitude of halftones (bands). If focus is excessively lost, dots are not recognizable with the 16/256 band, resulting in uneven density. It also results in vertical streaks in the 24/256 and/or 32/256 bands.</p> <p style="text-align: center;">Figure 1-3-6</p> <p>Completion Press the stop key.</p>

Service items	Description
Developer Setting	<p>Entering initial value for replacing the developing unit</p> <p>Description After replacing the developing unit, enter the initial value (6-digit data) assigned on a label attached to the package or developing unit.</p> <p>Purpose To set the initial value after replacing the developing unit.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Enter the Service Setting menu. 2. Select [DeveloperSetting] using the cursor up/down keys. 3. Press the start key. Enter the initial value (6-digit data) using the cursor up/down keys. 4. Press the start key. The initial value is set. <div data-bbox="534 784 1287 1279" style="text-align: center;"> <p>The diagram illustrates the location of the initial value label. On the left is a 'Developing unit' with a label on its top surface. On the right is a 'Package' with a label on its side. A callout box labeled 'Label' shows the label's content: a QR code, the code '128F1E', and the model number 'DV560Y'.</p> </div> <p>Figure 1-3-7</p> <p>Completion Press the stop key.</p>

Service items	Description
Developer Refresh	<p>Performing developer refresh</p> <p>Description The laser output of the image data for developer refreshing is carried out, and operation to exposure, developing, and primary transfer is performed by 10 pages (paper is not fed).</p> <p>Purpose To perform cleaning when faulty images occur and a line appears longitudinally.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Enter the Service Setting menu. 2. Select [DeveloperRefresh] using the cursor up/down keys. 3. Press the start key. 4. Press [Yes] (the Left Select key). Developer refresh is performed. <div data-bbox="651 792 1173 1478" style="text-align: center;"> <p>A4 paper size</p>  <p>Toner image on the transfer belt</p> </div> <p>Figure 1-3-8</p> <p>Completion Press the stop key.</p>

Service items	Description
Laser Scanner Cleaning	<p>Performing LSU cleaning</p> <p>Description The LSU cleaning motor drives the cleaning pad which in turn wipes clean the LSU dust shield glass.</p> <p>Purpose To perform cleaning when the printed image is bad and stripes are seen in the vertical direction.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Enter the Service Setting menu. 2. Select [LaserScanner Cln] using the cursor up/down keys. 3. Press the start key. 4. Press [Yes] (the Left Select key). LSU cleaning is performed. <p>Completion Press the stop key.</p>
Drum surface refreshing	<p>Performing drum surface refreshing</p> <p>Description Rotates the drum approximately 2 minutes with toner lightly on the overall drum. The cleaning blade in the drum unit scrapes toner off the drum surface to clean it.</p> <p>Purpose To clean the drum surface when image failure occurs due to the drum. This mode is effective when dew condensation on the drum occurs.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Enter the Service Setting menu. 2. Select [Drum Refresh] using the cursor up/down keys. 3. Press the start key. 4. Press [Yes] (the Left Select key). Drum surface refreshing is performed. <p>Completion Press the stop key.</p>

Service items	Description
Altitude adjustment	<p>Setting altitude adjustment</p> <p>Description Sets the altitude adjustment mode.</p> <p>Purpose Used when print quality deteriorates in an installation at the altitude of 1,500 meters or higher.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Enter the Service Setting menu. 2. Select [Altitude Adj.] using the cursor up/down keys. 3. Press the start key. 4. Select [Normal], [High 1] or [High 2]) using the cursor up/down keys. 5. Press the start key. The setting is set. <p>Completion Press the stop key.</p>
Main charger adjustment	<p>Setting main charger output</p> <p>Description Sets the main charger output. This is executable only when the altitude adjustment mode is set to [Normal].</p> <p>Purpose Execute when the image density declines or an offset has occurred.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Enter the Service Setting menu. 2. Select [MC] using the cursor up/down keys. 3. Press the start key. 4. Select [1], [2] or [3] using the cursor up/down keys. 5. Press the start key. The setting is set. <p>Completion Press the stop key.</p>

Service items	Description																																																																												
FAX country code	<p>FAX Country Code</p> <p>Description Initializes software switches and all data in the backup data on the FAX control PWB, according to the destination.</p> <p>Purpose To initialize the FAX control PWB.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Enter the Service Setting menu. 2. Select [FAX Country Code] using the cursor up/down keys. 3. Press the start key. 4. Enter a destination code using the numeric keys. 5. Press the start key. The setting is set. 6. Press the start key. Data initialization starts. <p>Destination code list</p> <table border="1" data-bbox="437 840 1385 1749"> <thead> <tr> <th>Code</th> <th>Destination</th> <th>Code</th> <th>Destination</th> </tr> </thead> <tbody> <tr> <td>000</td> <td>Japan</td> <td>253</td> <td>CTR21 (European nations)</td> </tr> <tr> <td>009</td> <td>Australia</td> <td></td> <td>Italy</td> </tr> <tr> <td>038</td> <td>China</td> <td></td> <td>Germany</td> </tr> <tr> <td>080</td> <td>Hong Kong</td> <td></td> <td>Spain</td> </tr> <tr> <td>084</td> <td>Indonesia</td> <td></td> <td>U.K.</td> </tr> <tr> <td>088</td> <td>Israel</td> <td></td> <td>Netherlands</td> </tr> <tr> <td>097</td> <td>Korea</td> <td></td> <td>Sweden</td> </tr> <tr> <td>108</td> <td>Malaysia</td> <td></td> <td>France</td> </tr> <tr> <td>126</td> <td>New Zealand</td> <td></td> <td>Austria</td> </tr> <tr> <td>136</td> <td>Peru</td> <td></td> <td>Switzerland</td> </tr> <tr> <td>137</td> <td>Philippines</td> <td></td> <td>Belgium</td> </tr> <tr> <td>152</td> <td>Middle East</td> <td></td> <td>Denmark</td> </tr> <tr> <td>156</td> <td>Singapore</td> <td></td> <td>Finland</td> </tr> <tr> <td>159</td> <td>South Africa</td> <td></td> <td>Portugal</td> </tr> <tr> <td>169</td> <td>Thailand</td> <td></td> <td>Ireland</td> </tr> <tr> <td>181</td> <td>U.S.A.</td> <td></td> <td>Norway</td> </tr> <tr> <td>242</td> <td>South America</td> <td>254</td> <td>Taiwan</td> </tr> <tr> <td>243</td> <td>Saudi Arabia</td> <td></td> <td></td> </tr> </tbody> </table> <p>Completion Press the stop key.</p>	Code	Destination	Code	Destination	000	Japan	253	CTR21 (European nations)	009	Australia		Italy	038	China		Germany	080	Hong Kong		Spain	084	Indonesia		U.K.	088	Israel		Netherlands	097	Korea		Sweden	108	Malaysia		France	126	New Zealand		Austria	136	Peru		Switzerland	137	Philippines		Belgium	152	Middle East		Denmark	156	Singapore		Finland	159	South Africa		Portugal	169	Thailand		Ireland	181	U.S.A.		Norway	242	South America	254	Taiwan	243	Saudi Arabia		
Code	Destination	Code	Destination																																																																										
000	Japan	253	CTR21 (European nations)																																																																										
009	Australia		Italy																																																																										
038	China		Germany																																																																										
080	Hong Kong		Spain																																																																										
084	Indonesia		U.K.																																																																										
088	Israel		Netherlands																																																																										
097	Korea		Sweden																																																																										
108	Malaysia		France																																																																										
126	New Zealand		Austria																																																																										
136	Peru		Switzerland																																																																										
137	Philippines		Belgium																																																																										
152	Middle East		Denmark																																																																										
156	Singapore		Finland																																																																										
159	South Africa		Portugal																																																																										
169	Thailand		Ireland																																																																										
181	U.S.A.		Norway																																																																										
242	South America	254	Taiwan																																																																										
243	Saudi Arabia																																																																												

Service items	Description								
FAX call Setting	<p>FAX call setting</p> <p>Description Selects if a fax is to be connected to either a PBX or public switched telephone network. Selects the mode to connect an outside call when connected to a PBX. Access code registration for connection to PSTN.</p> <p>Purpose To be executed as required.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Enter the Service Setting menu. 2. Select [FAX Call Set.] using the cursor up/down keys. 3. Press the start key. <table border="1" data-bbox="437 701 1385 893"> <thead> <tr> <th data-bbox="437 701 703 745">Display</th> <th data-bbox="703 701 1385 745">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="437 745 703 790">Exchange Select.</td> <td data-bbox="703 745 1385 790">Setting the connection to PBX/PSTN</td> </tr> <tr> <td data-bbox="437 790 703 835">PBX Setting</td> <td data-bbox="703 790 1385 835">Setting for a PBX</td> </tr> <tr> <td data-bbox="437 835 703 880">Dial No. to PSTN</td> <td data-bbox="703 835 1385 880">Setting access code to PSTN</td> </tr> </tbody> </table> <p>Setting the connection to PBX/PSTN</p> <ol style="list-style-type: none"> 1. Select [Exchange Select.] using the cursor up/down keys. 2. Press the start key. 3. Select [PBX] or [PSTN] using the cursor up/down keys. 4. Press the start key. The setting is set. <p>Setting for PBX</p> <ol style="list-style-type: none"> 1. Select [PBX Setting] using the cursor up/down keys. 2. Press the start key. 3. Select [Loop], [Flash] or [Earth] using the cursor up/down keys. 4. Press the start key. The setting is set. <p>Setting access code to PSTN</p> <ol style="list-style-type: none"> 1. Select [Dial No. to PSTN] using the cursor up/down keys. 2. Press the start key. 3. Enter access code using the numeric keys. (0 to 9, 00 to 99) 4. Press the start key. The setting is set. <p>Completion Press the stop key.</p>	Display	Description	Exchange Select.	Setting the connection to PBX/PSTN	PBX Setting	Setting for a PBX	Dial No. to PSTN	Setting access code to PSTN
Display	Description								
Exchange Select.	Setting the connection to PBX/PSTN								
PBX Setting	Setting for a PBX								
Dial No. to PSTN	Setting access code to PSTN								

Service items	Description
Remote diagnostics	<p>Setting remote diagnostics</p> <p>Description Sets the remote diagnostics.</p> <p>Purpose Used to establish communication between the machine and the service facility when a problem is encountered.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Enter the Service Setting menu. 2. Select [Remote Diag.Set.] using the cursor up/down keys. 3. Press the start key. 4. Select [On] using the cursor up/down keys. 5. Press the start key. The setting is set. 6. Select [Remote Diag. ID] using the cursor up/down keys. 7. Press the start key. 8. Enter the prespecified remote diagnostics ID number (0000 to 9999) using the numeric keys. 9. Press the start key. The setting is set. <p>Completion Press the stop key.</p>

This page is intentionally left blank.

1-4-1 Paper misfeed detection

(1) Paper misfeed indication

When a paper misfeed occurs, the machine immediately stops printing and displays the paper misfeed message on the operation panel. To remove paper misfed in the machine, pull out the cassette, open the rear cover or paper conveying unit.




Figure 1-4-1 Paper misfeed indication

(2) Paper misfeed detection condition





Figure 1-4-2 Paper jam location

Code	Contents	Conditions	Jam location*
0100	Controller sequence error	Secondary paper feed request given by the controller is unreachable.	C
0105	Registration sensor not detected	Activation of the registration sensor (on/off) is undetected for 90 s during printing.	-
0106	Controller sequence error	Paper feeding request for duplex printing given by the controller is unreachable.	E
0110	Top tray open	The top tray is opened during printing.	-
0111	Rear cover open	The rear cover is opened during printing.	-
0112	Front cover open	The waste toner cover is opened during printing.	-
0113	MP tray open	The MP tray is opened during printing.	-
0120	Controller sequence error	Paper feed request was received from the duplex section despite the absence of paper in the duplex section.	E
0121	Controller sequence error	The controller issued the duplex section a request for more pages than the duplex print cycle contains.	E
0211	Rear cover open (paper feeder 1)	The rear cover of paper feeder 1 is opened during printing.	-
0212	Rear cover open (paper feeder 2)	The rear cover of paper feeder 2 is opened during printing.	-
0501	No paper feed from cassette 1	The registration sensor (RS) does not turn on during paper feed from cassette.	A
0502	No paper feed from cassette 2	PF feed sensor 1 (PFFS1) does not turn on during paper feed from paper feeder 1.	F
0503	No paper feed from cassette 3	PF feed sensor 2 (PFFS2) does not turn on during paper feed from paper feeder 2.	G
0508	No paper feed from duplex section	The registration sensor (RS) does not turn on during paper feed from duplex section.	E
0509	No paper feed from MP tray	MP feed sensor (MPFS) does not turn on during paper feed from MP tray.	B
0511	Multiple sheets in cassette 1	The registration sensor (RS) does not turn off during paper feed from cassette.	A
0512	Multiple sheets in cassette 2	PF feed sensor 1 (PFFS1) does not turn off during paper feed from paper feeder 1.	F
0513	Multiple sheets in cassette 3	PF feed sensor 2 (PFFS2) does not turn off during paper feed from paper feeder 2.	G
0518	Multiple sheets in duplex section	The registration sensor (RS) does not turn off during paper feed from duplex section.	E
0519	Multiple sheets in MP tray	MP feed sensor (MPFS) does not turn off during paper feed from MP tray.	B

*: Refer to figure 1-4-2 for paper jam location (see page 1-4-2).

Code	Contents	Conditions	Jam location*
1020	MP feed sensor is turned ON	MP feed sensor (MPFS) is turned on when the power is turned on.	B
1403	PF feed sensor 1 does not turn ON	PF feed sensor 1 (PFFS1) does not turn on during paper feed from paper feeder 2.	F
1413	PF feed sensor 1 does not turn OFF	PF feed sensor 1 (PFFS1) does not turn off during paper feed from paper feeder 2.	F
1420	PF feed sensor 1 is turned ON	PF feed sensor 1 (PFFS1) is turned on when the power is turned on.	F
1620	PF feed sensor 2 is turned ON	PF feed sensor 2 (PFFS2) is turned on when the power is turned on.	G
4002	Registration sensor does not turn ON	The registration sensor (RS) does not turn on during paper feed from paper feeder 1.	A
4003		The registration sensor (RS) does not turn on during paper feed from paper feeder 2.	A
4009		The registration sensor (RS) does not turn on during paper feed from MP tray.	A
4012	Registration sensor does not turn OFF	The registration sensor (RS) does not turn off during paper feed from paper feeder 1.	C
4013		The registration sensor (RS) does not turn off during paper feed from paper feeder 2.	C
4019		The registration sensor (RS) does not turn off during paper feed from MP tray.	C
4020	Registration sensor is turned ON	The registration sensor (RS) is turned on when the power is turned on.	C
4201	Eject sensor does not turn ON	The eject sensor (ES) does not turn on during paper feed from cassette.	C
4202		The eject sensor (ES) does not turn on during paper feed from paper feeder 1.	C
4203		The eject sensor (ES) does not turn on during paper feed from paper feeder 2.	C
4208		The eject sensor (ES) does not turn on during paper feed from duplex section.	C
4209		The eject sensor (ES) does not turn on during paper feed from MP tray.	C

*: Refer to figure 1-4-2 for paper jam location (see page 1-4-2).

Code	Contents	Conditions	Jam location*
4211	Eject sensor does not turn OFF	The eject sensor (ES) does not turn off during paper feed from cassette.	D
4212		The eject sensor (ES) does not turn off during paper feed from paper feeder 1.	D
4213		The eject sensor (ES) does not turn off during paper feed from paper feeder 2.	D
4218		The eject sensor (ES) does not turn off during paper feed from duplex section.	D
4219		The eject sensor (ES) does not turn off during paper feed from MP tray.	D
4220	Eject sensor is turned ON	The eject sensor (ES) is turned on when the power is turned on.	D
9010	DP top cover open	The DP top cover is opened during original feeding. The DP timing sensor (DPTS) turns on when starting the original paper feed.	H
9400	No original feed	The DP timing sensor (DPTS) does not turn on within specified time during the first sheet feeding (Retry 5 times).	H
		The DP timing sensor (DPTS) does not turn on within specified time during the second sheet feeding (Retry 5 times).	H
9401	An original jam in the original switchback section 2	During original switchback operation, DP timing sensor (DPTS) does not turn off within specified time of the DP paper feed motor (DPPFM) turning on.	H
9410	An original jam in the original conveying section	The DP timing sensor (DPTS) does not turn off within specified time of the DP paper feed motor (DPPFM) turning on.	H
9411	An original jam in the original switchback section 1	The DP timing sensor (DPTS) does not turn on within specified time of the DP paper feed motor (DPPFM) turning off.	H

*: Refer to figure 1-4-2 for paper jam location (see page 1-4-2).

www.tonerplus.com.ua

1-4-2 Self-diagnostic function

(1) Self-diagnostic function

This machine is equipped with self-diagnostic function. When a problem is detected, the machine stops printing and display an error message on the operation panel. An error message consists of a message prompting a contact to service personnel and a four-digit error code indicating the type of the error.



Figure 1-4-3

(2) Self diagnostic codes

If the part causing the problem was not supplied, use the unit including the part for replacement.

Code	Contents	Causes	Check procedures/ corrective measures
0030	FAX control PWB system error Processing with the fax software was disabled due to a hardware problem.	Defective FAX control PWB.	Replace the fax control PWB and check for correct operation. (see page 1-5-35).
0070	FAX control PWB incompatible detection error Abnormal detection of FAX control PWB incompatibility In the initial communication with the FAX control PWB, any normal communication command is not transmitted.	Defective FAX software.	Install the fax software.
		Defective FAX control PWB.	Replace the fax control PWB and check for correct operation. (see page 1-5-35).
0100	Backup memory device error	Defective flash memory.	Replace the main PWB and check for correct operation (see page 1-5-29).
		Defective main PWB.	Replace the main PWB and check for correct operation (see page 1-5-29).
0120	MAC address data error For data in which the MAC address is invalid.	Defective flash memory.	Replace the main PWB and check for correct operation (see page 1-5-29).
		Defective engine PWB.	Replace the engine PWB and check for correct operation (see page 1-5-26).
0130	Backup memory read/write error (main PWB)	Defective flash memory.	Replace the main PWB and check for correct operation (see page 1-5-29).
		Defective main PWB.	Replace the main PWB and check for correct operation (see page 1-5-29).
0140	Backup memory data error (main PWB)	Defective flash memory.	Replace the main PWB and check for correct operation (see page 1-5-29).
		Defective main PWB.	Replace the main PWB and check for correct operation (see page 1-5-29).
0150	Engine PWB EEPROM error Detecting engine PWB EEPROM communication error.	Improper installation engine PWB EEPROM.	Check the installation of the EEPROM and remedy if necessary.
		Defective engine PWB.	Replace the engine PWB and check for correct operation (see page 1-5-26).
		Device damage of EEPROM.	Contact the Service Administrative Division.
0170	Billing counting error A checksum error is detected in the main and engine backup memories for the billing counters.	Data damage of EEPROM.	Contact the Service Administrative Division.
		Defective PWB.	Replace the main PWB or the engine PWB and check for correct operation (see page 1-5-29, 1-5-26).

Code	Contents	Causes	Check procedures/ corrective measures
0180	Machine number mismatch Machine number of main and engine does not match.	Data damage of EEPROM.	Contact the Service Administrative Division.
0600	Expanded memory (DIMM) installing error The expansion memory modules (DIMM) are not correctly mounted.	Improper installation expanded memory (DIMM).	Check the installation of the expanded memory (DIMM).
0610	Expanded memory (DIMM) error The expansion memory modules (DIMM) mounted on the main PWB does not operate correctly.	Defective expanded memory (DIMM).	Replace the expanded memory (DIMM) and check for correct operation (see page 1-2-8).
		Defective main PWB.	Replace the main PWB and check for correct operation (see page 1-5-29).
0640	Hard disk error The hard disk cannot be accessed.	Defective hard disk.	Replace the hard disk and check for correct operation.
		Defective main PWB.	Replace the main PWB and check for correct operation (see page 1-5-29).
0830	FAX control PWB flash program area checksum error A checksum error occurred with the program of the FAX control PWB.	Defective FAX software.	Install the fax software.
		Defective FAX control PWB.	Replace the FAX control PWB (see page 1-5-35).
0840	Faults of RTC The time is judged to go back based on the comparison of the RTC time and the current time or five years or more have passed.	The battery is disconnected from the main PWB.	Check visually and remedy if necessary
		Defective main PWB.	Replace the main PWB and check for correct operation (see page 1-5-29).
0870	FAX control PWB to main PWB high capacity data transfer error High-capacity data transfer between the FAX control PWB and the main PWB of the machine was not normally performed even if the data transfer was retried the specified times.	Improper installation FAX control PWB.	Reinstall the FAX control PWB (see page 1-5-35).
		Defective FAX control PWB or main PWB.	Replace the FAX control PWB or main PWB and check for correct operation (see page 1-5-35 or 1-5-29).
0920	Fax file system error The backup data is not retained for file system abnormality of flash memory of the FAX control PWB.	Defective FAX control PWB.	Replace the FAX control PWB and check for correct operation (see page 1-5-35).

Code	Contents	Causes	Check procedures/ corrective measures
0930	EEPROM bus error	Defective drum PWB (EEPROM).	Replace the drum unit (see page 1-5-20).
		Defective engine PWB (EEPROM).	Replace the engine PWB and check for correct operation (see page 1-5-26).
		Defective engine PWB.	Replace the engine PWB and check for correct operation (see page 1-5-26).
		Defective main PWB.	Replace the main PWB and check for correct operation (see page 1-5-29).
1010	Lift motor error When the lift motor is driven, the motor over-current detection signal is detected continuously for 50 times (5 s) at 100 ms intervals. After the lift motor is driven, the ON status of lift sensor cannot be detected for 8 s. The cassette installed confirmation message is displayed on the operation panel, and even if the cassette is opened and closed, the cassette installed confirmation message is displayed 5 times successively.	Defective bottom plate elevation mechanism in the cassette.	Check to see if the bottom plate can move smoothly and repair it if any problem is found.
		Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. Lift motor and engine PWB (YC27)
		Defective drive transmission system of the lift motor.	Check if the gears rotate smoothly. If not, grease the bushes and gears. Check for broken gears and replace if any.
		Defective lift motor.	Replace the lift motor
		Defective engine PWB.	Replace the engine PWB and check for correct operation (see page 1-5-26).
1020	PF lift motor error (paper feeder 1) When the lift motor is driven, the motor over-current detection signal is detected continuously for 50 times (5 s) at 100 ms intervals. After the lift motor is driven, the ON status of lift sensor cannot be detected for 8 s. The cassette installed confirmation message is displayed on the operation panel, and even if the cassette is opened and closed, the cassette installed confirmation message is displayed 5 times successively.	Defective bottom plate elevation mechanism in the cassette.	Check to see if the bottom plate can move smoothly and repair it if any problem is found.
		Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. PF lift motor and PF main PWB (YC7)
		Defective drive transmission system of the PF lift motor.	Check if the gears rotate smoothly. If not, grease the bushes and gears. Check for broken gears and replace if any.
		Defective PF lift motor.	Replace the PF lift motor
		Defective PF main PWB.	Replace the PF main PWB (Refer to the service manual for the paper feeder).

Code	Contents	Causes	Check procedures/ corrective measures
1030	PF lift motor error (paper feeder 2) When the lift motor is driven, the motor over-current detection signal is detected continuously for 50 times (5 s) at 100 ms intervals. After the lift motor is driven, the ON status of lift sensor cannot be detected for 8 s. The cassette installed confirmation message is displayed on the operation panel, and even if the cassette is opened and closed, the cassette installed confirmation message is displayed 5 times successively.	Defective bottom plate elevation mechanism in the cassette.	Check to see if the bottom plate can move smoothly and repair it if any problem is found.
		Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. PF lift motor and PF main PWB (YC7)
		Defective drive transmission system of the PF lift motor.	Check if the gears rotate smoothly. If not, grease the bushes and gears. Check for broken gears and replace if any.
		Defective PF lift motor.	Replace the PF lift motor
		Defective PF main PWB.	Replace the PF main PWB (Refer to the service manual for the paper feeder).
1500	PF heater 1 high temperature error (paper feeder 1) A temperature higher than 75°C/167°F is detected.	Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. PF fan motor 1 and PF main PWB (YC111)
		Shorted PF thermistor 1.	Replace the top heater unit (Refer to the service manual for the paper feeder).
		Defective PF fan motor 1.	Replace the top heater unit (Refer to the service manual for the paper feeder).
		Defective PF main PWB.	Replace the PF main PWB (Refer to the service manual for the paper feeder).
1510	PF heater 2 high temperature error (paper feeder 1) A temperature higher than 75°C/167°F is detected.	Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. PF fan motor 2 and PF main PWB (YC111)
		Shorted PF thermistor 2.	Replace the side heater unit (Refer to the service manual for the paper feeder).
		Defective PF fan motor 2.	Replace the side heater unit (Refer to the service manual for the paper feeder).
		Defective PF main PWB.	Replace the PF main PWB (Refer to the service manual for the paper feeder).

Code	Contents	Causes	Check procedures/ corrective measures
1520	PF heater 1 high temperature error (paper feeder 2) A temperature higher than 75°C/167°F is detected.	Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. PF fan motor 1 and PF main PWB (YC111)
		Shorted PF thermistor 1.	Replace the top heater unit (Refer to the service manual for the paper feeder).
		Defective PF fan motor 1.	Replace the top heater unit (Refer to the service manual for the paper feeder).
		Defective PF main PWB.	Replace the PF main PWB (Refer to the service manual for the paper feeder).
1530	PF heater 2 high temperature error (paper feeder 2) A temperature higher than 75°C/167°F is detected.	Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. PF fan motor 2 and PF main PWB (YC111)
		Shorted PF thermistor 2.	Replace the side heater unit (Refer to the service manual for the paper feeder).
		Defective PF fan motor 2.	Replace the side heater unit (Refer to the service manual for the paper feeder).
		Defective PF main PWB.	Replace the PF main PWB (Refer to the service manual for the paper feeder).
1600	PF heater 1 low temperature error (paper feeder 1) An external temperature higher than + 5°C/+ 9°F is not detected when one minute elapses after PF heater 1 is turned on.	Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. PF heater 1 and PF heater PWB (YC1) PF heater PWB (YC3) and PF main PWB (YC113) PF thermistor 1 and PF main PWB (YC114)
		PF thermistor 1 installed incorrectly.	Check the installation of the PF thermistor 1.
		Defective PF thermistor 1.	Replace the top heater unit (Refer to the service manual for the paper feeder).
		Broken PF heater 1.	Replace the top heater unit (Refer to the service manual for the paper feeder).
		Defective PF heater PWB or PF main PWB.	Replace the PF heater PWB or PF main PWB (Refer to the service manual for the paper feeder).

Code	Contents	Causes	Check procedures/ corrective measures
1610	PF heater 2 low temperature error (paper feeder 1) An external temperature higher than + 5°C/+ 9°F is not detected when one minute elapses after PF heater 2 is turned on.	Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. PF heater 2 and PF heater PWB (YC2) PF heater PWB (YC3) and PF main PWB (YC113) PF thermistor 2 and PF main PWB (YC115)
		PF thermistor 2 installed incorrectly.	Check the installation of the PF thermistor 2.
		Defective PF thermistor 2.	Replace the side heater unit (Refer to the service manual for the paper feeder).
		Broken PF heater 2.	Replace the side heater unit (Refer to the service manual for the paper feeder).
		Defective PF heater PWB or PF main PWB.	Replace the PF heater PWB or PF main PWB (Refer to the service manual for the paper feeder).
1620	PF heater 1 low temperature error (paper feeder 2) An external temperature higher than + 5°C/+ 9°F is not detected when one minute elapses after PF heater 1 is turned on.	Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. PF heater 1 and PF heater PWB (YC1) PF heater PWB (YC3) and PF main PWB (YC113) PF thermistor 1 and PF main PWB (YC114)
		PF thermistor 1 installed incorrectly.	Check the installation of the PF thermistor 1.
		Defective PF thermistor 1.	Replace the top heater unit (Refer to the service manual for the paper feeder).
		Broken PF heater 1.	Replace the top heater unit (Refer to the service manual for the paper feeder).
		Defective PF heater PWB or PF main PWB.	Replace the PF heater PWB or PF main PWB (Refer to the service manual for the paper feeder).

Code	Contents	Causes	Check procedures/ corrective measures
1630	PF heater 2 low temperature error (paper feeder 2) An external temperature higher than + 5°C/+ 9°F is not detected when one minute elapses after PF heater 2 is turned on.	Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. PF heater 2 and PF heater PWB (YC2) PF heater PWB (YC3) and PF main PWB (YC113) PF thermistor 2 and PF main PWB (YC115)
		PF thermistor 2 installed incorrectly.	Check the installation of the PF thermistor 2.
		Defective PF thermistor 2.	Replace the side heater unit (Refer to the service manual for the paper feeder).
		Broken PF heater 2.	Replace the side heater unit (Refer to the service manual for the paper feeder).
		Defective PF heater PWB or PF main PWB.	Replace the PF heater PWB or PF main PWB (Refer to the service manual for the paper feeder).
1800	Paper feeder communication error Communication error between engine PWB and optional paper feeder.	Improper installation paper feeder.	Follow installation instruction carefully again.
		Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. PF main PWB (YC3) and engine PWB (YC33)
		Defective engine PWB.	Replace the engine PWB and check for correct operation (see page 1-5-26).
		Defective PF main PWB.	Replace the PF main PWB (Refer to the service manual for the paper feeder).
2100	Developing motor error The developing motor ready input is not given for 5 s during the main motor is ON.	Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. Developing motor and engine PWB (YC14)
		Defective drive transmission system of the developing motor.	Check if the rollers and gears rotate smoothly. If not, grease the bushes and gears. Check for broken gears and replace if any.
		Defective developing motor.	Replace the developing motor.
		Defective engine PWB.	Replace the engine PWB and check for correct operation (see page 1-5-26).

Code	Contents	Causes	Check procedures/ corrective measures
2200	Drum motor error The drum motor ready input is not given for 5 s during the drum motor is ON.	Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. Drum motor and engine PWB (YC13)
		Defective drive transmission system of the drum motor.	Check if the rollers and gears rotate smoothly. If not, grease the bushes and gears. Check for broken gears and replace if any.
		Defective drum motor.	Replace the drum motor.
		Defective engine PWB.	Replace the engine PWB and check for correct operation (see page 1-5-26).
2330	Fuser pressure release motor error When the fuser pressure release motor is driven, the motor over-current detection signal is detected continuously for 8 times (800 ms) at 100 ms intervals.	Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. Fuser pressure release motor and engine PWB (YC38)
		Defective drive transmission system of the fuser pressure release motor.	Check if the rollers and gears rotate smoothly. If not, grease the bushes and gears. Check for broken gears and replace if any.
		Defective fuser pressure release motor.	Replace the fuser pressure release motor.
		Defective engine PWB.	Replace the engine PWB and check for correct operation (see page 1-5-26).
2340	Fuser pressure release motor time-out error When the fuser pressure release motor is driven, the envelope switch (EVS) is not detectable for 6 s.	Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. Fuser pressure release motor and engine PWB (YC38)
		Defective drive transmission system of the fuser pressure release motor.	Check if the rollers and gears rotate smoothly. If not, grease the bushes and gears. Check for broken gears and replace if any.
		Defective fuser pressure release motor.	Replace the fuser pressure release motor.
		Defective engine PWB.	Replace the engine PWB and check for correct operation (see page 1-5-26).

Code	Contents	Causes	Check procedures/ corrective measures
2500	Paper feed motor error The drum motor ready input is not given for 5 s during the paper feed motor is ON.	Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. Paper feed motor and engine PWB (YC3)
		Defective drive transmission system of the paper feed motor.	Check if the rollers and gears rotate smoothly. If not, grease the bushes and gears. Check for broken gears and replace if any.
		Defective paper feed motor.	Replace the paper feed motor.
		Defective engine PWB.	Replace the engine PWB and check for correct operation (see page 1-5-26).
2600	PF paper feed motor error (paper feeder 1) The drum motor ready input is not given for 2 s during the PF paper feed motor is ON.	Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. PF paper feed motor and PF main PWB (YC6)
		Defective drive transmission system of the PF paper feed motor.	Check if the rollers and gears rotate smoothly. If not, grease the bushes and gears. Check for broken gears and replace if any.
		Defective PF paper feed motor.	Replace the PF paper feed motor.
		Defective PF main PWB.	Replace the PF main PWB (Refer to the service manual for the paper feeder).
2610	PF paper feed motor error (paper feeder 2) The drum motor ready input is not given for 2 s during the PF paper feed motor is ON.	Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. PF paper feed motor and PF main PWB (YC6)
		Defective drive transmission system of the PF paper feed motor.	Check if the rollers and gears rotate smoothly. If not, grease the bushes and gears. Check for broken gears and replace if any.
		Defective PF paper feed motor.	Replace the PF paper feed motor.
		Defective PF main PWB.	Replace the PF main PWB (Refer to the service manual for the paper feeder).

Code	Contents	Causes	Check procedures/ corrective measures
2730	Developing release motor error When the developing release motor is driven, the motor over-current detection signal is detected continuously for 8 times (800 ms) at 100 ms intervals.	Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. Developing release motor and engine PWB (YC35)
		Defective drive transmission system of the developing release motor.	Check if the rollers and gears rotate smoothly. If not, grease the bushes and gears. Check for broken gears and replace if any.
		Defective developing release motor.	Replace the developing release motor.
		Defective engine PWB.	Replace the engine PWB and check for correct operation (see page 1-5-26).
2740	Developing release motor time-out error When the developing release motor is driven, the developing release switch (DEVRSW) is not detectable for 1 s.	Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. Developing release motor and engine PWB (YC35)
		Defective drive transmission system of the developing release motor.	Check if the rollers and gears rotate smoothly. If not, grease the bushes and gears. Check for broken gears and replace if any.
		Defective developing release motor.	Replace the developing release motor.
		Defective engine PWB.	Replace the engine PWB and check for correct operation (see page 1-5-26).
2820	Fuser motor error The fuser motor ready input is not given for 5 s during the fuser motor is ON.	Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. Fuser motor and engine PWB (YC15)
		Defective drive transmission system of the fuser motor.	Check if the rollers and gears rotate smoothly. If not, grease the bushes and gears. Check for broken gears and replace if any.
		Defective fuser motor.	Replace the fuser motor.
		Defective engine PWB.	Replace the engine PWB and check for correct operation (see page 1-5-26).

Code	Contents	Causes	Check procedures/ corrective measures
3100	ISU home position error The home position is not correct when the power is turned on or at the start of copying using the table.	Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. Home position sensor and CCD PWB (YC3) CCD PWB (YC1) and main PWB (YC8) ISU motor and main PWB (YC36)
		Defective home position sensor.	Replace the home position sensor.
		Defective ISU motor.	Replace the ISU motor.
		Defective CCD PWB.	Replace the scanner unit (see page 1-5-47).
		Defective main PWB.	Replace the main PWB and check for correct operation (see page 1-5-29).
3200	Exposure lamp error When input value at the time of exposure lamp illumination does not exceed the threshold value between 5 s.	Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. Exposure lamp and inverter PWB (CN2) Inverter PWB (CN1) and CCD PWB (YC3) CCD PWB (YC1) and main PWB (YC8)
		Defective exposure lamp.	Replace the scanner unit (see page 1-5-47).
		Defective inverter PWB or CCD PWB.	Replace the scanner unit (see page 1-5-47).
		Defective main PWB.	Replace the main PWB and check for correct operation (see page 1-5-29).
3300	AGC error After AGC, correct input is not obtained at CCD.	Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. Inverter PWB (CN1) and CCD PWB (YC3) CCD PWB (YC1) and main PWB (YC8)
		Defective exposure lamp.	Replace the scanner unit (see page 1-5-47).
		Defective inverter PWB or CCD PWB.	Replace the scanner unit (see page 1-5-47).
		Defective main PWB.	Replace the main PWB and check for correct operation (see page 1-5-29).

Code	Contents	Causes	Check procedures/ corrective measures
3500	Communication error between scanner and ASIC An error code is detected.	Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. CCD PWB (YC1) and main PWB (YC8)
		Defective CCD PWB.	Replace the scanner unit (see page 1-5-47).
		Defective main PWB.	Replace the main PWB and check for correct operation (see page 1-5-29).
4001	Polygon motor KM error The polygon motor KM ready input is not given for 10 s during the polygon motor is ON.	Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. Laser scanner unit KM and engine PWB (YC31)
		Defective polygon motor KM.	Replace the laser scanner unit KM (see page 1-5-44).
		Defective engine PWB.	Replace the engine PWB and check for correct operation (see page 1-5-26).
4002	Polygon motor CY error The polygon motor CY ready input is not given for 10 s during the polygon motor is ON.	Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. Laser scanner unit CY and engine PWB (YC31)
		Defective polygon motor CY.	Replace the laser scanner unit CY (see page 1-5-44).
		Defective engine PWB.	Replace the engine PWB and check for correct operation (see page 1-5-26).
4201	Laser output error (black) The pin photo signal is not output from PD PWB K for one second while laser is emitted.	Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. APC PWB K and engine PWB (YC31)
		Defective APC PWB K.	Replace the laser scanner unit KM (see page 1-5-44).
		Defective PD PWB K.	Replace the laser scanner unit KM (see page 1-5-44).
		Defective engine PWB.	Replace the engine PWB and check for correct operation (see page 1-5-26).

Code	Contents	Causes	Check procedures/ corrective measures
4202	Laser output error (cyan) The pin photo signal is not output from PD PWB C for one second while laser is emitted.	Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. APC PWB C and engine PWB (YC32)
		Defective APC PWB C.	Replace the laser scanner unit CY (see page 1-5-44).
		Defective PD PWB C.	Replace the laser scanner unit CY (see page 1-5-44).
		Defective engine PWB.	Replace the engine PWB (see page 1-5-26).
4203	Laser output error (magenta) The pin photo signal is not output from PD PWB M for one second while laser is emitted.	Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. APC PWB M and engine PWB (YC31)
		Defective APC PWB M.	Replace the laser scanner unit KM (see page 1-5-44).
		Defective PD PWB M.	Replace the laser scanner unit KM (see page 1-5-44).
		Defective engine PWB.	Replace the engine PWB (see page 1-5-26).
4204	Laser output error (yellow) The pin photo signal is not output from PD PWB Y for one second while laser is emitted.	Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. APC PWB Y and engine PWB (YC32)
		Defective APC PWB Y.	Replace the laser scanner unit CY (see page 1-5-44).
		Defective PD PWB Y.	Replace the laser scanner unit CY (see page 1-5-44).
		Defective engine PWB.	Replace the engine PWB (see page 1-5-26).
4600	LSU cleaning motor error When the LSU cleaning motor is driven, the motor over-current detection signal is detected continuously for 50 times (5 s) at 100 ms intervals.	Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. LSU cleaning motor and engine PWB (YC36)
		Defective drive transmission system of the LSU cleaning motor.	Check if the rollers and gears rotate smoothly. If not, grease the bushes and gears. Check for broken gears and replace if any.
		Defective LSU cleaning motor.	Replace the LSU cleaning motor.
		Defective engine PWB.	Replace the engine PWB and check for correct operation (see page 1-5-26).

Code	Contents	Causes	Check procedures/ corrective measures
4700	VIDEO ASIC device error	Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. Main PWB (YC39) and relay PWB (YC3) Relay PWB (YC2, 4) and engine PWB (YC8, 9)
		Defective main PWB or engine PWB.	Replace the main PWB or the engine PWB and check for correct operation (see page 1-5-29, 1-5-26).
5301	Broken cleaning lamp K wire When the cleaning lamp K is driven, the lamp over-current detection signal is detected continuously for 10 times (1 s) at 100 ms intervals.	Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. Drum unit K and Drum relay PWB (YC2) Drum relay PWB (YC1) and engine PWB (YC34)
		Defective cleaning lamp K.	Replace the drum unit K. (see page 1-5-20).
		Defective engine PWB.	Replace the engine PWB and check for correct operation (see page 1-5-26).
5302	Broken cleaning lamp C wire When the cleaning lamp C is driven, the lamp over-current detection signal is detected continuously for 10 times (1 s) at 100 ms intervals.	Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. Drum unit C and Drum relay PWB (YC4) Drum relay PWB (YC1) and engine PWB (YC34)
		Defective cleaning lamp C.	Replace the drum unit C. (see page 1-5-20).
		Defective engine PWB.	Replace the engine PWB and check for correct operation (see page 1-5-26).
5303	Broken cleaning lamp M wire When the cleaning lamp M is driven, the lamp over-current detection signal is detected continuously for 10 times (1 s) at 100 ms intervals.	Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. Drum unit M and Drum relay PWB (YC3) Drum relay PWB (YC1) and engine PWB (YC34)
		Defective cleaning lamp M.	Replace the drum unit M. (see page 1-5-20).
		Defective engine PWB.	Replace the engine PWB and check for correct operation (see page 1-5-26).

Code	Contents	Causes	Check procedures/ corrective measures
5304	Broken cleaning lamp Y wire When the cleaning lamp Y is driven, the lamp over-current detection signal is detected continuously for 10 times (1 s) at 100 ms intervals.	Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. Drum unit Y and Drum relay PWB (YC5) Drum relay PWB (YC1) and engine PWB (YC34)
		Defective cleaning lamp Y.	Replace the drum unit Y. (see page 1-5-20).
		Defective engine PWB.	Replace the engine PWB and check for correct operation (see page 1-5-26).
6000	Broken fuser heater wire The detected temperature of fuser thermistor does not rise 1°C/1.8°F after the fuser heater has been turned on continuously for 10 s in warming up. The fuser temperature does not reach 100°C/212°F after the fuser heater has been turned on continuously for 30 s in warming up. The detected temperature of fuser thermistor does not reach the specified temperature (ready indication temperature) after the fuser heater has been turned on continuously for 60 s in warming up. The detected temperature of fuser thermistor does not rise 1°C/1.8°F after the fuser heater has been turned on continuously for 10 s during printing.	Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. Fuser heater and power source PWB (YC102) Fuser unit and eject PWB (YC3) Eject PWB (YC1) and engine PWB (YC19)
		Fuser thermostat triggered.	Reinsert the fuser unit (see page 1-5-25).
		Broken fuser heater wire.	Replace the fuser unit (see page 1-5-25).
		Defective engine PWB.	Replace the engine PWB and check for correct operation (see page 1-5-26).
6020	Abnormally high fuser thermistor temperature The fuser thermistor detects a temperature higher than 240°C/464°F. By the activation of the high temperature error detection circuit (230°C/446°F or more) of fuser thermistor, the illumination of fuser heater was forcibly turned off and 10 s has elapsed.	Shorted fuser thermistor.	Replace the fuser unit (see page 1-5-25).
		Defective engine PWB.	Replace the engine PWB and check for correct operation (see page 1-5-26).

Code	Contents	Causes	Check procedures/ corrective measures
6030	Broken fuser thermistor wire Input from fuser thermistor is 3 or less (A/D value) continuously for 1 s.	Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. Fuser unit and eject PWB (YC3) Eject PWB (YC1) and engine PWB (YC19)
		Broken fuser thermistor wire.	Replace the fuser unit (see page 1-5-25).
		Fuser thermostat triggered.	Reinsert the fuser unit (see page 1-5-25).
		Broken fuser heater wire.	Replace the fuser unit (see page 1-5-25).
		Defective engine PWB.	Replace the engine PWB and check for correct operation (see page 1-5-26).
6400	Zero-cross signal error The zero-cross signal does not reach the engine PWB for more than 1 s.	Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. Power source PWB (YC103) and relay PWB (YC1) Relay PWB (YC4) and engine PWB (YC9)
		Defective power source PWB or engine PWB.	Replace the power source PWB or the engine PWB and check for correct operation (see page 1-5-28, 1-5-26).
7001	Toner motor K error When the toner motor K is driven, the motor over-current detection signal is detected continuously for 50 times (5 s) at 100 ms intervals.	Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. Toner motor K and engine PWB (YC23)
		Defective drive transmission system of the toner motor K.	Check if the rollers and gears rotate smoothly. If not, grease the bushes and gears. Check for broken gears and replace if any.
		Defective toner motor K.	Replace the toner motor K.
		Defective engine PWB.	Replace the engine PWB and check for correct operation (see page 1-5-26).

Code	Contents	Causes	Check procedures/ corrective measures
7002	Toner motor C error When the toner motor C is driven, the motor over-current detection signal is detected continuously for 50 times (5 s) at 100 ms intervals.	Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. Toner motor C and engine PWB (YC25)
		Defective drive transmission system of the toner motor C.	Check if the rollers and gears rotate smoothly. If not, grease the bushes and gears. Check for broken gears and replace if any.
		Defective toner motor C.	Replace the toner motor C.
		Defective engine PWB.	Replace the engine PWB and check for correct operation (see page 1-5-26).
7003	Toner motor M error When the toner motor M is driven, the motor over-current detection signal is detected continuously for 50 times (5 s) at 100 ms intervals.	Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. Toner motor M and engine PWB (YC24)
		Defective drive transmission system of the toner motor M.	Check if the rollers and gears rotate smoothly. If not, grease the bushes and gears. Check for broken gears and replace if any.
		Defective toner motor M.	Replace the toner motor M.
		Defective engine PWB.	Replace the engine PWB and check for correct operation (see page 1-5-26).
7004	Toner motor Y error When the toner motor Y is driven, the motor over-current detection signal is detected continuously for 50 times (5 s) at 100 ms intervals.	Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. Toner motor Y and engine PWB (YC26)
		Defective drive transmission system of the toner motor Y.	Check if the rollers and gears rotate smoothly. If not, grease the bushes and gears. Check for broken gears and replace if any.
		Defective toner motor Y.	Replace the toner motor Y.
		Defective engine PWB.	Replace the engine PWB and check for correct operation (see page 1-5-26).

Code	Contents	Causes	Check procedures/ corrective measures
7401	Developing unit K non-installing error No density detection signal is output from toner sensor K in developing unit K.	Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. Developing unit K and Drum relay PWB (YC6) Drum relay PWB (YC1) and engine PWB (YC34)
		Defective toner sensor K.	Replace the developing unit K (see page 1-5-18).
		Defective engine PWB.	Replace the engine PWB and check for correct operation (see page 1-5-26).
7402	Developing unit C non-installing error No density detection signal is output from toner sensor C in developing unit C.	Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. Developing unit C and Drum relay PWB (YC10) Drum relay PWB (YC1) and engine PWB (YC34)
		Defective toner sensor C.	Replace the developing unit C (see page 1-5-18).
		Defective engine PWB.	Replace the engine PWB and check for correct operation (see page 1-5-26).
7403	Developing unit M non-installing error No density detection signal is output from toner sensor M in developing unit M.	Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. Developing unit M and Drum relay PWB (YC7) Drum relay PWB (YC1) and engine PWB (YC34)
		Defective toner sensor M.	Replace the developing unit M (see page 1-5-18).
		Defective engine PWB.	Replace the engine PWB and check for correct operation (see page 1-5-26).
7404	Developing unit Y non-installing error No density detection signal is output from toner sensor Y in developing unit Y.	Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. Developing unit Y and Drum relay PWB (YC13) Drum relay PWB (YC1) and engine PWB (YC34)
		Defective toner sensor Y.	Replace the developing unit Y (see page 1-5-18).
		Defective engine PWB.	Replace the engine PWB and check for correct operation (see page 1-5-26).

Code	Contents	Causes	Check procedures/ corrective measures
7411	Drum unit K non- installing error The EEPROM of drum PWB K does not communicate normally.	Installation of incompatible drum unit K.	Install drum unit K compatible with the specifications to the machine.
		Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. Drum unit K and Drum relay PWB (YC2) Drum relay PWB (YC1) and engine PWB (YC34)
		Defective drum PWB K.	Replace the drum unit K (see page 1-5-20).
		Defective engine PWB.	Replace the engine PWB and check for correct operation (see page 1-5-26).
7412	Drum unit C non- installing error The EEPROM of drum PWB C does not communicate normally.	Installation of incompatible drum unit C.	Install drum unit C compatible with the specifications to the machine.
		Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. Drum unit C and Drum relay PWB (YC4) Drum relay PWB (YC1) and engine PWB (YC34)
		Defective drum PWB C.	Replace the drum unit C (see page 1-5-20).
		Defective engine PWB.	Replace the engine PWB and check for correct operation (see page 1-5-26).
7413	Drum unit M non- installing error The EEPROM of drum PWB M does not communicate normally.	Installation of incompatible drum unit M.	Install drum unit M compatible with the specifications to the machine.
		Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. Drum unit M and Drum relay PWB (YC3) Drum relay PWB (YC1) and engine PWB (YC34)
		Defective drum PWB M.	Replace the drum unit M (see page 1-5-20).
		Defective engine PWB.	Replace the engine PWB and check for correct operation (see page 1-5-26).

Code	Contents	Causes	Check procedures/ corrective measures
7414	Drum unit Y non- installing error The EEPROM of drum PWB Y does not communicate normally.	Installation of incompatible drum unit Y.	Install drum unit Y compatible with the specifications to the machine.
		Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. Drum unit Y and Drum relay PWB (YC5) Drum relay PWB (YC1) and engine PWB (YC34)
		Defective drum PWB Y.	Replace the drum unit Y (see page 1-5-20).
		Defective engine PWB.	Replace the engine PWB and check for correct operation (see page 1-5-26).
9500			Contact the Service Administrative Division.
9510			Contact the Service Administrative Division.
9520			Contact the Service Administrative Division.
9530	Backup data error The serial number of the machine written on the EEPROM of the engine PWB differs with that is written on both the flash memory of the engine PWB and the EEPROM of the drum PWB as a backup.	Replacing both the engine PWB and the drum unit at the same time.	Check that the machine operates properly by reverting the engine controller and the drum unit to the old ones. To replace the engine PWB and the drum unit at the same time, turn on the machine after replacing either one. Check that the machine operates properly and then turn off the machine. Replace the other and turn on the machine to check that the machine operates properly. Be sure to replace one by one.
F000	Main PWB - operation panel PWB communication error	Defective main PWB.	Turn the main power switch off/on to restart the machine. If the error is not resolved, replace main PWB (see page 1-5-29).
		Defective operation panel PWB.	Replace the operation panel PWB and check for correct operation.
F010	Main PWB checksum error	Defective main PWB.	Turn the main power switch off/on to restart the machine. If the error is not resolved, replace main PWB (see page 1-5-29).
F020	Main PWB RAM checksum error	Defective main memory (RAM) on the main PWB.	Turn the main power switch off/on to restart the machine. If the error is not resolved, replace main PWB (see page 1-5-29).
		Defective expanded memory (DIMM).	Replace the expanded memory (DIMM) (see page 1-2-8).

Code	Contents	Causes	Check procedures/ corrective measures
F040	Main PWB - print engine communication error	Defective main PWB.	Turn the main power switch off/on to restart the machine. If the error is not resolved, replace main PWB (see page 1-5-29).
		Defective engine PWB.	Replace the engine PWB and check for correct operation (see page 1-5-26).
F041	Main PWB - scanner engine communication error	Defective main PWB.	Turn the main power switch off/on to restart the machine. If the error is not resolved, replace main PWB (see page 1-5-29).
		Defective engine PWB.	Replace the engine PWB and check for correct operation (see page 1-5-26).
F050	Print engine ROM checksum error	Defective engine PWB.	Turn the main power switch off/on to restart the machine. If the error is not resolved, replace engine PWB (see page 1-5-26).
F051	Scanner engine ROM checksum error	Defective engine PWB.	Turn the main power switch off/on to restart the machine. If the error is not resolved, replace engine PWB (see page 1-5-26).
F278	Power supply in drive system error	Main power switch was turned off without using the power key, or a power failure has occurred.	Turn on power. (To switch off power, first press the power key until the main power indicator goes off, then turn the main power switch off.)

1-4-3 Image formation problems

If the part causing the problem was not supplied, use the unit including the part for replacement.

(1) No image appears (entirely white).



See page 1-4-29

(2) No image appears (entirely black).



See page 1-4-29

(3) A specific color is printed solid.



See page 1-4-30

(4) The back side gets dirty.




See page 1-4-30

(5) Image is too light.



See page 1-4-30

(6) The background is colored.



See page 1-4-31

(7) White streaks are printed vertically.




See page 1-4-31

(8) Black streaks are printed vertically.



See page 1-4-31

(9) Streaks are printed horizontally.




See page 1-4-32

(10) Spots are printed.




See page 1-4-32

(11) The leading edge of image begins to print too early or too late.




See page 1-4-32

(12) Paper is wrinkled.




See page 1-4-32

(13) Offset occurs.




See page 1-4-33

(14) Part of image is missing.



See page 1-4-33

(15) Fusing is loose.



See page 1-4-33


(16) Colors are printed offset to each other.



See page 1-4-34



(1) No image appears (entirely white).

Print example	Causes		Check procedures/corrective measures
	Defective transfer bias output.	Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. High voltage PWB and engine PWB (YC11)
		Defective high voltage PWB.	Replace the high voltage PWB (see page 1-5-34).
		Defective engine PWB.	Replace the engine PWB (see page 1-5-26).
	Defective developing bias output.	Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. High voltage PWB and engine PWB (YC11)
		Defective high voltage PWB.	Replace the high voltage PWB (see page 1-5-34).
		Defective engine PWB.	Replace the engine PWB (see page 1-5-26).
	No LSU laser is output.	Defective laser scanner unit.	Replace the laser scanner unit KM/CY (see page 1-5-44).
		Defective engine PWB.	Replace the engine PWB (see page 1-5-26).


(2) No image appears (entirely black).

Print example	Causes		Check procedures/corrective measures
	No main charging.	Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. High voltage PWB and engine PWB (YC11)
		Defective main charger unit.	Replace the drum unit (see page 1-5-20).
		Defective high voltage PWB.	Replace the high voltage PWB (see page 1-5-34).
		Defective engine PWB.	Replace the engine PWB (see page 1-5-26).
	Exposure lamp fails to light.	Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. Exposure lamp and inverter PWB (CN2) Inverter PWB (CN1) and CCD PWB (YC3) CCD PWB (YC1) and main PWB (YC8)
		Defective inverter PWB or CCD PWB.	Replace the scanner unit (see page 1-5-47).
		Defective main PWB.	Replace the main PWB (see page 1-5-29).
	The laser is activated simultaneously for all colors.	Defective laser scanner unit.	Replace the laser scanner unit KM/CY (see page 1-5-44).

(3) A specific color is printed solid.

Print example	Causes	Check procedures/corrective measures
	Defective main charger unit which corresponds to the color causing the problem.	Replace the drum unit for the color that causes an error (see page 1-5-20).
	Laser of laser scanner unit for solid color printing is ON. Defective laser scanner unit.	Replace the laser scanner unit KM/CY (see page 1-5-44).


(4) The back side gets dirty.

Print example	Causes	Check procedures/corrective measures
	Dirty secondary transfer roller.	Clean the secondary transfer roller.
	Dirty paper conveying path.	Clean the paper conveying path.
	Dirty heat roller and press roller.	Clean the heat roller and press roller.

(5) Image is too light.

Print example	Causes	Check procedures/corrective measures	
	Defective developing bias output.	Defective developing unit.	Replace the developing unit for the color that causes an error (see page 1-5-18).
		Defective high voltage PWB.	Replace the high voltage PWB (see page 1-5-34).
		Defective engine PWB.	Replace the engine PWB (see page 1-5-26).
	Defective drum unit.		Decrease the surface potential by performing the main charger adjustment (see page 1-3-68). When the problem is not cleared, replace the drum unit (see page 1-5-20).
	Defective transfer bias output.	Defective high voltage PWB.	Replace the high voltage PWB (see page 1-5-34).
		Defective engine PWB.	Replace the engine (see page 1-5-26).
	Defective color calibration.		Perform the color calibration (Refer to operation guide).
	Insufficient toner.		If the display shows the message requesting toner replenishment, replace the container.
	Insufficient agitation of toner container.		Shake the toner container vertically approximately 10 times.
	Paper damp.		Check the paper storage conditions, replace the paper.


(6) The background is colored.

Print example	Causes		Check procedures/corrective measures
	Defective color calibration.		Perform the color calibration (Refer to operation guide).
	Defective developing bias output.	Defective developing unit.	Replace the developing unit for the color that causes an error (see page 1-5-18).
		Defective high voltage PWB.	Replace the high voltage PWB (see page 1-5-34).
		Defective engine PWB.	Replace the engine PWB (see page 1-5-26).
	Defective drum surface charging.	Defective drum unit.	Replace the drum unit (see page 1-5-20).
		Defective high voltage PWB.	Replace the high voltage PWB (see page 1-5-34).
		Defective engine PWB.	Replace the engine PWB (see page 1-5-26).


(7) White streaks are printed vertically.

Print example	Causes	Check procedures/corrective measures
	Foreign object in one of the developing units.	Replace the developing unit for the color that causes an error (see page 1-5-18).
	Adhesion of soiling to transfer belt.	Clean the transfer belt. Replace the intermediate transfer unit if it is extremely dirty (see page 1-5-21).
	Adhesion of soiling to transfer roller.	Clean the transfer roller. Replace the transfer roller if it is extremely dirty (see page 1-5-24).
	Dirty LSU dust shield glass.	Perform the LSU dust shield glass cleaning.


(8) Black streaks are printed vertically.

Print example	Causes	Check procedures/corrective measures
	Dirty contact glass.	Clean the contact glass.
	Dirty slit glass.	Clean the slit glass.
	Dirty or flawed drum.	Perform the drum surface refreshing (see page 1-3-67). Flawed drum. Replace the drum unit (see page 1-5-20).
	Deformed or worn cleaning blade in the drum unit.	Replace the drum unit (see page 1-5-20).
	Worn primary transfer belt.	Replace the intermediate transfer unit (see page 1-5-21).
	Defective transfer roller.	Replace the transfer roller (see page 1-5-24).


(9) Streaks are printed horizontally.

Print example	Causes	Check procedures/corrective measures
	Dirty or flawed drum.	Perform the drum surface refreshing (see page 1-3-67). Flawed drum. Replace the drum unit (see page 1-5-20).
	Dirty developing section.	Clean any part contaminated with toner in the developing section.
	Poor contact of grounding terminal of drum unit.	Check the installation of the drum unit. If it operates incorrectly, replace it (see page 1-5-20).


(10) Spots are printed.

Print example	Causes	Check procedures/corrective measures
	Dirty contact glass.	Clean the contact glass.
	Dirty or flawed drum.	Perform the drum surface refreshing (see page 1-3-67). Flawed drum. Replace the drum unit (see page 1-5-20).
	Deformed or worn cleaning blade in the drum unit.	Replace the drum unit (see page 1-5-20).
	Flawed developing roller.	Replace the developing unit (see page 1-5-18).
	Dirty heat roller and press roller.	Clean the heat roller and press roller.


(11) The leading edge of image begins to print too early or too late.

Print example	Causes	Check procedures/corrective measures
	Paper feed clutch or registration clutch operating incorrectly.	Check the installation of the clutch. If it operates incorrectly, replace it.


(12) Paper is wrinkled.

Print example	Causes	Check procedures/corrective measures
	Paper curled.	Check the paper storage conditions.
	Paper damp.	Check the paper storage conditions.


(13) Offset occurs.

Print example	Causes	Check procedures/corrective measures
	Defective drum surface charging.	Perform the drum surface refreshing (see page 1-3-67). When the problem is not cleared, increase the surface potential by performing the main charger adjustment (see page 1-3-68).
	Deformed or worn cleaning blade in the drum unit.	Replace the drum unit (see page 1-5-20).
	Defective transfer belt cleaning.	Replace the intermediate transfer unit (see page 1-5-21).
	Defective fuser unit.	Replace the fuser unit (see page 1-5-25).
	Wrong types of paper.	Check if the paper meets specifications. Replace paper.


(14) Part of image is missing.

Print example	Causes	Check procedures/corrective measures
	Paper damp.	Check the paper storage conditions.
	Paper creased.	Replace the paper.
	Drum condensation.	Perform the drum surface refreshing (see page 1-3-67).
	Dirty or flawed drum.	Perform the drum surface refreshing (see page 1-3-67). Flawed drum. Replace the drum unit (see page 1-5-20).
	Dirty transfer belt.	Clean the transfer belt. Replace the intermediate transfer unit if it is extremely dirty (see page 1-5-21).
	Dirty transfer roller.	Clean the transfer roller. Replace the transfer roller if it is extremely dirty (see page 1-5-24).

(15) Fusing is loose.

Print example	Causes	Check procedures/corrective measures
	Wrong types of paper.	Check if the paper meets specifications, replace paper.
	Flawed heat roller or press roller.	Replace the fuser unit (see page 1-5-25).

(16) Colors are printed offset to each other.

Print example	Causes	Check procedures/corrective measures
	Defective color calibration.	Perform the color calibration (refer to operation guide).
	Slip the mirror position of laser scanner unit.	Perform the normal color registration. When the problem is not cleared, perform the detail color registration adjustment (refer to operation guide).

1-4-4 Electric problems

If the part causing the problem was not supplied, use the unit including the part for replacement.
Troubleshooting to each failure must be in the order of the numbered symptoms.

Problem	Causes	Check procedures/corrective measures
(1) The machine does not operate when the main power switch is turned on.	1. No electricity at the power outlet.	Measure the input voltage.
	2. The power cord is not plugged in properly.	Check the contact between the power plug and the outlet.
	3. The top tray is not closed completely.	Check the top tray.
	4. Broken power cord.	Check for continuity. If none, replace the cord.
	5. Defective main power switch.	Check for continuity across the contacts. If none, replace the power source PWB (see page 1-5-28).
	6. Defective interlock switch.	Check for continuity across the contacts of interlock switch. If none, replace the power source PWB (see page 1-5-28).
	7. Defective power source PWB.	Replace the power source PWB (see page 1-5-28).
(2) Duplex motor does not operate.	1. Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. Duplex motor and engine PWB (YC37)
	2. Defective drive transmission system.	Check if the rollers and gears rotate smoothly. If not, grease the bushes and gears. Check for broken gears and replace if any.
	3. Defective motor.	Replace the duplex motor.
	4. Defective PWB.	Replace the engine PWB and check for correct operation (see page 1-5-26).
(3) Right fan motor does not operate.	1. Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. Right fan motor and main PWB (YC42)
	2. Defective motor.	Replace the right fan motor.
	3. Defective PWB.	Replace the main PWB and check for correct operation (see page 1-5-29).
(4) Left fan motor does not operate.	1. Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. Left fan motor and engine PWB (YC29)
	2. Defective motor.	Replace the left fan motor.
	3. Defective PWB.	Replace the engine PWB and check for correct operation (see page 1-5-26).

Problem	Causes	Check procedures/corrective measures
(5) Controller fan motor does not operate.	1. Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. Controller fan motor and main PWB (YC41)
	2. Defective motor.	Replace the controller fan motor.
	3. Defective PWB.	Replace the main PWB and check for correct operation (see page 1-5-29).
(6) Fuser fan motor does not operate.	1. Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. Fuser fan motor and engine PWB (YC40)
	2. Defective motor.	Replace the fuser fan motor.
	3. Defective PWB.	Replace the engine PWB and check for correct operation (see page 1-5-26).
(7) Container fan motor does not operate.	1. Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. Container fan motor and engine PWB (YC28)
	2. Defective motor.	Replace the container fan motor.
	3. Defective PWB.	Replace the engine PWB and check for correct operation (see page 1-5-26).
(8) ISU motor does not operate.	1. Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. ISU motor and main PWB (YC36)
	2. Defective drive transmission system.	Check if the rollers and gears rotate smoothly. If not, grease the bushes and gears. Check for broken gears and replace if any.
	3. Defective motor.	Replace the ISU motor.
	4. Defective PWB.	Replace the main PWB and check for correct operation (see page 1-5-29).
(9) Paper feed clutch does not operate.	1. Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. Paper feed clutch and engine PWB (YC3)
	2. Defective clutch.	Replace the paper feed clutch.
	3. Defective PWB.	Replace the engine PWB and check for correct operation (see page 1-5-26).
(10) MP feed clutch does not operate.	1. Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. MP feed clutch and engine PWB (YC3)
	2. Defective clutch.	Replace the MP feed clutch.
	3. Defective PWB.	Replace the engine PWB and check for correct operation (see page 1-5-26).

Problem	Causes	Check procedures/corrective measures
(11) Registration clutch does not operate.	1. Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. Registration clutch and engine PWB (YC3)
	2. Defective clutch.	Replace the registration clutch.
	3. Defective PWB.	Replace the engine PWB and check for correct operation (see page 1-5-26).
(12) Middle clutch does not operate.	1. Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. Middle clutch and engine PWB (YC3)
	2. Defective clutch.	Replace the middle clutch.
	3. Defective PWB.	Replace the engine PWB and check for correct operation (see page 1-5-26).
(13) MP solenoid does not operate.	1. Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. MP solenoid and engine PWB (YC4)
	2. Defective solenoid.	Replace the MP solenoid.
	3. Defective PWB.	Replace the engine PWB and check for correct operation (see page 1-5-26).
(14) The message requesting paper to be loaded is shown when paper is present on the cassette.	1. Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. Cassette PWB (YC1) and engine PWB (YC21)
	2. Deformed actuator of the paper sensor.	Check visually and replace if necessary.
	3. Defective paper sensor.	Replace the cassette PWB.
	4. Defective PWB.	Replace the engine PWB and check for correct operation (see page 1-5-26).
(15) The message requesting paper to be loaded is shown when paper is present on the MP tray.	1. Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. MP paper sensor and engine PWB (YC16)
	2. Deformed actuator of the MP paper sensor.	Check visually and replace if necessary.
	3. Defective MP paper sensor.	Replace the MP paper sensor.
	4. Defective PWB.	Replace the engine PWB and check for correct operation (see page 1-5-26).
(16) The size of paper on the cassette is not displayed correctly.	1. Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. Cassette size switch and engine PWB (YC17)
	2. Defective cassette size switch.	Replace the cassette size switch.
	3. Defective PWB.	Replace the engine PWB and check for correct operation (see page 1-5-26).

Problem	Causes	Check procedures/corrective measures
(17) A paper jam in the paper feed, paper conveying or eject section is indicated when the main power switch is turned on.	1. A piece of paper torn from paper is caught around registration sensor, MP feed sensor or eject sensor.	Check visually and remove it, if any.
	2. Defective registration sensor.	Replace the registration sensor.
	3. Defective MP feed sensor.	Replace the MP feed sensor.
	4. Defective eject sensor.	Replace the eject PWB.
(18) A message indicating cover open is displayed when the top tray or rear cover is closed.	1. Deformed actuator of the interlock switch.	Check visually and replace if necessary.
	2. Defective interlock switch.	Replace the interlock switch.
(19) DP paper feed motor does not operate.	1. Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. DP paper feed motor and DP drive PWB (YC3) DP drive PWB (YC1) and main PWB (YC32)
	2. Defective drive transmission system.	Check if the rollers and gears rotate smoothly. If not, grease the bushes and gears. Check for broken gears and replace if any.
	3. Defective motor.	Replace the DP paper feed motor.
	4. Defective PWB.	Replace the DP drive PWB or main PWB and check for correct operation (see page 1-5-60, 1-5-29).
(20) DP paper feed clutch does not operate.	1. Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. DP paper feed clutch and DP drive PWB (YC6) DP drive PWB (YC8) and main PWB (YC32)
	2. Defective clutch.	Replace the DP paper feed clutch.
	3. Defective PWB.	Replace the DP drive PWB or main PWB and check for correct operation (see page 1-5-60, 1-5-29).
(21) DP pressure solenoid does not operate.	1. Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. DP pressure solenoid and DP drive PWB (YC4) DP drive PWB (YC8) and main PWB (YC32)
	2. Defective solenoid.	Replace the DP pressure solenoid.
	3. Defective PWB.	Replace the DP drive PWB or main PWB and check for correct operation (see page 1-5-60, 1-5-29).

Problem	Causes	Check procedures/corrective measures
(22) DP switchback solenoid does not operate.	1. Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. DP switchback solenoid and DP drive PWB (YC5) DP drive PWB (YC8) and main PWB (YC32)
	2. Defective solenoid.	Replace the DP switchback solenoid.
	3. Defective PWB.	Replace the DP drive PWB or main PWB and check for correct operation (see page 1-5-60, 1-5-29).
(23) An original jams when the main power switch is turned on.	1. A piece of paper torn from an original is caught around the DP timing sensor.	Check visually and remove it, if any.
	2. Defective DP timing sensor.	Replace the DP timing sensor.
(24) A message indicating cover open is displayed when the DP top cover is closed.	1. Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable. DP open/close sensor and DP drive PWB (YC2) DP drive PWB (YC8) and main PWB (YC32)
	2. Defective DP open/close sensor.	Replace the DP open/close sensor.

1-4-5 Mechanical problems

If the part causing the problem was not supplied, use the unit including the part for replacement.

Problem	Causes/check procedures	Corrective measures
(1) No primary paper feed.	Check if the surfaces of the following rollers are dirty with paper powder. Pickup roller Paper feed roller MP paper feed roller	Clean with isopropyl alcohol.
	Check if the following rollers is deformed. Pickup roller Paper feed roller MP paper feed roller	Check visually and replace any deformed (see page 1-5-14, 1-5-16).
	Defective paper feed clutch installation.	Check visually and remedy if necessary.
(2) No secondary paper feed.	Check if the surfaces of the following rollers are dirty with paper powder. Front registration roller Rear registration roller	Clean with isopropyl alcohol.
	Defective registration clutch installation.	Check visually and remedy if necessary.
(3) Skewed paper feed.	Paper width guide in a cassette installed incorrectly.	Check the paper width guide visually and remedy or replace if necessary.
(4) Multiple sheets of paper are fed.	Check if the paper is excessively curled.	Change the paper.
	Paper is loaded incorrectly.	Load the paper correctly.
	Check if the retard roller is worn.	Replace the retard roller if it is worn (see page 1-5-12).
(5) Paper jams.	Check if the paper is excessively curled.	Change the paper.
	Check if the contact between the front and rear registration rollers is correct.	Check visually and remedy if necessary.
	Check if the heat roller or press roller is extremely dirty or deformed.	Check visually and replace the fuser unit (see page 1-5-25).
(6) Toner drops on the paper conveying path.	Check if the drum unit or developing unit is extremely dirty.	Clean the drum unit or developing unit.
(7) Abnormal noise is heard.	Check if the rollers, pulleys and gears operate smoothly.	Grease the bushes and gears.
	Check if the following clutches are installed correctly. Paper feed clutch MP feed clutch Registration clutch Middle clutch	Check visually and remedy if necessary.

Problem	Causes/check procedures	Corrective measures
(8) No primary original feed.	Check if the surfaces of the following pulleys are dirty with paper powder. DP forwarding pulley DP feed pulley	Clean with isopropyl alcohol.
	Check if the following pulleys is deformed. DP forwarding pulley DP feed pulley	Check visually and replace any deformed (see page 1-5-55).
(9) Multiple sheets of original are fed.	Original is not correctly set.	Set the original correctly.
	Check if the DP separation pad is worn.	Replace the DP separation pad if it is worn (see page 1-5-59).
(10) Originals jam.	Originals outside the specifications are used.	Use only originals conforming to the specifications.
	Check if the surfaces of the following pulleys are dirty with paper powder. DP forwarding pulley DP feed pulley	Clean with isopropyl alcohol.
	Check if the contact between the conveying roller and conveying pulley is correct.	Check visually and remedy if necessary.
	Check if the contact between the eject roller and eject pulley is correct.	Check visually and remedy if necessary.
	Check if the contact between the switchback roller and switchback pulley is correct.	Check visually and remedy if necessary.

1-4-6 Send error code

(1) Scan to SMB error codes

Code	Display	Causes	Check procedures/corrective measures
1101	Host name error	Enter the disable host name of SMB server.	Enter the correct host name in COMMAND CENTER.
1102	User/Password or Folder/Shared name error	Domain name is not entered.	Enter the user name with the form of either [Domain¥User], [Domain/User] or [Domain@User].
		Assign disable user/password.	Enter the correct user name/password.
		Assign disable folder/shared name.	Enter the correct folder/shared name.
		Assign the user who is not allowed to access to folder.	Check the access limit of destination folder.
		Host name error.	Check if the prohibited letters are used to shared name. `~!@#\$%^&*()=+[]{ ;:'"<>/?
1103	Folder path or File name error	Domain name is not enter	Enter the user name with the form of either [Domain¥User], [Domain/User] or [Domain@User].
		Assign disable folder path.	Enter correct folder path.
		Assign the user who is not allowed to access to folder.	Check the access limit of destination folder.
1105	Protocol error	SMB protocol is set to OFF.	Enable SMB protocol in COMMAND CENTER.
2101	Server connect error	Enter the disable host name/IP address.	Enter the correct host name or IP address.
		Assign the wrong port number.	Enter the correct port number.
		Network is not connected.	Check if the server is operating properly. Check the network connection (cable. network condition within LAN, etc.).
2201	Network transfer error	Error occurs on the network.	Check the network connection (cable. network condition within LAN, etc.).
2203	Response wait with timeout error	Response is not returned from the server above specified time.	Check the network connection (cable. network condition within LAN, etc.).
9181	Page max count over error	The number of pages of a send file exceeded 999 pages.	Set the number of pages as 999 or less.

(2) Scan to FTP error codes

Code	Contents	Causes	Check procedures/corrective measures
1101	Host name error	Enter the disable host name of FTP server.	Enter the correct host name in COMMAND CENTER.
1102	User/Password error	Domain name is not entered.	Enter the user name with the form of either [Domain¥User] or [Domain/User].
		Assign disable user/password.	Enter the correct user name/password.
1103	Folder path or File name error	Connect to the folder which is not permitted for reference/writing.	Enter correct user name/password. Check the access limit of destination folder.
		Assign disable folder path.	Enter correct folder path.
1105	Protocol error	FTP protocol is set to OFF.	Enable FTP protocol in COMMAND CENTER
2101	Server connect error	Enter the disable host name/IP address.	Enter the correct host name or IP address.
		Assign the wrong port number.	Enter the correct port number.
		Network is not connected.	Check if the server is operating properly. Check the network connection (cable, network condition within LAN, etc.).
2102	Connect with timeout error	The server is unable to communicate.	Check if the server is operating properly.
		Send the server which does not support FTP server.	Enter the correct host name or IP address.
2103	Response wait with timeout error	The server is unable to communicate.	Check if the server is operating properly.
2201	Network transfer error	Error occurs on the network.	Check the network connection (cable, network condition within LAN, etc.).
2202	Network transfer with timeout error	Error occurs on the network.	Check the network connection (cable, network condition within LAN, etc.).
2203	Response wait with timeout error	Response is not returned from the server above specified time.	Check the network connection (cable, network condition within LAN, etc.).
3101	Server response error	The server is error status.	Check if the server is working properly.
9181	Page max count over error	The number of pages of a send file exceeded 999 pages.	Set the number of pages as 999 or less.

(3) Scan to E-mail error codes

Code	Display	Causes	Check procedures/corrective measures
1101	Server name error	Enter the disable SMTP/POP3 server name.	Enter the correct server name in COMMAND CENTER.
1102	User/Password error	Assign disable user/password.	Enter the correct user name/password.
1104	No recipient address	The destination address is not specified.	Specify the destination address.
1105	Protocol error	SMTP protocol is set to OFF.	Enable SMTP protocol in COMMAND CENTER
2101	Server connect error	Select [Other authenticate] when authenticating POP before SMTP.	Select valid POP3 user other than [Other].
		The specified server is not SMTP server.	Enter the correct server name in COMMAND CENTER.
		Network is not connected.	Check if the server is operating properly. Check the network connection (cable. network condition within LAN, etc.).
2102	Connect with timeout error	The server is unable to communicate.	Check if the server is operating properly.
2103	Response wait with timeout error	The server is unable to communicate.	Check if the server is operating properly.
2201	Response wait with timeout error	Error occurs on the network.	Check the network connection (cable. network condition within LAN, etc.).
2202	Network transfer error	Error occurs on the network.	Check the network connection (cable. network condition within LAN, etc.).
2203	Response wait with timeout error	Response is not returned from the server above specified time.	Check the network connection (cable. network condition within LAN, etc.).
2204	E-Mail size limit error	The size of E-mail exceeds its limit.	Change the E-mail size limit] in COMMAND CENTER.
3101	Server response error	The server is error status.	Check if the server is working properly.
		Server setting is not authenticated normally.	Check the settings for client/server authentication.
3201	Authentication Mechanism error	Unsupported SMTP Authentication Mechanism is found.	Check the settings for client/server Authentication Mechanism.
9181	Page max count over error	The number of pages of a send file exceeded 999 pages.	Set the number of pages as 999 or less.

(4) Software trouble error codes

Code	Display	Causes	Check procedures/corrective measures
5101	Not yet connected	Operation handle error. Error for stored status in the operation handle.	Turn the main power switch off and on.
5102	Already connected	Operation handle error. Error for stored status in the operation handle.	Turn the main power switch off and on.
5103	Not yet opened	Error for stored status in the operation handle.	Turn the main power switch off and on.
5104	Already opened error	Error for stored status in the operation handle.	Turn the main power switch off and on.
7101	Memory Allocation error	Insufficient memory space.	Turn the main power switch off and on.
7102	Socket create error	Unable to create a communication socket.	Turn the main power switch off and on.
720f	Unknown error	Unable to determine the cause.	Turn the main power switch off and on.

1-4-7 Error codes

(1) Error code

Error codes are listed on the communication reports, activity report, etc. The codes consist of an error code indication U followed by a 5-digit number. (Error codes for V34 communication errors start with an E indication, followed by five digits.)

The upper three of the five digits indicate general classification of the error and its cause, while the lower two indicate the detailed classification. Items for which detailed classification is not necessary have 00 as the last two digits.




Figure 1-4-4

(2) Table of general classification

Error code	Description
U00000	No response or busy after the set number of redials.
U00100	Transmission was interrupted by a press of the stop/clear key.
U00200	Reception was interrupted by a press of the stop/clear key.
U00300	Recording paper on the destination unit has run out during transmission.
U004XX	A connection was made but interrupted during handshake with the receiver unit (refer to 1-4-49 U004XX error code table).
U006XX	Communication was interrupted because of a machine problem (refer to 1-4-49 U006XX error code table).
U00700	Communication was interrupted because of a problem in the destination unit.
U008XX	A page transmission error occurred in G3 mode (refer to 1-4-49 U008XX error code table).
U009XX	A page reception error occurred in G3 mode (refer to 1-4-49 U009XX error code table).
U010XX	Transmission in G3 mode was interrupted by a signal error (refer to 1-4-50 U010XX error code table).
U011XX	Reception in G3 mode was interrupted by a signal error (refer to 1-4-51 U011XX error code table).
U01400	An invalid one-touch key was specified during communication.
U01500	A communication error occurred when calling in V.8 mode.
U01600	A communication error occurred when called in V.8 mode.
U017XX	A communication error occurred before starting T.30 protocol during transmission in V.34 mode (refer to 1-4-52 U017XX error code table).
U018XX	A communication error occurred before starting T.30 protocol during reception in V.34 mode (refer to 1-4-52 U018XX error code table).
U03000	No document was present in the destination unit when polling reception started.
U03200	In interoffice subaddress-based bulletin board reception, data was not stored in the box specified by the destination unit.
U03300	In polling reception from a unit of our make, operation was interrupted due to a mismatch in permit ID or telephone number. Or, in interoffice subaddress-based bulletin board reception, operation was interrupted due to a mismatch in permit ID or telephone number.
U03400	Polling reception was interrupted because of a mismatch in individual numbers (destination unit is either of our make or by another manufacturer).
U03500	In interoffice subaddress-based bulletin board reception, the specified Subaddress confidential box number was not registered in the destination unit.
U03600	An interoffice subaddress-based bulletin board reception was interrupted because of a mismatch in the specified subaddress confidential box number.
U03700	Interoffice subaddress-based bulletin board reception failed because the destination unit had no subaddress-based bulletin board transmission capability, or data was not stored in any subaddress confidential box in the destination unit.
U04000	In interoffice subaddress-based transmission mode, the specified subaddress box number was not registered in the destination unit.

Error code	Description
U04100	Subaddress-based transmission failed because the destination unit had no subaddress-based reception capability.
U04200	In encrypted transmission, the specified encryption box was not registered in the destination unit.
U04300	Encrypted transmission failed because the destination unit had no encrypted communication capability.
U04400	Encrypted transmission was interrupted because encryption keys did not agree.
U04500	Encrypted reception was interrupted because of a mismatch in encryption keys.
U05100	Password check transmission or restricted transmission was interrupted because the permit ID's did not agree with.
U05200	Password check reception or restricted reception was interrupted because the permit ID's did not match, the rejected FAX number's did match, or the destination receiver did not return its phone number.
U05300	The password check reception or the restricted reception was interrupted because the permitted numbers did not match, the rejected numbers did match, or the machine in question did not acknowledge its phone number.
U14000	Memory overflowed during confidential reception. Or, in subaddress-based confidential reception, memory overflowed.
U14100	In interoffice subaddress-based transmission, memory overflowed in the destination unit.
U19000	Memory overflowed during memory reception.
U19100	Memory overflowed in the destination unit during transmission.
U19300	Transmission failed because an error occurred during JBIG encoding.

(2-1) U004XX error code table: Interrupted phase B

Error code	Description
U00430	Polling request was received but interrupted because of a mismatch in permit number. Or, subaddress-based bulletin board transmission request was received but interrupted because of a mismatch in permit ID in the transmitting unit.
U00431	An subaddress-based bulletin board transmission was interrupted because the specified subaddress confidential box was not registered.
U00432	An subaddress-based bulletin board transmission was interrupted because of a mismatch in Subaddress confidential box numbers.
U00433	Subaddress-based bulletin board transmission request was received but data was not present in the subaddress confidential box.
U00440	Subaddress-based confidential reception was interrupted because the specified subaddress box was not registered.
U00450	The destination transmitter disconnected because the permit ID's did not agree with while the destination transmitter is in password-check transmission or restricted transmission.
U00460	Encrypted reception was interrupted because the specified encryption box number was not registered.
U00462	Encrypted reception was interrupted because the encryption key for the specified encryption box was not registered.

(2-2) U006XX error code table: Problems with the unit

Error code	Description
U00601	Document jam or the document length exceeds the maximum.
U00613	Image writing section problem
U00656	Data was not transmitted to a modem error.
U00690	System error.

(2-3) U008XX error code table: Page transmission error

Error code	Description
U00800	A page transmission error occurred because of reception of a RTN or PIN signal.
U00811	A page transmission error reoccurred after retry of transmission in the ECM mode.

(2-4) U009XX error code table: Page reception error

Error code	Description
U00900	An RTN or PIN signal was transmitted because of a page reception error.
U00910	A page reception error remained after retry of transmission in the ECM mode.

(2-5) U010XX error code table: G3 transmission

Error code	Description
U01000	An FTT signal was received for a set number of times after TCF signal transmission at 2400 bps. Or, an RTN signal was received in response to a Q signal (excluding EOP) after transmission at 2400 bps.
U01001	Function of the unit differs from that indicated by a DIS signal.
U01016	An MCF signal was received but no DIS signal was received after transmission of an EOM signal, and T1 timeout was detected.
U01019	No relevant signal was received after transmission of a CNC signal, and the preset number of command retransfers was exceeded (between units of our make).
U01020	No relevant signal was received after transmission of a CTC signal, and the preset number of command retransfers was exceeded (ECM).
U01021	No relevant signal was received after transmission of an EOR.Q signal, and the preset number of command retransfers was exceeded (ECM).
U01022	No relevant signal was received after transmission of an RR signal, and the preset number of command retransfers was exceeded (ECM).
U01028	T5 time-out was detected during ECM transmission (ECM).
U01052	A DCN signal was received after transmission of an RR signal (ECM).
U01080	A PIP signal was received after transmission of a PPS.NULL signal.
U01092	During transmission in V.34 mode, communication was interrupted because of an impossible combination of the symbol speed and communication speed.
U01093	A DCN or other inappropriate signal was received during phase B of transmission.
U01094	The preset number of command retransfers for DCS/NSS signals was exceeded during phase B of transmission.
U01095	No relevant signal was received after transmission of a PPS (Q) signal during phase D of transmission, and the preset number of command transfers was exceeded.
U01096	A DCN signal or invalid command was received during phase D of transmission.
U01097	The preset number of command retransfers was exceeded after transmission of an RR signal or no response.

(2-6) U011XX error code table: G3 reception

Error code	Description
U01100	Function of the unit differs from that indicated by a DCS signal.
U01101	Function of the unit (excl. communication mode select) differs from that indicated by an NSS signal.
U01102	A DTC (NSC) signal was received when no transmission data was in the unit.
U01110	No response after transmission of a DIS signal.
U01111	No response after transmission of a DTC (NSC) signal.
U01113	No response after transmission of an FTT signal.
U01125	No response after transmission of a CNS signal (between units of our make).
U01129	No response after transmission of an SPA signal (short protocol).
U01141	A DCN signal was received after transmission of a DTC signal.
U01143	A DCN signal was received after transmission of an FTT signal.
U01155	A DCN signal was received after transmission of an SPA signal (short protocol).
U01160	During message reception, transmission time exceeded the maximum transmission time per line.
U01162	Reception was aborted due to a modem malfunction during message reception.
U01191	Communication was interrupted because an error occurred during an image data reception sequence in the V.34 mode.
U01193	There was no response, or a DCN signal or invalid command was received, during phase C/D of reception.
U01194	A DCN signal was received during phase B of reception.
U01195	No message was received during phase C of reception.
U01196	Error line control was exceeded and a decoding error occurred for the message being received.

(2-7) U017XX error code table: V.34 transmission

Error code	Description
U01700	A communication error occurred in phase 2 (line probing).
U01720	A communication error occurred in phase 4 (modem parameter exchange).
U01721	Operation was interrupted due to the absence of a common communication speed between units.

U01700: A communication error that occurs at the transmitting unit in the period after transmission of INFO0 before entering phase 3 (primary channel equivalent device training). For example, INFO0/A/Abar (B/Bbar, for polling transmission)/INFOh was not detected.

U01720: A communication error that occurs at the transmitting unit in the period after initiating the control channel before entering the T.30 process. For example, PPh/ALT/MPh/E was not detected.

U01721: In the absence of a common communication speed between units (including when an impossible combination of communication speed and symbol speed occurs) after MPh exchange; 1) a DCN signal was received from the destination unit, and the line was cut; or 2) a DIS (NSF, CSI) signal was received from the destination unit and, in response to the signal, the unit transmitted a DCN signal, and the line was cut.

(2-8) U018XX error code table: V.34 reception

Error code	Description
U01800	A communication error occurred in phase 2 (line probing).
U01810	A communication error occurred in phase 3 (primary channel equivalent device training).
U01820	A communication error occurred in phase 4 (modem parameter exchange).
U01821	Operation was interrupted due to the absence of a common communication speed between units.

U01800: A communication error that occurs at the receiver unit in the period after transmission of INFO0 before entering phase 3 (primary channel equivalent device training). For example, INFO0/B/Bbar (A/Abar, for polling reception)/probing tone was not detected.

U01810: A communication error that occurs at the receiver unit in phase 3 (primary channel equivalent device training). For example, S/Sbar/PP/TRN was not detected.

U01820: A communication error that occurs at the receiver unit in the period after initiating the control channel before entering the T.30 process. For example, PPh/ALT/MPh/E was not detected.

U01821: In the absence of a common communication speed between units (including when an impossible combination of communication speed and symbol speed occurs) after MPh exchange, a DCN signal was transmitted to the destination unit and the line was cut.

1-5-1 Precautions for assembly and disassembly

(1) Precautions

Before starting disassembly, press the Power key on the operation panel to off. Make sure that the Power lamp is off before turning off the main power switch. And then unplug the power cable from the wall outlet.

When the fax kit is installed, be sure to disconnect the modular code before starting disassembly.

When handling PWBs (printed wiring boards), do not touch parts with bare hands.

The PWBs are susceptible to static charge.

Do not touch any PWB containing ICs with bare hands or any object prone to static charge.

When removing the hook of the connector, be sure to release the hook.

Take care not to get the cables caught.

To reassemble the parts, use the original screws. If the types and the sizes of screws are not known, refer to the PARTS LIST.

(2) Drum

Note the following when handling or storing the drum.

When removing the drum unit, never expose the drum surface to strong direct light.

Keep the drum at an ambient temperature between -20°C/-4°F and 40°C/104°F and at a relative humidity not higher than 85% RH. Avoid abrupt changes in temperature and humidity.

Avoid exposure to any substance which is harmful to or may affect the quality of the drum.

Do not touch the drum surface with any object. Should it be touched by hands or stained with oil, clean it.

(3) Toner

Store the toner container in a cool, dark place.

Avoid direct light and high humidity.

(4) How to tell a genuine Kyocera Mita toner container

As a means of brand protection, the Kyocera Mita toner container utilizes an optical security technology to enable visual validation. A validation viewer is required to accomplish this.

Hold the validation viewer over the left side part of the brand protection seal on the toner container. Through each window of the validation viewer, the left side part of the seal should be seen as follows:

A black-colored band when seen through the left side window (●)

A shiny or gold-colored band when seen through the right side window (☀)

The above will reveal that the toner container is a genuine Kyocera Mita branded toner container, otherwise, it is a counterfeit.




Figure 1-5-1

The brand protection seal has an incision as shown below to prohibit reuse.




Figure 1-5-2

1-5-2 Outer covers

(1) Detaching and refitting the rear upper cover, right upper cover, left upper cover and front cover

Procedure

1. Open the paper conveying unit.
2. Release the hook and then remove the IF cover.




Figure 1-5-3

3. Remove two screws and then remove the rear upper cover.




Figure 1-5-4

4. Pull the top tray lever and open the top tray.
5. Release the hook. Slide the right upper cover backward and then remove it.




Figure 1-5-5

6. Release the hook. Slide the left upper cover backward and then remove it.




Figure 1-5-6

7. Release five hooks (hook A → B) and then remove the front cover.




Figure 1-5-7

(2) Detaching and refitting the right rear cover, right cover and right lower cover

Procedure

1. Remove the rear upper cover, right upper cover, left upper cover and front cover (see page 1-5-3).
2. Slide the power source cover backward and then remove it.




Figure 1-5-8

3. Remove the screw.
4. Release four hooks. Slide the right rear cover backward and then remove it.




Figure 1-5-9

5. Open the memory cover and then remove it.




Figure 1-5-10

6. Release four hooks (hook A → B). Slide the right cover forward and then remove it.
7. Remove the waste toner cover.




Figure 1-5-11

8. Release the hook. Slide the right lower cover forward and then remove it.




Figure 1-5-12

(3) Detaching and refitting the left rear cover, left cover and left lower cover

Procedure

1. Remove the rear upper cover, right upper cover, left upper cover and front cover (see page 1-5-3).
2. Release the hook. Slide the left rear cover upward and then remove it.




Figure 1-5-13

3. Release four hooks (hook A → B) and then remove the left cover.





Figure 1-5-14


4. Remove the screw.
5. Release three hooks (hook A → B) and then remove the left lower cover.

**Figure 1-5-15**

(4) Detaching and refitting the inner cover

Procedure

1. Remove the rear upper cover, right upper cover, left upper cover and front cover (see page 1-5-3).
2. Remove the right rear cover, right cover and right lower cover (see page 1-5-6).
3. Remove the left rear cover, left cover and left lower cover (see page 1-5-9).
4. Release four hooks and then remove the inner cover.



Inner cover




Figure 1-5-16

1-5-3 Paper feed section

(1) Detaching and refitting the retard roller unit

Procedure

1. Remove the cassette.




Figure 1-5-17

2. Open the paper conveying unit.
3. Pull the middle roller unit forward to the hook.
4. While pressing the right and left hooks outwards, unlatch the shaft from the rail and remove the middle roller unit.





Figure 1-5-18

5. Pull the retard cover down and remove.
6. Release two hooks and then remove the retard roller unit.
7. Check or replace the retard roller unit and refit all the removed parts.




Figure 1-5-19

(2) Detaching and refitting the paper feed roller unit

Procedure

1. Remove the retard roller unit (see page 1-5-12).
2. Turn forward the lever of the feed pin to release the lock.
3. Slide the feed pin.




Figure 1-5-20

4. Remove the paper feed roller unit.
5. Check or replace the paper feed roller unit and refit all the removed parts.




Figure 1-5-21

(3) Detaching and refitting the MP paper feed roller

Procedure

1. Remove the cassette.
2. Raise the MP tray cover upward.
Release two hooks and then remove the MP tray cover.




Figure 1-5-22

3. Open the conveying lower cover.




Figure 1-5-23

- Remove two screws and then remove the MP paper feed lower unit.




Figure 1-5-24

- Pull the hook forward and then slide the MP feed shaft.
- Remove the MP paper feed roller.
- Check or replace the Mp paper feed roller and refit all the removed parts.




Figure 1-5-25

1-5-4 Developing section

(1) Detaching and refitting the developing unit

Procedure

1. Remove the intermediate transfer unit (see page 1-5-21).
2. Remove drum units (K, M, C, Y).
3. Pinch the lever of developing unit.
4. Remove developing units (K, M, C, Y).




Figure 1-5-26

5. Check or replace the developing unit and refit all the removed parts.

NOTE:

- *: Remove the cap before installing the new developing unit.
- *: When reinstalling the developing unit, press it down until the lever of developing unit is engaged with the notch.
- *: If it is difficult to engage the lever, press the unit down while rotating the gear to engage it.





Figure 1-5-27

1-5-5 Drum section

(1) Detaching and refitting the drum unit

Procedure

1. Remove the intermediate transfer unit (see page 1-5-21).
2. Remove drum units (K, M, C, Y).
3. Check or replace the drum unit and refit all the removed parts.




Figure 1-5-28

1-5-6 Transfer/Separation section

(1) Detaching and refitting the intermediate transfer unit

Procedure

1. Open the top tray and the paper conveying unit.
2. Remove toner containers (K, M, C, Y).




Figure 1-5-29

3. Slide the container guide forward and then remove it.




Figure 1-5-30

4. Open the RFID holder.




Figure 1-5-31

5. Slide the shutter forward and seal the toner inlet.
6. Remove the screw.




Figure 1-5-32

7. Remove the intermediate transfer unit.
8. Check or replace the intermediate transfer unit and refit all the removed parts.




Figure 1-5-33

(2) Detaching and refitting the transfer roller unit

Procedure

1. Open the paper conveying unit.
2. Release two hooks and then remove the transfer roller unit.
3. Check or replace the transfer roller unit and refit all the removed parts.




Figure 1-5-34

1-5-7 Fuser section

(1) Detaching and refitting the fuser unit

Procedure

1. Open the paper conveying unit.
2. Remove the IF cover (see page 1-5-3).
3. Remove the screw and then fuser wire cover.




Figure 1-5-35

4. Remove three connectors.
5. Remove two screws and then remove the fuser unit.
6. Check or replace the fuser unit and refit all the removed parts.




Figure 1-5-36

1-5-8 PWBs

(1) Detaching and refitting the engine PWB

Procedure

1. Remove the left cover (see page 1-5-9).
2. Remove all connectors from the engine PWB.





Figure 1-5-37

3. Remove three screws and then remove the engine PWB.
 4. Check or replace the engine PWB and refit all the removed parts.
- *: To replace the engine PWB, remove the EEPROM (U1) from the old engine PWB and mount it to the new engine PWB.

**Figure 1-5-38**

(2) Detaching and refitting the power source PWB

Procedure

1. Remove the right rear cover, right cover and right lower cover (see page 1-5-6).
2. Remove three screws and then remove the power source shield.
Screws A and B are unidentical, therefore, do not mix up.




Figure 1-5-39

3. Remove all connectors from power source PWB.
4. Remove two screws.
5. Release three hooks and then remove the power source PWB.
6. Check or replace the power source PWB and refit all the removed parts.





Figure 1-5-40

(3) Detaching and refitting the main PWB

Procedure

1. Remove the FAX control PWB, if installed (see page 1-5-35).
2. Remove the right rear cover, right cover and right lower cover (see page 1-5-6).
3. Remove three screws and then remove the power source shield.
Screws A and B are unidentical, therefore, do not mix up.




Figure 1-5-41

4. Open the fan bracket.
5. Slide the fan plate. Release four hooks and then remove the fan plate.




Figure 1-5-42

- 6. Remove the screw and then remove the fuser wire cover.




Figure 1-5-43

- 7. Remove five screws and then remove the controller shield.




Figure 1-5-44

- 8. Remove the connector (YC41) of the controller fan motor.
- 9. Open the fan bracket and then remove it.




Figure 1-5-45

- 10. Remove seven connectors (YC15, YC37, YC41, YC40, YC38, YC39 and YC42) from the main PWB.




Figure 1-5-46

11. Remove two screws.
12. Release three hooks and then remove the wire holder.




Figure 1-5-47

13. Remove three connectors (YC36, YC32, YC12) and two FFCs (YC8, YC43) from the main PWB.





Figure 1-5-48

14. Remove five screws and then remove the main PWB.
15. Check or replace the main PWB and refit all the removed parts.

**Figure 1-5-49**

(4) Detaching and refitting the high voltage PWB

Procedure

1. Remove the right rear cover and right cover (see page 1-5-6).
2. Remove the FFC from the high voltage PWB.




Figure 1-5-50

3. Remove the screw.
4. Release eight hooks and then remove the high voltage PWB.
5. Check or replace the high voltage PWB and refit all the removed parts.






Figure 1-5-51

(5) Detaching and refitting the FAX control PWB (4 in 1 model (with FAX) only)**Procedure**

1. Remove the IF cover (see page 1-5-3).
2. Remove two screws and then remove the FAX control PWB.
3. Check or replace the FAX control PWB and refit all the removed parts.

**Figure 1-5-52**

1-5-9 Drive section

(1) Detaching and refitting the MP feed drive unit

Procedure

1. Remove the rear upper cover, right upper cover, left upper cover and front cover (see page 1-5-3).
2. Remove the right rear cover and right cover (see page 1-5-6).
3. Remove the left rear cover, left cover and left lower cover (see page 1-5-9).
4. Remove the inner cover (see page 1-5-11).
5. Remove the engine PWB (see page 1-5-26).
6. Release three hooks and then remove the left fan motor.




Figure 1-5-53

7. Turn the cam inside the device to the position indicated.
8. Remove three screws and then remove MP feed drive unit.
9. Check or replace the MP feed drive unit and refit all the removed parts.





Figure 1-5-54

(2) Detaching and refitting the drum/developing drive unit

Procedure

1. Remove drum units (K, M, C, Y) and developing units (K, M, C, Y) (see page 1-5-20, 18).
2. Remove the rear upper cover, right upper cover, left upper cover and front cover (see page 1-5-3).
3. Remove the left rear cover, left cover and left lower cover (see page 1-5-9).
4. Remove the engine PWB (see page 1-5-26).
5. Remove the screw and release the hook, and then remove the developing fan unit.




Figure 1-5-55

6. Remove the screw and then remove the ID guide.




Figure 1-5-56

7. Remove five screws and then remove drum/developing drive unit.
8. Check or replace the drum/developing drive unit and refit all the removed parts.




Figure 1-5-57

(3) Detaching and refitting the paper feed drive unit

Procedure

1. Remove the rear upper cover, right upper cover, left upper cover and front cover (see page 1-5-3).
2. Remove the left rear cover, left cover and left lower cover (see page 1-5-9).
3. Remove connector (YC3) from engine PWB.




Figure 1-5-58

4. Remove four screws and then remove the paper feed drive unit.
5. Check or replace the paper feed drive unit and refit all the removed parts.




Figure 1-5-59

(4) Detaching and refitting the fuser pressure drive unit

Procedure

1. Remove the fuser unit (see page 1-5-25).
2. Remove the rear upper cover, right upper cover, left upper cover and front cover (see page 1-5-3).
3. Remove the left rear cover and left cover (see page 1-5-9).
4. Remove connector (YC38) from engine PWB.




Figure 1-5-60

5. Remove the developing fan unit (see page 1-5-37).
6. Remove three screws.
7. Release two hooks remove the fuser pressure drive unit.
8. Check or replace the fuser pressure drive unit and refit all the removed parts.




Figure 1-5-61

(5) Detaching and refitting the middle transfer drive unit

Procedure

1. Remove the intermediate transfer unit (see page 1-5-21).
2. Remove the rear upper cover, right upper cover, left upper cover and front cover (see page 1-5-3).
3. Remove the left rear cover and left cover (see page 1-5-9).
4. Remove the fuser pressure drive unit (see page 1-5-40).
5. Remove connector (YC15) from engine PWB.






Figure 1-5-62

6. Remove the screw and then remove the ID guide.

**Figure 1-5-63**

7. Remove three screws and then remove the middle transfer drive unit.
8. Check or replace the middle transfer drive unit and refit all the removed parts.

**Figure 1-5-64**

1-5-10 Optical section

(1) Detaching and refitting the laser scanner unit

Procedure

1. Remove the intermediate transfer unit (see page 1-5-21).
2. Remove drum units (K, M, C, Y) and developing units (K, M, C, Y) (see page 1-5-20, 18).
3. Remove the rear upper cover, right upper cover, left upper cover and front cover (see page 1-5-3).
4. Remove the left rear cover and left cover (see page 1-5-9).
5. Remove two connectors (YC31, YC32) from engine PWB.





Figure 1-5-65

6. Draw two connectors (YC31, YC32) into the machine inside.




Figure 1-5-66

7. Remove the right rear cover, right cover and right lower cover (see page 1-5-6).
8. Remove the controller shield (see page 1-5-29).
9. Remove two connectors (YC38, YC40) from main PWB.




Figure 1-5-67

10. Draw two connectors (YC38, YC40) into the machine inside.




Figure 1-5-68

11. Remove each three screws and then remove laser scanner unit (KM, CY).
12. Check or replace the laser scanner unit and refit all the removed parts.





Figure 1-5-69

(2) Detaching and refitting the scanner unit

Procedure

1. Remove the document processor (see page 1-5-51).
2. Remove the connector (YC36) and two FFCs (YC8, YC43) from main PWB.
3. Open the scanner unit.




Figure 1-5-70

4. Remove the motor wire, CCD wire and LCD wire from the wire holder.




Figure 1-5-71

5. Release each four hooks and then remove left and right rails.




Figure 1-5-72

6. Remove two springs from left and right rails.




Figure 1-5-73

7. Remove left and right rails from the scanner unit.




Figure 1-5-74

8. Remove left and right washers and springs and then pull pins out.




Figure 1-5-75

9. Remove the scanner unit.




Figure 1-5-76

1-5-11 Document processor

(1) Detaching and refitting the document processor

Procedure

1. Remove the rear upper cover, right upper cover, left upper cover and front cover (see page 1-5-3).
2. Remove left and right pins and then close the top tray.




Figure 1-5-77

3. Release four hooks and then remove the upper middle cover.




Figure 1-5-78

4. Remove the right rear cover, right cover and right lower cover (see page 1-5-6).
5. Remove the controller shield (see page 1-5-29).
6. Remove connector (YC32) from main PWB.




Figure 1-5-79

7. Remove the DP wire and ground wire from wire holder.
8. Close the scanner unit.




Figure 1-5-80

9. Press the DP lock lever through the hole at the bottom right side of the scanner unit, and open the document processor.




Figure 1-5-81

10. Remove the wire cover.




Figure 1-5-82

11. Remove the document processor.




Figure 1-5-83

(2) Detaching and refitting the DP paper feed pulley unit

Procedure

1. Open the DP top cover.
2. Remove the screw.
3. Release three hooks and then remove the DP rear cover.




Figure 1-5-84

4. Release two hooks and then remove the DP front cover.




Figure 1-5-85

5. Remove the stop ring and bush.




Figure 1-5-86

6. Remove the stop ring A and then remove the DP paper feed clutch from the PF shaft.
7. Remove the stop ring B and then remove the PF collar, spring, spring collar, pin and bush from the PF shaft.




Figure 1-5-87

8. Remove the DP forwarding pulley unit.




Figure 1-5-88

- 9. Remove the stop ring A.
- 10. Remove the DP feed pulley unit from the LF holder.
- 11. Remove the stop ring B.
- 12. Remove the PF collar, spring, spring collar and pin from the PF shaft.
- 13. Remove the DP feed pulley, one-way clutch, PF pulley gear and pin from the PF shaft.





Figure 1-5-89

14. Remove the PF stopper from the LF holder.
15. Remove the stop ring.
16. Pull out the LF shaft and then remove the LF gear 18, joint gear and DP forwarding pulley.
17. Check or replace the DP feed pulley and DP forwarding pulley, and refit all the removed parts.

**Figure 1-5-90**

(3) Detaching and refitting the DP separation pad

Procedure

1. Remove the DP paper feed pulley unit (see page 1-5-55).
2. Remove the DP separation pad.
3. Check or replace the DP separation pad and refit all the removed parts.




Figure 1-5-91

(4) Detaching and refitting the DP drive PWB

Procedure

1. Remove the DP rear cover (see page 1-5-55).
2. Remove all connectors from DP drive PWB.
3. Remove the screw and then remove the DP drive PWB.
4. Check or replace the DP drive PWB and refit all the removed parts.




Figure 1-5-92

1-5-12 Others

(1) Detaching and refitting the paper conveying unit

Procedure

1. Open the rear cover.
2. Remove left and right straps.




Figure 1-5-93

3. Remove the rear cover unit.




Figure 1-5-94

4. Remove the paper conveying unit.




Figure 1-5-95

(2) Detaching and refitting the operation panel

Procedure

1. Release four hooks and then remove the operation panel.
2. Remove the FFC from connector.
3. Check or replace the operation panel and refit all the removed parts.




Figure 1-5-96

(3) Direction of installing the principal fan motors

When detaching or refitting the fan motors, be careful of the airflow direction (intake or exhaust).




Figure 1-5-97

1-6-1 Upgrading the firmware

Follow the procedure below to upgrade the firmware of main PWB (main controller and scanner), engine PWB, FAX control PWB*, optional language, optional paper feeder and color table.

Preparation

Extract the file that has the download firmware and put them in the USB Memory.

Procedure

1. Turn ON the main power switch and confirm if the screen shows "Ready to print" then, turn OFF the main power switch.
2. Insert USB memory that has the firmware in the USB memory slot.
3. Turn ON the main power switch.
4. About 40 seconds later, "FW-Update" will be displayed and blinking the data LED (this shows to start the download).
5. Display the software that now upgrading.

"FW-Update [CTRL]"
 "FW-Update [ENGIN]"
 "FW-Update [PF1]"
 "FW-Update [PF2]"
 "FW-Update [SCAN]"
 "FW-Update [FAX]" *
 "FW-Update [OPT]"
 "FW-Update [CLT]"

6. Display the completion of the upgrade (Data LED is ON condition).
7. ROM version is confirmed by the content of the display.
8. Turn OFF the main power switch and remove the USB memory.




Figure 1-6-1

*: 4 in 1 model (with FAX) only.

1-6-2 Remarks on engine PWB replacement

When replacing the engine PWB, remove the EEPROM (U1) from the engine PWB that has been removed and then reattach it to the new engine PWB.




Figure 1-6-2

2-1-1 Paper feed/conveying section

Paper feed/conveying section consists of the paper feed unit that feeds paper from the cassette and the MP tray paper feed unit that feeds paper from the MP tray, and the paper conveying section that conveys the fed paper to the transfer/separation section.

(1) Cassette paper feed section

The cassette can contain 250 sheets. The sheet from the cassette is pulled out by rotation of the pickup roller and sent to the paper conveying section by rotation of the paper feed roller. Also the retard roller prevents multiple feeding of paper.




Figure 2-1-1 Cassette paper feed section

- | | |
|----------------------|-----------------------------|
| 1. Pickup roller | 7. Bottom plate |
| 2. Paper feed roller | 8. Lift work plate |
| 3. Retard roller | 9. Paper sensor (PS) |
| 4. Retard cover | 10. Actuator (paper sensor) |
| 5. Paper hook | 11. Lift sensor (LS) |
| 6. Cassette base | 12. Cassette PWB (CPWB) |




Figure 2-1-2 Cassette paper feed section block diagram

(2) MP tray paper feed section

The MP tray can contain 50 sheets. Feeding from the MP tray is performed by the rotation of the MP paper feed roller. Also, function of the MPF separation pad prevents paper from multiple feeding.




Figure 2-1-3 MP tray paper feed section

- | | |
|-------------------------|--------------------------------|
| 1. MP paper feed roller | 7. MPF base |
| 2. MPF separation pad | 8. MPF cover |
| 3. MPF bottom plate | 9. MPF tray |
| 4. Friction pad | 10. MP paper sensor (MPPS) |
| 5. MPF feed roller | 11. Actuator (MP paper sensor) |
| 6. Feed pulley | |




Figure 2-1-4 MP tray paper feed section block diagram

(3) Paper conveying section

The paper conveying section conveys paper to the transfer/separation section as paper feeding from the cassette or MP tray, or as paper refeeding for duplex printing. Paper by feeding is conveyed by the middle roller to the position where the registration sensor (RS) is turned on, and then sent to the transfer/separation section by the front registration roller and rear registration roller.




Figure 2-1-5 Paper conveying section

- | | |
|-------------------------|------------------------------------|
| 1. MPF feed rollers | 7. Front registration roller |
| 2. Feed pulleys | 8. Rear registration roller |
| 3. MPF feed upper guide | 9. MP feed sensor (MPFS) |
| 4. MPF feed lower guide | 10. Actuator (MP feed sensor) |
| 5. Middle roller | 11. Registration sensor (RS) |
| 6. Middle pulley | 12. Actuator (registration sensor) |




Figure 2-1-6 Paper conveying section block diagram

2-1-2 Drum section

The drum section consists of the drum, the charger roller unit, and the cleaning unit, and the drum surface is uniformly charged in preparation for formation of residual image by laser beam.

After transfer is complete, toner remaining on the drum surface is chipped off with the cleaning blade and is collected to the waste toner box with the drum screw. The cleaning lamp (CL) consists of LEDs and removes residual charge on the drum before main charging.




Figure 2-1-7 Drum section

- | | |
|----------------------------|-----------------------|
| 1. Drum | 5. Drum frame |
| 2. Charger roller | 6. Cleaning blade |
| 3. Charger cleaning roller | 7. Drum screw |
| 4. Charger case | 8. Cleaning lamp (CL) |




Figure 2-1-8 Drum section block diagram

2-1-3 Developing section

The developing unit consists of the sleeve roller that forms the magnetic brush, the magnet roller, the developing blade and the developing screws that agitate the toner. Also, the toner sensor (TS) checks whether or not toner remains in the developing unit.




Figure 2-1-9 Developing section

- | | |
|-----------------------|--------------------------|
| 1. Sleeve roller | 6. Developer case |
| 2. Magnet roller | 7. Upper developer cover |
| 3. Developing screw A | 8. Developer base |
| 4. Developing screw B | 9. Sleeve cover |
| 5. Developing blade | 10. Toner sensor (TS) |




Figure 2-1-10 Developing section block diagram

2-1-4 Optical section

The optical section consists of the image scanner section for scanning and the laser scanner section for printing.

(1) Image scanner section

The original image is illuminated by the exposure lamp (EL) and scanned by the CCD image sensor in the CCD PWB (CCDPWB) via the four mirrors and ISU lens, the reflected light being converted to an electrical signal.

If a document processor is used, the image scanner unit stops at the position of the DP contact glass and scans sequentially one row of the image on the original in synchronization with the moving timing of the original in the sub scan direction by driving the DP.




Figure 2-1-11 Scanner unit

- | | |
|----------------------------------|-------------------------------|
| 1. Contact glass | 6. ISU belt |
| 2. DP contact glass | 7. ISU shaft |
| 3. Original size indicator plate | 8. Image scanner unit (ISU) |
| 4. ISU top frame | 9. Home position sensor (HPS) |
| 5. ISU bottom frame | 10. ISU motor (ISUM) |




Figure 2-1-12 Image scanner unit (ISU)

- | | |
|-----------------------|--------------------------------|
| 1. Lamp mount | 8. Mirror D |
| 2. ISU housing | 9. ISU lens |
| 3. ISU reflector | 10. CCD PWB (CCDPWB) |
| 4. Exposure lamp (EL) | 11. Inverter PWB (INPWB) |
| 5. Mirror A | 12. Home position sensor (HPS) |
| 6. Mirror B | 13. ISU shaft |
| 7. Mirror C | |




Figure 2-1-13 Scanner unit block diagram

(2) Laser scanner section

The charged surface of the drum is then scanned by the laser beam from the laser scanner unit. The laser beam is dispersed as the polygon motor (PM) revolves to reflect the laser beam over the drum. Various lenses and mirror are housed in the laser scanner unit, adjust the diameter of the laser beam, and focalize it at the drum surface. Also the LSU cleaning motor (LSUCM) is activated to conduct automatically cleaning of the LSU dust shield glass.




Figure 2-1-14 Laser scanner unit (LSU)

- | | |
|-----------------------|--------------------------|
| 1. Polygon motor (PM) | 6. Mirror B |
| 2. Polygon mirror | 7. Mirror C |
| 3. f-θ lens A | 8. LSU dust shield glass |
| 4. f-θ lens B | 9. LSU spiral |
| 5. Mirror A | |




Figure 2-1-15 Laser scanner unit block diagram

2-1-5 Transfer/Separation section

The transfer/separation section consists of the intermediate transfer unit section and the secondary transfer roller section.

(1) Intermediate transfer unit section

The intermediate transfer unit section consists of the transfer cleaning unit, the transfer belt, and the four primary transfer rollers for respective color drums, and forms a full-color toner image by superimposing and transferring single-color toner images formed on each drum onto the transfer belt. Also with the ID sensors (IDS) mounted on the machine frame, the toner density on the transfer belt is measured.

The transfer cleaning unit collects toner remaining on the transfer belt after secondary transfer and forwards it as waste toner to the waste toner box.




Figure 2-1-16 Intermediate transfer unit section

- | | |
|------------------------------|-----------------------|
| 1. Tension roller | 7. Transfer belt |
| 2. Drive roller | 8. Cleaning fur brush |
| 3. Primary transfer roller K | 9. Cleaning roller |
| 4. Primary transfer roller M | 10. Cleaning blade |
| 5. Primary transfer roller C | 11. Cleaning screw |
| 6. Primary transfer roller Y | 12. ID sensors (IDS) |




Figure 2-1-17 Intermediate transfer unit section block diagram

(2) Secondary transfer roller section

The secondary transfer roller section consists of the secondary transfer roller mounted to the paper conveying unit and the separation brush. To the secondary transfer roller, DC bias is applied from the high voltage PWB (HVPWB). The toner image formed on the transfer belt is transferred to the paper by the potential difference and the paper is separated by curvature separation.




Figure 2-1-18 Secondary transfer roller section

- 1. Secondary transfer roller
- 2. Brush holder
- 3. Paper chute guide
- 4. Separation brush




Figure 2-1-19 Secondary transfer roller section block diagram

2-1-6 Fuser section

The paper sent from the transfer/separation section is interleaved between the heat roller and the press roller. The heat roller is heated by the fuser heater (FH), and the toner is fused by heat and pressure and fixed onto the paper because the press roller is pressed by the fuser press spring. The surface temperature of heat roller is detected by the fuser thermistor (FTH) and controlled by the engine PWB (EPWB). If the fuser section shows extremely high temperature, the power line will be shut off and the fuser heater (FH) is forced to turn off.




Figure 2-1-20 Fuser section

- | | |
|----------------------|----------------------------|
| 1. Heat roller | 6. Eject roller |
| 2. Press roller | 7. Eject pulley |
| 3. Upper fuser frame | 8. Fuser heater (FH) |
| 4. Fuser paper guide | 9. Fuser thermistor (FTH) |
| 5. Separators | 10. Fuser thermostat (FTS) |




Figure 2-1-21 Fuser section block diagram

2-1-7 Eject/Feedshift section

The paper eject/feedshift section consists of the conveying path which sends the paper that has passed the fuser section to the top tray or the duplex conveying section.




Figure 2-1-22 Eject/Feed shift section

- | | |
|----------------------|----------------------------------|
| 1. Eject roller | 7. Eject sensor (ES) |
| 2. Eject pulley | 8. Actuator (eject sensor) |
| 3. Eject roller | 9. Actuator (eject sensor) |
| 4. Eject pulley | 10. Paper full sensor |
| 5. Upper eject guide | 11. Actuator (paper full sensor) |
| 6. Change guide | |




Figure 2-1-23 Eject/Feed shift section block diagram

2-1-8 Duplex conveying section

The duplex conveying section consists of conveying path which sends the paper sent from the eject/feedshift section to the paper feed/conveying section when duplex printing.




Figure 2-1-24 Duplex conveying section




Figure 2-1-25 Duplex conveying section block diagram

2-1-9 Document processor

(1) Original feed section

The original feed section consists of the parts shown in figure. An original placed on the original table is conveyed to the original conveying section. Original is fed by the rotation of the DP forwarding pulley and DP feed pulley.




Figure 2-1-26 Original feed section

- | | |
|-------------------------|-----------------------------------|
| 1. DP forwarding pulley | 7. DP separation pad |
| 2. DP feed pulley | 8. Upper guide |
| 3. LF holder | 9. Switchback guide |
| 4. PF stopper | 10. DP original sensor (DPOS) |
| 5. Front separation pad | 11. Actuator (DP original sensor) |
| 6. LF friction plate | 12. Original table |

1




Figure 2-1-27 Original feed section block diagram

(2) Original conveying section

The original conveying section consists of the parts shown in figure. A conveyed original is scanned by the optical section (CCD) of main machine when it passes through the DP contact glass of main machine.




Figure 2-1-28 Original conveying section

- | | |
|-----------------------|--------------------------------|
| 1. Conveying roller A | 5. DP timing sensor (DPTS) |
| 2. Conveying pulley | 6. Actuator (DP timing sensor) |
| 3. Conveying bottom | 7. DP contact glass |
| 4. Reading guide | |




Figure 2-1-29 Original conveying section block diagram

(3) Original switchback/eject sections

The original switchback/eject sections consists of the parts shown in figure. An original of which scanning is complete is ejected to the original eject table by the eject roller. In the case of duplex switchback scanning, an original is conveyed temporarily to the switchback tray and conveyed again to the original conveying section by the switchback roller.




Figure 2-1-30 Original switchback/eject sections

- | | |
|-------------------------|----------------------------|
| 1. Conveying roller B | 6. Switchback guide |
| 2. Conveying pulley | 7. Switchback roller |
| 3. Eject roller | 8. Switchback pulley |
| 4. Eject pulley | 9. Switchback pulley mount |
| 5. Original eject table | 10. Switchback tray |




Figure 2-1-31 Original switchback/eject sections block diagram

2-2-1 Electrical parts layout

(1) PWBs




Figure 2-2-1 PWBs


- | | |
|--------------------------------------|---|
| 1. Main PWB (MPWB) | Controls the software such as the print data processing and provides the interface with computers. |
| 2. Engine PWB (EPWB)..... | Controls printer hardware such as high voltage/bias output control, paper conveying system control, and fuser temperature control, etc. |
| 3. Power source PWB (PSPWB) | After full-wave rectification of AC power source input, switching for converting to 24 V DC for output. Controls the fuser heater. |
| 4. High voltage PWB (HVPWB) | Generates main charging, developing bias, transfer bias and cleaning bias. |
| 5. Operation panel PWB (OPPWB) | Consists the LCD, LED indicators and key switches. |
| 6. LCD PWB (LCDPWB)..... | Controls the LCD display. |
| 7. Relay PWB (RPWB) | Consists of wiring relay circuit between main PWB and engine PWB and power source PWB. |
| 8. Drum relay PWB (DRRPWB)..... | Consists of wiring relay circuit between engine PWB and the drum units and developing units. |

9. Eject PWB (EJPWB) Consists of wiring relay circuit between engine PWB and each electrical component (eject section).
10. Cassette PWB (CPWB) Interconnects the engine PWB and each electrical component (cassette section).
11. Drum PWB K (DRPWB-K) Relays wirings from electrical components on the drum unit K. Drum individual information in EEPROM storage.
12. Drum PWB M (DRPWB-M) Relays wirings from electrical components on the drum unit M. Drum individual information in EEPROM storage.
13. Drum PWB C (DRPWB-C) Relays wirings from electrical components on the drum unit C. Drum individual information in EEPROM storage.
14. Drum PWB Y (DRPWB-Y) Relays wirings from electrical components on the drum unit Y. Drum individual information in EEPROM storage.
15. Developing PWB K (DEVPWB-K) Relays wirings from electrical components on the developing unit K.
16. Developing PWB M (DEVPWB-M) Relays wirings from electrical components on the developing unit M.
17. Developing PWB C (DEVPWB-C) Relays wirings from electrical components on the developing unit C.
18. Developing PWB Y (DEVPWB-Y) Relays wirings from electrical components on the developing unit Y.
19. APC PWB K (APCPWB-K) Generates and controls the laser beam (black).
20. APC PWB M (APCPWB-M) Generates and controls the laser beam (magenta).
21. APC PWB C (APCPWB-C) Generates and controls the laser beam (cyan).
22. APC PWB Y (APCPWB-Y) Generates and controls the laser beam (yellow).
23. PD PWB K (PDPWB-K) Controls horizontal synchronizing timing of laser beam (black).
24. PD PWB M (PDPWB-M) Controls horizontal synchronizing timing of laser beam (magenta).
25. PD PWB C (PDPWB-C) Controls horizontal synchronizing timing of laser beam (cyan).
26. PD PWB Y (PDPWB-Y) Controls horizontal synchronizing timing of laser beam (yellow).
27. CCD PWB (CCDPWB) Reads the image of originals.
28. Inverter PWB (INPWB) Controls the exposure lamp.
29. Fax control PWB (FCPWB)* Modulates, demodulates, compresses, decompresses and smoothes out image data, and converts resolution of image data.

*: 4 in 1 model (with FAX) only.

List of correspondences of PWB names

No.	Name used in service manual	Name used in parts list
1	Main PWB (MPWB)	PARTS PWB MAIN ASSY SP
2	Engine PWB (EPWB)	PARTS PWB ENGINE ASSY SP
3	Power source PWB (PSPWB)	PARTS SWITCHING REGULATOR SP
4	High voltage PWB (HVPWB)	PARTS HIGH VOLTAGE UNIT SP
5	Operation panel PWB (OPPWB)	-
6	LCD PWB (LCDPWB)	-
7	Relay PWB (RPWB)	-
8	Drum relay PWB (DRRPWB)	-
9	Eject PWB (EJPWB)	PARTS PWB ASSY EXIT SP
10	Cassette PWB (CPWB)	PARTS PWB ASSY CASSETTE SP
11	Drum PWB K (DRPWB-K)	-
12	Drum PWB M (DRPWB-M)	-
13	Drum PWB C (DRPWB-C)	-
14	Drum PWB Y (DRPWB-Y)	-
15	Developing PWB K (DEVPWB-K)	-
16	Developing PWB M (DEVPWB-M)	-
17	Developing PWB C (DEVPWB-C)	-
18	Developing PWB Y (DEVPWB-Y)	-
19	APC PWB K (APCPWB-K)	-
20	APC PWB M (APCPWB-M)	-
21	APC PWB C (APCPWB-C)	-
22	APC PWB Y (APCPWB-Y)	-
23	PD PWB K (PDPWB-K)	-
24	PD PWB M (PDPWB-M)	-
25	PD PWB C (PDPWB-C)	-
26	PD PWB Y (PDPWB-Y)	-
27	CCD PWB (CCDPWB)	-
28	Inverter PWB (INPWB)	-
29	Fax control PWB (FCPWB)	PARTS FAX UNIT J SP

(2) Switches and sensors**Figure 2-2-2 Switches and sensors**

- | | |
|--------------------------------------|---|
| 1. Main power switch (MSW) | Turns ON/OFF the AC power source. |
| 2. Interlock switch (ILSW) | Shuts off 24 V DC power line when the top tray and rear cover are opened. |
| 3. Cassette size switch (CSSW) | Detects the paper size dial setting of the paper setting dial. |
| 4. Paper sensor (PS) | Detects the presence of paper in the cassette. |
| 5. Lift sensor (LS)..... | Detects activation of upper limit of the bottom plate. |
| 6. Registration sensor (RS)..... | Controls the secondary paper feed start timing. |
| 7. MP paper sensor (MPPS) | Detects the presence of paper on the MP tray. |
| 8. MP feed sensor (MPFS) | Detects a paper misfeed in the MP conveying section. |
| 9. Eject sensor (ES)..... | Detects a paper misfeed in the fuser or eject section. |
| 10. Paper full sensor (PFS)..... | Detects the paper full in the top tray. |
| 11. Toner sensor K (TS-K) | Detects the toner density in the developing unit K. |
| 12. Toner sensor K (TS-M)..... | Detects the toner density in the developing unit M. |
| 13. Toner sensor K (TS-C)..... | Detects the toner density in the developing unit C. |
| 14. Toner sensor K (TS-Y)..... | Detects the toner density in the developing unit Y. |
| 15. ID sensor 1 (IDS1) | Measures image density for color calibration. |
| 16. ID sensor 2 (IDS2) | Measures image density for color calibration. |

17. Developing release switch (DEVRSW)..... Detects separation of developing units M, C and Y.
18. Waste toner sensor (WTS)..... Detects when the waste toner box is full.
19. Envelope switch (EVSW)..... Detects the envelope mode setting.
20. Top tray switch (TTSW)..... Breaks the safety circuit when the top tray is opened.
21. Toner container switch (TCSW) Detects the presence of the toner container.
22. Waste toner cover switch (WTCSW)..... Breaks the safety circuit when the waste toner cover is opened.
23. Fuser thermistor (FTH) Detects the heat roller temperature.
24. Outer temperature sensor (OTEMS)..... Detects the outside temperature and humidity.
25. Inner temperature sensor (ITEMS) Detects the inside temperature.
26. Home position sensor (HPS) Detects the ISU in the home position.

(3) Motors





Figure 2-2-3 Motors


- | | |
|---|--|
| 1. Paper feed motor (PFM) | Drives the paper feed section. |
| 2. Lift motor (LM)..... | Operates the bottom plate. |
| 3. Drum motor (DRM) | Drives the drum unit. |
| 4. Developing motor (DEVM)..... | Drives the developing unit. |
| 5. Fuser motor (FUM) | Drives the transfer section and the fuser section. |
| 6. Duplex motor (DUM)..... | Drives the duplex section. |
| 7. Toner motor K (TM-K)..... | Replenishes toner to the developing unit K |
| 8. Toner motor M (TM-M)..... | Replenishes toner to the developing unit M |
| 9. Toner motor C (TM-C)..... | Replenishes toner to the developing unit C |
| 10. Toner motor Y (TM-Y) | Replenishes toner to the developing unit Y |
| 11. Polygon motor KM (PM-KM)..... | Drives the polygon mirror KM. |
| 12. Polygon motor CY (PM-CY)..... | Drives the polygon mirror CY. |
| 13. Developing release motor (DEVRM)..... | Drives separation of developing units M, C and Y. |
| 14. LSU cleaning motor (LSUCM) | Drives LSU dust shield glass cleaning system. |
| 15. Fuser pressure release motor (FPRM) | Drives fuser pressure release. |
| 16. Left fan motor (LFM)..... | Cools the interior of machine. |
| 17. Right fan motor (RFM)..... | Cools the interior of machine. |



- 18. Controller fan motor (CONFM)..... Cools the controller section.
- 19. Fuser fan motor (FUFM) Cools the fuser section.
- 20. Container fan motor (CFM) Cools the toner container section.
- 21. ISU motor (ISUM) Drives the ISU.

(4) Others**Figure 2-2-4 Others**

- | | |
|-----------------------------------|---|
| 1. Paper feed clutch (PFCL) | Primary paper feed from cassette. |
| 2. MP feed clutch (MPFCL)..... | Controls the drive of MP conveying section. |
| 3. Registration clutch (RCL)..... | Controls the secondary paper feed. |
| 4. Middle clutch (MCL)..... | Controls the drive of conveying section. |
| 5. MP solenoid (MPSOL) | Controls the MP bottom plate. |
| 6. Cleaning lamp K (CL-K)..... | Eliminates the residual electrostatic charge on the drum (black). |
| 7. Cleaning lamp M (CL-M)..... | Eliminates the residual electrostatic charge on the drum (magenta). |
| 8. Cleaning lamp C (CL-C)..... | Eliminates the residual electrostatic charge on the drum (cyan). |
| 9. Cleaning lamp Y (CL-Y)..... | Eliminates the residual electrostatic charge on the drum (yellow). |
| 10. Fuser heater (FH) | Heats the heat roller. |
| 11. Fuser thermal cutout..... | Prevents overheating of the heat roller. |
| 12. Exposure lamp (EL) | Exposes originals. |

(5) Document processor**Figure 2-2-5 Document processor**

1. DP drive PWB (DPDPWB)..... Consists the solenoids and clutch driver circuit and wiring relay circuit.
2. DP original sensor (DPOS)..... Detects the presence of an original.
3. DP timing sensor (DPTS)..... Detects the original scanning timing.
4. DP open/close sensor (DPOCS)..... Detects the opening/closing of the DP.
5. DP paper feed motor (DPPFM)..... Drives the original feed section.
6. DP paper feed clutch (DPPFCL)..... Controls the drive of the DP forwarding pulley and DP feed pulley.
7. DP switchback solenoid (DPSBSOL).... Operates the switchback guide.
8. DP pressure solenoid (DPPRSOL)..... Operates the switchback pulley.

This page is intentionally left blank.

2-3-1 Power source PWB




Figure 2-3-1 Power source PWB silk-screen diagram

Connector	Pin	Signal	I/O	Voltage	Description	
YC101	1	LIVE	I	120 V AC 220-240 V AC	AC power input	
	Connected to AC inlet and main power switch	2	NEUTRAL	I	120 V AC 220-240 V AC	AC power input
YC102	1	NEUTRAL	O	120 V AC/0 V 220-240 V AC/0 V	FH: On/Off	
	Connected to fuser heater	2	LIVE	O	120 V AC 220-240 V AC	AC power to FH
YC103	1	+24V1	O	24 V DC	24 V DC power to RYPWB	
	Connected to relay PWB	2	GND	-	-	Ground
		3	GND	-	-	Ground
		4	GND	-	-	Ground
		5	GND	-	-	Ground
		6	+24V2	O	24 V DC	24 V DC power to RYPWB (via ILSW)
	7	+24V2	O	24 V DC	24 V DC power to RYPWB (via ILSW)	
	8	+24V2	O	24 V DC	24 V DC power to RYPWB (via ILSW)	
	9	+24V2	O	24 V DC	24 V DC power to RYPWB (via ILSW)	
	10	PSSLEEPN	I	0/3.3 V DC	Sleep mode signal: On/Off	
	11	ZCROSS	O	0/3.3 V DC (pulse)	Zero-cross signal	
	12	RELAY	I	0/3.3 V DC	Relay signal	
	13	HEATRE1	I	0/3.3 V DC	FH: On/Off	
YC104	1	+24V1	O	24 V DC	24 V DC power to ILSW	
	Connected to interlock switch	2	N.C	-	-	Not used
		3	+24V2	I	24 V DC	24 V DC power from ILSW
YC105	1	+24V1	O	24 V DC	24 V DC power to MPWB	
	Connected to main PWB	2	GND	-	-	Ground
		3	GND	-	-	Ground
		4	+5V1	O	5 V DC	5 V DC power to MPWB

2-3-2 Engine PWB




Figure 2-3-2 Engine PWB silk-screen diagram

Connector	Pin	Signal	I/O	Voltage	Description
YC3	1	MPFCLDRN	O	0/24 V DC	MPFCL: On/Off
Connected to MP feed clutch, paper feed clutch, paper feed motor, middle clutch and registration clutch	2	+24V3	O	24 V DC	24 V DC power to MPFCL
	3	FEDCLDRN	O	0/24 V DC	PFCL: On/Off
	4	+24V3	O	24 V DC	24 V DC power to PFCL
	5	N.C.	-	-	Not used
	6	FEMOTRDYN	I	0/3.3 V DC	PFM ready signal
	7	FEMOTCLK	O	0/3.3 V DC (pulse)	PFM clock signal
	8	FEMOTREN	O	0/3.3 V DC	PFM: On/Off
	9	GND	-	-	Ground
	10	+24V3	O	24 V DC	24 V DC power to PFM
	11	MIDCLDRN	O	0/24 V DC	MCL: On/Off
	12	+24V3	O	24 V DC	24 V DC power to MCL
	13	REGCLDRN	O	0/24 V DC	RCL: On/Off
	14	+24V3	O	24 V DC	24 V DC power to RCL
	YC4	1	+24V3	O	24 V DC
Connected to MP solenoid	2	MPSOLDRN	I	0/24 V DC	MPSOL: On/Off
YC6	1	VOSL	I	Analog	IDS1 detection signal
Connected to ID sensor 1	2	VOPL	I	Analog	IDS1 detection signal
	3	GND	-	-	Ground
	4	LEDREFL	O	Analog	IDS1 control signal
	5	+3.3V2	O	3.3 V DC	3.3 V DC power to IDS1
YC7	1	VOSR	I	Analog	IDS2 detection signal
Connected to ID sensor 2	2	VOPR	I	Analog	IDS2 detection signal
	3	GND	-	-	Ground
	4	LEDREFR	O	Analog	IDS2 control signal
	5	+3.3V2	O	3.3 V DC	3.3 V DC power to IDS2

Connector	Pin	Signal	I/O	Voltage	Description
YC8 Connected to relay PWB	1	+24V1	I	24 V DC	24 V DC power from RYPWB
	2	GND	-	-	Ground
	3	GND	-	-	Ground
	4	GND	-	-	Ground
	5	GND	-	-	Ground
	6	+24V3	O	24 V DC	24 V DC power from RYPWB
	7	+24V3	O	24 V DC	24 V DC power from RYPWB
	8	+24V3	O	24 V DC	24 V DC power from RYPWB
	9	+24V3	O	24 V DC	24 V DC power from RYPWB
	10	GND	-	-	Ground
	11	SLEEPN	O	0/3.3 V DC	Sleep mode signal: On/Off
	12	HYPINT	O	0/3.3 V DC	Interruption signal
	13	I2CINT	I	0/3.3 V DC (pulse)	Communication signal
	14	+3.3V2	I	3.3 V DC	3.3 V DC power from RYPWB
YC9 Connected to relay PWB	1	TCONTN	O	0/3.3 V DC	TCSW: On/Off
	2	EGHOLD	I	0/3.3 V DC	Engine hold signal
	3	ZCROSS	I	0/3.3 V DC (pulse)	Zero-cross signal
	4	RELAY	O	0/3.3 V DC	Power relay signal
	5	HEATRE1	O	0/3.3 V DC	FH: On/Off
	6	(HEATRE2)	-	-	Not used
	7	VSYNC	O	0/3.3 V DC	Horizontal synchronizing signal
	8	EGIRN	O	0/3.3 V DC	Engine interruption signal
	9	SBSY	O	0/3.3 V DC	Serial busy signal
	10	SDIR	O	0/3.3 V DC	Serial communication direction change signal
	11	SI	I	0/3.3 V DC (pulse)	Serial communication data signal input
	12	SO	O	0/3.3 V DC (pulse)	Serial communication data signal output
	13	SCKN	I	0/3.3 V DC (pulse)	Serial communication clock signal
	14	N.C.	-	-	Not used
	15	I2CSCL	I	0/3.3 V DC (pulse)	EEPROM clock signal
	16	GND	-	-	Ground
	17	I2CSDA	I/O	0/3.3 V DC (pulse)	EEPROM data signal
	18	MPFJAM	I	0/3.3 V DC	MPFS: On/Off
	19	+3.3V1_MFP	I	3.3 V DC	3.3 V DC power from RYPWB

Connector	Pin	Signal	I/O	Voltage	Description
YC10 Connected to waste toner sensor	1	LEDA	O	3.3 V DC	3.3 V DC power to WTS
	2	LEDK	O	0/3.3 V DC (pulse)	WTS LED emitter signal
	3	PTRE	I	Analog	WTS detection signal
	4	PTRC	O	3.3 V DC	3.3 V DC power to WTS
YC11 Connected to high voltage PWB	1	+24V3	O	24 V DC	24 V DC power to HVPWB
	2	+24V3	O	24 V DC	24 V DC power to HVPWB
	3	T1CCNT	O	PWM	Primary transfer bias control voltage (Cyan)
	4	HVCLKY	O	0/3.3 V DC (pulse)	Developing bias clock signal (Yellow)
	5	T1MCNT	O	PWM	Primary transfer bias control voltage (Magenta)
	6	HVCLKC	O	0/3.3 V DC (pulse)	Developing bias clock signal (Cyan)
	7	T2CNT	O	PWM	Secondary transfer bias control voltage
	8	BCMCNT	O	PWM	Developing magnet bias control voltage (Cyan)
	9	CLCNT	O	PWM	Cleaning bias control voltage
	10	BKMCNT	O	PWM	Developing magnet bias control voltage (Black)
	11	T1YCNT	O	PWM	Primary transfer bias control voltage (Yellow)
	12	BKSCNT	O	PWM	Developing sleeve bias control voltage (Black)
	13	T1KCNT	O	PWM	Primary transfer bias control voltage (Black)
	14	BYSCNT	O	PWM	Developing sleeve bias control voltage (Yellow)
	15	MYCNT	O	PWM	Main charger control voltage (Yellow)
	16	BMMCNT	O	PWM	Developing magnet bias control voltage (Magenta)
	17	MKCNT	O	PWM	Main charger control voltage (Black)
	18	BYMCNT	O	PWM	Developing magnet bias control voltage (Yellow)
	19	MCCNT	O	PWM	Main charger control voltage (Cyan)
	20	T2RREM	O	0/3.3 V DC (pulse)	Secondary transfer bias reverse signal
	21	MMCNT	O	PWM	Main charger control voltage (Magenta)
	22	BMSCNT	O	PWM	Developing sleeve bias control voltage (Magenta)
	23	MISENS	I	Analog	Main charger AC current signal
	24	BKACNT	O	PWM	Developing AC bias control voltage (Black)

Connector	Pin	Signal	I/O	Voltage	Description
YC11 Connected to high voltage PWB	25	BCACNT	O	PWM	Developing AC bias control voltage (Cyan)
	26	BMACNT	O	PWM	Developing AC bias control voltage (Magenta)
	27	BYACNT	O	PWM	Developing AC bias control voltage (Yellow)
	28	HVCLKK	O	0/3.3 V DC (pulse)	Developing bias clock signal (Black)
	29	BCSCNT	O	PWM	Developing sleeve bias control voltage (Cyan)
	30	HVCLKM	O	0/3.3 V DC (pulse)	Developing bias clock signal (Magenta)
	31	GND	-	-	Ground
	32	GND	-	-	Ground
YC13 Connected to drum motor	1	MOTREV (GND)	-	-	Ground
	2	MOTRDYN	I	0/3.3 V DC	DRM ready signal
	3	SPEEDSEL	O	0/3.3 V DC	DRM speed selection signal
	4	MOTCLK	O	0/3.3 V DC (pulse)	DRM clock signal
	5	MOTEN	O	0/3.3 V DC	DRM: On/Off
	6	GND	-	-	Ground
	7	+24V3	O	24 V DC	24 V DC power to DRM
YC14 Connected to developing motor	1	+24V3	O	24 V DC	24 V DC power to DEVM
	2	GND	-	-	Ground
	3	DLPMOTREN	O	0/3.3 V DC	DEVM: On/Off
	4	DLPMOTCLK	O	0/3.3 V DC (pulse)	DEVM clock signal
	5	DLPMOT RDYN	I	0/3.3 V DC	DEVM ready signal
	6	MOTREV	O	0/3.3 V DC	DEVM drive switch signal
YC15 Connected to fuser motor	1	IMAMOT RDYN	I	0/3.3 V DC	FUM ready signal
	2	IMAMOTCLK	O	0/3.3 V DC (pulse)	FUM clock signal
	3	IMAMOTREN	O	0/3.3 V DC	FUM: On/Off
	4	GND	-	-	Ground
	5	+24V3	O	24 V DC	24 V DC power to FUM
YC16 Connected to MP paper sensor	1	+3.3V2_LED1	O	3.3 V DC	3.3 V DC power to MPPS
	2	GND	-	-	Ground
	3	MPFPAP	I	0/3.3 V DC	MPPS: On/Off

Connector	Pin	Signal	I/O	Voltage	Description
YC17 Connected to cassette size switch	1	CAS2	I	0/3.3 V DC	CSSW (SW2): On/Off
	2	CAS1	I	0/3.3 V DC	CSSW (SW1): On/Off
	3	COM	-	-	Ground
	4	CAS0	I	0/3.3 V DC	CSSW (SW0): On/Off
YC18 Connected to registration sensor	1	+3.3V2_LED2	O	3.3 V DC	3.3 V DC power to RS
	2	GND	-	-	Ground
	3	REGPAP	I	0/3.3 V DC	RS: On/Off
YC19 Connected to eject PWB	1	PDIRN	I	0/3.3 V DC	EVSW: On/Off
	2	+3.3V2	O	3.3 V DC	3.3 V DC power to EJPWB
	3	FTHERM	I	Analog	FTH detection voltage
	4	FUSPAP	I	0/3.3 V DC	ES: On/Off
	5	FDFULL	I	0/3.3 V DC	PFS: On/Off
	6	GND	-	-	Ground
YC20 Connected to toner container switch and waste toner cover switch	1	+3.3V2_LED3	O	3.3 V DC	3.3 V DC power to TCSW
	2	GND	-	-	Ground
	3	TCONTN	I	0/3.3 V DC	TCSW: On/Off
	4	+3.3V2_LED7	O	3.3 V DC	3.3 V DC power to WTCSW
	5	GND	-	-	Ground
	6	WSTOPN	I	0/3.3 V DC	WTCSW: On/Off
YC21 Connected to cassette PWB	1	GND	-	-	Ground
	2	PAPVOL2	-	-	Not used
	3	PAPVOL1	I	0/3.3 V DC	PS: On/Off
	4	LIFTSEN	I	0/3.3 V DC	LS: On/Off
	5	+3.3V2	O	3.3 V DC	3.3 V DC power to CPWB
YC23 Connected to toner motor K	1	+24V3	O	24 V DC	24 V DC power to TM-K
	2	TNMKDRN	O	0/24 V DC	TM-K: On/Off
YC24 Connected to toner motor M	1	+24V3	O	24 V DC	24 V DC power to TM-M
	2	TNMMDRN	O	0/24 V DC	TM-M: On/Off
YC25 Connected to toner motor C	1	+24V3	O	24 V DC	24 V DC power to TM-C
	2	TNMCDRN	O	0/24 V DC	TM-C: On/Off
YC26 Connected to toner motor Y	1	+24V3	O	24 V DC	24 V DC power to TM-Y
	2	TNMYDRN	O	0/24 V DC	TM-Y: On/Off

Connector	Pin	Signal	I/O	Voltage	Description
YC27 Connected to lift motor	1	LMOTDRN	O	0/24 V DC	LM: On/Off
	2	GND	-	-	Ground
YC28 Connected to container fan motor	1	+24V1	O	24 V DC	24 V DC power to CFM
	2	TCONFAN DRN	O	0/12/24 V DC	CFM: Full speed/Half speed/Off
YC29 Connected to left fan motor	1	+24V1	O	24 V DC	24 V DC power to LFM
	2	LFANDRN	O	0/12/24 V DC	LFM: Full speed/Half speed/Off
YC30 Connected to top tray switch	1	TCONTN	O	0/3.3 V DC	TTSW: On/Off
	2	GND	-	-	Ground
YC31 Connected to laser scanner unit KM	1	GND	-	-	Ground
	2	VREFK	O	Analog	APCPWB-K laser power standard voltage
	3	LONBKN	O	0/3.3 V DC	APCPWB-K sample/hold signal
	4	ENBKN	O	0/3.3 V DC	APCPWB-K laser enable signal
	5	PDKN	I	0/3.3 V DC (pulse)	Horizontal synchronizing signal
	6	GND	-	-	Ground
	7	VREFM	O	Analog	APCPWB-M laser power standard voltage
	8	LONBMN	O	0/3.3 V DC	APCPWB-M sample/hold signal
	9	ENBMN	O	0/3.3 V DC	APCPWB-M laser enable signal
	10	PDMN	I	0/3.3 V DC (pulse)	Horizontal synchronizing signal
	11	LSUTHERMM	I	Analog	ITEMS detection voltage
	12	POLCLK1	O	0/3.3 V DC (pulse)	PM-KM clock signal
	13	POLRDYN1	I	0/3.3 V DC	PM-KM ready signal
	14	POLONN1	O	0/3.3 V DC	PM-KM: On/Off
	15	GND	-	-	Ground
	16	+24V3	O	24 V DC	24 V DC power to PM-KM
	17	N.C.	-	-	Not used
	18	N.C.	-	-	Not used

Connector	Pin	Signal	I/O	Voltage	Description
YC32	1	GND	-	-	Ground
Connected to laser scanner unit CY	2	VREFC	O	Analog	APCPWB-C laser power standard voltage
	3	LONBCN	O	0/3.3 V DC	APCPWB-C sample/hold signal
	4	ENBCN	O	0/3.3 V DC	APCPWB-C laser enable signal
	5	PDCN	I	0/3.3 V DC (pulse)	Horizontal synchronizing signal
	6	GND	-	-	Ground
	7	VREFY	O	Analog	APCPWB-Y laser power standard voltage
	8	LONBYN	O	0/3.3 V DC	APCPWB-Y sample/hold signal
	9	ENBYN	O	0/3.3 V DC	APCPWB-Y laser enable signal
	10	PDYN	I	0/3.3 V DC (pulse)	Horizontal synchronizing signal
	11	LSUTHERMY	-	-	Not used
	12	POLCLK0	O	0/3.3 V DC (pulse)	PM-CY clock signal
	13	POLRDYN0	I	0/3.3 V DC	PM-CY ready signal
	14	POLONN0	O	0/3.3 V DC	PM-CY: On/Off
	15	GND	-	-	Ground
	16	+24V3	O	24 V DC	24 V DC power to PM-CY
YC33	1	GND	-	-	Ground
Connected to paper feeder	2	OPCLK	O	0/3.3 V DC (pulse)	Paper feeder clock signal
	3	OPRDYN	O	0/3.3 V DC	Paper feeder ready signal
	4	OPSDI	I	0/3.3 V DC (pulse)	Paper feeder serial communication data signal input
	5	OPSDO	O	0/3.3 V DC (pulse)	Paper feeder serial communication data signal output
	6	+3.3V1	O	3.3 V DC	3.3 V DC power to paper feeder
	7	GND	-	-	Ground
	8	OPSEL0	O	0/3.3 V DC	Paper feeder selection signal
	9	OPSEL1	O	0/3.3 V DC	Paper feeder selection signal
	10	OPSEL2	O	0/3.3 V DC	Paper feeder selection signal
	11	+24V3	O	24 V DC	24 V DC power to paper feeder

Connector	Pin	Signal	I/O	Voltage	Description
YC34 Connected to drum relay PWB	1	TNSENK	I	Analog	TS-M detection voltage
	2	ERASECDR	O	0/24 V DC	CL-C: On/Off
	3	TNSENK	I	Analog	TS-K detection voltage
	4	ERASEMDR	O	0/24 V DC	CL-M: On/Off
	5	DLPTHERM	I	Analog	DEVTH detection voltage
	6	ERASEKDR	O	0/24 V DC	CL-K: On/Off
	7	+3.3V2	O	3.3 V DC	3.3 V DC power to DRRPWB
	8	EECLK	O	0/3.3 V DC (pulse)	EEPROM clock signal
	9	GND	-	-	Ground
	10	EEDATA	I/O	0/3.3 V DC (pulse)	EEPROM data signal
	11	TNSENK	I	Analog	TS-Y detection voltage
	12	ERASEYDR	O	0/24 V DC	CL-Y: On/Off
	13	TNSENK	I	Analog	TS-C detection voltage
YC35 Connected to developing release switch and developing release motor	1	DLPDIRN	I	0/3.3 V DC	DEVRSW: On/Off
	2	GND	-	-	Ground
	3	DLPCMOTA	O	24/0 V DC	DEVRM: Forward/Stop (Reverse)
	4	DLPCMOTB	O	24/0 V DC	DEVRM: Reverse/Stop (Forward)
YC36 Connected to LSU cleaning motor	1	LSUMOTA	O	24/0 V DC	LSUCM: Forward/Stop (Reverse)
	2	LSUMOTB	O	24/0 V DC	LSUCM: Reverse/Stop (Forward)
YC37 Connected to duplex motor	1	STDUA	O	0/24 V DC (pulse)	DUM drive control signal
	2	STDUB	O	0/24 V DC (pulse)	DUM drive control signal
	3	STDUAN	O	0/24 V DC (pulse)	DUM drive control signal
	4	STDUBN	O	0/24 V DC (pulse)	DUM drive control signal
YC38 Connected to fuser pressure release motor	1	PREMOTDRN	O	0/24 V DC	FPRM: On/Off
	2	GND	-	-	Ground
YC40 Connected to fuser fan motor	1	+24V1	O	24 V DC	24 V DC power to FUFM
	2	FUFANDRN	O	0/12/24 V DC	FUFM: Full speed/Half speed/Off

Connector	Pin	Signal	I/O	Voltage	Description
YC42	1	GND	-	-	Ground
Connected to outer temper- ature sensor	2	AIRTEMP	I	Analog	OITEMS detection voltage (temperature)
	3	WETCLK0	O	0/3.3 V DC (pulse)	OITEMS clock signal
	4	WETCLK1	O	0/3.3 V DC (pulse)	OITEMS clock signal
	5	AIRWETOUT	I	Analog	OITEMS detection voltage (humidity)

Connector	Pin	Signal	I/O	Voltage	Description
YC3 Connected to USB	1	VBUS	O	5 V DC	5 V DC power output
	2	DATA-	I/O	-	USB data signal
	3	DATA+	I/O	-	USB data signal
	4	GND	-	-	Ground
YC8 Connected to CCD PWB	1	CCDSW	O	0/3.3 V DC	CCD color/BW change signal
	2	CCDSH	O	0/3.3 V DC	CCD shift gate signal
	3	CCDCLPN	O	LVDS	CCD clamp signal
	4	CCDCLPP	O	LVDS	CCD clamp signal
	5	NC	-	-	Not used
	6	CCDRSP	O	LVDS	CCD reset signal
	7	CCDRSN	O	LVDS	CCD reset signal
	8	NC	-	-	Not used
	9	CCDPH1N	O	LVDS	CCD shift register clock signal
	10	CCDPH1P	O	LVDS	CCD shift register clock signal
	11	NC	-	-	Not used
	12	CCDPH2P	O	LVDS	CCD shift register clock signal
	13	CCDPH2N	O	LVDS	CCD shift register clock signal
	14	NC	-	-	Not used
	15	+3.3VS	O	3.3 V DC	3.3 V DC power to CCDPWB
	16	HPSWN	I	0/3.3 V DC	HPS: On/Off
	17	NC	-	-	Not used
	18	+24V_LAMP	O	24 V DC	24 V DC power to CCDPWB
	19	LAMPTH	O	0/3.3 V DC	EL drive signal
	20	GND_LAMP	-	-	Ground
	21	NC	-	-	Not used
	22	GND	-	-	Ground
	23	CCDDATAB	I	Analog	CCD image output signal (B)
	24	GND	-	-	Ground
	25	CCDDATAG	I	Analog	CCD image output signal (G)
	26	GND	-	-	Ground
	27	CCDDATAR	I	Analog	CCD image output signal (R)
	28	GND	-	-	Ground
	29	NC	-	-	Not used
	30	+5V1	O	5 V DC	5 V DC power to CCDPWB
	31	NC	-	-	Not used
	32	+12VS	O	DC12V	12 V DC power to CCDPWB

Connector	Pin	Signal	I/O	Voltage	Description
YC12 Connected to USB	1	VBUS	O	5 V DC	5 V DC power output
	2	DATA-	I/O	-	USB data signal
	3	DATA+	I/O	-	USB data signal
	4	GND	-	-	Ground
	5	GND	-	-	Ground
YC14 Connected to FAX control PWB	A1	NC	-	-	Not used
	B1	NC	-	-	Not used
	A2	NC	-	-	Not used
	B2	NC	-	-	Not used
	A3	GND	-	-	Ground
	B3	3.3V	O	3.3 V DC	3.3 V DC power output
	A4	3.3V	O	3.3 V DC	3.3 V DC power output
	B4	A15	O	0/3.3 V DC (pulse)	Address bus signal
	A5	GND	-	-	Ground
	B5	A14	O	0/3.3 V DC (pulse)	Address bus signal
	A6	A13	O	0/3.3 V DC (pulse)	Address bus signal
	B6	A12	O	0/3.3 V DC (pulse)	Address bus signal
	A7	A11	O	0/3.3 V DC (pulse)	Address bus signal
	B7	A10	O	0/3.3 V DC (pulse)	Address bus signal
	A8	A9	O	0/3.3 V DC (pulse)	Address bus signal
	B8	A8	O	0/3.3 V DC (pulse)	Address bus signal
	A9	GND	-	-	Ground
	B9	A7	O	0/3.3 V DC (pulse)	Address bus signal
	A10	A6	O	0/3.3 V DC (pulse)	Address bus signal
	B10	A5	O	0/3.3 V DC (pulse)	Address bus signal
	A11	A4	O	0/3.3 V DC (pulse)	Address bus signal
	B11	A3	O	0/3.3 V DC (pulse)	Address bus signal
	A12	A2	O	0/3.3 V DC (pulse)	Address bus signal
	B12	A1	O	0/3.3 V DC (pulse)	Address bus signal
	A13	GND	-	-	Ground
	B13	3.3V	O	3.3 V DC	3.3 V DC power output
	A14	OP2IFN	O	0/3.3 V DC	Select signal
	B14	OP2ACKN	I	0/3.3 V DC (pulse)	OP2ACKN signal
	A15	OP2IRN	I	0/3.3 V DC	Interruption signal
	B15	5V	O	5 V DC	5 V DC power output
	A16	RDY	O	0/3.3 V DC	Ready signal

Connector	Pin	Signal	I/O	Voltage	Description	
YC14	B16	RXDREQ	I	0/3.3 V DC	Reception DMA request signal	
Connected to FAX control PWB	A17	GND	-	-	Ground	
	B17	RXDMACKN	O	0/3.3 V DC (pulse)	Reception DMACK signal	
	A18	IORN	O	0/3.3 V DC	Read enable signal	
	B18	IOWN	O	0/3.3 V DC	Write enable signal	
	A19	RESETN	O	0/3.3 V DC	Reset signal	
	B19	VOLTDETECT	-	-	Ground	
	A20	D15	I/O	0/3.3 V DC (pulse)	Data bus signal	
	B20	D14	I/O	0/3.3 V DC (pulse)	Data bus signal	
	A21	GND	-	-	Ground	
	B21	D13	I/O	0/3.3 V DC (pulse)	Data bus signal	
	A22	D12	I/O	0/3.3 V DC (pulse)	Data bus signal	
	B22	D11	I/O	0/3.3 V DC (pulse)	Data bus signal	
	A23	D10	I/O	0/3.3 V DC (pulse)	Data bus signal	
	B23	D9	I/O	0/3.3 V DC (pulse)	Data bus signal	
	A24	D8	I/O	0/3.3 V DC (pulse)	Data bus signal	
	B24	D7	I/O	0/3.3 V DC (pulse)	Data bus signal	
	A25	GND	-	-	Ground	
	B25	D6	I/O	0/3.3 V DC (pulse)	Data bus signal	
	A26	D5	I/O	0/3.3 V DC (pulse)	Data bus signal	
	B26	D4	I/O	0/3.3 V DC (pulse)	Data bus signal	
	A27	D3	I/O	0/3.3 V DC (pulse)	Data bus signal	
	B27	D2	I/O	0/3.3 V DC (pulse)	Data bus signal	
	A28	D1	I/O	0/3.3 V DC (pulse)	Data bus signal	
	B28	D0	I/O	0/3.3 V DC (pulse)	Data bus signal	
	A29	GND	-	-	Ground	
	B29	NC	-	-	Not used	
	A30	NC	-	-	Not used	
	B30	NC	-	-	Not used	
	YC15	1	OUT-	O	Analog	Speaker sound signal (-)
	Connected to speaker	2	OUT+	O	Analog	Speaker sound signal (+)

Connector	Pin	Signal	I/O	Voltage	Description
YC32 Connected to DP drive PWB	1	FEEDCL	O	0/24 V DC	DPPFCL: On/Off
	2	REVSOL	O	0/24 V DC	DPSBSOL: On/Off
	3	PRESOLN	O	0/24 V DC	DPPRSOL: On (Press)/Off
	4	RELSOLN	O	0/24 V DC	DPPRSOL: On (Release)/Off
	5	DPDETN	I	0/3.3 V DC	DP set signal
	6	OPSWN	I	0/3.3 V DC	DPOCS: On/Off
	7	ORGSWN	I	0/3.3 V DC	DPOS: On/Off
	8	TIMSWN	I	0/3.3 V DC	DPTS: On/Off
	9	GND	-	-	Ground
	10	+3.3V2	O	3.3 V DC	3.3 V DC power to DPDPWB
	11	GND	-	-	Ground
	12	+24V2	O	24 V DC	24 V DC power to PDPWB
	13	MOTB2	O	0/24 V DC (pulse)	DPPFM drive control signal
	14	MOTA2	O	0/24 V DC (pulse)	DPPFM drive control signal
	15	MOTB1	O	0/24 V DC (pulse)	DPPFM drive control signal
	16	MOTA1	O	0/24 V DC (pulse)	DPPFM drive control signal
YC36 Connected to ISU motor	1	SCMOTB2	O	0/24 V DC (pulse)	ISUM drive control signal
	2	SCMOTA1	O	0/24 V DC (pulse)	ISUM drive control signal
	3	SCMOTB1	O	0/24 V DC (pulse)	ISUM drive control signal
	4	SCMOTA2	O	0/24 V DC (pulse)	ISUM drive control signal
YC37 Connected to power source PWB	1	+24V1	I	24 V DC	24 V DC power from PSPWB
	2	GND	-	-	Ground
	3	GND	-	-	Ground
	4	+5V1	I	5 V DC	5 V DC power from PSPWB
YC38 Connected to laser scanner unit KM	1	GND	-	-	Ground
	2	+3.3V3	O	3.3 V DC	3.3 V DC power to APCPWB-M
	3	PDMN	I	0/3.3 V DC (pulse)	Horizontal synchronizing signal
	4	VDOMP	O	LVDS	APCPWB-M video data signal (+)
	5	VDOMN	O	LVDS	APCPWB-M video data signal (-)
	6	GND	-	-	Ground
	7	+3.3V3	O	3.3 V DC	3.3 V DC power to APCPWB-K
	8	PDKN	I	0/3.3 V DC (pulse)	Horizontal synchronizing signal
	9	VDOKP	O	LVDS	APCPWB-K video data signal (+)
	10	VDOKN	O	LVDS	APCPWB-K video data signal (-)

Connector	Pin	Signal	I/O	Voltage	Description
YC39	1	+3.3V1_MFP	O	3.3 V DC	3.3 V DC power to RYPWB
Connected to relay PWB	2	I2CSDA	I/O	0/3.3 V DC (pulse)	EEPROM data signal
	3	GND	-	-	Ground
	4	I2CSCL	O	0/3.3 V DC (pulse)	EEPROM clock signal
	5	SCKN	O	0/3.3 V DC (pulse)	Serial communication clock signal
	6	SO	I	0/3.3 V DC (pulse)	Serial communication data signal input
	7	SI	O	0/3.3 V DC (pulse)	Serial communication data signal output
	8	SDIR	I	0/3.3 V DC	Serial communication direction change signal
	9	SBSY	I	0/3.3 V DC	Serial busy signal
	10	EGIRN	I	0/3.3 V DC	Engine interruption signal
	11	VSYNC	I	0/3.3 V DC (pulse)	Horizontal synchronizing signal
	12	+3.3V2	O	3.3 V DC	3.3 V DC power to RYPWB
	13	GND	-	-	Ground
	14	EGHOLD	O	0/3.3 V DC	Engine hold signal
	15	I2CINT	O	0/3.3 V DC (pulse)	Communication signal
	16	HYPINT	I	0/3.3 V DC	Interruption signal
	17	PSSLEEPN	O	0/3.3 V DC	Sleep mode signal: On/Off
YC40	1	GND	-	-	Ground
Connected to laser scanner unit CY	2	+3.3V3	O	3.3 V DC	3.3 V DC power to APCPWB-Y
	3	PDYN	I	0/3.3 V DC (pulse)	Horizontal synchronizing signal
	4	VDOYP	O	LVDS	APCPWB-Y video data signal (+)
	5	VDOYN	O	LVDS	APCPWB-Y video data signal (-)
	6	GND	-	-	Ground
	7	+3.3V3	O	3.3 V DC	3.3 V DC power to APCPWB-C
	8	PDCN	I	0/3.3 V DC (pulse)	Horizontal synchronizing signal
	9	VDOCP	O	LVDS	APCPWB-C video data signal (+)
	10	VDOCN	O	LVDS	APCPWB-C video data signal (-)
	YC41	1	+24V1	O	24 V DC
Connected to controller fan motor	2	CONTFAN DRN	O	0/12/24 V DC	CONFM: Full speed/Half speed/Off
YC42	1	+24V1	O	24 V DC	24 V DC power to RFM
Connected to right fan motor	2	RFANDRN	O	0/12/24 V DC	RFM: Full speed/Half speed/Off

Connector	Pin	Signal	I/O	Voltage	Description
YC43	1	+5V1	-	5 V DC	5 V DC power to OPPWB
Connected to operation panel PWB	2	POWERKEY	I	0/3.3 V DC	Power key input signal
	3	FPRSTN	O	0/3.3 V DC	OPPWB reset signal
	4	PANTXD	O	0/3.3 V DC (pulse)	OPPWB transmission data
	5	PANRXD	I	0/3.3 V DC (pulse)	OPPWB received data
	6	+3.3V	O	3.3 V DC	3.3 V DC power to OPPWB
	7	PANEL_MODE1	O	0/3.3 V DC	OPPWB mode signal
	8	GND	-	-	Ground
	9	PANEL_MODE0	O	0/3.3 V DC	OPPWB mode signal
YC44	1	TCT	O	3.3 V DC	3.3 V DC power output
Connected to ethernet	2	TD+	O	0/3.3 V DC (pulse)	Transmission data
	3	TD-	O	0/3.3 V DC (pulse)	Transmission data
	4	RD+	I	0/3.3 V DC (pulse)	Received data
	5	RD-	I	0/3.3 V DC (pulse)	Received data
	6	RCT	O	3.3 V DC	3.3 V DC power output
	7	CAT PHY	O	0/3.3 V DC	Control signal
	8	ANO PHY	O	3.3 V DC	3.3 V DC power output
	9	CAT MAC	-	-	Ground
	10	ANO MAC	O	0/3.3 V DC	Control signal

2-3-4 Drum relay PWB



Figure 2-3-4 Drum relay PWB silk-screen diagram

Connector	Pin	Signal	I/O	Voltage	Description
YC1 Connected to engine PWB	1	TNSENK	O	Analog	TS-M detection voltage
	2	ERASECDR	I	0/24 V DC	CL-C: On/Off
	3	TNSENK	O	Analog	TS-K detection voltage
	4	ERASEMDR	I	0/24 V DC	CL-M: On/Off
	5	DLP THERM	O	Analog	DEVTH detection voltage
	6	ERASEKDR	I	0/24 V DC	CL-K: On/Off
	7	+3.3V2	I	3.3 V DC	3.3 V DC power from EPWB
	8	EECLK	I	0/3.3 V DC (pulse)	EEPROM clock signal
	9	GND	-	-	Ground
	10	EEDATA	I/O	0/3.3 V DC (pulse)	EEPROM data signal
	11	TNSENK	O	Analog	TS-Y detection voltage
	12	ERASEYDR	I	0/24 V DC	CL-Y: On/Off
	13	TNSENK	O	Analog	TS-C detection voltage
YC2 Connected to drum PWB K	1	GND	-	-	Ground
	2	EECLK	O	0/3.3 V DC (pulse)	EEPROM clock signal
	3	ERASEKDR	O	0/24 V DC	CL-K: On/Off
	4	EEDATA	I/O	0/3.3 V DC (pulse)	EEPROM data signal
	5	N.C.	-	-	Not used
	6	+3.3V2	O	3.3 V DC	3.3 V DC power to DRPWB-K
	7	DA0	-	-	Not used
	8	DA1	-	-	Not used
YC3 Connected to drum PWB M	1	GND	-	-	Ground
	2	EECLK	O	0/3.3 V DC (pulse)	EEPROM clock signal
	3	ERASEMDR	O	0/24 V DC	CL-M: On/Off
	4	EEDATA	I/O	0/3.3 V DC (pulse)	EEPROM data signal
	5	N.C.	-	-	Not used
	6	+3.3V2	O	3.3 V DC	3.3 V DC power to DRPWB-M
	7	DA0	-	-	Ground
	8	DA1	-	-	Not used
YC4 Connected to drum PWB C	1	GND	-	-	Ground
	2	EECLK	O	0/3.3 V DC (pulse)	EEPROM clock signal
	3	ERASECDR	O	0/24 V DC	CL-C: On/Off
	4	EEDATA	I/O	0/3.3 V DC (pulse)	EEPROM data signal
	5	N.C.	-	-	Not used
	6	+3.3V2	O	3.3 V DC	3.3 V DC power to DRPWB-C
	7	DA0	-	-	Not used
	8	DA1	-	-	Ground

Connector	Pin	Signal	I/O	Voltage	Description
YC5 Connected to drum PWB Y	1	GND	-	-	Ground
	2	EECLK	O	0/3.3 V DC (pulse)	EEPROM clock signal
	3	ERASEYDR	O	0/24 V DC	CL-Y: On/Off
	4	EEDATA	I/O	0/3.3 V DC (pulse)	EEPROM data signal
	5	N.C.	-	-	Not used
	6	+3.3V2	O	3.3 V DC	3.3 V DC power to DRPWB-Y
	7	DA0	-	-	Ground
	8	DA1	-	-	Ground
YC6 Connected to developing PWB K	1	GND	-	-	Ground
	2	TNSENK	I	Analog	TS-K detection voltage
	3	+3.3V2	O	3.3 V DC	3.3 V DC power to DEVPWB-K
	4	DLP THERM	I	Analog	DEVTH detection voltage
YC7 Connected to developing PWB M	1	GND	-	-	Ground
	2	TNSEN M	I	Analog	TS-M detection voltage
	3	+3.3V2	O	3.3 V DC	3.3 V DC power to DEVPWB-M
	4	N.C.	-	-	Not used
YC10 Connected to developing PWB C	1	GND	-	-	Ground
	2	TNSEN C	I	Analog	TS-C detection voltage
	3	+3.3V2	O	3.3 V DC	3.3 V DC power to DEVPWB-C
	4	N.C.	-	-	Not used
YC13 Connected to developing PWB Y	1	GND	-	-	Ground
	2	TNSEN Y	I	Analog	TS-Y detection voltage
	3	+3.3V2	O	3.3 V DC	3.3 V DC power to DEVPWB-Y
	4	N.C.	-	-	Not used

2-3-5 DP drive PWB




Figure 2-3-5 DP drive PWB silk-screen diagram


Connector	Pin	Signal	I/O	Voltage	Description
YC1 Connected to main PWB	1	MOTA1	I	0/24 V DC (pulse)	DPPFM drive control signal
	2	MOTB1	I	0/24 V DC (pulse)	DPPFM drive control signal
	3	MOTA2	I	0/24 V DC (pulse)	DPPFM drive control signal
	4	MOTB2	I	0/24 V DC (pulse)	DPPFM drive control signal
	5	+24V2	I	24 V DC	24 V DC power from MPWB
	6	GND	-	-	Ground
YC2 Connected to DP open/close sensor, DP original sensor and DP timing sensor	1	+3.3V2	O	3.3 V DC	3.3 V DC power to DPOCS
	2	GND	-	-	Ground
	3	OPSWN	I	0/3.3 V DC	DPOCS: On/Off
	4	+3.3V2	O	3.3 V DC	3.3 V DC power to DPOS
	5	GND	-	-	Ground
	6	ORGSWN	I	0/3.3 V DC	DPOS: On/Off
	7	+3.3V2	O	3.3 V DC	3.3 V DC power to DPTS
	8	GND	-	-	Ground
	9	TIMSWN	I	0/3.3 V DC	DPTS: On/Off
YC3 Connected to DP paper feed motor	1	DPMOT1A	O	0/24 V DC (pulse)	DPPFM drive control signal
	2	DPMOT2A	O	0/24 V DC (pulse)	DPPFM drive control signal
	3	DPMOT1B	O	0/24 V DC (pulse)	DPPFM drive control signal
	4	DPMOT2B	O	0/24 V DC (pulse)	DPPFM drive control signal
YC4 Connected to DP pressure solenoid	1	+24V2	O	24 V DC	24 V DC power to DPPRSOL
	2	PRESOLN	O	0/24 V DC	DPPRSOL: On (Press)/Off
	3	RELSOLN	O	0/24 V DC	DPPRSOL: On (Release)/Off
YC5 Connected to DP switch-back solenoid	1	+24V2	O	24 V DC	24 V DC power to DPSBSOL
	2	REVSOL	O	0/24 V DC	DPSBSOL: On/Off
YC6 Connected to DP paper feed clutch	1	+24V2	O	24 V DC	24 V DC power to DPPFCL
	2	FEEDCL	O	0/24 V DC	DPPFCL: On/Off

Connector	Pin	Signal	I/O	Voltage	Description
YC8	1	+3.3V2	I	3.3 V DC	3.3 V DC power from MPWB
Connected to main PWB	2	GND	-	-	Ground
	3	TIMSWN	O	0/3.3 V DC	DPTS: On/Off
	4	ORGSWN	O	0/3.3 V DC	DPOS: On/Off
	5	OPSWN	O	0/3.3 V DC	DPOCS: On/Off
	6	DPDETN	O	0/3.3 V DC	DP set signal
	7	RELSOLN	I	0/24 V DC	DPPRSOL: On (Release)/Off
	8	PRESOLN	I	0/24 V DC	DPPRSOL: On (Press)/Off
	9	REVSOL	I	0/24 V DC	DPSBSOL: On/Off
	10	FEEDCL	I	0/24 V DC	DPPFCL: On/Off

This page is intentionally left blank.

2-4-1 Appendixes

(1) Repetitive defects gauge



(2) Firmware environment commands

The printer maintains a number of printing parameters in its memory. These parameters may be changed permanently with the FRPO (Firmware RePrOgram) commands.

This section provides information on how to use the FRPO command and its parameters using examples.

Using FRPO commands for reprogramming firmware

The current settings of the FRPO parameters are listed as optional values on the service status page.

Note: Before changing any FRPO parameter, print out a service status page, so you will know the parameter values before the changes are made. To return FRPO parameters to their factory default values, send the FRPO INIT (FRPO-INITialize) command.(!R! FRPO INIT; EXIT;)

The FRPO command is sent to the printer in the following sequence:

!R! FRPO parameter, value; EXIT;

Example: Changing emulation mode to PC-PR201/65A

!R! FRPO P1, 11; EXIT;

FRPO parameters

Item	FRPO	Setting values	Factory setting
Top margin	A1	Integer value in inches	0
	A2	Fraction value in 1/100 inches	0
Left margin	A3	Integer value in inches	0
	A4	Fraction value in 1/100 inches	0
Page length	A5	Integer value in inches	16
	A6	Fraction value in 1/100 inches	61
Page width	A7	Integer value in inches	16
	A8	Fraction value in 1/100 inches	61
Default pattern resolution	B8	0: 300 dpi	0
		1: 600 dpi	
Page orientation	C1	0: Portrait	0
		1: Landscape	
Default font No. *	C2	Middle two digits of power-up font	0
	C3	Last two digits of power-up font	0
	C5	First two digits of power-up font	0
Print density	D4	Number from 1 (Light) to 5 (Dark)	3
Total host buffer size	H8	0 to 99 in units of the size defined by FRPO S5	5
Form feed time-out value	H9	Value in units of 5 seconds (0 to 99).	1
Reduce ratio	J0	0: 100 %	0
		5: 70 %	
		6: 81 %	
		7: 86 %	
		8: 94 %	
		9: 98 %	

Item	FRPO	Setting values	Factory setting
Offset (horizontal direction)	K0	Integer value in centimeters (-7 to +7)	0
	K1	Fraction value in 1/100 centimeters (-99 to +99)	0
Offset (vertical direction)	K2	Integer value in centimeters (-7 to +7)	0
	K3	Fraction value in 1/100 centimeters (-99 to +99)	0
KIR mode	N0	0: Off 2: On	2
Duplex binding	N4	0: Off 1: Long edge 2: Short edge	0
Sleep timer time-out time	N5	1 to 240 minutes [0: Off]	15
Ecoprint level	N6	0: Off 2: On	0
Printing resolution	N8	0: 300dpi 1: 600dpi 3: 1200dpi	1
Default emulation mode	P1	6: PCL 5e 9: KPDL (option) 11: PC-PR201/65A 12: IBM 5577 13: VP-1000	6
Carriage-return action *	P2	0: Ignores 0x0d 1: Carriage-return 2: Carriage-return+linefeed	1
Linefeed action *	P3	0: Ignores 0x0d 1: Linefeed 2: Linefeed+carriage-return	1
Automatic emulation sensing (For KPDL3)	P4	0: AES disabled 1: AES enabled	0
Alternative emulation (For KPDL3)	P5	Same as the P1 values except that 9 is ignored.	6
Automatic emulation switching trigger (For KPDL3)	P7	0: Page eject commands 1: None 2: Page eject and prescribe EXIT 3: Prescribe EXIT 4: Formfeed (^L) 6: Page eject, prescribe EXIT and formfeed 10: Page eject commands; if AES fails, resolves to KPDL	10
Command recognition character	P9	ASCII code of 33 to 126	82 (R)

Item	FRPO	Setting values	Factory setting
Default paper size	R2	0: Size of the default paper cassette (See R4.) 1: Monarch (3-7/8 × 7-1/2 inches) 2: Business (4-1/8 × 9-1/2 inches) 3: International DL (11 × 22 cm) 4: International C5 (16.2 × 22.9 cm) 5: Executive (7-1/4 × 10-1/2 inches) 6: US Letter (8-1/2 × 11 inches) 7: US Legal (8-1/2 × 14 inches) 8: A4 (21.0 × 29.7 cm) 9: JIS B5 (18.2 × 25.7 cm) 13: ISO A5 14: A6 (10.5 × 14.8 cm) 15: JIS B6 (12.8 × 18.2 cm) 16: Commercial #9 (3-7/8 × 8-7/8 inches) 17: Commercial #6 (3-5/8 × 6-1/2 inches) 18: ISO B5 (17.6 × 25 cm) 19: Custom (11.7 × 17.7 inches) 20: B4→A4 reduces 21: A3→A4 reduces 22: A4→A4 98% reduces 23: Stock form→A4 reduces 31: Hagaki (10 × 14.8 cm) 32: Ofuku-hagaki (14.8 × 20 cm) 33: Officio II 40: 16K 50: Statement 51: Folio 52: Youkei 2 53: Youkei 4	0
Default cassette	R4	0: MP tray 1: Cassette 1 2: Cassette 2 3: Cassette 3 4: Cassette 4	1
MP tray paper size	R7	Same as the R2 values except: 0	8 (A4)
A4/letter equation	S4	0: Off 1: On	0
Host buffer size	S5	0: 10kB (x H8) 1: 100kB (x H8) 2: 1024kB (x H8)	1
Wide A4	T6	0: Off 1: On	0
Line spacing *	U0	Lines per inch (integer value)	6
Line spacing *	U1	Lines per inch (fraction value)	0
Character spacing *	U2	Characters per inch (integer value)	10
Character spacing *	U3	Characters per inch (fraction value)	0

Item	FRPO	Setting values	Factory setting
Country code	U6	0: US-ASCII 1: France 2: Germany 3: UK 4: Denmark 5: Sweden 6: Italy 7: Spain 8: Japan 9: US Legal 10: IBM PC-850 (Multilingual) 11: IBM PC-860 (Portuguese) 12: IBM PC-863 (Canadian French) 13: IBM PC-865 (Norwegian) 14: Norway 15: Denmark 2 16: Spain 2 17: Latin America 21: US ASCII (U7 = 50 SET) 77: HP Roman-8 (U7 = 52 SET)	0
Code set at power up in daisy-wheel emulation	U7	0: Same as the default emulation mode (P1) 1: IBM 6: IBM PC-8 50: US ASCII (U6 = 21 SET) 52: HP Roman-8 (U6 = 77 SET)	0
Font pitch for fixed pitch scalable font	U8	Integer value in cpi: 0 to 99	10
	U9	Fraction value in 1/100 cpi: 0 to 99	0
Font height for the default scalable font *	V0	Integer value in 100 points: 0 to 9	0
	V1	Integer value in points: 0 to 99	12
	V2	Fraction value in 1/100 points: 0, 25, 50, 75	0
Default scalable font *	V3	Name of typeface of up to 32 characters, enclosed with single or double quotation marks	Courier
Default weight (courier and letter Gothic)	V9	0: Courier = darkness Letter Gothic = darkness 1: Courier = regular Letter Gothic = darkness 4: Courier = darkness Letter Gothic = regular 5: Courier = regular Letter Gothic = regular	5

Item	FRPO	Setting values	Factory setting
Paper type for the MP tray	X0	1: Plain 1 2: Transparency 3: Preprinted 4: Label 5: Bond 6: Recycle 7: Vellum 9: Letterhead 10: Color 11: Prepunched 12: Envelope 13: Cardstock 16: Thick 17: High quality 21: Custom1 22: Custom2 23: Custom3 24: Custom4 25: Custom5 26: Custom6 27: Custom7 28: Custom8	1
Paper type for paper cassettes 1	X1	1: Plain 3: Preprinted 5: Bond 6: Recycled 9: Letterhead 10: Color 11: Prepunched 17: High quality 21: Custom1 22: Custom2 23: Custom3 24: Custom4 25: Custom5 26: Custom6 27: Custom7 28: Custom8	1


Item	FRPO	Setting values	Factory setting
Paper type for paper cassettes 2 to 4	X2	1: Plain	1
	X3	3: Preprinted	
	X4	5: Bond	
		6: Recycled	
		9: Letterhead	
		10: Color	
		11: Prepunched	
		17: High quality	
		21: Custom1	
		22: Custom2	
		23: Custom3	
		24: Custom4	
		25: Custom5	
	26: Custom6		
	27: Custom7		
	28: Custom8		
PCL paper source	X9	0: Performs paper selection depending on media type. 1: Performs paper selection depending on paper sources.	0
Automatic continue for 'Press GO'	Y0	0: Off 1: On	0
Automatic continue timer	Y1	Number from 0 to 99 in increments of 5 seconds	6 (30 seconds)
Error message for device error	Y3	0: Not detect 1: Detect	0
Duplex operation for specified paper type (Prepunched, Preprinted and Letterhead)	Y4	0: Off 1: On	0
Default operation for PDF direct printing	Y5	0: Enlarges or reduces the image to fit in the current paper size. Loads paper from the current paper cassette. 1: Through the image. Loads paper which is the same size as the image. 2: Enlarges or reduces the image to fit in the current paper size. Loads Letter, A4 size paper depending on the image size. 3: Through the image. Loads Letter, A4 size paper depending on the image size. 8: Through the image. Loads paper from the current paper cassette. 9: Through the image. Loads Letter, A4 size paper depending on the image size. 10: Enlarges or reduces the image to fit in the current paper size. Loads Letter, A4 size paper depending on the image size.	0


*: Ignored in some emulation modes.




This page is intentionally left blank.

(3) Wiring diagram







KYOCERA MITA EUROPE B.V.

Bloemlaan 4, 2132 NP Hoofddorp,
The Netherlands
Phone: +31.20.654.0000
Home page: <http://www.kyoceramita-europe.com>
Email: info@kyoceramita-europe.com

KYOCERA MITA NEDERLAND B.V.
Beechavenue 25, 1119RA Schiphol-Rijk
The Netherlands
Phone: +31.20.58.77.200

KYOCERA MITA (UK) LTD
8 Beacontree Plaza
Gillette Way Reading Berks RG2 OBS,
U.K.
Phone: +44.1189.311.500

KYOCERA MITA ITALIA S.p.A.
Via G. Verdi, 89 / 91, 20063 Cernusco s/N
Milano, Italy
Phone: +39.02.92179.1

S.A. KYOCERA MITA BELGIUM N.V.
Sint-Martinusweg 199-201, 1930 Zaventem,
Belgium
Phone: +32.2.720.9270

KYOCERA MITA FRANCE S.A.
Parc Les Algorithmes Saint Aubin
91194 GIF-SUR-YVETTE,
France
Phone: +33.1.6985.2600

KYOCERA MITA ESPAÑA S.A.
Edificio Kyocera, Avda de Manacor No. 2,
28290 Las Matas (Madrid),
Spain
Phone: +34.91.631.8392

KYOCERA MITA FINLAND OY
Atomitie 5C, 00370 Helsinki,
Finland
Phone: +358.9.4780.5200

KYOCERA MITA (SCHWEIZ)
Hohlstrasse 614, 8048 Zürich
Switzerland
Phone: +41.44.908.4949

KYOCERA MITA DEUTSCHLAND GMBH
Otto-Hahn-Str. 12 D-40670 Meerbusch,
Germany
Phone: +49.2159.918.0

KYOCERA MITA GMBH AUSTRIA
Eduard-Kittenberger-Gasse 95,
1230 Wien,
Austria
Phone: +43.1.86338

KYOCERA MITA SVENSKA AB
Esbogatan 16B 164 75 Kista,
Sweden
Phone: +46.8.546.55000

KYOCERA MITA NORGE
Postboks 150 Oppsal, NO 0619 Oslo
Olaf Helsetsvai 6, NO 0694 Oslo,
Norway
Phone: +47.22.62.73.00

KYOCERA MITA DANMARK A/S
Ejby Industrivej 1, DK-2600 Glostrup,
Denmark
Phone: +45.7022.3880

KYOCERA MITA PORTUGAL LDA.
Rua do Centro Cultural, 41 (Alvalade) 1700-106 Lisboa,
Portugal
Phone: +351.21.843.6780

KYOCERA MITA SOUTH AFRICA (PTY) LTD.
49 Kyalami Boulevard,
Kyalami Business Park Midrand,
South Africa
Phone: +27.(0)11.540.2600

KYOCERA MITA AMERICA, INC.

Headquarters:
225 Sand Road,
Fairfield, New Jersey 07004-0008,
U.S.A.
Phone: (973) 808-8444

KYOCERA MITA AUSTRALIA PTY. LTD.
Level 3, 6-10 Talavera Road, North Ryde,
N.S.W. 2113 Australia
Phone: (02) 9888-9999

KYOCERA MITA NEW ZEALAND LTD.
1-3 Parkhead Place, Albany
P.O. Box 302 125 NHPC, Auckland,
New Zealand
Phone: (09) 415-4517

KYOCERA MITA (THAILAND) CORP., LTD.
9/209 Ratchada-Prachachem Road,
Bang Sue, Bangkok 10800, Thailand
Phone: (02) 586-0333

KYOCERA MITA SINGAPORE PTE LTD.
121 Genting Lane, 3rd Level,
Singapore 349572
Phone: 67418733

KYOCERA MITA HONG KONG LIMITED
16/F., Mita Centre,
552-566, Castle Peak Road,
Tsuen Wan, New Territories,
Hong Kong
Phone: 24297422

KYOCERA MITA TAIWAN Corporation.
6F., No.37, Sec. 3, Minquan E. Rd.,
Zhongshan Dist., Taipei 104, Taiwan R.O.C.
Phone: (02) 25076709

KYOCERA MITA Corporation

2-28, 1-chome, Tamatsukuri, Chuo-ku
Osaka 540-8585, Japan
Phone: (06) 6764-3555
<http://www.kyoceramita.com>

KYOCERA MITA AMERICA, INC.

Headquarters:

225 Sand Road,
Fairfield, New Jersey 07004-0008
TEL : (973) 808-8444
FAX : (973) 882-6000

New York Branch:

1410 Broadway 23rd floor
New York, NY 10018
TEL : (917) 286-5400
FAX : (917) 286-5402

Northeastern Region:

225 Sand Road,
Fairfield, New Jersey 07004-0008
TEL : (973) 808-8444
FAX : (973) 882-4401

Midwestern Region:

201 Hansen Court Suite 119
Wood Dale, Illinois 60191
TEL : (630) 238-9982
FAX : (630) 238-9487

Western Region:

14101 Alton Parkway,
Irvine, California 92618-7006
TEL : (949) 457-9000
FAX : (949) 457-9119

Southeastern Region:

1500 Oakbrook Drive,
Norcross, Georgia 30093
TEL : (770) 729-9786
FAX : (770) 729-9873

Southwestern Region:

2825 West Story Road,
Irving, Texas 75038-5299
TEL : (972) 550-8987
FAX : (972) 252-9786

National Operation Center & National Training Center:

2825 West Story Road,
Irving, Texas 75038-5299
TEL : (972) 659-0055
FAX : (972) 570-5816

Latin America Division:

8240 N.W. 52nd. Terrace Dawson Building,
Suite 108 Miami, Florida 33166
TEL : (305) 421-6640
FAX : (305) 421-6666

KYOCERA MITA CANADA, LTD.

6120 Kestrel Road, Mississauga,
Ontario L5T 1S8, Canada
TEL : (905) 670-4425
FAX : (905) 670-8116

KYOCERA MITA MEXICO, S.A. DE C.V.

Av. 16 de Septiembre #407
Col. Santa Inés,
Azcapotzalco México,
D.F. 02130, México
TEL : (55) 5383-2741
FAX : (55) 5383-7804