



KM-1650

KM-2050

**SERVICE
MANUAL**

Published in May '04
842DA110

CAUTION

Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type recommended by the manufacturer. Dispose of used batteries according to the manufacturer's instructions.

CAUTION

Double-pole/neutral fusing.

Revision history

Revision	Date	Replaced pages	Remarks
-	-	-	-
-	-	-	-
-	-	-	-

This page is intentionally left blank.



Safety precautions

This booklet provides safety warnings and precautions for our service personnel to ensure the safety of their customers, their machines as well as themselves during maintenance activities. Service personnel are advised to read this booklet carefully to familiarize themselves with the warnings and precautions described here before engaging in maintenance activities.

Safety warnings and precautions

Various symbols are used to protect our service personnel and customers from physical danger and to prevent damage to their property. These symbols are described below:

⚠ DANGER: High risk of serious bodily injury or death may result from insufficient attention to or incorrect compliance with warning messages using this symbol.

⚠ WARNING: Serious bodily injury or death may result from insufficient attention to or incorrect compliance with warning messages using this symbol.

⚠ CAUTION: Bodily injury or damage to property may result from insufficient attention to or incorrect compliance with warning messages using this symbol.

Symbols

The triangle (\triangle) symbol indicates a warning including danger and caution. The specific point of attention is shown inside the symbol.



General warning.



Warning of risk of electric shock.



Warning of high temperature.

⊘ indicates a prohibited action. The specific prohibition is shown inside the symbol.



General prohibited action.



Disassembly prohibited.

● indicates that action is required. The specific action required is shown inside the symbol.



General action required.



Remove the power plug from the wall outlet.



Always ground the copier.

1. Installation Precautions

WARNING

• Do not use a power supply with a voltage other than that specified. Avoid multiple connections to one outlet: they may cause fire or electric shock. When using an extension cable, always check that it is adequate for the rated current.



• Connect the ground wire to a suitable grounding point. Not grounding the copier may cause fire or electric shock. Connecting the earth wire to an object not approved for the purpose may cause explosion or electric shock. Never connect the ground cable to any of the following: gas pipes, lightning rods, ground cables for telephone lines and water pipes or faucets not approved by the proper authorities.



CAUTION:

• Do not place the copier on an infirm or angled surface: the copier may tip over, causing injury.



• Do not install the copier in a humid or dusty place. This may cause fire or electric shock.



• Do not install the copier near a radiator, heater, other heat source or near flammable material. This may cause fire.



• Allow sufficient space around the copier to allow the ventilation grills to keep the machine as cool as possible. Insufficient ventilation may cause heat buildup and poor copying performance.



• Always handle the machine by the correct locations when moving it.



• Always use anti-toppling and locking devices on copiers so equipped. Failure to do this may cause the copier to move unexpectedly or topple, leading to injury.



• Avoid inhaling toner or developer excessively. Protect the eyes. If toner or developer is accidentally ingested, drink a lot of water to dilute it in the stomach and obtain medical attention immediately. If it gets into the eyes, rinse immediately with copious amounts of water and obtain medical attention.



• Advise customers that they must always follow the safety warnings and precautions in the copier's instruction handbook.



2. Precautions for Maintenance

WARNING

- Always remove the power plug from the wall outlet before starting machine disassembly. 
- Always follow the procedures for maintenance described in the service manual and other related brochures. 
- Under no circumstances attempt to bypass or disable safety features including safety mechanisms and protective circuits. 
- Always use parts having the correct specifications. 
- Always use the thermostat or thermal fuse specified in the service manual or other related brochure when replacing them. Using a piece of wire, for example, could lead to fire or other serious accident. 
- When the service manual or other serious brochure specifies a distance or gap for installation of a part, always use the correct scale and measure carefully. 
- Always check that the copier is correctly connected to an outlet with a ground connection. 
- Check that the power cable covering is free of damage. Check that the power plug is dust-free. If it is dirty, clean it to remove the risk of fire or electric shock. 
- Never attempt to disassemble the optical unit in machines using lasers. Leaking laser light may damage eyesight. 
- Handle the charger sections with care. They are charged to high potentials and may cause electric shock if handled improperly. 

CAUTION

- Wear safe clothing. If wearing loose clothing or accessories such as ties, make sure they are safely secured so they will not be caught in rotating sections. 
- Use utmost caution when working on a powered machine. Keep away from chains and belts. 
- Handle the fixing section with care to avoid burns as it can be extremely hot. 
- Check that the fixing unit thermistor, heat and press rollers are clean. Dirt on them can cause abnormally high temperatures. 
- Do not remove the ozone filter, if any, from the copier except for routine replacement. 

- Do not pull on the AC power cord or connector wires on high-voltage components when removing them; always hold the plug itself.
- Do not route the power cable where it may be stood on or trapped. If necessary, protect it with a cable cover or other appropriate item.
- Treat the ends of the wire carefully when installing a new charger wire to avoid electric leaks.
- Remove toner completely from electronic components.
- Run wire harnesses carefully so that wires will not be trapped or damaged.
- After maintenance, always check that all the parts, screws, connectors and wires that were removed, have been refitted correctly. Special attention should be paid to any forgotten connector, trapped wire and missing screws.
- Check that all the caution labels that should be present on the machine according to the instruction handbook are clean and not peeling. Replace with new ones if necessary.
- Handle greases and solvents with care by following the instructions below:
 - Use only a small amount of solvent at a time, being careful not to spill. Wipe spills off completely.
 - Ventilate the room well while using grease or solvents.
 - Allow applied solvents to evaporate completely before refitting the covers or turning the main switch on.
 - Always wash hands afterwards.
- Never dispose of toner or toner bottles in fire. Toner may cause sparks when exposed directly to fire in a furnace, etc.
- Should smoke be seen coming from the copier, remove the power plug from the wall outlet immediately.



3. Miscellaneous

WARNING

- Never attempt to heat the drum or expose it to any organic solvents such as alcohol, other than the specified refiner; it may generate toxic gas.



CONTENTS

1-1 Specifications	
1-1-1 Specifications	1-1-1
1-1-2 Parts names and their functions	1-1-3
(1) MFP	1-1-3
(2) Operation panel	1-1-4
1-1-3 Machine cross section	1-1-5
1-1-4 Drive system	1-1-6
1-2 Handling Precautions	
1-2-1 Drum	1-2-1
1-2-2 Toner	1-2-1
1-2-3 Installation environment	1-2-2
1-3 Installation	
1-3-1 Unpacking and installation	1-3-1
(1) Installation procedure	1-3-1
1-3-2 Setting initial copy modes	1-3-6
1-3-3 Installing the paper feeder (option)	1-3-7
1-3-4 Installing the DP (option)	1-3-9
1-3-5 Installing the duplex unit (option)	1-3-13
1-3-6 Installing the drawer heater (option)	1-3-16
1-3-7 Installing the key counter (option)	1-3-19
1-3-8 Installing the finisher (option)	1-3-22
1-3-9 Installing the job separator (option)	1-3-30
1-3-10 Installing the fax system (option)	1-3-35
1-3-11 Installing the scan system (option)	1-3-43
1-3-12 Installing the hard disk (option)	1-3-45
1-4 Maintenance Mode	
1-4-1 Maintenance mode	1-4-1
(1) Executing a maintenance item	1-4-1
(2) Maintenance modes item list	1-4-2
(3) Contents of maintenance mode items	1-4-5
1-5 Troubleshooting	
1-5-1 Paper misfeed detection	1-5-1
(1) Paper misfeed indication	1-5-1
(2) Paper misfeed detection conditions	1-5-2
(3) Paper misfeeds	1-5-7
1-5-2 Self-diagnosis	1-5-17
(1) Self-diagnostic function	1-5-17
(2) Self-diagnostic codes	1-5-18
1-5-3 Image formation problems	1-5-26
(1) No image appears (entirely white).	1-5-27
(2) No image appears (entirely black).	1-5-27
(3) Image is too light.	1-5-28
(4) Background is visible.	1-5-28
(5) A white line appears longitudinally.	1-5-28
(6) A black line appears longitudinally.	1-5-29
(7) A black line appears laterally.	1-5-29
(8) One side of the copy image is darker than the other.	1-5-29
(9) Black dots appear on the image.	1-5-30
(10) Image is blurred.	1-5-30
(11) The leading edge of the image is consistently misaligned with the original.	1-5-30
(12) The leading edge of the image is sporadically misaligned with the original.	1-5-31

- (13) Paper creases. 1-5-31
- (14) Offset occurs. 1-5-31
- (15) Image is partly missing. 1-5-32
- (16) Fixing is poor. 1-5-32
- (17) Image is out of focus. 1-5-32
- (18) Image center does not align with the original center. 1-5-33
- 1-5-4 Electrical problems 1-5-34
 - (1) The machine does not operate when the power switch is turned on. 1-5-34
 - (2) The drive motor does not operate (C2000). 1-5-34
 - (3) The registration motor does not operate. 1-5-34
 - (4) The exit motor does not operate. 1-5-34
 - (5) The scanner motor does not operate. 1-5-35
 - (6) Cooling fan motor 1 does not operate. 1-5-35
 - (7) Cooling fan motor 2 does not operate. 1-5-35
 - (8) Cooling fan motor 3 does not operate. 1-5-35
 - (9) The drawer drive motor* does not operate. 1-5-35
 - (10) The paper feed clutch does not operate. 1-5-35
 - (11) The bypass paper feed clutch does not operate. 1-5-35
 - (12) The drawer paper feed clutch* does not operate. 1-5-36
 - (13) The cleaning lamp does not turn on. 1-5-36
 - (14) The exposure lamp does not turn on. 1-5-36
 - (15) The exposure lamp does not turn off. 1-5-36
 - (16) The fixing heater does not turn on (C6000). 1-5-36
 - (17) The fixing heater does not turn off. 1-5-36
 - (18) Main charging is not performed. 1-5-36
 - (19) Transfer charging is not performed. 1-5-37
 - (20) No developing bias is output. 1-5-37
 - (21) The original size is not detected. 1-5-37
 - (22) The original size is not detected correctly. 1-5-37
 - (23) The message requesting paper to be loaded is shown when paper is present in the drawer 1. ... 1-5-37
 - (24) The message requesting paper to be loaded is shown when paper is present in the drawer 2*. 1-5-37
 - (25) The size of paper in the drawer 1 is not displayed correctly. 1-5-37
 - (26) The size of paper in the drawer 2* is not displayed correctly. 1-5-37
 - (27) A paper jam in the paper feed, paper conveying or fixing section is indicated when the power switch is turned on. 1-5-38
 - (28) The message requesting covers to be closed is displayed when the front cover and left cover are closed. 1-5-38
 - (29) Others. 1-5-38
- 1-5-5 Mechanical problems 1-5-39
 - (1) No primary paper feed. 1-5-39
 - (2) No secondary paper feed. 1-5-39
 - (3) Skewed paper feed. 1-5-39
 - (4) The scanner does not travel. 1-5-39
 - (5) Multiple sheets of paper are fed at one time. 1-5-39
 - (6) Paper jams. 1-5-39
 - (7) Toner drops on the paper conveying path. 1-5-40
 - (8) Abnormal noise is heard. 1-5-40

1-6 Assembly and Disassembly

- 1-6-1 Precautions for assembly and disassembly 1-6-1
 - (1) Precautions 1-6-1
 - (2) Running a maintenance item 1-6-2
- 1-6-2 Paper feed section 1-6-3
 - (1) Detaching and refitting the separation pulley 1-6-3
 - (2) Detaching and refitting the forwarding pulley and paper feed pulley 1-6-5
 - (3) Detaching and refitting the feed roller (20 ppm model only) 1-6-7
 - (4) Detaching and refitting the drawer separation pulley (20 ppm model only) 1-6-8

(5) Detaching and refitting the drawer forwarding pulley and drawer paper feed pulley (20 ppm model only)	1-6-9
(6) Detaching and refitting the paper conveying unit	1-6-11
(7) Detaching and refitting the bypass paper feed pulley and bypass separation pad	1-6-13
(8) Detaching and refitting the registration left roller	1-6-15
(9) Detaching and refitting the registration cleaner	1-6-15
(10) Adjustment after roller and clutch replacement	1-6-16
(10-1) Adjusting the leading edge registration of image printing	1-6-16
(10-2) Adjusting the leading edge registration for memory image printing	1-6-17
(10-3) Adjusting the center line of image printing	1-6-18
(10-4) Adjusting the trailing edge margin of image printing	1-6-19
(10-5) Adjusting the margins for printing	1-6-20
(10-6) Adjusting the amount of slack in the paper	1-6-21
1-6-3 Optical section	1-6-22
(1) Detaching and refitting the exposure lamp	1-6-22
(2) Detaching and refitting the scanner wires	1-6-23
(2-1) Detaching the scanner wires	1-6-23
(2-2) Fitting the scanner wires	1-6-25
(3) Detaching and refitting the ISU (reference)	1-6-28
(4) Detaching and refitting the laser scanner unit	1-6-29
(5) Adjusting the longitudinal squareness (reference)	1-6-32
(6) Adjusting magnification of the scanner in the main scanning direction	1-6-33
(7) Adjusting magnification of the scanner in the auxiliary scanning direction	1-6-34
(8) Adjusting the scanner leading edge registration	1-6-35
(9) Adjusting the scanner center line	1-6-36
(10) Adjusting the margins for scanning an original on the contact glass	1-6-37
1-6-4 Drum section	1-6-38
(1) Detaching and refitting the drum unit	1-6-38
(2) Detaching and refitting the drum separation claws	1-6-39
(3) Detaching and refitting the main charger unit	1-6-40
1-6-5 Developing section	1-6-41
(1) Detaching and refitting the developing unit	1-6-41
1-6-6 Transfer section	1-6-42
(1) Detaching and refitting the transfer roller	1-6-42
1-6-7 Fixing section	1-6-43
(1) Detaching and refitting the fixing unit	1-6-43
(2) Detaching and refitting the press roller	1-6-44
(3) Detaching and refitting the fixing heater M and S	1-6-45
(4) Detaching and refitting the heat roller separation claws	1-6-46
(5) Detaching and refitting the heat roller	1-6-47
(6) Detaching and refitting the fixing thermostat	1-6-48
(7) Detaching and refitting the fixing thermistor	1-6-48

1-7 Requirements on PCB Replacement

1-7-1 Upgrading the firmware on the main PCB	1-7-1
1-7-2 Upgrading the printer board firmware	1-7-2
1-7-3 Adjustment-free variable resistors (VR)	1-7-3
1-7-4 Remarks on engine PCB or main PCB replacement	1-7-3

2-1 Mechanical construction

2-1-1 Paper feed section	2-1-1
2-1-2 Optical section	2-1-4
(1) Original scanning	2-1-5
(2) Image printing	2-1-6
2-1-3 Drum section	2-1-8
2-1-4 Developing section	2-1-10
(1) Formation of magnetic brush	2-1-11
(2) Single component developing system	2-1-12

2-1-5	Transfer and separation sections	2-1-13
2-1-6	Fixing section	2-1-15
	(1) Fixing temperature system	2-1-16
	(2) Fixing temperature control based on ambient temperature	2-1-16
2-1-7	Exit and switchback sections	2-1-17
2-1-8	Duplex section	2-1-18
	(1) Paper conveying operation in duplex copying	2-1-19
2-2	Electrical Parts Layout	
2-2-1	Electrical parts layout	2-2-1
	(1) PCBs	2-2-1
	(2) Switches and sensors	2-2-2
	(3) Motors	2-2-4
	(4) Other electrical components	2-2-5
2-4	Appendixes	
	Timing chart No. 1	2-4-1
	Timing chart No. 2	2-4-2
	Timing chart No. 3	2-4-3
	Timing chart No. 4	2-4-4
	Chart of image adjustment procedures	2-4-5
	Maintenance parts list	2-4-8
	Periodic maintenance procedures	2-4-9
	General wiring diagram	2-4-11

1-1-1 Specifications

Type	Desktop	
Copying system	Indirect electrostatic system	
Originals	Sheets, books and 3-dimensional objects (Maximum original size: A3/11" × 17")	
Original feed system	Fixed	
Copy paper	Paper weights	
	Drawer: 60 – 105 g/m ²	
	Bypass table: 45 – 160 g/m ²	
	Paper type	
	Drawer: Plain paper, recycled paper and colored paper	
	Bypass table: Plain paper, recycled paper, thin paper, thick paper and colored paper	
Copying sizes	Maximum: A3/11" × 17"	
	Minimum: A6R /5 ¹ / ₂ " × 8 ¹ / ₂ "	
Magnification ratios	Manual mode: 25 – 200%, 1% increments	
Copy speed	At 100% magnification in copy mode:	
	16 ppm model	20 ppm model
	A4: 16 copies/min.	A4: 20 copies/min.
	A4R: 13 copies/min.	A4R: 13 copies/min.
	A3: 8 copies/min.	A3: 10 copies/min.
	A5R: 10 copies/min.	A5R: 10 copies/min.
	A6R: 10 copies/min.	A6R: 10 copies/min.
	B5: 16 copies/min.	B5: 20 copies/min.
	B5R: 13 copies/min.	B5R: 13 copies/min.
	B4 (257 × 364 mm): 8 copies/min.	B4 (257 × 364 mm): 11 copies/min.
	11" × 8 ¹ / ₂ " : 16 copies/min.	11" × 8 ¹ / ₂ " : 20 copies/min.
	8 ¹ / ₂ " × 11" : 13 copies/min.	8 ¹ / ₂ " × 11" : 13 copies/min.
	11" × 17" : 8 copies/min.	11" × 17" : 10 copies/min.
	8 ¹ / ₂ " × 14" : 8 copies/min.	8 ¹ / ₂ " × 14" : 11 copies/min.
First copy time	5.9 s or less (A4/11" × 8 ¹ / ₂ ")	
Warm-up time	Less than 20 s (room temperature 23°C/73.4°F, 50% RH)	
	Time for recovery from low power mode: 10 s	
	Time for recovery from sleep mode: 20 s	
Paper feed system	Automatic feed	
	Capacity:	
	Drawers: 300 sheets (80 g/m ²)	
	100 sheets (90 – 105 g/m ²)	
	Manual feed	
	Capacity:	
	Bypass: 50 sheets (A4/11" × 8 ¹ / ₂ " or less)	
	25 sheets (A3, B4, 11" × 17", 8 ¹ / ₂ " × 14")	
Paper ejection system	In-machine ejection (face down)	
	Capacity: 250 sheets (80 g/m ²)	
Continuous copying	1 – 999 sheets	
Photoconductor	OPC (drum diameter 30 mm)	
Charging system	Single positive corona charging	
Recording system	Semiconductor laser	
Developing system	Single component developing system	
	Toner: magnetism toner	
	Toner replenishing: automatic from a toner container	
Transfer system	Transfer roller	
Separation system	Curvature separation and separation electrode	
Fixing system	Heat roller	
	Heat source: halogen heaters (120 V specifications: main 550 W, sub 400W/ 220-240 V specifications: main 590 W, sub 430 W)	
	Control temperature: 170°C/338°F (180°C/356°F on and after 6th sheet)	
	Abnormally high temperature protection device: 180°C/356°F thermostat	
	Fixing pressure: 44.1 N	
Charge erasing system	Exposure by cleaning lamp	
Cleaning system	Cleaning blade	
Scanning system	Flat bed scanning by CCD image sensor	
Bitmap memory	35 MB (standard)	
Image storage memory	29 MB (standard)	

2DA/2DB

Additional memory	16 MB, 32 MB, 64 MB and 128 MB
Resolution	600 × 600 dpi
Light source	Inert gas lamp
Dimensions	574 (W) × 603 (D) × 545 (H) mm 22 ⁵ / ₈ " (W) × 23 ³ / ₄ " (D) × 21 ¹ / ₂ " (H)
Weight	Approx. 40.7 kg/89.7 lbs
Floor requirements	827 (W) × 603 (D) mm 32 ⁵ / ₈ " (W) × 23 ³ / ₄ " (D)
Functions	Automatic paper selection, Image quality selection, Automatic sizing selection function, zoom function, Duplex copy, Divided copy, Binding margin, Border width, Aggregate copy, Sort copy, Eco-copy, Copy program and Section management mode
Power source	120 V AC, 60 Hz, 9.0 A 220 – 240 V AC, 50 Hz, 5.0 A
Options	Document processor, paper feeder, duplex unit, finisher, job separator, key counter, fax system, network scanner, hard disk and additional memory

• Printer functions

Printing speed	Same as copying speed
First print time	Approx. 5.5 s (A4/11" × 8 ¹ / ₂ ")
Resolution	300 dpi, 600 dpi, Fast 1200 mode
Memory	64 MB (standard) Additional memory: 32 MB, 64 MB, 128 MB and 256 MB Hard disk: 340 MB, 512 MB and 1 GB
Applicable OS	Microsoft Windows 95/98/Me/NT4.x/2000/XP Apple Macintosh OS 9.x/OS X 10.x UNIX/Linux
Interface	Parallel interface (based on IEEE1284) Network interface USB 2.0 (USB Hi-Speed) Network interface card (option)

• Duplex unit

Type	Internal type
Copy paper	Paper weights: 64 – 90 g/m ² Paper type: Plain paper, recycled paper and colored paper
Paper sizes	A3 – A5R/11" × 17" – 5 ¹ / ₂ " × 8 ¹ / ₂ "
Power source	Electrically connected to the MFP
Dimensions	368 (W) × 53 (D) × 180 (H) mm 14 ¹ / ₂ " (W) × 2 ¹ / ₁₆ " (D) × 7 ¹ / ₁₆ " (H)
Weight	Approx. 0.65 kg/1.43 lbs

1-1-2 Parts names and their functions

(1) MFP





Figure 1-1-1

- ① Original cover
- ② Copy storage section
- ③ Operation panel
- ④ Drawer 1
- ⑤ Drawer 2 (20 ppm model only)
- ⑥ Width guide
- ⑦ Length guide
- ⑧ Left cover handle
- ⑨ Bypass tray

- ⑩ Support guide
- ⑪ Slider
- ⑫ Contact glass
- ⑬ Original size indicator plates
- ⑭ Left cover
- ⑮ Waste toner box
- ⑯ Toner container release lever
- ⑰ Toner container
- ⑱ Cleaner rod

- ⑲ Front cover
- ⑳ Power switch
- ㉑ Power switch cover
- ㉒ Handles for transport
- ㉓ Network interface connector
- ㉔ USB interface connector
- ㉕ Parallel interface connector
- ㉖ Memory card slot



(2) Operation panel




Figure 1-1-2

- | | |
|---|---|
| ① System Menu/Counter key and indicator | ⑳ Paper Select key / Right cursor key |
| ② Copier key and indicator | ㉑ Enter key |
| ③ Printer key and indicator | ㉒ Image quality mode select key |
| ④ Scanner key and indicator | ㉓ Auto Exposure key |
| ⑤ Fax key and indicator | ㉔ Lighter key / Darker key / exposure display |
| ⑥ Combine key and indicator | ㉕ Message display |
| ⑦ Border Erase key and indicator | ㉖ Ready indicator |
| ⑧ Duplex/Split Page key and indicator | ㉗ Data indicator |
| ⑨ Offset key and indicator | ㉘ Attention indicator |
| ⑩ Function key | ㉙ Job Accounting key |
| ⑪ Scanner Function key | ㉚ Interrupt key and indicator |
| ⑫ Auto Selection key and indicator | ㉛ Energy Saver key and indicator |
| ⑬ Margin key and indicator | ㉜ Power key and indicator |
| ⑭ Sort key and indicator | ㉝ Numeric keys |
| ⑮ Staple key and indicator | ㉞ Reset key |
| ⑯ Program key | ㉟ Stop/Clear key |
| ⑰ Zoom key / Left cursor key | ㊱ Start key and indicator |
| ⑱ Auto%/100% key / Down cursor key | ㊲ Main power indicator |
| ⑲ Original Size key / Up cursor key | |

1-1-3 Machine cross section




Figure 1-1-3 Machine cross section

- ① Paper feed section
- ② Optical section
- ③ Drum section
- ④ Developing section
- ⑤ Transfer and separation section
- ⑥ Fixing section
- ⑦ Exit and switchback section
- ⑧ Duplex section

1-1-4 Drive system




Figure 1-1-4

- ① Drive motor gear
- ② Gear 122
- ③ Registration gear 51
- ④ Registration motor gear
- ⑤ Gear 32
- ⑥ Gear 25
- ⑦ Gear 25
- ⑧ Gear 20
- ⑨ Paper feed clutch gear
- ⑩ Gear 30
- ⑪ Gear 31
- ⑫ Gear 25
- ⑬ Gear 49
- ⑭ Gear 30/23
- ⑮ Developing gear 25
- ⑯ Developing gear 26
- ⑰ Fixing joint gear 29
- ⑱ Gear 40
- ⑲ Gear 40
- ⑳ Gear 88/34
- ㉑ Gear 40
- ㉒ Fixing joint gear 40
- ㉓ Coupling gear
- ㉔ Gear 50
- ㉕ Gear 60
- ㉖ Exit motor gear
- ㉗ Gear 43/20

1-2-1 Drum

Note the following when handling or storing the drum.


- When removing the drum unit, never expose the drum surface to strong direct light.
- Keep the drum at an ambient temperature between $-20^{\circ}\text{C}/-4^{\circ}\text{F}$ and $55^{\circ}\text{C}/131^{\circ}\text{F}$ and at a relative humidity not higher than 90% RH. Avoid abrupt changes in temperature and humidity.
- Avoid exposure to any substance which is harmful to or may affect the quality of the drum.
- Do not touch the drum surface with any object. Should it be touched by hands or stained with oil, clean it.

1-2-2 Toner

Store the toner in a cool, dark place. Avoid direct light and high humidity.

1-2-3 Installation environment

1. Temperature: 10 - 32.5°C/50 - 90.5°F
2. Humidity: 15 - 80%RH
3. Power supply: 120 V AC, 9.0 A
220 - 240 V AC, 5.0 A
4. Power source frequency: 50 Hz ±0.3%/60 Hz ±0.3%
5. Installation location
 - Avoid direct sunlight or bright lighting. Ensure that the photoconductor will not be exposed to direct sunlight or other strong light when removing paper jams.
 - Avoid extremes of temperature and humidity, abrupt ambient temperature changes, and hot or cold air directed onto the machine.
 - Avoid dust and vibration.
 - Choose a surface capable of supporting the weight of the machine.
 - Place the machine on a level surface (maximum allowance inclination: 1°).
 - Avoid air-borne substances that may adversely affect the machine or degrade the photoconductor, such as mercury, acidic or alkaline vapors, inorganic gasses, NOx, SOx gases and chlorine-based organic solvents.
 - Select a room with good ventilation.
6. Allow sufficient access for proper operation and maintenance of the machine.
Machine front: 1000 mm/39³/₈" Machine rear: 100 mm/3¹⁵/₁₆"
Machine right: 300 mm/11¹³/₁₆" Machine left: 300 mm/11¹³/₁₆"




- a: 571 mm/22¹/₂"
- b: 603 mm/23³/₄"
- c: 502 mm/19³/₄"
- d: 1371.5 mm/54"
- e: 1323 mm/52¹/₁₆"
- f: 952.5 mm/37¹/₂"

Figure 1-2-1 Installation dimensions

1-3-1 Unpacking and installation

(1) Installation procedure



Unpack.

16 ppm model




Figure 1-3-1a Unpacking

- | | | |
|-------------------|-------------------|---|
| ① MFP | ⑩ Left spacer | ⑲ Original holder
(Asia and Oceania) |
| ② Power cord | ⑪ Rear spacer | ⑳ Operation guide |
| ③ Toner container | ⑫ Rear pad | Cassette size sheet |
| ④ Outer case | ⑬ Skid | Paper protection bag |
| ⑤ Lower left pad | ⑭ Belt | Error code label |
| ⑥ Lower right pad | ⑮ Eject sheet | Inspection report |
| ⑦ Upper left pad | ⑯ Machine cover | |
| ⑧ Upper right pad | ⑰ Bar code labels | |
| ⑨ Inner frame | ⑱ Top sheet | |

* Place the machine on a level surface.



20 ppm model




Figure 1-3-1b Unpacking

- | | | |
|-------------------|-------------------|---|
| ① MFP | ⑩ Left spacer | ⑲ Original holder
(Asia and Oceania) |
| ② Power cord | ⑪ Rear spacer | ⑳ Front pad |
| ③ Toner container | ⑫ Rear pad | ㉑ Operation guide
Cassette size sheet
Paper protection bag
Error code label
Inspection report |
| ④ Outer case | ⑬ Skid | |
| ⑤ Lower left pad | ⑭ Belt | |
| ⑥ Lower right pad | ⑮ Eject sheet | |
| ⑦ Upper left pad | ⑯ Machine cover | |
| ⑧ Upper right pad | ⑰ Bar code labels | |
| ⑨ Inner frame | ⑱ Top sheet | |

* Place the machine on a level surface.



Install the optional paper feeder.

1. Install the optional paper feeder as necessary (see page 1-3-7 to 1-3-8).

Remove the tapes and pins.

1. Remove the ten tapes (16 ppm model).
Remove the fifteen tapes (20 ppm model).





Figure 1-3-2

2. Remove the two pins for light source unit.




Figure 1-3-3

Install the original cover or optional DP.

1. Install the original cover or optional DP (see pages 1-3-9 to 1-3-12 when installing the DP).

Install the optional duplex unit.

1. Install the optional duplex unit as necessary (see pages 1-3-13 to 1-3-15).

Install the optional finisher or job separator.

1. Install the optional finisher or job separator as necessary (see pages 1-3-22 to 1-3-34).

Install the toner container.

1. Open the front cover.
2. Tap the top of the toner container five to six times.
3. Shake the toner container approximately 10 times in the horizontal direction to stir toner.
4. Turn the toner container release lever and gently push the toner container into the MFP.
 - * Push the container all the way into the MFP until it locks in place.
5. Restore the toner container release lever.
6. Close the front cover.




Figure 1-3-4

Connect the power cord.

1. Connect the power cord to the connector on the MFP.
2. Insert the power plug into the wall outlet and turn the power switch on.

Installing the toner (maintenance item U130).

1. Enter the maintenance mode by entering "10871087" using the numeric keys.
2. Enter "130" using the numeric keys and press the start key.
3. Press the start key to execute the maintenance item.
 - Installation of toner starts and time (minutes) is indicated until the installation ends.
4. When the installation is complete, "FINISHED" will be displayed if the installation is successful or "NG" will be displayed if it has failed.
5. Press the stop/clear key.

Load paper.

1. Load paper in the drawer.



Output an own-status report (maintenance item U000).

1. Enter "000" using the numeric keys and press the start key.
2. Select "MAINTENANCE" and press the start key to output a list of the current settings of the maintenance items.
3. Press the stop/clear key.

Exit maintenance mode.

1. Enter "001" using the numeric keys and press the start key.
The machine exits the maintenance mode.

Make test copies.

1. Place an original and make test copies.

End of installation.

1-3-2 Setting initial copy modes

Factory settings are as follows:

Maintenance item No.	Contents	Factory setting
U253	Switching between double and single counts	Double count
U254	Turning auto start function on/off	ON
U258	Switching copy operation at toner empty detection	SINGLE MODE
U260	Changing the copy count timing	After ejection
U264	Setting the display order of the date	Month/Day/Year (Inch specifications) Day/Month/Year (Inch specifications)
U277	Setting auto application change time	30
U326	Setting the black line cleaning indication	ON
U342	Setting the ejection restriction	ON
U343	Switching between duplex/simplex copy mode	OFF
U344	Setting preheat/energy saver mode	ENERGY STAR

1-3-3 Installing the paper feeder (option)

<Procedure>

- Place the MFP on the paper feeder by aligning the positioning insertion sections of the MFP with the positioning pins at the rear part of the paper feeder.
* When placing the MFP, take care not to hit the MFP against the drawer, the pins or ground plate of the paper feeder.




Figure 1-3-5

For stacking paper feeders for use:

Stack a paper feeder on another paper feeder by aligning the positioning insertion sections of the first paper feeder with the positioning pins at the rear part of the second paper feeder.

(For 16 ppm model, three paper feeders can be stacked./For 20 ppm model, two paper feeders can be stacked.)




Figure 1-3-6

- If a type of paper that is not included in the specifications for the standard sheet cassette size is used, replace the cassette size sheet indication with the supplied one.
- Insert the MFP power plug into the wall outlet and turn the power switch on.
Load paper in the drawer and make test copies to check the operation.




Figure 1-3-7

Adjusting the leading edge timing

1. Run maintenance mode 034.
 Select ADJ, RCL ON TIMING and press the start key.
 First optional cassette: Select RCL T1.
 Second optional cassette: Select RCL T2.
 Third optional cassette: Select RCL T3.
 For models equipped with two standard cassettes, adjust only RCL T2 and RCL T3.
 Press the Interrupt key to output the test pattern and check the image. If an adequate image cannot be obtained, carry out the following adjustment.
2. If a test pattern (a) is obtained, increase the adjustment value.
 If a test pattern (b) is obtained, decrease the adjustment value.
 Setting range: -5.0 - +10.0
 Changing the value by one moves the leading edge by 0.1 mm.
3. Output the test pattern again.
4. Repeat steps 2 and 3 until an adequate image is obtained.




Figure 1-3-8

Adjusting the center line

1. Run maintenance mode 034.
 Select ADJ, LSU OUT TIMING and press the start key.
 First optional cassette: Select LSU T1.
 Second optional cassette: Select LSU T2.
 Third optional cassette: Select LSU T3.
 For models equipped with two standard cassettes, adjust only LSU T2 and LSU T3.
 Press the Interrupt key to output the test pattern and check the image. If an adequate image cannot be obtained, carry out the following adjustment.
2. If a test pattern (a) is obtained, increase the adjustment value.
 If a test pattern (b) is obtained, decrease the adjustment value.
 Setting range: -7.0 - +10.0
 Changing the value by one moves the center line by 0.1 mm.
3. Output the test pattern again.
4. Repeat steps 2 and 3 until an adequate image is obtained.




Figure 1-3-9

1-3-4 Installing the DP (option)

<Procedure>

1. Remove the original holder and remove the two screws from the rear top cover.
2. Pass the two pins through the screw holes of the rear top cover and attach them to the lower frame.




Figure 1-3-10

3. Place the DP on the MFP by fitting the pins into the holes at the hinge sections of the DP and sliding them toward the front side.




Figure 1-3-11

4. Secure the DP with the two TP Taptite chromate screws M4 × 10 and the two screws that have been removed in step 1.




Figure 1-3-12

5. Close the DP, fit the fixing fitting from the rear side of the right hinge, and secure it with the two bronze TP screws M3 x 06.
6. Connect the cable of the DP to the MFP.
 - * Be sure to tighten the fixing screws on both side of the connector.




Figure 1-3-13

7. Clean the pasting position for the caution label with alcohol.
Paste the caution label that corresponds to the language according to the destination to the DP.




Figure 1-3-14

[Operation check]

1. Prepare an original on which 4 lines are drawn 15 mm from the edges and the center line is drawn.
2. Set the original on the DP and make a test copy to check the copy image.
At this time, set the paper guide for the original table and drawer to the paper size to be used.
3. If the copy image does not match the original image, carry out the following adjustments in maintenance mode.
 - Maintenance mode 070 (sub-scan line adjustment)
 - Maintenance mode 071 (leading edge timing adjustment)
 - Maintenance mode 072 (center line adjustment)






Figure 1-3-15

Maintenance mode 070 (sub-scan line adjustment)

- Run maintenance mode 070.
Select CONVEY SPEED1.
(For adjustment of the back side in duplex copying, select CONVEY SPEED2.)
Set originals in the original tray and press the interrupt key. Make a test copy to check the image.
If an adequate image cannot be obtained, carry out the following adjustment.
- For copy example (a): decrease the value.
For copy example (b): increase the value.
Setting range: -25 - +25
Changing the value by one changes the sub-scan line by 0.1%.
A smaller setting value makes the copy image shorter. A larger value makes the image longer.

**Figure 1-3-16****Maintenance mode 071 (leading edge timing adjustment)**

- Run maintenance mode 071.
Select LEAD1.
(For adjustment of the back side in duplex copying, select LEAD2.)
Set originals in the original tray and press the interrupt key. Make a test copy to check the image.
If an adequate image cannot be obtained, carry out the following adjustment.
- For copy example (a): increase the value.
For copy example (b): decrease the value.
Setting range: -32 - +32
Changing the value by one moves the leading edge by 0.2 mm.
The larger the value, the later the image scan start timing.
The smaller the value, the earlier the image scan start timing.

**Figure 1-3-17**

Maintenance mode 072 (center line adjustment)

1. Run maintenance mode 072.

Select 1sided.

(For adjustment of the front side in duplex copying, select 2sided front. For adjustment of the back side, select 2sided back.)

Set originals in the original tray and press the Interrupt key. Make a test copy to check the image.

If an adequate image cannot be obtained, carry out the following adjustment.

2. For copy example (a): increase the value.

For copy example (b): decrease the value.

Setting range: -39 - +39

Changing the value by one moves the center line by 0.1 mm.

The larger the value, the center of the image moves toward the right.

The smaller the value, the center of the image moves toward the left.




Figure 1-3-18

1-3-5 Installing the duplex unit (option)

<Procedure>

1. Open the left cover.
2. Remove the stop ring and the strap from the rear side.
3. Restore the conveyor section.
4. Remove the fitting projection and pin, and then remove the stopper from the front side.
5. Open the left cover until it is put horizontally.




Figure 1-3-19

6. Turn the wire guide section of the duplex unit in the direction indicated by the arrow.




Figure 1-3-20

7. Insert the axis sections of the duplex unit into the U-shape grooves of the conveyor unit.




Figure 1-3-21

8. Press the duplex unit in the direction indicated by the arrow to fit the claws into the conveyer unit.




Figure 1-3-22

9. Secure the duplex unit with the two S tite screws M3 × 06.




Figure 1-3-23

10. Open the conveyer unit and connect the connector of the duplex unit to the MFP.
11. Reattach the removed parts to their original positions.
12. Connect the MFP power plug to the wall outlet and turn the power switch on.




Figure 1-3-24

Adjusting the leading edge timing

- Run maintenance mode 034.
Select ADJ, RCL ON TIMING and press the start key.
Select RCL DUP.
Press the Interrupt key to output the test pattern in the duplex mode and check the image.
If an adequate image cannot be obtained, carry out the following adjustment.
- If a test pattern (a) is obtained, increase the adjustment value.
If a test pattern (b) is obtained, decrease the adjustment value.
Setting range: -5.0 - +10.0
Changing the value by one moves the leading edge by 0.1 mm.
- Output the test pattern again.
- Repeat steps 2 and 3 until an adequate image is obtained.




Figure 1-3-25

Adjusting the center line

- Run maintenance mode 034.
Select ADJ, LSU OUT TIMING and press the start key.
Select LSU DUP.
Press the Interrupt key to output the test pattern in the duplex mode and check the image.
If an adequate image cannot be obtained, carry out the following adjustment.
- a: Adequate image
If a test pattern (a) is obtained, increase the adjustment value.
If a test pattern (b) is obtained, decrease the adjustment value.
Setting range: -7.0 - +10.0
Changing the value by one moves the center line by 0.1 mm.
- Output the test pattern again.
- Repeat steps 2 and 3 until an adequate image is obtained.




Figure 1-3-26

1-3-6 Installing the drawer heater (option)

Drawer heater installation requires the following parts:

- Drawer heater (P/N 120 V specifications: 2C960030, 220-240 V specifications: 2C960040)
- One (1) M4 × 10 tap-tight S binding screw (P/N B3024100)

<Procedure>

1. Remove the right cover.
2. Pull out the drawer.
3. Remove the three screws and then the front right cover.




Figure 1-3-27

4. Insert the cassette heater from the bottom of the machine and attach it to the MFP.
- 1) Pass the connector of the cassette heater through the hole located in the right frame of the machine to pull it out.
- 2) Insert the projections at the rear side of the cassette heater mounting plate into the two holes in the rear frame of the machine.
- 3) Position the screw hole of the drawer heater to the screw hole of the front frame of the machine and secure the heater using the M4 × 10 Taptite S binding screw.




Figure 1-3-28

2DA/2DB

5. Remove the two screws and open the power source PCB in the direction indicated by the arrow.
 - * Take care not to open the power source PCB too much.
6. Fit the wire of the drawer heater into the groove of the frame and put it inside the power source PCB.
 - * Fit the wire into the groove so that the band mounted to the wire is located above the frame.




Figure 1-3-29

7. Reattach the power source PCB to its original position and connect the connector of the drawer heater to YC8 of the power source PCB.
8. Refit all the removed parts.




Figure 1-3-30

1-3-7 Installing the key counter (option)

Key counter installation requires the following parts:

- Key counter cover (P/N 2A360010)
- Key counter retainer (P/N 66060030)
- Key counter mount (P/N 66060040)
- Key counter assembly (P/N 41529210)
- Four (4) M4 × 6 bronze TP-A screws (P/N B4304060)
- One (1) M4 × 35 round head screw (P/N B0004350)
- Two (2) M3 × 6 bronze flat-head screws (P/N B2303060)
- One (1) M3 bronze nut (P/N C2303000)
- Key counter mounting plate (P/N 2C960100)
- Key counter wire (P/N 2C960110)

Procedure

1. Fit the key counter socket assembly to the key counter retainer using the two screws and nut.
2. Fit the key counter mount to the key counter cover using the two screws, and attach the key counter retainer to the mount using the two screws.




Figure 1-3-31

3. Remove the rear cover.
4. Cut out the aperture plate on the right cover using nippers.
5. Connect the 4-pin connector of the key counter wire (located at a longer distance from the tube) to YC13 on the engine PCB, pass the wire through the two clamps, and pull the other 4-pin connector out from the aperture of the right cover.
- * Arrange the key counter wire behind the optical system wire as shown in the illustration.
6. Fold the 7-pin connector of the key counter wire back, pass the wire through the clamp at the upper part of the controller box, and hang it.




Figure 1-3-32

7. Pass the connector of the key counter through the aperture of the key counter mounting plate, and engage the projection of key counter mounting plate with the square hole of the key counter cover.




Figure 1-3-33

8. Connect the 4-pin connector of the key counter to the key counter wire.
9. Engage the projection of the key counter mounting plate with the aperture of the right cover.
10. Secure the key counter cover and the key counter mounting plate together with the MFP using a M4 x 35 screw.
11. Refit the rear cover.




Figure 1-3-34

12. Insert the key counter into the key counter socket assembly.
13. Turn the power switch on and enter the maintenance mode.
14. Run maintenance item U204 and select "KEY-COUNTER."
15. Exit the maintenance mode.
16. Check that the message requesting the key counter to be inserted is displayed on the message display when the key counter is pulled out.
17. Check that the counter counts up as copies are made.

1-3-8 Installing the finisher (option)

<Note>

When placing the transfer unit on the floor or the like, be sure to place it upside down. If not, the staple mounting plate may be deformed, resulting in a malfunction.




Figure 1-3-35

Be sure to remove the tape for the intermediate tray at Procedure 16 not removing before mounting.




Figure 1-3-36

<Procedure>

Remove the covers.

1. Remove the two screws to remove the upper left cover.




Figure 1-3-37

2. Open the front cover.
3. Remove the inner cover.




Figure 1-3-38

4. Release the fitting parts using a small screw driver or the like and remove the front side cover.




Figure 1-3-39

5. Remove the screw and the fitting part located on the right side and then remove the left front cover.
6. Open the front cover.




Figure 1-3-40

2DA/2DB

7. Remove the three screws and then remove the ejection cover and inner ejection cover.




Figure 1-3-41

8. Remove the two screws and then remove the cover.




Figure 1-3-42

Attach the transfer unit.

9. Insert the transfer unit from the MFP front side and slide it to the left to install to the ejector part.
10. Place the transfer unit closer to the ejector side and then secure the front side using the TP bind screw M3 × 06 and the rear side using the pin.




Figure 1-3-43

Release the lever securing fitting.

11. Loosen the screw located at the rear side of the transfer unit and release the lever securing fitting in the direction of an arrow, and then retighten the screw.




Figure 1-3-44

Attach the intermediate tray.

12. Loosen the screw located inside of the MFP by about 3 turns.
* Do not turn the screw too much, otherwise it may drop in the machine.
13. Hang the hook of the hook holder onto the screw and then retighten the screw.




Figure 1-3-45

14. Insert the intermediate tray from the front side of the MFP while pushing the hook to the back and then push the pin located at the right rear side of the intermediate tray into the hook holder until the fitting sound is heard.




Figure 1-3-46

15. Fit the pin located at the left rear side of the intermediate tray from the rear side of the MFP onto the hook of the transfer unit.
16. Remove the tape and pull out the 13-pin connector and 24-pin connector.




Figure 1-3-47

17. Connect the 24-pin connector of the intermediate tray to the connector of the transfer unit.
18. Connect the 13-pin connector of the intermediate tray to YC5 on the engine circuit board.




Figure 1-3-48

Attach the covers.

19. Attach the cover that has been removed by Procedure 8 to its original position using the two screws.
20. Attach the large ejection cover with the two screws that have been removed by Procedure 1.




Figure 1-3-49

21. Attach the front ejection cover and rear ejection cover using the TP bind screw M3 × 06 each.




Figure 1-3-50

- 22. Open the front cover.
- 23. Attach the staple cover as it is fitted to the staple unit from the ejection side and then secure it using the TP bind screw M3 × 06.
- 24. Attach the inner cover that has been removed by Procedure 3 to its original position.
- 25. Close the front cover.




Figure 1-3-51

26. Insert the front and rear hooks of the copy tray into the front ejection cover and rear ejection cover each and then attach the copy tray.




Figure 1-3-52

27. Open the staple cover and then insert the staple cartridge into the staple unit.
28. Close the staple cover.




Figure 1-3-53

Operation check

1. Insert the MFP power plug into an outlet and then turn the power switch on.
2. Select the staple mode and check the staple operation.

1-3-9 Installing the job separator (option)

<Procedure>

Remove the covers.

1. Open the front cover.
2. Remove the inner cover.




Figure 1-3-54

3. Release the fitting parts using a small screw driver or the like and remove the front side cover.




Figure 1-3-55

4. Remove the screw and the fitting part located on the right side and then remove the left front cover.






Figure 1-3-56

5. Remove the three screws and then remove the ejection cover and inner ejection cover.

**Figure 1-3-57**

6. Remove the two screws and then remove the cover.

**Figure 1-3-58**

Attach the job separator.

- 7. Insert the job separator from the MFP front side and slide it to the left to install to the ejector part.
- 8. Place the job separator closer to the ejector side and then secure the front side with the large pin and the rear side with the small pin.




Figure 1-3-59

- 9. Loosen the screw that secures the drive unit located at the rear side of the job separator to make it ready for starting to drive and then retighten the screw.
- 10. Connect the connector of the job separator to YC5 on the engine circuit board.
- 11. Attach the cover that has been removed by Procedure 6 to its original position using the two screws.




Figure 1-3-60

Attach the copy tray.

12. Insert the left part of the copy tray into the groove of the job separator. Fit the right hook into the hole located inside of MFP while pushing the copy tray to the back along the groove.




Figure 1-3-61

Attach the left front cover JS.

13. Pull out the connector of the job separator from the hole of the left front cover that has been removed by Procedure 4 and then attach the left front cover to its original position using the screw.




Figure 1-3-62

14. Connect the pulled out connector of the job separator to the LED PCB of the left front cover JS and then pass the wire through the two positions of the groove of the left front cover JS.




Figure 1-3-63

15. Fit the pawl of the left front cover JS into the hole of the left front cover to attach the left front cover JS.
* In this time, take care that the routed wire in the groove does not come off.
16. Attach the inner cover that has been removed by Procedure 2 to its original position.
17. Close the front cover.




Figure 1-3-64

Operation check

1. Insert the power plug of the MFP into an outlet and then turn the power switch on.
2. Set the “copy ejection location” of the machine default settings to job separator.
3. Make a test copy to check that a copy is ejected to the job separator tray.

1-3-10 Installing the fax system (option)

<Procedure>

Install the optional Memory module DIMM (32MB).

1. Remove the two connectors of the fax control PCB assembly.
2. Remove the three screws and remove the mounting plate and the ground wire.




Figure 1-3-65

3. Insert the memory module DIMM at an angle into the memory slot so that the notch of the memory DIMM is positioned to the projection of the memory slot on the fax control PCB assembly. (①)
4. Push the free end of the module down toward the board. (②)
5. Attach the mounting plate and the ground wire that have been removed by Procedure 2 with the three screws to their original positions.
6. Connect the two connectors that have been removed by Procedure 1.




Figure 1-3-66

Remove the shield cover.

- 7. Remove the six screws, lift the shield cover and then remove the cover.




Figure 1-3-67

Remove the modular cover.

- 8. Remove the screw and take off the modular cover.




Figure 1-3-68

Attach the fax control PCB assembly.

- 9. Loosen the screw on the printer board.
- 10. While taking care that the mounting surface of the board does not contact the frame section of the rear cover, insert the U terminal of the ground wire of the fax control PCB assembly and secure it with the screw.




Figure 1-3-69

11. Connect the YC1 connector on the fax control PCB assembly to the YC15 connector on the engine PCB.
12. Insert the fax control PCB assembly to the shield box so that the projection of the fax control PCB assembly is positioned to the slit of the shield box.
13. Secure the fax control PCB assembly using the three TP tap tight screws M3 × 6.

Take care that the ground wire is not put on the frame section of the rear cover.




Figure 1-3-70

Attach the NCU PCB assembly.

14. Connect the NCU wire connector on the NCU PCB assembly to the YC2 connector on the fax control PCB assembly.




Figure 1-3-71

15. Secure the NCU PCB assembly using the four TP tap tight screws M3 × 6, paying attention so that the tape section of the shield box does not contact with the PCB.




Figure 1-3-72

Attach the modular cover.

16. Attach the modular cover that has been removed by Procedure 8 with the screw to the position shown in the illustration.




Figure 1-3-73

Install the shield cover.

17. Insert the lower part of the shield cover that has been removed by Procedure 7 into the shield box and then attach it with the six screws and TP tap tight screw M4 × 6 to its original position.




Figure 1-3-74

Connect the telephone line to the line terminal.

18. Insert the modular connector cable to the line terminal to connect it to the telephone line. For 120 V specifications, use supplied modular cord B.




Figure 1-3-75

Attach the operation section sheet for fax.

19. Insert the small screw driver into the two points of the opening and remove the left cover of the operation section.




Figure 1-3-76

20. Lift the two pawls and remove the operation section sheet cover.




Figure 1-3-77

21. Remove the operation section sheet and replace it with the operation section sheet for fax of the corresponding language.




Figure 1-3-78

Attach the cover plate.

27. Incurvate the cover plate a little and then insert the upper and lower projections to the fitting parts of the operation section to attach.
28. Check that the cover plate smoothly moves on either side.




Figure 1-3-82

Attach the one-touch sheet.

29. Divide the one-touch sheet of the corresponding language into two parts and then mount them on the one-touch securing sheet each. Bring back the left cover of the operation section that has been removed by Procedure 19, operation section sheet that has been removed by Procedure 21, operation section sheet for fax that corresponds to the unused languages, and the one-touch sheet.




Figure 1-3-83

Attach the alphabet labels.

30. Take the alphabet labels from the one-touch label sheet, and adhere them above the corresponding numeric keys on the operation panel after wiping the panel with alcohol.
In Asia and Oceania, use the PQRS TUV WXYZ label, and do not use the PRS TUV WXZ and OPER labels.




Figure 1-3-84

Attach the certification label (120 V specifications only).

31. Adhere the FCC68 label onto the shield cover after wiping the cover with alcohol.




Figure 1-3-85

Execute the maintenance mode.

After installation is complete, the fax control PCB must be initialized by executing the maintenance mode U601/ U602.
(See the service manual of the fax system.)

1-3-11 Installing the scan system (option)

<Procedure>

Remove the covers.

1. Remove the six screws (a), lift the shield cover and then remove the cover.
If the fax system is installed, remove the six screws (a) and screw (b), lift the shield cover and then remove the cover.
2. Remove the two screws, and take off the cover.




Figure 1-3-86

Install the scanner board.

3. Insert the scanner board into the OPT1 opening of the shield box and firmly push the CN5 connector on the scanner board all the way into the YC12 connector on the engine circuit board.




Figure 1-3-87

4. Fasten the scanner board onto the shield box cover using the two screws that have been removed by Procedure 2.




Figure 1-3-88

Install the shield cover.

5. Insert the lower part of the shield cover that has been removed by Procedure 1 into the shield box and refit it to its original position using the six screws (a).
If the fax system is installed, refit the shield cover using the six screws (a) and screw (b) to its original position.




Figure 1-3-89

1-3-12 Installing the hard disk (option)

<Procedure>

1. Remove the two screws of the slot for OPT2 which is on the machine right back, and then remove the cover.
2. Insert the hard disk in the socket on the printer board PCB.
3. Refit the cover which is removed with step 1.
4. Turn the power switch on and initialize the hard disk at the printer menu.
5. Output the printer status report and confirm whether the hard disk is recognized.





Figure 1-3-90

1-4-1 Maintenance mode

The machine is equipped with a maintenance function which can be used to maintain and service the machine.

(1) Executing a maintenance item



(2) Maintenance modes item list

Section	Item No.	Maintenance item contents	Initial setting*
General	U000	Outputting an own-status report	—
	U001	Exiting the maintenance mode	—
	U002	Setting the factory default data	—
	U003	Setting the service telephone number	*****
	U004	Displaying the machine number	—
	U005	Copying without paper	—
	U019	Displaying the ROM version	—
Initialization	U020	Initializing all data	—
	U021	Initializing memories	—
	U022	Initializing backup memory	—
	U026	Evacuation of backup data	—
	U027	Return of backup data	—
Drive, paper feed, paper conveying and cooling system	U030	Checking motor operation	—
	U031	Checking switches for paper conveying	—
	U032	Checking clutch operation	—
	U034	Adjusting the print start timing <ul style="list-style-type: none"> • Adjusting the leading edge registration • Adjusting the center line • Adjusting the trailing edge margin 	0.9/1.2/1.3/ 1.3/1.3/1.0 -1.0/0.4/-1.2 -1.2/-1.2/0.3 0.0
	U035	Setting folio size <ul style="list-style-type: none"> • Length/Width • Width 	330 210
	U051	Adjusting the amount of slack in the paper	20/0/0/-20/-20/0
	U053	Performing fine adjustment of the motor speed	0.1/0/-0.5/0.1/ -0.1/-0.3/-0.3/ -1.5/-1.5
Optical	U060	Adjusting the scanner input properties	12
	U061	Turning the exposure lamp on	—
	U063	Adjusting the shading position	0
	U065	Adjusting the scanner magnification <ul style="list-style-type: none"> • Main scanning direction/auxiliary scanning direction 	0/-10
	U066	Adjusting the leading edge registration for scanning an original on the contact glass	7/0
	U067	Adjusting the center line for scanning an original on the contact glass	-4/0
	U068	Adjusting the scanning position for originals from the DP	0
	U070	Adjusting the DP magnification	0/0
	U071	Adjusting the DP scanning timing	0/0/0/0
	U072	Adjusting the DP center line	0/0/0
	U073	Checking scanner operation	—
	U074	Adjusting the DP input light luminosity	0
	U076	Executing DP automatic adjustment	—
	U087	Turning the DP scanning position adjust mode on/off	—
	U089	Outputting a MIP-PG pattern	—
	U092	Adjusting the scanner automatically	—
	U093	Setting the exposure density gradient <ul style="list-style-type: none"> • Text and photo/text/photo/text in fax mode/photo in fax mode 	0/0/0/2/3
	U099	Checking the original size detection	—

* Initial setting for executing maintenance item U020

Section	Item No.	Maintenance item contents	Initial setting*
High voltage	U100	Checking the operation of main high voltage	135/60/50/10
	U101	Setting high voltages <ul style="list-style-type: none"> • Developing bias • Transfer voltage • Separation voltage 	27/45/22/45 171/182/37/35 1/35/42
	U110	Checking/clearing the drum count	—
Developing	U130	Initial setting for the developer	—
	U144	Setting toner loading operation	OFF
	U157	Checking/clearing the developing drive time	—
	U158	Checking the developing count	—
Fixing and cleaning	U161	Setting the fixing control temperature <ul style="list-style-type: none"> • Primary stabilization fixing temperature • Secondary stabilization fixing temperature • Copying operation temperature 1 • Copying operation temperature 2 • Number of sheets for fixing control • Number of sheets for fixing control (thick paper) 	140 160 170 180 5 20
	U162	Stabilizing fixing forcibly	—
	U163	Resetting the fixing problem data	—
	U167	Checking/clearing fixing counts	—
	U199	Checking the fixing temperature	—
Operation panel and support equipment	U200	Turning all LEDs on	—
	U202	Setting the KMAS host monitoring system	—
	U203	Checking DP operation	—
	U204	Setting the presence or absence of a key card or key counter	—
	U207	Checking the operation panel keys	—
	U243	Checking the operation of the DP motors and solenoids	—
	U244	Checking the DP switches	—
	U245	Checking messages	—
	U246	Setting the finisher	4/4/4
Mode setting	U249	Checking the paper ejection to optional devices	—
	U250	Setting the maintenance cycle	150000
	U251	Checking/clearing the maintenance count	—
	U252	Setting the destination	Japan
	U253	Switching between double and single counts	Double count
	U254	Turning auto start function on/off	On
	U258	Switching copy operation at toner empty detection	Single mode
	U260	Changing the copy count timing	After ejection
	U264	Setting the display order of the date	Inch specifications: MONTH-DATE-YEAR Metric specifications: DATE-MONTH-YEAR
	U265	Setting OEM purchaser code	—
	U277	Setting auto application change time	30
	U326	Setting the black line cleaning indication	ON
	U332	Setting the size conversion factor	—
	U341	Specific paper feed location setting for printing function	—
U342	Setting the ejection restriction	On	
U343	Switching between duplex/simplex copy mode	Off	

* Initial setting for executing maintenance item U020

Section	Item No.	Maintenance item contents	Initial setting*
Mode setting	U344	Setting preheat/energy saver mode	ENERGY STAR
	U345	Setting the value for maintenance due indication	—
Image processing	U402	Adjusting margins of image printing	3.0/3.0/4.0
	U403	Adjusting margins for scanning an original on the contact glass	2.0/3.0/2.0/2.0
	U404	Adjusting margins for scanning an original from the DP	2.0/3.0/2.0/2.0
	U407	Adjusting the leading edge registration for memory image printing	0.0
Network scanner	U504	Initializing the scanner NIC	—
	U506	Setting the time out	10
Others	U901	Checking/clearing copy counts by paper feed locations	—
	U903	Checking/clearing the paper jam counts	—
	U904	Checking/clearing the service call counts	—
	U905	Checking counts by optional devices	—
	U906	Resetting partial operation control	—
	U908	Changing the total counter value	—
	U910	Clearing the black ratio data	—
	U911	Checking/clearing copy counts by paper sizes	—
	U917	Setting backup data reading/writing	—
	U920	Checking the accounting counts	—
	U925	Checking/clearing the system error counts	—
	U926	Rewriting FAX program	—
	U927	Clearing the all accounting counts and machine life counts	—
	U928	Checking machine life counts	—
	U941	Setting the default magnification ratio of the default drawer	—
	U942	Adjusting the DP amount of slack in the original	0
	U990	Checking/clearing the time for the exposure lamp to light	—
	U991	Checking the scanner count	—
U993	Outputting a VTC-PG pattern	—	

(3) Contents of maintenance mode items

Maintenance item No.	Description								
<p>U000</p>	<p>Outputting an own-status report</p> <p>Description Outputs lists of the current settings of the maintenance items, and paper jam and service call occurrences.</p> <p>Purpose To check the current setting of the maintenance items, or paper jam or service call occurrences. Before initializing or replacing the backup RAM, output a list of the current settings of the maintenance items to reenter the settings after initialization or replacement.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. The screen for selecting an item is displayed. 2. Select the item to be output using the up/down cursor keys. The selected item is displayed in reverse. <table border="1" data-bbox="320 636 1382 775"> <thead> <tr> <th data-bbox="320 636 699 678">Display</th> <th data-bbox="699 636 1382 678">Output list</th> </tr> </thead> <tbody> <tr> <td data-bbox="320 678 699 712">MAINTENANCE</td> <td data-bbox="699 678 1382 712">List of the current settings of the maintenance modes</td> </tr> <tr> <td data-bbox="320 712 699 745">JAM</td> <td data-bbox="699 712 1382 745">List of the paper jam occurrences</td> </tr> <tr> <td data-bbox="320 745 699 775">SERVICE CALL</td> <td data-bbox="699 745 1382 775">List of the service call occurrences</td> </tr> </tbody> </table> <ol style="list-style-type: none"> 3. Press the start key. The interrupt print mode is entered and a list is output. When A4/11" × 8 1/2" paper is available, a report of this size is output. If not, specify the paper feed location. When output is complete, the screen for selecting an item is displayed. <p>Completion Press the stop/clear key at the screen for selecting an item. The screen for selecting a maintenance item No. is displayed.</p>	Display	Output list	MAINTENANCE	List of the current settings of the maintenance modes	JAM	List of the paper jam occurrences	SERVICE CALL	List of the service call occurrences
Display	Output list								
MAINTENANCE	List of the current settings of the maintenance modes								
JAM	List of the paper jam occurrences								
SERVICE CALL	List of the service call occurrences								
<p>U001</p>	<p>Exiting the maintenance mode</p> <p>Description Exits the maintenance mode and returns to the normal copy mode.</p> <p>Purpose To exit the maintenance mode.</p> <p>Method Press the start key. The normal copy mode is entered.</p>								
<p>U002</p>	<p>Setting the factory default data</p> <p>Description Restores the machine conditions to the factory default settings.</p> <p>Purpose To move the mirror frame of the scanner to the position for transport (position in which the frame can be fixed).</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. The screen for executing is displayed. 2. Select the EXECUTE using the up/down cursor keys. It is displayed in reverse. 3. Press the start key. The mirror frame of the scanner returns to the position for transport. <p>Completion The power switch turns off.</p>								



Maintenance item No.	Description														
<p>U003</p>	<p>Setting the service telephone number</p> <p>Description Sets the telephone number to be displayed when a service call code is detected.</p> <p>Purpose To set the telephone number to call service when installing the machine.</p> <p>Method Press the start key. The currently set telephone number is displayed.</p> <p>Setting</p> <ol style="list-style-type: none"> Enter a telephone number (up to 15 digits) using the numeric keys. Move the cursor using the left/right cursor keys and select a number or symbol using the up/down cursor keys. To enter symbols, press the keys shown below as required. <table border="1" data-bbox="304 640 1062 871"> <thead> <tr> <th>Key</th> <th>Symbol</th> </tr> </thead> <tbody> <tr> <td>* key</td> <td>*</td> </tr> <tr> <td># key</td> <td>#</td> </tr> <tr> <td>Image mode selection key</td> <td>(</td> </tr> <tr> <td>Aoto mode selection key</td> <td>)</td> </tr> <tr> <td>Lighter key</td> <td>-</td> </tr> <tr> <td>Darker key</td> <td>Space</td> </tr> </tbody> </table> <ol style="list-style-type: none"> Press the start key. The phone number is set, and the screen for selecting a maintenance item No. is displayed. <p>Completion To exit this maintenance item without changing the current setting, press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p>	Key	Symbol	* key	*	# key	#	Image mode selection key	(Aoto mode selection key)	Lighter key	-	Darker key	Space
Key	Symbol														
* key	*														
# key	#														
Image mode selection key	(
Aoto mode selection key)														
Lighter key	-														
Darker key	Space														
<p>U004</p>	<p>Displaying the machine number</p> <p>Description Displays the machine number.</p> <p>Purpose To check the machine number.</p> <p>Method Press the start key. The currently machine number is displayed.</p> <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p>														



Maintenance item No.	Description						
<p>U005</p>	<p>Copying without paper</p> <p>Description Simulates the copy operation without paper feed.</p> <p>Purpose To check the overall operation of the machine.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. The screen for selecting an item is displayed. 2. Select the item to be operated using the up/down cursor keys. The selected item is displayed in reverse. <table border="1" data-bbox="320 517 1382 629"> <thead> <tr> <th data-bbox="320 517 699 562">Display</th> <th data-bbox="699 517 1382 562">Operation</th> </tr> </thead> <tbody> <tr> <td data-bbox="320 562 699 595">PPC</td> <td data-bbox="699 562 1382 595">Only the MFP operates.</td> </tr> <tr> <td data-bbox="320 595 699 629">PPC + DP</td> <td data-bbox="699 595 1382 629">Both the MFP and DP operate (continuous operation).</td> </tr> </tbody> </table> <ol style="list-style-type: none"> 3. Press the interrupt key. The copy mode screen is displayed. 4. Set the operation conditions required on the copy mode screen. Changes in the following settings can be made. <ul style="list-style-type: none"> • Paper feed locations • Magnifications • Simplex or duplex copy mode • Number of copies: in simplex copy mode, continuous copying is performed when set to 999; in duplex copy mode, continuous copying is performed regardless of the setting. • Copy density • Keys on the operation panel other than the energy saver (preheat) key 5. To control the paper feed pulley, remove all the paper in the drawers, or the drawers. With the paper present, the paper feed pulley does not operate. 6. Press the start key. The operation starts. Copy operation is simulated without paper under the set conditions. When operation is complete, the screen for selecting an item is displayed. 7. To stop continuous operation, press the stop/clear key. <p>Completion Press the stop/clear key at the screen for selecting an item. The screen for selecting a maintenance item No. is displayed.</p>	Display	Operation	PPC	Only the MFP operates.	PPC + DP	Both the MFP and DP operate (continuous operation).
Display	Operation						
PPC	Only the MFP operates.						
PPC + DP	Both the MFP and DP operate (continuous operation).						



Maintenance item No.	Description																										
<p>U019</p>	<p>Displaying the ROM version</p> <p>Description Displays the part number of the ROM fitted to each PCB.</p> <p>Purpose To check the part number or to decide if the ROM version is new from the last digit of the number.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. The part number indicating the ROM version are displayed. 2. Change the screen using the up/down cursor keys. <table border="1" data-bbox="304 517 1366 920"> <thead> <tr> <th>Display</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>MAIN</td> <td>Main ROM IC</td> </tr> <tr> <td>ENGINE</td> <td>Engine ROM IC</td> </tr> <tr> <td>LANG(St)</td> <td>Standard language ROM IC</td> </tr> <tr> <td>LANG(Op)</td> <td>Optional language ROM IC</td> </tr> <tr> <td>MAIN BOOT</td> <td>Boot of main ROM IC</td> </tr> <tr> <td>PRINTER</td> <td>Printer board ROM IC</td> </tr> <tr> <td>NWS</td> <td>Network scanner*1 ROM IC</td> </tr> <tr> <td>DP</td> <td>DP*1 ROM IC</td> </tr> <tr> <td>FINISHER</td> <td>Finisher*1 ROM IC</td> </tr> <tr> <td>CASS2</td> <td>First paper feeder*2 ROM IC</td> </tr> <tr> <td>CASS3</td> <td>Second paper feeder*1 ROM IC</td> </tr> <tr> <td>CASS4</td> <td>Third paper feeder*1 ROM IC</td> </tr> </tbody> </table> <p>*1: Optional. *2: Optional for 16 ppm model. Standard for 20 ppm model.</p> <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	MAIN	Main ROM IC	ENGINE	Engine ROM IC	LANG(St)	Standard language ROM IC	LANG(Op)	Optional language ROM IC	MAIN BOOT	Boot of main ROM IC	PRINTER	Printer board ROM IC	NWS	Network scanner*1 ROM IC	DP	DP*1 ROM IC	FINISHER	Finisher*1 ROM IC	CASS2	First paper feeder*2 ROM IC	CASS3	Second paper feeder*1 ROM IC	CASS4	Third paper feeder*1 ROM IC
Display	Description																										
MAIN	Main ROM IC																										
ENGINE	Engine ROM IC																										
LANG(St)	Standard language ROM IC																										
LANG(Op)	Optional language ROM IC																										
MAIN BOOT	Boot of main ROM IC																										
PRINTER	Printer board ROM IC																										
NWS	Network scanner*1 ROM IC																										
DP	DP*1 ROM IC																										
FINISHER	Finisher*1 ROM IC																										
CASS2	First paper feeder*2 ROM IC																										
CASS3	Second paper feeder*1 ROM IC																										
CASS4	Third paper feeder*1 ROM IC																										
<p>U020</p>	<p>Initializing all data</p> <p>Description Initializes all the backup RAM on the main PCB to return to the original settings.</p> <p>Purpose Run as needed.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. The screen for executing is displayed. 2. Select the EXECUTE using the up/down cursor keys. It is displayed in reverse. 3. Press the start key. All data in the backup RAM is initialized, and the original settings for Japan specifications are set. <p>When initialization is complete, the machine automatically returns to the same status as when the main switch is turned on.</p> <p>Completion To exit this maintenance item without executing initialization, press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p>																										
<p>U021</p>	<p>Initializing memories</p> <p>Description Initializes the setting data other than that for adjustments due to variations between respective machines, i.e., settings for counters, service call history and mode settings. As a result, initializes the backup RAM according to the specifications depending on the destination selected in U252.</p> <p>Purpose Used to return the machine settings to the factory settings.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. The screen for executing is displayed. 2. Select the EXECUTE using the up/down cursor keys. It is displayed in reverse. 3. Press the start key. All data other than that for adjustments due to variations between machines is initialized based on the destination setting. <p>Completion To exit this maintenance item without executing initialization, press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p>																										

Maintenance item No.	Description								
U022	<p>Initializing backup memory</p> <p>Description Initializes only the data set for the optical section or initializes various setting data when installing the optional network scanner board.</p> <p>Purpose To be executed after replacing the scanner unit or installing the network scanner board.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. The screen for executing is displayed. 2. Select the EXECUTE using the up/down cursor keys. It is displayed in reverse. 3. Press the start key. The data for the optical section (U060 to 067, U092 to 099, U403, U990 and U991) is initialized. The setting data of scanner function initial settings are initialized, and the registered transmission and reception are cleared. <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p>								
U026	<p>Evacuation of backup data</p> <p>Description Transfers the backup data of the main PCB to the EEPROM.</p> <p>Purpose Used when replacing the main PCB.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. The screen for executing is displayed. 2. Select the EXECUTE using the up/down cursor keys. It is displayed in reverse. 3. Press the start key to transfer the backup data. The screen displays the result. <p>EXECUTE CHECK SUM: **** CODE : XXXX (See the table below)</p> <table border="1" data-bbox="320 1167 1382 1308"> <thead> <tr> <th>Code</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0000</td> <td>Processing ends correctly.</td> </tr> <tr> <td>0101</td> <td>Verification abnormality occurs.</td> </tr> <tr> <td>0102</td> <td>Verification abnormality occurs at the time of check sum entry.</td> </tr> </tbody> </table> <ol style="list-style-type: none"> 4. Press the stop/clear key. The screen for selecting a maintenance item No. is displayed. <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p>	Code	Description	0000	Processing ends correctly.	0101	Verification abnormality occurs.	0102	Verification abnormality occurs at the time of check sum entry.
Code	Description								
0000	Processing ends correctly.								
0101	Verification abnormality occurs.								
0102	Verification abnormality occurs at the time of check sum entry.								

Maintenance item No.	Description																
<p>U027</p>	<p>Return of backup data</p> <p>Description Transfers the backup data of the EEPROM which was transferred with the U026 to flash memory.</p> <p>Purpose To use after the main PCB replaced.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. The screen for executing is displayed. 2. Select the EXECUTE using the up/down cursor keys. It is displayed in reverse. 3. Press the start key to transfer the backup data. The screen displays the result. <p>EXECUTE CHECK SUM: **** CODE : XXXX (See the table below)</p> <table border="1" data-bbox="304 689 1366 804"> <thead> <tr> <th>Code</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0000</td> <td>Processing ends correctly.</td> </tr> <tr> <td>0203</td> <td>Check sum does not agree when reading out from the EEPROM.</td> </tr> </tbody> </table> <ol style="list-style-type: none"> 4. Disconnect and connect the power plug. <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p>	Code	Description	0000	Processing ends correctly.	0203	Check sum does not agree when reading out from the EEPROM.										
Code	Description																
0000	Processing ends correctly.																
0203	Check sum does not agree when reading out from the EEPROM.																
<p>U030</p>	<p>Checking motor operation</p> <p>Description Drives each motor.</p> <p>Purpose To check the operation of each motor.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. The screen for selecting an item is displayed. 2. Select the motor to be operated using the up/down cursor keys. 3. Press the start key. The operation starts. <table border="1" data-bbox="304 1232 1366 1487"> <thead> <tr> <th>Display</th> <th>Operation</th> </tr> </thead> <tbody> <tr> <td>MAIN</td> <td>Drive motor (DM) operates</td> </tr> <tr> <td>RES</td> <td>Registration motor (RM) operates</td> </tr> <tr> <td>T1</td> <td>Drawer drive motor 1*2 (DDM1) operates</td> </tr> <tr> <td>T2</td> <td>Drawer drive motor 2*1 (DDM2) operates</td> </tr> <tr> <td>T3</td> <td>Drawer drive motor 3*1 (DDM3) operates</td> </tr> <tr> <td>EJE1</td> <td>Eject motor rotates forward</td> </tr> <tr> <td>EJE2</td> <td>Eject motor rotates in reverse</td> </tr> </tbody> </table> <p>*1: Optional. *2: Optional for 16 ppm model. Standard for 20 ppm model.</p> <ol style="list-style-type: none"> 4. To stop operation, press the stop/clear key. <p>Completion Press the stop key after operation stops. The screen for selecting a maintenance item No. is displayed.</p>	Display	Operation	MAIN	Drive motor (DM) operates	RES	Registration motor (RM) operates	T1	Drawer drive motor 1*2 (DDM1) operates	T2	Drawer drive motor 2*1 (DDM2) operates	T3	Drawer drive motor 3*1 (DDM3) operates	EJE1	Eject motor rotates forward	EJE2	Eject motor rotates in reverse
Display	Operation																
MAIN	Drive motor (DM) operates																
RES	Registration motor (RM) operates																
T1	Drawer drive motor 1*2 (DDM1) operates																
T2	Drawer drive motor 2*1 (DDM2) operates																
T3	Drawer drive motor 3*1 (DDM3) operates																
EJE1	Eject motor rotates forward																
EJE2	Eject motor rotates in reverse																



Maintenance item No.	Description																
U031	<p>Checking switches for paper conveying</p> <p>Description Displays the on-off status of each paper detection switch on the paper path.</p> <p>Purpose To check if the switches for paper conveying operate correctly.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. A list of the switches, the on-off status of which can be checked, are displayed. 2. Turn each switch on and off manually to check the status. <p>When the on-status of a switch is detected, that switch is displayed in reverse.</p> <table border="1" data-bbox="320 546 1382 801"> <thead> <tr> <th>Display</th> <th>Switches</th> </tr> </thead> <tbody> <tr> <td>EJE</td> <td>Eject switch (ESW)</td> </tr> <tr> <td>RES</td> <td>Registration switch (RSW)</td> </tr> <tr> <td>PF2</td> <td>Drawer feed switch 1*2 (DFSW1)</td> </tr> <tr> <td>PF3</td> <td>Drawer feed switch 2*1 (DFSW2)</td> </tr> <tr> <td>BRA</td> <td>Feedshift switch (FSSW)</td> </tr> <tr> <td>DUP</td> <td>Duplex paper conveying switch*1 (DUPPCSW)</td> </tr> <tr> <td>JOB</td> <td>Job separator eject switch*1 (JBESW)</td> </tr> </tbody> </table> <p>*1: Optional. *2: Optional for 16 ppm model. Standard for 20 ppm model.</p> <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Switches	EJE	Eject switch (ESW)	RES	Registration switch (RSW)	PF2	Drawer feed switch 1*2 (DFSW1)	PF3	Drawer feed switch 2*1 (DFSW2)	BRA	Feedshift switch (FSSW)	DUP	Duplex paper conveying switch*1 (DUPPCSW)	JOB	Job separator eject switch*1 (JBESW)
Display	Switches																
EJE	Eject switch (ESW)																
RES	Registration switch (RSW)																
PF2	Drawer feed switch 1*2 (DFSW1)																
PF3	Drawer feed switch 2*1 (DFSW2)																
BRA	Feedshift switch (FSSW)																
DUP	Duplex paper conveying switch*1 (DUPPCSW)																
JOB	Job separator eject switch*1 (JBESW)																
U032	<p>Checking clutch operation</p> <p>Description Turns each clutch on.</p> <p>Purpose To check the operation of each clutch.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. The screen for selecting an item is displayed. 2. Select the clutch to be operated using the up/down cursor keys. 3. Press the start key. The clutch turns on for 1 s. <table border="1" data-bbox="320 1205 1382 1397"> <thead> <tr> <th>Display</th> <th>Clutches</th> </tr> </thead> <tbody> <tr> <td>PF1</td> <td>Paper feed clutch (PFCL)</td> </tr> <tr> <td>PFBYP</td> <td>Bypass paper feed solenoid (BYPPFSOL)</td> </tr> <tr> <td>FEED1</td> <td>Drawer paper feed clutch 1*2 (DPFCL1)</td> </tr> <tr> <td>FEED2</td> <td>Drawer paper feed clutch 2*1 (DPFCL2)</td> </tr> <tr> <td>FEED3</td> <td>Drawer paper feed clutch 3*1 (DPFCL3)</td> </tr> </tbody> </table> <p>*1: Optional. *2: Optional for 16 ppm model. Standard for 20 ppm model.</p> <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Clutches	PF1	Paper feed clutch (PFCL)	PFBYP	Bypass paper feed solenoid (BYPPFSOL)	FEED1	Drawer paper feed clutch 1*2 (DPFCL1)	FEED2	Drawer paper feed clutch 2*1 (DPFCL2)	FEED3	Drawer paper feed clutch 3*1 (DPFCL3)				
Display	Clutches																
PF1	Paper feed clutch (PFCL)																
PFBYP	Bypass paper feed solenoid (BYPPFSOL)																
FEED1	Drawer paper feed clutch 1*2 (DPFCL1)																
FEED2	Drawer paper feed clutch 2*1 (DPFCL2)																
FEED3	Drawer paper feed clutch 3*1 (DPFCL3)																

Maintenance item No.	Description																																								
U034	<p>Adjusting the print start timing</p> <p>Adjustment See pages 1-6-10 and 12.</p>																																								
U035	<p>Setting folio size</p> <p>Description Changes the image area for copying onto folio size paper.</p> <p>Purpose To prevent the image at the trailing edge, or right or left side of the paper from not being copied by setting the actual size of the folio paper used.</p> <p>Method Press the start key. The screen for setting is displayed.</p> <p>Setting</p> <ol style="list-style-type: none"> Select the item to be set using the up/down cursor keys. The selected item is displayed in reverse. Change the setting using the left/right cursor keys. <table border="1"> <thead> <tr> <th>Display</th> <th>Setting</th> <th>Setting range</th> <th>Initial setting</th> </tr> </thead> <tbody> <tr> <td>LENGTH DATA</td> <td>Length</td> <td>330 to 356 mm</td> <td>330</td> </tr> <tr> <td>WIDTH DATA</td> <td>Width</td> <td>200 to 220 mm</td> <td>210</td> </tr> </tbody> </table> <ol style="list-style-type: none"> Press the start key. The value is set. <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Setting	Setting range	Initial setting	LENGTH DATA	Length	330 to 356 mm	330	WIDTH DATA	Width	200 to 220 mm	210																												
Display	Setting	Setting range	Initial setting																																						
LENGTH DATA	Length	330 to 356 mm	330																																						
WIDTH DATA	Width	200 to 220 mm	210																																						
U051	<p>Adjusting the amount of slack in the paper</p> <p>Adjustment See page 1-6-14.</p>																																								
U053	<p>Performing fine adjustment of the motor speed</p> <p>Description Performs fine adjustment of the speeds of the motors.</p> <p>Purpose Used to adjust the speed of the respective motors when the magnification is not correct. Also speed adjustment for each paper source.</p> <p>Method Press the start key. The screen for setting is displayed.</p> <p>Setting</p> <ol style="list-style-type: none"> Select the item to be set using the up/down cursor keys. The selected item is displayed in reverse. Change the setting using the left/right cursor keys. <table border="1"> <thead> <tr> <th>Display</th> <th>Description</th> <th>Setting range</th> <th>Initial setting</th> </tr> </thead> <tbody> <tr> <td>MAIN</td> <td>Drive motor speed adjustment</td> <td>-5.0 to +5.0</td> <td>0.1</td> </tr> <tr> <td>POLY</td> <td>Polygon motor speed adjustment</td> <td>-5.0 to +5.0</td> <td>0</td> </tr> <tr> <td>EJE</td> <td>Eject motor speed adjustment</td> <td>-5.0 to +5.0</td> <td>-0.5</td> </tr> <tr> <td>RES</td> <td>Registration motor speed adjustment</td> <td>-5.0 to +5.0</td> <td>-0.1</td> </tr> <tr> <td>BYP</td> <td>Motor speed adjustment (for paper feed from bypass tray)</td> <td>-5.0 to +5.0</td> <td>-0.1</td> </tr> <tr> <td>CAS</td> <td>Drawer paper feed motor speed adjustment (for paper feed from paper feeder)</td> <td>-5.0 to +5.0</td> <td>-0.3</td> </tr> <tr> <td>DUP</td> <td>Duplex paper feed motor speed adjustment (in duplex mode)</td> <td>-5.0 to +5.0</td> <td>-0.3</td> </tr> <tr> <td>EJE2</td> <td>Optional ejection correction value of eject motor (In the case of paper width more than 220 mm)</td> <td>-5.0 to +5.0</td> <td>-1.5</td> </tr> <tr> <td>EJE3</td> <td>Optional ejection correction value of eject motor (In the case of paper width less than or equal to 220 mm)</td> <td>-5.0 to +5.0</td> <td>-1.5</td> </tr> </tbody> </table>	Display	Description	Setting range	Initial setting	MAIN	Drive motor speed adjustment	-5.0 to +5.0	0.1	POLY	Polygon motor speed adjustment	-5.0 to +5.0	0	EJE	Eject motor speed adjustment	-5.0 to +5.0	-0.5	RES	Registration motor speed adjustment	-5.0 to +5.0	-0.1	BYP	Motor speed adjustment (for paper feed from bypass tray)	-5.0 to +5.0	-0.1	CAS	Drawer paper feed motor speed adjustment (for paper feed from paper feeder)	-5.0 to +5.0	-0.3	DUP	Duplex paper feed motor speed adjustment (in duplex mode)	-5.0 to +5.0	-0.3	EJE2	Optional ejection correction value of eject motor (In the case of paper width more than 220 mm)	-5.0 to +5.0	-1.5	EJE3	Optional ejection correction value of eject motor (In the case of paper width less than or equal to 220 mm)	-5.0 to +5.0	-1.5
Display	Description	Setting range	Initial setting																																						
MAIN	Drive motor speed adjustment	-5.0 to +5.0	0.1																																						
POLY	Polygon motor speed adjustment	-5.0 to +5.0	0																																						
EJE	Eject motor speed adjustment	-5.0 to +5.0	-0.5																																						
RES	Registration motor speed adjustment	-5.0 to +5.0	-0.1																																						
BYP	Motor speed adjustment (for paper feed from bypass tray)	-5.0 to +5.0	-0.1																																						
CAS	Drawer paper feed motor speed adjustment (for paper feed from paper feeder)	-5.0 to +5.0	-0.3																																						
DUP	Duplex paper feed motor speed adjustment (in duplex mode)	-5.0 to +5.0	-0.3																																						
EJE2	Optional ejection correction value of eject motor (In the case of paper width more than 220 mm)	-5.0 to +5.0	-1.5																																						
EJE3	Optional ejection correction value of eject motor (In the case of paper width less than or equal to 220 mm)	-5.0 to +5.0	-1.5																																						

Maintenance item No.	Description
U053	<p>MAIN MOTOR Increasing the setting makes the image longer in the auxiliary scanning direction, and decreasing it makes the image shorter in the auxiliary scanning direction.</p> <p>POLYGON MOTOR Increasing the setting makes the image longer in the main scanning direction and shorter in the auxiliary scanning direction; decreasing the setting makes the image shorter in the main scanning direction and longer in the auxiliary scanning direction.</p> <p>3. Press the start key. The value is set.</p> <p>Interrupt copy mode While this maintenance item is being performed, a VTC pattern shown below is output in interrupt copy mode.</p> <ol style="list-style-type: none"> 1. Press the interrupt key. The machine enters the interrupt copy mode. 2. Press the start key. A VTC pattern is output. <p>To return to the screen for setting, press the interrupt key.</p> <p>Correct values for an A3/11" × 17" output are: A = 300 ± 1.5 mm B = 270 ± 1.35 mm</p> <div data-bbox="740 725 975 1021" data-label="Diagram"> </div> <p>Figure 1-4-1</p> <p>Adjustment</p> <ol style="list-style-type: none"> 1. Output an A3/11" × 17" VTC pattern in interrupt copy mode. 2. Measure A and B on the VTC pattern (Figure 1-4-1), and perform the following adjustments if they are different from the correct sizes: <ul style="list-style-type: none"> A: Drive motor speed adjustment B: Polygon motor speed adjustment <p>Completion Press the stop/clear key at the screen for setting. The screen for selecting a maintenance item No. is displayed.</p>

Maintenance item No.	Description						
<p>U060</p>	<p>Adjusting the scanner input properties</p> <p>Description Adjusts the image scanning density in text, text and photo, or photo mode.</p> <p>Purpose Used when the entire image appears too dark or light.</p> <p>Method Press the start key. The screen for setting is displayed.</p> <p>Setting</p> <ol style="list-style-type: none"> Change the setting using the left/right cursor keys. <table border="1" data-bbox="304 551 1366 636"> <thead> <tr> <th>Description</th> <th>Setting range</th> <th>Initial setting</th> </tr> </thead> <tbody> <tr> <td>Image scannig density</td> <td>1 to +23</td> <td>12</td> </tr> </tbody> </table> <p>Increasing the setting makes the density lower, and decreasing it makes the density higher.</p> <ol style="list-style-type: none"> Press the start key. The value is set. <p>Interrupt copy mode While this maintenance item is being performed, copying from an original can be made in interrupt copy mode.</p> <ol style="list-style-type: none"> Press the interrupt key. The machine enters the interrupt copy mode. Set the original and press the strat key. To return to the screen for setting, press the interrupt key. <p>Completion Press the stop/clear key at the screen for setting. The screen for selecting a maintenance item No. is displayed.</p>	Description	Setting range	Initial setting	Image scannig density	1 to +23	12
Description	Setting range	Initial setting					
Image scannig density	1 to +23	12					
<p>U061</p>	<p>Turning the exposure lamp on</p> <p>Description Turns the exposure lamp on.</p> <p>Purpose To check the exposure lamp.</p> <p>Method</p> <ol style="list-style-type: none"> Press the start key. The screen for executing is displayed. Press the start key. The exposure lamp lights. To turn the exposure lamp off, press the stop/clear key. <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p>						



Maintenance item No.	Description								
<p>U063</p>	<p>Adjusting the shading position</p> <p>Description Changes the shading position.</p> <p>Purpose Used when white lines continue to appear longitudinally on the image after the shading plate is cleaned. This is due to flaws or stains inside the shading plate. To prevent this problem, the shading position should be changed so that shading is possible without being affected by the flaws or stains.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. The screen for setting is displayed. 2. Change the setting using the left/right cursor keys. <table border="1" data-bbox="320 573 1382 658"> <thead> <tr> <th>Description</th> <th>Setting range</th> <th>Initial setting</th> <th>Change in value per step</th> </tr> </thead> <tbody> <tr> <td>Shading position</td> <td>-8 to +8</td> <td>0</td> <td>0.17 mm</td> </tr> </tbody> </table> <p>Increasing the setting moves the shading position toward the machine right, and decreasing it moves the position toward the machine left.</p> <ol style="list-style-type: none"> 3. Press the start key. The value is set. <p>Interrupt copy mode While this maintenance item is being performed, copying from an original can be made in interrupt copy mode.</p> <ol style="list-style-type: none"> 1. Press the interrupt key. The machine enters the interrupt copy mode. 2. Set the original and press the strat key. <p>To return to the screen for setting, press the interrupt key.</p> <p>Completion Press the stop/clear key at the screen for setting. The screen for selecting a maintenance item No. is displayed.</p>	Description	Setting range	Initial setting	Change in value per step	Shading position	-8 to +8	0	0.17 mm
Description	Setting range	Initial setting	Change in value per step						
Shading position	-8 to +8	0	0.17 mm						
<p>U065</p>	<p>Adjusting the scanner magnification</p> <p>Adjustment See pages 1-6-27 and 28.</p>								
<p>U066</p>	<p>Adjusting the leading edge registration for scanning an original on the contact glass</p> <p>Adjustment See page 1-6-29.</p>								
<p>U067</p>	<p>Adjusting the center line for scanning an original on the contact glass</p> <p>Adjustment See page 1-6-30.</p>								
<p>U068</p>	<p>Adjusting the scanning position for originals from the DP</p> <p>Description Adjusts the position for scanning originals from the DP.</p> <p>Purpose Used when there is a regular error between the leading edges of the original and the copy image when the DP is used.</p> <p>Method Press the start key. The screen for setting is displayed.</p> <p>Setting</p> <ol style="list-style-type: none"> 1. Change the setting using the left/right cursor keys. <table border="1" data-bbox="320 1615 1382 1700"> <thead> <tr> <th>Description</th> <th>Setting range</th> <th>Initial setting</th> <th>Change in value per step</th> </tr> </thead> <tbody> <tr> <td>Scanning position</td> <td>-17 to +17</td> <td>0</td> <td>0.17 mm</td> </tr> </tbody> </table> <p>Increasing the setting moves the image backward, and decreasing it moves the image forward.</p> <ol style="list-style-type: none"> 2. Press the start key. The value is set. <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p>	Description	Setting range	Initial setting	Change in value per step	Scanning position	-17 to +17	0	0.17 mm
Description	Setting range	Initial setting	Change in value per step						
Scanning position	-17 to +17	0	0.17 mm						



Maintenance item No.	Description															
<p>U070</p>	<p>Adjusting the DP magnification</p> <p>Description Adjusts the DP original scanning speed.</p> <p>Purpose To be executed if the correct magnification is not obtained in the auxiliary scanning direction when the optional DP is used.</p> <p>Caution Before making this adjustment, ensure that the following adjustments have been made in maintenance mode.</p> <p>U053 → U065 → U070</p> <p>Method Press the start key. The screen for setting is displayed.</p> <p>Setting</p> <ol style="list-style-type: none"> 1. Select the item to be set using the up/down cursor keys. The selected item is displayed in reverse. 2. Change the setting using the left/right cursor keys. <table border="1" data-bbox="304 734 1366 927"> <thead> <tr> <th>Display</th> <th>Description</th> <th>Setting range</th> <th>Initial setting</th> <th>Change in value per step</th> </tr> </thead> <tbody> <tr> <td>CONVEY SPEED1</td> <td>Original conveying motor speed (simplex original)</td> <td>-25 to +25</td> <td>0</td> <td>0.1%</td> </tr> <tr> <td>CONVEY SPEED2</td> <td>Original conveying motor speed (duplex original)</td> <td>-25 to +25</td> <td>0</td> <td>0.1%</td> </tr> </tbody> </table> <p>Increasing the setting makes the image longer, and decreasing it makes the image shorter.</p> <ol style="list-style-type: none"> 3. Press the start key. The value is set. <p>Interrupt copy mode While this maintenance item is being performed, copying from an original can be made in interrupt copy mode.</p> <ol style="list-style-type: none"> 1. Press the interrupt key. The machine enters the interrupt copy mode. 2. Set the original and press the strat key. To return to the screen for setting, press the interrupt key. <p>Completion Press the stop/clear key at the screen for setting. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Setting range	Initial setting	Change in value per step	CONVEY SPEED1	Original conveying motor speed (simplex original)	-25 to +25	0	0.1%	CONVEY SPEED2	Original conveying motor speed (duplex original)	-25 to +25	0	0.1%
Display	Description	Setting range	Initial setting	Change in value per step												
CONVEY SPEED1	Original conveying motor speed (simplex original)	-25 to +25	0	0.1%												
CONVEY SPEED2	Original conveying motor speed (duplex original)	-25 to +25	0	0.1%												



Maintenance item No.	Description																									
U071	<p>Adjusting the DP scanning timing</p> <p>Description Adjusts the DP original scanning timing.</p> <p>Purpose To be executed if there is a regular error between the leading or trailing edges of the original and the copy image when the optional DP is used.</p> <p>Caution Before making this adjustment, ensure that the following adjustments have been made in maintenance mode.</p> <p>U034 → U066 → U071</p> <p>Method Press the start key. The screen for setting an item is displayed.</p> <p>Setting</p> <ol style="list-style-type: none"> 1. Select the item to be set using the up/down cursor keys. The selected item is displayed in reverse. 2. Change the setting using the left/right cursor keys. <table border="1"> <thead> <tr> <th>Display</th> <th>Description</th> <th>Setting range</th> <th>Initial setting</th> <th>Change in value per step</th> </tr> </thead> <tbody> <tr> <td>LEAD1</td> <td>DP leading edge registration (simplex original)</td> <td>-32 to +22</td> <td>0</td> <td>0.2 mm</td> </tr> <tr> <td>TRAIL1</td> <td>DP trailing edge registration (simplex original)</td> <td>-22 to +32</td> <td>0</td> <td>0.2 mm</td> </tr> <tr> <td>LEAD2</td> <td>DP leading edge registration (duplex original)</td> <td>-32 to +22</td> <td>0</td> <td>0.2mm</td> </tr> <tr> <td>TRAIL2</td> <td>DP trailing edge registration (duplex original)</td> <td>-22 to +32</td> <td>0</td> <td>0.2mm</td> </tr> </tbody> </table> <p>Increasing the setting moves the copy image backward, and decreasing it moves the copy image forward.</p> <ol style="list-style-type: none"> 3. Press the start key. The value is set. <p>Interrupt copy mode While this maintenance item is being performed, copying from an original can be made in interrupt copy mode.</p> <ol style="list-style-type: none"> 1. Press the interrupt key. The machine enters the interrupt copy mode. 2. Set the original and press the strat key. To return to the screen for setting, press the interrupt key. <p>Adjustment</p> <ol style="list-style-type: none"> 1. In interrupt copy mode, make a copy using the DP. 2. Check the copy image and adjust the registration as follows. For copy example 1, decrease the setting of LEAD1 or LEAD2. For copy example 2, increase the setting of LEAD1 or LEAD2. <div style="text-align: center;">  <p>Original Copy example 1 Copy example 2</p> </div> <p>Figure 1-4-2</p> <p>Completion Press the stop/clear key at the screen for setting. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Setting range	Initial setting	Change in value per step	LEAD1	DP leading edge registration (simplex original)	-32 to +22	0	0.2 mm	TRAIL1	DP trailing edge registration (simplex original)	-22 to +32	0	0.2 mm	LEAD2	DP leading edge registration (duplex original)	-32 to +22	0	0.2mm	TRAIL2	DP trailing edge registration (duplex original)	-22 to +32	0	0.2mm
Display	Description	Setting range	Initial setting	Change in value per step																						
LEAD1	DP leading edge registration (simplex original)	-32 to +22	0	0.2 mm																						
TRAIL1	DP trailing edge registration (simplex original)	-22 to +32	0	0.2 mm																						
LEAD2	DP leading edge registration (duplex original)	-32 to +22	0	0.2mm																						
TRAIL2	DP trailing edge registration (duplex original)	-22 to +32	0	0.2mm																						

Maintenance item No.	Description																				
<p>U072</p> <p>Adjusting the DP center line</p> <p>Description Adjusts the scanning start position for the DP original.</p> <p>Purpose To be executed if there is a regular error between the centers of the original and the copy image when the optional DP is used.</p> <p>Caution Before making this adjustment, ensure that the following adjustments have been made in maintenance mode. <div style="border: 1px solid black; padding: 2px; display: inline-block; margin-right: 5px;">U034</div> → <div style="border: 1px solid black; padding: 2px; display: inline-block; margin-right: 5px;">U067</div> → <div style="border: 1px solid black; padding: 2px; display: inline-block;">U072</div> </p> <p>Method Press the start key. The screen for setting is displayed.</p> <p>Setting</p> <ol style="list-style-type: none"> Select the item to be set using the up/down cursor keys. The selected item is displayed in reverse. Change the setting using the left/right cursor keys. <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th>Display</th> <th>Description</th> <th>Setting range</th> <th>Initial setting</th> <th>Change in value per step</th> </tr> </thead> <tbody> <tr> <td>1 sided</td> <td>Simplex copy mode</td> <td>-39 to +39</td> <td>0</td> <td>0.1 mm</td> </tr> <tr> <td>2 sided front</td> <td>Front face in duplex copy mode</td> <td>-39 to +39</td> <td>0</td> <td>0.1 mm</td> </tr> <tr> <td>2 sided back</td> <td>Reverse face in duplex copy mode</td> <td>-39 to +39</td> <td>0</td> <td>0.1 mm</td> </tr> </tbody> </table> <p style="text-align: center;">Increasing the setting moves the image to the right, and decreasing it moves the image to the left.</p> <ol style="list-style-type: none"> Press the start key. The value is set. <p>Interrupt copy mode While this maintenance item is being performed, copying from an original can be made in interrupt copy mode.</p> <ol style="list-style-type: none"> Press the interrupt key. The machine enters the interrupt copy mode. Set the original and press the strat key. To return to the screen for setting, press the interrupt key. <p>Adjustment</p> <ol style="list-style-type: none"> In interrupt copy mode, make a copy using the DP. Check the copy image and adjust the center line as follows. For copy example 1, increase the setting. For copy example 2, decrease the setting. <div style="text-align: center; margin: 10px 0;"> <p>Reference</p> <p style="display: flex; justify-content: space-around; width: 100%;"> Original Copy example 1 Copy example 2 </p> </div> <p>Figure 1-4-3</p> <p>Completion Press the stop/clear key at the screen for setting. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Setting range	Initial setting	Change in value per step	1 sided	Simplex copy mode	-39 to +39	0	0.1 mm	2 sided front	Front face in duplex copy mode	-39 to +39	0	0.1 mm	2 sided back	Reverse face in duplex copy mode	-39 to +39	0	0.1 mm	
Display	Description	Setting range	Initial setting	Change in value per step																	
1 sided	Simplex copy mode	-39 to +39	0	0.1 mm																	
2 sided front	Front face in duplex copy mode	-39 to +39	0	0.1 mm																	
2 sided back	Reverse face in duplex copy mode	-39 to +39	0	0.1 mm																	









Maintenance item No.	Description																																												
U073	<p>Checking scanner operation</p> <p>Description Simulates the scanner operation under arbitrary conditions.</p> <p>Purpose To check scanner operation.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. The screen for selecting an item is displayed. 2. Select the item to be changed using the up/down cursor keys. The selected item is displayed in reverse. 3. Change the setting using the left/right cursor keys. <table border="1" data-bbox="320 546 1382 685"> <thead> <tr> <th>Display</th> <th>Operating conditions</th> <th>Setting range</th> </tr> </thead> <tbody> <tr> <td>ZOOM</td> <td>Magnification</td> <td>100 to 400%</td> </tr> <tr> <td>SIZE</td> <td>Original size</td> <td>See below.</td> </tr> <tr> <td>LAMP</td> <td>On and off of the exposure lamp</td> <td>0 (off) or 1 (on)</td> </tr> </tbody> </table> <p>Original sizes for each setting in SIZE</p> <table border="1" data-bbox="320 725 1382 981"> <thead> <tr> <th>Setting</th> <th>Paper size</th> <th>Setting</th> <th>Paper size</th> </tr> </thead> <tbody> <tr> <td>8</td> <td>A4</td> <td>42</td> <td>A5R</td> </tr> <tr> <td>9</td> <td>B5</td> <td>47</td> <td>Folio</td> </tr> <tr> <td>24</td> <td>11" × 8¹/₂"</td> <td>52</td> <td>11" × 17"</td> </tr> <tr> <td>36</td> <td>A3</td> <td>53</td> <td>11" × 15"</td> </tr> <tr> <td>39</td> <td>B4</td> <td>55</td> <td>8¹/₂" × 14"</td> </tr> <tr> <td>40</td> <td>A4R</td> <td>56</td> <td>8¹/₂" × 11"</td> </tr> <tr> <td>41</td> <td>B5R</td> <td>58</td> <td>5¹/₂" × 8¹/₂"</td> </tr> </tbody> </table> <ol style="list-style-type: none"> 4. Press the start key. Scanning starts under the selected conditions. 5. To stop operation, press the stop/clear key. <p>Completion Press the stop/clear key when scanning stops. The screen for selecting a maintenance item No. is displayed.</p>	Display	Operating conditions	Setting range	ZOOM	Magnification	100 to 400%	SIZE	Original size	See below.	LAMP	On and off of the exposure lamp	0 (off) or 1 (on)	Setting	Paper size	Setting	Paper size	8	A4	42	A5R	9	B5	47	Folio	24	11" × 8 ¹ / ₂ "	52	11" × 17"	36	A3	53	11" × 15"	39	B4	55	8 ¹ / ₂ " × 14"	40	A4R	56	8 ¹ / ₂ " × 11"	41	B5R	58	5 ¹ / ₂ " × 8 ¹ / ₂ "
Display	Operating conditions	Setting range																																											
ZOOM	Magnification	100 to 400%																																											
SIZE	Original size	See below.																																											
LAMP	On and off of the exposure lamp	0 (off) or 1 (on)																																											
Setting	Paper size	Setting	Paper size																																										
8	A4	42	A5R																																										
9	B5	47	Folio																																										
24	11" × 8 ¹ / ₂ "	52	11" × 17"																																										
36	A3	53	11" × 15"																																										
39	B4	55	8 ¹ / ₂ " × 14"																																										
40	A4R	56	8 ¹ / ₂ " × 11"																																										
41	B5R	58	5 ¹ / ₂ " × 8 ¹ / ₂ "																																										
U074	<p>Adjusting the DP input light luminosity</p> <p>Description Adjusts the luminosity of the exposure lamp for scanning originals from the DP.</p> <p>Purpose Used if the exposure amount differs significantly between when scanning an original on the contact glass and when scanning an original from the DP.</p> <p>Method Press the start key.</p> <p>Setting</p> <ol style="list-style-type: none"> 1. Change the setting using the left/right cursor keys. <table border="1" data-bbox="320 1447 1382 1527"> <thead> <tr> <th>Description</th> <th>Setting range</th> <th>Initial setting</th> </tr> </thead> <tbody> <tr> <td>DP input light luminosity</td> <td>0 to 8</td> <td>0</td> </tr> </tbody> </table> <p>Increasing the setting makes the luminosity higher, and decreasing it makes the luminosity lower.</p> <ol style="list-style-type: none"> 2. Press the start key. The value is set. <p>Interrupt copy mode While this maintenance item is being performed, copying from an original can be made in interrupt copy mode.</p> <ol style="list-style-type: none"> 1. Press the interrupt key. The machine enters the interrupt copy mode. 2. Set the original and press the strat key. To return to the screen for setting, press the interrupt key. <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p>	Description	Setting range	Initial setting	DP input light luminosity	0 to 8	0																																						
Description	Setting range	Initial setting																																											
DP input light luminosity	0 to 8	0																																											

Maintenance item No.	Description								
<p>U076</p>	<p>Executing DP automatic adjustment</p> <p>Description Uses a specified original and automatically adjusts the following items in the DP scanning section.</p> <ul style="list-style-type: none"> • Adjusting the DP magnification (U070) • Adjusting the DP scanning timing (U071) • Adjusting the DP center line (U072) <p>When you run this maintenance mode, the preset values of U070, U071 and U072 will also be updated.</p> <p>Purpose To perform automatic adjustment of various items in the DP scanning section.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Set a specified original (part number: 2AC68241) in the DP. 2. Press the start key. The screen for executing is displayed. 3. Press the start key. Auto adjustment starts. When adjustment is complete, each adjusted value is displayed. <table border="1" data-bbox="304 689 1366 831"> <thead> <tr> <th data-bbox="304 689 683 734">Display</th> <th data-bbox="683 689 1366 734">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="304 734 683 768">CONVEY SPEED</td> <td data-bbox="683 734 1366 768">DP magnification in the auxiliary scanning direction</td> </tr> <tr> <td data-bbox="304 768 683 801">LEAD EDGE ADJ</td> <td data-bbox="683 768 1366 801">DP leading edge registration</td> </tr> <tr> <td data-bbox="304 801 683 831">DP CENTER</td> <td data-bbox="683 801 1366 831">DP original center line</td> </tr> </tbody> </table> <p>If a problem occurs during auto adjustment, DATA: XX (XX is replaced by an error code) is displayed and operation stops. Should this happen, determine the details of the problem and either repeat the procedure from the beginning, or adjust the remaining items manually by running the corresponding maintenance items.</p> <p>Completion Press the stop/clear key after auto adjustment is complete. The screen for selecting a maintenance item is displayed. If the stop/clear key is pressed during auto adjustment, adjustment stops and no settings are changed.</p>	Display	Description	CONVEY SPEED	DP magnification in the auxiliary scanning direction	LEAD EDGE ADJ	DP leading edge registration	DP CENTER	DP original center line
Display	Description								
CONVEY SPEED	DP magnification in the auxiliary scanning direction								
LEAD EDGE ADJ	DP leading edge registration								
DP CENTER	DP original center line								



Maintenance item No.	Description												
U087	<p>Turning the DP scanning position adjust mode on/off</p> <p>Description Turns on or off the DP scanning position adjust mode, in which the DP original scanning position is adjusted automatically by determining the presence or absence of dust on the slit glass. Also changes the reference data for identifying dust.</p> <p>Reference In the DP original scanning position adjust mode, the presence or absence of dust is determined by comparing the scan data of the original trailing edge and that taken after the original is conveyed past the DP original scanning position. If dust is identified, the DP original scanning position is adjusted for the following originals.</p> <p>Purpose Used to prevent appearance of black lines due to dust adhering in the original scanning position on the slit glass when the DP is used.</p> <p>Setting</p> <ol style="list-style-type: none"> 1. Press the start key. The screen for selecting an item is displayed. 2. Select ON or OFF using the up/down cursor keys. The selected item is displayed in reverse. <table border="1" data-bbox="320 728 1382 840"> <thead> <tr> <th>Display</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>ON</td> <td>DP scanning position adjust mode on</td> </tr> <tr> <td>OFF</td> <td>DP scanning position adjust mode off</td> </tr> </tbody> </table> <p>Initial setting: ON</p> <p>Available only when the mode is turned on.</p> <ol style="list-style-type: none"> 3. Change the setting using the left/right cursor keys. <table border="1" data-bbox="320 967 1382 1052"> <thead> <tr> <th>Description</th> <th>Setting range</th> <th>Initial setting</th> </tr> </thead> <tbody> <tr> <td>Minimum density to be regarded as dust</td> <td>10 to 95</td> <td>35</td> </tr> </tbody> </table> <p>Example The figure indicates the density in 256 levels of gray (0: white, 255: black). When the setting is 35, data of the level of 35 or higher is regarded as dust and data of lower level is regarded as the background (scan data taken when there is no original).</p> <ol style="list-style-type: none"> 4. Press the start key. The value is set. <p>Completion Press the stop/clear key. The indication for selecting a maintenance item No. appears.</p>	Display	Description	ON	DP scanning position adjust mode on	OFF	DP scanning position adjust mode off	Description	Setting range	Initial setting	Minimum density to be regarded as dust	10 to 95	35
Display	Description												
ON	DP scanning position adjust mode on												
OFF	DP scanning position adjust mode off												
Description	Setting range	Initial setting											
Minimum density to be regarded as dust	10 to 95	35											

Maintenance item No.	Description																								
<p>U089</p>	<p>Outputting a MIP-PG pattern</p> <p>Description Selects and outputs the MIP-PG pattern created in the machine.</p> <p>Purpose When performing respective image printing adjustments, used to check the machine status apart from that of the scanner with a non-scanned output MIP-PG pattern.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. The screen for selecting an item is displayed. 2. Select the MIP-PG pattern to be output using the up/down cursor keys. <table border="1" data-bbox="424 566 1273 1411"> <thead> <tr> <th>Display</th> <th>PG pattern to be output</th> <th>Purpose</th> </tr> </thead> <tbody> <tr> <td>GRAYSCALE</td> <td></td> <td>To check the laser scanner unit engine output characteristics.</td> </tr> <tr> <td>MONO-LEVEL</td> <td></td> <td>To check the drum quality.</td> </tr> <tr> <td>256-LEVEL</td> <td></td> <td>To check resolution reproducibility in printing.</td> </tr> <tr> <td>1 DOT-LEVEL</td> <td></td> <td>To check fine line reproducibility. To adjust the position of the laser scanner unit (lateral squareness)</td> </tr> </tbody> </table> <ol style="list-style-type: none"> 3. To change the output conditions of MONO-LEVEL and 1dot-LEVEL, use the left/right cursor keys to change the preset values and press the start key to register the setting. <table border="1" data-bbox="301 1503 1366 1610"> <thead> <tr> <th>Display</th> <th>Setting range</th> <th>Initial setting</th> </tr> </thead> <tbody> <tr> <td>Output density of MONO-LEVEL</td> <td>0 or 35</td> <td>0</td> </tr> <tr> <td>1dot-LEVEL</td> <td>0 to 21</td> <td>0</td> </tr> </tbody> </table> <ol style="list-style-type: none"> 4. Press the interrupt key. The copy mode screen is displayed. 5. Press the start key. A MIP-PG pattern is output. <p>Completion Press the stop/clear key at the screen for selecting an item. The screen for maintenance item No. is displayed.</p>	Display	PG pattern to be output	Purpose	GRAYSCALE		To check the laser scanner unit engine output characteristics.	MONO-LEVEL		To check the drum quality.	256-LEVEL		To check resolution reproducibility in printing.	1 DOT-LEVEL		To check fine line reproducibility. To adjust the position of the laser scanner unit (lateral squareness)	Display	Setting range	Initial setting	Output density of MONO-LEVEL	0 or 35	0	1dot-LEVEL	0 to 21	0
Display	PG pattern to be output	Purpose																							
GRAYSCALE		To check the laser scanner unit engine output characteristics.																							
MONO-LEVEL		To check the drum quality.																							
256-LEVEL		To check resolution reproducibility in printing.																							
1 DOT-LEVEL		To check fine line reproducibility. To adjust the position of the laser scanner unit (lateral squareness)																							
Display	Setting range	Initial setting																							
Output density of MONO-LEVEL	0 or 35	0																							
1dot-LEVEL	0 to 21	0																							



Maintenance item No.	Description										
U092	<p>Adjusting the scanner automatically</p> <p>Description Makes auto scanner adjustments in the order below using the specified original.</p> <ul style="list-style-type: none"> • Adjusting the scanner center line (U067) • Adjusting the scanner leading edge registration (U066) • Adjusting scanner magnification in the auxiliary direction (U065) <p>When this maintenance item is performed, the settings in U065, U066 and U067 are also changed.</p> <p>Purpose Used to make respective auto adjustments for the scanner.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Place the specified original (P/N: 2A068020) on the contact glass. 2. Press the start key. The screen for executing is displayed. 3. Press the start key. Auto adjustment starts. When adjustment is complete, each adjusted value is displayed. <table border="1" data-bbox="320 689 1382 860"> <thead> <tr> <th data-bbox="320 689 699 734">Display</th> <th data-bbox="699 689 1382 734">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="320 734 699 768">SCN CENTER</td> <td data-bbox="699 734 1382 768">Scanner center line</td> </tr> <tr> <td data-bbox="320 768 699 801">SCN TIMING</td> <td data-bbox="699 768 1382 801">Scanner leading registration</td> </tr> <tr> <td data-bbox="320 801 699 835">SUB SCAN</td> <td data-bbox="699 801 1382 835">Scanner magnification in the auxiliary scanning direction</td> </tr> <tr> <td data-bbox="320 835 699 860">MAIN SCAN</td> <td data-bbox="699 835 1382 860">Scanner magnification in the main scanning direction</td> </tr> </tbody> </table> <p>If a problem occurs during auto adjustment, DATA: XX (XX is replaced by an error code) is displayed and operation stops. Should this happen, determine the details of the problem and either repeat the procedure from the beginning, or adjust the remaining items manually by running the corresponding maintenance items.</p> <p>Completion Press the stop/clear key after auto adjustment is complete. The screen for selecting a maintenance item No. is displayed. If the stop/clear key is pressed during auto adjustment, adjustment stops and no settings are changed.</p>	Display	Description	SCN CENTER	Scanner center line	SCN TIMING	Scanner leading registration	SUB SCAN	Scanner magnification in the auxiliary scanning direction	MAIN SCAN	Scanner magnification in the main scanning direction
Display	Description										
SCN CENTER	Scanner center line										
SCN TIMING	Scanner leading registration										
SUB SCAN	Scanner magnification in the auxiliary scanning direction										
MAIN SCAN	Scanner magnification in the main scanning direction										

Maintenance item No.	Description																																				
U093	<p>Setting the exposure density gradient</p> <p>Description Changes the exposure density gradient in manual density mode, depending on respective image modes (text, text and photo, photo, text in fax mode, photo in fax mode).</p> <p>Purpose To set how the image density is altered by a change of one step in the manual density adjustment. Also used to make copy image darker or lighter.</p> <p>Start</p> <ol style="list-style-type: none"> 1. Press the start key. The screen for selecting an item is displayed. 2. Select the image mode to be adjusted using the up/down cursor keys and press the start key. The screen for the selected item is displayed. <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="text-align: left;">Display</th> <th style="text-align: left;">Description</th> </tr> </thead> <tbody> <tr> <td>MIXED</td> <td>Density in text and photo mode</td> </tr> <tr> <td>TEXT</td> <td>Density in text mode</td> </tr> <tr> <td>PHOTO</td> <td>Density in photo mode</td> </tr> <tr> <td>FAX TEXT</td> <td>Density in the text in fax mode</td> </tr> <tr> <td>FAX PHOTO</td> <td>Density in the photo in fax mode</td> </tr> </tbody> </table> <p>Setting: Density in text and photo mode</p> <ol style="list-style-type: none"> 1. Select the item to be adjusted using the up/down cursor keys. The selected item is displayed in reverse. 2. Adjust the setting using the left/right cursor keys. <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="text-align: left;">Display</th> <th style="text-align: left;">Description</th> <th style="text-align: left;">Setting range</th> <th style="text-align: left;">Initial setting</th> </tr> </thead> <tbody> <tr> <td>MIXED DARKER</td> <td>Change in density when manual density is set dark</td> <td>0 to 3</td> <td>0</td> </tr> <tr> <td>MIXED LIGHTER</td> <td>Change in density when manual density is set light</td> <td>0 to 3</td> <td>0</td> </tr> </tbody> </table> <p>Increasing the setting makes the change in density larger, and decreasing it makes the change smaller.</p> <div style="text-align: center;"> </div> <p>Figure 1-4-4 Exposure density gradient</p> <ol style="list-style-type: none"> 3. Press the start key. The value is set. 4. To return to the screen for selecting an item, press the stop/clear key. <p>Setting: Density in text mode</p> <ol style="list-style-type: none"> 1. Select the item to be adjusted using the up/down cursor keys. The selected item is displayed in reverse. 2. Adjust the setting using the left/right cursor keys. <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="text-align: left;">Display</th> <th style="text-align: left;">Description</th> <th style="text-align: left;">Setting range</th> <th style="text-align: left;">Initial setting</th> </tr> </thead> <tbody> <tr> <td>TEXT DARKER</td> <td>Change in density when manual density is set dark</td> <td>0 to 3</td> <td>0</td> </tr> <tr> <td>TEXT LIGHTER</td> <td>Change in density when manual density is set light</td> <td>0 to 3</td> <td>0</td> </tr> </tbody> </table> <p>Increasing the setting makes the change in density larger, and decreasing it makes the change smaller.</p> <ol style="list-style-type: none"> 3. Press the start key. The value is set. 4. To return to the screen for selecting an item, press the stop/clear key. 	Display	Description	MIXED	Density in text and photo mode	TEXT	Density in text mode	PHOTO	Density in photo mode	FAX TEXT	Density in the text in fax mode	FAX PHOTO	Density in the photo in fax mode	Display	Description	Setting range	Initial setting	MIXED DARKER	Change in density when manual density is set dark	0 to 3	0	MIXED LIGHTER	Change in density when manual density is set light	0 to 3	0	Display	Description	Setting range	Initial setting	TEXT DARKER	Change in density when manual density is set dark	0 to 3	0	TEXT LIGHTER	Change in density when manual density is set light	0 to 3	0
Display	Description																																				
MIXED	Density in text and photo mode																																				
TEXT	Density in text mode																																				
PHOTO	Density in photo mode																																				
FAX TEXT	Density in the text in fax mode																																				
FAX PHOTO	Density in the photo in fax mode																																				
Display	Description	Setting range	Initial setting																																		
MIXED DARKER	Change in density when manual density is set dark	0 to 3	0																																		
MIXED LIGHTER	Change in density when manual density is set light	0 to 3	0																																		
Display	Description	Setting range	Initial setting																																		
TEXT DARKER	Change in density when manual density is set dark	0 to 3	0																																		
TEXT LIGHTER	Change in density when manual density is set light	0 to 3	0																																		



Maintenance item No.	Description																																				
U093	<p>Setting: Density in photo mode</p> <ol style="list-style-type: none"> 1. Select the item to be adjusted using the up/down cursor keys. The selected item is displayed in reverse. 2. Adjust the setting using the left/right cursor keys. <table border="1" data-bbox="320 349 1382 517"> <thead> <tr> <th>Display</th> <th>Description</th> <th>Setting range</th> <th>Initial setting</th> </tr> </thead> <tbody> <tr> <td>PHOTO DARKER</td> <td>Change in density when manual density is set dark</td> <td>0 to 3</td> <td>0</td> </tr> <tr> <td>PHOTO LIGHTER</td> <td>Change in density when manual density is set light</td> <td>0 to 3</td> <td>0</td> </tr> </tbody> </table> <p>Increasing the setting makes the change in density larger, and decreasing it makes the change smaller.</p> <ol style="list-style-type: none"> 3. Press the start key. The value is set. 4. To return to the screen for selecting an item, press the stop/clear key. <p>Setting: Density in the text in fax mode</p> <ol style="list-style-type: none"> 1. Select the item to be adjusted using the up/down cursor keys. The selected item is displayed in reverse. 2. Adjust the setting using the left/right cursor keys. <table border="1" data-bbox="320 707 1382 875"> <thead> <tr> <th>Display</th> <th>Description</th> <th>Setting range</th> <th>Initial setting</th> </tr> </thead> <tbody> <tr> <td>FAX TEXT DARKER</td> <td>Change in density when manual density is set dark</td> <td>0 to 4</td> <td>2</td> </tr> <tr> <td>FAX TEXT LIGHTER</td> <td>Change in density when manual density is set light</td> <td>0 to 9</td> <td>2</td> </tr> </tbody> </table> <p>Increasing the setting makes the change in density larger, and decreasing it makes the change smaller.</p> <ol style="list-style-type: none"> 3. Press the start key. The value is set. 4. To return to the screen for selecting an item, press the stop/clear key. <p>Setting: Density in the photo in fax mode</p> <ol style="list-style-type: none"> 1. Select the item to be adjusted using the up/down cursor keys. The selected item is displayed in reverse. 2. Adjust the setting using the left/right cursor keys. <table border="1" data-bbox="320 1066 1382 1234"> <thead> <tr> <th>Display</th> <th>Description</th> <th>Setting range</th> <th>Initial setting</th> </tr> </thead> <tbody> <tr> <td>FAX PHOTO DARKER</td> <td>Change in density when manual density is set dark</td> <td>0 to 6</td> <td>3</td> </tr> <tr> <td>FAX PHOTO LIGHT.</td> <td>Change in density when manual density is set light</td> <td>0 to 6</td> <td>3</td> </tr> </tbody> </table> <p>Increasing the setting makes the change in density larger, and decreasing it makes the change smaller.</p> <ol style="list-style-type: none"> 3. Press the start key. The value is set. 4. To return to the screen for selecting an item, press the stop/clear key. <p>Interrupt copy mode</p> <p>While this maintenance item is being performed, copying from an original can be made in interrupt copy mode.</p> <ol style="list-style-type: none"> 1. Press the interrupt key. The machine enters the interrupt copy mode. 2. Set the original and press the strat key. <p>To return to the screen for setting, press the interrupt key.</p> <p>Completion</p> <p>Press the stop/clear key at the screen for selecting an item. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Setting range	Initial setting	PHOTO DARKER	Change in density when manual density is set dark	0 to 3	0	PHOTO LIGHTER	Change in density when manual density is set light	0 to 3	0	Display	Description	Setting range	Initial setting	FAX TEXT DARKER	Change in density when manual density is set dark	0 to 4	2	FAX TEXT LIGHTER	Change in density when manual density is set light	0 to 9	2	Display	Description	Setting range	Initial setting	FAX PHOTO DARKER	Change in density when manual density is set dark	0 to 6	3	FAX PHOTO LIGHT.	Change in density when manual density is set light	0 to 6	3
Display	Description	Setting range	Initial setting																																		
PHOTO DARKER	Change in density when manual density is set dark	0 to 3	0																																		
PHOTO LIGHTER	Change in density when manual density is set light	0 to 3	0																																		
Display	Description	Setting range	Initial setting																																		
FAX TEXT DARKER	Change in density when manual density is set dark	0 to 4	2																																		
FAX TEXT LIGHTER	Change in density when manual density is set light	0 to 9	2																																		
Display	Description	Setting range	Initial setting																																		
FAX PHOTO DARKER	Change in density when manual density is set dark	0 to 6	3																																		
FAX PHOTO LIGHT.	Change in density when manual density is set light	0 to 6	3																																		

Maintenance item No.	Description																														
U099	<p>Checking the original size detection</p> <p>Description Checks the operation of the original size detection sensor and sets the sensing threshold value.</p> <p>Purpose To adjust the sensitiveness of the sensor and size judgement time if the original size detection sensor malfunctions frequently due to incident light or the like.</p> <p>Start</p> <ol style="list-style-type: none"> 1. Press the start key. The screen for selecting an item is displayed. 2. Select an item using the up/down cursor keys. 3. Press the start key. The screen for executing each item is displayed. <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="width: 40%;">Display</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>DATA</td> <td>Displaying detection sensor transmission data</td> </tr> <tr> <td>B/W LEVEL</td> <td>Setting detection sensor threshold value Setting original size judgment time</td> </tr> </tbody> </table> <p>Method to display the data for the sensor</p> <ol style="list-style-type: none"> 1. Press the start key. The detection sensor transmission data is displayed. <div style="text-align: center; margin: 10px 0;"> </div> <p style="text-align: center;">Figure 1-4-5</p> <ol style="list-style-type: none"> 2. To return to the screen for selecting an item, press the stop/clear key. <p>Setting</p> <ol style="list-style-type: none"> 1. Select an item to be set using the up/down cursor keys. <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="width: 20%;">Display</th> <th style="width: 40%;">Description</th> <th style="width: 20%;">Setting range</th> <th style="width: 20%;">Initial setting</th> </tr> </thead> <tbody> <tr> <td>LEVEL</td> <td>Detection sensor threshold value</td> <td>0 to 255</td> <td>170</td> </tr> <tr> <td>WAIT TIME</td> <td>Original size judgment time*</td> <td>0 to 100</td> <td>30</td> </tr> <tr> <td>A4R AREA</td> <td>Threshold value in the main scan direction for A4R detection</td> <td>220 (mm)/ 240 (mm)</td> <td>240</td> </tr> <tr> <td>ORG AREA</td> <td>Original size detection position display (mm)</td> <td>0 to 350</td> <td>–</td> </tr> <tr> <td>SIZE</td> <td>Detected original size display</td> <td>0 to 63</td> <td>–</td> </tr> </tbody> </table> <p>* Time from activation of the original detection switch (ODSW) to original size judgment</p> <p>Method to set the detection threshold value</p> <ol style="list-style-type: none"> 1. Adjust the preset value using the left/right cursor keys. A larger value increases the sensor sensitivity, and a smaller value decreases it. 2. Press the start key. The value is set. 3. To return to the screen for selecting an item, press the stop/clear key. <p>Method to set the original size judgment time</p> <ol style="list-style-type: none"> 1. Adjust the preset value using the left/right cursor keys. A larger value increases the original size judgment time, and a smaller value decreases it. 2. Press the start key. The value is set. 3. To return to the screen for selecting an item, press the stop/clear key. <p>Completion Press the stop/clear key at the screen for selecting an item. The screen for maintenance item No. is displayed.</p>	Display	Description	DATA	Displaying detection sensor transmission data	B/W LEVEL	Setting detection sensor threshold value Setting original size judgment time	Display	Description	Setting range	Initial setting	LEVEL	Detection sensor threshold value	0 to 255	170	WAIT TIME	Original size judgment time*	0 to 100	30	A4R AREA	Threshold value in the main scan direction for A4R detection	220 (mm)/ 240 (mm)	240	ORG AREA	Original size detection position display (mm)	0 to 350	–	SIZE	Detected original size display	0 to 63	–
Display	Description																														
DATA	Displaying detection sensor transmission data																														
B/W LEVEL	Setting detection sensor threshold value Setting original size judgment time																														
Display	Description	Setting range	Initial setting																												
LEVEL	Detection sensor threshold value	0 to 255	170																												
WAIT TIME	Original size judgment time*	0 to 100	30																												
A4R AREA	Threshold value in the main scan direction for A4R detection	220 (mm)/ 240 (mm)	240																												
ORG AREA	Original size detection position display (mm)	0 to 350	–																												
SIZE	Detected original size display	0 to 63	–																												



Maintenance item No.	Description																																				
U100	<p>Setting the main high voltage</p> <p>Description Changes the surface potential by changing the grid control voltage. Also performs main charging. Also changes the setting of main charging copy quantity correction.</p> <p>Purpose To set the surface potential or check main charging. Also used when reentering data after initializing the set data.</p> <p>Start</p> <ol style="list-style-type: none"> 1. Press the start key. The screen for selecting an item is displayed. 2. Select the item using the up/down cursor keys. <table border="1" data-bbox="320 573 1382 806"> <thead> <tr> <th>Display</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>MC DATA</td> <td>Changing the grid control voltage</td> </tr> <tr> <td>MC ON</td> <td>Turning the main charger on</td> </tr> <tr> <td>LASER ON/OFF</td> <td>Turning the main charger on and the laser scanner unit on and off</td> </tr> <tr> <td>INTERVAL</td> <td>Main charging copy quantity correction, copy interval</td> </tr> <tr> <td>COPY CNT</td> <td>Main charging copy quantity correction, copy quantity</td> </tr> <tr> <td>MC ADJUST</td> <td>Main charging copy quantity correction, correction amount</td> </tr> </tbody> </table> <p>Method for main charger output</p> <ol style="list-style-type: none"> 1. Press the start key. The selected operation starts. 2. To stop operation, press the stop/clear key. <p>Setting the grid control voltage</p> <ol style="list-style-type: none"> 1. Change the setting using the left/right cursor keys. <table border="1" data-bbox="320 976 1382 1055"> <thead> <tr> <th>Description</th> <th>Setting range</th> <th>Initial setting</th> </tr> </thead> <tbody> <tr> <td>Grid control voltage</td> <td>0 to 255</td> <td>135</td> </tr> </tbody> </table> <p>Increasing the setting makes the surface potential higher, and decreasing it makes the potential lower.</p> <ol style="list-style-type: none"> 2. Press the start key. The value is set. <p>Setting the main charging copy quantity correction</p> <ol style="list-style-type: none"> 1. Change the setting using the left/right cursor keys. <table border="1" data-bbox="320 1193 1382 1335"> <thead> <tr> <th>Display</th> <th>Setting</th> <th>Setting range</th> <th>Initial setting</th> </tr> </thead> <tbody> <tr> <td>INTERVAL</td> <td>Copy interval</td> <td>1 to 255 (minute)</td> <td>60</td> </tr> <tr> <td>COPY CNT</td> <td>Copy quantity</td> <td>1 to 255 (10 sheets)</td> <td>50</td> </tr> <tr> <td>MC ADJUST</td> <td>Correction amount</td> <td>0 to 50 (bit)</td> <td>10</td> </tr> </tbody> </table> <p>Copy interval: Sets the time interval from the previous copying. If the time from the previous copying exceeds this preset value, the copy quantity counter will be reset.</p> <p>Copy quantity: Sets the copy quantity from which copy quantity correction starts. When the copy quantity counter reaches this preset value, correction will start.</p> <p>Correction amount: Sets the correction amount for copy quantity correction.</p> <p>Set the values in the range from 5 to 120 minutes for copy interval, from 10 to 2,000 sheets for copy quantity, and from 5 to 50 bits for correction amount.</p> <ol style="list-style-type: none"> 2. Press the start key. The value is set. <p>Completion</p> <p>Press the stop/clear key when main charger output stops while a selection item is displayed. The indication for selecting a maintenance item No. appears.</p>	Display	Description	MC DATA	Changing the grid control voltage	MC ON	Turning the main charger on	LASER ON/OFF	Turning the main charger on and the laser scanner unit on and off	INTERVAL	Main charging copy quantity correction, copy interval	COPY CNT	Main charging copy quantity correction, copy quantity	MC ADJUST	Main charging copy quantity correction, correction amount	Description	Setting range	Initial setting	Grid control voltage	0 to 255	135	Display	Setting	Setting range	Initial setting	INTERVAL	Copy interval	1 to 255 (minute)	60	COPY CNT	Copy quantity	1 to 255 (10 sheets)	50	MC ADJUST	Correction amount	0 to 50 (bit)	10
Display	Description																																				
MC DATA	Changing the grid control voltage																																				
MC ON	Turning the main charger on																																				
LASER ON/OFF	Turning the main charger on and the laser scanner unit on and off																																				
INTERVAL	Main charging copy quantity correction, copy interval																																				
COPY CNT	Main charging copy quantity correction, copy quantity																																				
MC ADJUST	Main charging copy quantity correction, correction amount																																				
Description	Setting range	Initial setting																																			
Grid control voltage	0 to 255	135																																			
Display	Setting	Setting range	Initial setting																																		
INTERVAL	Copy interval	1 to 255 (minute)	60																																		
COPY CNT	Copy quantity	1 to 255 (10 sheets)	50																																		
MC ADJUST	Correction amount	0 to 50 (bit)	10																																		

Maintenance item No.	Description																																																																
U101	<p>Setting the other high voltages</p> <p>Description Changes the developing bias voltage and transfer/separation voltage.</p> <p>Purpose To check the developing bias and the transfer/separation voltage or to take measures against drop of image density or background fog.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. The screen for selecting an item is displayed. 2. Select the item to be set using the up/down cursor keys. 3. Press the start key. The screen for executing each item is displayed. <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="text-align: left;">Display</th> <th style="text-align: left;">Description</th> </tr> </thead> <tbody> <tr> <td>DEV</td> <td>Setting the developing bias</td> </tr> <tr> <td>TC</td> <td>Setting the transfer voltage</td> </tr> <tr> <td>SC</td> <td>Setting the separation voltage</td> </tr> </tbody> </table> <p>Setting the developing bias</p> <ol style="list-style-type: none"> 1. Select the item to be set using the up/down cursor keys. 2. Change the setting using the left/right cursor keys. <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="text-align: left;">Display</th> <th style="text-align: left;">Description</th> <th style="text-align: left;">Setting range</th> <th style="text-align: left;">Initial setting</th> </tr> </thead> <tbody> <tr> <td>BIAS C</td> <td>Developing bias clock frequency (copier mode)</td> <td>2 to 255</td> <td>27</td> </tr> <tr> <td>DUTY C</td> <td>Developing bias clock duty (copier mode)</td> <td>1 to 99</td> <td>45</td> </tr> <tr> <td>BIAS P</td> <td>Developing bias clock frequency (printer mode)</td> <td>2 to 255</td> <td>22</td> </tr> <tr> <td>DUTY P</td> <td>Developing bias clock duty (printer mode)</td> <td>1 to 99</td> <td>45</td> </tr> </tbody> </table> <p>Increasing the BIAS C/P setting makes the image lighter; decreasing it makes the image darker. Increasing the DUTY C/P setting makes the image lighter; decreasing it makes the image darker.</p> <ol style="list-style-type: none"> 3. Press the start key. The value is set. <p>Setting the transfer voltage</p> <ol style="list-style-type: none"> 1. Select the item to be set using the up/down cursor keys. 2. Change the setting using the left/right cursor keys. <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="text-align: left;">Display</th> <th style="text-align: left;">Description</th> <th style="text-align: left;">Setting range</th> <th style="text-align: left;">Initial setting</th> </tr> </thead> <tbody> <tr> <td>TC DATA1</td> <td>Transfer control voltage (large size)</td> <td>0 to 255</td> <td>171</td> </tr> <tr> <td>TC DATA2</td> <td>Transfer control voltage (small size)</td> <td>0 to 255</td> <td>182</td> </tr> <tr> <td>OFF TIMING</td> <td>Transfer charging output OFF timing</td> <td>0 to 255</td> <td>37</td> </tr> <tr> <td>ON TIMING</td> <td>Transfer charging output ON timing</td> <td>0 to 255</td> <td>35</td> </tr> </tbody> </table> <ol style="list-style-type: none"> 3. Press the start key. The value is set. <p>Setting the separation voltage</p> <ol style="list-style-type: none"> 1. Select the item to be set using the up/down cursor keys. 2. Change the setting using the left/right cursor keys. <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="text-align: left;">Display</th> <th style="text-align: left;">Description</th> <th style="text-align: left;">Setting range</th> <th style="text-align: left;">Initial setting</th> </tr> </thead> <tbody> <tr> <td>SC SEL</td> <td>Separation control voltage</td> <td>0 to 2</td> <td>1</td> </tr> <tr> <td>SC ON TIMING</td> <td>Separation charging output ON timing</td> <td>0 to 255</td> <td>35</td> </tr> <tr> <td>SC OFF TIMING</td> <td>Separation charging output OFF timing</td> <td>0 to 255</td> <td>42</td> </tr> </tbody> </table> <ol style="list-style-type: none"> 3. Press the start key. The value is set. <p>Interrupt copy mode While this maintenance item is being performed, copying from an original can be made in interrupt copy mode.</p> <ol style="list-style-type: none"> 1. Press the interrupt key. The machine enters the interrupt copy mode. 2. Set the original and press the start key. To return to the screen for setting, press the interrupt key. <p>Completion Press the stop/clear key at the screen for selecting an item. The screen for maintenance item No. is displayed.</p>	Display	Description	DEV	Setting the developing bias	TC	Setting the transfer voltage	SC	Setting the separation voltage	Display	Description	Setting range	Initial setting	BIAS C	Developing bias clock frequency (copier mode)	2 to 255	27	DUTY C	Developing bias clock duty (copier mode)	1 to 99	45	BIAS P	Developing bias clock frequency (printer mode)	2 to 255	22	DUTY P	Developing bias clock duty (printer mode)	1 to 99	45	Display	Description	Setting range	Initial setting	TC DATA1	Transfer control voltage (large size)	0 to 255	171	TC DATA2	Transfer control voltage (small size)	0 to 255	182	OFF TIMING	Transfer charging output OFF timing	0 to 255	37	ON TIMING	Transfer charging output ON timing	0 to 255	35	Display	Description	Setting range	Initial setting	SC SEL	Separation control voltage	0 to 2	1	SC ON TIMING	Separation charging output ON timing	0 to 255	35	SC OFF TIMING	Separation charging output OFF timing	0 to 255	42
Display	Description																																																																
DEV	Setting the developing bias																																																																
TC	Setting the transfer voltage																																																																
SC	Setting the separation voltage																																																																
Display	Description	Setting range	Initial setting																																																														
BIAS C	Developing bias clock frequency (copier mode)	2 to 255	27																																																														
DUTY C	Developing bias clock duty (copier mode)	1 to 99	45																																																														
BIAS P	Developing bias clock frequency (printer mode)	2 to 255	22																																																														
DUTY P	Developing bias clock duty (printer mode)	1 to 99	45																																																														
Display	Description	Setting range	Initial setting																																																														
TC DATA1	Transfer control voltage (large size)	0 to 255	171																																																														
TC DATA2	Transfer control voltage (small size)	0 to 255	182																																																														
OFF TIMING	Transfer charging output OFF timing	0 to 255	37																																																														
ON TIMING	Transfer charging output ON timing	0 to 255	35																																																														
Display	Description	Setting range	Initial setting																																																														
SC SEL	Separation control voltage	0 to 2	1																																																														
SC ON TIMING	Separation charging output ON timing	0 to 255	35																																																														
SC OFF TIMING	Separation charging output OFF timing	0 to 255	42																																																														

Maintenance item No.	Description						
U110	<p>Checking/clearing the drum count</p> <p>Description Displays the drum counts for checking, clearing the figure.</p> <p>Purpose To check the drum status. Also used to clear the count after replacing the drum during regular maintenance. Since the count was cleared before shipping, do not clear it when installing. A drum count value less than 150K, however, cannot be cleared.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. The drum counter count is displayed. 2. Select the CLEAR using the up/down cursor keys. If the counter value is 150K or less, CLEAR is not displayed. 3. Press the start key. The count is cleared, and the screen for selecting a maintenance item No. is displayed. <p>Completion To exit the maintenance mode without changing the count, press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p>						
U130	<p>Initial setting for the developer</p> <p>Description Replenishes toner to the developer unit to a certain level from the toner container that has been installed.</p> <p>Purpose To operate when installing the machine.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. The screen for executing is displayed. 2. Select the EXECUTE using the up/down cursor keys. 3. Press the start key. Installation of toner starts and time (minutes) is indicated until the installation ends. 4. When the installation is complete, FINISHED will be displayed if the installation is successful or NG will be displayed if it has failed. <p>Completion Press the stop/clear key after operation is complete. The screen for selecting a maintenance item No. is displayed.</p>						
U144	<p>Setting toner loading operation</p> <p>Description Sets toner loading operation after completion of copying.</p> <p>Purpose To set whether or not toner is loaded on the drum after low density copying. Normally no change is necessary from the initial setting.</p> <p>Method Press the start key. The screen for selecting an item is displayed.</p> <p>Setting</p> <ol style="list-style-type: none"> 1. Select either ON or OFF using the up/down cursor keys. The selected item is displayed in reverse. <table border="1" data-bbox="317 1505 1382 1619"> <thead> <tr> <th data-bbox="317 1505 699 1547">Display</th> <th data-bbox="699 1505 1382 1547">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="317 1547 699 1581">ON</td> <td data-bbox="699 1547 1382 1581">Toner loaded</td> </tr> <tr> <td data-bbox="317 1581 699 1619">OFF</td> <td data-bbox="699 1581 1382 1619">Toner not loaded</td> </tr> </tbody> </table> <p>Initial setting: OFF</p> <ol style="list-style-type: none"> 2. Press the start key. The value is set. <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	ON	Toner loaded	OFF	Toner not loaded
Display	Description						
ON	Toner loaded						
OFF	Toner not loaded						

Maintenance item No.	Description																												
<p>U157</p>	<p>Checking/clearing the developing drive time</p> <p>Description Displays the developing drive time for checking, clearing or changing a figure.</p> <p>Purpose To check the developing drive time. Also used to clear the count after replacing the developing unit.</p> <p>Method Press the start key. The developing drive time is displayed in minutes.</p> <p>Clearing</p> <ol style="list-style-type: none"> 1. Select the CLEAR using the up/down cursor keys. 2. Press the start key. The time is cleared, and the screen for selecting a maintenance item No. is displayed. <p>Setting</p> <ol style="list-style-type: none"> 1. Enter a seven-digit drive time (in minutes) using the numeric keys. 2. Press the start key. The time is set, and the screen for selecting a maintenance item No. is displayed. <p>Completion To exit this maintenance item without changing the time, press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p>																												
<p>U158</p>	<p>Checking the developing count</p> <p>Description Displays the developing count for checking a figure.</p> <p>Purpose To check the developing count.</p> <p>Method Press the start key. The developing count is displayed.</p> <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p>																												
<p>U161</p>	<p>Setting the fixing control temperature</p> <p>Description Changes the fixing control temperature.</p> <p>Purpose Normally no change is necessary. However, can be used to prevent curling or creasing of paper, or solve a fixing problem on thick paper.</p> <p>Setting</p> <ol style="list-style-type: none"> 1. Press the start key. The screen for selecting an item is displayed. 2. Select the item to be set using the up/down cursor keys. The screen for executing each item is displayed. 3. Change the setting using the left/right cursor keys. <table border="1" data-bbox="304 1397 1366 1626"> <thead> <tr> <th>Display</th> <th>Description</th> <th>Setting range</th> <th>Initial setting</th> </tr> </thead> <tbody> <tr> <td>1ST TEMP</td> <td>Primary stabilization fixing temperature</td> <td>120 to 185 (°C)</td> <td>140</td> </tr> <tr> <td>2ND TEMP</td> <td>Secondary stabilization fixing temperature</td> <td>120 to 185 (°C)</td> <td>160</td> </tr> <tr> <td>COPY TEMP1</td> <td>Copying operation temperature 1</td> <td>160 to 220 (°C)</td> <td>170</td> </tr> <tr> <td>COPY TEMP2</td> <td>Copying operation temperature 2</td> <td>160 to 220 (°C)</td> <td>180</td> </tr> <tr> <td>COPY CNT</td> <td>Number of sheets for fixing control</td> <td>1 to 99</td> <td>5</td> </tr> <tr> <td>THICK CNT</td> <td>Number of sheets for fixing control (thick paper)</td> <td>1 to 99</td> <td>20</td> </tr> </tbody> </table> <p>Copying operation temperature 1: Temperature in copying operation at the start of copying Copying operation temperature 2: Temperature in copying operation after the specified number of sheets for fixing control have passed Number of sheets for fixing control: The number of sheets to be counted for switching from copying operation temperature 1 to copying operation temperature 2 The temperatures are to be set such that Secondary stabilization ≥ Primary stabilization.</p> <ol style="list-style-type: none"> 4. Press the start key. The value is set. <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Setting range	Initial setting	1ST TEMP	Primary stabilization fixing temperature	120 to 185 (°C)	140	2ND TEMP	Secondary stabilization fixing temperature	120 to 185 (°C)	160	COPY TEMP1	Copying operation temperature 1	160 to 220 (°C)	170	COPY TEMP2	Copying operation temperature 2	160 to 220 (°C)	180	COPY CNT	Number of sheets for fixing control	1 to 99	5	THICK CNT	Number of sheets for fixing control (thick paper)	1 to 99	20
Display	Description	Setting range	Initial setting																										
1ST TEMP	Primary stabilization fixing temperature	120 to 185 (°C)	140																										
2ND TEMP	Secondary stabilization fixing temperature	120 to 185 (°C)	160																										
COPY TEMP1	Copying operation temperature 1	160 to 220 (°C)	170																										
COPY TEMP2	Copying operation temperature 2	160 to 220 (°C)	180																										
COPY CNT	Number of sheets for fixing control	1 to 99	5																										
THICK CNT	Number of sheets for fixing control (thick paper)	1 to 99	20																										



Maintenance item No.	Description								
U162	<p>Stabilizing fixing forcibly</p> <p>Description Stops the stabilization fixing drive forcibly, regardless of fixing temperature.</p> <p>Purpose To forcibly stabilize the machine before the fixing section reaches stabilization temperature.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. The screen for executing is displayed. 2. Press the start key. The forced stabilization mode is entered, and stabilization operation stops regardless of fixing temperature. The screen for selecting a maintenance item No. is displayed. To exit the forced stabilization mode, turn the power off and on. <p>Completion To exit this maintenance item without executing forced fixing stabilization, press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p>								
U163	<p>Resetting the fixing problem data</p> <p>Description Resets the detection of a service call code indicating a problem in the fixing section.</p> <p>Purpose To prevent accidents due to an abnormally high fixing temperature.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. The screen for executing is displayed. 2. Select the EXECUTE using the up/down cursor keys. The selected item is displayed in reverse. 3. Press the start key. The fixing problem data is initialized. <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p>								
U167	<p>Checking/clearing fixing counts</p> <p>Description Displays or clears fixing counts.</p> <p>Purpose To check fixing counts. Also used to clear the count after replacing the fixing unit.</p> <p>Method Press the start key. The fixing counts are displayed.</p> <p>Clearing</p> <ol style="list-style-type: none"> 1. Select the CLEAR using the up/down cursor keys. 2. Press the start key. The count is cleared, and the screen for selecting a maintenance item No. is displayed. <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p>								
U199	<p>Checking the fixing temperature</p> <p>Description Displays the fixing temperature, the ambient temperature and the absolute humidity.</p> <p>Purpose To check the fixing temperature, the ambient temperature and the absolute humidity.</p> <p>Method Press the start key. The fixing temperature and ambient temperature are displayed in centigrade (°C) and the absolute humidity is displayed in percentage (%).</p> <table border="1" data-bbox="320 1688 1382 1827"> <thead> <tr> <th data-bbox="320 1688 699 1731">Display</th> <th data-bbox="699 1688 1382 1731">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="320 1731 699 1765">FIX TEMP</td> <td data-bbox="699 1731 1382 1765">Fixing temperature (°C)</td> </tr> <tr> <td data-bbox="320 1765 699 1798">SURROUND TEMP</td> <td data-bbox="699 1765 1382 1798">Ambient temperature (°C)</td> </tr> <tr> <td data-bbox="320 1798 699 1827">HUMIDITY</td> <td data-bbox="699 1798 1382 1827">Absolute humidity (%)</td> </tr> </tbody> </table> <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	FIX TEMP	Fixing temperature (°C)	SURROUND TEMP	Ambient temperature (°C)	HUMIDITY	Absolute humidity (%)
Display	Description								
FIX TEMP	Fixing temperature (°C)								
SURROUND TEMP	Ambient temperature (°C)								
HUMIDITY	Absolute humidity (%)								

Maintenance item No.	Description										
<p>U200</p>	<p>Turning all LEDs on</p> <p>Description Turns all the LEDs on the operation panel on.</p> <p>Purpose To check if all the LEDs on the operation panel light.</p> <p>Method Press the start key. All the LEDs on the operation panel light. Press the stop/clear key or wait for 10 s. The LEDs turns off, and the screen for selecting a maintenance item No. is displayed.</p>										
<p>U202</p>	<p>Setting the KMAS host monitoring system</p> <p>Description Initializes or operates the KMAS host monitoring system. This is an optional device which is currently supported only by Japanese specification machines, so no setting is necessary.</p>										
<p>U203</p>	<p>Checking DP operation</p> <p>Description Simulates the original conveying operation separately in the optional DP.</p> <p>Purpose To check the DP.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. The screen for selecting an item is displayed. 2. Place an original in the DP if running this simulation with paper. 3. Select the item to be operated using the up/down cursor keys. The selected item is displayed in reverse. <table border="1" data-bbox="304 999 1366 1171"> <thead> <tr> <th data-bbox="304 999 683 1043">Display</th> <th data-bbox="683 999 1366 1043">Operation</th> </tr> </thead> <tbody> <tr> <td data-bbox="304 1043 683 1077">ADP</td> <td data-bbox="683 1043 1366 1077">With paper, single-sided original</td> </tr> <tr> <td data-bbox="304 1077 683 1111">RADP</td> <td data-bbox="683 1077 1366 1111">With paper, double-sided original</td> </tr> <tr> <td data-bbox="304 1111 683 1144">ADP (NON-P)</td> <td data-bbox="683 1111 1366 1144">Without paper, single-sided original (continuous operation)</td> </tr> <tr> <td data-bbox="304 1144 683 1171">RADP (NON-P)</td> <td data-bbox="683 1144 1366 1171">Without paper, double-sided original (continuous operation)</td> </tr> </tbody> </table> <ol style="list-style-type: none"> 4. Press the start key. The operation starts. 5. To stop continuous operation, press the stop/clear key. <p>Completion Press the stop/clear key when the operation stops. The screen for selecting a maintenance item No. is displayed.</p>	Display	Operation	ADP	With paper, single-sided original	RADP	With paper, double-sided original	ADP (NON-P)	Without paper, single-sided original (continuous operation)	RADP (NON-P)	Without paper, double-sided original (continuous operation)
Display	Operation										
ADP	With paper, single-sided original										
RADP	With paper, double-sided original										
ADP (NON-P)	Without paper, single-sided original (continuous operation)										
RADP (NON-P)	Without paper, double-sided original (continuous operation)										



Maintenance item No.	Description								
U204	<p>Setting the presence or absence of a key card or key counter</p> <p>Description Sets the presence or absence of the optional key card or key counter.</p> <p>Purpose To run this maintenance item if a key card or key counter is installed.</p> <p>Setting</p> <ol style="list-style-type: none"> 1. Press the start key. The screen for selecting an item is displayed 2. Select the optional counter to be installed using the up/down cursor keys. The selected counter is displayed in reverse. <table border="1" data-bbox="320 546 1382 687"> <thead> <tr> <th data-bbox="320 546 699 589">Display</th> <th data-bbox="699 546 1382 589">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="320 589 699 622">OFF</td> <td data-bbox="699 589 1382 622">None</td> </tr> <tr> <td data-bbox="320 622 699 656">KEY-CARD</td> <td data-bbox="699 622 1382 656">The key card is installed</td> </tr> <tr> <td data-bbox="320 656 699 687">KEY-COUNTER</td> <td data-bbox="699 656 1382 687">The key counter is installed</td> </tr> </tbody> </table> <ol style="list-style-type: none"> 3. Press the start key. The setting is set and the screen for selecting a maintenance item No. is displayed. <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	OFF	None	KEY-CARD	The key card is installed	KEY-COUNTER	The key counter is installed
Display	Description								
OFF	None								
KEY-CARD	The key card is installed								
KEY-COUNTER	The key counter is installed								
U207	<p>Checking the operation panel keys</p> <p>Description Checks operation of the operation panel keys.</p> <p>Purpose To check operation of all the keys and LEDs on the operation panel.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. The screen for executing is displayed. 2. COUNT1 is displayed and the leftmost LED on the operation panel lights. 3. As the keys lined up in the same line as the lit indicator are pressed in the order from the top to the bottom, the figure shown on the touch panel increases in increments of 1. When all the keys in that line are pressed and if there are any LEDs corresponding to the keys in the line on the immediate right, the top LED in that line will light. 4. When all the keys on the operation panel have been pressed, all the LEDs light for up to 10 seconds. 5. When the LEDs go off, press the start key. All the LEDs light for 10 seconds again. <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p>								

Maintenance item No.	Description															
U243	<p>Checking the operation of the DP motors and solenoids</p> <p>Description Turns the motors or solenoids in the optional DP on.</p> <p>Purpose To check the operation of the DP motors and solenoids.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. The screen for selecting an item is displayed. 2. Select the item to be operated using the up/down cursor keys. 3. Press the start key. The operation starts. <table border="1" data-bbox="304 546 1367 712"> <thead> <tr> <th>Display</th> <th>Motors, solenoids and clutch</th> <th>Operation In operation</th> </tr> </thead> <tbody> <tr> <td>F MOT</td> <td>Original feed motor (OFM)</td> <td>In operation</td> </tr> <tr> <td>C MOT</td> <td>Original paper conveying motor (OCM)</td> <td>In operation</td> </tr> <tr> <td>RJ SL</td> <td>Switchback feedshift solenoid (SBFSSOL)</td> <td>On for 0.5 s</td> </tr> <tr> <td>RP SL</td> <td>Switchback pressure solenoid (SBPSOL)</td> <td>On for 0.5 s</td> </tr> </tbody> </table> <ol style="list-style-type: none"> 3. To turn each motor off, press the stop/clear key. <p>Completion Press the stop/clear key when operation stops. The screen for selecting a maintenance item No. is displayed.</p>	Display	Motors, solenoids and clutch	Operation In operation	F MOT	Original feed motor (OFM)	In operation	C MOT	Original paper conveying motor (OCM)	In operation	RJ SL	Switchback feedshift solenoid (SBFSSOL)	On for 0.5 s	RP SL	Switchback pressure solenoid (SBPSOL)	On for 0.5 s
Display	Motors, solenoids and clutch	Operation In operation														
F MOT	Original feed motor (OFM)	In operation														
C MOT	Original paper conveying motor (OCM)	In operation														
RJ SL	Switchback feedshift solenoid (SBFSSOL)	On for 0.5 s														
RP SL	Switchback pressure solenoid (SBPSOL)	On for 0.5 s														
U244	<p>Checking the DP switches</p> <p>Description Displays the status of the respective switches in the optional DP.</p> <p>Purpose To check if respective switches in the optional DP operate correctly.</p> <p>Start</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Turn the respective switches on and off manually to check the status. If the on-status of a switch is detected, the corresponding switch is displayed in reverse. <table border="1" data-bbox="304 1113 1367 1346"> <thead> <tr> <th>Display</th> <th>Switches</th> </tr> </thead> <tbody> <tr> <td>SET SW</td> <td>Original set switch (OSSW)</td> </tr> <tr> <td>TMG SW</td> <td>DP timing switch (DPTSW)</td> </tr> <tr> <td>MAT SW</td> <td>DP open/close switch (DPOCSW)</td> </tr> <tr> <td>COV SW</td> <td>DP original cover switch (DPOCSW)</td> </tr> <tr> <td>REV SW</td> <td>Original switchback switch (OSBSW)</td> </tr> <tr> <td>SZ A SW</td> <td>Original size length switch (OSLSW)</td> </tr> </tbody> </table> <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Switches	SET SW	Original set switch (OSSW)	TMG SW	DP timing switch (DPTSW)	MAT SW	DP open/close switch (DPOCSW)	COV SW	DP original cover switch (DPOCSW)	REV SW	Original switchback switch (OSBSW)	SZ A SW	Original size length switch (OSLSW)	
Display	Switches															
SET SW	Original set switch (OSSW)															
TMG SW	DP timing switch (DPTSW)															
MAT SW	DP open/close switch (DPOCSW)															
COV SW	DP original cover switch (DPOCSW)															
REV SW	Original switchback switch (OSBSW)															
SZ A SW	Original size length switch (OSLSW)															

Maintenance item No.	Description																
U245	<p>Checking messages</p> <p>Description Displays a list of messages or graphics on the operation panel.</p> <p>Purpose To check the messages or graphics to be displayed.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. The screen for selecting an item is displayed. 2. Select the item to be displayed using the up/down cursor keys. 3. Press the start key. The selected item is displayed. <table border="1" data-bbox="320 546 1382 656"> <thead> <tr> <th>Display</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>Check display messages</td> <td>Check the messages</td> </tr> <tr> <td>Check display graphics</td> <td>Check the graphics</td> </tr> </tbody> </table> <p>Method to display the messages</p> <ol style="list-style-type: none"> 1. Change the screen using the up/down cursor keys to display each message one at a time. You can select the language using the left/right cursor keys. 2. To return to the screen for selecting an item, press the stop/clear key. <p>Method to display the graphics</p> <ol style="list-style-type: none"> 1. Change the screen using the up/down cursor keys to display each graphic one at a time. You can select the background (black or white) using the left/right cursor keys. 2. To return to the screen for selecting an item, press the stop/clear key. <p>Completion Press the stop/clear key at the screen for selecting an item. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Check display messages	Check the messages	Check display graphics	Check the graphics										
Display	Description																
Check display messages	Check the messages																
Check display graphics	Check the graphics																
U246	<p>Setting the finisher</p> <p>Description Adjusts the side registration cursor stop position in the staple sort mode.</p> <p>Purpose To adjust when registration is not proper or staple position is shifted in the staple sort mode.</p> <p>Setting</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select the desired cursor position using the up/down cursor keys. The selected item is displayed in reverse. 3. Change the setting using the left/right cursor keys. <table border="1" data-bbox="320 1335 1382 1476"> <thead> <tr> <th>Display</th> <th>Description</th> <th>Setting range</th> <th>Initial setting</th> </tr> </thead> <tbody> <tr> <td>FRONT</td> <td>Front side registration cursor stop position</td> <td>0 to +8</td> <td>4</td> </tr> <tr> <td>REAR</td> <td>Rear side registration cursor stop position</td> <td>0 to +8</td> <td>4</td> </tr> <tr> <td>END</td> <td>Trailing edge registration cursor stop position</td> <td>0 to +8</td> <td>4</td> </tr> </tbody> </table> <ol style="list-style-type: none"> 4. Press the start key. The value is set. <p>Completion Press the stop/clear key at the screen for selecting an item. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Setting range	Initial setting	FRONT	Front side registration cursor stop position	0 to +8	4	REAR	Rear side registration cursor stop position	0 to +8	4	END	Trailing edge registration cursor stop position	0 to +8	4
Display	Description	Setting range	Initial setting														
FRONT	Front side registration cursor stop position	0 to +8	4														
REAR	Rear side registration cursor stop position	0 to +8	4														
END	Trailing edge registration cursor stop position	0 to +8	4														

Maintenance item No.	Description						
<p>U249</p>	<p>Checking the paper ejection to optional devices</p> <p>Description Ejects paper to an optional job separator.</p> <p>Purpose To check paper conveying operation to optional job separator.</p> <p>Method 1. While pressing the feedshift switch by your hand, press the start key. Paper transfer operation starts.</p> <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p>						
<p>U250</p>	<p>Setting the maintenance cycle</p> <p>Description Displays and changes the maintenance cycle.</p> <p>Purpose To check and change the maintenance cycle.</p> <p>Method Press the start key. The current setting is displayed.</p> <p>Setting 1. Change the setting using the numeric keys. To clear, press the reset key.</p> <table border="1" data-bbox="304 853 1366 936"> <thead> <tr> <th data-bbox="304 853 679 893">Description</th> <th data-bbox="679 853 967 893">Setting range</th> <th data-bbox="967 853 1366 893">Initial setting</th> </tr> </thead> <tbody> <tr> <td data-bbox="304 893 679 936">Maintenance cycle</td> <td data-bbox="679 893 967 936">0 to 9999999</td> <td data-bbox="967 893 1366 936">150000</td> </tr> </tbody> </table> <p>2. Press the start key. The value is set, and the screen for selecting a maintenance item No. is displayed.</p> <p>Completion To exit this maintenance item without changing the current setting, press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p>	Description	Setting range	Initial setting	Maintenance cycle	0 to 9999999	150000
Description	Setting range	Initial setting					
Maintenance cycle	0 to 9999999	150000					



Maintenance item No.	Description																				
U251	<p>Checking/clearing the maintenance count</p> <p>Description Displays, clears and changes the maintenance count.</p> <p>Purpose To check the maintenance count. Also to clear the count during maintenance service.</p> <p>Method Press the start key. The maintenance count is displayed.</p> <p>Clearing</p> <ol style="list-style-type: none"> 1. Select the CLEAR using the up/down cursor keys. 2. Press the start key. The count is cleared, and the screen for selecting a maintenance item No. is displayed. <p>Setting</p> <ol style="list-style-type: none"> 1. Select the COUNT using the up/down cursor keys. 2. Enter a seven-digit count using the numeric keys. 3. Press the start key. The count is set, and the screen for selecting a maintenance item No. is displayed. <p>Completion To exit this maintenance item without changing the count, press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p>																				
U252	<p>Setting the destination</p> <p>Description Switches the operations and screens of the machine according to the destination.</p> <p>Purpose To be executed after replacing the backup RAM on the main PCB or initializing the backup RAM by running maintenance item U020, in order to return the setting to the value before replacement or initialization.</p> <p>Method Press the start key. The screen for selecting an item is displayed.</p> <p>Setting</p> <ol style="list-style-type: none"> 1. Select the destination using the up/down cursor keys. The selected item is displayed in reverse. <table border="1" data-bbox="320 1133 1382 1301"> <thead> <tr> <th>Display</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>JAPAN METRIC</td> <td>Metric (Japan) specifications</td> </tr> <tr> <td>INCH</td> <td>Inch (North America) specifications</td> </tr> <tr> <td>EUROPE METRIC</td> <td>Metric (Europe) specifications</td> </tr> <tr> <td>ASIA PACIFIC</td> <td>Metric (Asia Pacific) specifications</td> </tr> </tbody> </table> <ol style="list-style-type: none"> 2. Press the start key. The setting is set, and the machine automatically returns to the same status as when the power is turned on. <p>Completion To exit this maintenance item without changing the current count, press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p> <p>Supplement The specified initial settings are provided according to the destinations in the maintenance items below. To change the initial settings in those items, be sure to run maintenance item U021 after changing the destination.</p> <ul style="list-style-type: none"> • Initial setting according to the destinations <table border="1" data-bbox="320 1592 1382 1709"> <thead> <tr> <th>Maintenance item No.</th> <th>Title</th> <th>Japan</th> <th>Inch</th> <th>Europe Metric, Asia Pacific</th> </tr> </thead> <tbody> <tr> <td>253</td> <td>Switching between double and single counts</td> <td>Single</td> <td>Double</td> <td>Double</td> </tr> </tbody> </table>	Display	Description	JAPAN METRIC	Metric (Japan) specifications	INCH	Inch (North America) specifications	EUROPE METRIC	Metric (Europe) specifications	ASIA PACIFIC	Metric (Asia Pacific) specifications	Maintenance item No.	Title	Japan	Inch	Europe Metric, Asia Pacific	253	Switching between double and single counts	Single	Double	Double
Display	Description																				
JAPAN METRIC	Metric (Japan) specifications																				
INCH	Inch (North America) specifications																				
EUROPE METRIC	Metric (Europe) specifications																				
ASIA PACIFIC	Metric (Asia Pacific) specifications																				
Maintenance item No.	Title	Japan	Inch	Europe Metric, Asia Pacific																	
253	Switching between double and single counts	Single	Double	Double																	

Maintenance item No.	Description								
<p>U253</p>	<p>Switching between double and single counts</p> <p>Description Switches the count system for the total counter and other counters.</p> <p>Purpose According to user (copy service provider) request, select if A3/11" × 17" paper is to be counted as one sheet (single count) or two sheets (double count).</p> <p>Method Press the start key. The screen for selecting an item is displayed.</p> <p>Setting</p> <ol style="list-style-type: none"> Select double or single count using the up/down cursor keys. The selected item is displayed in reverse. <table border="1" data-bbox="304 584 1366 723"> <thead> <tr> <th>Display</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>SINGLE COUNT</td> <td>Single count for all size paper</td> </tr> <tr> <td>DOUBLE COUNT (A3/LEDGER)</td> <td>Double count for A3/11" × 17" paper only</td> </tr> <tr> <td>DOUBLE COUNT (B4)</td> <td>Double count for B4 size or larger</td> </tr> </tbody> </table> <p>Initial setting: DOUBLE COUNT</p> <ol style="list-style-type: none"> Press the start key. The setting is set, and the screen for selecting a maintenance item No. is displayed. <p>Completion To exit this maintenance item without changing the current setting, press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	SINGLE COUNT	Single count for all size paper	DOUBLE COUNT (A3/LEDGER)	Double count for A3/11" × 17" paper only	DOUBLE COUNT (B4)	Double count for B4 size or larger
Display	Description								
SINGLE COUNT	Single count for all size paper								
DOUBLE COUNT (A3/LEDGER)	Double count for A3/11" × 17" paper only								
DOUBLE COUNT (B4)	Double count for B4 size or larger								
<p>U254</p>	<p>Turning auto start function on/off</p> <p>Description Selects if the auto start function is turned on.</p> <p>Purpose Normally no change is necessary. If incorrect operation occurs, turn the function off: this may solve the problem.</p> <p>Method Press the start key. The screen for selecting an item is displayed.</p> <p>Setting</p> <ol style="list-style-type: none"> Select either ON or OFF using the up/down cursor keys. The selected item is displayed in reverse. <table border="1" data-bbox="304 1218 1366 1330"> <thead> <tr> <th>Display</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>ON</td> <td>Auto start function on</td> </tr> <tr> <td>OFF</td> <td>Auto start function off</td> </tr> </tbody> </table> <p>Initial setting: ON</p> <ol style="list-style-type: none"> Press the start key. The setting is set, and the screen for selecting a maintenance item No. is displayed. <p>Completion To exit this maintenance item without changing the current setting, press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	ON	Auto start function on	OFF	Auto start function off		
Display	Description								
ON	Auto start function on								
OFF	Auto start function off								



Maintenance item No.	Description						
<p>U258</p>	<p>Switching copy operation at toner empty detection</p> <p>Description Selects if continuous copying is enabled after toner empty is detected, and sets the number of copies that can be made after the detection.</p> <p>Purpose To be set according to user request.</p> <p>Method Press the start key. The screen for selecting an item is displayed.</p> <p>Setting</p> <ol style="list-style-type: none"> 1. Select single or continuous copying using the up/down cursor keys. The selected item is displayed in reverse. <table border="1" data-bbox="320 611 1382 723"> <thead> <tr> <th>Display</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>SINGLE</td> <td>Enables only single copying.</td> </tr> <tr> <td>CONTINUE</td> <td>Enables single and continuous copying.</td> </tr> </tbody> </table> <p>Initial setting: SINGLE</p> <ol style="list-style-type: none"> 3. Press the start key. The setting is set, and the screen for selecting a maintenance item No. is displayed. <p>Completion To exit this maintenance item without changing the current setting, press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	SINGLE	Enables only single copying.	CONTINUE	Enables single and continuous copying.
Display	Description						
SINGLE	Enables only single copying.						
CONTINUE	Enables single and continuous copying.						
<p>U260</p>	<p>Changing the copy count timing</p> <p>Description Changes the copy count timing for the total counter and other counters.</p> <p>Purpose To be set according to user (copy service provider) request. If a paper jam occurs frequently in the finisher when the number of copies is counted at the time of paper ejection, copies are provided without copy counts. The copy service provider cannot charge for such copying. To prevent this, the copy timing should be made earlier. If a paper jam occurs frequently in the paper conveying or fixing sections when the number of copies is counted before the paper reaches those sections, copying is charged without a copy being made. To prevent this, the copy timing should be made later.</p> <p>Method Press the start key. The screen for selecting an item is displayed.</p> <p>Setting</p> <ol style="list-style-type: none"> 1. Select the copy count timing using the up/down cursor keys. The selected item is displayed in reverse. <table border="1" data-bbox="320 1361 1382 1473"> <thead> <tr> <th>Display</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>FEED</td> <td>When secondary paper feed starts</td> </tr> <tr> <td>EJECT</td> <td>When the paper is ejected</td> </tr> </tbody> </table> <p>Initial setting: EJECT</p> <ol style="list-style-type: none"> 2. Press the start key. The setting is set, and the screen for selecting a maintenance item No. is displayed. <p>Completion To exit this maintenance item without changing the current setting, press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	FEED	When secondary paper feed starts	EJECT	When the paper is ejected
Display	Description						
FEED	When secondary paper feed starts						
EJECT	When the paper is ejected						



Maintenance item No.	Description								
<p>U264</p>	<p>Setting the display order of the date</p> <p>Description Selects year, month and day as the order of that appears on lists, etc.</p> <p>Purpose Set according to the user preference.</p> <p>Method Press the start key. The screen for selecting an item is displayed.</p> <p>Setting</p> <ol style="list-style-type: none"> 1. Press the start key. The screen for selecting an item is displayed. 2. Select the desired order using the up/down cursor keys. <table border="1" data-bbox="304 584 1366 723"> <thead> <tr> <th>Display</th> <th>Setting</th> </tr> </thead> <tbody> <tr> <td>YEAR-MONTH-DATE</td> <td>Year/Month/Day</td> </tr> <tr> <td>MONTH-DATE-YEAR</td> <td>Month/Day/Year</td> </tr> <tr> <td>DATE-MONTH-YEAR</td> <td>Day/Month/Year</td> </tr> </tbody> </table> <p>Initial setting: "MONTH-DATE-YEAR" (for the inch specifications) "DATE-MONTH-YEAR" (for the metric specifications)</p> <ol style="list-style-type: none"> 3. Press the start key. The setting is set, and the screen for selecting a maintenance item No. is displayed. <p>Completion To exit this maintenance item without changing the current setting, press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Setting	YEAR-MONTH-DATE	Year/Month/Day	MONTH-DATE-YEAR	Month/Day/Year	DATE-MONTH-YEAR	Day/Month/Year
Display	Setting								
YEAR-MONTH-DATE	Year/Month/Day								
MONTH-DATE-YEAR	Month/Day/Year								
DATE-MONTH-YEAR	Day/Month/Year								
<p>U265</p>	<p>Setting OEM purchaser code</p> <p>Description Sets the OEM purchaser code.</p> <p>Purpose Sets the code when replacing the main PCB and the like.</p> <p>Method Press the start key.</p> <p>Setting</p> <ol style="list-style-type: none"> 1. Use the numeric keys or left/right cursor keys to adjust the preset value. 2. Press the start key. The count is set, and the screen for selecting a maintenance item is displayed. <p>Completion To exit this maintenance item without changing the current setting, press the stop/clear key. The screen for selecting a maintenance item is displayed.</p>								
<p>U277</p>	<p>Setting auto application change time</p> <p>Description Sets the time that passes until the machine starts automatically printing after completing copying or operation when the machine is used as a printer or fax.</p> <p>Purpose According to user request, changes the setting.</p> <p>Method Press the start key. The current setting is displayed.</p> <p>Setting</p> <ol style="list-style-type: none"> 1. Change the setting using the left/right cursor keys. <table border="1" data-bbox="304 1675 1366 1756"> <thead> <tr> <th>Description</th> <th>Setting range</th> <th>Initial setting</th> </tr> </thead> <tbody> <tr> <td>Switching time</td> <td>30 to 270 (s)</td> <td>30</td> </tr> </tbody> </table> <p>The setting can be changed by 30 s per step.</p> <ol style="list-style-type: none"> 2. Press the start key. The value is set, and the screen for selecting a maintenance item No. is displayed. <p>Completion To exit this maintenance item without changing the current setting, press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p>	Description	Setting range	Initial setting	Switching time	30 to 270 (s)	30		
Description	Setting range	Initial setting							
Switching time	30 to 270 (s)	30							



Maintenance item No.	Description																
U326	<p>Setting the black line cleaning indication</p> <p>Description Sets whether to display the cleaning guidance when detecting the black line.</p> <p>Purpose Displays the cleaning guidance in order to make the call for service with the black line decrease by the rubbish on the contact glass when scanning from the optional DP.</p> <p>Method Press the start key. The screen for selecting an item is displayed.</p> <p>Setting</p> <ol style="list-style-type: none"> 1. Select ON or OFF using the up/down cursor keys. <table border="1" data-bbox="320 584 1382 696"> <thead> <tr> <th>Display</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>ON</td> <td>Displays the cleaning guidance</td> </tr> <tr> <td>OFF</td> <td>Not to display the cleaning guidance</td> </tr> </tbody> </table> <p>Initial setting: ON</p> <ol style="list-style-type: none"> 2. Press the start key. The setting is set, and the screen for selecting a maintenance item No. is displayed. <p>Completion To exit this maintenance item without changing the current setting, press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	ON	Displays the cleaning guidance	OFF	Not to display the cleaning guidance										
Display	Description																
ON	Displays the cleaning guidance																
OFF	Not to display the cleaning guidance																
U332	<p>Setting the size conversion factor</p> <p>Description Sets the coefficient of nonstandard sizes in relation to the A4/11" × 8¹/₂" size. The coefficient set here is used to convert the black ratio in relation to the A4/11" × 8¹/₂" size and to display the result in user simulation.</p> <p>Purpose To set the coefficient for converting the black ratio for nonstandard sizes in relation to the A4/11" × 8¹/₂" size for copy mode, printer mode and fax mode respectively.</p> <p>Method Press the start key. The screen for selecting an item is displayed.</p> <p>Setting</p> <ol style="list-style-type: none"> 1. Select copier mode (COPY), printer mode (PRT) or fax mode (FAX) using the up/down cursor keys. 2. Change the setting using the cursor left/right keys. <table border="1" data-bbox="320 1245 1382 1384"> <thead> <tr> <th>Display</th> <th>Description</th> <th>Setting range</th> <th>Initial setting</th> </tr> </thead> <tbody> <tr> <td>COPY</td> <td>Size parameter for copier mode</td> <td>0.1 to 3.0</td> <td>1.0</td> </tr> <tr> <td>PRINTER</td> <td>Size parameter for printer mode</td> <td>0.1 to 3.0</td> <td>1.0</td> </tr> <tr> <td>FAX</td> <td>Size parameter for fax mode</td> <td>0.1 to 3.0</td> <td>1.0</td> </tr> </tbody> </table> <ol style="list-style-type: none"> 3. Press the start key. The setting is set, and the screen for selecting a maintenance item No. is displayed. <p>Completion To exit this maintenance item without changing the current setting, press the stop/clear key. The screen for selecting a maintenance item is displayed.</p>	Display	Description	Setting range	Initial setting	COPY	Size parameter for copier mode	0.1 to 3.0	1.0	PRINTER	Size parameter for printer mode	0.1 to 3.0	1.0	FAX	Size parameter for fax mode	0.1 to 3.0	1.0
Display	Description	Setting range	Initial setting														
COPY	Size parameter for copier mode	0.1 to 3.0	1.0														
PRINTER	Size parameter for printer mode	0.1 to 3.0	1.0														
FAX	Size parameter for fax mode	0.1 to 3.0	1.0														

Maintenance item No.	Description										
<p>U341</p>	<p>Specific paper feed location setting for printing function</p> <p>Description Sets a paper feed location specified for printer output.</p> <p>Purpose To use a paper feed location only for printer output.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. The screen for selecting an item is displayed. 2. Select the paper feed location for the printer using the up/down cursor keys. The selected item is displayed in reverse. <table border="1" data-bbox="304 544 1366 719"> <thead> <tr> <th>Display</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>PF1</td> <td>Drawer</td> </tr> <tr> <td>PF2</td> <td>First paper feeder*2</td> </tr> <tr> <td>PF3</td> <td>Second paper feeder*1</td> </tr> <tr> <td>PF4</td> <td>Third paper feeder*1</td> </tr> </tbody> </table> <p>*1: Optional. *2: Optional for 16 ppm model. Standard for 20 ppm model.</p> <ol style="list-style-type: none"> 3. Change the setting using the left/right cursor keys. 0: OFF 1: ON 4. Press the start key. The setting is set. <p>Completion Press the stop/clear key. The screen for selecting a maintenance item is displayed.</p>	Display	Description	PF1	Drawer	PF2	First paper feeder*2	PF3	Second paper feeder*1	PF4	Third paper feeder*1
Display	Description										
PF1	Drawer										
PF2	First paper feeder*2										
PF3	Second paper feeder*1										
PF4	Third paper feeder*1										
<p>U342</p>	<p>Setting the ejection restriction</p> <p>Description Sets or cancels the restriction on the number of sheets to be ejected continuously. When the restriction is set, the number of sheets that can be ejected continuously to the internal eject tray will be limited to 250.</p> <p>Purpose According to user request, sets or cancels restriction on the number of sheets.</p> <p>Method Press the start key. The screen for selecting an item is displayed.</p> <p>Setting</p> <ol style="list-style-type: none"> 1. Select either ON or OFF using the up/down cursor keys. The selected item is displayed in reverse. <table border="1" data-bbox="304 1267 1366 1379"> <thead> <tr> <th>Display</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>ON</td> <td>Sets restriction on the number of sheets</td> </tr> <tr> <td>OFF</td> <td>Cancels restriction on the number of sheets</td> </tr> </tbody> </table> <p>Initial setting: ON</p> <ol style="list-style-type: none"> 2. Press the start key. The setting is set. <p>Completion Press the stop/clear key. The screen for selectiong a maintenance item No. is displayed.</p>	Display	Description	ON	Sets restriction on the number of sheets	OFF	Cancels restriction on the number of sheets				
Display	Description										
ON	Sets restriction on the number of sheets										
OFF	Cancels restriction on the number of sheets										



Maintenance item No.	Description						
<p>U343</p>	<p>Switching between duplex/simplex copy mode</p> <p>Description Switches the initial setting between duplex and simplex copy.</p> <p>Purpose To be set according to frequency of use: set to the more frequently used mode.</p> <p>Method Press the start key. The screen for selecting an item is displayed.</p> <p>Setting</p> <ol style="list-style-type: none"> 1. Select ON or OFF using the up/down cursor keys. The selected item is displayed in reverse. <table border="1" data-bbox="320 555 1382 667"> <thead> <tr> <th>Display</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>ON</td> <td>Duplex copy</td> </tr> <tr> <td>OFF</td> <td>Simplex copy</td> </tr> </tbody> </table> <p>Initial setting: OFF</p> <ol style="list-style-type: none"> 2. Press the start key. The setting is set, and the screen for selecting a maintenance item No. is displayed. <p>Completion To exit this maintenance item without changing the current setting, press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	ON	Duplex copy	OFF	Simplex copy
Display	Description						
ON	Duplex copy						
OFF	Simplex copy						
<p>U344</p>	<p>Setting preheat/energy saver mode</p> <p>Description Changes the control for preheat/energy saver mode.</p> <p>Purpose According to user request, selects which has priority, the recovery time from preheat or energy saver.</p> <p>Method Press the start key. The screen for selecting an item is displayed.</p> <p>Setting</p> <ol style="list-style-type: none"> 1. Select control mode using the up/down cursor keys. The selected item is displayed in reverse. <table border="1" data-bbox="320 1131 1382 1299"> <thead> <tr> <th>Display</th> <th>Control in preheat mode</th> </tr> </thead> <tbody> <tr> <td>ENERGY STAR</td> <td>The fixing control temperature is lowered by 20°C/68°F and forced stabilization is performed 30 seconds after exiting preheat.</td> </tr> <tr> <td>GEEA</td> <td>The fixing control temperature is lowered by 15°C/59°F and forced stabilization is performed 30 seconds after exiting preheat.</td> </tr> </tbody> </table> <p>Initial setting: ENERGY STAR</p> <ol style="list-style-type: none"> 2. Press the start key. The setting is set, and the screen for selecting a maintenance item No. is displayed. <p>Completion To exit this maintenance item without changing the current setting, press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Control in preheat mode	ENERGY STAR	The fixing control temperature is lowered by 20°C/68°F and forced stabilization is performed 30 seconds after exiting preheat.	GEEA	The fixing control temperature is lowered by 15°C/59°F and forced stabilization is performed 30 seconds after exiting preheat.
Display	Control in preheat mode						
ENERGY STAR	The fixing control temperature is lowered by 20°C/68°F and forced stabilization is performed 30 seconds after exiting preheat.						
GEEA	The fixing control temperature is lowered by 15°C/59°F and forced stabilization is performed 30 seconds after exiting preheat.						
<p>U345</p>	<p>Setting the value for maintenance due indication</p> <p>Description Sets when to display a message notifying that the time for maintenance is about to be reached, by setting the number of copies that can be made before the current maintenance cycle ends. When the difference between the number of copies of the maintenance cycle and that of the maintenance count reaches the set value, the message is displayed. This maintenance mode is effective for only Japanese specification.</p>						
<p>U402</p>	<p>Adjusting margins of image printing</p> <p>Adjustment See page 1-6-13.</p>						
<p>U403</p>	<p>Adjusting margins for scanning an original on the contact glass</p> <p>Adjustment See page 1-6-31.</p>						



Maintenance item No.	Description																									
<p>U404</p>	<p>Adjusting margins for scanning an original from the DP</p> <p>Description Adjusts margins for scanning the original from the DP.</p> <p>Purpose Used if margins are not correct when the optional DP is used.</p> <p>Caution Before making this adjustment, ensure that the following adjustments have been made in maintenance mode. U402 → U403 → U404</p> <p>Method Press the start key. The screen for selecting an item is displayed.</p> <p>Setting</p> <ol style="list-style-type: none"> 1. Select the item to be set using the up/down cursor keys. The selected item is displayed in reverse. 2. Change the setting using the left/right cursor keys. <table border="1" data-bbox="304 703 1366 871"> <thead> <tr> <th>Display</th> <th>Description</th> <th>Setting range</th> <th>Initial setting</th> <th>Change in value per step</th> </tr> </thead> <tbody> <tr> <td>A MARGIN</td> <td>Left margin</td> <td>0 to 10.0</td> <td>2.0</td> <td>0.1 mm</td> </tr> <tr> <td>B MARGIN</td> <td>Leading edge margin</td> <td>0 to 10.0</td> <td>3.0</td> <td>0.1 mm</td> </tr> <tr> <td>C MARGIN</td> <td>Right margin</td> <td>0 to 10.0</td> <td>2.0</td> <td>0.1 mm</td> </tr> <tr> <td>D MARGIN</td> <td>Trailing edge margin</td> <td>0 to 10.0</td> <td>2.0</td> <td>0.1 mm</td> </tr> </tbody> </table> <p>Increasing the setting makes the margin wider, and decreasing it makes the margin narrower.</p> <div data-bbox="459 936 1214 1339" data-label="Diagram"> </div> <p style="text-align: center;">Figure 1-4-6 Correct margin amount</p> <ol style="list-style-type: none"> 3. Press the start key. The value is set. <p>Interrupt copy mode While this maintenance item is being performed, copying from an original can be made in interrupt copy mode.</p> <ol style="list-style-type: none"> 1. Press the interrupt key. The machine enters the interrupt copy mode. 2. Set the original and press the start key. To return to the screen for setting, press the interrupt key. <p>Completion Press the stop/clear key at the screen for selecting an item. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Setting range	Initial setting	Change in value per step	A MARGIN	Left margin	0 to 10.0	2.0	0.1 mm	B MARGIN	Leading edge margin	0 to 10.0	3.0	0.1 mm	C MARGIN	Right margin	0 to 10.0	2.0	0.1 mm	D MARGIN	Trailing edge margin	0 to 10.0	2.0	0.1 mm
Display	Description	Setting range	Initial setting	Change in value per step																						
A MARGIN	Left margin	0 to 10.0	2.0	0.1 mm																						
B MARGIN	Leading edge margin	0 to 10.0	3.0	0.1 mm																						
C MARGIN	Right margin	0 to 10.0	2.0	0.1 mm																						
D MARGIN	Trailing edge margin	0 to 10.0	2.0	0.1 mm																						
<p>U407</p>	<p>Adjusting the leading edge registration for memory image printing</p> <p>Adjustment See page 1-6-11.</p>																									



Maintenance item No.	Description						
<p>U504</p>	<p>Initializing the scanner NIC</p> <p>Description Initializing the optional scanner NIC to its factory default.</p> <p>Purpose To return to a setup at the time of factory shipments.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. The screen for executing is displayed. 2. Select the EXECUTE using the up/down cursor keys. It is displayed in reverse. 3. Press the start key. All data in the scanner NIC is initialized. <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p>						
<p>U506</p>	<p>Setting the time out</p> <p>Description Sets the communication timeout time for connection to a computer.</p> <p>Purpose To change the preset value if a communication error occurs after connection to a computer continues for a long time. By delaying the error detection timing, the error may be cleared. If the error is not cleared after the preset value is changed, however, return the preset value to the initial value.</p> <p>Method Press the start key. The screen for selecting an item is displayed.</p> <p>Setting</p> <ol style="list-style-type: none"> 1. Select ON or OFF using the left/right cursor keys. The selected item is displayed in reverse. <table border="1" data-bbox="320 972 1382 1055"> <thead> <tr> <th data-bbox="320 972 699 1014">Description</th> <th data-bbox="699 972 986 1014">Setting range</th> <th data-bbox="986 972 1382 1014">Initial setting</th> </tr> </thead> <tbody> <tr> <td data-bbox="320 1014 699 1055">timeout time</td> <td data-bbox="699 1014 986 1055">10 to 120 (s)</td> <td data-bbox="986 1014 1382 1055">10</td> </tr> </tbody> </table> <p>The setting can be changed by 10 s per step.</p> <ol style="list-style-type: none"> 2. Press the start key. The setting is set, and the screen for selecting a maintenance item No. is displayed. <p>Completion To exit this maintenance item without changing the current setting, press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p>	Description	Setting range	Initial setting	timeout time	10 to 120 (s)	10
Description	Setting range	Initial setting					
timeout time	10 to 120 (s)	10					



Maintenance item No.	Description														
U901	<p>Checking/clearing copy counts by paper feed locations</p> <p>Description Displays or clears copy counts by paper feed locations.</p> <p>Purpose To check the time to replace consumable parts. Also to clear the counts after replacing the consumable parts.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. The counts by paper feed locations are displayed. 2. Change the screen using the left/right cursor keys. <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="text-align: left;">Display</th> <th style="text-align: left;">Paper feed locations</th> </tr> </thead> <tbody> <tr> <td>BYP</td> <td>Bypass tray</td> </tr> <tr> <td>PF1</td> <td>Drawer</td> </tr> <tr> <td>PF2</td> <td>First paper feeder*2</td> </tr> <tr> <td>PF3</td> <td>Second paper feeder*1</td> </tr> <tr> <td>PF4</td> <td>Third paper feeder*1</td> </tr> <tr> <td>DUP</td> <td>Duplex section*1</td> </tr> </tbody> </table> <p>*1: Optional. *2: Optional for 16 ppm model. Standard for 20 ppm model.</p> <p>Clearing</p> <ol style="list-style-type: none"> 1. Select the count to be cleared using the up/down cursor keys. The selected item is displayed in reverse. However, PF2, 3, and 4 are displayed only and cannot be cleared. 2. Press the start key. The count is cleared. <p>Completion To exit this maintenance item without changing the count, press the stop/clear key. The screen for selecting a maintenance No. item is displayed.</p>	Display	Paper feed locations	BYP	Bypass tray	PF1	Drawer	PF2	First paper feeder*2	PF3	Second paper feeder*1	PF4	Third paper feeder*1	DUP	Duplex section*1
Display	Paper feed locations														
BYP	Bypass tray														
PF1	Drawer														
PF2	First paper feeder*2														
PF3	Second paper feeder*1														
PF4	Third paper feeder*1														
DUP	Duplex section*1														
U903	<p>Checking/clearing the paper jam counts</p> <p>Description Displays or clears the jam counts by jam locations.</p> <p>Purpose To check the paper jam status. Also to clear the jam counts after replacing consumable parts.</p> <p>Start</p> <ol style="list-style-type: none"> 1. Press the start key. The screen for selecting an item is displayed. 2. Select the item using the up/down cursor keys. 3. Press the start key. The code by type is displayed. <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="text-align: left;">Display</th> <th style="text-align: left;">Description</th> </tr> </thead> <tbody> <tr> <td>COUNT</td> <td>Displays/clears the jam counts</td> </tr> <tr> <td>TOTAL COUNT</td> <td>Displays the total jam counts</td> </tr> </tbody> </table> <p>Method: Displays/clears the jam counts</p> <ol style="list-style-type: none"> 1. Change the screen using the left/right cursor keys. 2. Select the counts for all jam codes and select the ALL. Jam counts cannot be cleared individually. 3. Press the start key. The counts are cleared. <p>Method: Displays the total jam counts</p> <ol style="list-style-type: none"> 1. Change the screen using the left/right cursor keys. The total number of jam count cannot be cleared. 2. To return to the screen for selecting an item, press the stop/clear key. <p>Completion To exit this maintenance item without changing the count, press the stop/clear key. The screen for selecting a maintenance No. item is displayed.</p>	Display	Description	COUNT	Displays/clears the jam counts	TOTAL COUNT	Displays the total jam counts								
Display	Description														
COUNT	Displays/clears the jam counts														
TOTAL COUNT	Displays the total jam counts														



Maintenance item No.	Description														
U904	<p>Checking/clearing the service call counts</p> <p>Description Displays or clears the service call code counts by types.</p> <p>Purpose To check the service call code status by types. Also to clear the service call code counts after replacing consumable parts.</p> <p>Start</p> <ol style="list-style-type: none"> 1. Press the start key. The screen for selecting an item is displayed. 2. Select the item using the up/down cursor keys. 3. Press the start key. The code by type is displayed. <table border="1" data-bbox="320 573 1382 685"> <thead> <tr> <th>Display</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>COUNT</td> <td>Displays/clears the service call code counts</td> </tr> <tr> <td>TOTAL COUNT</td> <td>Displays the total service call code counts</td> </tr> </tbody> </table> <p>Method: Displays/clears the service call code counts</p> <ol style="list-style-type: none"> 1. Select the code to be cleared using the up/down cursor keys. Change the screen using the left/right cursor keys. Select the counts for all service call codes and select the ALL. 2. Press the start key. The count is cleared. <p>Method: Displays the total service call code counts</p> <ol style="list-style-type: none"> 1. Change the screen using the left/right cursor keys. The total number of service call code count cannot be cleared. 2. To return to the screen for selecting an item, press the stop/clear key. <p>Completion To exit this maintenance item without changing the count, press the stop/clear key. The screen for selecting a maintenance No. item is displayed.</p>	Display	Description	COUNT	Displays/clears the service call code counts	TOTAL COUNT	Displays the total service call code counts								
Display	Description														
COUNT	Displays/clears the service call code counts														
TOTAL COUNT	Displays the total service call code counts														
U905	<p>Checking counts by optional devices</p> <p>Description Displays the counts of the optional DP or finisher.</p> <p>Purpose To check the use of the DP and finisher.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. The screen for selecting an item is displayed. 2. Select the device using the up/down cursor keys, the count of which is to be checked and press the start key. The count of the selected device is displayed. <ul style="list-style-type: none"> • DP <table border="1" data-bbox="320 1391 1382 1503"> <thead> <tr> <th>Display</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>ADP</td> <td>No. of single-sided originals that has passed through the DP in ADP mode</td> </tr> <tr> <td>RADP</td> <td>No. of double-sided originals that has passed through the DP in RADP mode</td> </tr> </tbody> </table> <ul style="list-style-type: none"> • Finisher <table border="1" data-bbox="320 1543 1382 1686"> <thead> <tr> <th>Display</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>CP CNT</td> <td>No. of copies that has passed</td> </tr> <tr> <td>STAPLE</td> <td>Frequency the stapler has been activated</td> </tr> <tr> <td>BUNDLE EJECT</td> <td>Frequency the bundle discharge has been activated</td> </tr> </tbody> </table> <p>Completion Press the stop/clear key at the screen for selecting an item. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	ADP	No. of single-sided originals that has passed through the DP in ADP mode	RADP	No. of double-sided originals that has passed through the DP in RADP mode	Display	Description	CP CNT	No. of copies that has passed	STAPLE	Frequency the stapler has been activated	BUNDLE EJECT	Frequency the bundle discharge has been activated
Display	Description														
ADP	No. of single-sided originals that has passed through the DP in ADP mode														
RADP	No. of double-sided originals that has passed through the DP in RADP mode														
Display	Description														
CP CNT	No. of copies that has passed														
STAPLE	Frequency the stapler has been activated														
BUNDLE EJECT	Frequency the bundle discharge has been activated														

Maintenance item No.	Description
U906	<p>Resetting partial operation control</p> <p>Description Resets the service call code for partial operation control.</p> <p>Purpose To be reset after partial operation is performed due to problems in the drawers or other sections, and the related parts are serviced.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select the EXECUTE using the up/down cursor keys. It is displayed in reverse. 3. Press the start key to reset partial operation control. The maintenance mode is exited, and the machine returns to the same status as when the power switch is turned on.
U908	<p>Changing the total counter value</p> <p>Description Displays the total counter value.</p> <p>Purpose To check the total counter value.</p> <p>Method Press the start key. The current total counter value is displayed.</p> <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p>
U910	<p>Clearing the black ratio data</p> <p>Description Clears the accumulated black ratio data for A4 sheets.</p> <p>Purpose To clear data as required at times such as during maintenance service.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select the EXECUTE using the up/down cursor keys. It is displayed in reverse. 3. Press the start key. The accumulated black ratio data is cleared, and the screen for selecting a maintenance item is displayed. <p>Completion To exit this maintenance item without changing the current setting, press the stop/clear key. The screen for selecting a maintenance item is displayed.</p>
U911	<p>Checking/clearing copy counts by paper sizes</p> <p>Description Displays and clears the paper feed counts by paper sizes.</p> <p>Purpose To check or clear the counts after replacing consumable parts.</p> <p>Method Press the start key. The screen for the paper feed counts by paper size is displayed.</p> <p>Clearing</p> <ol style="list-style-type: none"> 1. Select the paper size to be cleared using the up/down cursor keys. The selected item is displayed in reverse. To clear all counts, select the ALL. 2. Press the start key. The count is cleared. When clearing all counts, the screen for selecting a maintenance item is displayed. <p>Completion To exit this maintenance item without changing the count, press the stop/clear key. The screen for selecting a maintenance item is displayed.</p>







Maintenance item No.	Description																																		
U917	<p>Setting backup data reading/writing</p> <p>Description Stores backup data from the fax control PCB (when an optional fax kit is installed) into Compact Flash or reads the data from Compact Flash.</p> <p>Purpose To store and write data when replacing the PCB.</p> <p>Setting</p> <ol style="list-style-type: none"> 1. Turn the power switch off and disconnect the power plug. 2. Remove the rear cover. 3. Insert Compact Flash in a notch hole of the machine. 4. While pressing the Copier key, turn on the power switch and connect the power plug. Press and hold on the Copier key until the message "Please wait." disappears. 5. Enter the maintenance item. 6. Press the start key. The screen for selecting an item is displayed. 7. Select the item using the up/down cursor keys. The selected item is displayed in reverse. <table border="1" data-bbox="320 719 1382 891"> <thead> <tr> <th>Display</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>SRAM→CF: BKUP</td> <td>Writing the backup data of fax control PCB</td> </tr> <tr> <td>CF→SRAM: BKUP</td> <td>Reading the backup data of fax control PCB</td> </tr> <tr> <td>SRAM→CF: DIAL</td> <td>Writing the backup data of fax dial information</td> </tr> <tr> <td>CF→SRAM: DIAL</td> <td>Reading the backup data of fax dial information</td> </tr> </tbody> </table> <ol style="list-style-type: none"> 8. Press the start key. Reading or writing is executed, and the screen displays the result. <ul style="list-style-type: none"> • If the operation was successful: EXECUTE 0100 CHECK SUM **** CODE 0000 • If the operation failed: EXECUTE 0100 CHECK SUM **** CODE XXXX Where XXX is the error code indicating the reason for the failure. See "Error Codes for Operation U917 and U926" below. 9. Turn the power switch off and disconnect the power plug. 10. Remove the Compact Flash from the machine. <p>Error Codes for Operation U917 and U926</p> <table border="1" data-bbox="288 1431 1426 1879"> <thead> <tr> <th>Code</th> <th>Meaning</th> </tr> </thead> <tbody> <tr> <td>0102</td> <td>Detects call for service on fax control PCB.</td> </tr> <tr> <td>0104</td> <td>Communication error.</td> </tr> <tr> <td>0105</td> <td>Detects call for service on main PCB.</td> </tr> <tr> <td>01FF</td> <td>CF error.</td> </tr> <tr> <td>0202</td> <td>No CF card.</td> </tr> <tr> <td>0203</td> <td>No data in CF card.</td> </tr> <tr> <td>0204</td> <td>CF data is incompatible.</td> </tr> <tr> <td>0205</td> <td>Bad CF data (Checksum error)</td> </tr> <tr> <td>0206</td> <td>CF read error.</td> </tr> <tr> <td>0207</td> <td>CF write error.</td> </tr> <tr> <td>0212</td> <td>Fax control PCB flash memory error.</td> </tr> </tbody> </table>	Display	Description	SRAM→CF: BKUP	Writing the backup data of fax control PCB	CF→SRAM: BKUP	Reading the backup data of fax control PCB	SRAM→CF: DIAL	Writing the backup data of fax dial information	CF→SRAM: DIAL	Reading the backup data of fax dial information	Code	Meaning	0102	Detects call for service on fax control PCB.	0104	Communication error.	0105	Detects call for service on main PCB.	01FF	CF error.	0202	No CF card.	0203	No data in CF card.	0204	CF data is incompatible.	0205	Bad CF data (Checksum error)	0206	CF read error.	0207	CF write error.	0212	Fax control PCB flash memory error.
Display	Description																																		
SRAM→CF: BKUP	Writing the backup data of fax control PCB																																		
CF→SRAM: BKUP	Reading the backup data of fax control PCB																																		
SRAM→CF: DIAL	Writing the backup data of fax dial information																																		
CF→SRAM: DIAL	Reading the backup data of fax dial information																																		
Code	Meaning																																		
0102	Detects call for service on fax control PCB.																																		
0104	Communication error.																																		
0105	Detects call for service on main PCB.																																		
01FF	CF error.																																		
0202	No CF card.																																		
0203	No data in CF card.																																		
0204	CF data is incompatible.																																		
0205	Bad CF data (Checksum error)																																		
0206	CF read error.																																		
0207	CF write error.																																		
0212	Fax control PCB flash memory error.																																		

Maintenance item No.	Description
U920	<p>Checking the accounting counts</p> <p>Description Checks the accounting counts.</p> <p>Purpose To check the accounting counts.</p> <p>Method Press the start key. The current counts of copy counter, printer counter and fax counter are displayed.</p> <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p>
U925	<p>Checking/clearing the system error counts</p> <p>Description Displays and clears the count value of system error.</p> <p>Purpose To check the system error status by types. Also to clear the service call code counts after replacing consumable parts.</p> <p>Method Press the start key. The count for system error detection by type is displayed.</p> <p>Clearing</p> <ol style="list-style-type: none"> 1. Change the screen using the left/right cursor keys. 2. Select the counts for system error and select the ALL. System error counts cannot be cleared individually. 3. Press the start key. The counts are cleared. <p>Completion To exit this maintenance item without changing the count, press the stop/clear key. The screen for selecting a maintenance No. item is displayed.</p>
U926	<p>Rewriting FAX program</p> <p>Description Downloads the fax program and fax fonts when installing an optional fax kit.</p> <p>Purpose To run when upgrading the fax program and fax fonts.</p> <p>Setting</p> <ol style="list-style-type: none"> 1. Turn the power switch off and disconnect the power plug. 2. Remove the rear cover. 3. Insert Compact Flash in a notch hole of the machine. 4. While pressing the Copier key, turn on the power switch and connect the power plug. Press and hold on the Copier key until the message "Please wait." disappears. 5. Enter the maintenance item. 6. Press the start key. Downloading of the fax program starts and the result shown below is displayed. <ul style="list-style-type: none"> • If the operation was successful: EXECUTE 0100 CHECKSUM **** CODE 0000 • If the operation failed: EXECUTE 0100 CHECKSUM **** CODE XXXX Where XXX is the error code indicating the reason for the failure. <ol style="list-style-type: none"> 7. Then, downloading of the fax fonts starts and the result shown below is displayed.

Maintenance item No.	Description						
U926	<ul style="list-style-type: none"> • If the operation was successful: EXECUTE 0100 CHECKSUM **** CODE 0000 • If the operation failed: EXECUTE 0100 CHECKSUM **** CODE XXXX Where XXX is the error code indicating the reason for the failure. See "Error Codes for Operation U917 and U926" on page 1-4-59. <p>8. Turn the power switch off and disconnect the power plug. 9. Remove the Compact Flash from the machine.</p>						
U927	<p>Clearing the all accounting counts and machine life counts</p> <p>Description Clears the all accounting counts and machine life counts.</p> <p>Purpose To start the counters with value 0 when installing the machine.</p> <p>Supplement The all accounting counts and the machine life counter can be cleared only once only if the count values are 1000 or less.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. The screen for executing is displayed. 2. Select the EXECUTE using the up/down cursor keys. It is displayed in reverse. 3. Press the start key. All accounting counts and machine life counts are cleared. If the counts cannot be cleared, CANNOT EXECUTE is displayed. <p>Completion To exit this maintenance item without changing the count, press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p>						
U928	<p>Checking machine life counts</p> <p>Description Displays the machine life counts.</p> <p>Purpose To check the machine life counts.</p> <p>Method Press the start key. The current machine life counts is displayed.</p> <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p>						
U941	<p>Setting the default magnification ratio of the default drawer</p> <p>Description Sets the default magnification ratio when paper selection of copy default setting is set to the default drawer.</p> <p>Purpose Accounting to user request, changes the setting.</p> <p>Method Press the start key. The screen for selecting an item is displayed.</p> <p>Setting</p> <ol style="list-style-type: none"> 1. Select 100% or AMS using the up/down cursor keys. The selected item is displayed in reverse. <table border="1" data-bbox="320 1771 1382 1883"> <thead> <tr> <th data-bbox="320 1771 699 1816">Display</th> <th data-bbox="699 1771 1382 1816">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="320 1816 699 1850">100%</td> <td data-bbox="699 1816 1382 1850">100 % magnification ratio</td> </tr> <tr> <td data-bbox="320 1850 699 1883">AMS</td> <td data-bbox="699 1850 1382 1883">Automatical magnification ratio</td> </tr> </tbody> </table> <p>Initial setting: 100 % magnification ratio</p> <ol style="list-style-type: none"> 2. Press the start key. The setting is set, and the screen for selecting a maintenance item No. is displayed. <p>Completion To exit this maintenance item without changing the current setting, press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	100%	100 % magnification ratio	AMS	Automatical magnification ratio
Display	Description						
100%	100 % magnification ratio						
AMS	Automatical magnification ratio						

Maintenance item No.	Description												
<p>U942</p>	<p>Adjusting the DP amount of slack in the original</p> <p>Description Adjusts the DP amount of slack in the original.</p> <p>Purpose To run this mode if original jams or Z folds occur when copying from the DP.</p> <p>Method Press the start key. The screen for setting is displayed.</p> <p>Setting</p> <ol style="list-style-type: none"> 1. Select the item to be set using the up/down cursor keys. The selected item is displayed in reverse. 2. Change the setting using the left/right cursor keys. <table border="1" data-bbox="304 584 1366 696"> <thead> <tr> <th>Display</th> <th>Description</th> <th>Setting range</th> <th>Initial setting</th> </tr> </thead> <tbody> <tr> <td>CONVEY</td> <td></td> <td>-10 to +20</td> <td>0</td> </tr> <tr> <td>FEED</td> <td></td> <td>-10 to +20</td> <td>0</td> </tr> </tbody> </table> <p>Increasing the setting, the larger the amount of slack; decreasing the setting, the smaller the amount of slack.</p> <ol style="list-style-type: none"> 3. Press the start key. The value is set. <p>Interrupt copy mode While this maintenance item is being performed, copying from an original can be made in interrupt copy mode.</p> <ol style="list-style-type: none"> 1. Press the interrupt key. The machine enters the interrupt copy mode. 2. Set the original and press the strat key. To return to the screen for setting, press the interrupt key. <p>Completion Press the stop/clear key at the screen for setting. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Setting range	Initial setting	CONVEY		-10 to +20	0	FEED		-10 to +20	0
Display	Description	Setting range	Initial setting										
CONVEY		-10 to +20	0										
FEED		-10 to +20	0										
<p>U990</p>	<p>Checking/clearing the time for the exposure lamp to light</p> <p>Description Displays, clears or changes the accumulated time for the exposure lamp to light.</p> <p>Purpose To check duration of use of the exposure lamp. Also to clear the accumulated time for the lamp after replacement.</p> <p>Method Press the start key. The accumulated time of illumination for the exposure lamp is displayed in minutes.</p> <p>Clearing</p> <ol style="list-style-type: none"> 1. Select the CLEAR using the up/down cursor keys. 2. Press the start key. The accumulated time is cleared, and the screen for selecting a maintenance item No. is displayed. <p>Setting</p> <ol style="list-style-type: none"> 1. Enter a seven-digit accumulated time using the numeric keys. 2. Press the start key. The time is set, and the screen for selecting a maintenance item No. is displayed. <p>Completion To exit this maintenance item without changing the accumulated time, press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p>												



Maintenance item No.	Description												
U991	<p>Checking the scanner count</p> <p>Description Displays the scanner operation count.</p> <p>Purpose To check the status of use of the scanner.</p> <p>Method Press the start key. The screen for the scanner operation count is displayed.</p> <table border="1" data-bbox="320 488 1382 627"> <thead> <tr> <th>Display</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>COPY</td> <td>Scanner operation count for copying</td> </tr> <tr> <td>FAX</td> <td>Scanner operation count for fax</td> </tr> <tr> <td>NWS</td> <td>Network scanner operation count</td> </tr> </tbody> </table> <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	COPY	Scanner operation count for copying	FAX	Scanner operation count for fax	NWS	Network scanner operation count				
Display	Description												
COPY	Scanner operation count for copying												
FAX	Scanner operation count for fax												
NWS	Network scanner operation count												
U993	<p>Outputting a VTC-PG pattern</p> <p>Description Selects and outputs a VTC-PG pattern created in the machine.</p> <p>Purpose When performing respective image printing adjustments, used to check the machine status apart from that of the scanner with a non-scanned output VTC-PG pattern.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. The screen for selecting an item is displayed. 2. Select the VTC-PG pattern to be output using the up/down cursor keys. <table border="1" data-bbox="419 1025 1295 1751"> <thead> <tr> <th>Display</th> <th>PG pattern to be output</th> <th>Purpose</th> </tr> </thead> <tbody> <tr> <td>PG1</td> <td></td> <td> <ul style="list-style-type: none"> • Center line adjustment </td> </tr> <tr> <td>PG2</td> <td></td> <td> <ul style="list-style-type: none"> • Lateral squareness adjustment • Magnification adjustment </td> </tr> <tr> <td>PG3</td> <td></td> <td>_____</td> </tr> </tbody> </table> <ol style="list-style-type: none"> 3. Press the interrupt key. The copy mode screen is displayed. 4. Press the start key. A VTC-PG pattern is output. <p>Completion Press the stop/clear key at the screen for selecting an item. The screen for selecting a maintenance item No. is displayed.</p>	Display	PG pattern to be output	Purpose	PG1		<ul style="list-style-type: none"> • Center line adjustment 	PG2		<ul style="list-style-type: none"> • Lateral squareness adjustment • Magnification adjustment 	PG3		_____
Display	PG pattern to be output	Purpose											
PG1		<ul style="list-style-type: none"> • Center line adjustment 											
PG2		<ul style="list-style-type: none"> • Lateral squareness adjustment • Magnification adjustment 											
PG3		_____											

1-5-1 Paper misfeed detection

(1) Paper misfeed indication

When a paper misfeed occurs, the machine immediately stops operating and displays the jam location on the operation panel.

Paper misfeed counts sorted by the detection condition can be checked in maintenance item U903.

To remove paper jammed in the machine, open the front cover, left cover, or pull the drawer out.

To remove original jammed in the DP, open the DP original cover.

Paper misfeed detection can be reset by opening and closing the respective covers to turn safety switch off and on.




Figure 1-5-1

- ① Misfeed in the drawer 1
- ② Misfeed in the drawer 2*²
- ③ Misfeed in the drawer 3*¹
- ④ Misfeed in the drawer 4*¹
- ⑤ Misfeed in the bypass tray
- ⑥ Misfeed in the paper conveying section
- ⑦ Misfeed in the exit section
(Misfeed in the job separator*¹ or finisher*¹)
- ⑧ Misfeed in the DP*¹

*1: Optional.

*2: Optional for 16 ppm model.
Standard for 20 ppm model.

(2) Paper misfeed detection conditions




Figure 1-5-2

Section	Jam code	Description	Conditions
System	00	No paper feed	When the power switch is turned on, the machine detects activation of the registration switch (RSW), the exit switch (ESW) or the feedshift switch (FSSW).
	04	Cover open JAM	A cover open state is detected during copying.
	05	Secondary paper feed timeout	When the machine waits for secondary paper feed, 30 s or more have elapsed.
Paper feed section	10	No paper feed from the bypass tray	The registration switch (RSW) does not turn on within 1680 ms of the bypass paper feed solenoid (BYPPFSOL) turning on; the solenoid is then successively held off for 1 s and turned back on once, but the switch again fails to turn on within 1680 ms.
	11	No paper feed from the drawer 1 (drawer)	The registration switch (RSW) does not turn on within 1430 ms of the paper feed clutch (PFCL) turning on; the clutch is then successively held off for 1 s and turned back on once, but the switch again fails to turn on within 1430 ms.
	12	No paper feed from the drawer 2*2 (first paper feeder)	The registration switch (RSW) does not turn on within 2780 ms of the drawer paper feed clutch 1 (DPFCL1)*2 turning on; the clutch is then successively held off for 1 s and turned back on once, but the switch again fails to turn on within 2780 ms.
	13	No paper feed from the drawer 3*1 (second paper feeder)	The drawer feed switch 1 (DFSW1)*2 does not turn on within 2490 ms of the drawer paper feed clutch 2 (DPFCL2)*1 turning on; the clutch is then successively held off for 1 s and turned back on once, but the switch again fails to turn on within 2490 ms.
	14	No paper feed from the drawer 4*1 (third paper feeder)	The drawer feed switch 2 (DFSW2)*1 does not turn on within 2490 ms of the drawer paper feed clutch 3 (DPFCL3)*1 turning on; the clutch is then successively held off for 1 s and turned back on once, but the switch again fails to turn on within 2490 ms.
	15	Misfeed in vertical paper conveying 1	The registration switch (RSW) does not turn on within 2340 ms of drawer feed switch 1 (DFSW1)*2 turning on.
			The drawer feed switch 1 (DFSW1)*2 does not turn off within 2050 ms of drawer feed switch 2 (DFSW2)*1 turning on.
	The drawer feed switch 1 (DFSW1)*2 does not turn off within 2050 ms of drawer feed switch 2 (DFSW2)*1 turning off.		
	16	Misfeed in vertical paper conveying 2	The drawer feed switch 1 (DFSW1)*2 does not turn on within 2050 ms of drawer feed switch 2 (DFSW2)*1 turning on.
Paper conveying section	20	Multiple sheets in the bypass tray	The registration switch (RSW) does not turn off within 6320 ms of registration switch (RSW) turning on.
			The registration switch (RSW) does not turn off within 1680 ms of bypass paper feed solenoid (BYPPFSOL) turning on.
	21	Multiple sheets in the drawer 1 (drawer)	The registration switch (RSW) does not turn off within 6320 ms of registration switch (RSW) turning on.
			The registration switch (RSW) does not turn off within 1430 ms of paper feed clutch (PFCL) turning on.

*1: Optional. *2: Optional for 16 ppm model. Standard for 20 ppm model.

Section	Jam code	Description	Conditions
Paper conveying section	22	Multiple sheets in the drawer 2*2 (first paper feeder)	The registration switch (RSW) does not turn off within 6320 ms of registration switch (RSW) turning on.
			The registration switch (RSW) does not turn off within 2780 ms of drawer paper feed clutch 1 (DPFCL1)*2 turning on.
	23	Multiple sheets in the drawer 3*1 (second paper feeder)	The drawer feed switch 1 (DFSW1)*2 does not turn off within 6320 ms of drawer feed switch 1 (DFSW1)*2 turning on.
			The drawer feed switch 1 (DFSW1)*2 does not turn off within 2490 ms of drawer paper feed clutch 2 (DPFCL2)*1 turning on.
	24	Multiple sheets in the drawer 4*1 (third paper feeder)	The drawer feed switch 2 (DFSW2)*1 does not turn off within 6320 ms of drawer feed switch 2 (DFSW2)*1 turning on.
			The drawer feed switch 2 (DFSW2)*1 does not turn off within 2490 ms of drawer paper feed clutch 3 (DPFCL3)*1 turning on.
Transfer section	30	Misfeed in registration/transfer section	The registration switch (RSW) does not turn off within 2340 ms of drawer feed switch 1 (DFSW1)*2 turning on.
			The registration switch (RSW) does not turn off within 2340 ms of drawer feed switch 1 (DFSW1)*2 turning off.
			The registration switch (RSW) does not turn off within 1760 ms of duplex paper conveying switch (DUPPCSW1)*1 turning on.
Fixing section	40	Misfeed in the fixing section (paper feed from bypass tray)	The exit switch (ESW) does not turn on within 3020 ms of the registration motor (RM) turning on.
	41	Misfeed in the fixing section (paper feed from drawer)	The exit switch (ESW) does not turn on within 3020 ms of the registration motor (RM) turning on.
	42	Misfeed in the fixing section (paper feed from first paper feeder*2)	The exit switch (ESW) does not turn on within 3020 ms of the registration motor (RM) turning on.
	43	Misfeed in the fixing section (paper feed from second paper feeder*1)	The exit switch (ESW) does not turn on within 3020 ms of the registration motor (RM) turning on.
	44	Misfeed in the fixing section (paper feed from third paper feeder*1)	The exit switch (ESW) does not turn on within 3020 ms of the registration motor (RM) turning on.
	45	Misfeed in the fixing section (paper feed from duplex section*1)	The exit switch (ESW) does not turn on within 3020 ms of the registration motor (RM) turning on.
Exit section	50	Misfeed in the exit section	The exit switch (ESW) does not turn off within 3020 ms of the registration switch (RSW) turning off.
			The exit switch (ESW) does not turn on within 3020 ms of the registration motor (RM) turning on.
	51	Misfeed in the job separator*1	The job separator eject switch (JBESW)*1 does not turn on within 2050 ms of feedshift switch (FSSW) turning on.
			The job separator eject switch (JBESW)*1 does not turn off within 2050 ms of feedshift switch (FSSW) turning off.
			The job separator eject switch (JBESW)*1 does not turn off within 2050 ms of feedshift switch (FSSW) turning off.

*1: Optional. *2: Optional for 16 ppm model. Standard for 20 ppm model.

Section	Jam code	Description	Conditions
Feedshift section	52	Misfeed in the feedshift section (paper feed from bypass tray)	The feedshift switch (FSSW) does not turn on within 6320 ms of feedshift switch (FSSW) turning on.
			The feedshift switch (FSSW) does not turn off within 1530 ms of paper switchback.
			The feedshift switch (FSSW) does not turn on within 1530 ms of paper switchback.
	53	Misfeed in the feedshift section (paper feed from drawer)	The feedshift switch (FSSW) does not turn on within 6320 ms of feedshift switch (FSSW) turning on.
			The feedshift switch (FSSW) does not turn off within 1530 ms of paper switchback.
			The feedshift switch (FSSW) does not turn on within 1530 ms of paper switchback.
	54	Misfeed in the feedshift section (paper feed from first paper feeder* ²)	The feedshift switch (FSSW) does not turn on within 6320 ms of feedshift switch (FSSW) turning on.
			The feedshift switch (FSSW) does not turn off within 1530 ms of paper switchback.
			The feedshift switch (FSSW) does not turn on within 1530 ms of paper switchback.
	55	Misfeed in the feedshift section (paper feed from second paper feeder* ¹)	The feedshift switch (FSSW) does not turn on within 6320 ms of feedshift switch (FSSW) turning on.
			The feedshift switch (FSSW) does not turn off within 1530 ms of paper switchback.
			The feedshift switch (FSSW) does not turn on within 1530 ms of paper switchback.
	56	Misfeed in the feedshift section (paper feed from third paper feeder* ¹)	The feedshift switch (FSSW) does not turn on within 6320 ms of feedshift switch (FSSW) turning on.
			The feedshift switch (FSSW) does not turn off within 1530 ms of paper switchback.
			The feedshift switch (FSSW) does not turn on within 1530 ms of paper switchback.
	57	Misfeed in the feedshift section (paper feed from duplex section* ¹)	The feedshift switch (FSSW) does not turn on within 6320 ms of feedshift switch (FSSW) turning on.
			The feedshift switch (FSSW) does not turn off within 1530 ms of paper switchback.
			The feedshift switch (FSSW) does not turn on within 1530 ms of paper switchback.
Duplex section	60	Misfeed in duplex paper conveying section* ¹	The duplex paper conveying switch (DUPPCSW)* ¹ does not turn off within 3280 ms of the feedshift switch (FSSW) turning on.
			The duplex paper conveying switch (DUPPCSW)* ¹ does not turn on within 3280 ms of the feedshift switch (FSSW) turning on.
			The duplex paper conveying switch (DUPPCSW)* ¹ does not turn off within 3280 ms of the feedshift switch (FSSW) turning off.

*1: Optional. *2: Optional for 16 ppm model. Standard for 20 ppm model.

Section	Jam code	Description	Conditions
Duplex section	61	Misfeed in duplex exit section*1	The registration switch (RSW) does not turn on within 1760 ms of the duplex paper conveying switch (DUPPCSW)*1 turning on.
			The registration switch (RSW) does not turn off within 1760 ms of the duplex paper conveying switch (DUPPCSW)*1 turning off.
DP	70	No original feed*1	During the primary feed of the second original in the single-sided or double-sided original mode, even if retry operation is performed five times, primary original feed is not performed.
	71	An original jam in the original conveying section 1*1	During the secondary original feed in the single-sided or double-sided original mode, the DP timing switch (DPTSW)*1 does not turn off within 6500 ms of the original conveying motor (OCM)*1 turning on.
	72	An original size error jam*1	During the secondary original feed in the single-sided or double-sided original mode, the DP timing switch (DPTSW)*1 does turn off within 750 ms of the original conveying motor (OCM)*1 turning on.
	73	An original jam in the original conveying section 2*1	During scanning of the second side or reversing of the original for ejection in the double-sided original mode, the DP timing switch (DPTSW)*1 does not turn off within 6500 ms of the original conveying motor (OCM)*1 turning on.
	74	An original jam in the original conveying section 3*1	During scanning of the second side or reversing of the original for ejection in the double-sided original mode, the DP timing switch (DPTSW)*1 does not turn on within 750 ms of the original conveying motor (OCM)*1 turning on.
	75	An original jam in the original switchback section*1	During the switchback operation of an original in the double-sided original mode, the original switchback switch (OSBSW)*1 does not turn on within 1300 ms of the original conveying motor (OCM)*1 turning on.
Finisher	80	Jam between the finisher and MFP*1	The paper conveying switch (PCSW)*1 does not turn on within 1550 ms of the signal requesting paper ejection is output from the MFP.
	81	Intake jam*1	During paper intake from the MFP, the paper conveying switch (PCSW)*1 does not turn off within 1960 to 3480 ms (depending on paper size) of paper conveying switch (PCSW)*1 turning on.
	83	Jam during paper conveying for batch ejection 1*1	When ejection a stack of paper, the paper conveying switch (PCSW)*1 does not turn on within 1590 ms of the paper conveying motor (PCM)*1 turning on.
	84	Jam during paper conveying for batch ejection 2*1	When ejection a stack of paper, the paper conveying switch (PCSW)*1 does not turn off within 2260 to 3190 ms (varies depending on the paper size) of the paper conveying motor (PCM)*1 turning on.

*1: Optional. *2: Optional for 16 ppm model. Standard for 20 ppm model.

(3) Paper misfeeds

Problem	Causes/check procedures	Corrective measures
(1) A paper jam in the paper feed, paper conveying or exit section is indicated as soon as the power switch is turned on. Jam code 00	A piece of paper torn from copy paper is caught around registration switch, exit sensor or feedshift switch.	Check visually and remove it, if any.
	Defective registration switch.	Run maintenance item U031 and turn registration switch on and off manually. Replace registration switch if indication of the corresponding switch is not light.
	Defective exit switch.	Run maintenance item U031 and turn exit switch on and off manually. Replace exit switch if indication of the corresponding switch is not light.
	Defective feedshift switch.	Run maintenance item U031 and turn feedshift switch on and off manually. Replace feedshift switch if indication of the corresponding switch is not light.
(2) A paper jam in the paper feed section is indicated during copying (no paper feed from the bypass tray). Jam code 10	Paper on the bypass tray is extremely curled.	Change the paper.
	Check if the bypass paper feed pulley is deformed.	Check visually and replace any deformed pulley.
	Broken registration switch actuator.	Check visually and replace registration switch if its actuator is broken.
	Defective registration switch.	Run maintenance item U031 and turn registration switch on and off manually. Replace registration switch if indication of the corresponding switch is not light.
	Check if the bypass paper feed solenoid malfunctions.	Run maintenance item U032 and select the bypass paper feed solenoid to be turned on and off. Check the status and remedy if necessary.
	Electrical problem with the bypass paper feed solenoid.	Check (see page 1-5-35).
(3) A paper jam in the paper feed section is indicated during copying (no paper feed from the drawer 1). Jam code 11	Paper in the drawer is extremely curled.	Change the paper.
	Check if the paper feed pulley, separation pulley or forward pulley is deformed.	Check visually and replace any deformed pulley.
	Broken registration switch actuator.	Check visually and replace registration switch if its actuator is broken.
	Defective registration switch.	Run maintenance item U031 and turn registration switch on and off manually. Replace registration switch if indication of the corresponding switch is not light.
	Check if the paper feed clutch malfunctions.	Run maintenance item U032 and select the paper feed clutch to be turned on and off. Check the status and remedy if necessary.
	Electrical problem with the paper feed clutch.	Check (see page 1-5-35).

Problem	Causes/check procedures	Corrective measures
(4) A paper jam in the paper feed section is indicated during copying (no paper feed from the drawer 2). Jam code 12	Paper in the first paper feeder*2 is extremely curled.	Change the paper.
	Check if the paper feed pulley, separation pulley or forward pulley in the first paper feeder*2 is deformed.	Check visually and replace any deformed pulley.
	Broken registration switch actuator.	Check visually and replace registration switch if its actuator is broken.
	Defective registration switch.	Run maintenance item U031 and turn registration switch on and off manually. Replace registration switch if indication of the corresponding switch is not light.
	Check if the drawer paper feed clutch 1*2 malfunctions.	Run maintenance item U032 and select the drawer paper feed clutch 1 to be turned on and off. Check the status and remedy if necessary.
	Electrical problem with the drawer paper feed clutch 1*2.	Check.
(5) A paper jam in the paper feed section is indicated during copying (no paper feed from the drawer 3). Jam code 13	Paper in the second paper feeder*1 is extremely curled.	Change the paper.
	Check if the paper feed pulley, separation pulley or forward pulley in the second paper feeder*1 is deformed.	Check visually and replace any deformed pulley.
	Broken drawer feed switch 1*2 actuator.	Check visually and replace drawer feed switch 1 if its actuator is broken.
	Defective drawer feed switch 1*2.	Run maintenance item U031 and turn drawer feed switch 1 on and off manually. Replace drawer feed switch 1 if indication of the corresponding switch is not light.
	Check if the drawer paper feed clutch 2*1 malfunctions.	Run maintenance item U032 and select the drawer paper feed clutch 2 to be turned on and off. Check the status and remedy if necessary.
	Electrical problem with the drawer paper feed clutch 2*1.	Check.
(6) A paper jam in the paper feed section is indicated during copying (no paper feed from the drawer 4). Jam code 14	Paper in the third paper feeder*1 is extremely curled.	Change the paper.
	Check if the paper feed pulley, separation pulley or forward pulley in the third paper feeder*1 is deformed.	Check visually and replace any deformed pulley.
	Broken drawer feed switch 2*1 actuator.	Check visually and replace drawer feed switch 2 if its actuator is broken.

*1: Optional. *2: Optional for 16 ppm model. Standard for 20 ppm model.

Problem	Causes/check procedures	Corrective measures
(6) A paper jam in the paper feed section is indicated during copying (no paper feed from the drawer 4). Jam code 14	Defective drawer feed switch 2*1.	Run maintenance item U031 and turn drawer feed switch 2 on and off manually. Replace drawer feed switch 2 if indication of the corresponding switch is not light.
	Check if the drawer paper feed clutch 3*1 malfunctions.	Run maintenance item U032 and select the drawer paper feed clutch 3 to be turned on and off. Check the status and remedy if necessary.
	Electrical problem with the drawer paper feed clutch 3*1.	Check.
(7) A paper jam in the paper feed section is indicated during copying (misfeed in vertical paper conveying 1). Jam code 15	Broken registration switch actuator.	Check visually and replace registration switch if its actuator is broken.
	Defective registration switch.	Run maintenance item U031 and turn registration switch on and off manually. Replace registration switch if indication of the corresponding switch is not light.
	Broken drawer feed switch 1*2 actuator.	Check visually and replace drawer feed switch 1 if its actuator is broken.
	Defective drawer feed switch 1*2.	Run maintenance item U031 and turn drawer feed switch 1 on and off manually. Replace drawer feed switch 1 if indication of the corresponding switch is not light.
	Broken drawer feed switch 2*1 actuator.	Check visually and replace drawer feed switch 2 if its actuator is broken.
	Defective drawer feed switch 2*1.	Run maintenance item U031 and turn drawer feed switch 2 on and off manually. Replace drawer feed switch 2 if indication of the corresponding switch is not light.
	Check if the paper feed clutch malfunctions.	Run maintenance item U032 and select the paper feed clutch to be turned on and off. Check the status and remedy if necessary.
	Electrical problem with the paper feed clutch.	Check (see page 1-5-35).
	Check if the drawer paper feed clutch 1*2 malfunctions.	Run maintenance item U032 and select the drawer paper feed clutch 1 to be turned on and off. Check the status and remedy if necessary.
	Electrical problem with the drawer paper feed clutch 1*2.	Check.
	Check if the drawer paper feed clutch 2*1 malfunctions.	Run maintenance item U032 and select the drawer paper feed clutch 2 to be turned on and off. Check the status and remedy if necessary.
	Electrical problem with the drawer paper feed clutch 2*1.	Check.
	Check if the drawer paper feed clutch 3*1 malfunctions.	Run maintenance item U032 and select the drawer paper feed clutch 3 to be turned on and off. Check the status and remedy if necessary.
	Electrical problem with the drawer paper feed clutch 3*1.	Check.

*1: Optional. *2: Optional for 16 ppm model. Standard for 20 ppm model.

Problem	Causes/check procedures	Corrective measures
(8) A paper jam in the paper feed section is indicated during copying (misfeed in vertical paper conveying 2). Jam code 16	Broken drawer feed switch 1*2 actuator.	Check visually and replace drawer feed switch 1 if its actuator is broken.
	Defective drawer feed switch 1*2.	Run maintenance item U031 and turn drawer feed switch 1 on and off manually. Replace drawer feed switch 1 if indication of the corresponding switch is not light.
	Broken drawer feed switch 2*1 actuator.	Check visually and replace drawer feed switch 2 if its actuator is broken.
	Defective drawer feed switch 2*1.	Run maintenance item U031 and turn drawer feed switch 2 on and off manually. Replace drawer feed switch 2 if indication of the corresponding switch is not light.
	Check if the drawer paper feed clutch 1*2 malfunctions.	Run maintenance item U032 and select the drawer paper feed clutch 1 to be turned on and off. Check the status and remedy if necessary.
	Electrical problem with the drawer paper feed clutch 1*2.	Check.
	Check if the drawer paper feed clutch 2*1 malfunctions.	Run maintenance item U032 and select the drawer paper feed clutch 2 to be turned on and off. Check the status and remedy if necessary.
	Electrical problem with the drawer paper feed clutch 2*1.	Check.
(9) A paper jam in the paper conveying section is indicated during copying (multiple sheets in the bypass tray). Jam code 20	Deformed guides along the paper conveying path.	Repair or replace if necessary.
	Broken registration switch actuator.	Check visually and replace registration switch if its actuator is broken.
	Defective registration switch.	Run maintenance item U031 and turn registration switch on and off manually. Replace registration switch if indication of the corresponding switch is not light.
	Check if the bypass paper feed solenoid malfunctions.	Run maintenance item U032 and select the bypass paper feed solenoid to be turned on and off. Check the status and remedy if necessary.
	Electrical problem with the bypass paper feed solenoid.	Check (see page 1-5-35).
	Check if the right and left registration rollers contact each other.	Check visually and remedy if necessary.
(10) A paper jam in the paper conveying section is indicated during copying (multiple sheets in the drawer 1). Jam code 21	Deformed guides along the paper conveying path.	Repair or replace if necessary.
	Broken registration switch actuator.	Check visually and replace registration switch if its actuator is broken.
	Defective registration switch.	Run maintenance item U031 and turn registration switch on and off manually. Replace registration switch if indication of the corresponding switch is not light.
	Check if the paper feed clutch malfunctions.	Run maintenance item U032 and select the paper feed clutch to be turned on and off. Check the status and remedy if necessary.

*1: Optional. *2: Optional for 16 ppm model. Standard for 20 ppm model.

Problem	Causes/check procedures	Corrective measures
(10) A paper jam in the paper conveying section is indicated during copying (multiple sheets in the drawer 1). Jam code 21	Electrical problem with the paper feed clutch.	Check (see page 1-5-35).
	Check if the right and left registration rollers contact each other.	Check visually and remedy if necessary.
(11) A paper jam in the paper conveying section is indicated during copying (multiple sheets in the drawer 2). Jam code 22	Deformed guides along the paper conveying path.	Repair or replace if necessary.
	Broken registration switch actuator.	Check visually and replace registration switch if its actuator is broken.
	Defective registration switch.	Run maintenance item U031 and turn registration switch on and off manually. Replace registration switch if indication of the corresponding switch is not light.
	Check if the drawer paper feed clutch 1*2 malfunctions.	Run maintenance item U032 and select the drawer paper feed clutch 1 to be turned on and off. Check the status and remedy if necessary.
	Electrical problem with the drawer paper feed clutch 1*2.	Check.
	Check if the right and left registration rollers contact each other.	Check visually and remedy if necessary.
(12) A paper jam in the paper conveying section is indicated during copying (multiple sheets in the drawer 3). Jam code 23	Deformed guides along the paper conveying path.	Repair or replace if necessary.
	Broken drawer feed switch 1*2 actuator.	Check visually and replace drawer feed switch 1 if its actuator is broken.
	Defective drawer feed switch 1*2.	Run maintenance item U031 and turn drawer feed switch 1 on and off manually. Replace drawer feed switch 1 if indication of the corresponding switch is not light.
	Check if the drawer paper feed clutch 2*1 malfunctions.	Run maintenance item U032 and select the drawer paper feed clutch 2 to be turned on and off. Check the status and remedy if necessary.
	Electrical problem with the drawer paper feed clutch 2*1.	Check.
(13) A paper jam in the paper conveying section is indicated during copying (multiple sheets in the drawer 4). Jam code 24	Deformed guides along the paper conveying path.	Repair or replace if necessary.
	Broken drawer feed switch 2*1 actuator.	Check visually and replace drawer feed switch 2 if its actuator is broken.
	Defective drawer feed switch 2*1.	Run maintenance item U031 and turn drawer feed switch 2 on and off manually. Replace drawer feed switch 2 if indication of the corresponding switch is not light.
	Check if the drawer paper feed clutch 3*1 malfunctions.	Run maintenance item U032 and select the drawer paper feed clutch 3 to be turned on and off. Check the status and remedy if necessary.
	Electrical problem with the drawer paper feed clutch 3*1.	Check.

*1: Optional. *2: Optional for 16 ppm model. Standard for 20 ppm model.

Problem	Causes/check procedures	Corrective measures
(14) A paper jam in the transfer section is indicated during copying (misfeed in registration/transfer section). Jam code 30	Deformed guides along the paper conveying path.	Repair or replace if necessary.
	Broken registration switch actuator.	Check visually and replace registration switch if its actuator is broken.
	Defective registration switch.	Run maintenance item U031 and turn registration switch on and off manually. Replace registration switch if indication of the corresponding switch is not light.
	Broken drawer feed switch 1*2 actuator.	Check visually and replace drawer feed switch 1 if its actuator is broken.
	Defective drawer feed switch 1*2.	Run maintenance item U031 and turn drawer feed switch 1 on and off manually. Replace drawer feed switch 1 if indication of the corresponding switch is not light.
	Broken duplex paper conveying switch*1 actuator.	Check visually and replace the duplex paper conveying switch if its actuator is broken.
	Defective duplex paper conveying switch*1.	Run maintenance item U031 and turn duplex paper conveying switch on and off manually. Replace duplex paper conveying switch if indication of the corresponding switch is not light.
(15) A paper jam in the fixing section is indicated during copying (misfeed in the fixing section). Jam code 40, 41, 42, 43, 44, 45	Check if the fixing unit front guide is deformed.	Repair or replace if necessary.
	Check if the press roller is extremely dirty or deformed.	Clean or replace if necessary.
	Check if the heat roller separation claws are dirty or deformed.	Clean or replace if necessary.
	Check if the heat roller and its separation claws contact each other.	Remedy if the separation claw springs are out of place.
	Broken exit switch actuator.	Check visually and replace the exit switch if its actuator is broken.
	Defective exit switch.	Run maintenance item U031 and turn exit switch on and off manually. Replace exit switch if indication of the corresponding switch is not light.
	Check if the registration motor malfunctions.	Run maintenance item U030 and select the registration motor to be turned on and off. Check the status and remedy if necessary.
	Electrical problem with the registration motor.	Check (see page 1-5-34).
(16) A paper jam in the exit section is indicated during copying (misfeed in the exit section). Jam code 50	Broken registration switch actuator.	Check visually and replace registration switch if its actuator is broken.
	Defective registration switch.	Run maintenance item U031 and turn registration switch on and off manually. Replace registration switch if indication of the corresponding switch is not light.
	Broken exit switch actuator.	Check visually and replace the exit switch if its actuator is broken.
	Defective exit switch.	Run maintenance item U031 and turn exit switch on and off manually. Replace exit switch if indication of the corresponding switch is not light.

*1: Optional. *2: Optional for 16 ppm model. Standard for 20 ppm model.

Problem	Causes/check procedures	Corrective measures
(16) A paper jam in the exit section is indicated during copying (misfeed in the exit section). Jam code 50	Check if the registration motor malfunctions.	Run maintenance item U030 and select the registration motor to be turned on and off. Check the status and remedy if necessary.
	Electrical problem with the registration motor.	Check (see page 1-5-34).
(17) A paper jam in the exit section is indicated during copying (misfeed in the job separator). Jam code 51	Broken feedshift switch actuator.	Check visually and replace the feedshift switch if its actuator is broken.
	Defective feedshift switch.	Run maintenance item U031 and turn feedshift switch on and off manually. Replace feedshift switch if indication of the corresponding switch is not light.
	Broken Job separator eject switch*1 actuator.	Check visually and replace the Job separator eject switch if its actuator is broken.
	Defective Job separator eject switch*1.	Run maintenance item U031 and turn Job separator eject switch on and off manually. Replace Job separator eject switch if indication of the corresponding switch is not light.
(18) A paper jam in the feedshift section is indicated during copying (misfeed in the feedshift section). Jam code 52, 53, 54, 55, 56, 57	Broken feedshift switch actuator.	Check visually and replace the feedshift switch if its actuator is broken.
	Defective feedshift switch.	Run maintenance item U031 and turn feedshift switch on and off manually. Replace feedshift switch if indication of the corresponding switch is not light.
	Check if the exit motor malfunctions.	Run maintenance item U030 and select the exit motor to be turned on and off. Check the status and remedy if necessary.
	Electrical problem with the exit motor.	Check (see page 1-5-34).
(19) A paper jam in the duplex section is indicated during copying (misfeed in duplex paper conveying section). Jam code 60	Broken feedshift switch actuator.	Check visually and replace the feedshift switch if its actuator is broken.
	Defective feedshift switch.	Run maintenance item U031 and turn feedshift switch on and off manually. Replace feedshift switch if indication of the corresponding switch is not light.
	Broken duplex paper conveying switch*1 actuator.	Check visually and replace the duplex paper conveying switch if its actuator is broken.
	Defective duplex paper conveying switch*1.	Run maintenance item U031 and turn duplex paper conveying switch on and off manually. Replace duplex paper conveying switch if indication of the corresponding switch is not light.
	Check if the exit motor malfunctions.	Run maintenance item U030 and select the exit motor to be turned on and off. Check the status and remedy if necessary.
	Electrical problem with the exit motor.	Check (see page 1-5-34).
	Check if the duplex feed clutch*1 malfunctions.	Check visually and remedy if necessary.
	Electrical problem with the duplex feed clutch*1.	Check.

Problem	Causes/check procedures	Corrective measures
(20) A paper jam in the duplex section is indicated during copying (misfeed in duplex paper conveying section). Jam code 61	Broken duplex paper conveying switch*1 actuator.	Check visually and replace the duplex paper conveying switch if its actuator is broken.
	Defective duplex paper conveying switch*1.	Run maintenance item U031 and turn duplex paper conveying switch on and off manually. Replace duplex paper conveying switch if indication of the corresponding switch is not light.
	Broken registration switch actuator.	Check visually and replace the registration switch if its actuator is broken.
	Defective registration switch.	Run maintenance item U031 and turn registration switch on and off manually. Replace registration switch if indication of the corresponding switch is not light.
	Check if the duplex feed clutch*1 malfunctions.	Check visually and remedy if necessary.
	Electrical problem with the duplex feed clutch*1.	Check.
(21) An original jams when the power switch is turned on.	A piece of paper torn from an original is caught around the DP timing switch*1 or original switchback switch*1.	Check visually and remove it, if any.
	Defective DP timing switch*1.	Run maintenance item U244 and turn DP timing switch on and off manually. Replace DP timing switch if indication of the corresponding switch is not light.
	Defective original switchback switch*1.	Run maintenance item U244 and turn original switchback switch on and off manually. Replace original switchback switch if indication of the corresponding switch is not light.
(22) An original jams in the original feed section is indicated during copying (no original feed). Jam code 70	Defective original set switch*1.	Run maintenance item U244 and turn original set switch on and off manually. Replace original set switch if indication of the corresponding switch is not light.
	Check if the original feed motor*1 malfunctions.	Run maintenance item U243 and select the original feed motor to be turned on and off. Check the status and remedy if necessary.
	Check if the DP paper feed pulley or DP separation pad is deformed.	Check visually and replace the deformed pulley.
(23) An original jams in the original conveying section is indicated during copying (An original jam in the original conveying section 1). Jam code 71	Broken DP timing switch*1 actuator.	Check visually and replace DP timing switch if its actuator is broken.
	Defective DP timing switch*1.	Run maintenance item U244 and turn DP timing switch on and off manually. Replace DP timing switch if indication of the corresponding switch is not light.
	Check if the original conveying motor*1 malfunctions.	Run maintenance item U243 and select the original conveying motor to be turned on and off. Check the status and remedy if necessary.

Problem	Causes/check procedures	Corrective measures
(24) An original jams in the original conveying section is indicated during copying (An original size error jam). Jam code 72	Broken DP timing switch* ¹ actuator.	Check visually and replace DP timing switch if its actuator is broken.
	Defective DP timing switch* ¹ .	Run maintenance item U244 and turn DP timing switch on and off manually. Replace DP timing switch if indication of the corresponding switch is not light.
	Check if the original conveying motor* ¹ malfunctions.	Run maintenance item U243 and select the original conveying motor to be turned on and off. Check the status and remedy if necessary.
(25) An original jams in the original conveying section is indicated during copying (An original jam in the original conveying section 2). Jam code 73	Broken DP timing switch* ¹ actuator.	Check visually and replace DP timing switch if its actuator is broken.
	Defective DP timing switch* ¹ .	Run maintenance item U244 and turn DP timing switch on and off manually. Replace DP timing switch if indication of the corresponding switch is not light.
	Check if the original conveying motor* ¹ malfunctions.	Run maintenance item U243 and select the original conveying motor to be turned on and off. Check the status and remedy if necessary.
	Check if the switchback feedshift solenoid* ¹ malfunctions.	Run maintenance item U243 and select the switchback feedshift solenoid to be turned on and off. Check the status and remedy if necessary.
(26) An original jams in the original conveying section is indicated during copying (An original jam in the original conveying section 3). Jam code 74	Broken DP timing switch* ¹ actuator.	Check visually and replace DP timing switch if its actuator is broken.
	Defective DP timing switch* ¹ .	Run maintenance item U244 and turn DP timing switch on and off manually. Replace DP timing switch if indication of the corresponding switch is not light.
	Check if the original conveying motor* ¹ malfunctions.	Run maintenance item U243 and select the original conveying motor to be turned on and off. Check the status and remedy if necessary.
	Check if the switchback feedshift solenoid malfunctions* ¹ .	Run maintenance item U243 and select the switchback feedshift solenoid to be turned on and off. Check the status and remedy if necessary.
(27) An original jams in the original switchback section is indicated during copying (An original jam in the original switchback section). Jam code 75	Defective original switchback switch* ¹ .	Run maintenance item U244 and turn original switchback switch on and off manually. Replace original switchback switch if indication of the corresponding switch is not light.
	Check if the original conveying motor* ¹ malfunctions.	Run maintenance item U243 and select the original conveying motor to be turned on and off. Check the status and remedy if necessary.
	Check if the switchback feedshift solenoid* ¹ malfunctions.	Run maintenance item U243 and select the switchback feedshift solenoid to be turned on and off. Check the status and remedy if necessary.
(28) Original jams frequently.	An original outside the specifications is used.	Use only originals conforming to the specifications.
	The DP forwarding pulley or DP paper feed pulley is dirty with paper powder.	Clean with isopropyl alcohol.
	The DP paper feed pulley and DP separation pad do not contact correctly.	Check and remedy.

*1: Optional. *2: Optional for 16 ppm model. Standard for 20 ppm model.

Problem	Causes/check procedures	Corrective measures
(29) A paper jam in the finisher*1 is indicated during copying (Intake jam). Jam code 81	Defective paper conveying switch*1.	With 5 V DC present at CN4-9 on the finisher main PCB, check if CN4-10 on the finisher main PCB remains high or low when the paper conveying switch is turned on and off. If it does, replace the paper conveying switch.
	Check if the feedshift roller or feedshift pulley is deformed.	Check visually and replace the pulley or roller if deformed.
(30) A paper jam in the finisher*1 is indicated during copying (jam during paper conveying for batch ejection 1). Jam code 83	Defective paper conveying switch*1.	With 5 V DC present at CN4-9 on the finisher main PCB, check if CN4-10 on the finisher main PCB remains high or low when the paper conveying switch is turned on and off. If it does, replace the paper conveying switch.
	Check if the feedshift roller or press roller is deformed.	Check visually and replace the pulley or roller if deformed.
(31) A paper jam in the finisher*1 is indicated during copying (jam during paper conveying for batch ejection 2). Jam code 84	Defective paper conveying switch*1.	With 5 V DC present at CN4-9 on the finisher main PCB, check if CN4-10 on the finisher main PCB remains high or low when the paper conveying switch is turned on and off. If it does, replace the paper conveying switch.
	Check if the eject roller or eject pulley is deformed.	Check visually and replace the pulley or roller if deformed.

1-5-2 Self-diagnosis

(1) Self-diagnostic function

This unit is equipped with a self-diagnostic function. When a problem is detected, copying is disabled. "C" and a number between 0030 and 8210 alternates, indicating the nature of the problem.

A message is also displayed requesting the user to call for service.

After removing the problem, the self-diagnostic function can be reset by power switch turns off and on.

• List of system errors

When an unexpected error is detected for some reason, a system error will be indicated. After a system error is indicated, the error can be cleared by turning the main switch off and then on. If the error is detected continuously, however, perform the operation shown in Table 1-5-1. If a system error occurs frequently, a fault may have occurred. Check the details of the C call to take proper measures.

System error	Contents	Operation
0210	Communication problem between the main PCB and engine PCB	System error → Normal C call processing
0250	Scanner network board* ¹ communication problem	System error → Normal C call processing
0410	DP* ¹ communication problem	System error → Normal C call processing
0420	First paper feeder* ² communication problem	System error → Normal C call processing
0440	Finisher* ¹ communication problem	System error
0500	Second paper feeder* ¹ communication problem	System error → Normal C call processing
0510	Third paper feeder* ¹ communication problem	System error → Normal C call processing
0630	DMA problem	System error → Normal C call processing
3100	Scanner carriage problem	System error → Normal C call processing

*1: Optional. *2: Optional for 16 ppm model. Standard for 20 ppm model.

Table 1-5-1 List of system errors

• Partial operation control

If any of the following calls for service is detected, partial operation control will be activated. After taking measures against the cause of trouble, run maintenance item U906 to reset partial operation control.

Display	Contents
C8170	Finisher* ¹ front side registration motor problem
C8180	Finisher* ¹ rear side registration motor problem
C8190	Finisher* ¹ trailing edge registration motor problem
C8210	Finisher* ¹ front stapler problem

*1: Optional.

(2) Self diagnostic codes

Code	Contents	Remarks	
		Causes	Check procedures/corrective measures
C0030	Fax control PCB*¹ system problem <ul style="list-style-type: none"> Processing with the fax software was disabled due to a hardware or software problem. 	Defective fax control PCB.	Replace the fax control PCB and check for correct operation.
C0070	Fax control PCB*¹ incompatibility detection problem <ul style="list-style-type: none"> Fax software is not compatible with MMI software. 	Fax software or main software is something of the other machine.	Check the version of the Fax software and the main software, upgrade the version to the compatible software.
C0100	Backup memory read/write problem (main PCB flash) <ul style="list-style-type: none"> Read and write data does not match. 	Defective main PCB.	Replace the main PCB and check for correct operation.
C0110	Backup memory data problem (main PCB flash) <ul style="list-style-type: none"> Data in the specified area of the backup memory does not match the specified values. 	Problem with the backup memory data.	Turn safety switch off and back on and run maintenance item U020 to set the contents of the backup memory data again.
		Defective backup RAM.	If the C0110 is displayed after re-setting the backup memory contents, replace the main PCB.
C0130	Backup memory read/write problem (main PCB EEPROM) <ul style="list-style-type: none"> Read and write data does not match. 	Defective EEPROM or main PCB.	Replace the main PCB and check for correct operation.
C0140	Backup memory data problem (main PCB EEPROM) <ul style="list-style-type: none"> Data in the specified area of the backup memory does not match the specified values. 	Problem with the backup memory data.	Turn safety switch off and back on and run maintenance item U020 to set the contents of the backup memory data again.
		Defective EEPROM.	If the C0140 is displayed after re-setting the backup memory contents, replace the EEPROM or main PCB.
C0150	Backup memory read/write problem (engine PCB) <ul style="list-style-type: none"> Read and write data does not match. 	Defective engine PCB.	Replace the engine PCB and check for correct operation.
C0160	Backup memory data problem (engine PCB) <ul style="list-style-type: none"> Data in the specified area of the backup memory does not match the specified values. 	Problem with the backup memory data.	Turn safety switch off and back on and run maintenance item U020 to set the contents of the backup memory data again.
		Defective backup RAM.	If the C0160 is displayed after re-setting the backup memory contents, replace the engine PCB.
C0170	Accounting count problem <ul style="list-style-type: none"> When the power is turned on, the total count and the scan count are abnormal both on the main PCB and the engine PCB. 	Defective main PCB or engine PCB.	Replace the main PCB or engine PCB and check for correct operation.
C0180	Machine number mismatch <ul style="list-style-type: none"> When the power is turned on, the machine number does not match between the main PCB and the engine PCB. 	Correct EEPROM is not installed.	Install the correct EEPROM. If it does not solve the problem, contact the Service Administrative Division.
		Data damage of EEPROM.	Contact the Service Administrative Division.

*1: Optional. *2: Optional for 16 ppm model. Standard for 20 ppm model.

Code	Contents	Remarks	
		Causes	Check procedures/corrective measures
C0210	Communication problem between the main PCB and engine PCB <ul style="list-style-type: none"> When the power is turned on, the machine does not detect the low level of SBSY and the high level of SDIR for 10 s. 	Poor contact in the connector terminals.	Check the connection of connector. Repair or replace if necessary.
		Defective main PCB or engine PCB.	Replace the main PCB or engine PCB and check for correct operation.
C0240	Printer board PCB communication problem <ul style="list-style-type: none"> The printer board PCB does not respond 120 s after the power is turned on. 	Poor contact in the connector terminals.	Check the connection of connector. Repair or replace if necessary.
		Defective main PCB or printer board PCB.	Replace the main PCB or printer board PCB and check for correct operation.
C0250	Scanner network board*¹ communication problem <ul style="list-style-type: none"> The scanner network board does not respond. 	Poor contact in the connector terminals.	Check the connection of connector. Repair or replace if necessary.
		Defective main PCB or scanner network board.	Replace the main PCB or scanner network board and check for correct operation.
C0280	Fax control PCB*¹ communication problem <ul style="list-style-type: none"> Communication between the fax control PCB and the main PCB of the machine cannot be performed normally. 	Poor contact in the connector terminals.	Check the connection of connector. Repair or replace if necessary.
		Defective main PCB or fax control PCB.	Replace the main PCB or fax control PCB and check for correct operation.
C0410	DP*¹ communication problem <ul style="list-style-type: none"> Communication fails five times successively. 	DP installed incorrectly.	Check the installation state of the DP and adjust it if it is not properly installed.
		Defective engine PCB or DP driver PCB.	Replace the engine PCB or DP driver PCB and check for correct operation.
C0420	First paper feeder*² communication problem <ul style="list-style-type: none"> Communication fails five times successively. 	Paper feeder installed incorrectly.	Check the installation state of the paper feeder and adjust it if it is not properly installed.
		Defective engine PCB or drawer main PCB.	Replace the engine PCB or drawer main PCB and check for correct operation.
C0440	Finisher*¹ communication problem <ul style="list-style-type: none"> Communication fails five times successively. 	Finisher installed incorrectly.	Check the installation state of the finisher and adjust it if it is not properly installed.
		Defective engine PCB or finisher main PCB.	Replace the engine PCB or finisher main PCB and check for correct operation.
C0500	Second paper feeder*¹ communication problem <ul style="list-style-type: none"> Communication fails five times successively. 	Paper feeder installed incorrectly.	Check the installation state of the paper feeder and adjust it if it is not properly installed.
		Defective engine PCB or drawer main PCB.	Replace the engine PCB or drawer main PCB and check for correct operation.

*1: Optional. *2: Optional for 16 ppm model. Standard for 20 ppm model.

Code	Contents	Remarks	
		Causes	Check procedures/corrective measures
C0510	Third paper feeder*1 communication problem <ul style="list-style-type: none"> Communication fails five times successively. 	Paper feeder installed incorrectly.	Check the installation state of the paper feeder and adjust it if it is not properly installed.
		Defective engine PCB or drawer main PCB.	Replace the engine PCB or drawer main PCB and check for correct operation.
C0610	Bitmap (DIMM) problem <ul style="list-style-type: none"> There is a problem with the data or address bus of the bitmap DRAM. 	Defective main PCB.	Replace the main PCB and check for correct operation.
		DIMM installed incorrectly.	Check if the DIMM is inserted into the socket on the main PCB correctly.
		Defective DIMM.	Replace the DIMM and check for correct operation.
C0630	DMA problem <ul style="list-style-type: none"> DMA transmission of compressed, decompressed, rotated, relocated or blanked-out image data does not complete within the specified period of time. 	Defective main PCB.	Replace the main PCB and check for correct operation.
C0800	Image processing problem <ul style="list-style-type: none"> JAM05 is detected twice. 	Defective main PCB.	Replace the main PCB and check for correct operation.
C0820	Fax control PCB*1 CG ROM checksum error <ul style="list-style-type: none"> A checksum error occurred with the CG ROM data of the fax control PCB. 	Defective fax control PCB.	Replace the fax control PCB and check for correct operation.
C0830	Flash ROM program area checksum error <ul style="list-style-type: none"> A checksum error occurred with the program of the fax control PCB. 	Defective fax control PCB.	Replace the fax control PCB and check for correct operation.
C0860	Fax control PCB*1 software switch checksum error <ul style="list-style-type: none"> A checksum error occurred with the software switch value of the fax control PCB. 	Defective fax software.	Install the fax software to Ver. 2.xx or later.
		Defective fax control PCB.	Replace the fax control PCB and check for correct operation.
C0870	Fax control PCB*1 to main PCB high-capacity data transfer problem <ul style="list-style-type: none"> High-capacity data transfer between the fax control PCB and the main PCB of the machine was not normally performed even if the data transfer was retried the specified times. 	Poor contact in the connector terminals.	Check the connection of connector. Repair or replace if necessary.
		Defective main PCB or fax control PCB.	Replace the main PCB or fax control PCB and check for correct operation.
C0880	Fax control PCB*1 program archive problem <ul style="list-style-type: none"> When power is turned on, the compressed program in the Flash ROM on the fax control PCB was not successfully decompressed. 	Defective fax control PCB.	Replace the fax control PCB and check for correct operation.

*1: Optional. *2: Optional for 16 ppm model. Standard for 20 ppm model.

Code	Contents	Remarks	
		Causes	Check procedures/corrective measures
C0890	Fax control PCB*¹ CG font archive problem <ul style="list-style-type: none"> When power is turned on, the compressed CG font in the Flash ROM on the fax control PCB was not successfully decompressed. 	Defective fax control PCB.	Replace the fax control PCB and check for correct operation.
C0900	Fax software incompatibility detection problem <ul style="list-style-type: none"> Version of fax software is not compatible with that of main software. 	Fax software version or main software is earlier.	Check the version of the fax software and the main software, upgrade the version to the compatible software.
C0920	Fax file system error <ul style="list-style-type: none"> The backup data is not retained for file system abnormality of flash memory of the fax control PCB. 	Defective fax control PCB.	Replace the fax control PCB and check for correct operation.
C2000	Drive motor problem <ul style="list-style-type: none"> LOCK ALM signal remains high for 1 s, 1 s after the drive motor has turned on. 	Poor contact in the drive motor connector terminals.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable.
		Defective drive motor rotation control circuit.	Replace the drive motor.
		Defective drive transmission system.	Check if the rollers and gears rotate smoothly. If not, grease the bushings and gears. Check for broken gears and replace if any.
C3100	Scanner carriage problem <ul style="list-style-type: none"> The home position is not correct when the power is turned on or copying the document placed on the contact glass. 	Poor contact of the connector terminals.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable.
		Defective scanner home position switch.	Replace the scanner home position switch.
		Defective engine PCB.	Replace the engine PCB and check for correct operation.
		Defective scanner motor.	Replace the scanner motor.
C3200	Exposure lamp problem <ul style="list-style-type: none"> Non-lighting of the exposure lamp is detected at the beginning of copying. 	Poor contact of the connector terminals.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable.
		Defective exposure lamp or inverter PCB.	Replace the exposure lamp or inverter PCB.
		Defective engine PCB.	Replace the engine PCB and check for correct operation.
		Incorrect shading position.	Adjust the position of the contact glass (shading plate). If the problem still occurs, replace the scanner home position switch.

*1: Optional. *2: Optional for 16 ppm model. Standard for 20 ppm model.

Code	Contents	Remarks	
		Causes	Check procedures/corrective measures
C3300	Optical system (AGC) problem <ul style="list-style-type: none"> After AGC, correct input is not obtained at CCD. 	Insufficient exposure lamp luminosity.	Replace the exposure lamp or inverter PCB.
		Defective engine PCB.	Replace the engine PCB and check for correct operation.
		Incorrect shading position.	Adjust the position of the contact glass (shading plate). If the problem still occurs, replace the scanner home position switch.
		Defective CCD PCB.	Replace the ISU.
C4000	Polygon motor synchronization problem <ul style="list-style-type: none"> The polygon motor does not reach the stable speed within 15 s of the START signal turning on. 	Poor contact in the polygon motor connector terminals.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable.
		Defective polygon motor.	Replace the LSU.
		Defective engine PCB.	Replace the engine PCB and check for correct operation.
C4010	Polygon motor steady-state problem <ul style="list-style-type: none"> The polygon motor rotation is not stable for 5 s after the polygon motor rotation has been stabilized. 	Poor contact in the polygon motor connector terminals.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable.
		Defective polygon motor.	Replace the LSU.
		Defective engine PCB.	Replace the engine PCB and check for correct operation.
C4200	BD steady-state problem <ul style="list-style-type: none"> The MIP detects a BD error for 600 ms after the polygon motor rotation has been stabilized. 	Defective laser diode.	Replace the LSU.
		Defective polygon motor.	Replace the LSU.
		Defective main PCB.	Replace the main PCB and check for correct operation.
		Defective engine PCB.	Replace the engine PCB and check for correct operation.
C6000	Broken fixing heater wire <ul style="list-style-type: none"> In fixing warm-up, the time to reach 50°C/122 °F exceeds 13.5 s, the time to reach 100°C/212 °F exceeds 10 s, the time to reach the primary stabilization exceeds 10 s or the time to reach the secondary stabilization exceeds 24 s. 	Poor contact in the thermistor connector terminals.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable.
		Fixing thermistor installed incorrectly.	Check and reinstall if necessary.
		Fixing thermostat triggered.	Check for continuity. If none, replace the fixing thermostat.


Code	Contents	Remarks	
		Causes	Check procedures/corrective measures
C6000	Broken fixing heater wire <ul style="list-style-type: none"> In fixing warm-up, the time to reach 50°C/122 °F exceeds 13.5 s, the time to reach 100°C/212 °F exceeds 10 s, the time to reach the primary stabilization exceeds 10 s or the time to reach the secondary stabilization exceeds 24 s. 	Fixing heater M or S installed incorrectly.	Check and reinstall if necessary.
		Broken fixing heater M or S wire.	Check for continuity. If none, replace the fixing heater M or S.
C6020	Abnormally high fixing unit thermistor temperature <ul style="list-style-type: none"> The fixing temperature exceeds 230°C/446 °F for 40 ms. 	Shorted thermistor.	Measure the resistance. If it is 0 Ω, replace the thermistor.
		Broken heater control circuit on the power supply PCB.	Replace the power supply PCB and check for correct operation.
C6050	Abnormally low fixing unit thermistor temperature <ul style="list-style-type: none"> The fixing temperature remains below 90°C/194°F for 1 s. 	Poor contact in the thermistor connector terminals.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable.
		Broken fixing thermistor wire.	Measure the resistance. If it is ∞ Ω, replace the fixing thermistor.
		Fixing thermistor installed incorrectly.	Check and reinstall if necessary.
		Fixing thermostat triggered.	Check for continuity. If none, replace the fixing thermostat.
		Fixing heater M or S installed incorrectly.	Check and reinstall if necessary.
		Broken fixing heater M or S wire.	Check for continuity. If none, replace the fixing heater M or S.
C6400	Zero-crossing signal problem <ul style="list-style-type: none"> The engine PCB does not detect the zero-crossing signal for the time specified below. At power-on: 3 s Others: 5 s 	Poor contact in the connector terminals.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable.
		Defective power supply PCB.	Check if the zero-crossing signal is output from YC2-5 on the power supply PCB. If not, replace the power supply PCB.
		Defective engine PCB.	Replace the engine PCB if C6400 is detected while YC2-5 on the power supply PCB outputs the zero-crossing signal.
C7800	Broken external temperature thermistor <ul style="list-style-type: none"> The input voltage is 0.5 V or less. 	Poor contact in the humidity sensor connector terminals.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable.
		Defective humidity sensor.	Replace the drawer PCB and check for correct operation.

Code	Contents	Remarks	
		Causes	Check procedures/corrective measures
C7810	Short-circuited external temperature thermistor <ul style="list-style-type: none"> The input voltage is 4.5 V or more. 	Poor contact in the humidity sensor connector terminals.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable.
		Defective humidity sensor.	Replace the drawer PCB and check for correct operation.
C8170	Finisher*1 front side registration motor problem <ul style="list-style-type: none"> If the front side registration home position sensor is on in initialization, the sensor does not turn off within 570 ms of starting initialization. If the front side registration home position sensor is off in initialization, the sensor does not turn on within 3180 ms of starting initialization. 	The front side registration motor connector makes poor contact.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable.
		The front side registration motor malfunctions.	Replace the front side registration motor and check for correct operation.
		The front side registration home position sensor connector makes poor contact.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable.
		The front side registration home position sensor malfunctions.	Replace the front side registration home position sensor and check for correct operation.
		Defective finisher main PCB.	Replace the finisher main PCB and check for correct operation.
C8180	Finisher*1 rear side registration motor problem <ul style="list-style-type: none"> If the rear side registration home position sensor is on in initialization, the sensor does not turn off within 570 ms of starting initialization. If the rear side registration home position sensor is off in initialization, the sensor does not turn on within 2880 ms of starting initialization. 	The rear side registration motor connector makes poor contact.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable.
		The rear side registration motor malfunctions.	Replace the rear side registration motor and check for correct operation.
		The rear side registration home position sensor connector makes poor contact.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable.
		The rear side registration home position sensor malfunctions.	Replace the rear side registration home position sensor and check for correct operation.
		Defective finisher main PCB.	Replace the finisher main PCB and check for correct operation.

Code	Contents	Remarks	
		Causes	Check procedures/corrective measures
C8170	Finisher*¹ trailing edge registration motor problem <ul style="list-style-type: none"> • If the trailing edge registration home position sensor is on in initialization, the sensor does not turn off within 570 ms of starting initialization. • If the trailing edge registration home position sensor is off in initialization, the sensor does not turn on within 4550 ms of starting initialization. 	The trailing edge registration motor connector makes poor contact.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable.
		The trailing edge registration motor malfunctions.	Replace the trailing edge registration motor and check for correct operation.
		The trailing edge registration home position sensor connector makes poor contact.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable.
		The trailing edge registration home position sensor malfunctions.	Replace the trailing edge registration home position sensor and check for correct operation.
		Defective finisher main PCB.	Replace the finisher main PCB and check for correct operation.
C8180	Finisher*¹ front stapler problem <ul style="list-style-type: none"> • The front stapler home position sensor does not change state from non-detection to detection within 200 ms of the start of front stapler motor counterclockwise (forward) rotation. • During initialization, the front stapler home position sensor does not change state from non-detection to detection within 600 ms of the start of front stapler motor clockwise (reverse) rotation. 	The front stapler connector makes poor contact.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable.
		The front stapler malfunctions. <ul style="list-style-type: none"> a) The front stapler is blocked with a staple. b) The front stapler is broken. 	<ul style="list-style-type: none"> a) Remove the front stapler cartridge, and check the cartridge and the stapling section of the stapler. b) Replace the front stapler and check for correct operation.
		Defective finisher main PCB.	Replace the finisher main PCB and check for correct operation.

1-5-3 Image formation problems

(1) No image appears (entirely white).



See page 1-5-27

(2) No image appears (entirely black).




See page 1-5-27

(3) Image is too light.



See page 1-5-28

(4) Background is visible.




See page 1-5-28

(5) A white line appears longitudinally.




See page 1-5-28

(6) A black line appears longitudinally.




See page 1-5-29

(7) A black line appears laterally.




See page 1-5-29

(8) One side of the copy image is darker than the other.



See page 1-5-29

(9) Black dots appear on the image.




See page 1-5-30

(10) Image is blurred.




See page 1-5-30

(11) The leading edge of the image is consistently misaligned with the original.




See page 1-5-30

(12) The leading edge of the image is sporadically misaligned with the original.




See page 1-5-31

(13) Paper creases.



See page 1-5-31

(14) Offset occurs.




See page 1-5-31

(15) Image is partly missing.



See page 1-5-32

(16) Fixing is poor.



See page 1-5-32

(17) Image is out of focus.




See page 1-5-32

(18) Image center does not align with the original center.



See page 1-5-33

- (1) No image appears
(entirely white).

**Causes**

1. No transfer charging.
2. No LSU laser is output.
3. No developing bias is output.

Causes	Check procedures/corrective measures
1. No transfer charging.	
A. The connector terminals of the high-voltage PCB make poor contact.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable.
B. Defective engine PCB.	Replace the engine PCB and check for correct operation.
C. Defective high-voltage PCB.	Replace the high voltage PCB and check for correct operation.
2. No LSU laser is output.	
A. Defective laser scanner unit.	Replace the laser scanner unit (see page 1-6-29).
B. Defective main PCB.	Replace the main PCB and check for correct operation.
3. No developing bias is output.	
A. The connector terminals of the high-voltage PCB make poor contact.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable.
B. Defective engine PCB.	Replace the engine PCB and check for correct operation.
C. Defective high-voltage PCB.	Replace the high voltage PCB and check for correct operation.

- (2) No image appears
(entirely black).

**Causes**

1. No main charging.
2. Exposure lamp fails to light.

Causes	Check procedures/corrective measures
1. No main charging.	
A. Broken main charger wire.	Replace the main charger unit (see page 1-6-40).
B. Leaking main charger housing.	Clean the main charger wire, grid and shield.
C. The connector terminals of the high-voltage PCB make poor contact.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable.
D. Defective engine PCB.	Check if YC9-5 on the engine PCB goes low when maintenance item U100 is run. If not, replace the engine PCB.
E. Defective high-voltage PCB.	Check if main charging takes place when YC1-12 on the high-voltage PCB goes low while maintenance item U100 is run. If not, replace the high-voltage PCB.
2. Exposure lamp fails to light.	
A. The connector terminals of the exposure lamp make poor contact.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable.
B. Defective inverter PCB.	Check if the exposure lamp lights when YC1-1 and 1-6 on the inverter PCB go low while maintenance item U061 is run. If not, replace the inverter PCB.
C. Defective engine PCB.	Check if YC17-1 and YC17-6 on the engine PCB goes low when maintenance item U061 is run. If not, replace the engine PCB.

(3) Image is too light.



Causes


1. Insufficient toner.
2. The transfer voltage is not output properly.
3. Dirty main charger wire.
4. Dirty main charger grid.

Causes	Check procedures/corrective measures
1. Insufficient toner.	If the display shows the message requesting toner replenishment, replace the container.
2. The transfer voltage is not output properly.	Clean or check the transfer roller (see page 1-6-42).
3. Dirty main charger wire.	Clean the main charger wire or, if it is extremely dirty, replace the main charger unit (see page 1-6-40).
4. Dirty main charger grid.	Clean the main charger grid or, if it is extremely dirty, replace the main charger unit (see page 1-6-40).

(4) Background is visible.

Causes

1. The developing bias voltage is not properly.
2. Dirty main charger wire.



Causes	Check procedures/corrective measures
1. The developing bias voltage is not properly.	Replace the high voltage PCB and check for correct operation.
2. Dirty main charger wire.	Clean the main charger wire or, if it is extremely dirty, replace the main charger unit (see page 1-6-40).

(5) A white line appears longitudinally.

Causes


1. Dirty main charger wire.
2. Foreign matter in the developing unit.
3. Dirty shading plate.



Causes	Check procedures/corrective measures
1. Dirty main charger wire.	Clean the main charger wire or, if it is extremely dirty, replace the main charger unit (see page 1-6-40).
2. Foreign matter in the developing unit.	Check if the magnetic brush is formed uniformly. Replace the developing unit if any foreign matter (see page 1-6-41).
3. Dirty shading plate.	Clean the shading plate.



(6) A black line appears longitudinally.




Causes

1. Dirty contact glass.
2. Dirty or flawed drum.
3. Dirty scanner mirror.
4. Dirty main charger wire.

Causes	Check procedures/corrective measures
1. Dirty contact glass.	Clean the contact glass.
2. Dirty or flawed drum.	Clean the drum or, if it is flawed, replace the drum unit (see page 1-6-38).
3. Dirty scanner mirror.	Clean the scanner mirror.
4. Dirty main charger wire.	Clean the main charger wire or, if it is extremely dirty, replace the main charger unit (see page 1-6-40).

(7) A black line appears laterally.




Causes

1. Dirty contact glass.
2. Dirty or flawed drum.
3. Dirty scanner mirror.
4. Dirty shading plate.
5. Leaking main charger housing.

Causes	Check procedures/corrective measures
1. Dirty contact glass.	Clean the contact glass.
2. Dirty or flawed drum.	Clean the drum or, if it is flawed, replace it (see page 1-6-38).
3. Dirty scanner mirror.	Clean the scanner mirror.
4. Dirty shading plate.	Clean the shading plate.
5. Leaking main charger housing.	Clean the main charger wire, grid and shield.

(8) One side of the copy image is darker than the other.




Causes

1. Dirty main charger wire.
2. Defective exposure lamp.

Causes	Check procedures/corrective measures
1. Dirty main charger wire.	Clean the main charger wire or, if it is extremely dirty, replace the main charger unit (see page 1-6-40).
2. Defective exposure lamp.	Check if the exposure lamp light is distributed evenly. If not, replace the exposure lamp and inverter PCB.

(9) Black dots appear on the image.




Causes

1. Dirty or flawed drum.
2. Dirty contact glass.
3. Deformed or worn cleaning blade.
4. Dirty drum separation claws.
5. Dirty heat roller separation claws.

Causes	Check procedures/corrective measures
1. Dirty or flawed drum.	Clean the drum or, if it is flawed, replace the drum unit (see page 1-6-38).
2. Dirty contact glass.	Clean the contact glass.
3. Deformed or worn cleaning blade.	Replace the drum unit (see page 1-6-38).
4. Dirty drum separation claws.	Clean the drum separation claws.
5. Dirty the heat roller separation claws.	Clean the heat roller separation claws.

(10) Image is blurred.



Causes

1. Scanner moves erratically.
2. Deformed press roller.
3. Paper conveying section drive problem.

Causes	Check procedures/corrective measures
1. Scanner moves erratically.	Check if there is any foreign matter on the front and rear scanner rails. If any, remove it.
2. Deformed press roller.	Replace the press roller (see page 1-6-44).
3. Paper conveying section drive problem.	Check the gears and belts and, if necessary, grease them.

(11) The leading edge of the image is consistently misaligned with the original.



Causes

1. Misadjusted leading edge registration.
2. Misadjusted scanner leading edge registration.

Causes	Check procedures/corrective measures
1. Misadjusted leading edge registration.	Readjust the leading edge registration (see pages 1-6-16).
2. Misadjusted scanner leading edge registration.	Readjust the scanner leading edge registration (see page 1-6-35).

(12) The leading edge of the image is sporadically misaligned with the original.

Causes

1. Paper feed clutch, bypass paper feed solenoid or registration motor installed or operating incorrectly.




Causes	Check procedures/corrective measures
1. Paper feed clutch, bypass paper feed solenoid or registration motor installed or operating incorrectly.	Check the installation position and operation of the paper feed clutch, bypass paper feed solenoid and registration motor. If any of them operates incorrectly, replace it.

(13) Paper creases.

Causes

1. Paper curled.
2. Paper damp.
3. Defective pressure springs.
4. Defective separation.
5. Dirty separation electrode.




Causes	Check procedures/corrective measures
1. Paper curled.	Check the paper storage conditions.
2. Paper damp.	Check the paper storage conditions.
3. Defective pressure springs.	Replace the pressure springs.
4. Defective separation.	Check the drum separation claws and heat roller separation claws.
5. Dirty separation electrode.	Clean the separation electrode.

(14) Offset occurs.

Causes

1. Defective cleaning blade.
2. Defective fixing section.



Causes	Check procedures/corrective measures
1. Defective cleaning blade.	Replace the drum unit (see page 1-6-38).
2. Defective fixing section.	Check the heat roller and press roller.

(15) Image is partly missing.




Causes

1. Paper damp.
2. Paper creased.
3. Dirty or flawed drum.
4. Dirty transfer roller.

Causes	Check procedures/corrective measures
1. Paper damp.	Check the paper storage conditions.
2. Paper creased.	Replace the paper.
3. Dirty or flawed drum.	Clean the drum or, if it is flawed, replace the drum unit (see page 1-6-38).
4. Dirty transfer roller.	Clean the transfer roller.

(16) Fixing is poor.



Causes

1. Wrong paper.
2. Defective pressure springs.
3. Flawed press roller.
4. Defective fixing heater.

Causes	Check procedures/corrective measures
1. Wrong paper.	Check if the paper meets specifications.
2. Defective pressure springs.	Replace the pressure springs.
3. Flawed press roller.	Replace the press roller (see page 1-6-44).
4. Defective fixing heater.	Replace the fixing heater (see page 1-6-45).

(17) Image is out of focus.



Causes

1. Defective image scanning unit.
2. Drum condensation.

Causes	Check procedures/corrective measures
1. Defective image scanning unit.	Replace the image scanning unit (see page 1-6-28).
2. Drum condensation.	Clean the drum.

(18) Image center does not align with the original center.

Causes

1. Misadjusted center line of image printing.
2. Misadjusted scanner center line.
3. Original placed incorrectly.



Causes	Check procedures/corrective measures
1. Misadjusted center line of image printing.	Readjust the center line of image printing (see page 1-6-18).
2. Misadjusted scanner center line.	Readjust the scanner center line (see page 1-6-36).
3. Original placed incorrectly.	Place the original correctly.

1-5-4 Electrical problems

Problem	Causes	Check procedures/corrective measures
(1) The machine does not operate when the power switch is turned on.	No electricity at the power outlet.	Measure the input voltage.
	The power cord is not plugged in properly.	Check the contact between the power plug and the outlet.
	The front cover or left cover is not closed completely.	Check the front cover and left cover.
	Broken power cord.	Check for continuity. If none, replace the cord.
	Defective power switch.	Check for continuity across the contacts. If none, replace the power switch.
	Blown fuse in the power source PCB.	Check for continuity. If none, remove the cause of blowing and replace the fuse.
	Defective front or left cover safety switch.	Check for continuity across the contacts of each switch. If none, replace the switch.
	Defective power source PCB.	With AC present, check for 24 V DC at YC1-1 and 5 V DC at YC1-7 on the power source PCB. If none, replace the power source PCB.
(2) The drive motor does not operate (C2000).	Poor contact in the drive motor connector terminals.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable.
	Broken drive motor gear.	Check visually and replace the drive motor if necessary.
	Defective drive motor.	Run maintenance item U030 and check if the drive motor operates when YC7-5 on the engine PCB goes low. If not, replace the drive motor.
	Defective engine PCB.	Run maintenance item U030 and check if YC7-5 on the engine PCB goes low. If not, replace the engine PCB.
(3) The registration motor does not operate.	Poor contact in the registration motor connector terminals.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable.
	Broken registration motor gear.	Check visually and replace the registration motor if necessary.
	Defective registration motor.	Run maintenance item U030 and check if the registration motor operates when YC2-1,2,4,5 on the registration motor PCB goes low. If not, replace the registration motor.
	Defective engine PCB.	Run maintenance item U030 and check if YC4-4 on the engine PCB goes low. If not, replace the engine PCB.
(4) The exit motor does not operate.	Poor contact in the exit motor connector terminals.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable.
	Broken exit motor gear.	Check visually and replace the exit motor if necessary.
	Defective exit motor.	Run maintenance item U030 and check if the exit motor operates when YC14-1,2,3,4 on the engine PCB go low. If not, replace the exit motor.
	Defective engine PCB.	Run maintenance item U030 and check if YC14-1,2,3,4 on the engine PCB go low. If not, replace the engine PCB.

Problem	Causes	Check procedures/corrective measures
(5) The scanner motor does not operate.	Broken scanner motor coil.	Check for continuity across the coil. If none, replace the scanner motor.
	Poor contact in the scanner motor connector terminals.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable.
(6) Cooling fan motor 1 does not operate.	Broken cooling fan motor 1 coil.	Check for continuity across the coil. If none, replace cooling fan motor 1.
	Poor contact in the cooling fan motor 1 connector terminals.	Reinsert the connector. Also check for continuity within the connector cable. If none, repair or replace the cable.
(7) Cooling fan motor 2 does not operate.	Broken cooling fan motor 2 coil.	Check for continuity across the coil. If none, replace cooling fan motor 2.
	Poor contact in the cooling fan motor 2 connector terminals.	Reinsert the connector. Also check for continuity within the connector cable. If none, repair or replace the cable.
(8) Cooling fan motor 3 does not operate.	Broken cooling fan motor 3 coil.	Check for continuity across the coil. If none, replace cooling fan motor 3.
	Poor contact in the cooling fan motor 3 connector terminals.	Reinsert the connector. Also check for continuity within the connector cable. If none, repair or replace the cable.
(9) The drawer drive motor* does not operate.	Poor contact in the drawer drive motor connector terminals.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable.
	Broken drawer drive motor gear.	Check visually and replace the drawer drive motor if necessary.
	Defective drawer drive motor.	Run maintenance item U030 and check if the drawer drive motor operates when YC9-2,3,4,5 on the drawer main PCB goes low. If not, replace the drawer drive motor.
	Defective drawer main PCB.	Run maintenance item U030 and check if YC9-2,3,4,5 on the drawer main PCB goes low. If not, replace the drawer main PCB.
(10) The paper feed clutch does not operate.	Broken paper feed clutch coil.	Check for continuity across the coil. If none, replace the paper feed clutch.
	Poor contact in the paper feed clutch connector terminals.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable.
	Defective engine PCB.	Run maintenance item U032 and check if YC8-3 on the engine PCB goes low. If not, replace the engine PCB.
(11) The bypass paper feed solenoid does not operate.	Broken bypass paper feed solenoid coil.	Check for continuity across the coil. If none, replace the bypass paper feed solenoid.
	Poor contact in the bypass paper feed solenoid connector terminals.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable.
	Defective engine PCB.	Run maintenance item U032 and check if YC8-5 on the engine PCB goes low. If not, replace the engine PCB.

*: 20 ppm model only.

Problem	Causes	Check procedures/corrective measures
(12) The drawer paper feed clutch* does not operate.	Broken drawer paper feed clutch coil.	Check for continuity across the coil. If none, replace the drawer paper feed clutch.
	Poor contact in the drawer paper feed clutch connector terminals.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable.
	Defective drawer main PCB.	Run maintenance item U032 and check if YC8-3 on the drawer main PCB goes low. If not, replace the drawer main PCB.
(13) The cleaning lamp does not turn on.	Poor contact in the cleaning lamp connector terminals.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable.
	Defective cleaning lamp.	Check for continuity. If none, replace the cleaning lamp.
	Defective engine PCB.	If the cleaning lamp turns on when YC3-7,8 on the engine PCB is held low, replace the engine PCB.
(14) The exposure lamp does not turn on.	Poor contact in the exposure lamp connector terminals.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable.
	Defective inverter PCB.	Run maintenance item U061 and check if the exposure lamp turns on with YC1-1 and YC1-6 on the inverter PCB go low. If not, replace the inverter PCB.
	Defective engine PCB.	Run maintenance item U061 and check if YC17-1 and YC17-6 on the engine PCB goes low. If not, replace the engine PCB.
(15) The exposure lamp does not turn off.	Defective inverter PCB.	If the exposure lamp does not turn off with YC1-1 and YC1-6 on the inverter PCB high, replace the inverter PCB.
	Defective engine PCB.	If YC17-1 and YC17-6 on the engine PCB are always low, replace the engine PCB.
(16) The fixing heater does not turn on (C6000).	Broken wire in fixing heater M or S.	Check for continuity across each heater. If none, replace the heater M or S.
	Fixing thermostat triggered.	Check for continuity across thermostat. If none, remove the cause and replace the thermostat.
(17) The fixing heater does not turn off.	Broken fixing thermistor wire.	Measure the resistance. If it is $\infty \Omega$, replace the fixing thermistor.
	Dirty sensor part of the fixing thermistor.	Check visually and clean the thermistor sensor parts.
(18) Main charging is not performed.	Broken main charger wire.	See page 1-5-27.
	Leaking main charger housing.	
	Poor contact in the high-voltage PCB connector terminals.	
	Defective engine PCB.	
	Defective high-voltage PCB.	



*: 20 ppm model only.

Problem	Causes	Check procedures/corrective measures
(19) Transfer charging is not performed.	Poor contact in the high-voltage PCB connector terminals.	See page 1-5-27.
	Defective engine PCB.	
	Defective high-voltage PCB.	
(20) No developing bias is output.	Poor contact in the high-voltage PCB connector terminals.	See page 1-5-27.
	Defective engine PCB.	
	Defective high-voltage PCB.	
(21) The original size is not detected.	Defective original detection switch.	If the level of YC18-5 on the engine PCB does not change when the original detection switch is turned on and off, replace the original detection switch.
(22) The original size is not detected correctly.	Original is not placed correctly.	Check the original and correct if necessary.
	Poor contact in the original size detection sensor connector terminals.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable.
	Defective original size detection sensor.	Check if sensor operates correctly. If not, replace it.
(23) The message requesting paper to be loaded is shown when paper is present in the drawer 1.	Poor contact in the paper switch connector terminals.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable.
	Defective paper switch.	If the level of YC8-2 on the engine PCB does not change when the paper switch is turned on and off, replace the paper switch.
(24) The message requesting paper to be loaded is shown when paper is present in the drawer 2*.	Poor contact in the drawer paper switch connector terminals.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable.
	Defective drawer paper switch.	If the level of YC5-2 on the drawer main PCB does not change when the drawer paper switch is turned on and off, replace the drawer paper switch.
(25) The size of paper in the drawer 1 is not displayed correctly.	Poor contact in the paper length switch connector terminals.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable.
	Defective paper length switch.	Check if YC22-1,2,4 on the engine PCB goes low when the paper length switch is turned on. If not, replace the paper length switch.
(26) The size of paper in the drawer 2* is not displayed correctly.	Poor contact in the drawer paper length switch connector terminals.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable.
	Defective drawer paper length switch.	Check if YC4-5,6,8 on the drawer main PCB goes low when the drawer paper length switch is turned on. If not, replace the drawer paper length switch.

*: 20 ppm model only.

Problem	Causes	Check procedures/corrective measures
<p>(27) A paper jam in the paper feed, paper conveying or fixing section is indicated when the power switch is turned on.</p>	<p>A piece of paper torn from copy paper is caught around registration switch, exit switch or feedshift switch.</p>	<p>Check and remove if any.</p>
	<p>Defective registration switch.</p>	<p>Run maintenance item U031 and turn registration switch on and off manually. Replace registration switch if indication of the corresponding sensor is not light.</p>
	<p>Defective exit switch.</p>	<p>Run maintenance item U031 and turn exit switch on and off manually. Replace exit switch if indication of the corresponding sensor is not light.</p>
	<p>Defective feedshift switch.</p>	<p>Run maintenance item U031 and turn feedshift switch on and off manually. Replace feedshift switch if indication of the corresponding sensor is not light.</p>
<p>(28) The message requesting covers to be closed is displayed when the front cover and left cover are closed.</p>	<p>Poor contact in the connector terminals of safety switch.</p>	<p>Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable.</p>
	<p>Defective safety switch.</p>	<p>Check for continuity across each switch. If there is no continuity when the switch is on, replace it.</p>
<p>(29) Others.</p>	<p>Wiring is broken, shorted or makes poor contact.</p>	<p>Check for continuity. If none, repair.</p>
	<p>Noise.</p>	<p>Locate the source of noise and remove.</p>



1-5-5 Mechanical problems

Problem	Causes/check procedures	Corrective measures
(1) No primary paper feed.	Check if the surfaces of the following rollers or pulleys are dirty with paper powder: forwarding pulley, paper feed pulley, separation pulley, registration rollers, bypass paper feed pulley, bypass separation pad, feed roller*, drawer forwarding pulley*, drawer paper feed pulley* and drawer separation pulley*.	Clean with isopropyl alcohol.
	Check if the forwarding pulley, paper feed pulley or separation pulley is deformed.	Check visually and replace any deformed pulleys (see pages 1-6-3 and 5).
	Check if the drawer forwarding pulley, drawer paper feed pulley or drawer separation pulley is deformed.	Check visually and replace any deformed pulleys (see pages 1-6-7 to 10).
	Electrical problem with the following electromagnetic clutches: paper feed clutch, bypass paper feed solenoid and drawer paper feed clutch*.	See pages 1-5-35 and 36.
(2) No secondary paper feed.	Check if the surfaces of the right and left registration rollers are dirty with paper powder.	Clean with isopropyl alcohol.
	Electrical problem with the registration motor.	See page 1-5-34.
(3) Skewed paper feed.	Width guide in a drawer installed incorrectly.	Check the width guide visually and correct or replace if necessary.
	Deformed width guide in a drawer.	Repair or replace if necessary .
	Check if a pressure spring along the paper conveying path is deformed or out of place.	Repair or replace.
(4) The scanner does not travel.	Check if the scanner wire is loose.	Reinstall the scanner wire (see page 1-6-23).
	The scanner motor malfunctions.	See page 1-5-35.
(5) Multiple sheets of paper are fed at one time.	Check if the separation pulley or drawer separation pulley* is worn.	Replace the separation pulley if it is worn (see pages 1-6-3 and 8).
	Check if the paper is curled.	Change the paper.
(6) Paper jams.	Check if the paper is excessively curled.	Change the paper.
	Deformed guides along the paper conveying path.	Repair or replace if necessary.
	Check if the contact between the right and left registration rollers is correct.	Check visually and remedy if necessary.
	Check if the press roller is extremely dirty or deformed.	Clean or replace the press roller (see page 1-6-44).
	Check if the contact between the heat roller and its separation claws is correct.	Repair if any springs are off the separation claws.
	Check if the contact between the exit roller and pulley is correct.	Check visually and remedy if necessary.

*: 20 ppm model only.


Problem	Causes/check procedures	Corrective measures
(7) Toner drops on the paper conveying path.	Check if the developing unit is extremely dirty.	Clean the developing unit.
(8) Abnormal noise is heard.	Check if the pulleys, rollers and gears operate smoothly.	Grease the bearings and gears.
	Check if the following electromagnetic clutches are installed correctly: paper feed clutch, bypass paper feed solenoid and drawer paper feed clutch*.	Correct.

1-6-1 Precautions for assembly and disassembly

(1) Precautions

- Be sure to turn the power switch off and disconnect the power plug before starting disassembly.
 - When handling PCBs, do not touch connectors with bare hands or damage the board.
 - Do not touch any PCB containing ICs with bare hands or any object prone to static charge.
 - Use only the specified parts to replace the fixing unit thermostat. Never substitute electric wires, as the MFP may be seriously damaged.
 - Use the following testers when measuring voltages:
 - Hioki 3200
 - Sanwa MD-180C
 - Sanwa YX-360TR
 - Beckman TECH300
 - Beckman DM45
 - Beckman 330*
 - Beckman 3030*
 - Beckman DM850*
 - Fluke 8060A*
 - Arlec DMM1050
 - Arlec YF1030C
- * Capable of measuring RMS values.
- Prepare the following as test originals:
 1. NTC (new test chart)
 2. NPTC (newspaper test chart)

(2) Running a maintenance item



1-6-2 Paper feed section

(1) Detaching and refitting the separation pulley

Follow the procedure below to replace the separation pulley.

Procedure

1. Open the front cover and left cover. Remove the waste toner box.
2. Pull out the drawer.




Figure 1-6-1

3. Remove the screw and then the front left lower cover.




Figure 1-6-2

4. Remove the screw and then the lower paper feed unit.




Figure 1-6-3

2DA/2DB

5. Remove the separation pulley unit from the lower paper feed unit.
6. Remove the separation pulley from the separation pulley unit.
7. Replace the separation pulley and refit all the removed parts.





Figure 1-6-4

(2) Detaching and refitting the forwarding pulley and paper feed pulley


Follow the procedure below to replace the forwarding pulley and paper feed pulley.

Procedure


1. Remove the lower paper feed unit (see page 1-6-3).
2. Remove the drum unit (see page 1-6-38).
3. Remove the rear cover.
4. Remove the paper feed clutch, stop ring and bushing at the machine rear.

**Figure 1-6-5**

5. Remove the screw and then the registration guide.

**Figure 1-6-6**

6. Remove the screw and then the upper paper feed unit.

**Figure 1-6-7**

7. Remove the springs, stop ring and bushing and then the shaft holder from the upper paper feed unit.




Figure 1-6-8

8. Remove the forwarding pulley from the upper paper feed unit.
9. Remove the paper feed pulley from the upper paper feed unit.
10. Replace the forwarding pulley and paper feed pulley and refit all the removed parts.




Figure 1-6-9

(3) Detaching and refitting the feed roller (20 ppm model only)

Follow the procedure below to replace the feed roller.

Procedure

1. Open the drawer left cover.
2. Remove the two stop ring, gear and spring pin from rear side of the feed roller.
 - * When removing the gear, take care not to lose the spring pin.
3. Slide the bearings in the front and rear of the feed roller toward the inside, push the feed roller once into the rear side of the machine, and then remove it from the paper feeder.
4. Remove the two bushing from front and rear side of the feed roller.
5. Replace the feed roller and refit all the removed parts.




Figure 1-6-10

(4) Detaching and refitting the drawer separation pulley (20 ppm model only)

Follow the procedure below to replace the drawer separation pulley.

Procedure

1. Pull out the drawer. Open the drawer left cover.
2. Remove the screw and then the lower paper feed unit.




Figure 1-6-11

3. Remove the drawer separation pulley unit from the lower paper feed unit.
4. Remove the drawer separation pulley from the drawer separation pulley unit.
5. Replace the drawer separation pulley and refit all the removed parts.




Figure 1-6-12

(5) Detaching and refitting the drawer forwarding pulley and drawer paper feed pulley (20 ppm model only)

Follow the procedure below to replace the drawer forwarding pulley and drawer paper feed pulley.

Procedure

1. Remove the lower paper feed unit (see page 1-6-8).
2. Remove the drawer rear cover.
3. Remove the stop ring and drawer paper feed clutch from the machine rear side. Remove the stop ring and bushing.




Figure 1-6-13

4. Remove the screw and then the upper paper feed unit.




Figure 1-6-14

5. Remove the springs, stop ring and bushing and then the shaft holder from the upper paper feed unit.




Figure 1-6-15

6. Remove the drawer forwarding pulley from the upper paper feed unit.
7. Remove the drawer paper feed pulley from the upper paper feed unit.
8. Replace the drawer forwarding pulley and drawer paper feed pulley and refit all the removed parts.




Figure 1-6-16

(6) Detaching and refitting the paper conveying unit

Follow the procedure below to maintenance of the paper feed section.

Procedure

1. Remove the drum unit (see page 1-6-38).
2. Remove the strap from the rear side. Restore the paper conveying unit. Remove the fitting projection and pin, and then remove the stopper from the front side.
3. Open the left cover until it is put horizontally.




Figure 1-6-17

4. Push the fitting portions of the fixtures located on the front and rear and then remove the fixtures from the left cover.
5. Remove the left cover from the MFP.




Figure 1-6-18

- 6. Push the fitting portions of the bypass upper cover. Remove the bypass upper cover from the bypass unit.




Figure 1-6-19

- 7. Detach the connector and remove the bypass lower cover from the MFP.




Figure 1-6-20

- 8. Remove the paper conveying unit from the MFP.





Figure 1-6-21

(7) Detaching and refitting the bypass paper feed pulley and bypass separation pad


Follow the procedure below to replace the bypass paper feed pulley and bypass separation pad.

Procedure


1. Open the front cover and remove the waste toner box. Pull out the drawer.
2. Remove the screw and then the front left lower cover.

**Figure 1-6-22**

3. Remove the paper conveying unit (see page 1-6-11).
4. Remove the stop ring and bushing at the machine front side.

**Figure 1-6-23**

5. Remove the rear cover.
6. Remove the stop ring and bypass paper feed clutch gear at the machine rear side.

**Figure 1-6-24**

- 7. Temporarily push the bypass paper feed pulley unit into the rear side to unlock the front side and then remove it from the MFP.




Figure 1-6-25

- 8. Remove the bypass paper feed pulley from the bypass paper feed pulley shaft.




Figure 1-6-26

- 9. Push the fitting portions of the bypass separation pad. Remove the bypass separation pad from the MFP.
- 10. Replace the bypass paper feed pulley and bypass separation pad and refit all the removed parts.





Figure 1-6-27

(8) Detaching and refitting the registration left roller

Follow the procedure below to replace the registration left roller.

Procedure


1. Remove the paper conveying unit (see page 1-6-11).
2. Remove the transfer roller (see page 1-6-42).
3. Release the stoppers at the front and rear side, and then remove the registration left roller from the paper conveying unit.
4. Replace the registration left roller and refit all the removed parts.

**Figure 1-6-28****(9) Detaching and refitting the registration cleaner**


Follow the procedure below to replace the registration cleaner.

Procedure

1. Remove the drum unit (see page 1-6-38).
2. Remove the screw and then the registration guide.

**Figure 1-6-29**

3. Remove the screw and then the registration cleaner.
4. Replace the registration cleaner and refit all the removed parts.


**Figure 1-6-30**

(10) Adjustment after roller and clutch replacement

Perform the following adjustment after refitting rollers and clutches.

(10-1) Adjusting the leading edge registration of image printing

Make the following adjustment if there is a regular error between the leading edges of the copy image and original.



Caution:

Check the copy image after the adjustment. If the image is still incorrect, perform the above adjustments in maintenance mode.

Procedure






Figure 1-6-31

- RCL ON: Drawer
- RCL BYP: Bypass tray
- RCL T1: Optional first paper feeder (standard for 20 ppm model)
- RCL T2: Optional second paper feeder
- RCL T3: Optional third paper feeder
- RCL DUP: Duplex copying (second face)




Setting range (Initial setting)
 RCL ON: -5.0 – +10.0 (0.9)
 RCL BYP: -5.0 – +10.0 (1.2)
 RCL T1: -5.0 – +10.0 (1.3)
 RCL T2: -5.0 – +10.0 (1.3)
 RCL T3: -5.0 – +10.0 (1.3)
 RCL DUP: -5.0 – +10.0 (1.0)
 Changing the value by 1 moves the leading edge by 0.1 mm.




(10-2) Adjusting the leading edge registration for memory image printing

Make the following adjustment if there is a regular error between the leading edge of the copy image and the leading edge of the original during memory copying.


**Caution:**

Before making the following adjustment, ensure the above adjustments have been made in maintenance mode.

Procedure

(10-3) Adjusting the center line of image printing

Make the following adjustment if there is a regular error between the center lines of the copy image and original when paper is fed from the drawer.



Caution:

Check the copy image after the adjustment. If the image is still incorrect, perform the above adjustments in maintenance mode.

Procedure






Figure 1-6-33


- LSU OUT: Drawer
- LSU BYP: Bypass tray
- LSU T1: Optional first paper feeder (standard for 20 ppm model)
- LSU T2: Optional second paper feeder
- LSU T3: Optional third paper feeder
- LSU DUP: Duplex copying (second face)



Setting range (Initial setting)
 LSU OUT: -7.0 – +10.0 (-1.0)
 LSU BYP: -7.0 – +10.0 (0.4)
 LSU T1: -7.0 – +10.0 (-1.2)
 LSU T1: -7.0 – +10.0 (-1.2)
 LSU T1: -7.0 – +10.0 (-1.2)
 LSU DUP: -7.0 – +10.0 (0.3)
 Changing the value by 1 moves the center line by 0.1 mm.


(10-4) Adjusting the trailing edge margin of image printing

Make the following adjustment if there is a regular error between the trailing edges of the copy image and original.

Procedure

(10-5) Adjusting the margins for printing

Make the following adjustment if the margins are not correct.



Caution:

Check the copy image after the adjustment. If the margins are still incorrect, perform the above adjustments in maintenance mode.

Procedure





Figure 1-6-35

(10-6) Adjusting the amount of slack in the paper

Make the following adjustment if the leading edge of the copy image is missing or varies randomly, or if the copy paper is Z-folded.

Procedure



1-6-3 Optical section

(1) Detaching and refitting the exposure lamp

Take the following procedure when the exposure lamp is to be replaced.

Procedure

1. Remove the original cover or the DP.
2. Remove the two screws holding the upper right cover and then the cover. Remove the contact glass.




Figure 1-6-37

3. Move the mirror 1 frame to the cutouts of the machine.
* When moving the mirror 1 frame, do not touch the exposure lamp nor the inverter PCB.
4. Detach the exposure lamp connector from the inverter PCB and release the wire from three clamps.




Figure 1-6-38

5. Remove the two screws holding the exposure lamp and then the lamp.
6. Replace the exposure lamp and refit all the removed parts.





Figure 1-6-39

(2) Detaching and refitting the scanner wires


Take the following procedure when the scanner wires are broken or to be replaced.

(2-1) Detaching the scanner wires**Procedure**


1. Remove the exposure lamp (see page 1-6-22).
2. Remove the two screws holding the upper rear cover and then the cover. Remove the two screws holding the middle left cover and upper left cover and then the covers.

**Figure 1-6-40**

3. Remove the screw and then the slit retainer and slit glass. Detach the fitting portions and then remove the front scanner cover.

**Figure 1-6-41**

4. Remove the inverter wire guide and then detach the inverter wire from the inverter PCB.

**Figure 1-6-42**

5. Remove the screw holding each of the front and rear wire retainers and then remove the mirror 1 frame from the scanner unit.




Figure 1-6-43

6. Unhook the round terminal of the scanner wire from the scanner tension spring on the left side of the scanner unit.
7. Remove the scanner wire.




Figure 1-6-44

(2-2) Fitting the scanner wires**Caution:**

When fitting the wires, be sure to use those specified below.

Machine front: P/N 2C91236 (gray)

Machine rear: P/N 2C91235 (black)

Fitting requires the following tools:

Two frame securing tools (P/N 2AV6808)

Two scanner wire stoppers (P/N 3596811)

Procedure

1. Remove the screw and then scanner wire drum gear at the machine rear side.




Figure 1-6-45

2. Remove the stop ring and bushing from the front of the scanner wire drum shaft.
3. Remove the scanner wire drum shaft from the scanner unit.




Figure 1-6-46

4. Insert the locating ball on each of the scanner wires into the hole in the respective scanner wire drum and wind the scanner wire three turns inward and four turns outward.
 - With the locating ball as the reference point, wind the shorter end of each of the wires outward.
5. Secure the scanner wires using the scanner wire stoppers.




Figure 1-6-47

6. Refit the scanner wire drum shaft to the scanner unit.
7. Insert the two frame securing tools into the positioning holes at the front and rear of the scanner unit to pin the mirror 2 frame in position.




Figure 1-6-48

8. Loop the outer ends of the scanner wires around the outer grooves in the pulleys on the mirror 2 frame, winding from below to above. ①
9. Hook the round terminals onto the catches inside the scanner unit. ②
10. Loop the inner ends of the scanner wires around the grooves in the pulleys at the left of the scanner unit, winding from below to above. ③
11. Loop the scanner wires around the inner grooves in the pulleys on the mirror 2 frame, winding from above to below. ④
12. Wind the scanner wires around the grooves in the scanner wire guides at the left of the scanner unit. ⑤
13. Hook the round terminals onto the scanner tension springs. ⑥




Figure 1-6-49

14. Remove the scanner wire stoppers and frame securing tools.
15. Gather the scanner wires toward the locating balls.
16. Move the mirror 2 frame from side to side to correctly locate the wires in position.
17. Put the mirror 1 frame on the scanner rail and move it toward the left side of the machine.
18. Insert the frame securing tools into the positioning holes (leftmost holes) at the front and the rear of the scanner unit and screw the mirror 1 frame while securing both the mirror 1 frame and the mirror 2 frame.
19. Remove the two frame securing tools.
20. Refit all the removed parts.




Figure 1-6-50

(3) Detaching and refitting the ISU (reference)

Take the following procedure when the ISU is to be replaced.

Procedure

• Detaching the ISU

1. Remove the contact glass (see page 1-6-22).
2. Remove the four screws holding the ISU cover and then the cover.




Figure 1-6-51

3. Detach the CCD wire from the CCD PCB.
4. Remove the four screws holding the ISU and then the ISU.
5. Replace the ISU.




Figure 1-6-52

• Refitting the ISU

1. Align the positioning holes of the ISU by pushing it a little and attach the ISU to the scanner unit.
* Attach the ISU with reference to marking "C".
2. Secure the ISU using the four screws.
3. Refit the CCD wire to CCD PCB.
4. Refit all the removed parts.




Figure 1-6-53

(4) Detaching and refitting the laser scanner unit

Take the following procedure when the laser scanner unit is to be replaced.

Procedure

1. Remove the original cover or the DP.
2. Remove the upper right cover, contact glass, upper rear cover, middle left cover, upper left cover, slit glass and front scanner cover (see page 1-6-23).
3. Remove the four screws holding the right cover and then the cover. Remove the seven screws holding the rear cover and then the cover.




Figure 1-6-54

4. Detach the connector YC8 on the main PCB. Detach the connectors YC16, YC17, YC18 and YC19 on the engine PCB.




Figure 1-6-55

5. Remove the four pins holding the scanner unit and then the unit.




Figure 1-6-56

6. Remove the screw holding the exit cover and then the cover. Remove the two screws holding the inner rear cover and then the cover.




Figure 1-6-57

7. Remove the front and rear left cover.




Figure 1-6-58

8. Remove the two screws holding the exit unit and then pull out the unit a little.




Figure 1-6-59

9. Remove the exit tray.




Figure 1-6-60

10. Remove the four screws and detach the two connector and then remove the laser scanner unit.
11. Replace the laser scanner unit and refit all the removed parts.




Figure 1-6-61

(5) Adjusting the longitudinal squareness (reference)

Perform the following adjustment if the copy image is longitudinally skewed (longitudinal squareness not obtained).

Caution:

- Adjust the amount of slack in the paper (page 1-6-21) first. Check for the longitudinal squareness of the copy image, and if it is not obtained, perform the longitudinal squareness adjustment.
- Before making the following adjustment, output a VTC-PG2 pattern in maintenance item U993 to use as the original for the adjustment.

Procedure





Figure 1-6-62







Figure 1-6-63

(6) Adjusting magnification of the scanner in the main scanning direction

Perform the following adjustment if the magnification in the main scanning direction is not correct.


**Caution:**

Before making the following adjustment, ensure that the above adjustments have been made in maintenance mode. Also, perform “(7) Adjusting magnification of the scanner in the auxiliary scanning direction” (page 1-6-34) and “(9) Adjusting the scanner center line” (page 1-6-36) after this adjustment.

Procedure**Figure 1-6-64**

(7) Adjusting magnification of the scanner in the auxiliary scanning direction

Perform the following adjustment if the magnification in the auxiliary scanning direction is not correct.



Caution:

Before making the following adjustment, ensure that the above adjustments have been made in maintenance mode.

Procedure





Figure 1-6-65

Press the start key.

The new setting is stored.

For copy example 1, increase the value using the right cursor key.
For copy example 2, decrease the value using the left cursor key.


Setting range: -25 – +25
Initial setting: -10
Changing the value by 1 changes the magnification by 0.1%.
Increasing the value makes the image longer, and decreasing it make the image shorter.

(8) Adjusting the scanner leading edge registration

Perform the following adjustment if there is regular error between the leading edges of the copy image and original.

**Caution:**

Before making the following adjustment, ensure that the above adjustments have been made in maintenance mode.

Procedure

(9) Adjusting the scanner center line


Perform the following adjustment if there is a regular error between the center lines of the copy image and original.



Caution:

Before making the following adjustment, ensure that the above adjustments have been made in maintenance mode.

Procedure



(10) Adjusting the margins for scanning an original on the contact glass

Perform the following adjustment if the margins are not correct.



Caution:

Before making the following adjustment, ensure that the above adjustments have been made in maintenance mode.

Procedure





Figure 1-6-68

1-6-4 Drum section

(1) Detaching and refitting the drum unit

Follow the procedure below to replace the drum unit.

Cautions:

- Avoid direct sunlight or strong light when detaching and refitting the drum unit.
- Never touch the drum surface when holding the drum unit.

Procedure

1. Open the front cover and left cover. Remove the waste toner box and toner container.
2. Remove the inner cover.
3. Remove the screw holding the developing release lever.
4. Pull the developing release lever and then release the developing unit.




Figure 1-6-69

5. Remove the screw and detach the connector and then remove the drum unit from MFP.
6. Replace the drum unit and refit all the removed parts.




Figure 1-6-70

(2) Detaching and refitting the drum separation claws

Follow the procedure below to replace the drum separation claws.

Procedure

1. Remove the drum unit (see page 1-6-38).
2. Push the drum separation claws with the minus driver from the top of the corner hole and remove the claws.
3. Replace the drum separation claws and refit all the removed parts.




Figure 1-6-71

(3) Detaching and refitting the main charger unit

Follow the procedure below to replace the main charger unit.

Procedure

1. Open the front cover and remove the waste toner box and inner cover.
2. While lifting the main charger unit toward the upper right, remove the unit from the MFP.
3. While pressing the main charger release lever in the direction indicated by the arrow at the removal stopper position to release the removal stopper, remove the main charger unit from the MFP.
4. Replace the main charger unit and refit all the removed parts.




Figure 1-6-72

1-6-5 Developing section

(1) Detaching and refitting the developing unit

Follow the procedure below to replace the developing unit.

Procedure

1. Remove the drum unit (see page 1-6-38).
2. While lifting the developing unit a little, remove the unit from the MFP.
3. Replace the developing unit and refit all the removed parts.




Figure 1-6-73

1-6-6 Transfer section

(1) Detaching and refitting the transfer roller

Follow the procedure below to replace the transfer roller.

Procedure

1. Remove the paper conveying unit (see page 1-6-11).
2. Remove the screw holding each of the front and rear release lever stoppers and then the stoppers from the release lever shaft.




Figure 1-6-74

3. Detach the fitting portions located on the front and rear and then remove the transfer roller from the paper conveying unit.
4. Replace the transfer roller and refit all the removed parts.




Figure 1-6-75

1-6-7 Fixing section

(1) Detaching and refitting the fixing unit

Follow the procedure below to replace the fixing unit.

Procedure

1. Open the front cover and left cover and then remove the inner cover.
2. Insert a flat-blade screwdriver or the like through the groove at the left side of the machine and unlock the engaged portion of front left cover 1 to remove it.




Figure 1-6-76

3. Remove the screw and then remove the front left cover 2.




Figure 1-6-77

4. Remove the screw and detach the two connectors and then remove the fixing unit from MFP.
5. Replace the fixing unit and refit all the removed parts.




Figure 1-6-78

(2) Detaching and refitting the press roller

Follow the procedure below to replace the press roller.

Procedure

1. Remove the fixing unit (see page 1-6-43).
2. Remove the two screws and then separate the fixing right unit and left unit.




Figure 1-6-79

3. Remove the three screws holding the press roller guide from fixing right unit.




Figure 1-6-80

4. Remove the press roller from the fixing right unit.
5. Replace the press roller and refit all the removed parts.




Figure 1-6-81

(3) Detaching and refitting the fixing heater M and S

Follow the procedure below to replace the fixing heater M and S.

Procedure

1. Remove the fixing unit and separate the fixing right unit and left unit (see pages 1-6-43, 44).
2. Remove the two screws holding each of the fixing heater M and S on the front and rear of the fixing left unit.




Figure 1-6-82

3. Pull out the fixing heater M and S from the fixing left unit.
4. Replace the fixing heater M and S, and refit all the removed parts.




Figure 1-6-83

(4) Detaching and refitting the heat roller separation claws

Follow the procedure below to replace the heat roller separation claws.

Procedure

1. Remove the fixing unit and separate the fixing right unit and left unit (see pages 1-6-43, 44).
2. Detach the fitting portions and then remove the heat roller guide from the fixing left unit.




Figure 1-6-84

3. Remove the heat roller separation claws from the fixing left unit.
4. Replace the heat roller separation claws and refit all the removed parts.




Figure 1-6-85

(5) Detaching and refitting the heat roller

Follow the procedure below to replace the heat roller.

Procedure

1. Remove the fixing unit and separate the fixing right unit and left unit (see pages 1-6-43, 44).
2. Remove the heat roller separation claws. (see page 1-6-46).
3. Pull out the heat roller bushing from the fixing left unit and then remove the heat roller.
4. Replace the heat roller and refit all the removed parts.




Figure 1-6-86

(6) Detaching and refitting the fixing thermostat

Follow the procedure below to replace the fixing thermostat.

Procedure

1. Remove the fixing unit and separate the fixing right unit and left unit (see pages 1-6-43, 44).
2. Remove the heat roller (see page 1-6-47).
3. Remove the two screws holding the fixing thermostat and then the thermostat.
4. Replace the fixing thermostat and refit all the removed parts.




Figure 1-6-87

(7) Detaching and refitting the fixing thermistor

Follow the procedure below to replace the fixing thermistor.

Procedure

1. Remove the fixing unit and separate the fixing right unit and left unit (see pages 1-6-43, 44).
2. Remove the heat roller (see page 1-6-47).
3. Remove the screw holding the fixing thermistor and then the thermistor.
4. Replace the fixing thermistor and refit all the removed parts.




Figure 1-6-88

1-7-1 Upgrading the firmware on the main PCB

Firmware upgrading requires the following tools:

Compact Flash (Products manufactured by SANDISK are recommended.)

NOTE

When writing data to a new Compact Flash from a computer, be sure to format it in advance.

Procedure

1. Turn the power switch off and disconnect the power plug.
2. Remove the rear cover.
3. Insert Compact Flash in a notch hole of the machine (insert the surface of Compact Flash toward the machine rear).
4. Insert the power plug and turn the power switch on. Upgrading firmware starts.
Caution:
Never turn the power switch off during upgrading.
5. "Completed" is indicated on the message display when upgrading is complete.
6. Turn the power switch off and disconnect the power plug.
7. Remove Compact Flash from the machine and refit the rear cover.
8. Insert the power plug and turn the power switch on.

Figure 1-7-1

1-7-2 Upgrading the printer board firmware

Firmware upgrading requires the following tools:
Compact Flash (Products manufactured by SANDISK are recommended.)

NOTE

When writing data to a new Compact Flash from a computer, be sure to format it in advance.

Procedure

1. Turn the power switch off and disconnect the power plug.
2. Insert Compact Flash in a notch hole of the machine (insert the surface of Compact Flash toward the machine rear).
3. Insert the power plug and turn the power switch on. Upgrading firmware starts.
Caution:
Never turn the power switch off during upgrading.
4. "Completed" is indicated on the message display when upgrading is complete.
5. Turn the power switch off and disconnect the power plug.
6. Remove Compact Flash from the machine and refit the rear cover.
7. Insert the power plug and turn the power switch on.




Figure 1-7-2

1-7-3 Adjustment-free variable resistors (VR)

The variable resistors listed below are set at the factory prior to shipping and cannot be adjusted in the field.

- High-voltage PCB: VR201, VR202, VR301
- Drum unit zener PCB: VR1

1-7-4 Remarks on PCBs replacement

Confirm the version of the firmware and upgrade the version in up-to-date state when replacing PCBs.

When replacing the engine PCB or main PCB, remove the EEPROM from the engine PCB or main PCB that has been removed and then reattach it to the new engine PCB or main PCB.




Figure 1-7-3

2-1-1 Paper feed section

The paper feed section conveys paper from the drawer (one drawer is standard for 16 ppm model/two drawers are standard for 20 ppm model) or bypass tray to the left and right registration rollers, at which point secondary feed takes place and the paper travels to the transfer section in sync with the printing timing.

Drawer can hold up to 300 sheets of paper. Paper is fed from the drawer by the rotation of the forwarding pulley and paper feed pulley. The separation pulley prevents multiple sheets from being fed at one time, via the torque limiter.

The bypass tray can hold up to 50 sheets of paper. Paper is fed from the bypass tray by the rotation of the bypass paper feed pulley.





Figure 2-1-1 Paper feed section


- | | |
|-----------------------------|---------------------------------------|
| ① Separation pulley | ⑩ Bypass paper width switch (BYPPWSW) |
| ② Forwarding pulley | ⑪ Drawer paper feed pulley* |
| ③ Paper feed pulley | ⑫ Drawer forwarding pulley* |
| ④ Bypass paper feed pulley | ⑬ Drawer separation pulley* |
| ⑤ Bypass separation pad | ⑭ Feed roller* |
| ⑥ Left registration roller | ⑮ Feed pulley* |
| ⑦ Right registration roller | ⑯ Drawer lift* |
| ⑧ Drawer lift | ⑰ Drawer feed switch (DFSW)* |
| ⑨ Registration switch (RSW) | |

*: 20 ppm model only



*: 20 ppm model only

Figure 2-1-2 Paper feed section block diagram



Timing chart 2-1-1 Paper feed from the drawer (A4, single-sided copy)

- (a): The paper feed clutch (PFCL) turns on to start primary paper feed.
- (b): 430 ms after the paper feed clutch (PFCL) turns on, the registration switch (RSW) turns on.
- (c): 105 ms after the registration switch (RSW) turns on, the paper feed clutch (PFCL) turns off.
- (d): 150 ms after the paper feed clutch (PFCL) turns on, the registration motor (RM) turns on to start secondary paper feed.
- (e): 550 ms after the registration motor (RM) turns on, the paper feed clutch (PFCL) turns off.
- (f): 1900 ms after the registration motor (RM) turns on, the registration switch (RSW) turns off. At the same time, the paper feed clutch (PFCL) turns on to start primary paper feed of the second sheet.
- (g): 320 ms after the registration switch (RSW) turns off, the registration motor (RM) turns off.

2-1-2 Optical section

The optical section consists of the scanner, mirror frames and the image scanning unit for scanning and the laser scanner unit for printing.




Figure 2-1-3 Optical section

- ① Mirror 1 frame
- ② Mirror 2 frame
- ③ Exposure lamp (EL)
- ④ Mirror 1
- ⑤ Mirror 2
- ⑥ Mirror 3
- ⑦ Image scanning unit (ISU)
- ⑧ CCD PCB (CCDPCB)
- ⑨ Laser scanner unit (LSU)
- ⑩ Scanner home position switch (SHPSW)
- ⑪ Original detection switch (ODSW)
- ⑫ Original size detection sensor (OSDS)

(1) Original scanning

The original image is illuminated by the exposure lamp (EL) and scanned by the CCD PCB (CCDPCB) in the image scanning unit via the three mirrors, the reflected light being converted to an electrical signal. The scanner and mirror frames travel to scan on the optical rails on the front and rear of the machine to scan from side to side. The speed of the mirror frames is half the speed of the scanner. When the DP is used, the scanner and mirror frames stop at the DP original scanning position to start scanning.




Figure 2-1-4 Optional section block diagram

(2) Image printing

The image data scanned by the CCD PCB (CCDPCB) is processed on the main PCB (MPCB) and transmitted as image printing data to the laser scanner unit (LSU). By repeatedly turning the laser on and off, the laser scanner unit forms a latent image on the drum surface.




Figure 2-1-5 Laser scanner unit

- ① Laser diode: Generates the laser beam which forms a latent image on the drum.
- ② Collimator lens: Collimates the diffused laser beam emitted from the laser diode to convert it into a cylindrical beam.
- ③ Cylindrical lens: Shapes the collimated laser beam to suit the printing resolution.
- ④ Polygon mirror: Six-facet mirror that rotates at approximately 23619 rpm with each face reflecting the laser beam toward the drum for one main-direction scan.
- ⑤ Polygon motor: Drives the polygon mirror.
- ⑥ F θ lens: Corrects for non-linearity of the laser beam scanning speed on the drum surface, keeps the beam diameter constant and corrects for the vertical alignment of the polygon mirror to ensure that the focal plane of the laser beam is on the drum surface.
- ⑦ F θ lens: Corrects for non-linearity of the laser beam scanning speed on the drum surface, keeps the beam diameter constant and corrects for the vertical alignment of the polygon mirror to ensure that the focal plane of the laser beam is on the drum surface.
- ⑧ PD sensor mirror: Reflects the laser beam to the PD sensor to generate the main-direction (horizontal) sync signal.
- ⑨ Cylindrical correcting lens: Corrects for the deviation of the laser beam reflected by the PD sensor mirror to the PD sensor.
- ⑩ PD sensor: Detects the beam reflected by the PD sensor mirror, outputting a signal to the main PCB (MPCB) to provide timing for the main-direction sync signal.

The dimensions of the laser beam are as shown in Figure 2-1-6.




Figure 2-1-6

Scanning in the main direction is provided by the rotating polygon mirror, while scanning in the auxiliary direction is provided by the rotating drum, forming a static latent image on the drum. The static latent image of the letter “A”, for example, is formed on the drum surface as shown in Figure 2-1-7. Electrical charge is dissipated on the area of the drum surface irradiated by the laser. The focal point of the laser beam is moved line by line, and adjacent lines slightly overlap each other.




Figure 2-1-7

2-1-3 Drum section

The drum section consists of the drum, main charger section, cleaning section and cleaning lamp.

The main charger section consists of main charger wire, main charger grid and main charger shield, and the drum is charged by a high voltage applied to the main charger wire. In addition, this section is equipped with a manual main charger cleaner that is used for cleaning the main charger wire.

The cleaning section consists of the cleaning blade and cleaning roller that removes residual toner from the drum surface after the transfer process, and the cleaning spiral that carries the residual toner back to the waste toner box.

The cleaning lamp (CL) consists of LEDs which remove residual charge from the drum surface.




Figure 2-1-8 Drum section

- ① Drum
- ② Main charger unit
- ③ Main charger wire
- ④ Drum separation claw
- ⑤ Cleaning roller
- ⑥ Cleaning spiral
- ⑦ Cleaning blade
- ⑧ Cleaning lamp (CL)





Figure 2-1-9 Drum section block diagram



Timing chart 2-1-2 Main charging section operation

- (a): The drive motor (DM) turns on at the same time, the cleaning lamp (CL) turns on.
- (b): 100 ms after the drive motor (DM) turns on, main charging starts.
- (c): 840 ms after the exit switch (ESW) off, main charging is completed.
- (d): The drive motor (DM) turns off at the same time, the cleaning lamp (CL) turns off.

2-1-4 Developing section

The developing section consists of the developing unit and the toner container.
 The developing unit consists of the developing roller where a magnetic brush is formed, the doctor blade and the developing spirals that agitate the toner.
 Also, the toner container sensor (TCS) checks whether or not toner remains in the toner container.




Figure 2-1-10 Developing section

- ① Developing unit
- ② Developing roller
- ③ Doctor blade
- ④ Left developing spiral
- ⑤ Right developing spiral
- ⑥ Toner container
- ⑦ Toner container sensor (TCS)
- ⑧ Toner container detection switch (TCDSW)

(1) Formation of magnetic brush

The developing roller consists of a magnet roller with four poles and a sleeve roller. Rotation of the sleeve roller around the magnet roller entrains toner, which in turn forms a magnetic brush at pole N1 on the magnet roller. The height of the magnetic brush is regulated by the doctor blade; the developing result is affected by the position of the poles on the magnet roller and the position of the doctor blade.

A developing bias voltage generated by the high-voltage PCB (HVTPCB) is applied to the developing roller to provide image contrast.




Figure 2-1-11 Forming a magnetic brush




Figure 2-1-12 Developing section block diagram

(2) Single component developing system

This machine uses the single component developing system, and reversal processing is performed with a + charged drum (a-Si) and a + charged magnetic toner.

With the single component developing system, toner is electrically charged by friction with the developing sleeve and + charged when it passes through the magnetic doctor blade. The toner that has passed through the magnetic doctor blade forms a uniform layer on the developing sleeve. When the toner layer comes to the location where the developing sleeve is the nearest to the drum, toner moves between the drum and the developing sleeve by an electric field of the magnetic pole. Then, when the developing sleeve rotates and passes through the nearest location to the drum, on the portion of the drum that has been exposed to light, toner is attracted toward the drum by potential difference between the developing bias and the drum surface and development is performed. On the other hand, on the portion of the drum that has not been exposed to light, toner is attracted toward the sleeve and development is not performed. When toner comes to an area where the gap between the drum and the developing sleeve is large, an electric field disappears and toner does not leave the developing sleeve. Development is complete.




Figure 2-1-13 Single component developing system

Developing bias parameters

For the bias to the developing sleeve, an alternating current (AC) is applied. Parameters for the developing bias are shown below.

Vp-p: Difference between the maximum and the minimum of applied voltage

1.6 kV (fixed)

Vf: Frequency

Typically 2.7 kHz. This value varies depending on the preset value of the drive time and the environmental correction. (Can be adjusted with the maintenance item U101.)

Duty: Ratio of time where + voltage is applied in a cycle

Typically 45%. (Can be adjusted with the maintenance item U101.)

Vdc: Developing shift bias potential 290 V

Supplementation

Vo: Drum surface potential on non-image area (area not exposed to light)

VL: Drum surface potential on image area (area exposed to light)




Figure 2-1-14 Developing bias waveformsa



2-1-5 Transfer and separation sections

The transfer and separation sections consists of the transfer roller, separation electrode and drum separation claws. A high voltage generated by the high-voltage PCB (HVTPCB) is applied to the transfer roller for transfer charging. Paper after transfer is separated from the drum by applying separation bias that is output from the high-voltage PCB (HVTPCB) to the separation electrode.




Figure 2-1-15 Transfer and separation sections

- ① Transfer roller
- ② Separation electrode
- ③ Drum separation claw
- ④ Drum





Figure 2-1-16 Transfer and separation sections block diagram



Timing chart 2-1-3 Transfer and separation sections operation

- Ⓐ: 290 ms after the registration motor (RM) turns on to start secondary paper feed, separation charging starts.
- Ⓑ: 10 ms after separation charging starts, transfer charging starts.
- Ⓒ: 670 ms after the registration switch (RSW) turns off, transfer charging ends.
- Ⓓ: 100 ms after transfer charging ends, separation charging ends.

2-1-6 Fixing section

The fixing section consists of the parts shown in figure. When paper reaches the fixing section after the transfer process, it passes between the press roller and heat roller, which is heated by fixing heaters M and S (FH-M/FH-S). Pressure is applied by the fixing unit pressure springs so that the toner on the paper is melted, fused and fixed onto the paper. The heat roller is heated by fixing heaters M and S (FH-M/FH-S) inside it; its surface temperature is detected by the fixing thermistor (FTH) and is regulated by the fixing heaters turning on and off. If the fixing section becomes abnormally hot, fixing thermostat (FTS) operates shutting the power to the fixing heaters off. When the fixing process is completed, the paper is separated from the heat roller by its separation claws and is conveyed from the MFP to exit and switchback section.




Figure 2-1-17 Fixing section




Figure 2-1-18 Fixing section block diagram

(1) Fixing temperature system




Figure 2-1-19 Fixing temperature system

- Warm-up control
 1. 500 ms after the fixing heater S (FH-S) turns on, the fixing heater M (FH-M) turns on.
 2. When the fixing temperature reaches preset temperature, both fixing heater S (FH-S) and fixing heater M (FH-M) turn off simultaneously.
- Ready state control
 1. When the fixing temperature drops to the preset temperature, fixing heater S (FH-S) turns on, and after specified time, the heater turns off.
 2. When fixing heater S (FH-S) turns off, fixing heater M (FH-M) turns on at the same time, and after specified time, the heater turns off.
 3. The operation above is repeated to keep the fixing temperature to the preset temperature.

* If a temperature more than or equal to the preset temperature + 20°C/68°F is detected, both fixing heater S (FH-S) and fixing heater M (FH-M) are turned off forcibly.

(2) Fixing temperature control based on ambient temperature

This machine performs fixing temperature control based on the ambient temperature.

Ambient temperature	Fixing temperature (°C)
Lower than 15°C/59°F	Reference value +10
Higher than or equal to 15°C/59°F, lower than 20°C/68°F	Reference value +5
Higher than or equal to 20°C/68°F, lower than 31°C/78.8°F	Reference value
Higher than 31°C/78.8°F	Reference value -5



2-1-7 Exit and switchback sections

The exit and switchback sections exit paper on which fixing has ended with the exit roller that is rotated by forward rotation of the exit motor.
 In duplex copying, paper is turned over by reverse rotation of the exit motor.




Figure 2-1-20 Exit and switchback sections




Figure 2-1-21 Exit and switchback sections block diagram

2-1-8 Duplex section

In duplex mode, after copying on to the reverse face of the paper, the paper is reversed in the switchback section and conveyed to the duplex unit. The paper is then conveyed to the MFP paper feed section by the upper and lower duplex feed rollers.




Figure 2-1-22 Duplex section




Figure 2-1-23 Duplex section block diagram

(1) Paper conveying operation in duplex copying

Paper of which copying onto the reverse side is complete is conveyed to the switchback section, the exit motor switches from forward rotation to reverse rotation to switch the exit roller to reverse rotation, and the paper conveying direction is reversed. Paper that has been switched back is conveyed to the duplex unit via the exit roller and the switchback roller. Paper that has been conveyed to the duplex unit is conveyed to the paper feed section again by rotation of the upper duplex feed roller and the lower duplex feed roller and copying onto the front side is performed.




Figure 2-1-24

2-2-1 Electrical parts layout

(1) PCBs




Figure 2-2-1 PCBs

- | | |
|--|---|
| 1. Engine PCB (EPCB) | Controls the other PCBs, electrical components and optional devices. |
| 2. Main PCB (MPCB) | Controls the operation panel and laser scanner unit. |
| 3. Power source PCB (PSPCB) | Generates +24 V DC and 5V DC; controls the fixing heater. |
| 4. High-voltage PCB (HVTPCB) | Main charging. Generates high voltages for transfer and high voltages for separation. |
| 5. Inverter PCB (INPCB) | Controls the exposure lamp. |
| 6. CCD PCB (CCDPCB) | Reads the image off originals. |
| 7. Operation unit PCB (OPCB) | Consists of the operation keys and display LEDs. |
| 8. Drawer PCB (DPCB) | Controls the electrical components. |
| 9. APC PCB (APCPCB) | Generates and controls the laser light. |
| 10. PD PCB (PDPCB) | Controls horizontal synchronizing timing of laser beam. |
| 11. Registration motor PCB (RMPCB) | Controls the registration motor. |
| 12. Printer board PCB (PRNPCB) | Controls the printer functions. |
| 13. LCD PCB (LCDPCB) | Controls the display of LCD. |
| 14. Drawer main PCB (DMPCB)*1 | Controls electrical components of the drawer. |
| 15. Drawer heater PCB (DHPCB)*1 | Relays the drawer heater power. |

*1: Optional for 16 ppm model./Standard for 20 ppm model.

www.tonerplus.com.ua

(2) Switches and sensors




Figure 2-2-2 Switches and sensors

- 1. Power switch (POWSW) Turns the AC power on and off.
- 2. Front cover safety switch (FCSSW) Breaks the safety circuit when the front cover is opened.
- 3. Left cover safety switch (LCSSW) Breaks the safety circuit when the left cover is opened.
- 4. Paper switch (PSW) Detects the presence of paper in the drawer.
- 5. Paper size length switch (PLSW) Detects the length of paper in the drawer.
- 6. Paper size width switch (PWSW) Detects the width of paper in the drawer.
- 7. Bypass paper size width switch (BYPPWSW) Detects the width of paper on the bypass tray.
- 8. Scanner home position switch (SHPSW) Detects the optical system in the home position.
- 9. Original detection switch (ODSW) Operates the original size detection sensor.
- 10. Original size detection sensor (OSDS) Detects the size of the original.
- 11. Registration switch (RSW) Controls the secondary paper feed start timing.
- 12. Exit switch (ESW) Detects a paper misfeed in the fixing section.
- 13. Feedshift switch (FSSW) Detects a paper misfeed in the switchback section in a duplex copy.
- 14. Toner container sensor (TCS) Detects the quantity of toner in a toner container.
- 15. Toner container detection switch (TCDSW) Detects the presence of the toner container.
- 16. Overflow sensor (OFS) Detects when the waste toner box is full.
- 17. Fixing thermistor (FTH) Detects the heat roller temperature.
- 18. Drawer left cover safety switch (DLCSW)*1 Breaks the safety circuit when the drawer left cover is opened.

- 19. Drawer feed switch (DFSW)*1 Detects a paper misfeed.
- 20. Drawer paper switch (DPSW)*1 Detects the presence of paper in the drawer.
- 21. Drawer paper size width switch (DPWSW)*1 Detects the width of paper in the drawer.
- 22. Drawer paper size length switch (DPLSW)*1 Detects the length of paper in the drawer.
- 23. Duplex paper conveying switch (DUPPCSW)*2 Detects a paper misfeed in the duplex unit.

*1: Optional for 16 ppm model./Standard for 20 ppm model.

*2: Optional.



(3) Motors




Figure 2-2-3 Motors

- 1. Drive motor (DM) Drives the machine.
- 2. Scanner motor (SM) Drives the optical system.
- 3. Exit motor (EM) Drives the exit section.
- 4. Cooling fan motor 1 (CFM1) Cools the machine interior.
- 5. Cooling fan motor 2 (CFM2) Cools the machine interior.
- 6. Cooling fan motor 3 (CFM3) Cools the machine interior.
- 7. Polygon motor (PM) Drives the polygon mirror.
- 8. Registration motor (RM) Drives the registration roller.
- 9. Drawer drive motor (DDM)*1 Drives the drawer section.

*1: Optional for 16 ppm model./Standard for 20 ppm model.

(4) Other electrical components





Figure 2-2-4 Other electrical components

- | | |
|--|--|
| 1. Paper feed clutch (PFCL) | Primary paper feed from the drawer. |
| 2. Bypass paper feed solenoid (BYPPFSOL) .. | Primary paper feed from the bypass tray. |
| 3. Exposure lamp (EL) | Exposes originals. |
| 4. Cleaning lamp (CL) | Removes residual charge from the drum surface. |
| 5. Fixing heater M (FH-M) | Heats the heat roller. |
| 6. Fixing heater S (FH-S) | Heats the heat roller. |
| 7. Fixing thermostat (FTS) | Prevents overheating in the fixing section. |
| 8. Drawer heater (DH)*2 | Dehumidifies the drawer section. |
| 9. Drawer heater (DH)*1 | Dehumidifies the drawer section. |
| 10. Drawer paper feed clutch (DPFCL)*1 | Primary paper feed from the drawer. |
| 11. Duplex feed clutch (DUPFCL)*2 | Controls the drive of the duplex feed roller. |


*1: Optional for 16 ppm model./Standard for 20 ppm model.

*2: Optional.


Timing chart No. 1 Paper feed from drawer, single-side mode, original size A4/11" x 8 1/2", two sheets



Timing chart No. 2 Paper feed from drawer, single-side mode, original size A3/11" x 17", two sheets



Timing chart No. 3 Paper feed from first paper feeder (optional for 16 ppm model/standard for 20 ppm model), single-side mode, original size A4/11" x 8 1/2", two sheets



Timing chart No. 4 Paper feed from second paper feeder (optional), single-side mode, original size A4/11" x 8 1/2", two sheets




















Chart of image adjustment procedures

Adjusting order	Item	Image	Description	Maintenance mode		Original	Page	Remarks
				Item No.	Display			
①	Adjusting the magnification in the main scanning direction (printing adjustment)		Polygon motor speed adjustment	U053	POLY	U053 test pattern	1-4-13	
②	Adjusting the magnification in the auxiliary scanning direction (printing adjustment)		Drive motor speed adjustment	U053	MAIN	U053 test pattern	1-4-13	
③	Adjusting the center line of the bypass tray (printing adjustment)		Adjusting the LSU print start timing	U034	LSU BYP	U034 test pattern	1-6-18	
④	Adjusting the center line of the drawers (printing adjustment)		Adjusting the LSU print start timing	U034	LSU OUT	U034 test pattern	1-6-18	First paper feeder: select LSU T1 Second paper feeder: select LSU T2 Third paper feeder: select LSU T3 Duplex copying: select LSU DUP
⑤	Adjusting the leading edge registration of the bypass tray (printing adjustment)		Registration motor turning on timing (secondary paper feed start timing)	U034	RCL BYP	U034 test pattern	1-6-16	
⑥	Adjusting the leading edge registration of the drawer (printing adjustment)		Registration motor turning on timing (secondary paper feed start timing)	U034	RCL ON	U034 test pattern	1-6-16	First paper feeder: select RCL T1 Second paper feeder: select RCL T2 Third paper feeder: select RCL T3 Duplex copying: select RCL DUP
⑦	Adjusting the leading edge margin (printing adjustment)		LSU illumination start timing	U402	LEAD	U402 test pattern	1-6-20	
⑧	Adjusting the trailing edge margin (printing adjustment)		LSU illumination end timing	U402	TRAIL	U402 test pattern	1-6-20	

Adjusting order	Item	Image	Description	Maintenance mode		Original	Page	Remarks
				Item No.	Display			
⑨	Adjusting the left and right margins (printing adjustment)		LSU illumination start/end timing	U402	AC	U402 test pattern	1-6-20	
⑩	Adjusting magnification of the scanner in the main scanning direction (scanning adjustment)		Data processing	U065	MAIN SCAN ADJ	Test chart	1-6-33	No adjustment for copying using the DP.
⑪	Adjusting magnification of the scanner in the auxiliary scanning direction (scanning adjustment)		Original scanning speed	U065 U070	SUB SCAN ADJ	Test chart	1-6-34 1-4-16	U065: For copying an original placed on the contact glass. U070: For copying originals from the DP.
⑫	Adjusting the center line (scanning adjustment)		Adjusting the original scan data (image adjustment)	U067 U072	— —	Test chart	1-6-36 1-4-18	U067: For copying an original placed on the contact glass. U072: For copying originals from the DP.
⑬	Adjusting the leading edge registration (scanning adjustment)		Original scan start timing	U066 U071	— —	Test chart	1-6-35 1-4-17	U066: For copying an original placed on the contact glass. U071: For copying originals from the DP.
⑭	Adjusting the leading edge margin (scanning adjustment)		Adjusting the original scan data (image adjustment)	U403 U404	B MARGIN B MARGIN	Test chart	1-6-37 1-4-44	U403: For copying an original placed on the contact glass. U404: For copying originals from the DP.
⑮	Adjusting the trailing edge margin (scanning adjustment)		Adjusting the original scan data (image adjustment)	U403 U404	D MARGIN D MARGIN	Test chart	1-6-37 1-4-44	U403: For copying an original placed on the contact glass. U404: For copying originals from the DP.
⑯	Adjusting the left and right margins (scanning adjustment)		Adjusting the original scan data (image adjustment)	U403 U404	A/C MARGIN A/C MARGIN	Test chart	1-6-37 1-4-44	U403: For copying an original placed on the contact glass. U404: For copying originals from the DP.



When maintenance item U092 (Adjusting the scanner automatically) is run using the specified original (P/N 2A068020), the following adjustments are automatically made:

- Adjusting the scanner center line (U067)
- Adjusting the scanner magnification in the main scanning direction (U065)
- Adjusting the scanner leading edge registration (U066)
- Adjusting the scanner magnification in the auxiliary scanning direction (U065)

When maintenance item U076 (Adjusting the DP automatically) is run using the specified original (P/N 2AC68241), the following adjustments are automatically made:

- Adjusting the DP magnification (U070)
- Adjusting the DP scanning timing (U071)
- Adjusting the DP center line (U072)

Item	Specifications
100% magnification	Copier: $\pm 0.8\%$
Enlargement/reduction	Using DP: $\pm 1.5\%$
Lateral squareness	Copier: $\pm 1.0\%$
Margins	Using DP: $\pm 1.5\%$
Leading edge registration	Copier: ± 1.5 mm/375 mm
Skewed paper feed (left-right difference)	Using DP: ± 3.0 mm/375 mm
Lateral image shifting	A: 3.0 ± 2.5 mm
	B: 3.0 ± 2.5 mm
	C: 3.0 ± 2.5 mm
	D: 3.0 ± 2.5 mm
	Drawer: ± 2.5 mm
	Bypass: ± 2.5 mm
	Duplex copying: ± 2.5 mm
	Drawer: 1.5 mm or less
	Bypass: 1.5 mm or less
	Duplex copying: 2.0 mm or less
	Drawer: ± 2.0 mm
	Bypass: ± 2.0 mm
	Duplex copying: ± 3.0 mm

Maintenance parts list

Maintenance part name		Part No.	Fig. No.	Ref. No.
Name used in service manual	Name used in parts list			
Paper feed pulley	PULLEY, PAPER FEED	2AR07220	7	39
Separation pulley	PULLEY, SEPARATION	2AR07230	7	40
Forwarding pulley	PULLEY, LEADING FEED	2AR07240	7	41
Drawer paper feed pulley	PULLEY, PAPER FEED	2AR07220	4	16
Drawer separation pulley	PULLEY, SEPARATION	2AR07230	4	17
Drawer forwarding pulley	PULLEY, LEADING FEED	2AR07240	4	18
Bypass paper feed pulley	PARTS, BYPASS PULLEY, SP	2C993130	8	19
Bypass separation pad	PARTS, BYPASS PAD, SP	2C993140	8	15
Left registration roller	ROLLER REGIST LEFT	2C916020	6	1
Right registration roller	RIGHT ROLL REGIST	2C907180	7	9
Registration cleaner	PARTS, REGIST CLEANER, ASSY	2C993210	7	27
Trans guide film	FILM RIGHT TRANS A	2C917220	7	28
Feed roller	ROLLER FEED	3HW06020	4	3
Feed pulley	PULLEY FEED	2BL16080	3	24
Slit glass	CONTACT GLASS ADF	2C912280	10	27
Contact glass	CONTACT GLASS	2C912250	10	24
Mirror 1	MIRROR A	2C912390	10	37
Mirror 2 and mirror 3	MIRROR B	2AV12160	10	4
Lens	LENS	2C912500	–	–
Reflector	REFLECTOR SCANNER	2C912110	10	12
Exposure lamp	LAMP SCANNER YG	2C912090	10	10
Front scanner rail	FRONT RAIL SCANNER	2C912070	–	–
Rear scanner rail	REAR RAIL SCANNER	2C912080	–	–
Original size detection sensor	SENSOR ORIGINAL	2C912090	10	55
Transfer roller	ROLLER TRANSFER	2C917010	6	21
Separation electrode	PLATE STA ELIMINATION	2C917080	6	28
Developing unit	PARTS, DV-410, SP	2C993030	11	1
Drum unit	SET, MK-410	2C982010	11	5
Fixing unit	PARTS, FK-410(A), SP	2C993051	12	–
Fixing unit	PARTS, FK-410(E), SP	2C993061	12	–
Heat roller	ROLLER HEAT	2C920050	12	5
Press roller	ROLLER PRESS	2C920060	12	6
Heat roller separation claw	SEPARATOR ASSY	2BR20240	12	24
Exit roller	ROLLER EXIT INNER	2C921010	9	17
Exit pulley	PULLEY EJECT	2C921360	9	46
Switchback roller	ROLLER FEED SHIFT	2C921020	9	18
Switchback pulley	PULLEY FEED SHIFT	2C921040	9	19

Periodic maintenance procedures

Section	Maintenance part/location	Method	Maintenance cycle	Points and cautions	Page
Test copy and test print	Perform at the maximum copy size	Test copy	Every service		



Section	Maintenance part/location	Method	Maintenance cycle	Points and cautions	Page
Paper feed section	Paper feed pulley	Clean or replace	-	Clean with the alcohol.	1-6-5
	Separation pulley	Clean or replace	-	Clean with the alcohol.	1-6-3
	Forwarding pulley	Clean or replace	-	Clean with the alcohol.	1-6-5
	Drawer paper feed pulley	Clean or replace	-	Clean with the alcohol.	1-6-9
	Drawer separation pulley	Clean or replace	-	Clean with the alcohol.	1-6-8
	Drawer forwarding pulley	Clean or replace	-	Clean with the alcohol.	1-6-9
	Bypass paper feed pulley	Clean or replace	-	Clean with the alcohol.	1-6-13
	Bypass separation pad	Clean or replace	-	Clean with the alcohol.	1-6-13
	Left registration roller	Clean or replace	Every 150,000 counts	Clean with alcohol or a dry cloth.	1-6-15
	Right registration roller	Clean	Every 150,000 counts	Clean with alcohol or a dry cloth.	1-6-15
	Registration cleaner	Clean or replace	Every 150,000 counts	Vacuum.	1-6-15
	Trans guide film	Check or replace	-		
	Feed roller	Clean or replace	-	Clean with the alcohol.	1-6-7
Feed pulley	Check or replace	-	Clean with alcohol or a dry cloth.		



Section	Maintenance part/location	Method	Maintenance cycle	Points and cautions	Page
Optical section	Slit glass	Clean	Every 150,000 counts	Clean with alcohol and then a dry cloth.	
	Contact glass	Clean	Every 150,000 counts	Clean with alcohol and then a dry cloth.	
	Mirror 1	Clean	-	Clean with alcohol and then a dry cloth only if vertical black lines appear on the copy image.	
	Mirror 2 and mirror 3	Clean	-	Clean with alcohol and then a dry cloth only if vertical black lines appear on the copy image.	
	Lens	Clean	-	Clean with alcohol and then a dry cloth only if vertical black lines appear on the copy image.	
	Reflector	Clean	-	Clean with alcohol and then a dry cloth only if vertical black lines appear on the copy image.	
	Exposure lamp	Clean or replace	-	Replace if an image problem occurs or after the exposure lamp does not turn on.	1-6-22
	Optical rail	Grease	-	Check noise and shifting and then apply scanner rail grease EM-50E.	
	Original size detection sensor	Clean	-	Clean with alcohol or a dry cloth.	



Section	Maintenance part/location	Method	Maintenance cycle	Points and cautions	Page
Transfer and separation	Transfer roller Separation electrode section	Clean Check or clean	- -	Vaccum or clean with a dry cloth. Clean with the equipped brush.	1-6-42



Section	Maintenance part/location	Method	Maintenance cycle	Points and cautions	Page
Developing section	Developing unit	Check or replace	-	Replace if the problem occurs.	1-6-41



Section	Maintenance part/location	Method	Maintenance cycle	Points and cautions	Page
Drum section	Drum unit	Check or replace	Every 150,000 counts	Replace if the problem occurs.	1-6-38



Section	Maintenance part/location	Method	Maintenance cycle	Points and cautions	Page
Fixing section	Fixing unit	Check or replace	-	Replace if the problem occurs.	1-6-43
	Heat roller	Clean	Every 150,000 counts	Clean with alcohol.	1-6-47
	Press roller	Clean	Every 150,000 counts	Clean with alcohol.	1-6-44
	Heat roller separation	Clean or replace claw	Every 150,000 counts	Clean with alcohol. Replace if it is being lacking, deformed or rubbing.	1-6-46



Section	Maintenance part/location	Method	Maintenance cycle	Points and cautions	Page
Exit section	Exit roller	Check or clean	-	Clean with alcohol or a dry cloth.	
	Exit pulley	Check or clean	-	Clean with alcohol or a dry cloth.	
	Switchback roller	Check or clean	-	Clean with alcohol or a dry cloth.	
	Switchback pulley	Check or clean	-	Clean with alcohol or a dry cloth.	



Section	Maintenance part/location	Method	Maintenance cycle	Points and cautions	Page
Covers	Covers	Clean	Every 150,000 counts	Clean with alcohol or a dry cloth.	



Section	Maintenance part/location	Method	Maintenance cycle	Points and cautions	Page
Other	Image quality	Check and adjust	Every service		

KYOCERA MITA EUROPE B.V.

Hoeksteen 40, 2132 MS Hoofddorp,
The Netherlands
Phone: +31.(0)20.654.000
Home page: <http://www.kyoceramita-europe.com>
Email: info@kyoceramita-europe.com

KYOCERA MITA NEDERLAND B.V.

Hoeksteen 40 2132 MS Hoofddorp
The Netherlands
Phone: +31.(0)20.587.7200

KYOCERA MITA (UK) LTD.

8 Beacontree Plaza
Gillette Way,
Reading Berks RG2 0BS, UK
Phone: +44.(0)118.931.1500

KYOCERA MITA ITALIA S.P.A.

Via Verdi 89 / 91 20063 Cernusco sul Naviglio,
Italy
Phone: +39.02.92179.1

S.A. KYOCERA MITA BELGIUM N.V.

Hermesstraat 8A 1930 Zaventem Belgium
Phone: +32.(0)2.720.9270

KYOCERA MITA FRANCE S.A.

Parc Les Algorithmes
Saint Aubin
91194 GIF-SUR-YVETTE
France

Phone: +33.(0)1.6985.2600

KYOCERA MITA ESPAÑA S.A.

Edificio Kyocera, Avda de Manacor N. 2,
Urb. Parque Rozas 28290 Las Rozas,
Madrid, Spain
Phone: +34.(0)91.631.8392

KYOCERA MITA FINLAND OY

Kirvesmiehenkatu 4 00810 Helsinki,
Finland
Phone: +358.(0)9.4780.5200

KYOCERA MITA (SCHWEIZ) AG

Holzliwisen Industriestrasse 28
8604 Volketswil, Switzerland
Phone: +41.(0)1.908.4949

KYOCERA MITA DEUTSCHLAND GMBH

Mollsfeld 12 D-40670 Meerbusch,
Germany
Phone: +49.(0)2159.918.0

KYOCERA MITA GMBH AUSTRIA

Eduard-Kittenberger Gasse 95
1230 Wien, Austria
Phone: +43.(0)1.86338.0

KYOCERA MITA SVENSKA AB

Box 1402 171 27 Solna, Sweden
Phone: +46.(0)8.546.550.00

KYOCERA MITA NORGE

Postboks 150 Oppsal, NO 0619 Oslo
Olaf Helsetsvai 6, NO 0694 Oslo
Phone: +47.(0)22.62.73.00

KYOCERA MITA DANMARK A/S

Slotsmarken 11, 2
DK-2970 Hørsholm, Denmark
Phone: +45.7022.3880

KYOCERA MITA PORTUGAL LDA.

Rua do Centro Cultural, no 41 1700-106
Lisbon, Portugal
Phone: +351.(0)21.842.9100

KYOCERA MITA SOUTH AFRICA

(PTY) LTD.

527 Kyalami Boulevard,
Kyalami Business Park 1685 Midrand South
Phone: +27.(0)11.466.3290

KYOCERA MITA AMERICA, INC.

Headquarters:

225 Sand Road,
Fairfield, New Jersey 07004-0008,
U.S.A.
Phone: (973) 808-8444

KYOCERA MITA AUSTRALIA PTY. LTD.

Level 3, 6-10 Talavera Road, North Ryde,
N.S.W. 2113 Australia
Phone: (02) 9888-9999

KYOCERA MITA NEW ZEALAND LTD.

1-3 Parkhead Place, Albany
P.O. Box 302 125 NHPC, Auckland,
New Zealand
Phone: (09) 415-4517

KYOCERA MITA (THAILAND) CORP., LTD.

9/209 Ratchada-Prachachem Road,
Bang Sue, Bangkok 10800, Thailand
Phone: (02) 586-0320

KYOCERA MITA SINGAPORE PTE LTD.

121 Genting Lane, 3rd Level,
Singapore 349572
Phone: 67418733

KYOCERA MITA HONG KONG LIMITED

11/F., Mita Centre,
552-566, Castle Peak Road,
Tsuen Wan, New Territories,
Hong Kong
Phone: 24297422

KYOCERA MITA TAIWAN

Corporation.
7F-1~2, No.41, Lane 221, Gangchi Rd.
Neihu District, Taipei, Taiwan, 114. R.O.C.
Phone: (02) 87511560

KYOCERA MITA

2-28, 1-chome, Tamatsukuri, Chuo-ku
Osaka 540-8585, Japan
Phone: (06) 6764-3555
<http://www.kyoceramita.com>

TONER
©2004 KYOCERA MITA Corporation

 **KYOCERA** is a trademark of Kyocera Corporation

Printed in Holland