



KM-2540

KM-3040



SERVICE

MANUAL

Published in April 2008
842JB113
2JBSM063
Rev. 3

CAUTION

RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE. DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS.

It may be illegal to dispose of this battery into the municipal waste stream. Check with your local solid waste officials for details in your area for proper disposal.

ATTENTION

IL Y A UN RISQUE D'EXPLOSION SI LA BATTERIE EST REMPLACÉE PAR UN MODÈLE DE TYPE INCORRECT. METTRE AU REBUT LES BATTERIES UTILISÉES SELON LES INSTRUCTIONS DONNÉES.

Il peut être illégal de jeter les batteries dans des eaux d'égout municipales. Vérifiez avec les fonctionnaires municipaux de votre région pour les détails concernant des déchets solides et une mise au rebut appropriée.

Revision history

| Revision | Date | Replaced pages | Remarks |
|----------|------------------|--|---------|
| 1 | October 31, 2007 | CONTENTS, 1-1-1, 1-1-2, 1-2-1, 1-2-2, 1-2-4, 1-2-10, 1-2-11, 1-3-2, 1-3-22, 1-3-23, 1-3-25, 1-4-18 to 1-4-21, 1-4-38, 1-4-39, 1-5-1, 1-5-41 to 1-5-57, 1-6-1, 1-6-2, 2-4-1, 2-4-3 to 2-4-6 | - |
| 2 | January 8, 2008 | 1-1-4, 1-3-64, 1-3-66 | - |
| 3 | April 25, 2008 | CONTENTS, 1-5-2, 1-5-36 | - |


This page is intentionally left blank.


Safety precautions


This booklet provides safety warnings and precautions for our service personnel to ensure the safety of their customers, their machines as well as themselves during maintenance activities. Service personnel are advised to read this booklet carefully to familiarize themselves with the warnings and precautions described here before engaging in maintenance activities.

Safety warnings and precautions


Various symbols are used to protect our service personnel and customers from physical danger and to prevent damage to their property. These symbols are described below:

 **DANGER:** High risk of serious bodily injury or death may result from insufficient attention to or incorrect compliance with warning messages using this symbol.

 **WARNING:** Serious bodily injury or death may result from insufficient attention to or incorrect compliance with warning messages using this symbol.

 **CAUTION:** Bodily injury or damage to property may result from insufficient attention to or incorrect compliance with warning messages using this symbol.

Symbols

The triangle () symbol indicates a warning including danger and caution. The specific point of attention is shown inside the symbol.



General warning.



Warning of risk of electric shock.



Warning of high temperature.

 indicates a prohibited action. The specific prohibition is shown inside the symbol.



General prohibited action.



Disassembly prohibited.

 indicates that action is required. The specific action required is shown inside the symbol.



General action required.





Remove the power plug from the wall outlet.





Always ground the copier.

1. Installation Precautions


WARNING



- Do not use a power supply with a voltage other than that specified. Avoid multiple connections to one outlet: they may cause fire or electric shock. When using an extension cable, always check that it is adequate for the rated current. 
- Connect the ground wire to a suitable grounding point. Not grounding the copier may cause fire or electric shock. Connecting the earth wire to an object not approved for the purpose may cause explosion or electric shock. Never connect the ground cable to any of the following: gas pipes, lightning rods, ground cables for telephone lines and water pipes or faucets not approved by the proper authorities. 


CAUTION:


- Do not place the copier on an infirm or angled surface: the copier may tip over, causing injury. 
- Do not install the copier in a humid or dusty place. This may cause fire or electric shock. 
- Do not install the copier near a radiator, heater, other heat source or near flammable material.

This may cause fire. 

- Allow sufficient space around the copier to allow the ventilation grills to keep the machine as cool as possible. Insufficient ventilation may cause heat buildup and poor copying performance. 











- Always handle the machine by the correct locations when moving it. 
- Always use anti-toppling and locking devices on copiers so equipped. Failure to do this may cause the copier to move unexpectedly or topple, leading to injury. 

- Avoid inhaling toner or developer excessively. Protect the eyes. If toner or developer is accidentally ingested, drink a lot of water to dilute it in the stomach and obtain medical attention immediately. If it gets into the eyes, rinse immediately with copious amounts of water and obtain medical attention. 





- Advice customers that they must always follow the safety warnings and precautions in the copier's instruction handbook. 

2.Precautions for Maintenance

WARNING

- Always remove the power plug from the wall outlet before starting machine disassembly. 
- Always follow the procedures for maintenance described in the service manual and other related brochures. 
- Under no circumstances attempt to bypass or disable safety features including safety mechanisms and protective circuits. 
- Always use parts having the correct specifications. 
- Always use the thermostat or thermal fuse specified in the service manual or other related brochure when replacing them. Using a piece of wire, for example, could lead to fire or other serious accident. 
- When the service manual or other serious brochure specifies a distance or gap for installation of a part, always use the correct scale and measure carefully. 
- Always check that the copier is correctly connected to an outlet with a ground connection. 
- Check that the power cable covering is free of damage. Check that the power plug is dust-free. If it is dirty, clean it to remove the risk of fire or electric shock. 
- Never attempt to disassemble the optical unit in machines using lasers. Leaking laser light may damage eyesight. 
- Handle the charger sections with care. They are charged to high potentials and may cause electric shock if handled improperly. 

CAUTION

- Wear safe clothing. If wearing loose clothing or accessories such as ties, make sure they are safely secured so they will not be caught in rotating sections. 
- Use utmost caution when working on a powered machine. Keep away from chains and belts. 
- Handle the fixing section with care to avoid burns as it can be extremely hot. 
- Check that the fixing unit thermistor, heat and press rollers are clean. Dirt on them can cause abnormally high temperatures. 

• Do not remove the ozone filter, if any, from the copier except for routine replacement.



• Do not pull on the AC power cord or connector wires on high-voltage components when removing them; always hold the plug itself.



• Do not route the power cable where it may be stood on or trapped. If necessary, protect it with a cable cover or other appropriate item.



• Treat the ends of the wire carefully when installing a new charger wire to avoid electric leaks.



• Remove toner completely from electronic components.



• Run wire harnesses carefully so that wires will not be trapped or damaged.



• After maintenance, always check that all the parts, screws, connectors and wires that were removed, have been refitted correctly. Special attention should be paid to any forgotten connector, trapped wire and missing screws.



• Check that all the caution labels that should be present on the machine according to the instruction handbook are clean and not peeling. Replace with new ones if necessary.



• Handle greases and solvents with care by following the instructions below:



- Use only a small amount of solvent at a time, being careful not to spill. Wipe spills off completely.
- Ventilate the room well while using grease or solvents.
- Allow applied solvents to evaporate completely before refitting the covers or turning the power switch on.
- Always wash hands afterwards.

• Never dispose of toner or toner bottles in fire. Toner may cause sparks when exposed directly to fire in a furnace, etc.




• Should smoke be seen coming from the copier, remove the power plug from the wall outlet immediately.



3.Miscellaneous

WARNING

• Never attempt to heat the drum or expose it to any organic solvents such as alcohol, other than the specified refiner; it may generate toxic gas.



This page is intentionally left blank.

CONTENTS

1-1 Specifications

| | |
|-----------------------------------|-------|
| 1-1-1 Specifications | 1-1-1 |
| 1-1-2 Parts names | 1-1-3 |
| (1) Machine | 1-1-3 |
| (2) Operation panel | 1-1-4 |
| 1-1-3 Machine cross section | 1-1-5 |

1-2 Installation

| | |
|---|--------|
| 1-2-1 Installation environment | 1-2-1 |
| 1-2-2 Unpacking and installation | 1-2-2 |
| (1) Installation procedure | 1-2-2 |
| (2) Setting initial copy modes | 1-2-11 |
| 1-2-3 Installing the key counter (option) | 1-2-12 |

1-3 Maintenance Mode

| | |
|--|--------|
| 1-3-1 Maintenance mode | 1-3-1 |
| (1) Executing a maintenance item | 1-3-1 |
| (2) Maintenance modes item list | 1-3-2 |
| (3) Contents of the maintenance mode items | 1-3-5 |
| 1-3-2 User management | 1-3-71 |
| (1) Using the user management mode | 1-3-71 |
| (2) Job accounting | 1-3-72 |
| (3) Default settings for copying | 1-3-74 |
| (4) Machine default | 1-3-76 |
| (5) Setting MP tray | 1-3-78 |
| (6) Registering non-standard sizes for originals | 1-3-78 |
| (7) Drum refresh | 1-3-78 |
| (8) Printing reports | 1-3-78 |
| (9) Checking total copy count | 1-3-78 |

1-4 Troubleshooting

| | |
|---|--------|
| 1-4-1 Paper misfeed detection | 1-4-1 |
| (1) Paper misfeed indication | 1-4-1 |
| (2) Paper misfeed detection conditions | 1-4-2 |
| (3) Paper misfeeds | 1-4-9 |
| 1-4-2 Self-diagnosis | 1-4-18 |
| (1) Self-diagnostic function | 1-4-18 |
| (2) Self diagnostic codes | 1-4-19 |
| 1-4-3 Image formation problems | 1-4-34 |
| (1) No image appears (entirely white) | 1-4-35 |
| (2) No image appears (entirely black) | 1-4-35 |
| (3) Image is too light | 1-4-36 |
| (4) Background is visible | 1-4-36 |
| (5) A white line appears longitudinally | 1-4-36 |
| (6) A black line appears longitudinally | 1-4-37 |
| (7) A black line appears laterally | 1-4-37 |
| (8) One side of the copy image is darker than the other | 1-4-37 |
| (9) Black dots appear on the image | 1-4-37 |
| (10) Image is blurred | 1-4-38 |
| (11) The leading edge of the image is consistently misaligned with the original | 1-4-38 |
| (12) The leading edge of the image is sporadically misaligned with the original | 1-4-38 |
| (13) Paper creases | 1-4-38 |
| (14) Offset occurs | 1-4-39 |
| (15) Image is partly missing | 1-4-39 |
| (16) Fusing is poor | 1-4-39 |
| (17) Image is out of focus | 1-4-39 |
| (18) Image center does not align with the original center | 1-4-40 |
| 1-4-4 Electric problems | 1-4-41 |
| 1-4-5 Mechanical problems | 1-4-45 |

1-5 Assembly and Disassembly

| | | |
|-------|--|--------|
| 1-5-1 | Precautions for assembly and disassembly | 1-5-1 |
| (1) | Precautions | 1-5-1 |
| (2) | Drum | 1-5-1 |
| (3) | Toner | 1-5-1 |
| (4) | How to tell a genuine Kyocera Mita toner container | 1-5-2 |
| 1-5-2 | Paper feed section | 1-5-3 |
| (1) | Detaching and refitting the forwarding, paper feed and separation pulleys | 1-5-3 |
| (2) | Detaching and refitting the MP separation, MP paper feed and MP forwarding pulleys | 1-5-6 |
| 1-5-3 | Optical section | 1-5-15 |
| (1) | Detaching and refitting the exposure lamp | 1-5-15 |
| (2) | Detaching and refitting the scanner unit | 1-5-19 |
| (3) | Detaching and refitting the scanner wires | 1-5-23 |
| (3-1) | Detaching the scanner wires | 1-5-23 |
| (3-2) | Fitting the scanner wires | 1-5-25 |
| (4) | Detaching and refitting the ISU (reference) | 1-5-28 |
| (5) | Detaching and refitting the laser scanner unit | 1-5-30 |
| (6) | Adjusting the position of the ISU (reference) | 1-5-34 |
| 1-5-4 | Drum section | 1-5-35 |
| (1) | Detaching and refitting the drum unit | 1-5-35 |
| (2) | Detaching and refitting the main charger unit | 1-5-37 |
| (3) | Detaching and refitting the drum separation claws | 1-5-38 |
| 1-5-5 | Developing section | 1-5-39 |
| (1) | Detaching and refitting the developing unit | 1-5-39 |
| 1-5-6 | Transfer section | 1-5-40 |
| (1) | Detaching and refitting the transfer roller unit | 1-5-40 |
| 1-5-7 | Fuser section | 1-5-41 |
| (1) | Detaching and refitting the fuser unit | 1-5-41 |
| (2) | Detaching and refitting the heat roller separation claws | 1-5-44 |
| (3) | Detaching and refitting the press roller | 1-5-45 |
| (4) | Detaching and refitting the fuser heater | 1-5-47 |
| (5) | Detaching and refitting the heat roller | 1-5-49 |
| (6) | Detaching and refitting the fuser thermistor 1 | 1-5-50 |
| (7) | Detaching and refitting the fuser thermistor 2 | 1-5-51 |
| (8) | Detaching and refitting the fuser thermostats 1 and 2 | 1-5-52 |
| (9) | Adjusting front position of the fuser unit (adjusting lateral squareness) | 1-5-54 |
| 1-5-8 | PWBs | 1-5-55 |
| (1) | Detaching and refitting the engine PWB | 1-5-55 |
| 1-5-9 | Others | 1-5-57 |
| (1) | Detaching and refitting the ozone filter 1 | 1-5-57 |
| (2) | Detaching and refitting the ozone filter 2 | 1-5-58 |

1-6 Requirements on PWB Replacement

| | | |
|-------|---|-------|
| 1-6-1 | Upgrading the firmware | 1-6-1 |
| 1-6-2 | Adjustment-free variable resistors (VR) | 1-6-1 |
| 1-6-3 | Remarks on engine PWB replacement | 1-6-2 |
| 1-6-4 | Remarks on main PWB replacement | 1-6-2 |

2-1 Mechanical construction

| | | |
|-------|--|--------|
| 2-1-1 | Paper feed section | 2-1-1 |
| (1) | Cassette paper feed section | 2-1-1 |
| (2) | MP tray paper feed section | 2-1-3 |
| 2-1-2 | Main charging section | 2-1-4 |
| 2-1-3 | Optical section | 2-1-5 |
| (1) | Image scanner section | 2-1-5 |
| (2) | Laser scanner section | 2-1-7 |
| 2-1-4 | Developing section | 2-1-9 |
| (1) | Single component developing system | 2-1-11 |
| 2-1-5 | Transfer and separation sections | 2-1-12 |
| 2-1-6 | Cleaning and charge erasing sections | 2-1-13 |
| 2-1-7 | Fuser section | 2-1-14 |
| 2-1-8 | Eject and switchback sections | 2-1-16 |

| | |
|---|--------|
| 2-1-9 Duplex section | 2-1-17 |
| (1) Paper conveying operation in duplex copying | 2-1-19 |
| 2-2 Electrical Parts Layout | |
| 2-2-1 Electrical parts layout | 2-2-1 |
| (1) PWBs | 2-2-1 |
| (2) Switches and sensors | 2-2-3 |
| (3) Motors | 2-2-5 |
| (4) Clutches and solenoids | 2-2-6 |
| (5) Other electrical components | 2-2-7 |
| 2-3 Operation of the PWBs | |
| 2-3-1 Power source PWB | 2-3-1 |
| 2-3-2 Engine PWB | 2-3-4 |
| 2-3-3 Main PWB | 2-3-13 |
| 2-3-4 Upper operation unit PWB | 2-3-18 |
| 2-3-5 Right operation unit PWB | 2-3-21 |
| 2-3-6 Left operation unit PWB | 2-3-23 |
| 2-4 Appendixes | |
| Maintenance parts list | 2-4-1 |
| Maintenance kits | 2-4-2 |
| Periodic maintenance procedures | 2-4-3 |
| Chart of image adjustment procedures | 2-4-7 |
| General wiring diagram | 2-4-9 |
| INSTALLATION GUIDE | |
| DOCUMENT PROCESSOR | |
| PAPER FEEDER | |
| DOCUMENT FINISHER | |
| BUILT-IN FINISHER | |
| JOB SEPARATOR | |
| FAX System (P) | |
| Printing System (Y) | |

This page is intentionally left blank.

1-1-1 Specifications

Machine

| | |
|--------------------------------|--|
| Type | Desktop |
| Copying method | Electrophotography by semiconductor laser |
| Supported original types | Sheets, books and three-dimensional objects |
| | Maximum original size: A3/11 x 17" |
| Original feed system | Fixed |
| Paper weight | Cassette: 60 to 120 g/m ² (Duplex: 60 to 80 g/m ²) |
| | MP tray : 45 to 200 g/m ² |
| Media type | Cassette: Plain, Rough, Vellum, Recycled, Preprinted, Bond, Color (Colour), Prepunched, Letterhead, Thick paper, High Quality, Custom 1 to 8 |
| | MP tray : Plain, Transparency, Rough, Vellum, Labels, Recycled, Preprinted, Bond, Cardstock, Color (Colour), Prepunched, Letterhead, Thick paper, Envelope, High Quality, Custom 1 to 8 |
| Paper size | Cassette: A3, B4, A4, A4R, B5, B5R, A5R, Folio, 11 x 17", 8 1/2 x 14", 11 x 8 1/2", 8 1/2 x 11", 5 1/2 x 8 1/2", 8 1/2 x 13" (Oficio II), 8 1/2 x 13 1/2", 8K, 16K, 16KR |
| | MP tray : A3, B4, A4, A4R, B5, B5R, A5R, B6R, 8K, 16K, 16KR, 11 x 17", 8 1/2 x 14", 11 x 8 1/2", 8 1/2 x 11", 5 1/2 x 8 1/2", 8 1/2 x 13" (Oficio II), 8 1/2 x 13 1/2", Executive, Postcards, Return postcard, Envelope DL, Envelope C5, Envelope C4, Comm. #10, Comm. #9, Comm. #6-3/4, Monarch, ISO B5, Youkei 2, Youkei 4 |
| Zoom level | Manual mode: 25 to 400%, 1% increments |
| | Auto mode: Preset Zoom |
| Copying speed | 25 ppm model |
| | Simplex |
| | A3/11 x 17" : 12.5 sheets/min. |
| | B4/8 1/2 x 14": 12.5 sheets/min. |
| | A4/11 x 8 1/2": 25 sheets/min. |
| | A4R/8 1/2 x 11": 17.5 sheets/min. |
| | B5 : 25 sheets/min. |
| | B5R: 20 sheets/min. |
| | Duplex |
| | A3/11 x 17" : 9 sheets/min. |
| | B4/8 1/2 x 14": 9 sheets/min. |
| | A4/11 x 8 1/2": 19 sheets/min. |
| | A4R/8 1/2 x 11": 10 sheets/min. |
| | B5 : 20 sheets/min. |
| | B5R: 11 sheets/min. |
| | 30 ppm model |
| | Simplex |
| | A3/11 x 17" : 15 sheets/min. |
| | B4/8 1/2 x 14": 15 sheets/min. |
| | A4/11 x 8 1/2": 30 sheets/min. |
| | A4R/8 1/2 x 11": 22 sheets/min. |
| | B5 : 30 sheets/min. |
| | B5R: 20 sheets/min. |
| | Duplex |
| | A3/11 x 17" : 9 sheets/min. |
| | B4/8 1/2 x 14": 10 sheets/min. |
| | A4/11 x 8 1/2": 20 sheets/min. |
| | A4R/8 1/2 x 11": 11 sheets/min. |
| | B5 : 21 sheets/min. |
| | B5R: 11 sheets/min. |
| First copy time | 4.7 s or less |
| Warm-up time | 15 s (room temperature 22°C/71.6°F, 60% RH) |
| | Recovery from low power mode: 10 s (room temperature 22°C/71.6°F, 60% RH) |
| | Recovery from sleep mode: 15 s (room temperature 22°C/71.6°F, 60% RH) |
| Paper capacity | Cassette : 500 sheets (80 g/m ²) |
| | MP tray : 200 sheets (80 g/m ²) |
| Output tray capacity | Top tray : 250 sheets (80 g/m ²) |
| | 150 sheets (80 g/m ² , with job separator) |
| | 100 sheets (80 g/m ² , with built-in finisher) |
| Continuous copying | 1 to 999 sheets |
| Light source | Inert gas lamp |
| Scanning system | Flat bed scanning by CCD image sensor |
| Photoconductor | a-Si (drum diameter 30 mm) |
| Image white system | Semiconductor laser |
| Charging system | Single positive corona charging |
| Developing system | Dry, reverse developing (single component system) |
| | Developer: 1-component, magnetism toner |
| | Toner replenishing: automatic from a toner container |
| Transfer system | Transfer roller |
| Separation system | Separation electrode |
| Cleaning system | Cleaning blade and roller |

| | |
|-----------------------------|--|
| Charge erasing system | Exposure by cleaning lamp |
| Fusing system | Heat roller |
| | Heat source: halogen heaters |
| | Abnormally high temperature protection devices: thermostats |
| Image storage memory | 64 MB (standard) |
| Resolution | 600 x 600 dpi |
| Operating environment | Temperature: 10 to 32.5°C/50 to 90.5°F |
| | Humidity: 15 to 80% RH |
| | Altitude: 2500 m/8,202 ft maximum |
| | Brightness: 1500 lux maximum |
| Dimensions | 570 (W) x 640 (D) x 767.2 (H) mm (main unit only) |
| | 22 7/16" (W) x 25 3/16" (D) x 30 3/16" (H) |
| Weight | 75 kg/165 lbs |
| Floor requirements | 725 (W) x 640 (D) mm (using MP tray) |
| | 28 9/16" (W) x 25 3/16" (D) |
| Power source | 120 V AC, 60 Hz, 11.2 A |
| | 220 to 240 V AC, 50 Hz, 6.0 A |
| Power consumption | 1360 W |
| Options | Document processor, paper feeder, document finisher, built-in finisher, job separator, key counter, printer kit and FAX kit |

NOTE: These specifications are subject to change without notice.



1-1-2 Parts names

(1) Machine





Figure 1-1-1

- | | | |
|-----------------------------------|--------------------------------|----------------------------------|
| 1. Original cover (Option) | 11. Toner container | 21. Paper width adjusting tab |
| 2. Platen | 12. Toner container stopper | 22. Paper length guide |
| 3. Original size indicator plates | 13. Main charger | 23. Carrying handles |
| 4. Left cover 1 | 14. Waste toner box | 24. Top tray |
| 5. Left cover 1 Lever | 15. Cleaning brush | 25. Output stopper |
| 6. Left cover 2 | 16. Knob (A1) | 26. Paper width guides |
| 7. Clip holder | 17. Paper feed unit (A2) | 27. Main power switch |
| 8. Operation panel | 18. Paper feed unit cover (A3) | 28. MP tray (multi-purpose tray) |
| 9. Cassette 1 | 19. Front cover | |
| 10. Cassette 2 | 20. Paper width guides | |

(2) Operation panel**Figure 1-1-2**

- | | |
|--|--------------------------------|
| 1. Brightness adjustment dial | 11. Interrupt key/indicator |
| 2. Copier key/indicator | 12. Energy saver key/indicator |
| 3. Printer key/indicator | 13. Power key/indicator |
| 4. Fax key/indicator | 14. Main power indicator |
| 5. System menu/Counter key | 15. Touch panel |
| 6. Print management key/indicator | 16. Numeric keys |
| 7. Repeat copy key/indicator | 17. Reset key |
| 8. Job build key/indicator | 18. Stop/Clear key |
| 9. Mixed sized originals key/indicator | 19. Start key/indicator |
| 10. Logout key | |

1-1-3 Machine cross section




Figure 1-1-3 Machine cross section

TONER
www.tonerplus.co

1. Paper feed section
2. Main charging section
3. Optical section
4. Developing section
5. Transfer and separation section

6. Cleaning and charge erasing section
7. Fuser section
8. Eject and switchback section
9. Duplex section

This page is intentionally left blank.



1-2-1 Installation environment

1. Temperature: 10 to 32.5°C/50 to 90.5°F
2. Humidity: 15 to 80% RH
3. Power supply: 120 V AC, 11.2 A
220 to 240 V AC, 6.0 A
4. Power source frequency: 50 Hz \pm 0.3%/60 Hz \pm 0.3%
5. Installation location

Avoid direct sunlight or bright lighting. Ensure that the photoconductor will not be exposed to direct sunlight or other strong light when removing paper jams.

Avoid locations subject to high temperature and high humidity or low temperature and low humidity; an abrupt change in the environmental temperature; and cool or hot, direct air.

Avoid places subject to dust and vibrations.

Choose a surface capable of supporting the weight of the machine.

Place the machine on a level surface (maximum allowance inclination: 1°).

Avoid air-borne substances that may adversely affect the machine or degrade the photoconductor, such as mercury, acidic or alkaline vapors, inorganic gasses, NOx, SOx gases and chlorine-based organic solvents.

Select a well-ventilated location.
6. Allow sufficient access for proper operation and maintenance of the machine.
Machine front: 1000 mm/39 3/8" Machine rear: 100 mm/3 15/16"
Machine right: 300 mm/11 13/16" Machine left: 400 mm/15 3/4"





Figure 1-2-1 Installation dimensions

1-2-2 Unpacking and installation

(1) Installation procedure



Moving the machine

When moving the machine, pull out the four carrying handles on the right and left sides and hold them.




Figure 1-2-2

Unpacking.




Figure 1-2-3 Unpacking

- | | |
|---------------------------|------------------------|
| 1. Machine | 12. Document tray |
| 2. Outer case | 13. Power cord |
| 3. Inner frame | 14. Plastic bag |
| 4. Skid | 15. Operation guide |
| 5. Bottom front left pad | 16. Size plates |
| 6. Bottom front right pad | 17. Plastic bag |
| 7. Bottom rear left pad | 18. Cursor pins |
| 8. Bottom rear right pad | 19. Hinge joints |
| 9. Bottom pad | 20. Paper storage bags |
| 10. Top pad | 21. Guide case |
| 11. Machine cover | |

Caution: Place the machine on a level surface.

Remove the eject spacer and tapes.

1. Remove the eject spacer.
2. Remove three tapes.




Figure 1-2-4

Install the optional paper feeder.

1. Install the optional paper feeder as necessary.
2. Verify levelness at the four corners of the platen using a level gauge, and adjust the level bolts at the bottom of the machine to optimize levelness.

Release the scanner pins.

1. Remove two tapes.
2. Remove two scanner pins.




Figure 1-2-5

Release of cassette lift plate.

1. Pull cassette 1 and 2 out. Remove the lift plate stopper from each cassette and attach it to the storage location. When moving the machine, attach the lift plate stopper in original position.




Figure 1-2-6

Load paper.

1. Holding the paper width adjusting tab both ends, move the paper width guides to fit the paper size.




Figure 1-2-7

2. Adjust the paper length guide to fit the paper size.




Figure 1-2-8

3. Align the paper flush against the left side of the cassette.





Figure 1-2-9


4. Gently push cassette 1 and 2 back in.

Install the toner container.


1. Open the front cover.
2. Hold the toner container vertically and tap the upper part five times or more.
Turn the toner container upside down and tap the upper part five times or more.

**Figure 1-2-10**

3. Shake the toner container up and down five times or more.
Turn the toner container upside down and shake it five times or more.

**Figure 1-2-11**

4. Shake the toner container approximately five times in the horizontal direction to stir toner.

**Figure 1-2-12**

5. Gently push the toner container into the machine along the rails. Push the container all the way into the machine until it locks in place.




Figure 1-2-13

Install the waste toner box.

1. Install the waste toner box in the machine.
2. Close the front cover.




Figure 1-2-14

Install the optional original cover or the DP.

1. Install the optional original cover or DP.

Install other optional devices.

1. Install the optional devices (job separator, built-in finisher, document finisher, printer kit and/or fax kit etc.) as necessary.

Connect the power cord.

1. Connect the power cord to the connector on the machine.
2. Insert the power plug into the wall outlet.

Installing toner.

1. Turn the main power switch on. Toner installation is started.
2. The drive chain is disengaged when toner installation is completed.
Run maintenance mode U130 if [Add Toner] remains displayed even after the drive chain is disengaged.

Output an own-status report (maintenance item U000).

1. Press the status key.
2. Enter the maintenance mode by entering 10871087 using the numeric keys.
3. Enter 000 using the numeric keys and press the start key.
4. Select MAINTENANCE and press the start key to output a list of the current settings of the maintenance items.
5. Press the stop/clear key.

Exit maintenance mode.

1. Enter 001 using the numeric keys and press the start key. The machine exits the maintenance mode.

Print out the user setting list.

1. Select [Report Print] to output the user various setting reports.

Make test copies.

1. Place an original and make test copies.

Attaching the language label (230 V specifications only).

1. According to need, attach the correspond language label.



Installing the guide case.

1. Install the guide case to the machine right.




Figure 1-2-14-1

Completion of the machine installation.

(2) Setting initial copy modes

Factory settings are as follows:

| Maintenance item No. | Contents | Factory setting |
|----------------------|--|-----------------------|
| U253 | Switching between double and single counts | Double count (A3/LGR) |
| U254 | Turning auto start function ON/OFF | ON |
| U260 | Selecting the timing for copy counting | After ejection |
| U277 | Setting auto application change time | 30 s |
| U285 | Setting service status page | ON |
| U324 | Setting the main charger cleaning indication | ON |
| U326 | Setting the black line cleaning indication | ON |
| U342 | Setting the ejection restriction | ON |
| U343 | Switching between duplex/simplex copy mode | OFF |

1-2-3 Installing the key counter (option)

Installing the key counter requires the following component:

Key counter (P/N 3025418011)

Key counter set (P/N 302A369708)

Supplied parts of key counter set:

Key counter socket assembly (P/N 3029236241)

Key counter cover (P/N 3066060011)

Key counter mount (P/N 3066060041)

Key counter retainer (P/N 302GR03020)

Key counter cover retainer (P/N 302GR03010)

One (1) M3 × 8 tap-tight P screw (P/N 5MBTPB3008PW++R)

Two (2) M4 × 10 tap-tight P screws (P/N 5MBTPB4010PW++R)

Two (2) M4 × 10 tap-tight S screws (P/N 5MBTPB4010TW++R)

Two (2) M3 × 6 bronze flat-head screws (P/N 7BB003306H)

One (1) M4 × 20 tap-tight S screw (P/N 7BB100420H)

One (1) M3 bronze nut (P/N 7BC1003055++H01)

One (1) M3 × 8 bronze binding screw (P/N B1B03080)

One (1) M4 × 30 tap-tight S screw (P/N B1B54300)

Five (5) M4 × 6 chrome TP screws (P/N B4A04060)

Two (2) M4 × 10 chrome TP screws (P/N B4A04100)

Procedure

1. Press the power key on the operation panel to off. Make sure that the power indicator and the memory indicator are off before turning off the main power switch. And then unplug the power cable from the wall outlet.
2. Fit the key counter socket assembly to the key counter retainer using two screws and nut.
3. Fit the key counter mount to the key counter cover using two screws.
4. Fit the key counter retainer to the key counter mount using two screws.




Figure 1-2-15

5. Remove two screws and remove the scanner right cover.
6. Cut out the aperture plate on the upper right cover using nippers.
7. Pull the key counter wire out.




Figure 1-2-16

8. Seat the fook of the key counter cover retainer in the aperture in the right upper cover.
9. Fit the key counter cover retainer using two screws.




Figure 1-2-17

10. Pass the 4-pin connector of the key counter signal cable through the aperture in the key counter cover retainer.
11. Insert the 4-pin connector of the key counter signal cable into the 4-pin connector of the key counter wire.
12. Hook the square hole on the key counter cover onto the key counter cover retainer.
13. Fit the key counter unit using the screw.




Figure 1-2-18

14. Seat the 2-pin and the 4-pin connectors between the right upper cover and the partition plate.
15. Refit the scanner right cover. Be sure not that the 2-pin connector is not pinched between the scanner right cover and the upper right cover.




Figure 1-2-19

16. Insert the key counter into the key counter socket assembly.
17. Turn the main power switch on and enter the maintenance mode.
18. Run maintenance item U204 and select ON.
19. Exit the maintenance mode.
20. Check that the message requesting the key counter to be inserted is displayed on the touch panel when the key counter is pulled out.
21. Check that the counter counts up as prints are made.





Figure 1-2-20

1-3-1 Maintenance mode

The machine is equipped with a maintenance function which can be used to maintain and service the machine.

(1) Executing a maintenance item



(2) Maintenance modes item list

| Section | Item No. | Content of maintenance item | Initial setting* |
|---|----------|--|--|
| General | U000 | Outputting an own-status report | - |
| | U001 | Exiting the maintenance mode | - |
| | U002 | Setting the factory default data | - |
| | U003 | Setting the service telephone number | *****1,*2 |
| | U004 | Displaying the machine number | - |
| | U005 | Copying without paper | - |
| | U019 | Displaying the ROM version | - |
| Initialization | U020 | Initializing all data | - |
| | U021 | Initializing counters and mode settings | - |
| | U022 | Initializing backup memory | - |
| Drive, paper feed, paper conveying and cooling system | U030 | Checking motor operation | - |
| | U031 | Checking switches for paper conveying | - |
| | U032 | Checking clutch operation | - |
| | U033 | Checking solenoid operation | - |
| | U034 | Adjusting the print start timing Adjusting the leading edge registration Adjusting the center line Adjusting the trailing edge registration | 2.0/0/0/0*1 0/0/0/-1.0/-1.0/-1.0/0*1 0*1 |
| | U035 | Setting the printing area for folio paper Length Width | 330*1 210*1 |
| | U051 | Adjusting the deflection in the paper | 0/50/50/40/10*1 |
| | U053 | Setting the adjustment of the motor speed | 0/-1/-2/0/2/-8/0*1 |
| | U059 | Setting fan mode | 45*1 |
| | U061 | Turning the exposure lamp on | - |
| Optical | U063 | Adjusting the shading position | 0*1 |
| | U065 | Adjusting the scanner magnification Main scanning direction/auxiliary scanning direction | 0/0*1 |
| | U066 | Adjusting the scanner leading edge registration | 0/0*1 |
| | U067 | Adjusting the scanner center line | 0/0*1 |
| | U068 | Adjusting the scanning position for originals from the DP | 0/0*1 |
| | U070 | Adjusting the DP magnification | 0/0*1 |
| | U071 | Adjusting the DP scanning timing | 0/0/0/0*1 |
| | U072 | Adjusting the DP center line | 0/0/0*1 |
| | U073 | Checking scanner operation | - |
| | U074 | Adjusting the DP input light luminosity | 0*1 |
| | U080 | Setting the economy mode | -6*1 |
| | U087 | Setting DP reading position modification operation | 35*1 |
| | U089 | Outputting a MIP-PG pattern | - |
| | U093 | Setting the exposure density gradient Text and photo/Text/Photo | 0/0/0/2/3*1 |
| | U099 | Adjusting original size detection | 215/30/240*1 |

*Initial setting for executing U020, *1: The item initialized for executing U020, *2: The item initialized for executing U021

| Section | Item No. | Content of maintenance item | Initial setting* |
|---------------------------------------|----------|--|---|
| High voltage | U100 | Setting the main high voltage | - |
| | U101 | Setting the other high voltages | 26/58/50/89/1* ¹ 115/91/68/40/92* ¹ |
| | U110 | Checking the drum count | - |
| | U114 | Setting separation charger mode | 4* ¹ |
| | U117 | Checking the drum number | - |
| | U118 | Displaying the drum history | - |
| Developing | U130 | Initial setting for the developing unit | - |
| | U135 | Checking toner motor operation | 100/30/100* ¹ |
| | U144 | Setting toner loading operation | 0/5/30* ¹ |
| | U150 | Checking sensors for toner | - |
| | U157 | Checking/clearing the developing drive time | - |
| | U158 | Checking the developing count | - |
| Fuser and cleaning | U161 | Setting the fuser control temperature Driving start temperature when warm-up starts Fuser center control temperature for displaying [Ready for copying.] Fuser edge control temperature for displaying [Ready for copying.] Fuser center control temperature during printing Time of period from driving until Ready is displayed | 110* ¹ 165* ¹ 155* ¹ 165* ¹ 0* ¹ |
| | U163 | Resetting the fuser problem data | - |
| | U167 | Checking/clearing the fuser counts | - |
| | U193 | Setting the fuser drive control | ON* ¹ |
| | U199 | Checking the fuser temperature | - |
| Operation panel and support equipment | U200 | Turning all LEDs on | - |
| | U201 | Initializing the touch panel | - |
| | U202 | Setting the KMAS host monitoring system | - |
| | U203 | Checking DP operation | - |
| | U204 | Setting the presence or absence of a key card or key counter | OFF* ^{1,2} |
| | U206 | Setting the presence or absence of the coin vender | - |
| | U207 | Checking the operation panel keys | - |
| | U233 | Limiting job separator output | MODE0* ^{1,2} |
| | U236 | Setting the limit for the ejection section of the built-in finisher | OFF* ^{1,2} |
| | U243 | Checking the operation of the DP motors | - |
| | U244 | Checking the DP switches | - |
| | U245 | Checking messages | - |
| | U246 | Setting the finisher | 0/0/0* ¹ |
| | U247 | Setting the paper feed device | - |
| Mode setting | U250 | Setting the maintenance cycle | 300000* ^{1,2} |
| | U251 | Checking/clearing the maintenance count | - |
| | U252 | Setting the destination | - |
| | U253 | Switching between double and single counts | Double count (A3/LGR)* ¹ |
| | U254 | Turning auto start function ON/OFF | ON* ^{1,2} |
| | U260 | Selecting the timing for copy counting | After ejection* ^{1,2} |

*Initial setting for executing U020, *1: The item initialized for executing U020, *2: The item initialized for executing U021

www.tonerplus.com.ua

| Section | Item No. | Content of maintenance item | Initial setting* |
|------------------|----------|--|---|
| Mode setting | U265 | Setting OEM purchaser code | 0 ^{*1} |
| | U277 | Setting auto application change time | 30 ^{*1,2} |
| | U285 | Setting service status page | ON ^{*1,2} |
| | U324 | Setting the main charger cleaning indication | ON ^{*1,2} |
| | U326 | Setting the black line cleaning indication | ON/8 ^{*1,2} |
| | U332 | Setting the size conversion factor | 1.0/1.0/1.0 ^{*1,2} |
| | U339 | Setting the drum heater ON/OFF | 0 ^{*1,2} |
| | U341 | Specific paper feed location setting for printing function | - |
| | U342 | Setting the ejection restriction | ON ^{*1,2} |
| | U343 | Switching between duplex/simplex copy mode | OFF ^{*1,2} |
| | U344 | Setting the low-power mode | ENERGY STAR (120 V) ^{*1,2} GEEA (220-240 V) ^{*1,2} |
| | U345 | Setting the value for maintenance due indication | - |
| Image processing | U402 | Adjusting margins of image printing | 3.0/3.0/3.0/4.0/6.5/4.6 ^{*1} |
| | U403 | Adjusting margins for scanning an original on the platen | 2.0/2.0/2.0/2.0 ^{*1} |
| | U404 | Adjusting margins for scanning an original from the DP | 3.0/2.5/3.0/4.0 ^{*1} |
| | U407 | Adjusting the leading edge registration for memory image printing | 0 ^{*1} |
| | U411 | Adjusting the scanner automatically | - |
| Others | U901 | Checking copy counts by paper feed locations | - |
| | U903 | Checking/clearing the paper jam counts | - |
| | U904 | Checking/clearing the service call counts | - |
| | U905 | Checking counts by optional devices | - |
| | U906 | Resetting partial operation control | - |
| | U908 | Checking the total counter value | - |
| | U910 | Clearing the black ratio data | - |
| | U911 | Checking/clearing copy counts by paper sizes | - |
| | U917 | Setting backup data reading/writing | - |
| | U920 | Checking the copy counts | - |
| | U925 | Checking/clearing the system error counts | - |
| | U926 | Rewriting FAX program | - |
| | U927 | Clearing the all copy counts and machine life counts (one time only) | - |
| | U928 | Checking machine life counts | - |
| | U931 | Setting the automatic toner install | ON ^{*1} |
| | U935 | Relay board maintenance | MODE0 ^{*1,2} |
| | U942 | Setting of deflection for feeding from DP | 0/0 ^{*1} |
| | U984 | Checking the developing unit number | - |
| | U985 | Displaying the developing unit history | - |
| | U990 | Checking/clearing the time for the exposure lamp to light | - |
| | U991 | Checking the scanner count | - |
| | U993 | Outputting a VTC-PG pattern | - |

*Initial setting for executing U020, *1: The item initialized for executing U020, *2: The item initialized for executing U021

(3) Contents of the maintenance mode items

| Maintenance item No. | Description | | | | | | | | | | |
|----------------------|--|---------|-------------|-------------|---|-----|-----------------------------------|--------------|--------------------------------------|----------------|----------------------------|
| U000 | <p>Outputting an own-status report</p> <p>Description Prints out a list of the current settings of all maintenance items, and occurrences of paper jams and service calls. Also, prints out a list of the toner coverage report (total toner coverage report, copy toner coverage report, printer toner coverage report, fax toner coverage report).</p> <p>Purpose To check the current setting of the maintenance items, or the occurrences of paper jams and service calls. Before initializing or replacing the backup RAM, print out a list of the current settings of the maintenance items so that you can reenter the same settings after initialization or replacement.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select the item to be output. <table border="1"> <thead> <tr> <th>Display</th><th>Output list</th></tr> </thead> <tbody> <tr> <td>MAINTENANCE</td><td>List of the current settings of the maintenance modes</td></tr> <tr> <td>JAM</td><td>List of the paper jam occurrences</td></tr> <tr> <td>SERVICE CALL</td><td>List of the service call occurrences</td></tr> <tr> <td>TONER COVERAGE</td><td>List of the toner coverage</td></tr> </tbody> </table> <ol style="list-style-type: none"> 3. Press the start key. The interrupt copy mode is entered and a list is output. When A4/11" x 8 1/2" paper is available, a report of this size is output. If not, specify the paper feed location. When output is complete, the screen for selecting an item is displayed. <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p> | Display | Output list | MAINTENANCE | List of the current settings of the maintenance modes | JAM | List of the paper jam occurrences | SERVICE CALL | List of the service call occurrences | TONER COVERAGE | List of the toner coverage |
| Display | Output list | | | | | | | | | | |
| MAINTENANCE | List of the current settings of the maintenance modes | | | | | | | | | | |
| JAM | List of the paper jam occurrences | | | | | | | | | | |
| SERVICE CALL | List of the service call occurrences | | | | | | | | | | |
| TONER COVERAGE | List of the toner coverage | | | | | | | | | | |
| U001 | <p>Exiting the maintenance mode</p> <p>Description Exits the maintenance mode and returns to the normal copy mode.</p> <p>Purpose To exit the maintenance mode.</p> <p>Method Press the start key. The normal copy mode is entered.</p> | | | | | | | | | | |
| U002 | <p>Setting the factory default data</p> <p>Description Restores the machine conditions to the factory default settings.</p> <p>Purpose To move the mirror frame of the scanner to the position for transport (position in which the frame can be fixed).</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Press [MODE1(ALL)] on the touch panel. 3. Press the start key. The mirror frame of the scanner returns to the position for transport. 4. Turn the main power switch off and on. | | | | | | | | | | |

| Maintenance item No. | Description | | | | | | | | |
|-------------------------|---|---|---|---|---|---|---------|------|-------|
| U003 | <p>Setting the service telephone number</p> <p>Description Sets the telephone number to be displayed when a service call code is detected.</p> <p>Purpose To set the telephone number to call service when installing the machine.</p> <p>Method Press the start key. The currently set telephone number is displayed.</p> <p>Setting</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Enter the telephone number (up to 15 digits) using the numeric keys. To enter symbols such as hyphens and parentheses, select as required from the symbols displayed on the touch panel as shown below. To move the cursor, press Left or Right in the bottom row. <table border="1" data-bbox="335 622 563 772"> <tbody> <tr> <td>*</td><td>#</td></tr> <tr> <td>(</td><td>)</td></tr> <tr> <td>-</td><td>(Space)</td></tr> <tr> <td>Left</td><td>Right</td></tr> </tbody> </table> <ol style="list-style-type: none"> 3. Press the start key. The telephone number is set. <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p> | * | # | (|) | - | (Space) | Left | Right |
| * | # | | | | | | | | |
| (|) | | | | | | | | |
| - | (Space) | | | | | | | | |
| Left | Right | | | | | | | | |
| U004 | <p>Displaying the machine number</p> <p>Description Displays the machine number.</p> <p>Purpose To check the machine number.</p> <p>Method Press the start key. The currently machine number is displayed.</p> <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p> | | | | | | | | |

| Maintenance item No. | Description | | | | | | |
|-------------------------|---|---------|-----------|-----|----------------------------|----------|---|
| U005 | <p>Copying without paper</p> <p>Description Simulates the copy operation without paper feed.</p> <p>Purpose To check the overall operation of the machine.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select the item to be operated. <table border="1" data-bbox="335 504 1398 629"> <thead> <tr> <th>Display</th><th>Operation</th></tr> </thead> <tbody> <tr> <td>PPC</td><td>Only the machine operates.</td></tr> <tr> <td>PPC + DP</td><td>Both the machine and DP operate (continuous operation).</td></tr> </tbody> </table> <ol style="list-style-type: none"> 3. Press the start key. 4. Press the interrupt key. The copy mode screen is displayed. 5. Set the operation conditions required on the copy mode screen. Changes in the following settings can be made. Paper feed locations Magnifications Simplex or duplex copy mode Number of copies: in simplex copy mode, continuous copying is performed when set to 999; in duplex copy mode, continuous copying is performed regardless of the setting. Copy density Keys on the operation panel 6. To control the paper feed pulley, remove all the paper in the drawers, or the drawers. With the paper present, the paper feed pulley does not operate. 7. Press the start key. The operation starts. Copy operation is simulated without paper under the set conditions. To stop continuous operation, press the stop/clear key. 8. To return to the screen for selecting an item, press the interrupt key. <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p> | Display | Operation | PPC | Only the machine operates. | PPC + DP | Both the machine and DP operate (continuous operation). |
| Display | Operation | | | | | | |
| PPC | Only the machine operates. | | | | | | |
| PPC + DP | Both the machine and DP operate (continuous operation). | | | | | | |


| Maintenance item No. | Description | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|----------------------|---|---------|-------------|------|-----------------|-----------|------------------|--------|-------------------|-------------|--------------------|----------|--------------------------|-----------------|--------------------------|------------|---|---------|-------------------------------|----|-----------------------------|-----------------|---------------------------------------|----------|--|----------------|--|--------------|------------------|
| U019 | <p>Displaying the ROM version</p> <p>Description Displays the part number of the ROM fitted to each PWB.</p> <p>Purpose To check the part number or to decide, if the newest version of ROM is installed.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. The ROM version are displayed. 2. Change the screen using the * or # keys. <table border="1"> <thead> <tr> <th>Display</th><th>Description</th></tr> </thead> <tbody> <tr> <td>MAIN</td><td>Main PWB ROM IC</td></tr> <tr> <td>MAIN BOOT</td><td>Main PWB booting</td></tr> <tr> <td>ENGINE</td><td>Engine PWB ROM IC</td></tr> <tr> <td>ENGINE BOOT</td><td>Engine PWB booting</td></tr> <tr> <td>LANGUAGE</td><td>Standard language ROM IC</td></tr> <tr> <td>OPTION LANGUAGE</td><td>Optional language ROM IC</td></tr> <tr> <td>DICTIONARY</td><td>-</td></tr> <tr> <td>PRINTER</td><td>Optional printer board ROM IC</td></tr> <tr> <td>DP</td><td>Optional DP main PWB ROM IC</td></tr> <tr> <td>OPTION CASSETTE</td><td>Optional paper feeder main PWB ROM IC</td></tr> <tr> <td>INNER DF</td><td>Optional built-in finisher main PWB ROM IC</td></tr> <tr> <td>SIMPLE DF MAIN</td><td>Optional document finisher main PWB ROM IC</td></tr> <tr> <td>ENGINE POWER</td><td>Engine power CPU</td></tr> </tbody> </table> <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p> | Display | Description | MAIN | Main PWB ROM IC | MAIN BOOT | Main PWB booting | ENGINE | Engine PWB ROM IC | ENGINE BOOT | Engine PWB booting | LANGUAGE | Standard language ROM IC | OPTION LANGUAGE | Optional language ROM IC | DICTIONARY | - | PRINTER | Optional printer board ROM IC | DP | Optional DP main PWB ROM IC | OPTION CASSETTE | Optional paper feeder main PWB ROM IC | INNER DF | Optional built-in finisher main PWB ROM IC | SIMPLE DF MAIN | Optional document finisher main PWB ROM IC | ENGINE POWER | Engine power CPU |
| Display | Description | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| MAIN | Main PWB ROM IC | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| MAIN BOOT | Main PWB booting | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ENGINE | Engine PWB ROM IC | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ENGINE BOOT | Engine PWB booting | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| LANGUAGE | Standard language ROM IC | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| OPTION LANGUAGE | Optional language ROM IC | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| DICTIONARY | - | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| PRINTER | Optional printer board ROM IC | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| DP | Optional DP main PWB ROM IC | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| OPTION CASSETTE | Optional paper feeder main PWB ROM IC | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| INNER DF | Optional built-in finisher main PWB ROM IC | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SIMPLE DF MAIN | Optional document finisher main PWB ROM IC | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ENGINE POWER | Engine power CPU | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| U020 | <p>Initializing all data</p> <p>Description Initializes all the backup RAM on the main PWB to return to the original settings. Refer to *1 of the maintenance mode item list about the item initialized. Reset each initialized mode based on an own-status report U000 printed at installing the machine.</p> <p>Purpose To be executed as required.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Press [INCH]. 3. Press the start key. All data in the backup memory is initialized and the default setting for the inch specifications is registered. 4. Turn the main power switch off and on. | | | | | | | | | | | | | | | | | | | | | | | | | | | | |




| Maintenance item No. | Description | | | | | | | | | | | | |
|----------------------|---|---------|-------------|--------|---|------|--|-----------|---|------------|--------------------------------|------|---------------------|
| U021 | <p>Initializing counters and mode settings</p> <p>Description Initializes all settings, except those pertinent to the type of machine, namely each counter, service call history and mode setting. Also initializes backup RAM according to region specification selected in maintenance item U252 Setting the destination. Refer to *2 of the maintenance mode item list about the item initialized.</p> <p>Purpose To return the machine settings to their factory default.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Press [EXECUTE] on the touch panel. 3. Press the start key. All data other than that for adjustments due to variations between machines is initialized based on the destination setting. 4. Turn the main power switch off and on. | | | | | | | | | | | | |
| U022 | <p>Initializing backup memory</p> <p>Description Initializes only the backup data for image processing.</p> <p>Purpose To be executed as required.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select the item to initialize. <table border="1"> <thead> <tr> <th>Display</th><th>Description</th></tr> </thead> <tbody> <tr> <td>ENGINE</td><td>Initialize the backup data of engine PWB.</td></tr> <tr> <td>DP</td><td>Initialize the backup data of DP main PWB.</td></tr> <tr> <td>MAIN</td><td>Initialize the backup data of main PWB.</td></tr> </tbody> </table> <ol style="list-style-type: none"> 3. Press [EXECUTE] on the touch panel. 4. Press the start key. All data in the backup RAM is initialized. 5. Turn the main power switch off and on. | Display | Description | ENGINE | Initialize the backup data of engine PWB. | DP | Initialize the backup data of DP main PWB. | MAIN | Initialize the backup data of main PWB. | | | | |
| Display | Description | | | | | | | | | | | | |
| ENGINE | Initialize the backup data of engine PWB. | | | | | | | | | | | | |
| DP | Initialize the backup data of DP main PWB. | | | | | | | | | | | | |
| MAIN | Initialize the backup data of main PWB. | | | | | | | | | | | | |
| U030 | <p>Checking motor operation</p> <p>Description Drives each motor.</p> <p>Purpose To check the operation of each motor.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select the motor to be operated. The operation starts. <table border="1"> <thead> <tr> <th>Display</th><th>Operation</th></tr> </thead> <tbody> <tr> <td>FEED</td><td>Paper feed motor operates</td></tr> <tr> <td>MAIN</td><td>Main motor operates</td></tr> <tr> <td>EJECT(FW)</td><td>Eject motor rotates forward</td></tr> <tr> <td>EJECT(REV)</td><td>Eject motor rotates in reverse</td></tr> <tr> <td>DRUM</td><td>Drum motor operates</td></tr> </tbody> </table> <ol style="list-style-type: none"> 3. To stop operation, press the stop/clear key. <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p> | Display | Operation | FEED | Paper feed motor operates | MAIN | Main motor operates | EJECT(FW) | Eject motor rotates forward | EJECT(REV) | Eject motor rotates in reverse | DRUM | Drum motor operates |
| Display | Operation | | | | | | | | | | | | |
| FEED | Paper feed motor operates | | | | | | | | | | | | |
| MAIN | Main motor operates | | | | | | | | | | | | |
| EJECT(FW) | Eject motor rotates forward | | | | | | | | | | | | |
| EJECT(REV) | Eject motor rotates in reverse | | | | | | | | | | | | |
| DRUM | Drum motor operates | | | | | | | | | | | | |




| Maintenance item No. | Description | | | | | | | | | | | | | | | | | | | | |
|----------------------|--|---------|----------|-------|----------------------------------|-------|----------------------------------|------------|-------------------------------|---------|------------------------|--------|---------------------------|---------|-------------------------------|--------------|-------------------------|--------|---|---------|-------------------------------------|
| U031 | <p>Checking switches for paper conveying</p> <p>Description Displays the on-off status of each paper detection switch on the paper path.</p> <p>Purpose To check if the switches for paper conveying operate correctly.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Turn each switch on and off manually to check the status. <p>When a switch is detected to be in the ON position, the display for that switch will be highlighted.</p> <table border="1"> <thead> <tr> <th>Display</th><th>Switches</th></tr> </thead> <tbody> <tr> <td>FEED1</td><td>Feed switch 1 (FSW1)</td></tr> <tr> <td>FEED2</td><td>Feed switch 2 (FSW2)</td></tr> <tr> <td>FEED3</td><td>Feed switch 3 (FSW3)</td></tr> <tr> <td>MP TRAY</td><td>MP feed switch (MPFSW)</td></tr> <tr> <td>REGIST</td><td>Registration switch (RSW)</td></tr> <tr> <td>EJECT</td><td>Eject switch (ESW)</td></tr> <tr> <td>BRANCH</td><td>Feedshift switch (FSSW)</td></tr> <tr> <td>DUPLEX</td><td>Duplex paper conveying switch (DUPPCSW)</td></tr> <tr> <td>JOB SEP</td><td>Job separator eject switch (JBESW)*</td></tr> </tbody> </table> <p>*: Optional.</p> <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p> | Display | Switches | FEED1 | Feed switch 1 (FSW1) | FEED2 | Feed switch 2 (FSW2) | FEED3 | Feed switch 3 (FSW3) | MP TRAY | MP feed switch (MPFSW) | REGIST | Registration switch (RSW) | EJECT | Eject switch (ESW) | BRANCH | Feedshift switch (FSSW) | DUPLEX | Duplex paper conveying switch (DUPPCSW) | JOB SEP | Job separator eject switch (JBESW)* |
| Display | Switches | | | | | | | | | | | | | | | | | | | | |
| FEED1 | Feed switch 1 (FSW1) | | | | | | | | | | | | | | | | | | | | |
| FEED2 | Feed switch 2 (FSW2) | | | | | | | | | | | | | | | | | | | | |
| FEED3 | Feed switch 3 (FSW3) | | | | | | | | | | | | | | | | | | | | |
| MP TRAY | MP feed switch (MPFSW) | | | | | | | | | | | | | | | | | | | | |
| REGIST | Registration switch (RSW) | | | | | | | | | | | | | | | | | | | | |
| EJECT | Eject switch (ESW) | | | | | | | | | | | | | | | | | | | | |
| BRANCH | Feedshift switch (FSSW) | | | | | | | | | | | | | | | | | | | | |
| DUPLEX | Duplex paper conveying switch (DUPPCSW) | | | | | | | | | | | | | | | | | | | | |
| JOB SEP | Job separator eject switch (JBESW)* | | | | | | | | | | | | | | | | | | | | |
| U032 | <p>Checking clutch operation</p> <p>Description Turns each clutch on.</p> <p>Purpose To check the operation of each clutch.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select the clutch to be operated. The clutch turns on for 1 s. <table border="1"> <thead> <tr> <th>Display</th><th>Clutches</th></tr> </thead> <tbody> <tr> <td>PF1</td><td>Upper paper feed clutch (PFCL-U)</td></tr> <tr> <td>PF2</td><td>Lower paper feed clutch (PFCL-L)</td></tr> <tr> <td>PF MP TRAY</td><td>MP paper feed clutch (MPPFCL)</td></tr> <tr> <td>FEED1</td><td>Feed clutch 1 (FCL1)</td></tr> <tr> <td>FEED2</td><td>Feed clutch 2 (FCL2)</td></tr> <tr> <td>LIFTBYP</td><td>MP paper feed clutch (MPPFCL)</td></tr> <tr> <td>FEED MP TRAY</td><td>MP feed clutch (MPFCL)</td></tr> <tr> <td>REGIST</td><td>Registration clutch (RCL)</td></tr> <tr> <td>DUPLEX</td><td>Duplex feed clutch (DUPFCL)</td></tr> </tbody> </table> <ol style="list-style-type: none"> 3. Press the interrupt key. Main motor (MM) and paper feed motor (PFM) are turned on. To stop driving motors, press the interrupt key again. <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p> | Display | Clutches | PF1 | Upper paper feed clutch (PFCL-U) | PF2 | Lower paper feed clutch (PFCL-L) | PF MP TRAY | MP paper feed clutch (MPPFCL) | FEED1 | Feed clutch 1 (FCL1) | FEED2 | Feed clutch 2 (FCL2) | LIFTBYP | MP paper feed clutch (MPPFCL) | FEED MP TRAY | MP feed clutch (MPFCL) | REGIST | Registration clutch (RCL) | DUPLEX | Duplex feed clutch (DUPFCL) |
| Display | Clutches | | | | | | | | | | | | | | | | | | | | |
| PF1 | Upper paper feed clutch (PFCL-U) | | | | | | | | | | | | | | | | | | | | |
| PF2 | Lower paper feed clutch (PFCL-L) | | | | | | | | | | | | | | | | | | | | |
| PF MP TRAY | MP paper feed clutch (MPPFCL) | | | | | | | | | | | | | | | | | | | | |
| FEED1 | Feed clutch 1 (FCL1) | | | | | | | | | | | | | | | | | | | | |
| FEED2 | Feed clutch 2 (FCL2) | | | | | | | | | | | | | | | | | | | | |
| LIFTBYP | MP paper feed clutch (MPPFCL) | | | | | | | | | | | | | | | | | | | | |
| FEED MP TRAY | MP feed clutch (MPFCL) | | | | | | | | | | | | | | | | | | | | |
| REGIST | Registration clutch (RCL) | | | | | | | | | | | | | | | | | | | | |
| DUPLEX | Duplex feed clutch (DUPFCL) | | | | | | | | | | | | | | | | | | | | |


| Maintenance item No. | Description | | | | | | |
|-------------------------|---|---------|-----------|---------|----------------------------|---------|-----------------------------|
| U033 | <p>Checking solenoid operation</p> <p>Description Applies current to each solenoid in order to check its ON status.</p> <p>Purpose To check the operation of each solenoid.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select the solenoid to be operated. The solenoid turns on for 1 s. <table border="1" data-bbox="335 510 1398 636"> <thead> <tr> <th>Display</th><th>Solenoids</th></tr> </thead> <tbody> <tr> <td>BRANCH1</td><td>Feedshift solenoid (FSSOL)</td></tr> <tr> <td>BRANCH2</td><td>Feedshift solenoid (FSSOL)*</td></tr> </tbody> </table> <p>*Optional.</p> <ol style="list-style-type: none"> 3. Press the interrupt key. Main motor (MM) and paper feed motor (PFM) are turned on. To stop driving motors, press the interrupt key again. <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p> | Display | Solenoids | BRANCH1 | Feedshift solenoid (FSSOL) | BRANCH2 | Feedshift solenoid (FSSOL)* |
| Display | Solenoids | | | | | | |
| BRANCH1 | Feedshift solenoid (FSSOL) | | | | | | |
| BRANCH2 | Feedshift solenoid (FSSOL)* | | | | | | |

| Maintenance item No. | Description | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|----------------------|--|---------------|-----------------|--------------------------|--------------------------------------|--------------|------------------------|-------------|---------------------------------------|---------|-------------|---------------|-----------------|--------------------------|-----|-------------------------------|--------------|-----|--------|---------|--------------------------|--------------|---|--------|----------|---------------------------|--------------|---|--------|--------|----------------------------|--------------|---|--------|
| U034 | <p>Adjusting the print start timing</p> <p>Description Adjusts the leading edge registration or center line.</p> <p>Purpose Make the adjustment if there is a regular error between the leading edges of the copy image and original. Make the adjustment if there is a regular error between the center lines of the copy image and original.</p> <p>Method</p> <ol style="list-style-type: none">1. Press the start key.2. Select the item to be adjusted. The setting screen for the selected item is displayed. <table><tr><th>Display</th><th>Description</th></tr><tr><td>LSU OUT TOP</td><td>Leading edge registration adjustment</td></tr><tr><td>LSU OUT LEFT</td><td>Center line adjustment</td></tr><tr><td>LSU OUT END</td><td>Trailing edge registration adjustment</td></tr></table> <p>Adjustment: Leading edge registration adjustment</p> <ol style="list-style-type: none">1. Select the item to be adjusted. <table><tr><th>Display</th><th>Description</th><th>Setting range</th><th>Initial setting</th><th>Change in value per step</th></tr><tr><td>TOP</td><td>Adjustment of reference value</td><td>-5.0 to 10.0</td><td>2.0</td><td>0.1 mm</td></tr><tr><td>MP TRAY</td><td>Paper feed from MP tray*</td><td>-5.0 to 10.0</td><td>0</td><td>0.1 mm</td></tr><tr><td>CASSETTE</td><td>Paper feed from cassette*</td><td>-5.0 to 10.0</td><td>0</td><td>0.1 mm</td></tr><tr><td>DUPLEX</td><td>Duplex mode (second side)*</td><td>-5.0 to 10.0</td><td>0</td><td>0.1 mm</td></tr></table> <p>*: Setting the difference value from reference value</p> <ol style="list-style-type: none">2. Press the interrupt key.3. Press the start key to output a test pattern.4. Press the interrupt key.5. Change the setting value using the cursor up/down keys. For output example 1, decrease the value. For output example 2, increase the value. <div><p>Leading edge registration</p><p>Correct image Output example 1 Output example 2</p></div> <p>Figure 1-3-1</p> <ol style="list-style-type: none">6. Press the start key. The value is set. <p>Caution Check the copy image after the adjustment. If the image is still incorrect, perform the following adjustments in maintenance mode.</p> <div><div>U034</div><div>→</div><div>U066 (P.1-3-19)</div><div>→</div><div>U071 (P.1-3-23)</div></div> | Display | Description | LSU OUT TOP | Leading edge registration adjustment | LSU OUT LEFT | Center line adjustment | LSU OUT END | Trailing edge registration adjustment | Display | Description | Setting range | Initial setting | Change in value per step | TOP | Adjustment of reference value | -5.0 to 10.0 | 2.0 | 0.1 mm | MP TRAY | Paper feed from MP tray* | -5.0 to 10.0 | 0 | 0.1 mm | CASSETTE | Paper feed from cassette* | -5.0 to 10.0 | 0 | 0.1 mm | DUPLEX | Duplex mode (second side)* | -5.0 to 10.0 | 0 | 0.1 mm |
| Display | Description | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| LSU OUT TOP | Leading edge registration adjustment | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| LSU OUT LEFT | Center line adjustment | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| LSU OUT END | Trailing edge registration adjustment | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Display | Description | Setting range | Initial setting | Change in value per step | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| TOP | Adjustment of reference value | -5.0 to 10.0 | 2.0 | 0.1 mm | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| MP TRAY | Paper feed from MP tray* | -5.0 to 10.0 | 0 | 0.1 mm | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| CASSETTE | Paper feed from cassette* | -5.0 to 10.0 | 0 | 0.1 mm | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| DUPLEX | Duplex mode (second side)* | -5.0 to 10.0 | 0 | 0.1 mm | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |

| Maintenance item No. | Description | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|----------------------|--|---------------|-----------------|--------------------------|-----------------|--------------------------|------|-------------------------------|--------------|---|--------|---------|--------------------------|--------------|---|--------|------------|-----------------------------|--------------|---|--------|------------|-----------------------------|--------------|------|--------|------------|--------------------------------------|--------------|------|--------|------------|--------------------------------------|--------------|------|--------|--------|----------------------------|--------------|---|--------|
| U034 | <div>Adjustment: Center line adjustment</div> <div>1. Select the item to be adjusted.</div> <table><thead><tr><th>Display</th><th>Description</th><th>Setting range</th><th>Initial setting</th><th>Change in value per step</th></tr></thead><tbody><tr><td>LEFT</td><td>Adjustment of reference value</td><td>-7.0 to 10.0</td><td>0</td><td>0.1 mm</td></tr><tr><td>MP TRAY</td><td>Paper feed from MP tray*</td><td>-7.0 to 10.0</td><td>0</td><td>0.1 mm</td></tr><tr><td>CASSETTE 1</td><td>Paper feed from cassette 1*</td><td>-7.0 to 10.0</td><td>0</td><td>0.1 mm</td></tr><tr><td>CASSETTE 2</td><td>Paper feed from cassette 2*</td><td>-7.0 to 10.0</td><td>-1.0</td><td>0.1 mm</td></tr><tr><td>CASSETTE 3</td><td>Paper feed from optional cassette 3*</td><td>-7.0 to 10.0</td><td>-1.0</td><td>0.1 mm</td></tr><tr><td>CASSETTE 4</td><td>Paper feed from optional cassette 4*</td><td>-7.0 to 10.0</td><td>-1.0</td><td>0.1 mm</td></tr><tr><td>DUPLEX</td><td>Duplex mode (second side)*</td><td>-7.0 to 10.0</td><td>0</td><td>0.1 mm</td></tr></tbody></table> <div>*: Setting the difference value from reference value</div> <div>2. Press the interrupt key.</div> <div>3. Press the start key to output a test pattern.</div> <div>4. Press the interrupt key.</div> <div>5. Change the setting value using the cursor up/down keys.</div> <div>For output example 1, decrease the value. For output example 2, increase the value.</div> <div><div><div>Center line of printing</div><div></div><div>Correct image Output example 1 Output example 2</div></div><div>Figure 1-3-2</div><div>6. Press the start key. The value is set.</div><div><div>Caution</div><div>Check the copy image after the adjustment. If the image is still incorrect, perform the following adjustments in maintenance mode.</div><div><div>U034</div><div>→</div><div>U067 (P.1-3-20)</div><div>→</div><div>U072 (P.1-3-25)</div></div></div></div> | Display | Description | Setting range | Initial setting | Change in value per step | LEFT | Adjustment of reference value | -7.0 to 10.0 | 0 | 0.1 mm | MP TRAY | Paper feed from MP tray* | -7.0 to 10.0 | 0 | 0.1 mm | CASSETTE 1 | Paper feed from cassette 1* | -7.0 to 10.0 | 0 | 0.1 mm | CASSETTE 2 | Paper feed from cassette 2* | -7.0 to 10.0 | -1.0 | 0.1 mm | CASSETTE 3 | Paper feed from optional cassette 3* | -7.0 to 10.0 | -1.0 | 0.1 mm | CASSETTE 4 | Paper feed from optional cassette 4* | -7.0 to 10.0 | -1.0 | 0.1 mm | DUPLEX | Duplex mode (second side)* | -7.0 to 10.0 | 0 | 0.1 mm |
| Display | Description | Setting range | Initial setting | Change in value per step | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| LEFT | Adjustment of reference value | -7.0 to 10.0 | 0 | 0.1 mm | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| MP TRAY | Paper feed from MP tray* | -7.0 to 10.0 | 0 | 0.1 mm | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| CASSETTE 1 | Paper feed from cassette 1* | -7.0 to 10.0 | 0 | 0.1 mm | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| CASSETTE 2 | Paper feed from cassette 2* | -7.0 to 10.0 | -1.0 | 0.1 mm | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| CASSETTE 3 | Paper feed from optional cassette 3* | -7.0 to 10.0 | -1.0 | 0.1 mm | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| CASSETTE 4 | Paper feed from optional cassette 4* | -7.0 to 10.0 | -1.0 | 0.1 mm | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| DUPLEX | Duplex mode (second side)* | -7.0 to 10.0 | 0 | 0.1 mm | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |

| Maintenance item No. | Description | | | | | | | | | | | | |
|----------------------|--|---------------|-----------------|--------------------------|-----------------|--------------------------|--------|---------------------------------------|------------|------------|-------|---------------|-----|
| U034 | <p>Adjustment: Trailing edge registration adjustment</p> <p>1. Select [END].</p> <table><tr><th>Display</th><th>Description</th><th>Setting range</th><th>Initial setting</th><th>Change in value per step</th></tr><tr><td>END</td><td>Trailing edge registration adjustment</td><td>-40 to 100</td><td>0</td><td>1 ms</td></tr></table> <p>2. Press the interrupt key.</p> <p>3. Press the start key to output a test pattern.</p> <p>4. Press the interrupt key.</p> <p>5. Change the setting value using the cursor up/down keys. For output example 1, decrease the value. For output example 2, increase the value.</p> <div><div><p>Correct image</p></div><div><p>Output example 1</p></div><div><p>Output example 2</p></div></div> <p>Figure 1-3-3</p> <p>6. Press the start key. The value is set.</p> <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p> | Display | Description | Setting range | Initial setting | Change in value per step | END | Trailing edge registration adjustment | -40 to 100 | 0 | 1 ms | | |
| Display | Description | Setting range | Initial setting | Change in value per step | | | | | | | | | |
| END | Trailing edge registration adjustment | -40 to 100 | 0 | 1 ms | | | | | | | | | |
| U035 | <p>Setting the printing area for folio paper</p> <p>Description Changes the printing area for copying on folio paper.</p> <p>Purpose To prevent cropped images on the trailing edge or left/right side of copy paper by setting the actual printing area for folio paper.</p> <p>Setting</p> <p>1. Press the start key.</p> <p>2. Select the item to be set.</p> <p>3. Change the setting using the cursor up/down keys.</p> <table><tr><th>Display</th><th>Setting</th><th>Setting range</th><th>Initial setting</th></tr><tr><td>LENGTH DATA</td><td>Length</td><td>330 to 356 mm</td><td>330</td></tr><tr><td>WIDTH DATA</td><td>Width</td><td>200 to 220 mm</td><td>210</td></tr></table> <p>4. Press the start key. The value is set.</p> <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p> | Display | Setting | Setting range | Initial setting | LENGTH DATA | Length | 330 to 356 mm | 330 | WIDTH DATA | Width | 200 to 220 mm | 210 |
| Display | Setting | Setting range | Initial setting | | | | | | | | | | |
| LENGTH DATA | Length | 330 to 356 mm | 330 | | | | | | | | | | |
| WIDTH DATA | Width | 200 to 220 mm | 210 | | | | | | | | | | |







| Maintenance item No. | Description | | | | | | | | | | | | | | | | | | | | | | | | |
|----------------------|--|---------------|-----------------|---------------|-----------------|---------|-------------------------|------------|---|----------|----------------------------|------------|----|-----------|----------------------------|------------|----|--------|---------------------------|------------|----|-----------------|---------------------------------------|------------|----|
| U051 | <div><div>Adjusting the deflection in the paper</div><div><div>Description</div><div>Adjusts the deflection in the paper.</div><div><div>Purpose</div><div>Make the adjustment if the leading edge of the copy image is missing or varies randomly, or if the copy paper is Z-folded.</div></div><div><div>Adjustment</div><div><div><div>1. Press the start key.</div><div>2. Select the item to be adjusted.</div></div><table><tr><th>Display</th><th>Description</th><th>Setting range</th><th>Initial setting</th></tr><tr><td>MP TRAY</td><td>Paper feed from MP tray</td><td>-50 to 127</td><td>0</td></tr><tr><td>CASSETTE</td><td>Paper feed from cassette 1</td><td>-50 to 127</td><td>50</td></tr><tr><td>CASSETTE2</td><td>Paper feed from cassette 2</td><td>-50 to 127</td><td>50</td></tr><tr><td>DUPLEX</td><td>Duplex mode (second side)</td><td>-50 to 127</td><td>40</td></tr><tr><td>MP TRAY (THICK)</td><td>Paper feed from MP tray (thick paper)</td><td>-50 to 127</td><td>10</td></tr></table><div><div><div>3. Press the interrupt key.</div><div>4. Place an original and press the start key to make a test copy.</div><div>5. Press the interrupt key.</div><div>6. Change the setting value using the cursor up/down keys.</div></div><div><div>For output example 1, increase the value. For output example 2, decrease the value.</div><div>The greater the value, the larger the deflection; the smaller the value, the smaller the deflection.</div></div><div><div><div><div></div><div>Original</div></div><div><div></div><div>Copy example 1</div></div><div><div></div><div>Copy example 2</div></div></div></div><div><div>7. Press the start key. The value is set.</div><div><div>Completion</div><div>Press the stop/clear key. The indication for selecting a maintenance item No. appears.</div></div></div></div></div></div></div></div> | Display | Description | Setting range | Initial setting | MP TRAY | Paper feed from MP tray | -50 to 127 | 0 | CASSETTE | Paper feed from cassette 1 | -50 to 127 | 50 | CASSETTE2 | Paper feed from cassette 2 | -50 to 127 | 50 | DUPLEX | Duplex mode (second side) | -50 to 127 | 40 | MP TRAY (THICK) | Paper feed from MP tray (thick paper) | -50 to 127 | 10 |
| Display | Description | Setting range | Initial setting | | | | | | | | | | | | | | | | | | | | | | |
| MP TRAY | Paper feed from MP tray | -50 to 127 | 0 | | | | | | | | | | | | | | | | | | | | | | |
| CASSETTE | Paper feed from cassette 1 | -50 to 127 | 50 | | | | | | | | | | | | | | | | | | | | | | |
| CASSETTE2 | Paper feed from cassette 2 | -50 to 127 | 50 | | | | | | | | | | | | | | | | | | | | | | |
| DUPLEX | Duplex mode (second side) | -50 to 127 | 40 | | | | | | | | | | | | | | | | | | | | | | |
| MP TRAY (THICK) | Paper feed from MP tray (thick paper) | -50 to 127 | 10 | | | | | | | | | | | | | | | | | | | | | | |


| Maintenance item No. | Description | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|----------------------|--|---------------|-----------------|--------------------------|-----------------|--------------------------|-----|---|-----------|---|--------|------------|-------------------------------|-----------|----|--------|------------|-------------------------------|-----------|----|--------|------------|-------------------------------------|-----------|---|--------|-------------|--------------------------------|-----------|---|--------|---------------|--------------------------------|-----------|----|---|----------|--|-----------|---|--------|
| U053 | <p>Setting the adjustment of the motor speed</p> <p>Description Performs fine adjustment of the speeds of the motors.</p> <p>Purpose To adjust the speed of the respective motors when the magnification is not correct.</p> <p>Method</p> <ol style="list-style-type: none">1. Press the start key.2. Select the item to be adjusted. <table><thead><tr><th>Display</th><th>Description</th><th>Setting range</th><th>Initial setting</th><th>Change in value per step</th></tr></thead><tbody><tr><td>ALL</td><td>Main motor, drum motor, paper feed motor and eject motor speed adjustment</td><td>-40 to 40</td><td>0</td><td>0.25 %</td></tr><tr><td>MAIN MOTOR</td><td>Main motor speed adjustment*1</td><td>-40 to 40</td><td>-1</td><td>0.25 %</td></tr><tr><td>DRUM MOTOR</td><td>Drum motor speed adjustment*1</td><td>-40 to 40</td><td>-2</td><td>0.25 %</td></tr><tr><td>FEED MOTOR</td><td>Paper feed motor speed adjustment*1</td><td>-40 to 40</td><td>0</td><td>0.25 %</td></tr><tr><td>EJECT MOTOR</td><td>Eject motor speed adjustment*1</td><td>-40 to 40</td><td>2</td><td>0.25 %</td></tr><tr><td>POLYGON MOTOR</td><td>Polygon motor speed adjustment</td><td>-20 to 20</td><td>-8</td><td>-</td></tr><tr><td>DF MOTOR</td><td>Paper conveying motor speed adjustment*2</td><td>-40 to 40</td><td>0</td><td>0.25 %</td></tr></tbody></table> <p>*1: Correction value for the [ALL] value *2: Optional built-in finisher</p> <p>Adjustment</p> <ol style="list-style-type: none">1. Press the interrupt key.2. Press the start key to output an A3/Ledger VTC pattern. <div><p>Correct values for an A3/11 x 17" output are: A = 300 ± 1.0 mm B = 260 ± 1.0 mm</p></div> <p>Figure 1-3-5</p> <ol style="list-style-type: none">3. Press the interrupt key.4. A: Magnification in the auxiliary scanning direction<ol style="list-style-type: none">1) Select [ALL].2) Change the setting value using the cursor up/down keys. Increasing the setting makes the image longer in the auxiliary scanning direction, and decreasing it makes the image shorter in the auxiliary scanning direction.B: Magnification in the main scanning direction<ol style="list-style-type: none">1) Select [POLYGON MOTOR].2) Change the setting value using the cursor up/down keys. Increasing the setting makes the image shorter in the main scanning direction, and decreasing it makes the image longer in the main scanning direction.5. Press the start key. The value is set. <p>Completion Press the stop/clear key. The indication for selecting a maintenance item No. appears.</p> | Display | Description | Setting range | Initial setting | Change in value per step | ALL | Main motor, drum motor, paper feed motor and eject motor speed adjustment | -40 to 40 | 0 | 0.25 % | MAIN MOTOR | Main motor speed adjustment*1 | -40 to 40 | -1 | 0.25 % | DRUM MOTOR | Drum motor speed adjustment*1 | -40 to 40 | -2 | 0.25 % | FEED MOTOR | Paper feed motor speed adjustment*1 | -40 to 40 | 0 | 0.25 % | EJECT MOTOR | Eject motor speed adjustment*1 | -40 to 40 | 2 | 0.25 % | POLYGON MOTOR | Polygon motor speed adjustment | -20 to 20 | -8 | - | DF MOTOR | Paper conveying motor speed adjustment*2 | -40 to 40 | 0 | 0.25 % |
| Display | Description | Setting range | Initial setting | Change in value per step | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ALL | Main motor, drum motor, paper feed motor and eject motor speed adjustment | -40 to 40 | 0 | 0.25 % | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| MAIN MOTOR | Main motor speed adjustment*1 | -40 to 40 | -1 | 0.25 % | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| DRUM MOTOR | Drum motor speed adjustment*1 | -40 to 40 | -2 | 0.25 % | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| FEED MOTOR | Paper feed motor speed adjustment*1 | -40 to 40 | 0 | 0.25 % | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| EJECT MOTOR | Eject motor speed adjustment*1 | -40 to 40 | 2 | 0.25 % | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| POLYGON MOTOR | Polygon motor speed adjustment | -20 to 20 | -8 | - | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| DF MOTOR | Paper conveying motor speed adjustment*2 | -40 to 40 | 0 | 0.25 % | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |


| Maintenance item No. | Description | | | | | | | | | | | |
|----------------------|--|-----------------|--------------------------|--|-------------|---------------|-----------------|--------------------------|------------------|--|--------------|----------|
| U059 | <p>Setting fan mode</p> <p>Description Sets the time of period cooling fan motor 1 is driven.</p> <p>Purpose To be executed as required.</p> <p>Method</p> <ol style="list-style-type: none">1. Press the start key.2. Change the setting using the cursor up/down keys. <table><tr><th>Display</th><th>Description</th><th>Setting range</th><th>Initial setting</th></tr><tr><td>FAN1</td><td>Time of period the fan is driven after printing is completed</td><td>0 to 250 (s)</td><td>45</td></tr></table> <ol style="list-style-type: none">3. Press the start key. The value is set. <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p> | | | | Display | Description | Setting range | Initial setting | FAN1 | Time of period the fan is driven after printing is completed | 0 to 250 (s) | 45 |
| Display | Description | Setting range | Initial setting | | | | | | | | | |
| FAN1 | Time of period the fan is driven after printing is completed | 0 to 250 (s) | 45 | | | | | | | | | |
| U061 | <p>Turning the exposure lamp on</p> <p>Description Turns the exposure lamp on.</p> <p>Purpose To check the exposure lamp.</p> <p>Method</p> <ol style="list-style-type: none">1. Press the start key.2. Press the start key. The exposure lamp lights.3. To turn the exposure lamp off, press the stop/clear key. <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p> | | | | | | | | | | | |
| U063 | <p>Adjusting the shading position</p> <p>Description Changes the shading position of the scanner.</p> <p>Purpose Used when white lines continue to appear longitudinally on the image after the shading plate is cleaned. This is due to flaws or stains inside the shading plate. To prevent this problem, the shading position should be changed so that shading is possible without being affected by the flaws or stains.</p> <p>Method</p> <ol style="list-style-type: none">1. Press the start key.2. Change the setting using the cursor up/down keys. <table><tr><th>Description</th><th>Setting range</th><th>Initial setting</th><th>Change in value per step</th></tr><tr><td>Shading position</td><td>-12 to 18</td><td>0</td><td>0.086 mm</td></tr></table> <p>Increasing the setting moves the shading position toward the machine left, and decreasing it moves the position toward the machine right.</p> <ol style="list-style-type: none">3. Press the start key. The value is set. <p>Supplement While this maintenance item is being executed, copying from an original is available in the interrupt copying mode.</p> <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p> | | | | Description | Setting range | Initial setting | Change in value per step | Shading position | -12 to 18 | 0 | 0.086 mm |
| Description | Setting range | Initial setting | Change in value per step | | | | | | | | | |
| Shading position | -12 to 18 | 0 | 0.086 mm | | | | | | | | | |

TONER

www.tonerplus.com.ua

| Maintenance item No. | Description | | | | | | | | | | | | | | | |
|----------------------|---|---------------|-----------------|--------------------------|-----------------|--------------------------|---------------|--|-----------|---|-------|--------------|---|-----------|---|-------|
| U065 | <p>Adjusting the scanner magnification</p> <p>Description Adjusts the magnification of the original scanning.</p> <p>Purpose Make the adjustment if the magnification in the main scanning direction is incorrect. Make the adjustment if the magnification in the auxiliary scanning direction is incorrect.</p> <p>Caution Adjust the magnification of the scanner in the following order.</p> <div><div>U053 (P.1-3-16)</div>→<div>U065 (main scanning direction)</div>→<div>U065 (auxiliary scanning direction)</div>→<div>U067 (P.1-3-20)</div>→<div>U070 (P.1-3-22)</div></div> <p>Method</p> <ol style="list-style-type: none">Press the start key.Select the item to be adjusted. <table><tr><th>Display</th><th>Description</th><th>Setting range</th><th>Initial setting</th><th>Change in value per step</th></tr><tr><td>MAIN SCAN ADJ</td><td>Scanner magnification in the main scanning direction</td><td>-15 to 15</td><td>0</td><td>0.1 %</td></tr><tr><td>SUB SCAN ADJ</td><td>Scanner magnification in the auxiliary scanning direction</td><td>-25 to 25</td><td>0</td><td>0.1 %</td></tr></table> <p>Adjustment: Main scanning direction</p> <ol style="list-style-type: none">Press the interrupt key.Place an original and press the start key to make a test copy.Press the interrupt key.Change the setting value using the cursor up/down keys. For copy example 1, increase the value. For copy example 2, decrease the value. <div><div></div><div></div><div></div><div>Original</div><div>Copy example 1</div><div>Copy example 2</div></div> <p>Figure 1-3-6</p> <ol style="list-style-type: none">Press the start key. The value is set. <p>Adjustment: Auxiliary scanning direction</p> <ol style="list-style-type: none">Press the interrupt key.Place an original and press the start key to make a test copy.Press the interrupt key.Change the setting value using the cursor up/down keys. For copy example 1, increase the value. For copy example 2, decrease the value. <div><div></div><div></div><div></div><div>Original</div><div>Copy example 1</div><div>Copy example 2</div></div> <p>Figure 1-3-7</p> <ol style="list-style-type: none">Press the start key. The value is set. <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p> | Display | Description | Setting range | Initial setting | Change in value per step | MAIN SCAN ADJ | Scanner magnification in the main scanning direction | -15 to 15 | 0 | 0.1 % | SUB SCAN ADJ | Scanner magnification in the auxiliary scanning direction | -25 to 25 | 0 | 0.1 % |
| Display | Description | Setting range | Initial setting | Change in value per step | | | | | | | | | | | | |
| MAIN SCAN ADJ | Scanner magnification in the main scanning direction | -15 to 15 | 0 | 0.1 % | | | | | | | | | | | | |
| SUB SCAN ADJ | Scanner magnification in the auxiliary scanning direction | -25 to 25 | 0 | 0.1 % | | | | | | | | | | | | |




| Maintenance item No. | Description | | | | | | | | | | | | | | | |
|----------------------|--|---------------|-----------------|--------------------------|-----------------|--------------------------|---------------|-----------------------------------|-----------|---|----------|--------------|--|-----------|---|----------|
| U066 | <p>Adjusting the scanner leading edge registration</p> <p>Description Adjusts the scanner leading edge registration of the original scanning.</p> <p>Purpose Make the adjustment if there is a regular error between the leading edges of the copy image and original.</p> <p>Adjustment</p> <ol style="list-style-type: none">1. Press the start key.2. Select the item to be adjusted. <table><tr><th>Display</th><th>Description</th><th>Setting range</th><th>Initial setting</th><th>Change in value per step</th></tr><tr><td>ADJUST DATA 1</td><td>Scanner leading edge registration</td><td>-45 to 45</td><td>0</td><td>0.086 mm</td></tr><tr><td>ADJUST DATA2</td><td>Scanner leading edge registration (rotate copying)</td><td>-20 to 20</td><td>0</td><td>0.086 mm</td></tr></table> <ol style="list-style-type: none">3. Press the interrupt key.4. Place an original and press the start key to make a test copy.5. Press the interrupt key.6. Change the setting value using the cursor up/down keys. For copy example 1, increase the value. For copy example 2, decrease the value. <div><p>Scanner leading edge registration</p><p>Original Copy example 1 Copy example 2</p></div> <p>Figure 1-3-8</p> <ol style="list-style-type: none">7. Press the start key. The value is set. <p>Caution Check the copy image after the adjustment. If the image is still incorrect, perform the following adjustments in maintenance mode.</p> <div><div>U066</div><div>→</div><div>U403 (P.1-3-56)</div><div>→</div><div>U071 (P.1-3-23)</div><div>→</div><div>U404 (P.1-3-57)</div></div> <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p> | Display | Description | Setting range | Initial setting | Change in value per step | ADJUST DATA 1 | Scanner leading edge registration | -45 to 45 | 0 | 0.086 mm | ADJUST DATA2 | Scanner leading edge registration (rotate copying) | -20 to 20 | 0 | 0.086 mm |
| Display | Description | Setting range | Initial setting | Change in value per step | | | | | | | | | | | | |
| ADJUST DATA 1 | Scanner leading edge registration | -45 to 45 | 0 | 0.086 mm | | | | | | | | | | | | |
| ADJUST DATA2 | Scanner leading edge registration (rotate copying) | -20 to 20 | 0 | 0.086 mm | | | | | | | | | | | | |

| Maintenance item No. | Description | | | | | | | | | | | | | | | |
|----------------------|---|---------------|-----------------|--------------------------|-----------------|--------------------------|---------------|---------------------|-----------|---|----------|---------------|--------------------------------------|-----------|---|----------|
| U067 | <p>Adjusting the scanner center line</p> <p>Description Adjusts the scanner center line of the original scanning.</p> <p>Purpose Make the adjustment if there is a regular error between the center lines of the copy image and original.</p> <p>Adjustment</p> <ol style="list-style-type: none">1. Press the start key.2. Select the item to be adjusted. <table><tr><th>Display</th><th>Description</th><th>Setting range</th><th>Initial setting</th><th>Change in value per step</th></tr><tr><td>ADJUST DATA 1</td><td>Scanner center line</td><td>-39 to 39</td><td>0</td><td>0.085 mm</td></tr><tr><td>ADJUST DATA 2</td><td>Scanner center line (rotate copying)</td><td>-39 to 39</td><td>0</td><td>0.085 mm</td></tr></table> <ol style="list-style-type: none">3. Press the interrupt key.4. Place an original and press the start key to make a test copy.5. Press the interrupt key.6. Change the setting value using the cursor up/down keys. For copy example 1, decrease the value. For copy example 2, increase the value. <div><p>Scanner center line</p></div> <p style="text-align: center;">Figure 1-3-9</p> <ol style="list-style-type: none">7. Press the start key. The value is set. <p>Caution Check the copy image after the adjustment. If the image is still incorrect, perform the following adjustments in maintenance mode.</p> <div><div>U067</div><div>→</div><div>U403 (P.1-3-56)</div><div>→</div><div>U072 (P.1-3-25)</div><div>→</div><div>U404 (P.1-3-57)</div></div> <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p> | Display | Description | Setting range | Initial setting | Change in value per step | ADJUST DATA 1 | Scanner center line | -39 to 39 | 0 | 0.085 mm | ADJUST DATA 2 | Scanner center line (rotate copying) | -39 to 39 | 0 | 0.085 mm |
| Display | Description | Setting range | Initial setting | Change in value per step | | | | | | | | | | | | |
| ADJUST DATA 1 | Scanner center line | -39 to 39 | 0 | 0.085 mm | | | | | | | | | | | | |
| ADJUST DATA 2 | Scanner center line (rotate copying) | -39 to 39 | 0 | 0.085 mm | | | | | | | | | | | | |


| Maintenance item No. | Description | | | | | | | | | | | | | | | |
|----------------------|--|---------------|-----------------|--------------------------|-----------------|--------------------------|-------------|---|-----------|---|----------|---------------|---|--------|---|---------|
| U068 | <p>Adjusting the scanning position for originals from the DP</p> <p>Description Adjusts the position for scanning originals from the DP. Performs the test copy at the four scanning positions after adjusting.</p> <p>Purpose Used when the image fogging occurs because the scanning position is not proper when the DP is used. Run U071 to adjust the timing of DP leading edge when the scanning position is changed.</p> <p>Setting</p> <p>1. Press the start key.</p> <table><tr><th>Display</th><th>Description</th><th>Setting range</th><th>Initial setting</th><th>Change in value per step</th></tr><tr><td>ADJUST DATA</td><td>Starting position adjustment for scanning originals</td><td>-33 to 33</td><td>0</td><td>0.086 mm</td></tr><tr><td>TEST POSITION</td><td>Scanning position for the test copy originals</td><td>0 to 3</td><td>0</td><td>0.22 mm</td></tr></table> <p>2. Select [ADJUST DATA] of the screen for selecting an item.</p> <p>3. Change the setting using the cursor up/down keys. When the setting value is increased, the scanning position moves to the right and it moves to the left when the setting value is decreased.</p> <p>4. Press the start key. The value is set.</p> <p>5. Select [TEST POSITION] of the screen for selecting an item.</p> <p>6. Select the scanning position using the cursor up/down keys.</p> <p>7. Press the start key. The value is set.</p> <p>8. Set the original (the one which density is known) in the DP and press the interrupt key. The screen for the test copy mode is displayed.</p> <p>9. Press the start key. Test copy is executed.</p> <p>10. Perform the test copy at each scanning position with the setting value from 0 to 3 and check that no black line appears and the image is normally scanned.</p> <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p> | Display | Description | Setting range | Initial setting | Change in value per step | ADJUST DATA | Starting position adjustment for scanning originals | -33 to 33 | 0 | 0.086 mm | TEST POSITION | Scanning position for the test copy originals | 0 to 3 | 0 | 0.22 mm |
| Display | Description | Setting range | Initial setting | Change in value per step | | | | | | | | | | | | |
| ADJUST DATA | Starting position adjustment for scanning originals | -33 to 33 | 0 | 0.086 mm | | | | | | | | | | | | |
| TEST POSITION | Scanning position for the test copy originals | 0 to 3 | 0 | 0.22 mm | | | | | | | | | | | | |

TONER




www.tonerplus.com.ua

| Maintenance item No. | Description | | | | | | | | | | | | | | | |
|----------------------|--|---------------|-----------------|--------------------------|-----------------|--------------------------|----------|--|-----------|---|-------|---------|---|-----------|---|-------|
| U070 | <p>Adjusting the DP magnification</p> <p>Description Adjusts the DP original scanning speed.</p> <p>Purpose Make the adjustment if the magnification is incorrect in the auxiliary scanning direction when the optional DP is used.</p> <p>Method</p> <ol style="list-style-type: none">1. Press the start key.2. Select the item to be adjusted. <table><tr><th>Display</th><th>Description</th><th>Setting range</th><th>Initial setting</th><th>Change in value per step</th></tr><tr><td>MAIN ADJ</td><td>Magnification in the auxiliary scanning direction (first page)</td><td>-25 to 25</td><td>0</td><td>0.1 %</td></tr><tr><td>SUB ADJ</td><td>Magnification in the auxiliary scanning direction (second page)</td><td>-25 to 25</td><td>0</td><td>0.1 %</td></tr></table> <p>Adjustment</p> <ol style="list-style-type: none">1. Press the interrupt key.2. Place an original on the DP and press the start key to make a test copy.3. Press the interrupt key.4. Change the setting value using the cursor up/down keys. For copy example 1, increase the value. For copy example 2, decrease the value. <div><div></div><div>Original</div><div></div><div>Copy example 1</div><div></div><div>Copy example 2</div></div> <p>Figure 1-3-10</p> <ol style="list-style-type: none">5. Press the start key. The value is set. <p>Caution Check the copy image after the adjustment. If the image is still incorrect, perform the following adjustments in maintenance mode.</p> <div><div>U070</div><div>→</div><div>U071 (P.1-3-23)</div><div>→</div><div>U404 (P.1-3-57)</div></div> <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p> | Display | Description | Setting range | Initial setting | Change in value per step | MAIN ADJ | Magnification in the auxiliary scanning direction (first page) | -25 to 25 | 0 | 0.1 % | SUB ADJ | Magnification in the auxiliary scanning direction (second page) | -25 to 25 | 0 | 0.1 % |
| Display | Description | Setting range | Initial setting | Change in value per step | | | | | | | | | | | | |
| MAIN ADJ | Magnification in the auxiliary scanning direction (first page) | -25 to 25 | 0 | 0.1 % | | | | | | | | | | | | |
| SUB ADJ | Magnification in the auxiliary scanning direction (second page) | -25 to 25 | 0 | 0.1 % | | | | | | | | | | | | |

TONER




www.tonerplus.com.ua

| Maintenance item No. | Description | | | | | | | | | | | | | | | | | | | | | | | | | |
|----------------------|---|---------------|-----------------|--------------------------|-----------------|--------------------------|--------------|--|-----------|---|----------|--------------|---|-----------|---|----------|--------------|---|-----------|---|----------|--------------|--|-----------|---|----------|
| U071 | <p>Adjusting the DP scanning timing</p> <p>Description Adjusts the DP original scanning timing.</p> <p>Purpose Make the adjustment if there is a regular error between the leading or trailing edges of the original and the copy image when the optional DP is used.</p> <p>Method</p> <ol style="list-style-type: none">1. Press the start key.2. Select the item to be adjusted. <table><tr><th>Display</th><th>Description</th><th>Setting range</th><th>Initial setting</th><th>Change in value per step</th></tr><tr><td>ADJUST DATA1</td><td>Leading edge registration (first page)</td><td>-32 to 32</td><td>0</td><td>0.196 mm</td></tr><tr><td>ADJUST DATA2</td><td>Trailing edge registration (first page)</td><td>-32 to 28</td><td>0</td><td>0.196 mm</td></tr><tr><td>ADJUST DATA3</td><td>Leading edge registration (second page)</td><td>-45 to 45</td><td>0</td><td>0.196 mm</td></tr><tr><td>ADJUST DATA4</td><td>Trailing edge registration (second page)</td><td>-45 to 28</td><td>0</td><td>0.196 mm</td></tr></table> <p>Adjustment: Leading edge registration</p> <ol style="list-style-type: none">1. Press the interrupt key.2. Place an original on the DP and press the start key to make a test copy.3. Press the interrupt key.4. Change the setting value using the cursor up/down keys. For copy example 1, increase the value. For copy example 2, decrease the value. <div><div> Original</div><div> Copy example 1</div><div> Copy example 2</div></div> <p>Figure 1-3-11</p> <ol style="list-style-type: none">5. Press the start key. The value is set. <p>Caution Check the copy image after the adjustment. If the image is still incorrect, perform the following adjustments in maintenance mode.</p> <div><div>U071</div><div>→</div><div>U404 (P.1-3-57)</div></div> | Display | Description | Setting range | Initial setting | Change in value per step | ADJUST DATA1 | Leading edge registration (first page) | -32 to 32 | 0 | 0.196 mm | ADJUST DATA2 | Trailing edge registration (first page) | -32 to 28 | 0 | 0.196 mm | ADJUST DATA3 | Leading edge registration (second page) | -45 to 45 | 0 | 0.196 mm | ADJUST DATA4 | Trailing edge registration (second page) | -45 to 28 | 0 | 0.196 mm |
| Display | Description | Setting range | Initial setting | Change in value per step | | | | | | | | | | | | | | | | | | | | | | |
| ADJUST DATA1 | Leading edge registration (first page) | -32 to 32 | 0 | 0.196 mm | | | | | | | | | | | | | | | | | | | | | | |
| ADJUST DATA2 | Trailing edge registration (first page) | -32 to 28 | 0 | 0.196 mm | | | | | | | | | | | | | | | | | | | | | | |
| ADJUST DATA3 | Leading edge registration (second page) | -45 to 45 | 0 | 0.196 mm | | | | | | | | | | | | | | | | | | | | | | |
| ADJUST DATA4 | Trailing edge registration (second page) | -45 to 28 | 0 | 0.196 mm | | | | | | | | | | | | | | | | | | | | | | |

TONER

www.tonerplus.com.ua



| Maintenance item No. | Description |
|-------------------------|---|
| U071 | <p>Adjustment: Trailing edge registration</p> <ol style="list-style-type: none"> 1. Press the interrupt key. 2. Place an original on the DP and press the start key to make a test copy. 3. Press the interrupt key. 4. Change the setting value using the cursor up/down keys. For copy example 1, increase the value. For copy example 2, decrease the value. <div data-bbox="641 459 1002 694" data-label="Image"> </div> <p style="text-align: center;">Figure 1-3-12</p> <ol style="list-style-type: none"> 5. Press the start key. The value is set. <p>Caution Check the copy image after the adjustment. If the image is still incorrect, perform the following adjustments in maintenance mode.</p> <div data-bbox="285 898 624 972" data-label="Diagram"> <pre> graph LR U071[U071] --> U404[U404 (P.1-3-57)] </pre> </div> <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p> |

| Maintenance item No. | Description | | | | | | | | | | | | | | | | | | | | |
|----------------------|--|---------------|-----------------|--------------------------|-----------------|--------------------------|----------------|--------------------------------|-----------|---|----------|----------------|--|-----------|---|----------|----------------|---|-----------|---|----------|
| U072 | <p>Adjusting the DP center line</p> <p>Description Adjusts the scanning start position for the DP original.</p> <p>Purpose Make the adjustment if there is a regular error between the centers of the original and the copy image when the optional DP is used.</p> <p>Adjustment</p> <ol style="list-style-type: none">1. Press the start key.2. Select the item to be adjusted. <table><tr><th>Display</th><th>Description</th><th>Setting range</th><th>Initial setting</th><th>Change in value per step</th></tr><tr><td>DATA(simplesx)</td><td>DP center line (simplesx mode)</td><td>-39 to 39</td><td>0</td><td>0.086 mm</td></tr><tr><td>DATA(duplex 1)</td><td>DP center line (first page of duplex mode)</td><td>-39 to 39</td><td>0</td><td>0.086 mm</td></tr><tr><td>DATA(duplex 2)</td><td>DP center line (second page of duplex mode)</td><td>-39 to 39</td><td>0</td><td>0.086 mm</td></tr></table> <ol style="list-style-type: none">3. Press the interrupt key.4. Place an original on the DP and press the start key to make a test copy.5. Press the interrupt key.6. Change the setting value using the cursor up/down keys. For copy example 1, increase the value. For copy example 2, decrease the value. <div><p>Reference</p><p>Original Copy example 1 Copy example 2</p></div> <p>Figure 1-3-13</p> <ol style="list-style-type: none">7. Press the start key. The value is set. <p>Caution Check the copy image after the adjustment. If the image is still incorrect, perform the following adjustments in maintenance mode.</p> <div><div>U072</div><div>→</div><div>U404 (P.1-3-57)</div></div> <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p> | Display | Description | Setting range | Initial setting | Change in value per step | DATA(simplesx) | DP center line (simplesx mode) | -39 to 39 | 0 | 0.086 mm | DATA(duplex 1) | DP center line (first page of duplex mode) | -39 to 39 | 0 | 0.086 mm | DATA(duplex 2) | DP center line (second page of duplex mode) | -39 to 39 | 0 | 0.086 mm |
| Display | Description | Setting range | Initial setting | Change in value per step | | | | | | | | | | | | | | | | | |
| DATA(simplesx) | DP center line (simplesx mode) | -39 to 39 | 0 | 0.086 mm | | | | | | | | | | | | | | | | | |
| DATA(duplex 1) | DP center line (first page of duplex mode) | -39 to 39 | 0 | 0.086 mm | | | | | | | | | | | | | | | | | |
| DATA(duplex 2) | DP center line (second page of duplex mode) | -39 to 39 | 0 | 0.086 mm | | | | | | | | | | | | | | | | | |













| Maintenance item No. | Description | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|----------------------|--|-------------------|-----------------|-------------|-------------------|---------------|-------------------------|------------|--------------------------------|------------|--|---------|----------------------|---------------|------|---------------|------------|------|---------------------------------|-------------------|---------|------------|---------|------------|------|----|------|-----|------|----|------|-------|------|--------------|-------|-----------|-------|----|------|-----------|------|----|------|--------------|------|-----|------|--------------|------|-----|------|-----------------|
| U073 | <p>Checking scanner operation</p> <p>Description Simulates the scanner operation under arbitrary conditions.</p> <p>Purpose To check scanner operation.</p> <p>Start</p> <ol style="list-style-type: none">1. Press the start key.2. Select the item to be operated. <table><tr><th>Display</th><th>Description</th></tr><tr><td>SCANNER MOT</td><td>Scanner operation</td></tr><tr><td>HOME POSITION</td><td>Home position operation</td></tr><tr><td>DP READING</td><td>DP scanning position operation</td></tr><tr><td>DUST CHECK</td><td>Dust adhesion check operation with lamp on</td></tr></table> <p>Setting: SCANNER MOTOR</p> <ol style="list-style-type: none">1. Select [SCANNER MOTOR].2. Select the item.3. Change the setting using the cursor up/down keys. <table><tr><th>Display</th><th>Operating conditions</th><th>Setting range</th></tr><tr><td>SIZE</td><td>Original size</td><td>See below.</td></tr><tr><td>LAMP</td><td>On and off of the exposure lamp</td><td>0 (off) or 1 (on)</td></tr></table> <p>Original sizes for each setting in SIZE</p> <table><tr><th>Setting</th><th>Paper size</th><th>Setting</th><th>Paper size</th></tr><tr><td>5000</td><td>A4</td><td>5000</td><td>A5R</td></tr><tr><td>4300</td><td>B5</td><td>7800</td><td>Folio</td></tr><tr><td>5100</td><td>11" x 8 1/2"</td><td>10200</td><td>11" x 17"</td></tr><tr><td>10000</td><td>A3</td><td>9000</td><td>11" x 15"</td></tr><tr><td>8600</td><td>B4</td><td>8400</td><td>8 1/2" x 14"</td></tr><tr><td>7100</td><td>A4R</td><td>6600</td><td>8 1/2" x 11"</td></tr><tr><td>6100</td><td>B5R</td><td>5100</td><td>5 1/2" x 8 1/2"</td></tr></table> <ol style="list-style-type: none">4. Press the start key. Scanning starts under the selected conditions.5. To stop operation, press the stop/clear key. <p>Method: HOME POSITION</p> <ol style="list-style-type: none">1. Select [HOME POSITION].2. Press the start key. The mirror frame of the scanner moves to the home position. <p>Method: DP READING</p> <ol style="list-style-type: none">1. Select [DP READING].2. Press the start key. The mirror frame of the scanner moves to the reading position. <p>Method: DUST CHECK</p> <ol style="list-style-type: none">1. Select [DUST CHECK].2. Press the start key. The exposure lamp lights.3. To turn the exposure lamp off, press the stop/clear key. <p>Completion Press the stop/clear key when scanning stops. The screen for selecting a maintenance item No. is displayed.</p> | Display | Description | SCANNER MOT | Scanner operation | HOME POSITION | Home position operation | DP READING | DP scanning position operation | DUST CHECK | Dust adhesion check operation with lamp on | Display | Operating conditions | Setting range | SIZE | Original size | See below. | LAMP | On and off of the exposure lamp | 0 (off) or 1 (on) | Setting | Paper size | Setting | Paper size | 5000 | A4 | 5000 | A5R | 4300 | B5 | 7800 | Folio | 5100 | 11" x 8 1/2" | 10200 | 11" x 17" | 10000 | A3 | 9000 | 11" x 15" | 8600 | B4 | 8400 | 8 1/2" x 14" | 7100 | A4R | 6600 | 8 1/2" x 11" | 6100 | B5R | 5100 | 5 1/2" x 8 1/2" |
| Display | Description | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SCANNER MOT | Scanner operation | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| HOME POSITION | Home position operation | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| DP READING | DP scanning position operation | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| DUST CHECK | Dust adhesion check operation with lamp on | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Display | Operating conditions | Setting range | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SIZE | Original size | See below. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| LAMP | On and off of the exposure lamp | 0 (off) or 1 (on) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Setting | Paper size | Setting | Paper size | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 5000 | A4 | 5000 | A5R | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 4300 | B5 | 7800 | Folio | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 5100 | 11" x 8 1/2" | 10200 | 11" x 17" | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 10000 | A3 | 9000 | 11" x 15" | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 8600 | B4 | 8400 | 8 1/2" x 14" | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 7100 | A4R | 6600 | 8 1/2" x 11" | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 6100 | B5R | 5100 | 5 1/2" x 8 1/2" | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |

| Maintenance item No. | Description | | | | | | |
|--------------------------------|---|-----------------|---------------|-----------------|--------------------------------|-----------|----|
| U074 | <p>Adjusting the DP input light luminosity</p> <p>Description Adjusts the luminosity of the exposure lamp for scanning originals from the DP.</p> <p>Purpose Used if the exposure amount differs significantly between when scanning an original on the platen and when scanning an original from the DP.</p> <p>Setting</p> <ol style="list-style-type: none">1. Press the start key.2. Select the item to be set. <table><tr><th>Description</th><th>Setting range</th><th>Initial setting</th></tr><tr><td>DP input light luminosity</td><td>-12 to 12</td><td>0</td></tr></table> <ol style="list-style-type: none">3. Change the setting using the cursor up/down keys. Increasing the setting makes the luminosity higher, and decreasing it makes the luminosity lower.4. Press the start key. The value is set. <p>Supplement While this maintenance item is being executed, copying from an original is available in the interrupt copying mode.</p> <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p> | Description | Setting range | Initial setting | DP input light luminosity | -12 to 12 | 0 |
| Description | Setting range | Initial setting | | | | | |
| DP input light luminosity | -12 to 12 | 0 | | | | | |
| U080 | <p>Setting the economy mode</p> <p>Description Sets the level in the economy mode.</p> <p>Purpose To increase or decrease the image density in the eco-print mode.</p> <p>Setting</p> <ol style="list-style-type: none">1. Press the start key.2. Select the item to be set. <table><tr><th>Description</th><th>Setting range</th><th>Initial setting</th></tr><tr><td>Exposure is toner economy mode</td><td>-12 to 0</td><td>-6</td></tr></table> <ol style="list-style-type: none">3. Change the setting value using the cursor up/down keys. Increasing the setting makes the image darker; decreasing it makes the image lighter.4. Press the start key. The value is set. <p>Supplement While this maintenance item is being executed, copying from an original is available in the interrupt copying mode.</p> <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p> | Description | Setting range | Initial setting | Exposure is toner economy mode | -12 to 0 | -6 |
| Description | Setting range | Initial setting | | | | | |
| Exposure is toner economy mode | -12 to 0 | -6 | | | | | |

TONER

www.tonerplus.com.ua

| Maintenance item No. | Description | | | | | | | | | | | | |
|----------------------|--|---------------|-----------------|---------------|-----------------|-----|---|----------|----|------------|--|---|---|
| U087 | <p>Setting DP reading position modification operation</p> <p>Description The presence or absence of dust is determined by comparing the scan data of the original trailing edge and that taken after the original is conveyed past the DP original scanning position. If dust is identified, the DP original scanning position is adjusted for the following originals.</p> <p>Purpose When using optional DP, to solve the problem when black lines occurs due to the dust with respect to original reading position.</p> <p>Method</p> <ol style="list-style-type: none">1. Press the start key.2. Select the item. <table><tr><th>Display</th><th>Description</th><th>Setting range</th><th>Initial setting</th></tr><tr><td>CCD</td><td>Setting of standard data when dust is detected.</td><td>10 to 95</td><td>35</td></tr><tr><td>BLACK LINE</td><td>Initialization of original reading position.</td><td>-</td><td>-</td></tr></table> <p>Setting: Standard data when dust is detected</p> <ol style="list-style-type: none">1. Change the value using the cursor up/down keys.2. Press the start key. The value is set. <p>Setting: Initialization of original reading position</p> <ol style="list-style-type: none">1. Select [CLEAR].2. Press the start key. The setting is cleared. <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p> | Display | Description | Setting range | Initial setting | CCD | Setting of standard data when dust is detected. | 10 to 95 | 35 | BLACK LINE | Initialization of original reading position. | - | - |
| Display | Description | Setting range | Initial setting | | | | | | | | | | |
| CCD | Setting of standard data when dust is detected. | 10 to 95 | 35 | | | | | | | | | | |
| BLACK LINE | Initialization of original reading position. | - | - | | | | | | | | | | |

| Maintenance item No. | Description | | | | | | | | | | | | | | | | | | | | | | | | |
|------------------------------|---|--|-------------------------|---------|-----------|---|--|------------|---|----------------------------|-----------|---|--|------------|---|--|-------------|---------------|-----------------|------------------------------|----------|---|-----------|---------|---|
| U089 | <p>Outputting a MIP-PG pattern</p> <p>Description Selects and outputs the MIP-PG pattern created in the machine.</p> <p>Purpose To check copier status other than scanner when adjusting image printing, using MIP-PG pattern output (without scanning).</p> <p>Method</p> <ol style="list-style-type: none">1. Press the start key.2. Select the MIP-PG pattern to be output and press the start key. <table><tr><th>Display</th><th>PG pattern to be output</th><th>Purpose</th></tr><tr><td>GRAYSCALE</td><td></td><td>To check the laser scanner unit engine output characteristics.</td></tr><tr><td>MONO-LEVEL</td><td></td><td>To check the drum quality.</td></tr><tr><td>256-LEVEL</td><td></td><td>To check resolution reproducibility in printing.</td></tr><tr><td>1 dot-LINE</td><td></td><td>To check fine line reproducibility. To adjust the position of the laser scanner unit (lateral squareness)</td></tr></table> <ol style="list-style-type: none">3. To change the output conditions of MONO-LEVEL and 1dot-LINE, use the couzor up/down keys to change the preset values and press the start key to register the setting. <table><tr><th>Description</th><th>Setting range</th><th>Initial setting</th></tr><tr><td>Output density of MONO-LEVEL</td><td>0 to 255</td><td>0</td></tr><tr><td>1dot-LINE</td><td>0 to 21</td><td>0</td></tr></table> <ol style="list-style-type: none">4. Press the interrupt key.5. Press the start key. A MIP-PG pattern is output.6. To return to the screen for selecting an item, press the interrupt key. <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p> | Display | PG pattern to be output | Purpose | GRAYSCALE |  | To check the laser scanner unit engine output characteristics. | MONO-LEVEL |  | To check the drum quality. | 256-LEVEL |  | To check resolution reproducibility in printing. | 1 dot-LINE |  | To check fine line reproducibility. To adjust the position of the laser scanner unit (lateral squareness) | Description | Setting range | Initial setting | Output density of MONO-LEVEL | 0 to 255 | 0 | 1dot-LINE | 0 to 21 | 0 |
| Display | PG pattern to be output | Purpose | | | | | | | | | | | | | | | | | | | | | | | |
| GRAYSCALE |  | To check the laser scanner unit engine output characteristics. | | | | | | | | | | | | | | | | | | | | | | | |
| MONO-LEVEL |  | To check the drum quality. | | | | | | | | | | | | | | | | | | | | | | | |
| 256-LEVEL |  | To check resolution reproducibility in printing. | | | | | | | | | | | | | | | | | | | | | | | |
| 1 dot-LINE |  | To check fine line reproducibility. To adjust the position of the laser scanner unit (lateral squareness) | | | | | | | | | | | | | | | | | | | | | | | |
| Description | Setting range | Initial setting | | | | | | | | | | | | | | | | | | | | | | | |
| Output density of MONO-LEVEL | 0 to 255 | 0 | | | | | | | | | | | | | | | | | | | | | | | |
| 1dot-LINE | 0 to 21 | 0 | | | | | | | | | | | | | | | | | | | | | | | |

TONER

www.tonerplus.com.ua

| Maintenance item No. | Description | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|----------------------|---|---------------|-----------------|-------|------------------------------------|------|----------------------|-------|-----------------------|----------|---------------------------------|-----------|----------------------------------|---------|-------------|---------------|-----------------|--------------|---|--------|---|---------------|--|--------|---|---------|-------------|---------------|-----------------|-------------|---|--------|---|--------------|--|--------|---|
| U093 | <p>Setting the exposure density gradient</p> <p>Description Changes the exposure density gradient in the manual density mode, depending on respective image quality modes.</p> <p>Purpose To set how the image density is altered by a change of one step in the manual density adjustment for respective image quality modes. Also used to make copy images darker or lighter.</p> <p>Method</p> <ol style="list-style-type: none">1. Press the start key.2. Select the image quality mode. The setting screen for the selected item is displayed. <table><tr><th>Display</th><th>Description</th></tr><tr><td>MIXED</td><td>Density in the text and photo mode</td></tr><tr><td>TEXT</td><td>Density in text mode</td></tr><tr><td>PHOTO</td><td>Density in photo mode</td></tr><tr><td>FAX TEXT</td><td>Density in the text in fax mode</td></tr><tr><td>FAX PHOTO</td><td>Density in the photo in fax mode</td></tr></table> <p>Setting: Density in text and photo mode</p> <ol style="list-style-type: none">1. Select the item to be set.2. Adjust the setting using the cursor up/down keys. <table><tr><th>Display</th><th>Description</th><th>Setting range</th><th>Initial setting</th></tr><tr><td>MIXED DARKER</td><td>Change in density when manual density is set dark</td><td>0 to 3</td><td>0</td></tr><tr><td>MIXED LIGHTER</td><td>Change in density when manual density is set light</td><td>0 to 3</td><td>0</td></tr></table> <p>Increasing the setting makes the change in density larger, and decreasing it makes the change smaller.</p> <div><p>Figure 1-3-14</p></div> <ol style="list-style-type: none">3. Press the start key. The value is set.4. To return to the screen for selecting an item, press the stop/clear key. <p>Setting: Density in text mode</p> <ol style="list-style-type: none">1. Select the item to be set.2. Adjust the setting using the cursor up/down keys. <table><tr><th>Display</th><th>Description</th><th>Setting range</th><th>Initial setting</th></tr><tr><td>TEXT DARKER</td><td>Change in density when manual density is set dark</td><td>0 to 3</td><td>0</td></tr><tr><td>TEXT LIGHTER</td><td>Change in density when manual density is set light</td><td>0 to 3</td><td>0</td></tr></table> <p>Increasing the setting makes the change in density larger, and decreasing it makes the change smaller.</p> <ol style="list-style-type: none">3. Press the start key. The value is set.4. To return to the screen for selecting an item, press the stop/clear key. | Display | Description | MIXED | Density in the text and photo mode | TEXT | Density in text mode | PHOTO | Density in photo mode | FAX TEXT | Density in the text in fax mode | FAX PHOTO | Density in the photo in fax mode | Display | Description | Setting range | Initial setting | MIXED DARKER | Change in density when manual density is set dark | 0 to 3 | 0 | MIXED LIGHTER | Change in density when manual density is set light | 0 to 3 | 0 | Display | Description | Setting range | Initial setting | TEXT DARKER | Change in density when manual density is set dark | 0 to 3 | 0 | TEXT LIGHTER | Change in density when manual density is set light | 0 to 3 | 0 |
| Display | Description | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| MIXED | Density in the text and photo mode | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| TEXT | Density in text mode | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| PHOTO | Density in photo mode | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| FAX TEXT | Density in the text in fax mode | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| FAX PHOTO | Density in the photo in fax mode | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Display | Description | Setting range | Initial setting | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| MIXED DARKER | Change in density when manual density is set dark | 0 to 3 | 0 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| MIXED LIGHTER | Change in density when manual density is set light | 0 to 3 | 0 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Display | Description | Setting range | Initial setting | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| TEXT DARKER | Change in density when manual density is set dark | 0 to 3 | 0 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| TEXT LIGHTER | Change in density when manual density is set light | 0 to 3 | 0 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |

| Maintenance item No. | Description | | | | | | | | | | | | |
|---|--|--|-----------------|-----------------|------------------|---|---|--------|------------------|--|--|--------|---|
| U093 | Setting: Density in photo mode 1. Select the item to be set. 2. Adjust the setting using the cursor up/down keys. | | | | | | | | | | | | |
| | <table><tr><th>Display</th><th>Description</th><th>Setting range</th><th>Initial setting</th></tr><tr><td>PHOTO DARKER</td><td>Change in density when manual density is set dark</td><td>0 to 3</td><td>0</td></tr><tr><td>PHOTO LIGTER</td><td>Change in density when manual density is set light</td><td>0 to 3</td><td>0</td></tr></table> | Display | Description | Setting range | Initial setting | PHOTO DARKER | Change in density when manual density is set dark | 0 to 3 | 0 | PHOTO LIGTER | Change in density when manual density is set light | 0 to 3 | 0 |
| | Display | Description | Setting range | Initial setting | | | | | | | | | |
| | PHOTO DARKER | Change in density when manual density is set dark | 0 to 3 | 0 | | | | | | | | | |
| | PHOTO LIGTER | Change in density when manual density is set light | 0 to 3 | 0 | | | | | | | | | |
| | Increasing the setting makes the change in density larger, and decreasing it makes the change smaller. | | | | | | | | | | | | |
| | 3. Press the start key. The value is set. 4. To return to the screen for selecting an item, press the stop/clear key. | | | | | | | | | | | | |
| | Setting: Density in text in fax mode 1. Select the item to be set. 2. Adjust the setting using the cursor up/down keys. | | | | | | | | | | | | |
| | <table><tr><th>Display</th><th>Description</th><th>Setting range</th><th>Initial setting</th></tr><tr><td>FAX TEXT DARKER</td><td>Change in density when manual density is set dark</td><td>0 to 4</td><td>2</td></tr><tr><td>FAX TEXT LIGHTER</td><td>Change in density when manual density is set light</td><td>0 to 4</td><td>2</td></tr></table> | Display | Description | Setting range | Initial setting | FAX TEXT DARKER | Change in density when manual density is set dark | 0 to 4 | 2 | FAX TEXT LIGHTER | Change in density when manual density is set light | 0 to 4 | 2 |
| | Display | Description | Setting range | Initial setting | | | | | | | | | |
| | FAX TEXT DARKER | Change in density when manual density is set dark | 0 to 4 | 2 | | | | | | | | | |
| | FAX TEXT LIGHTER | Change in density when manual density is set light | 0 to 4 | 2 | | | | | | | | | |
| Increasing the setting makes the change in density larger, and decreasing it makes the change smaller. | | | | | | | | | | | | | |
| 3. Press the start key. The value is set. 4. To return to the screen for selecting an item, press the stop/clear key. | | | | | | | | | | | | | |
| Setting: Density in photo in fax mode 1. Select the item to be set. 2. Adjust the setting using the cursor up/down keys. | | | | | | | | | | | | | |
| <table><tr><th>Display</th><th>Description</th><th>Setting range</th><th>Initial setting</th></tr><tr><td>FAX PHOTO DARKER</td><td>Change in density when manual density is set dark</td><td>0 to 6</td><td>3</td></tr><tr><td>FAX PHOTO LIGTER</td><td>Change in density when manual density is set light</td><td>0 to 6</td><td>3</td></tr></table> | Display | Description | Setting range | Initial setting | FAX PHOTO DARKER | Change in density when manual density is set dark | 0 to 6 | 3 | FAX PHOTO LIGTER | Change in density when manual density is set light | 0 to 6 | 3 | |
| Display | Description | Setting range | Initial setting | | | | | | | | | | |
| FAX PHOTO DARKER | Change in density when manual density is set dark | 0 to 6 | 3 | | | | | | | | | | |
| FAX PHOTO LIGTER | Change in density when manual density is set light | 0 to 6 | 3 | | | | | | | | | | |
| Increasing the setting makes the change in density larger, and decreasing it makes the change smaller. | | | | | | | | | | | | | |
| 3. Press the start key. The value is set. 4. To return to the screen for selecting an item, press the stop/clear key. | | | | | | | | | | | | | |
| Supplement While this maintenance item is being executed, copying from an original is available in the interrupt copying mode. | | | | | | | | | | | | | |
| Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed. | | | | | | | | | | | | | |

TONER

www.tonerplus.com.ua

| Maintenance item No. | Description | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|----------------------|---|-----------------------|-----------------|------|---|-----------|---|---------|-------------|---------------|-----------------|-------|----------------------------------|----------|-----|-----------|------------------------------|----------|----|----------|--|-----------------------|-----|---------------|---|----------|---|------|--------------------------------|---------|---|
| U099 | <p>Adjusting original size detection</p> <p>Description Checks the operation of the original size detection sensor and sets the sensing threshold value.</p> <p>Purpose To adjust the sensitiveness of the sensor and size judgement time if the original size detection sensor malfunctions frequently due to incident light or the like.</p> <p>Method</p> <ol style="list-style-type: none">1. Press the start key.2. Select the item. The screen for executing each item is displayed. <table><tr><th>Display</th><th>Description</th></tr><tr><td>DATA</td><td>Displaying detection sensor transmission data</td></tr><tr><td>B/W LEVEL</td><td>Setting detection sensor threshold value Setting original size judgment time</td></tr></table> <p>Method to display the data for the sensor</p> <ol style="list-style-type: none">1. Place the original and close the original cover or DP.2. Press the start key. The detection sensor transmission data is displayed. <div><div>Rear of machine Center of machine Front of machine</div><div><div>: 123 123 123</div><div>: 123 123 123</div><div>: 255 255 255</div></div></div> <p>Figure 1-3-15</p> <ol style="list-style-type: none">3. To return to the screen for selecting an item, press the stop/clear key. <p>Setting</p> <ol style="list-style-type: none">1. Select an item to be set.2. Adjust the setting using the +/- or numeric keys. <table><tr><th>Display</th><th>Description</th><th>Setting range</th><th>Initial setting</th></tr><tr><td>LEVEL</td><td>Detection sensor threshold value</td><td>0 to 255</td><td>215</td></tr><tr><td>WAIT TIME</td><td>Original size judgment time*</td><td>0 to 100</td><td>30</td></tr><tr><td>A4R AREA</td><td>Threshold value in the main scan direction for A4R detection</td><td>220 (mm)/ 240 (mm)</td><td>240</td></tr><tr><td>ORIGINAL AREA</td><td>Original size detection position display (mm)</td><td>0 to 350</td><td>-</td></tr><tr><td>SIZE</td><td>Detected original size display</td><td>0 to 63</td><td>-</td></tr></table> <ol style="list-style-type: none">3. Press the start key. The value is set.4. To return to the screen for selecting an item, press the stop/clear key. <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p> | Display | Description | DATA | Displaying detection sensor transmission data | B/W LEVEL | Setting detection sensor threshold value Setting original size judgment time | Display | Description | Setting range | Initial setting | LEVEL | Detection sensor threshold value | 0 to 255 | 215 | WAIT TIME | Original size judgment time* | 0 to 100 | 30 | A4R AREA | Threshold value in the main scan direction for A4R detection | 220 (mm)/ 240 (mm) | 240 | ORIGINAL AREA | Original size detection position display (mm) | 0 to 350 | - | SIZE | Detected original size display | 0 to 63 | - |
| Display | Description | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| DATA | Displaying detection sensor transmission data | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| B/W LEVEL | Setting detection sensor threshold value Setting original size judgment time | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Display | Description | Setting range | Initial setting | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| LEVEL | Detection sensor threshold value | 0 to 255 | 215 | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| WAIT TIME | Original size judgment time* | 0 to 100 | 30 | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| A4R AREA | Threshold value in the main scan direction for A4R detection | 220 (mm)/ 240 (mm) | 240 | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ORIGINAL AREA | Original size detection position display (mm) | 0 to 350 | - | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SIZE | Detected original size display | 0 to 63 | - | | | | | | | | | | | | | | | | | | | | | | | | | | | | |

| Maintenance item No. | Description | | | | | | |
|----------------------|--|---------|-------------|-------|-----------------------------|--------------|---|
| U100 | <p>Setting the main high voltage</p> <p>Description Performs main charging.</p> <p>Purpose To check main charging.</p> <p>Method</p> <ol style="list-style-type: none">1. Press the start key.2. Select the item to be operated.3. Press the start key. The selected operation starts. <table><tr><th>Display</th><th>Description</th></tr><tr><td>MC ON</td><td>Turning the main charger on</td></tr><tr><td>LASER ON/OFF</td><td>Turning the main charger on and the laser scanner unit on and off</td></tr></table> <ol style="list-style-type: none">4. To stop operation, press the stop/clear key. <p>Completion Press the stop/clear key when main charger output stops. The screen for selecting a maintenance item No. is displayed.</p> | Display | Description | MC ON | Turning the main charger on | LASER ON/OFF | Turning the main charger on and the laser scanner unit on and off |
| Display | Description | | | | | | |
| MC ON | Turning the main charger on | | | | | | |
| LASER ON/OFF | Turning the main charger on and the laser scanner unit on and off | | | | | | |



| Maintenance item No. | Description | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|----------------------|---|---------------|-----------------|---------------|-----------------|----------|---|----------|----|-----------|--|----------|----|----------|--|----------|----|---------|--------------------------|----------|----|---------|----------------------------|--------|---|----------|--|----------|-----|-------|---|----------|----|--------|---|----------|----|-------|---|----------|----|--------|---|----------|----|
| U101 | <p>Setting the other high voltages</p> <p>Description Sets the developing bias control voltage, the transfer control voltage and the separation control voltage or checks the output of these voltages. Sets the transfer control voltage and the separation control voltage ON/OFF timing.</p> <p>Purpose To check the developing bias, the transfer voltage and the separation voltage or to take measures against drop of image density or background fog.</p> <p>Setting</p> <ol style="list-style-type: none">1. Press the start key.2. Select the item to be set.3. Change the setting using the * or # keys. <table><tr><th>Display</th><th>Description</th><th>Setting range</th><th>Initial setting</th></tr><tr><td>DEV BIAS</td><td>Developing bias AC component frequency at image formation</td><td>20 to 32</td><td>26</td></tr><tr><td>DEV SBIAS</td><td>Developing shift bias potential at image formation</td><td>0 to 255</td><td>58</td></tr><tr><td>DEV DUTY</td><td>Developing bias AC component duty at image formation</td><td>0 to 100</td><td>50</td></tr><tr><td>TC DATA</td><td>Transfer control voltage</td><td>0 to 255</td><td>89</td></tr><tr><td>SC DATA</td><td>Separation control voltage</td><td>0 to 2</td><td>1</td></tr><tr><td>TC DATA2</td><td>Transfer control voltage for small sizes</td><td>0 to 255</td><td>115</td></tr><tr><td>TC ON</td><td>Time of period since the registration clutch is turned on until the transfer voltage is turned on</td><td>0 to 255</td><td>91</td></tr><tr><td>TC OFF</td><td>Time of period since the registration clutch is turned off until the transfer voltage is turned off</td><td>0 to 255</td><td>68</td></tr><tr><td>SC ON</td><td>Time of period since the registration clutch is turned on until the separation voltage is turned on</td><td>0 to 255</td><td>40</td></tr><tr><td>SC OFF</td><td>Time of period since the registration clutch is turned off until the separation voltage is turned off</td><td>0 to 255</td><td>92</td></tr></table> <p>Increasing the DEV BIAS setting makes the image darker; decreasing it makes the image lighter. Increasing the DEV SBIAS setting makes the image darker. Increasing the DEV DUTY setting makes the image lighter; decreasing it makes the image darker. Increasing the TC DATA/TC DATA2 setting makes the transfer voltage higher, and decreasing it makes the voltage lower. Increasing the SC DATA setting makes the separation voltage higher, and decreasing it makes the voltage lower.</p> <ol style="list-style-type: none">4. Press the start key. The value is set. <p>Supplement While this maintenance item is being executed, copying from an original is available in the interrupt copying mode.</p> <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p> | Display | Description | Setting range | Initial setting | DEV BIAS | Developing bias AC component frequency at image formation | 20 to 32 | 26 | DEV SBIAS | Developing shift bias potential at image formation | 0 to 255 | 58 | DEV DUTY | Developing bias AC component duty at image formation | 0 to 100 | 50 | TC DATA | Transfer control voltage | 0 to 255 | 89 | SC DATA | Separation control voltage | 0 to 2 | 1 | TC DATA2 | Transfer control voltage for small sizes | 0 to 255 | 115 | TC ON | Time of period since the registration clutch is turned on until the transfer voltage is turned on | 0 to 255 | 91 | TC OFF | Time of period since the registration clutch is turned off until the transfer voltage is turned off | 0 to 255 | 68 | SC ON | Time of period since the registration clutch is turned on until the separation voltage is turned on | 0 to 255 | 40 | SC OFF | Time of period since the registration clutch is turned off until the separation voltage is turned off | 0 to 255 | 92 |
| Display | Description | Setting range | Initial setting | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| DEV BIAS | Developing bias AC component frequency at image formation | 20 to 32 | 26 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| DEV SBIAS | Developing shift bias potential at image formation | 0 to 255 | 58 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| DEV DUTY | Developing bias AC component duty at image formation | 0 to 100 | 50 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| TC DATA | Transfer control voltage | 0 to 255 | 89 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SC DATA | Separation control voltage | 0 to 2 | 1 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| TC DATA2 | Transfer control voltage for small sizes | 0 to 255 | 115 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| TC ON | Time of period since the registration clutch is turned on until the transfer voltage is turned on | 0 to 255 | 91 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| TC OFF | Time of period since the registration clutch is turned off until the transfer voltage is turned off | 0 to 255 | 68 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SC ON | Time of period since the registration clutch is turned on until the separation voltage is turned on | 0 to 255 | 40 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SC OFF | Time of period since the registration clutch is turned off until the separation voltage is turned off | 0 to 255 | 92 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |

TONER

www.tonerplus.com.ua

| Maintenance item No. | Description | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|----------------------|--|---|--|--|---------|-------------|---------------|-----------------|------|-------------------------|--------|---|---------|------------|-------------|-------------------------|--------------------|---------------------------------|---------------------------------|--|--------------------|---------------------------------|---|--|--------------------|---|---|---|--------------------|-----------------------------------|--------------------------------|--|--------------------|---|--------------------------------|--|--------------------|--------------------------------|--------------------------------|---|
| U110 | Checking the drum count Description Displays the drum counts for checking. Purpose To check the drum status. Method Press the start key. The drum counter count is displayed. Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| U114 | Setting separation charger mode Description Sets the separation charger mode. Purpose To change the setting if the fuser offset or carrier leaking occurs. Method <div><div>1. Press the start key.</div><div>2. Change the setting using the cursor up/down keys.</div></div> <table><tr><th>Display</th><th>Description</th><th>Setting range</th><th>Initial setting</th></tr><tr><td>MODE</td><td>Separation charger mode</td><td>0 to 5</td><td>4</td></tr></table> <div>Details on the modes<table><tr><th>Display</th><th>First page</th><th>Second page</th><th>Specification by design</th></tr><tr><td>MODE0 (Value 0)</td><td>Full page separation turned off</td><td>Full page separation turned off</td><td>Countermeasure against thick paper, offset and carrier leaking</td></tr><tr><td>MODE1 (Value 1)</td><td>Full page separation turned off</td><td>Leading edge and trailing edge separation turned on</td><td>Countermeasure against thick paper, offset and carrier leaking</td></tr><tr><td>MODE2 (Value 2)</td><td>Leading edge and trailing edge separation turned on</td><td>Leading edge and trailing edge separation turned on</td><td>Countermeasure against color paper and back-side offset</td></tr><tr><td>MODE3 (Value 3)</td><td>Leading edge separation turned on</td><td>Full page separation turned on</td><td>Countermeasure against humidity-optimized paper and offset/smear</td></tr><tr><td>MODE4 (Value 4)</td><td>Leading edge and trailing edge separation turned on</td><td>Full page separation turned on</td><td>Countermeasure against low temperature and low moisture, and faulty paper separation</td></tr><tr><td>MODE5 (Value 5)</td><td>Full page separation turned on</td><td>Full page separation turned on</td><td>Countermeasure against thin paper and electrostatic discharging</td></tr></table></div> <div><div>3. Press the start key. The setting is set.</div><div>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</div></div> | | | | Display | Description | Setting range | Initial setting | MODE | Separation charger mode | 0 to 5 | 4 | Display | First page | Second page | Specification by design | MODE0 (Value 0) | Full page separation turned off | Full page separation turned off | Countermeasure against thick paper, offset and carrier leaking | MODE1 (Value 1) | Full page separation turned off | Leading edge and trailing edge separation turned on | Countermeasure against thick paper, offset and carrier leaking | MODE2 (Value 2) | Leading edge and trailing edge separation turned on | Leading edge and trailing edge separation turned on | Countermeasure against color paper and back-side offset | MODE3 (Value 3) | Leading edge separation turned on | Full page separation turned on | Countermeasure against humidity-optimized paper and offset/smear | MODE4 (Value 4) | Leading edge and trailing edge separation turned on | Full page separation turned on | Countermeasure against low temperature and low moisture, and faulty paper separation | MODE5 (Value 5) | Full page separation turned on | Full page separation turned on | Countermeasure against thin paper and electrostatic discharging |
| Display | Description | Setting range | Initial setting | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| MODE | Separation charger mode | 0 to 5 | 4 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Display | First page | Second page | Specification by design | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| MODE0 (Value 0) | Full page separation turned off | Full page separation turned off | Countermeasure against thick paper, offset and carrier leaking | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| MODE1 (Value 1) | Full page separation turned off | Leading edge and trailing edge separation turned on | Countermeasure against thick paper, offset and carrier leaking | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| MODE2 (Value 2) | Leading edge and trailing edge separation turned on | Leading edge and trailing edge separation turned on | Countermeasure against color paper and back-side offset | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| MODE3 (Value 3) | Leading edge separation turned on | Full page separation turned on | Countermeasure against humidity-optimized paper and offset/smear | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| MODE4 (Value 4) | Leading edge and trailing edge separation turned on | Full page separation turned on | Countermeasure against low temperature and low moisture, and faulty paper separation | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| MODE5 (Value 5) | Full page separation turned on | Full page separation turned on | Countermeasure against thin paper and electrostatic discharging | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |

TONER

www.tonerplus.com.ua

| Maintenance item No. | Description | | | | | | |
|----------------------|---|---------|-------------|---------------------|-------------------------------|--------------------|-----------------------------|
| U117 | <p>Checking the drum number</p> <p>Description Displays the drum number.</p> <p>Purpose To check the drum number.</p> <p>Method Press the start key. The drum number is displayed.</p> <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p> | | | | | | |
| U118 | <p>Displaying the drum history</p> <p>Description Displays the past record of machine number and the drum counter.</p> <p>Purpose To check the count value of machine number and the drum counter.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select the item to be display. 3. Press thte start key. Past record of 5 cases is displayed. <table border="1"> <thead> <tr> <th>Display</th><th>Description</th></tr> </thead> <tbody> <tr> <td>MACHINE No. HISTORY</td><td>Past record of machine number</td></tr> <tr> <td>DRUM COUNT HISTORY</td><td>Past record of drum counter</td></tr> </tbody> </table> <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p> | Display | Description | MACHINE No. HISTORY | Past record of machine number | DRUM COUNT HISTORY | Past record of drum counter |
| Display | Description | | | | | | |
| MACHINE No. HISTORY | Past record of machine number | | | | | | |
| DRUM COUNT HISTORY | Past record of drum counter | | | | | | |
| U130 | <p>Initial setting for the developing unit</p> <p>Description Replenishes toner to the developing unit to a certain level from the toner container that has been installed.</p> <p>Purpose To operate when installing the machine or replacing the developing unit.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. The screen for executing is displayed. 2. Press the start key. Toner installation is started and the output value of the sensor and execution time are displayed. <table border="1"> <thead> <tr> <th>Display</th><th>Description</th></tr> </thead> <tbody> <tr> <td>TONER SENSOR</td><td>Output value of the sensor</td></tr> <tr> <td>TIME(SEC)</td><td>Execution time</td></tr> </tbody> </table> <p>Completion Press the stop/clear key after initial setting is complete. The screen for selecting a maintenance item No. is displayed.</p> | Display | Description | TONER SENSOR | Output value of the sensor | TIME(SEC) | Execution time |
| Display | Description | | | | | | |
| TONER SENSOR | Output value of the sensor | | | | | | |
| TIME(SEC) | Execution time | | | | | | |

| Maintenance item No. | Description | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|----------------------|---|---------------|-----------------|-------|---|-------|---------------------|---------|-------------|-------------|------------------------|--------------|---------------------------|---------|-------------|---------------|-----------------|---------------|--------------------------------|----------|-----|----------------|---------------------------|----------|----|-----------------|----------------------------|----------|-----|
| U135 | <p>Checking toner motor operation</p> <p>Description Turns the toner feed motor and toner feed clutch on.</p> <p>Purpose To check the operation of the toner feed motor or toner feed clutch. Settings may also be modified where mobility in toner is inferior or when printing materials of very high density. Normally no change is necessary from the initial setting.</p> <p>Method</p> <ol style="list-style-type: none">1. Press the start key.2. Select the item. <table><tr><th>Display</th><th>Description</th></tr><tr><td>TONER</td><td>The toner feed motor (TFM) or the toner feed clutch (TNFCL) is turned on.</td></tr><tr><td>TIMER</td><td>On-Off time setting</td></tr></table> <p>Method</p> <ol style="list-style-type: none">1. Select the item.2. Press the start key. The operation starts. <table><tr><th>Display</th><th>Description</th></tr><tr><td>TONER CARRY</td><td>Toner feed motor (TFM)</td></tr><tr><td>TONER SUPPLY</td><td>Toner feed clutch (TNFCL)</td></tr></table> <ol style="list-style-type: none">3. To stop operation, press the stop/clear key. <p>Setting</p> <ol style="list-style-type: none">1. Select the item to be set.2. Change the setting using the cursor up/down keys. <table><tr><th>Display</th><th>Description</th><th>Setting range</th><th>Initial setting</th></tr><tr><td>CARRY ON TIME</td><td>Toner feed motor drive on time</td><td>0 to 255</td><td>100</td></tr><tr><td>SUPPLY ON TIME</td><td>Toner feed clutch on time</td><td>0 to 255</td><td>30</td></tr><tr><td>SUPPLY OFF TIME</td><td>Toner feed clutch off time</td><td>0 to 255</td><td>100</td></tr></table> <p>Increase the setting value of [CARRY ON TIME] where mobility in toner is inferior. Increase the setting value of [SUPPLY ON TIME] when printing materials of very high density.</p> <ol style="list-style-type: none">3. Press the start key. The value is set. <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p> | Display | Description | TONER | The toner feed motor (TFM) or the toner feed clutch (TNFCL) is turned on. | TIMER | On-Off time setting | Display | Description | TONER CARRY | Toner feed motor (TFM) | TONER SUPPLY | Toner feed clutch (TNFCL) | Display | Description | Setting range | Initial setting | CARRY ON TIME | Toner feed motor drive on time | 0 to 255 | 100 | SUPPLY ON TIME | Toner feed clutch on time | 0 to 255 | 30 | SUPPLY OFF TIME | Toner feed clutch off time | 0 to 255 | 100 |
| Display | Description | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| TONER | The toner feed motor (TFM) or the toner feed clutch (TNFCL) is turned on. | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| TIMER | On-Off time setting | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Display | Description | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| TONER CARRY | Toner feed motor (TFM) | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| TONER SUPPLY | Toner feed clutch (TNFCL) | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Display | Description | Setting range | Initial setting | | | | | | | | | | | | | | | | | | | | | | | | | | |
| CARRY ON TIME | Toner feed motor drive on time | 0 to 255 | 100 | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SUPPLY ON TIME | Toner feed clutch on time | 0 to 255 | 30 | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SUPPLY OFF TIME | Toner feed clutch off time | 0 to 255 | 100 | | | | | | | | | | | | | | | | | | | | | | | | | | |

TONER

www.tonerplus.com.ua

| Maintenance item No. | Description | | | | | | | | | | | | | | | | |
|----------------------|--|------------------|-----------------|------------------|--------------------|---------------|--|------------------|------------------------------|------------------|-----------------------|----------|---|-------|----------------|----------|----|
| U144 | <p>Setting toner loading operation</p> <p>Description Sets toner loading operation after completion of copying. Toner is forcibly evacuated in case the average printing ratio for the number of printed pages assigned by [PAGE] is lower than the ratio defined by [RATIO].</p> <p>Purpose To set whether or not toner is loaded on the drum after low density copying. Normally no change is necessary from the initial setting.</p> <p>Setting</p> <ol style="list-style-type: none">1. Press the start key.2. Select the item to be set.3. Change the setting using the cursor up/down keys. <table><tr><th>Display</th><th>Description</th><th>Setting range</th><th>Initial setting</th></tr><tr><td>MODE</td><td>Toner loading operation</td><td>1 (ON) / 0 (OFF)</td><td>0</td></tr><tr><td>PAGE</td><td>Number of pages set</td><td>1 to 50</td><td>5</td></tr><tr><td>RATIO</td><td>Printing ratio</td><td>10 to 40</td><td>30</td></tr></table> <ol style="list-style-type: none">4. Press the start key. The value is set. <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p> | Display | Description | Setting range | Initial setting | MODE | Toner loading operation | 1 (ON) / 0 (OFF) | 0 | PAGE | Number of pages set | 1 to 50 | 5 | RATIO | Printing ratio | 10 to 40 | 30 |
| Display | Description | Setting range | Initial setting | | | | | | | | | | | | | | |
| MODE | Toner loading operation | 1 (ON) / 0 (OFF) | 0 | | | | | | | | | | | | | | |
| PAGE | Number of pages set | 1 to 50 | 5 | | | | | | | | | | | | | | |
| RATIO | Printing ratio | 10 to 40 | 30 | | | | | | | | | | | | | | |
| U150 | <p>Checking sensors for toner</p> <p>Description Displays the on-off status of each sensor or switch related to toner.</p> <p>Purpose To check if the sensors and switches operate correctly.</p> <p>Method</p> <ol style="list-style-type: none">1. Press the start key.2. Turn each switch on and off manually to check the status. When the on-status of a switch is detected, that switch is displayed in reverse. <table><tr><th>Display</th><th>Switches</th></tr><tr><td>DEVELOPER SENSOR</td><td>Toner sensor (TNS)</td></tr><tr><td>CONTAINER SET</td><td>Toner container detection switch (TCDSW)</td></tr><tr><td>CONTAINER SENSOR</td><td>Toner container sensor (TCS)</td></tr><tr><td>WASTE BOX SENSOR</td><td>Overflow sensor (OFS)</td></tr><tr><td>MOTOR ON</td><td>The toner feed clutch (TNFCL), the paper feed motor (PFM) and the toner feed motor (TFM) are turned on.</td></tr></table> <p>To stop motor driving, press [MOTOR ON] again.</p> <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p> | Display | Switches | DEVELOPER SENSOR | Toner sensor (TNS) | CONTAINER SET | Toner container detection switch (TCDSW) | CONTAINER SENSOR | Toner container sensor (TCS) | WASTE BOX SENSOR | Overflow sensor (OFS) | MOTOR ON | The toner feed clutch (TNFCL), the paper feed motor (PFM) and the toner feed motor (TFM) are turned on. | | | | |
| Display | Switches | | | | | | | | | | | | | | | | |
| DEVELOPER SENSOR | Toner sensor (TNS) | | | | | | | | | | | | | | | | |
| CONTAINER SET | Toner container detection switch (TCDSW) | | | | | | | | | | | | | | | | |
| CONTAINER SENSOR | Toner container sensor (TCS) | | | | | | | | | | | | | | | | |
| WASTE BOX SENSOR | Overflow sensor (OFS) | | | | | | | | | | | | | | | | |
| MOTOR ON | The toner feed clutch (TNFCL), the paper feed motor (PFM) and the toner feed motor (TFM) are turned on. | | | | | | | | | | | | | | | | |

TONER

www.tonerplus.com.ua

| Maintenance item No. | Description | | | | | | | | | | | | | | | | | | | | | | | | |
|----------------------|--|---------------|-----------------|---------------|-----------------|------------------|---|---------------|-----|-----------------|--|---------------|-----|------------------|--|---------------|-----|-----------------|--|---------------|-----|-----------------|--|--------------|---|
| U157 | <p>Checking/clearing the developing drive time</p> <p>Description Displays the developing drive time for checking, or clearing a figure, which is used as a reference when correcting the toner control.</p> <p>Purpose To check the developing drive time after replacing the developing unit.</p> <p>Method Press the start key. The developing drive time is displayed in minutes.</p> <p>Clearing</p> <ol style="list-style-type: none">1. Press the reset key.2. Press the start key. The time is cleared. <p>Setting</p> <ol style="list-style-type: none">1. Enter a drive time (in minutes) using the cursor up/down keys.2. Press the start key. The time is set. <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p> | | | | | | | | | | | | | | | | | | | | | | | | |
| U158 | <p>Checking the developing count</p> <p>Description Displays the developing count for checking.</p> <p>Purpose To check the developing count after replacing the developing unit.</p> <p>Method Press the start key. The developing counter count is displayed.</p> <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p> | | | | | | | | | | | | | | | | | | | | | | | | |
| U161 | <p>Setting the fuser control temperature</p> <p>Description Changes the fuser control temperature.</p> <p>Purpose Normally no change is necessary. However, can be used to prevent curling or creasing of paper, or solve a fuser problem on thick paper.</p> <p>Method</p> <ol style="list-style-type: none">1. Press the start key.2. Select the item to be set.3. Change the setting using the cursor up/down keys. <table><tr><th>Display</th><th>Description</th><th>Setting range</th><th>Initial setting</th></tr><tr><td>DRIVE START TEMP</td><td>Driving start temperature when warm-up starts</td><td>0 to 255 (°C)</td><td>110</td></tr><tr><td>READY CONTROL T</td><td>Fuser center control temperature for displaying [Ready for copying.]</td><td>0 to 255 (°C)</td><td>165</td></tr><tr><td>READY CONTROL T2</td><td>Fuser edge control temperature for displaying [Ready for copying.]</td><td>0 to 255 (°C)</td><td>155</td></tr><tr><td>PRINT CONTROL T</td><td>Fuser center control temperature during printing</td><td>0 to 255 (°C)</td><td>165</td></tr><tr><td>READY DISP TIME</td><td>Time of period from driving until Ready is displayed</td><td>0 to 255 (s)</td><td>0</td></tr></table> <ol style="list-style-type: none">4. Press the start key. The value is set. <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p> | Display | Description | Setting range | Initial setting | DRIVE START TEMP | Driving start temperature when warm-up starts | 0 to 255 (°C) | 110 | READY CONTROL T | Fuser center control temperature for displaying [Ready for copying.] | 0 to 255 (°C) | 165 | READY CONTROL T2 | Fuser edge control temperature for displaying [Ready for copying.] | 0 to 255 (°C) | 155 | PRINT CONTROL T | Fuser center control temperature during printing | 0 to 255 (°C) | 165 | READY DISP TIME | Time of period from driving until Ready is displayed | 0 to 255 (s) | 0 |
| Display | Description | Setting range | Initial setting | | | | | | | | | | | | | | | | | | | | | | |
| DRIVE START TEMP | Driving start temperature when warm-up starts | 0 to 255 (°C) | 110 | | | | | | | | | | | | | | | | | | | | | | |
| READY CONTROL T | Fuser center control temperature for displaying [Ready for copying.] | 0 to 255 (°C) | 165 | | | | | | | | | | | | | | | | | | | | | | |
| READY CONTROL T2 | Fuser edge control temperature for displaying [Ready for copying.] | 0 to 255 (°C) | 155 | | | | | | | | | | | | | | | | | | | | | | |
| PRINT CONTROL T | Fuser center control temperature during printing | 0 to 255 (°C) | 165 | | | | | | | | | | | | | | | | | | | | | | |
| READY DISP TIME | Time of period from driving until Ready is displayed | 0 to 255 (s) | 0 | | | | | | | | | | | | | | | | | | | | | | |

TONER

www.tonerplus.com.ua

| Maintenance item No. | Description | | | | | | |
|----------------------|---|---------|-------------|----|------------------------|-----|-------------------------|
| U163 | <p>Resetting the fuser problem data</p> <p>Description Resets the detection of a service call code indicating a problem in the fuser section.</p> <p>Purpose To prevent accidents due to an abnormally high fuser temperature.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Press [EXECUTE] on the touch panel. 3. Press the start key. The fuser problem data is initialized. 4. Turn the main power switch off and on. | | | | | | |
| U167 | <p>Checking/clearing the fuser counts</p> <p>Description Displays and clears the fuser counts for checking.</p> <p>Purpose To check or clear the fuser counts after replacing the fuser unit.</p> <p>Method Press the start key. The fuser counts is displayed.</p> <p>Clearing</p> <ol style="list-style-type: none"> 1. Press the reset key. 2. Press the start key. The count is cleared. <p>Setting</p> <ol style="list-style-type: none"> 1. Change the count using the numeric key. 2. Press the start key. The count is set. <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p> | | | | | | |
| U193 | <p>Setting the fuser drive control</p> <p>Description Specifies ON/OFF the fuser drive control.</p> <p>Purpose Countermeasure against black dots which is caused by toner adhering to the heat roller separation claws.</p> <p>Setting</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select ON or OFF. <table border="1"> <thead> <tr> <th>Display</th><th>Description</th></tr> </thead> <tbody> <tr> <td>ON</td><td>Fuser drive control ON</td></tr> <tr> <td>OFF</td><td>Fuser drive control OFF</td></tr> </tbody> </table> <p>Initial setting: ON</p> <ol style="list-style-type: none"> 3. Press the start key. The setting is set. <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p> | Display | Description | ON | Fuser drive control ON | OFF | Fuser drive control OFF |
| Display | Description | | | | | | |
| ON | Fuser drive control ON | | | | | | |
| OFF | Fuser drive control OFF | | | | | | |

| Maintenance item No. | Description | | | | | | | | | | |
|----------------------|---|---------|-------------|-----------------|-------------------------------|---------------|-----------------------------|---------------|--------------------------|----------|-----------------------|
| U199 | <p>Checking the fuser temperature</p> <p>Description Displays the fuser temperature, the ambient temperature and the absolute humidity.</p> <p>Purpose To check the fuser temperature, the ambient temperature and the absolute humidity.</p> <p>Method Press the start key. The fuser temperature and ambient temperature are displayed in centigrade (°C) and the absolute humidity is displayed in percentage (%).</p> <table border="1"> <thead> <tr> <th>Display</th><th>Description</th></tr> </thead> <tbody> <tr> <td>FIX CENTER TEMP</td><td>Fuser center temperature (°C)</td></tr> <tr> <td>FIX EDGE TEMP</td><td>Fuser edge temperature (°C)</td></tr> <tr> <td>SURROUND TEMP</td><td>Ambient temperature (°C)</td></tr> <tr> <td>HUMIDITY</td><td>Absolute humidity (%)</td></tr> </tbody> </table> <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p> | Display | Description | FIX CENTER TEMP | Fuser center temperature (°C) | FIX EDGE TEMP | Fuser edge temperature (°C) | SURROUND TEMP | Ambient temperature (°C) | HUMIDITY | Absolute humidity (%) |
| Display | Description | | | | | | | | | | |
| FIX CENTER TEMP | Fuser center temperature (°C) | | | | | | | | | | |
| FIX EDGE TEMP | Fuser edge temperature (°C) | | | | | | | | | | |
| SURROUND TEMP | Ambient temperature (°C) | | | | | | | | | | |
| HUMIDITY | Absolute humidity (%) | | | | | | | | | | |
| U200 | <p>Turning all LEDs on</p> <p>Description Turns all the LEDs on the operation panel on.</p> <p>Purpose To check if all the LEDs on the operation panel light.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. All the LEDs on the operation panel light. 2. Press the stop/clear key. The LEDs turns off. <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p> | | | | | | | | | | |
| U201 | <p>Initializing the touch panel</p> <p>Description Automatically correct the positions of the X- and Y-axes of the touch panel.</p> <p>Purpose To automatically correct the display positions on the touch panel after it is replaced.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. The + key displayed at the upper left of the touch panel flashes. 2. Press on the center of the + key. The + key on lower right flashes. 3. Press the center of the flashing +. <p>Initialization of the touch panel is complete, and the screen for selecting a maintenance item No. is displayed.</p> <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p> | | | | | | | | | | |
| U202 | <p>Setting the KMAS host monitoring system</p> <p>Description Initializes or operates the KMAS host monitoring system. This is an optional device which is currently supported only by Japanese specification machines, so no setting is necessary.</p> | | | | | | | | | | |

| Maintenance item No. | Description | | | | | | | | | | | | | | | | | | | | |
|----------------------|--|----------------|-----------------|---------------|----------------------------|-------------|-----------------------------------|----------------|-----|------|-----------------------------------|----------------|-----|-------------|---|---|---|--------------|---|---|---|
| U203 | <p>Checking DP operation</p> <p>Description Simulates the original conveying operation separately in the optional DP.</p> <p>Purpose To check the DP operation.</p> <p>Method</p> <ol style="list-style-type: none">1. Press the start key.2. Place an original in the DP if running this simulation with paper.3. Select the item to be operated.4. When selecting [ADF] or [RADF], to set the magnification using the cursor up/down keys. <table><tr><th>Display</th><th>Operation</th><th>Setting range</th><th>Initial setting</th></tr><tr><td>ADF</td><td>With paper, single-sided original</td><td>100 to 200 (%)</td><td>100</td></tr><tr><td>RADF</td><td>With paper, double-sided original</td><td>100 to 200 (%)</td><td>100</td></tr><tr><td>ADF (NON P)</td><td>Without paper, single-sided original (continuous operation)</td><td>-</td><td>-</td></tr><tr><td>RADF (NON P)</td><td>Without paper, double-sided original (continuous operation)</td><td>-</td><td>-</td></tr></table> <ol style="list-style-type: none">5. Press the start key. The operation starts.6. To stop continuous operation, press the stop/clear key. <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p> | Display | Operation | Setting range | Initial setting | ADF | With paper, single-sided original | 100 to 200 (%) | 100 | RADF | With paper, double-sided original | 100 to 200 (%) | 100 | ADF (NON P) | Without paper, single-sided original (continuous operation) | - | - | RADF (NON P) | Without paper, double-sided original (continuous operation) | - | - |
| Display | Operation | Setting range | Initial setting | | | | | | | | | | | | | | | | | | |
| ADF | With paper, single-sided original | 100 to 200 (%) | 100 | | | | | | | | | | | | | | | | | | |
| RADF | With paper, double-sided original | 100 to 200 (%) | 100 | | | | | | | | | | | | | | | | | | |
| ADF (NON P) | Without paper, single-sided original (continuous operation) | - | - | | | | | | | | | | | | | | | | | | |
| RADF (NON P) | Without paper, double-sided original (continuous operation) | - | - | | | | | | | | | | | | | | | | | | |
| U204 | <p>Setting the presence or absence of a key card or key counter</p> <p>Description Sets the presence or absence of the optional key card or key counter.</p> <p>Purpose To run this maintenance item if a key card or key counter is installed.</p> <p>Setting</p> <ol style="list-style-type: none">1. Press the start key.2. Select the optional counter to be installed. <table><tr><th>Display</th><th>Description</th></tr><tr><td>KEY-CARD</td><td>The key card is installed.</td></tr><tr><td>KEY-COUNTER</td><td>The key counter is installed.</td></tr></table> <ol style="list-style-type: none">3. Press the start key. The setting is set and the screen for selecting a maintenance item No. is displayed.4. Turn the main power switch off and on. | Display | Description | KEY-CARD | The key card is installed. | KEY-COUNTER | The key counter is installed. | | | | | | | | | | | | | | |
| Display | Description | | | | | | | | | | | | | | | | | | | | |
| KEY-CARD | The key card is installed. | | | | | | | | | | | | | | | | | | | | |
| KEY-COUNTER | The key counter is installed. | | | | | | | | | | | | | | | | | | | | |

| Maintenance item No. | Description | | | | | | | | |
|----------------------|---|---------|-------------|--------|-----------------------|--------|---|--------|---|
| U206 | <p>Setting the presence or absence of the coin vender</p> <p>Description Sets the presence or absence of the optional coin vender. Also sets the details for coin vender operation, such as mode and unit price. This is an optional device which is currently supported only by Japanese specification machines, so no setting is necessary.</p> | | | | | | | | |
| U207 | <p>Checking the operation panel keys</p> <p>Description Checks operation of the operation panel keys.</p> <p>Purpose To check operation of all the keys and LEDs on the operation panel.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. The screen for executing is displayed. 2. COUNT0 is displayed and the leftmost LED on the operation panel lights. 3. As the keys lined up in the same line as the lit indicator are pressed in the order from the top to the bottom, the figure shown on the touch panel increases in increments of 1. When all the keys in that line are pressed and if there are any LEDs corresponding to the keys in the line on the immediate right, the top LED in that line will light. 4. When all the keys on the operation panel have been pressed, all the LEDs light for up to 10 seconds. <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p> | | | | | | | | |
| U233 | <p>Limiting job separator output</p> <p>Description Sets a limit of number of output pages from the optional job separator.</p> <p>Purpose Settings may be modified if curled paper is output from the job separator.</p> <p>Setting</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select the mode. <table border="1"> <thead> <tr> <th>Display</th><th>Description</th></tr> </thead> <tbody> <tr> <td>MODE 0</td><td>All sizes: 100 sheets</td></tr> <tr> <td>MODE 1</td><td>A3 and 11 x 17" sizes: 70, other sizes: 100</td></tr> <tr> <td>MODE 2</td><td>A3 and 11 x 17" sizes: 50, other sizes: 100</td></tr> </tbody> </table> <p>Initial setting: MODE0</p> <ol style="list-style-type: none"> 3. Press the start key. The setting is set. <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p> | Display | Description | MODE 0 | All sizes: 100 sheets | MODE 1 | A3 and 11 x 17" sizes: 70, other sizes: 100 | MODE 2 | A3 and 11 x 17" sizes: 50, other sizes: 100 |
| Display | Description | | | | | | | | |
| MODE 0 | All sizes: 100 sheets | | | | | | | | |
| MODE 1 | A3 and 11 x 17" sizes: 70, other sizes: 100 | | | | | | | | |
| MODE 2 | A3 and 11 x 17" sizes: 50, other sizes: 100 | | | | | | | | |

| Maintenance item No. | Description | | | | | | | | | | | | |
|----------------------|---|---------|----------------------|---------------|---|---------------|--|--------------|--|-----------|---|-----------|---|
| U236 | <p>Setting the limit for the ejection section of the built-in finisher</p> <p>Description If the machine is equipped with an optional built-in finisher, this mode sets whether A5R/B5R/5 1/2" x 8 1/2" size paper is output to the machine eject tray or not.</p> <p>Purpose If the machine is equipped with an optional built-in finisher and if paper jams occur due to curling of paper in the built-in ejection section when two-sided copying onto A5R/B5R/5 1/2" x 8 1/2" size paper is performed, this mode is used to change the setting to ON to disable ejection to the machine eject tray.</p> <p>Setting</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select ON or OFF. <table border="1"> <thead> <tr> <th>Display</th><th>Description</th></tr> </thead> <tbody> <tr> <td>ON</td><td>Does not eject to the machine eject tray.</td></tr> <tr> <td>OFF</td><td>Eject to the machine eject tray.</td></tr> </tbody> </table> <p>Initial setting: OFF</p> <ol style="list-style-type: none"> 3. Press the start key. The setting is set. <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p> | Display | Description | ON | Does not eject to the machine eject tray. | OFF | Eject to the machine eject tray. | | | | | | |
| Display | Description | | | | | | | | | | | | |
| ON | Does not eject to the machine eject tray. | | | | | | | | | | | | |
| OFF | Eject to the machine eject tray. | | | | | | | | | | | | |
| U243 | <p>Checking the operation of the DP motors</p> <p>Description Turns the motors and solenoids in the optional DP on.</p> <p>Purpose To check the operation of the DP motors or solenoids.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select the item to be operated. 3. Press the start key. The operation starts. <table border="1"> <thead> <tr> <th>Display</th><th>Motors and solenoids</th></tr> </thead> <tbody> <tr> <td>DP FEED MOTOR</td><td>Original feed motor (OFM) is turned on.</td></tr> <tr> <td>DP CONV MOTOR</td><td>Original conveying motor (OCM) is turned on.</td></tr> <tr> <td>DP REV MOTOR</td><td>Original switchback motor (OSBM) is turned on.</td></tr> <tr> <td>DP RJ SOL</td><td>Switchback feedshift solenoid (SBFSSOL) is turned on.</td></tr> <tr> <td>DP RP SOL</td><td>Switchback pressure solenoid (SBPSOL) is turned on.</td></tr> </tbody> </table> <ol style="list-style-type: none"> 4. To stop operation, press the stop/clear key. <p>Completion Press the stop/clear key when operation stops. The screen for selecting a maintenance item No. is displayed.</p> | Display | Motors and solenoids | DP FEED MOTOR | Original feed motor (OFM) is turned on. | DP CONV MOTOR | Original conveying motor (OCM) is turned on. | DP REV MOTOR | Original switchback motor (OSBM) is turned on. | DP RJ SOL | Switchback feedshift solenoid (SBFSSOL) is turned on. | DP RP SOL | Switchback pressure solenoid (SBPSOL) is turned on. |
| Display | Motors and solenoids | | | | | | | | | | | | |
| DP FEED MOTOR | Original feed motor (OFM) is turned on. | | | | | | | | | | | | |
| DP CONV MOTOR | Original conveying motor (OCM) is turned on. | | | | | | | | | | | | |
| DP REV MOTOR | Original switchback motor (OSBM) is turned on. | | | | | | | | | | | | |
| DP RJ SOL | Switchback feedshift solenoid (SBFSSOL) is turned on. | | | | | | | | | | | | |
| DP RP SOL | Switchback pressure solenoid (SBPSOL) is turned on. | | | | | | | | | | | | |

| Maintenance item No. | Description | | | | | | | | | | | | | | |
|-------------------------|---|---------|----------|-----------|----------------------------|-----------|-------------------------------------|-----------|------------------------------------|---------------|--------------------------|-------------|------------------------------|------------|-------------------------------|
| U244 | <p>Checking the DP switches</p> <p>Description Displays the status of the respective switches in the optional DP.</p> <p>Purpose To check if respective switches in the optional DP operate correctly.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Turn the respective switches on and off manually to check the status. <p>When a switch is detected to be in the ON position, the display for that switch will be highlighted.</p> <table border="1" data-bbox="335 533 1398 824"> <thead> <tr> <th>Display</th><th>Switches</th></tr> </thead> <tbody> <tr> <td>DP SET SW</td><td>Original set switch (OSSW)</td></tr> <tr> <td>DP PSD SW</td><td>Original size length switch (OSLSW)</td></tr> <tr> <td>DP REV SW</td><td>Original switchback switch (OSBSW)</td></tr> <tr> <td>CCD TIMING SW</td><td>DP timing switch (DPTSW)</td></tr> <tr> <td>DP COVER SW</td><td>DP interlock switch (DPILSW)</td></tr> <tr> <td>DP OPEN SW</td><td>DP open/close switch (DPOCSW)</td></tr> </tbody> </table> <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p> | Display | Switches | DP SET SW | Original set switch (OSSW) | DP PSD SW | Original size length switch (OSLSW) | DP REV SW | Original switchback switch (OSBSW) | CCD TIMING SW | DP timing switch (DPTSW) | DP COVER SW | DP interlock switch (DPILSW) | DP OPEN SW | DP open/close switch (DPOCSW) |
| Display | Switches | | | | | | | | | | | | | | |
| DP SET SW | Original set switch (OSSW) | | | | | | | | | | | | | | |
| DP PSD SW | Original size length switch (OSLSW) | | | | | | | | | | | | | | |
| DP REV SW | Original switchback switch (OSBSW) | | | | | | | | | | | | | | |
| CCD TIMING SW | DP timing switch (DPTSW) | | | | | | | | | | | | | | |
| DP COVER SW | DP interlock switch (DPILSW) | | | | | | | | | | | | | | |
| DP OPEN SW | DP open/close switch (DPOCSW) | | | | | | | | | | | | | | |
| U245 | <p>Checking messages</p> <p>Description Displays a list of messages on the touch panel of the operation panel.</p> <p>Purpose To check the messages to be displayed.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select the item to be displayed. 3. Displays the message one by one using cursor up/down keys. <p>When a message number is entered with the numeric keys and then the start key is pressed, the message corresponding the specified number is displayed.</p> <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p> | | | | | | | | | | | | | | |

| Maintenance item No. | Description | | | | | | | | | | | | | | | | | | | | |
|----------------------|--|---------------|--------------------|--------------------------|---------------------------------|--------------------------|---------------------------------------|--|--|----------|--|------|---|----------|---|----------|-----|---|----------|---|----------|
| U246 | <p>Setting the finisher</p> <p>Description Provides various settings for the built-in finisher, if furnished.</p> <p>Purpose Adjusts the side registration cursor stop position if paper registration is poor or stapling is made outside the specified area.</p> <p>Setting</p> <ol style="list-style-type: none">1. Press the start key.2. Press [FINISHER B-IN].3. Select the desired cursor position.4. Change the setting using the cursor up/down keys. <table><tr><th>Display</th><th>Description</th><th>Setting range</th><th>Initial setting</th><th>Change in value per step</th></tr><tr><td>FRONT</td><td>Front side registration cursor stop position</td><td>-4 to +4</td><td>0</td><td>0.566 mm</td></tr><tr><td>REAR</td><td>Rear side registration cursor stop position</td><td>-4 to +4</td><td>0</td><td>0.566 mm</td></tr><tr><td>END</td><td>Trailing edge registration cursor stop position</td><td>-4 to +4</td><td>0</td><td>0.566 mm</td></tr></table> <ol style="list-style-type: none">5. Press the start key. The value is set. <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p> | Display | Description | Setting range | Initial setting | Change in value per step | FRONT | Front side registration cursor stop position | -4 to +4 | 0 | 0.566 mm | REAR | Rear side registration cursor stop position | -4 to +4 | 0 | 0.566 mm | END | Trailing edge registration cursor stop position | -4 to +4 | 0 | 0.566 mm |
| Display | Description | Setting range | Initial setting | Change in value per step | | | | | | | | | | | | | | | | | |
| FRONT | Front side registration cursor stop position | -4 to +4 | 0 | 0.566 mm | | | | | | | | | | | | | | | | | |
| REAR | Rear side registration cursor stop position | -4 to +4 | 0 | 0.566 mm | | | | | | | | | | | | | | | | | |
| END | Trailing edge registration cursor stop position | -4 to +4 | 0 | 0.566 mm | | | | | | | | | | | | | | | | | |
| U247 | <p>Setting the paper feed device</p> <p>Description Turns on motor and clutches of optional paper feeder.</p> <p>Purpose To check the operation of motors and clutches of paper feeder.</p> <p>Method</p> <ol style="list-style-type: none">1. Press the start key.2. Select the item to be operated. <table><tr><th>Display</th><th>Motor and clutches</th></tr><tr><td>DESK FEED</td><td>Paper feeder drive motor (PFDM)</td></tr><tr><td>CLUTCH FEED</td><td>Paper feeder conveying clutch (PFCCL)</td></tr><tr><td>CLUTCH U</td><td>Paper feeder paper feed clutch 1 (PFPFCL1)</td></tr><tr><td>CLUTCH L</td><td>Paper feeder paper feed clutch 2 (PFPFCL2)</td></tr></table> <ol style="list-style-type: none">3. Press the start key. The operation starts.4. To stop operation, press the stop/clear key. <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p> | Display | Motor and clutches | DESK FEED | Paper feeder drive motor (PFDM) | CLUTCH FEED | Paper feeder conveying clutch (PFCCL) | CLUTCH U | Paper feeder paper feed clutch 1 (PFPFCL1) | CLUTCH L | Paper feeder paper feed clutch 2 (PFPFCL2) | | | | | | | | | | |
| Display | Motor and clutches | | | | | | | | | | | | | | | | | | | | |
| DESK FEED | Paper feeder drive motor (PFDM) | | | | | | | | | | | | | | | | | | | | |
| CLUTCH FEED | Paper feeder conveying clutch (PFCCL) | | | | | | | | | | | | | | | | | | | | |
| CLUTCH U | Paper feeder paper feed clutch 1 (PFPFCL1) | | | | | | | | | | | | | | | | | | | | |
| CLUTCH L | Paper feeder paper feed clutch 2 (PFPFCL2) | | | | | | | | | | | | | | | | | | | | |

| Maintenance item No. | Description | | | | | | |
|----------------------|--|-----------------|---------------|-----------------|-------------------|--------------|--------|
| U250 | <p>Setting the maintenance cycle</p> <p>Description Displays and changes the maintenance cycle.</p> <p>Purpose To check and change the maintenance cycle.</p> <p>Method Press the start key. The currently set maintenance cycle is displayed.</p> <p>Setting</p> <p>1. Change the setting using the numeric keys.</p> <table><tr><th>Description</th><th>Setting range</th><th>Initial setting</th></tr><tr><td>Maintenance cycle</td><td>0 to 9999999</td><td>300000</td></tr></table> <p>2. Press the start key. The value is set.</p> <p>Clearing</p> <p>1. Press the reset key.</p> <p>2. Press the start key. The count is cleared.</p> <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p> | Description | Setting range | Initial setting | Maintenance cycle | 0 to 9999999 | 300000 |
| Description | Setting range | Initial setting | | | | | |
| Maintenance cycle | 0 to 9999999 | 300000 | | | | | |
| U251 | <p>Checking/clearing the maintenance count</p> <p>Description Displays, clears and changes the maintenance count.</p> <p>Purpose To check the maintenance count. Also to clear the count during maintenance service.</p> <p>Method Press the start key. The maintenance count is displayed.</p> <p>Clearing</p> <p>1. Press the reset key.</p> <p>2. Press the start key. The count is cleared.</p> <p>Setting</p> <p>1. Enter a count using the numeric keys.</p> <p>2. Press the start key. The count is set.</p> <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p> | | | | | | |

TONER

www.tonerplus.com.ua

| Maintenance item No. | Description | | | | | | | | | | | | | | | | | | | | | | | |
|---------------------------|---|-------------|-------------|-----------------------------|-------------------------------------|-------------------------|--|------------------|--------------------------------------|---------------------------|--|-------|------|-----------------------------|-----|--|--------|--------|--------|-----|----------------------------|-------------|-------------|------|
| U252 | <p>Setting the destination</p> <p>Description Switches the operations and screens of the machine according to the destination.</p> <p>Purpose To be executed after initializing the backup RAM by running maintenance item U020, in order to return the setting to the value before replacement or initialization.</p> <p>Method Press the start key. The screen for selecting an item is displayed.</p> <p>Setting</p> <ol style="list-style-type: none">1. Press the start key.2. Select the destination. <table><tr><th>Display</th><th>Description</th></tr><tr><td>INCH</td><td>Inch (North America) specifications</td></tr><tr><td>EUROPE METRIC</td><td>Metric (Europe) specifications</td></tr><tr><td>ASIA PACIFIC</td><td>Metric (Asia Pacific) specifications</td></tr></table> <ol style="list-style-type: none">3. Press the start key. The setting is set.4. Turn the main power switch off and on. <p>Supplement The specified initial settings are provided according to the destinations in the maintenance items below. To change the initial settings in those items, be sure to run maintenance item U021 after changing the destination.</p> <p>Initial setting according to the destinations</p> <table><tr><th>Maintenance item No.</th><th>Title</th><th>Japan</th><th>Inch</th><th>Europe Metric, Asia Pacific</th></tr><tr><td>253</td><td>Switching between double and single counts</td><td>Single</td><td>Double</td><td>Double</td></tr><tr><td>344</td><td>Setting the low-power mode</td><td>ENERGY STAR</td><td>ENERGY STAR</td><td>GEEA</td></tr></table> | Display | Description | INCH | Inch (North America) specifications | EUROPE METRIC | Metric (Europe) specifications | ASIA PACIFIC | Metric (Asia Pacific) specifications | Maintenance item No. | Title | Japan | Inch | Europe Metric, Asia Pacific | 253 | Switching between double and single counts | Single | Double | Double | 344 | Setting the low-power mode | ENERGY STAR | ENERGY STAR | GEEA |
| Display | Description | | | | | | | | | | | | | | | | | | | | | | | |
| INCH | Inch (North America) specifications | | | | | | | | | | | | | | | | | | | | | | | |
| EUROPE METRIC | Metric (Europe) specifications | | | | | | | | | | | | | | | | | | | | | | | |
| ASIA PACIFIC | Metric (Asia Pacific) specifications | | | | | | | | | | | | | | | | | | | | | | | |
| Maintenance item No. | Title | Japan | Inch | Europe Metric, Asia Pacific | | | | | | | | | | | | | | | | | | | | |
| 253 | Switching between double and single counts | Single | Double | Double | | | | | | | | | | | | | | | | | | | | |
| 344 | Setting the low-power mode | ENERGY STAR | ENERGY STAR | GEEA | | | | | | | | | | | | | | | | | | | | |
| U253 | <p>Switching between double and single counts</p> <p>Description Switches the count system for the total counter and other counters.</p> <p>Purpose Used to select, according to the preference of the user (copy service provider), if A3/11" x 17" paper is to be counted as one sheet (single count) or two sheets (double count).</p> <p>Setting</p> <ol style="list-style-type: none">1. Press the start key.2. Select the count system. <table><tr><th>Display</th><th>Description</th></tr><tr><td>SINGLE COUNT</td><td>Single count for all size paper</td></tr><tr><td>DOUBLE COUNT(A3/LEDGER)</td><td>Double count for A3/11" x 17" size or larger</td></tr><tr><td>DOUBLE COUNT(B4)</td><td>Double count for B4 size or larger</td></tr><tr><td>DOUBLE COUNT(FOLIO/LEGAL)</td><td>Double count for Folio/8 1/2" x 14" size or larger</td></tr></table> <p>Initial setting: DOUBLE COUNT(A3/LEDGER)</p> <ol style="list-style-type: none">3. Press the start key. The setting is set. <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p> | Display | Description | SINGLE COUNT | Single count for all size paper | DOUBLE COUNT(A3/LEDGER) | Double count for A3/11" x 17" size or larger | DOUBLE COUNT(B4) | Double count for B4 size or larger | DOUBLE COUNT(FOLIO/LEGAL) | Double count for Folio/8 1/2" x 14" size or larger | | | | | | | | | | | | | |
| Display | Description | | | | | | | | | | | | | | | | | | | | | | | |
| SINGLE COUNT | Single count for all size paper | | | | | | | | | | | | | | | | | | | | | | | |
| DOUBLE COUNT(A3/LEDGER) | Double count for A3/11" x 17" size or larger | | | | | | | | | | | | | | | | | | | | | | | |
| DOUBLE COUNT(B4) | Double count for B4 size or larger | | | | | | | | | | | | | | | | | | | | | | | |
| DOUBLE COUNT(FOLIO/LEGAL) | Double count for Folio/8 1/2" x 14" size or larger | | | | | | | | | | | | | | | | | | | | | | | |

TONER

www.tonerplus.com.ua

| Maintenance item No. | Description | | | | | | |
|----------------------|---|---------|-------------|------|----------------------------------|-------|---------------------------|
| U254 | <p>Turning auto start function ON/OFF</p> <p>Description Selects if the auto start function is turned on.</p> <p>Purpose Normally no change is necessary. According to user request, changes the setting.</p> <p>Setting</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select ON or OFF. <table border="1"> <thead> <tr> <th>Display</th><th>Description</th></tr> </thead> <tbody> <tr> <td>ON</td><td>Auto start function on</td></tr> <tr> <td>OFF</td><td>Auto start function off</td></tr> </tbody> </table> <p>Initial setting: ON</p> <ol style="list-style-type: none"> 3. Press the start key. The setting is set. <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p> | Display | Description | ON | Auto start function on | OFF | Auto start function off |
| Display | Description | | | | | | |
| ON | Auto start function on | | | | | | |
| OFF | Auto start function off | | | | | | |
| U260 | <p>Selecting the timing for copy counting</p> <p>Description Changes the copy count timing for the total counter and other counters.</p> <p>Purpose To be set according to user (copy service provider) request. If a paper jam occurs frequently in the optional document finisher when the number of copies is counted at the time of paper ejection, copies are provided without copy counts. The copy service provider cannot charge for such copying. To prevent this, the copy timing should be made earlier. If a paper jam occurs frequently in the paper conveying or fuser sections when the number of copies is counted before the paper reaches those sections, copying is charged without a copy being made. To prevent this, the copy timing should be made later.</p> <p>Setting</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select the copy count timing. <table border="1"> <thead> <tr> <th>Display</th><th>Description</th></tr> </thead> <tbody> <tr> <td>FEED</td><td>When secondary paper feed starts</td></tr> <tr> <td>EJECT</td><td>When the paper is ejected</td></tr> </tbody> </table> <p>Initial setting: EJECT</p> <ol style="list-style-type: none"> 3. Press the start key. The setting is set. <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p> | Display | Description | FEED | When secondary paper feed starts | EJECT | When the paper is ejected |
| Display | Description | | | | | | |
| FEED | When secondary paper feed starts | | | | | | |
| EJECT | When the paper is ejected | | | | | | |
| U265 | <p>Setting OEM purchaser code</p> <p>Description Sets the OEM purchaser code.</p> <p>Purpose Sets the code when replacing the main PWB and the like.</p> <p>Setting</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Change the preset value using the cursor up/down keys. 3. Press the start key. The setting is set. <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p> | | | | | | |

| Maintenance item No. | Description | | | | | | | | |
|----------------------|---|-----------------|--|-------------|---------------|-----------------|---|---------------|---|
| U277 | <p>Setting auto application change time</p> <p>Description Sets the time that passes until the machine starts automatically printing after completing copying or operation when the machine is used as a printer.</p> <p>Purpose According to user request, changes the setting.</p> <p>Setting</p> <div><div>1. Press the start key.</div><div>2. Change the setting using the cursor up/down keys.</div></div> <table><tr><th>Description</th><th>Setting range</th><th>Default setting</th></tr><tr><td>Switching time</td><td>30 to 270 (s)</td><td>30 (s)</td></tr></table> <p>The setting can be changed by 30 s per step.</p> <div><div>3. Press the start key. The value is set.</div></div> <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p> | | | Description | Setting range | Default setting | Switching time | 30 to 270 (s) | 30 (s) |
| Description | Setting range | Default setting | | | | | | | |
| Switching time | 30 to 270 (s) | 30 (s) | | | | | | | |
| U285 | <p>Setting service status page</p> <p>Description Determines displaying the toner coverage report on reporting.</p> <p>Purpose According to user request, changes the setting.</p> <p>Setting</p> <div><div>1. Press the start key.</div><div>2. Select ON or OFF.</div></div> <table><tr><th>Display</th><th>Description</th></tr><tr><td>ON</td><td>Displays the toner coverage</td></tr><tr><td>OFF</td><td>Not to display the toner coverage</td></tr></table> <p>Initial setting: ON</p> <div><div>3. Press the start key. The setting is set.</div></div> <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p> | | | Display | Description | ON | Displays the toner coverage | OFF | Not to display the toner coverage |
| Display | Description | | | | | | | | |
| ON | Displays the toner coverage | | | | | | | | |
| OFF | Not to display the toner coverage | | | | | | | | |
| U324 | <p>Setting the main charger cleaning indication</p> <p>Description Sets whether to display the maincharger cleaning guidance.</p> <p>Purpose According to user request, changes the setting.</p> <p>Setting</p> <div><div>1. Press the start key.</div><div>2. Select ON or OFF.</div></div> <table><tr><th>Display</th><th>Description</th></tr><tr><td>ON</td><td>Displays the main charger cleaning guidance</td></tr><tr><td>OFF</td><td>Not to display the main charger cleaning guidance</td></tr></table> <p>Initial setting: ON</p> <div><div>3. Press the start key. The setting is set.</div><div>4. Turn the main power switch off and on.</div></div> | | | Display | Description | ON | Displays the main charger cleaning guidance | OFF | Not to display the main charger cleaning guidance |
| Display | Description | | | | | | | | |
| ON | Displays the main charger cleaning guidance | | | | | | | | |
| OFF | Not to display the main charger cleaning guidance | | | | | | | | |

TONER

www.tonerplus.com.ua

| Maintenance item No. | Description | | | | | | | | | | | | | | | | |
|----------------------|--|---------------|-----------------|---------------|--------------------------------|------|--------------------------------------|------------|--|-----|-----------------------------|------------|-----|-----|------------------------|------------|-----|
| U326 | <p>Setting the black line cleaning indication</p> <p>Description Sets whether to display the cleaning guidance when detecting the black line.</p> <p>Purpose Displays the cleaning guidance in order to make the call for service with the black line decrease by the rubbish on the platen when scanning from the DP.</p> <p>Setting</p> <ol style="list-style-type: none">1. Press the start key.2. Select ON or OFF. <table><tr><th>Display</th><th>Description</th></tr><tr><td>ON</td><td>Displays the cleaning guidance</td></tr><tr><td>OFF</td><td>Not to display the cleaning guidance</td></tr><tr><td>COUNT</td><td>Setting counts of the cleaning guidance indication</td></tr></table> <p>Initial setting: ON</p> <ol style="list-style-type: none">3. Press the start key. The setting is set. <p>Setting the count value</p> <ol style="list-style-type: none">1. Enter a count using the cursor up/down keys. Setting range: 0 to 999 Initial setting: 8 When setting is 0, the black line cleaning indication is displayed only if the black line is detected.2. Press the start key. The count is set. <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p> | Display | Description | ON | Displays the cleaning guidance | OFF | Not to display the cleaning guidance | COUNT | Setting counts of the cleaning guidance indication | | | | | | | | |
| Display | Description | | | | | | | | | | | | | | | | |
| ON | Displays the cleaning guidance | | | | | | | | | | | | | | | | |
| OFF | Not to display the cleaning guidance | | | | | | | | | | | | | | | | |
| COUNT | Setting counts of the cleaning guidance indication | | | | | | | | | | | | | | | | |
| U332 | <p>Setting the size conversion factor</p> <p>Description Sets the coefficient of nonstandard sizes in relation to the A4/11" x 8 1/2" size. The coefficient set here is used to convert the black ratio in relation to the A4/11" x 8 1/2" size and to display the result in user simulation.</p> <p>Purpose To set the coefficient for converting the black ratio for nonstandard sizes in relation to the A4/11" x 8 1/2" size for copying printing and fax respectively.</p> <p>Setting</p> <ol style="list-style-type: none">1. Press the start key.2. Select copying (COPY), printing (PRT) or fax (FAX).3. Change the setting using the cursor up/down keys. <table><tr><th>Display</th><th>Description</th><th>Setting range</th><th>Default setting</th></tr><tr><td>COPY</td><td>Size parameter for copying</td><td>0.1 to 3.0</td><td>1.0</td></tr><tr><td>PRT</td><td>Size parameter for printing</td><td>0.1 to 3.0</td><td>1.0</td></tr><tr><td>FAX</td><td>Size parameter for fax</td><td>0.1 to 3.0</td><td>1.0</td></tr></table> <ol style="list-style-type: none">4. Press the start key. The setting is set. <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p> | Display | Description | Setting range | Default setting | COPY | Size parameter for copying | 0.1 to 3.0 | 1.0 | PRT | Size parameter for printing | 0.1 to 3.0 | 1.0 | FAX | Size parameter for fax | 0.1 to 3.0 | 1.0 |
| Display | Description | Setting range | Default setting | | | | | | | | | | | | | | |
| COPY | Size parameter for copying | 0.1 to 3.0 | 1.0 | | | | | | | | | | | | | | |
| PRT | Size parameter for printing | 0.1 to 3.0 | 1.0 | | | | | | | | | | | | | | |
| FAX | Size parameter for fax | 0.1 to 3.0 | 1.0 | | | | | | | | | | | | | | |

TONER

www.tonerplus.com.ua

| Maintenance item No. | Description | | | | | | | | |
|----------------------|---|---------------|-----------------|---------------|-----------------|------|--------------------------------|---------|---|
| U339 | <p>Setting the drum heater ON/OFF</p> <p>Description Turns the drum heater on or off during sleep mode.</p> <p>Purpose Set according to the preference of the user.</p> <p>Setting</p> <ol style="list-style-type: none">1. Press the start key.2. Change the setting using the cursor up/down keys. <table><tr><th>Display</th><th>Description</th><th>Setting range</th><th>Initial setting</th></tr><tr><td>MODE</td><td>Setting the drum heater ON/OFF</td><td>0 to 4*</td><td>0</td></tr></table> <p>*: The drum heater is off at sleep mode when the value is 0. The drum heater is on at sleep mode when the value is between 1 and 4.</p> <ol style="list-style-type: none">3. Press the start key. The setting is set. <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p> | Display | Description | Setting range | Initial setting | MODE | Setting the drum heater ON/OFF | 0 to 4* | 0 |
| Display | Description | Setting range | Initial setting | | | | | | |
| MODE | Setting the drum heater ON/OFF | 0 to 4* | 0 | | | | | | |
| U341 | <p>Specific paper feed location setting for printing function</p> <p>Description Sets a paper feed location specified for printer output.</p> <p>Purpose To use a paper feed location only for printer output. A paper feed location specified for printer output cannot be used for copy output.</p> <p>Setting</p> <ol style="list-style-type: none">1. Press the start key.2. Select the paper feed location for the printer. Two or more cassette can be selected.3. Press the start key. The setting is set. <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p> | | | | | | | | |

TONER


www.tonerplus.com.ua

| Maintenance item No. | Description | | | | | | | | | | | | | | |
|---|---|---------|-------------|----|--|-----|---|-----------|------------------|---|-----|-------------------------------------|-----|---|-----|
| U342 | <p>Setting the ejection restriction</p> <p>Description Sets or cancels the restriction on the number of sheets to be ejected continuously when the internal eject tray is selected as the eject location.</p> <p>Purpose According to user request, sets or cancels restriction on the number of sheets.</p> <p>Setting</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select ON or OFF. <table border="1"> <thead> <tr> <th>Display</th><th>Description</th></tr> </thead> <tbody> <tr> <td>ON</td><td>Sets restriction on the number of sheets</td></tr> <tr> <td>OFF</td><td>Cancels restriction on the number of sheets</td></tr> </tbody> </table> <p>Initial setting: ON Details of restriction (number of sheets to be ejected continuously after the start key is pressed)</p> <table border="1"> <thead> <tr> <th>Condition</th><th>Number of sheets</th></tr> </thead> <tbody> <tr> <td>When no optional ejection device is installed</td><td>250</td></tr> <tr> <td>When the job separator is installed</td><td>150</td></tr> <tr> <td>When the built-in finisher is installed</td><td>100</td></tr> </tbody> </table> <ol style="list-style-type: none"> 3. Press the start key. The setting is set. <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p> | Display | Description | ON | Sets restriction on the number of sheets | OFF | Cancels restriction on the number of sheets | Condition | Number of sheets | When no optional ejection device is installed | 250 | When the job separator is installed | 150 | When the built-in finisher is installed | 100 |
| Display | Description | | | | | | | | | | | | | | |
| ON | Sets restriction on the number of sheets | | | | | | | | | | | | | | |
| OFF | Cancels restriction on the number of sheets | | | | | | | | | | | | | | |
| Condition | Number of sheets | | | | | | | | | | | | | | |
| When no optional ejection device is installed | 250 | | | | | | | | | | | | | | |
| When the job separator is installed | 150 | | | | | | | | | | | | | | |
| When the built-in finisher is installed | 100 | | | | | | | | | | | | | | |
| U343 | <p>Switching between duplex/simplex copy mode</p> <p>Description Switches the initial setting between duplex and simplex copy.</p> <p>Purpose To be set according to frequency of use: set to the more frequently used mode.</p> <p>Setting</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select ON or OFF. <table border="1"> <thead> <tr> <th>Display</th><th>Description</th></tr> </thead> <tbody> <tr> <td>ON</td><td>Duplex copy</td></tr> <tr> <td>OFF</td><td>Simplex copy</td></tr> </tbody> </table> <p>Initial setting: OFF</p> <ol style="list-style-type: none"> 3. Press the start key. The setting is set. <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p> | Display | Description | ON | Duplex copy | OFF | Simplex copy | | | | | | | | |
| Display | Description | | | | | | | | | | | | | | |
| ON | Duplex copy | | | | | | | | | | | | | | |
| OFF | Simplex copy | | | | | | | | | | | | | | |

| Maintenance item No. | Description | | | | | | |
|----------------------|--|---------|-------------|-------------|--|------|--|
| U344 | <p>Setting the low-power mode</p> <p>Description Changes the control for low-power mode.</p> <p>Purpose According to user request, selects which has priority, the recovery time from low-power or energy saver.</p> <p>Setting</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select control mode. <table border="1"> <thead> <tr> <th>Display</th><th>Description</th></tr> </thead> <tbody> <tr> <td>ENERGY STAR</td><td>The fuser control temperature is as low-power mode control temperature and forced stabilization is performed 30 seconds after exiting preheat.</td></tr> <tr> <td>GEEA</td><td>The fuser control temperature is as low-power mode control temperature and forced stabilization is performed 30 seconds after exiting preheat.</td></tr> </tbody> </table> <p>Initial setting: ENERGY STAR (120 V specifications)/GEEA (220-240 V specifications)</p> <ol style="list-style-type: none"> 3. Press the start key. The setting is set. <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p> | Display | Description | ENERGY STAR | The fuser control temperature is as low-power mode control temperature and forced stabilization is performed 30 seconds after exiting preheat. | GEEA | The fuser control temperature is as low-power mode control temperature and forced stabilization is performed 30 seconds after exiting preheat. |
| Display | Description | | | | | | |
| ENERGY STAR | The fuser control temperature is as low-power mode control temperature and forced stabilization is performed 30 seconds after exiting preheat. | | | | | | |
| GEEA | The fuser control temperature is as low-power mode control temperature and forced stabilization is performed 30 seconds after exiting preheat. | | | | | | |
| U345 | <p>Setting the value for maintenance due indication</p> <p>Description Sets when to display a message notifying that the time for maintenance is about to be reached, by setting the number of copies that can be made before the current maintenance cycle ends. When the difference between the number of copies of the maintenance cycle and that of the maintenance count reaches the set value, the message is displayed. This maintenance mode is effective for only Japanese specification.</p> | | | | | | |

| Maintenance item No. | Description | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|----------------------|--|---------------|-----------------|--------------------------|-----------------|--------------------------|------|-----------------------------|-----------|-----|--------|---|---------------------|--------------|-----|--------|---|----------------------|--------------|-----|--------|-------|------------------------------|--------------|-----|--------|------------|---|--------------|-----|--------|-----------|--|--------------|-----|--------|
| U402 | <p>Adjusting margins of image printing</p> <p>Description Adjusts margins for image printing.</p> <p>Purpose Make the adjustment if margins are incorrect.</p> <p>Adjustment</p> <div><div><div>1. Press the start key.</div><div>2. Select the item to be adjusted.</div></div><table><thead><tr><th>Display</th><th>Description</th><th>Setting range</th><th>Initial setting</th><th>Change in value per step</th></tr></thead><tbody><tr><td>LEAD</td><td>Printer leading edge margin</td><td>0 to 10.0</td><td>3.0</td><td>0.1 mm</td></tr><tr><td>A</td><td>Printer left margin</td><td>-3.4 to 10.0</td><td>3.0</td><td>0.1 mm</td></tr><tr><td>C</td><td>Printer right margin</td><td>-3.4 to 10.0</td><td>3.0</td><td>0.1 mm</td></tr><tr><td>TRAIL</td><td>Printer trailing edge margin</td><td>-5.0 to 10.0</td><td>4.0</td><td>0.1 mm</td></tr><tr><td>TRAIL(DUP)</td><td>Printer trailing edge margin in duplex mode (second side)</td><td>-5.0 to 10.0</td><td>6.5</td><td>0.1 mm</td></tr><tr><td>TRIAL(MP)</td><td>Printer trailing edge margin (MP tray)</td><td>-5.0 to 10.0</td><td>4.6</td><td>0.1 mm</td></tr></tbody></table><div><div><div>3. Press the interrupt key.</div><div>4. Press the start key to output a test pattern.</div><div>5. Press the interrupt key.</div><div>6. Change the setting value using the cursor up/down keys.</div></div><div>Increasing the value makes the margin wider, and decreasing it makes the margin narrower.</div></div><div><div><div>Printer leading edge margin (3.0±2.5 mm)</div><div>Printer left margin (2.0^{+2.0}_{-1.5} mm)</div><div>Printer right margin (2.0^{+2.0}_{-1.5} mm)</div><div>Printer trailing edge margin (3.0±2.5 mm)</div></div><div>Figure 1-3-16</div></div><div><div>7. Press the start key. The value is set.</div></div><p>Caution Check the copy image after the adjustment. If the image is still incorrect, perform the following adjustments in maintenance mode.</p><div><div>U402</div><div>→</div><div>U403 (P.1-3-56)</div><div>→</div><div>U404 (P.1-3-57)</div></div><p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p></div> | Display | Description | Setting range | Initial setting | Change in value per step | LEAD | Printer leading edge margin | 0 to 10.0 | 3.0 | 0.1 mm | A | Printer left margin | -3.4 to 10.0 | 3.0 | 0.1 mm | C | Printer right margin | -3.4 to 10.0 | 3.0 | 0.1 mm | TRAIL | Printer trailing edge margin | -5.0 to 10.0 | 4.0 | 0.1 mm | TRAIL(DUP) | Printer trailing edge margin in duplex mode (second side) | -5.0 to 10.0 | 6.5 | 0.1 mm | TRIAL(MP) | Printer trailing edge margin (MP tray) | -5.0 to 10.0 | 4.6 | 0.1 mm |
| Display | Description | Setting range | Initial setting | Change in value per step | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| LEAD | Printer leading edge margin | 0 to 10.0 | 3.0 | 0.1 mm | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| A | Printer left margin | -3.4 to 10.0 | 3.0 | 0.1 mm | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| C | Printer right margin | -3.4 to 10.0 | 3.0 | 0.1 mm | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| TRAIL | Printer trailing edge margin | -5.0 to 10.0 | 4.0 | 0.1 mm | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| TRAIL(DUP) | Printer trailing edge margin in duplex mode (second side) | -5.0 to 10.0 | 6.5 | 0.1 mm | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| TRIAL(MP) | Printer trailing edge margin (MP tray) | -5.0 to 10.0 | 4.6 | 0.1 mm | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |




| Maintenance item No. | Description | | | | | | | | | | | | | | | | | | | | | | | | | |
|----------------------|---|---------------|-----------------|--------------------------|-----------------|--------------------------|----------|---------------------|-----------|-----|--------|----------|-----------------------------|-----------|-----|--------|----------|----------------------|-----------|-----|--------|----------|------------------------------|-----------|-----|--------|
| U403 | <p>Adjusting margins for scanning an original on the platen</p> <p>Description Adjusts margins for scanning the original on the platen.</p> <p>Purpose Make the adjustment if margins are incorrect.</p> <p>Adjustment</p> <div><div><table><tr><th>Display</th><th>Description</th><th>Setting range</th><th>Initial setting</th><th>Change in value per step</th></tr><tr><td>A MARGIN</td><td>Scanner left margin</td><td>0 to 10.0</td><td>2.0</td><td>0.5 mm</td></tr><tr><td>B MARGIN</td><td>Scanner leading edge margin</td><td>0 to 10.0</td><td>2.0</td><td>0.5 mm</td></tr><tr><td>C MARGIN</td><td>Scanner right margin</td><td>0 to 10.0</td><td>2.0</td><td>0.5 mm</td></tr><tr><td>D MARGIN</td><td>Scanner trailing edge margin</td><td>0 to 10.0</td><td>2.0</td><td>0.5 mm</td></tr></table></div><div><div><div><div>Scanner leading edge margin (3±1.5 mm)</div><div>Scanner left margin (2±1.0 mm)</div><div>Scanner right margin (2±1.0 mm)</div><div>Scanner trailing edge margin (2±1.0 mm)</div></div><div></div></div></div><p>3. Press the interrupt key.</p><p>4. Place an original and press the start key to make a test copy.</p><p>5. Press the interrupt key.</p><p>6. Change the setting value using the cursor up/down keys. Increasing the value makes the margin wider, and decreasing it makes the margin narrower.</p><p>7. Press the start key. The value is set.</p><p>Caution Check the copy image after the adjustment. If the image is still incorrect, perform the following adjustments in maintenance mode.</p><div><div>U403</div><div>→</div><div>U404 (P.1-3-57)</div></div><p>Completion Press the stop/clear key. The indication for selecting a maintenance item No. appears.</p></div> | Display | Description | Setting range | Initial setting | Change in value per step | A MARGIN | Scanner left margin | 0 to 10.0 | 2.0 | 0.5 mm | B MARGIN | Scanner leading edge margin | 0 to 10.0 | 2.0 | 0.5 mm | C MARGIN | Scanner right margin | 0 to 10.0 | 2.0 | 0.5 mm | D MARGIN | Scanner trailing edge margin | 0 to 10.0 | 2.0 | 0.5 mm |
| Display | Description | Setting range | Initial setting | Change in value per step | | | | | | | | | | | | | | | | | | | | | | |
| A MARGIN | Scanner left margin | 0 to 10.0 | 2.0 | 0.5 mm | | | | | | | | | | | | | | | | | | | | | | |
| B MARGIN | Scanner leading edge margin | 0 to 10.0 | 2.0 | 0.5 mm | | | | | | | | | | | | | | | | | | | | | | |
| C MARGIN | Scanner right margin | 0 to 10.0 | 2.0 | 0.5 mm | | | | | | | | | | | | | | | | | | | | | | |
| D MARGIN | Scanner trailing edge margin | 0 to 10.0 | 2.0 | 0.5 mm | | | | | | | | | | | | | | | | | | | | | | |

| Maintenance item No. | Description | | | | | | | | | | | | | | | | | | | | | | | | | |
|----------------------|---|---------------|-----------------|--------------------------|-----------------|--------------------------|----------|-------------|-----------|-----|--------|----------|---------------------|-----------|-----|--------|----------|--------------|-----------|-----|--------|----------|----------------------|-----------|-----|--------|
| U404 | <p>Adjusting margins for scanning an original from the DP</p> <p>Description Adjusts margins for scanning the original from the DP.</p> <p>Purpose Make the adjustment if margins are incorrect when the optional DP is used.</p> <p>Caution Before making this adjustment, ensure that the following adjustments have been made in maintenance mode.</p> <div><div>U402 (P.1-3-55)</div>→<div>U403 (P.1-3-56)</div>→<div>U404</div></div> <p>Adjustment</p> <ol style="list-style-type: none">Press the start key.Select the item to be adjusted. <table><tr><th>Display</th><th>Description</th><th>Setting range</th><th>Initial setting</th><th>Change in value per step</th></tr><tr><td>A MARGIN</td><td>Left margin</td><td>0 to 10.0</td><td>3.0</td><td>0.5 mm</td></tr><tr><td>B MARGIN</td><td>Leading edge margin</td><td>0 to 10.0</td><td>2.5</td><td>0.5 mm</td></tr><tr><td>C MARGIN</td><td>Right margin</td><td>0 to 10.0</td><td>3.0</td><td>0.5 mm</td></tr><tr><td>D MARGIN</td><td>Trailing edge margin</td><td>0 to 10.0</td><td>4.0</td><td>0.5 mm</td></tr></table> <ol style="list-style-type: none">Press the interrupt key.Place an original on the DP and press the start key to make a test copy.Press the interrupt key.Change the setting value using the cursor up/down keys. Increasing the value makes the margin wider, and decreasing it makes the margin narrower. <div><p>Leading edge margin (3±1.5 mm)</p><p>Left margin (2±1.0 mm)</p><p>Right margin (2±1.0 mm)</p><p>Trailing edge margin (2±1.0 mm)</p></div> <p>Figure 1-3-18</p> <ol style="list-style-type: none">Press the start key. The value is set. <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p> | Display | Description | Setting range | Initial setting | Change in value per step | A MARGIN | Left margin | 0 to 10.0 | 3.0 | 0.5 mm | B MARGIN | Leading edge margin | 0 to 10.0 | 2.5 | 0.5 mm | C MARGIN | Right margin | 0 to 10.0 | 3.0 | 0.5 mm | D MARGIN | Trailing edge margin | 0 to 10.0 | 4.0 | 0.5 mm |
| Display | Description | Setting range | Initial setting | Change in value per step | | | | | | | | | | | | | | | | | | | | | | |
| A MARGIN | Left margin | 0 to 10.0 | 3.0 | 0.5 mm | | | | | | | | | | | | | | | | | | | | | | |
| B MARGIN | Leading edge margin | 0 to 10.0 | 2.5 | 0.5 mm | | | | | | | | | | | | | | | | | | | | | | |
| C MARGIN | Right margin | 0 to 10.0 | 3.0 | 0.5 mm | | | | | | | | | | | | | | | | | | | | | | |
| D MARGIN | Trailing edge margin | 0 to 10.0 | 4.0 | 0.5 mm | | | | | | | | | | | | | | | | | | | | | | |

| Maintenance item No. | Description | | | | | | | | |
|---|---|-----------------|--------------------------|-----------------|--------------------------|---|-----------|---|--------|
| U407 | <p>Adjusting the leading edge registration for memory image printing</p> <p>Description Adjusts the leading edge registration during memory copying.</p> <p>Purpose Make the following adjustment if there is a regular error between the leading edge of the copy image on the front face and that on the reverse face during duplex switchback copying.</p> <p>Caution Before making this adjustment, ensure that the following adjustments have been made in maintenance mode.</p> <div><div>U034 (P.1-3-12)</div>→<div>U402 (P.1-3-55)</div>→<div>U066 (P.1-3-19)</div>→<div>U403 (P.1-3-56)</div>→<div>U071 (P.1-3-23)</div>→</div> <div><div>U404 (P.1-3-57)</div>→<div>U407</div></div> <p>Adjustment</p> <div><div>1. Press the start key.</div><table><tr><th>Description</th><th>Setting range</th><th>Initial setting</th><th>Change in value per step</th></tr><tr><td>Leading edge registration for memory image printing</td><td>-20 to 20</td><td>0</td><td>0.1 mm</td></tr></table><div><div>2. Press the interrupt key.</div><div>3. Place an original and press the start key to make a test copy.</div><div>4. Press the interrupt key.</div><div>5. Change the setting value using the cursor up/down keys. For copy example 1, decrease the value. For copy example 2, increase the value.</div></div><div><div><div>↑</div><div>Original</div></div><div><div>↑</div><div>Copy example 1</div></div><div><div>↑</div><div>Copy example 2</div></div></div><p>Figure 1-3-19</p><div><div>6. Press the start key. The value is set.</div><p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p></div></div> | Description | Setting range | Initial setting | Change in value per step | Leading edge registration for memory image printing | -20 to 20 | 0 | 0.1 mm |
| Description | Setting range | Initial setting | Change in value per step | | | | | | |
| Leading edge registration for memory image printing | -20 to 20 | 0 | 0.1 mm | | | | | | |

TONER

www.tonerplus.com.ua

| Maintenance item No. | Description | | | | | | | | | | | | | | | | | |
|----------------------|--|--|-------------|--|---------|---|------------|----|---|----------|---------|-------------|-----|--|-------|--|-------|--|
| U411 | <p>Adjusting the scanner automatically</p> <p>Description Uses a specified original and automatically adjusts the following items in the scanner and the DP scanning sections.</p> <p>Purpose To perform automatic adjustment of various items in the scanner and the DP scanning sections. To adjust scanner automatically when initializing the machine using the maintenance item U020 or U022.</p> <p>Method</p> <ol style="list-style-type: none">Press the start key.Select the item. The screen for executing is displayed. <table><tr><th>Display</th><th>Description</th><th>Original to be used for adjustment (P/N)</th></tr><tr><td>SCANNER</td><td>Automatic adjustment in the scanner section</td><td>302FZ56990</td></tr><tr><td>DP</td><td>Automatic adjustment in the DP scanning section</td><td>2AC68241</td></tr></table> <p>Method: SCANNER</p> <ol style="list-style-type: none">Select [SCANNER].Set a specified original (P/N: 302FZ56990) on the platen.Select the item. <table><tr><th>Display</th><th>Description</th></tr><tr><td>ALL</td><td>Automatic adjustment using the platen for: original size magnification/leading edge timing/center line and input gamma</td></tr><tr><td>INPUT</td><td>Automatic adjustment using the platen for: original size magnification/leading edge timing/center line</td></tr><tr><td>GAMMA</td><td>Automatic adjustment using the platen for: input gamma</td></tr></table> <ol style="list-style-type: none">Press the start key. Auto adjustment starts. When automatic adjustment has normally completed, [RESULT OK 00] is displayed. If a problem occurs during auto adjustment, [ERROR XX] (XX is replaced by an error code) is displayed and operation stops. Should this happen, determine the details of the problem and either repeat the procedure from the beginning, or adjust the remaining items manually by running the corresponding maintenance items.To return to the screen for selecting an item, press the stop/clear key. <p>Method: DP</p> <ol style="list-style-type: none">Select [DP].Set a specified original (P/N: 2AC68241) in the DP. Cut the trailing edge of the original. <div><p>128±1 mm 60±1 mm</p><p>Cut with the edge of black belt.</p></div> | Display | Description | Original to be used for adjustment (P/N) | SCANNER | Automatic adjustment in the scanner section | 302FZ56990 | DP | Automatic adjustment in the DP scanning section | 2AC68241 | Display | Description | ALL | Automatic adjustment using the platen for: original size magnification/leading edge timing/center line and input gamma | INPUT | Automatic adjustment using the platen for: original size magnification/leading edge timing/center line | GAMMA | Automatic adjustment using the platen for: input gamma |
| Display | Description | Original to be used for adjustment (P/N) | | | | | | | | | | | | | | | | |
| SCANNER | Automatic adjustment in the scanner section | 302FZ56990 | | | | | | | | | | | | | | | | |
| DP | Automatic adjustment in the DP scanning section | 2AC68241 | | | | | | | | | | | | | | | | |
| Display | Description | | | | | | | | | | | | | | | | | |
| ALL | Automatic adjustment using the platen for: original size magnification/leading edge timing/center line and input gamma | | | | | | | | | | | | | | | | | |
| INPUT | Automatic adjustment using the platen for: original size magnification/leading edge timing/center line | | | | | | | | | | | | | | | | | |
| GAMMA | Automatic adjustment using the platen for: input gamma | | | | | | | | | | | | | | | | | |

TONER

www.tonerplus.com.ua

Figure 1-3-20

Figure 1-3-20

| Maintenance item No. | Description | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|----------------------|---|---------|-------------|-------|--|-------|-------------|----------|--|----------|--|----------|--|----------|--|----------|--|----------|--|----------|---|----------|---|----------|--|----------|---|----------|--|----------|--|----------|--|----------|--------------|----------|--|----------|---|----------|--|----------|---|----------|---------------------------|----------|---|----------|--|----------|---|----------|----------------|----------|--------------------|----------|-----------------|----------|---------------|----------|--------------------------|----------|-------------|----------|-------------------|
| U411 | <p>3. Press [INPUT].</p> <table border="1"> <tr> <th>Display</th><th>Description</th></tr> <tr> <td>INPUT</td><td>Automatic adjustment of first page using the DP for: original size magnification/leading edge timing/center line</td></tr> </table> <p>4. Press the start key. Auto adjustment starts. When automatic adjustment has normally completed, [RESULT OK 00] is displayed. If a problem occurs during auto adjustment, [ERROR XX] (XX is replaced by an error code) is displayed and operation stops. Should this happen, determine the details of the problem and either repeat the procedure from the beginning, or adjust the remaining items manually by running the corresponding maintenance items.</p> <p>5. To return to the screen for selecting an item, press the stop/clear key.</p> <p>Error Codes</p> <table border="1"> <tr> <th>Codes</th><th>Description</th></tr> <tr><td>ERROR 01</td><td>Black band detection error (scanner leading edge registration)</td></tr> <tr><td>ERROR 02</td><td>Black band detection error (scanner center line)</td></tr> <tr><td>ERROR 03</td><td>Black band detection error (scanner main scanning direction magnification)</td></tr> <tr><td>ERROR 04</td><td>Black band is not detected (scanner leading edge registration)</td></tr> <tr><td>ERROR 05</td><td>Black band is not detected (scanner center line)</td></tr> <tr><td>ERROR 06</td><td>Black band is not detected (scanner main scanning direction magnification)</td></tr> <tr><td>ERROR 07</td><td>Black band is not detected (scanner auxiliary scanning direction magnification)</td></tr> <tr><td>ERROR 08</td><td>Black band is not detected (DP main scanning direction magnification far end)</td></tr> <tr><td>ERROR 09</td><td>Black band is not detected (DP main scanning direction magnification near end)</td></tr> <tr><td>ERROR 0a</td><td>Black band is not detected (DP auxiliary scanning direction magnification leading edge)</td></tr> <tr><td>ERROR 0b</td><td>Black band is not detected (DP auxiliary scanning direction magnification leading edge original check)</td></tr> <tr><td>ERROR 0c</td><td>Black band is not detected (DP auxiliary scanning direction trailing edge)</td></tr> <tr><td>ERROR 0d</td><td>Black band is not detected (DP auxiliary scanning direction trailing edge 2)</td></tr> <tr><td>ERROR 0e</td><td>DMA time out</td></tr> <tr><td>ERROR 0f</td><td>Auxiliary scanning direction magnification error</td></tr> <tr><td>ERROR 10</td><td>Auxiliary scanning direction leading edge detection error</td></tr> <tr><td>ERROR 11</td><td>Auxiliary scanning direction trailing edge detection error</td></tr> <tr><td>ERROR 12</td><td>Auxiliary scanning direction skew 1.5 error</td></tr> <tr><td>ERROR 13</td><td>Maintenance request error</td></tr> <tr><td>ERROR 14</td><td>Main scanning direction center line error</td></tr> <tr><td>ERROR 15</td><td>Main scanning direction skew 1.5 error</td></tr> <tr><td>ERROR 16</td><td>Main scanning direction magnification error</td></tr> <tr><td>ERROR 17</td><td>Carriage error</td></tr> <tr><td>ERROR 18</td><td>Service call error</td></tr> <tr><td>ERROR 19</td><td>DP status error</td></tr> <tr><td>ERROR 1a</td><td>DP open error</td></tr> <tr><td>ERROR 1b</td><td>Original is not detected</td></tr> <tr><td>ERROR ff</td><td>Other error</td></tr> <tr><td>ERROR 65</td><td>Memory over error</td></tr> </table> <p>Completion Press the stop/clear key. The screen for selecting a maintenance item is displayed.</p> | Display | Description | INPUT | Automatic adjustment of first page using the DP for: original size magnification/leading edge timing/center line | Codes | Description | ERROR 01 | Black band detection error (scanner leading edge registration) | ERROR 02 | Black band detection error (scanner center line) | ERROR 03 | Black band detection error (scanner main scanning direction magnification) | ERROR 04 | Black band is not detected (scanner leading edge registration) | ERROR 05 | Black band is not detected (scanner center line) | ERROR 06 | Black band is not detected (scanner main scanning direction magnification) | ERROR 07 | Black band is not detected (scanner auxiliary scanning direction magnification) | ERROR 08 | Black band is not detected (DP main scanning direction magnification far end) | ERROR 09 | Black band is not detected (DP main scanning direction magnification near end) | ERROR 0a | Black band is not detected (DP auxiliary scanning direction magnification leading edge) | ERROR 0b | Black band is not detected (DP auxiliary scanning direction magnification leading edge original check) | ERROR 0c | Black band is not detected (DP auxiliary scanning direction trailing edge) | ERROR 0d | Black band is not detected (DP auxiliary scanning direction trailing edge 2) | ERROR 0e | DMA time out | ERROR 0f | Auxiliary scanning direction magnification error | ERROR 10 | Auxiliary scanning direction leading edge detection error | ERROR 11 | Auxiliary scanning direction trailing edge detection error | ERROR 12 | Auxiliary scanning direction skew 1.5 error | ERROR 13 | Maintenance request error | ERROR 14 | Main scanning direction center line error | ERROR 15 | Main scanning direction skew 1.5 error | ERROR 16 | Main scanning direction magnification error | ERROR 17 | Carriage error | ERROR 18 | Service call error | ERROR 19 | DP status error | ERROR 1a | DP open error | ERROR 1b | Original is not detected | ERROR ff | Other error | ERROR 65 | Memory over error |
| Display | Description | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| INPUT | Automatic adjustment of first page using the DP for: original size magnification/leading edge timing/center line | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Codes | Description | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ERROR 01 | Black band detection error (scanner leading edge registration) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ERROR 02 | Black band detection error (scanner center line) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ERROR 03 | Black band detection error (scanner main scanning direction magnification) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ERROR 04 | Black band is not detected (scanner leading edge registration) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ERROR 05 | Black band is not detected (scanner center line) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ERROR 06 | Black band is not detected (scanner main scanning direction magnification) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ERROR 07 | Black band is not detected (scanner auxiliary scanning direction magnification) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ERROR 08 | Black band is not detected (DP main scanning direction magnification far end) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ERROR 09 | Black band is not detected (DP main scanning direction magnification near end) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ERROR 0a | Black band is not detected (DP auxiliary scanning direction magnification leading edge) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ERROR 0b | Black band is not detected (DP auxiliary scanning direction magnification leading edge original check) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ERROR 0c | Black band is not detected (DP auxiliary scanning direction trailing edge) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ERROR 0d | Black band is not detected (DP auxiliary scanning direction trailing edge 2) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ERROR 0e | DMA time out | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ERROR 0f | Auxiliary scanning direction magnification error | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ERROR 10 | Auxiliary scanning direction leading edge detection error | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ERROR 11 | Auxiliary scanning direction trailing edge detection error | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ERROR 12 | Auxiliary scanning direction skew 1.5 error | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ERROR 13 | Maintenance request error | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ERROR 14 | Main scanning direction center line error | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ERROR 15 | Main scanning direction skew 1.5 error | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ERROR 16 | Main scanning direction magnification error | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ERROR 17 | Carriage error | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ERROR 18 | Service call error | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ERROR 19 | DP status error | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ERROR 1a | DP open error | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ERROR 1b | Original is not detected | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ERROR ff | Other error | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ERROR 65 | Memory over error | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |

| Maintenance item No. | Description | | | | | | | | | | | | | | |
|----------------------|---|---------|----------------------|--------|--------------------------------|-------------|-------------------------------|------------|------------|------------|---------------------|------------|---------------------|--------|----------------|
| U901 | <p>Checking copy counts by paper feed locations</p> <p>Description Displays copy counts by paper feed locations.</p> <p>Purpose To check the time to replace consumable parts.</p> <p>Method Press the start key. The counts by paper feed locations are displayed.</p> <table border="1"> <thead> <tr> <th>Display</th><th>Paper feed locations</th></tr> </thead> <tbody> <tr> <td>BYPASS</td><td>MP tray</td></tr> <tr> <td>CASSETTE 1</td><td>Cassette 1</td></tr> <tr> <td>CASSETTE 2</td><td>Cassette 2</td></tr> <tr> <td>CASSETTE 3</td><td>Optional cassette 3</td></tr> <tr> <td>CASSETTE 4</td><td>Optional cassette 4</td></tr> <tr> <td>DUPLEX</td><td>Duplex section</td></tr> </tbody> </table> <p>When an optional paper feed device is not installed, the corresponding count is not displayed.</p> <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p> | Display | Paper feed locations | BYPASS | MP tray | CASSETTE 1 | Cassette 1 | CASSETTE 2 | Cassette 2 | CASSETTE 3 | Optional cassette 3 | CASSETTE 4 | Optional cassette 4 | DUPLEX | Duplex section |
| Display | Paper feed locations | | | | | | | | | | | | | | |
| BYPASS | MP tray | | | | | | | | | | | | | | |
| CASSETTE 1 | Cassette 1 | | | | | | | | | | | | | | |
| CASSETTE 2 | Cassette 2 | | | | | | | | | | | | | | |
| CASSETTE 3 | Optional cassette 3 | | | | | | | | | | | | | | |
| CASSETTE 4 | Optional cassette 4 | | | | | | | | | | | | | | |
| DUPLEX | Duplex section | | | | | | | | | | | | | | |
| U903 | <p>Checking/clearing the paper jam counts</p> <p>Description Displays or clears the jam counts by jam locations.</p> <p>Purpose To check the paper jam status. Also to clear the jam counts after replacing consumable parts.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select the item. The screen for executing is displayed. <table border="1"> <thead> <tr> <th>Display</th><th>Description</th></tr> </thead> <tbody> <tr> <td>COUNT</td><td>Displays/clears the jam counts</td></tr> <tr> <td>TOTAL COUNT</td><td>Displays the total jam counts</td></tr> </tbody> </table> <p>Method: Displays/clears the jam counts</p> <ol style="list-style-type: none"> 1. Select [COUNT]. The count for jam detection by type is displayed. 2. Change the screen using the * or # keys. 3. Select the counts for all jam codes and press the reset key. 4. Press the start key. The count is cleared. The individual counter cannot be cleared. 5. To return to the screen for selecting an item, press the stop/clear key. <p>Method: Displays the total jam counts</p> <ol style="list-style-type: none"> 1. Select [TOTAL COUNT]. The total number of jam counts by type is displayed. 2. Change the screen using the * or # keys. The total number of jam count cannot be cleared. 3. To return to the screen for selecting an item, press the stop/clear key. <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p> | Display | Description | COUNT | Displays/clears the jam counts | TOTAL COUNT | Displays the total jam counts | | | | | | | | |
| Display | Description | | | | | | | | | | | | | | |
| COUNT | Displays/clears the jam counts | | | | | | | | | | | | | | |
| TOTAL COUNT | Displays the total jam counts | | | | | | | | | | | | | | |

| Maintenance item No. | Description | | | | | | | | | | | | | | | | | | |
|----------------------|---|---------|-------------|-------|---|-------------|--|---------|-------------|-----|--|------|--|---------|-------------|--------|-------------------------------|--------|--|
| U904 | <p>Checking/clearing the service call counts</p> <p>Description Displays or clears the service call code counts by types.</p> <p>Purpose To check the service call code status by types. Also to clear the service call code counts after replacing consumable parts.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select the item. The screen for executing is displayed. <table border="1"> <thead> <tr> <th>Display</th><th>Description</th></tr> </thead> <tbody> <tr> <td>COUNT</td><td>Displays/clears the service call counts</td></tr> <tr> <td>TOTAL COUNT</td><td>Displays the total service call counts</td></tr> </tbody> </table> <p>Method: Displays/clears the service call counts</p> <ol style="list-style-type: none"> 1. Select [COUNT]. The count for service call detection by type is displayed. 2. Change the screen using the * or # keys. 3. Select the counts for all service call codes and press the reset key. 4. Press the start key. The count is cleared. The individual counter cannot be cleared. 5. To return to the screen for selecting an item, press the stop/clear key. <p>Method: Displays the total service call counts</p> <ol style="list-style-type: none"> 1. Select [TOTAL COUNT]. The total number of service call counts by type is displayed. 2. Change the screen using the * or # keys. The total number of service call count cannot be cleared. 3. To return to the screen for selecting an item, press the stop/clear key. <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p> | Display | Description | COUNT | Displays/clears the service call counts | TOTAL COUNT | Displays the total service call counts | | | | | | | | | | | | |
| Display | Description | | | | | | | | | | | | | | | | | | |
| COUNT | Displays/clears the service call counts | | | | | | | | | | | | | | | | | | |
| TOTAL COUNT | Displays the total service call counts | | | | | | | | | | | | | | | | | | |
| U905 | <p>Checking counts by optional devices</p> <p>Description Displays the counts of optional DP or finisher.</p> <p>Purpose To check the use of optional DP and finisher.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select the device, the count of which is to be checked. The count of the selected device is displayed. <table border="1"> <thead> <tr> <th>Display</th><th>Description</th></tr> </thead> <tbody> <tr> <td>DP</td><td>Counts of optional DP</td></tr> <tr> <td>FINISHER</td><td>Counts of optional finisher</td></tr> </tbody> </table> <p>DP</p> <table border="1"> <thead> <tr> <th>Display</th><th>Description</th></tr> </thead> <tbody> <tr> <td>ADP</td><td>No. of single-sided originals that has passed through the DP</td></tr> <tr> <td>RADP</td><td>No. of double-sided originals that has passed through the DP</td></tr> </tbody> </table> <p>Finisher</p> <table border="1"> <thead> <tr> <th>Display</th><th>Description</th></tr> </thead> <tbody> <tr> <td>CP CNT</td><td>No. of copies that has passed</td></tr> <tr> <td>STAPLE</td><td>Frequency the stapler has been activated</td></tr> </tbody> </table> <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p> | Display | Description | DP | Counts of optional DP | FINISHER | Counts of optional finisher | Display | Description | ADP | No. of single-sided originals that has passed through the DP | RADP | No. of double-sided originals that has passed through the DP | Display | Description | CP CNT | No. of copies that has passed | STAPLE | Frequency the stapler has been activated |
| Display | Description | | | | | | | | | | | | | | | | | | |
| DP | Counts of optional DP | | | | | | | | | | | | | | | | | | |
| FINISHER | Counts of optional finisher | | | | | | | | | | | | | | | | | | |
| Display | Description | | | | | | | | | | | | | | | | | | |
| ADP | No. of single-sided originals that has passed through the DP | | | | | | | | | | | | | | | | | | |
| RADP | No. of double-sided originals that has passed through the DP | | | | | | | | | | | | | | | | | | |
| Display | Description | | | | | | | | | | | | | | | | | | |
| CP CNT | No. of copies that has passed | | | | | | | | | | | | | | | | | | |
| STAPLE | Frequency the stapler has been activated | | | | | | | | | | | | | | | | | | |

| Maintenance item No. | Description |
|-------------------------|---|
| U906 | <p>Resetting partial operation control</p> <p>Description Resets the service call code for partial operation control.</p> <p>Purpose To be reset after partial operation is performed due to problems in the cassettes or other sections, and the related parts are serviced.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Press [EXECUTE] on the touch panel. 3. Press the start key to reset partial operation control. 4. Turn the main power switch off and on. |
| U908 | <p>Checking the total counter value</p> <p>Description Displays the total counter value.</p> <p>Purpose To check the total counter value.</p> <p>Method Press the start key. The screen for total count value is displayed.</p> <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p> |
| U910 | <p>Clearing the black ratio data</p> <p>Description Clears the accumulated black ratio data for A4 sheet.</p> <p>Purpose To clear data as required at times such as during maintenance service.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Press [EXECUTE] on the touch panel. 3. Press the start key. The accumulated black ratio data is cleared. <p>When clearing is complete, the machine automatically returns to the same status as when the main power switch is turned on.</p> |
| U911 | <p>Checking/clearing copy counts by paper sizes</p> <p>Description Displays and clears the paper feed counts by paper sizes.</p> <p>Purpose To check or clear the counts after replacing consumable parts.</p> <p>Method Press the start key. The screen for the paper feed counts by paper size is displayed.</p> <p>Clearing</p> <ol style="list-style-type: none"> 1. Select the paper size. To clear all counts, press the reset key. 2. Press the start key. The count is cleared. <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p> |

| Maintenance item No. | Description | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|----------------------------|--|---------|-------------|-------------------------|--|-------------------------|--|----------------------------|---|----------------------------|---|------|-------------|------|--|------|---|------|----------------------|------|---------------------------------------|------|-----------|------|-------------|------|---------------------|------|--------------------------|------|------------------------------|------|----------------|------|-----------------|------|-------------------------------------|
| U917 | <p>Setting backup data reading/writing</p> <p>Description Stores backup data from the fax control PWB (when an optional fax kit is installed) into CompactFlash or reads the data from CompactFlash.</p> <p>Purpose To store and write data when replacing the PWB.</p> <p>Setting</p> <ol style="list-style-type: none"> 1. Press the power key on the operation panel, and after verifying the power indicator has gone off, switch off the main power switch. 2. Remove two screws and remove the right upper plate lid. 3. Insert Compact Flash in a notch hole of the machine. 4. While pressing the copier key, turn the main power switch on. 5. Enter the maintenance item. 6. Press the start key. 7. Select the item. <table border="1"> <thead> <tr> <th>Display</th><th>Description</th></tr> </thead> <tbody> <tr> <td>SRAM -> CF : FAX BACKUP</td><td>Writing the backup data of fax control PWB</td></tr> <tr> <td>CF -> SRAM : FAX BACKUP</td><td>Reading the backup data of fax control PWB</td></tr> <tr> <td>SRAM -> CF : FAX DIAL INFO</td><td>Writing the backup data of fax dial information</td></tr> <tr> <td>CF -> SRAM : FAX DIAL INFO</td><td>Reading the backup data of fax dial information</td></tr> </tbody> </table> <ol style="list-style-type: none"> 8. Press the start key. Reading or writing is executed, and the screen displays the result. If the operation was successful: EXECUTE 0100 CHECK SUM **** CODE 0000 If the operation failed: EXECUTE 0100 CHECK SUM **** CODE XXXX Where XXX is the error code indicating the reason for the failure. See Error Codes for Operation U917 and U926 below. 9. Press the power key on the operation panel, and after verifying the power indicator has gone off, switch off the main power switch. 10. Remove the Compact Flash from the machine. 11. Refit the right upper plate lid. <p>Error Codes for Operation U917 and U926</p> <table border="1"> <thead> <tr> <th>Code</th><th>Description</th></tr> </thead> <tbody> <tr> <td>0102</td><td>Detects call for service on fax control PWB.</td></tr> <tr> <td>0103</td><td>Detects call for service on engine PWB.</td></tr> <tr> <td>0104</td><td>Communication error.</td></tr> <tr> <td>0105</td><td>Detects call for service on main PWB.</td></tr> <tr> <td>01FF</td><td>CF error.</td></tr> <tr> <td>0202</td><td>No CF card.</td></tr> <tr> <td>0203</td><td>No data in CF card.</td></tr> <tr> <td>0204</td><td>CF data is incompatible.</td></tr> <tr> <td>0205</td><td>Bad CF data (Checksum error)</td></tr> <tr> <td>0206</td><td>CF read error.</td></tr> <tr> <td>0207</td><td>CF write error.</td></tr> <tr> <td>0212</td><td>Fax control PWB flash memory error.</td></tr> </tbody> </table> | Display | Description | SRAM -> CF : FAX BACKUP | Writing the backup data of fax control PWB | CF -> SRAM : FAX BACKUP | Reading the backup data of fax control PWB | SRAM -> CF : FAX DIAL INFO | Writing the backup data of fax dial information | CF -> SRAM : FAX DIAL INFO | Reading the backup data of fax dial information | Code | Description | 0102 | Detects call for service on fax control PWB. | 0103 | Detects call for service on engine PWB. | 0104 | Communication error. | 0105 | Detects call for service on main PWB. | 01FF | CF error. | 0202 | No CF card. | 0203 | No data in CF card. | 0204 | CF data is incompatible. | 0205 | Bad CF data (Checksum error) | 0206 | CF read error. | 0207 | CF write error. | 0212 | Fax control PWB flash memory error. |
| Display | Description | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SRAM -> CF : FAX BACKUP | Writing the backup data of fax control PWB | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| CF -> SRAM : FAX BACKUP | Reading the backup data of fax control PWB | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SRAM -> CF : FAX DIAL INFO | Writing the backup data of fax dial information | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| CF -> SRAM : FAX DIAL INFO | Reading the backup data of fax dial information | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Code | Description | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 0102 | Detects call for service on fax control PWB. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 0103 | Detects call for service on engine PWB. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 0104 | Communication error. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 0105 | Detects call for service on main PWB. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 01FF | CF error. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 0202 | No CF card. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 0203 | No data in CF card. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 0204 | CF data is incompatible. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 0205 | Bad CF data (Checksum error) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 0206 | CF read error. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 0207 | CF write error. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 0212 | Fax control PWB flash memory error. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |

| Maintenance item No. | Description |
|-------------------------|--|
| U920 | <p>Checking the copy counts</p> <p>Description Checks the copy counts.</p> <p>Purpose To check the copy counts.</p> <p>Method Press the start key. The current counts of copy counter, printer counter and fax counter are displayed.</p> <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p> |
| U925 | <p>Checking/clearing the system error counts</p> <p>Description Displays and clears the count value of system error.</p> <p>Purpose To check the system error status by types. Also to clear the service call code counts after replacing consumable parts.</p> <p>Method Press the start key. The count for system error detection by type is displayed.</p> <p>Clearing</p> <ol style="list-style-type: none"> 1. Press the reset key. 2. Press the start key. All counts are cleared. <p>Completion Press the stop/clear key. The screen for selecting a maintenance No. item is displayed.</p> |

| Maintenance item No. | Description |
|-------------------------|--|
| U926 | <p>Rewriting FAX program</p> <p>Description Downloads the fax program and fax fonts when installing an optional fax kit.</p> <p>Purpose To run when upgrading the fax program and fax fonts.</p> <p>Setting</p> <ol style="list-style-type: none"> 1. Press the power key on the operation panel, and after verifying the power indicator has gone off, switch off the main power switch. 2. Remove two screws and remove the right upper plate lid. 3. Insert Compact Flash in a notch hole of the machine. 4. While pressing the copier key, turn the main power switch on. 5. Enter the maintenance item. 6. Press the start key. 7. Select [FAX PROGRAM/FONT] and press the start key. Downloading of the fax program starts and the result shown below is displayed. <p>If the operation was successful: EXECUTE 0100 CHECK SUM **** CODE 0000</p> <p>If the operation failed: EXECUTE 0100 CHECK SUM **** CODE XXXX Where XXX is the error code indicating the reason for the failure.</p> <ol style="list-style-type: none"> 8. Then, downloading of the fax fonts starts and the result shown below is displayed. <p>If the operation was successful: EXECUTE 0100 CHECK SUM **** CODE 0000</p> <p>If the operation failed: EXECUTE 0100 CHECK SUM **** CODE XXXX Where XXX is the error code indicating the reason for the failure. See Error Codes for Operation U917 and U926 on P.1-3-64.</p> <ol style="list-style-type: none"> 9. Press the power key on the operation panel, and after verifying the power indicator has gone off, switch off the main power switch. 10. Remove the Compact Flash from the machine. 11. Refit the right upper plate lid. |










| Maintenance item No. | Description | | | | | | |
|----------------------|---|---------|-------------|----|-------------------------------------|-----|--------------------------------------|
| U927 | <p>Clearing the all copy counts and machine life counts (one time only)</p> <p>Description Resets all of the counts back to 0.</p> <p>Purpose To start the counters with value 0 when installing the machine.</p> <p>Supplement The total account counter and the machine life counter can be cleared only once if all count values are 1000 or less.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Press [EXECUTE] on the touch panel. 3. Press the start key. All copy counts and machine life counts are cleared. [CANNOT EXECUTE] is displayed if the count cannot be cleared. <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p> | | | | | | |
| U928 | <p>Checking machine life counts</p> <p>Description Displays the machine life counts.</p> <p>Purpose To check the machine life counts.</p> <p>Method Press the start key. The current machine life counts is displayed.</p> <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p> | | | | | | |
| U931 | <p>Setting the automatic toner install</p> <p>Description Sets automatic toner installation on or off when power is turned on.</p> <p>Purpose Changed to off when deactivating automatic toner installation.</p> <p>Setting</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select ON or OFF. <table border="1"> <thead> <tr> <th>Display</th><th>Description</th></tr> </thead> <tbody> <tr> <td>ON</td><td>Automatic toner install function ON</td></tr> <tr> <td>OFF</td><td>Automatic toner install function OFF</td></tr> </tbody> </table> <p>Initial setting: ON</p> <ol style="list-style-type: none"> 3. Press the start key. The setting is set. 4. Turn the main power switch off and on. | Display | Description | ON | Automatic toner install function ON | OFF | Automatic toner install function OFF |
| Display | Description | | | | | | |
| ON | Automatic toner install function ON | | | | | | |
| OFF | Automatic toner install function OFF | | | | | | |

| Maintenance item No. | Description | | | | | | | | | | | | | | | |
|----------------------|---|---------------|-----------------|--------------------------|-------------------|--------------------------|--|---------------------------------------|-----------|---|----------|---------|---|-----------|---|----------|
| U935 | <p>Relay board maintenance</p> <p>Description Sets the mode when call for service (C0060) occurs.</p> <p>Purpose Sets the machine status temporarily when call for service (C0060) occurs. However, after the setting, call for service (C0060) occurs again when progress of period.</p> <p>Setting</p> <ol style="list-style-type: none">1. Press the start key.2. Select the item. <table><tr><th>Display</th><th>Description</th></tr><tr><td>MODE 0</td><td>Setting mode: OFF</td></tr><tr><td>MODE 1</td><td>Setting mode: ON (Usable up to three times of use)</td></tr></table> <p>Initial setting: 0</p> <ol style="list-style-type: none">3. Press the start key. The setting is set.4. Turn the main power switch off and on. <p>Supplement After removing the cause of the problem, be sure to change the setting in OFF.</p> | Display | Description | MODE 0 | Setting mode: OFF | MODE 1 | Setting mode: ON (Usable up to three times of use) | | | | | | | | | |
| Display | Description | | | | | | | | | | | | | | | |
| MODE 0 | Setting mode: OFF | | | | | | | | | | | | | | | |
| MODE 1 | Setting mode: ON (Usable up to three times of use) | | | | | | | | | | | | | | | |
| U942 | <p>Setting of deflection for feeding from DP</p> <p>Description Adjusts the deflection generated when the optional DP is used.</p> <p>Purpose Use this mode if an original non-feed jam, oblique feed or wrinkling of original occurs when the DP is used.</p> <p>Setting</p> <ol style="list-style-type: none">1. Press the start key.2. Select the item to be adjusted. <table><tr><th>Display</th><th>Description</th><th>Setting range</th><th>Initial setting</th><th>Change in value per step</th></tr><tr><td>FEED MOT</td><td>Deflection in the original feed motor</td><td>-31 to 31</td><td>0</td><td>0.098 mm</td></tr><tr><td>REV MOT</td><td>Deflection in the original switchback motor</td><td>-31 to 31</td><td>0</td><td>0.098 mm</td></tr></table> <ol style="list-style-type: none">3. Press the interrupt key.4. Place an original on the DP and press the start key to make a test copy.5. Press the interrupt key.6. Change the setting value using the cursor up/down keys. The greater the value, the larger the deflection; the smaller the value, the smaller the deflection. If an original non-feed jam or oblique feed occurs, increase the setting value. If wrinkling of original occurs, decrease the value.7. Press the start key. The setting is set. <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p> | Display | Description | Setting range | Initial setting | Change in value per step | FEED MOT | Deflection in the original feed motor | -31 to 31 | 0 | 0.098 mm | REV MOT | Deflection in the original switchback motor | -31 to 31 | 0 | 0.098 mm |
| Display | Description | Setting range | Initial setting | Change in value per step | | | | | | | | | | | | |
| FEED MOT | Deflection in the original feed motor | -31 to 31 | 0 | 0.098 mm | | | | | | | | | | | | |
| REV MOT | Deflection in the original switchback motor | -31 to 31 | 0 | 0.098 mm | | | | | | | | | | | | |
| U984 | <p>Checking the developing unit number</p> <p>Description Displays the developing unit number.</p> <p>Purpose To check the developing unit number.</p> <p>Method Press the start key. The number is displayed.</p> <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p> | | | | | | | | | | | | | | | |

TONER

www.tonerplus.com.ua


| Maintenance item No. | Description | | | | | | |
|----------------------------|---|---------|-------------|----------------------------|-------------------------------------|----------------------|-----------------------------------|
| U985 | <p>Displaying the developing unit history</p> <p>Description Displays the past record of machine number and the developing counter.</p> <p>Purpose To check the count value machine number and the developing counter.</p> <p>Method Press the start key. Past record of 5 cases is displayed.</p> <table border="1"> <thead> <tr> <th>Display</th><th>Description</th></tr> </thead> <tbody> <tr> <td>MACHINE No. HISTORY 1 to 5</td><td>Past record of machine number</td></tr> <tr> <td>COUNT HISTORY 1 to 5</td><td>Past record of developing counter</td></tr> </tbody> </table> <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p> | Display | Description | MACHINE No. HISTORY 1 to 5 | Past record of machine number | COUNT HISTORY 1 to 5 | Past record of developing counter |
| Display | Description | | | | | | |
| MACHINE No. HISTORY 1 to 5 | Past record of machine number | | | | | | |
| COUNT HISTORY 1 to 5 | Past record of developing counter | | | | | | |
| U990 | <p>Checking/clearing the time for the exposure lamp to light</p> <p>Description Displays, clears or changes the accumulated time for the exposure lamp to light.</p> <p>Purpose To check duration of use of the exposure lamp. Also to clear the accumulated time for the lamp after replacement.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. The accumulated time of illumination for the exposure lamp is displayed in minutes. 2. Press the start key. The accumulated time is cleared. <p>Setting</p> <ol style="list-style-type: none"> 1. Enter a accumulated time using the cursor up/down keys. 2. Press the start key. The time is set. <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p> | | | | | | |
| U991 | <p>Checking the scanner count</p> <p>Description Displays the scanner operation count.</p> <p>Purpose To check the status of use of the scanner.</p> <p>Method Press the start key.</p> <table border="1"> <thead> <tr> <th>Display</th><th>Description</th></tr> </thead> <tbody> <tr> <td>COPY SCAN COUNT</td><td>Scanner operation count for copying</td></tr> <tr> <td>FAX SCAN COUNT</td><td>Scanner operation count for fax</td></tr> </tbody> </table> <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p> | Display | Description | COPY SCAN COUNT | Scanner operation count for copying | FAX SCAN COUNT | Scanner operation count for fax |
| Display | Description | | | | | | |
| COPY SCAN COUNT | Scanner operation count for copying | | | | | | |
| FAX SCAN COUNT | Scanner operation count for fax | | | | | | |

| Maintenance item No. | Description | | | | | | | | | | | | |
|----------------------|---|---|-------------------------|---------|-----|---|---|-----|---|---|-----|---|----------------------------|
| U993 | <p>Outputting a VTC-PG pattern</p> <p>Description Selects and outputs a VTC-PG pattern created in the machine.</p> <p>Purpose When performing respective image printing adjustments, used to check the machine status apart from that of the scanner with a non-scanned output VTC-PG pattern.</p> <p>Method</p> <ol style="list-style-type: none">1. Press the start key.2. Select the VTC-PG pattern to be output and press the start key. <table><tr><th>Display</th><th>PG pattern to be output</th><th>Purpose</th></tr><tr><td>PG1</td><td></td><td>Leading edge registration adjustment Center line adjustment Margin adjustment</td></tr><tr><td>PG2</td><td></td><td>Lateral squareness adjustment Magnification adjustment</td></tr><tr><td>PG3</td><td></td><td>Driving unevenness of drum</td></tr></table> <ol style="list-style-type: none">3. Press the interrupt key.4. Press the start key. A VTC-PG pattern is output.5. To return to the screen for selecting an item, press the interrupt key. <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p> | Display | PG pattern to be output | Purpose | PG1 |  | Leading edge registration adjustment Center line adjustment Margin adjustment | PG2 |  | Lateral squareness adjustment Magnification adjustment | PG3 |  | Driving unevenness of drum |
| Display | PG pattern to be output | Purpose | | | | | | | | | | | |
| PG1 |  | Leading edge registration adjustment Center line adjustment Margin adjustment | | | | | | | | | | | |
| PG2 |  | Lateral squareness adjustment Magnification adjustment | | | | | | | | | | | |
| PG3 |  | Driving unevenness of drum | | | | | | | | | | | |

1-3-2 User management

In addition to a maintenance function for service, the machine is equipped with a management function which can be operated by users. In this user management mode, settings such as default settings can be changed.

(1) Using the user management mode



(2) Job accounting

New account

Creates new accounts by entering an account ID code (of up to eight digits), account name, and restrictions on usage as desired.

1. Press [Management Edit].
2. Press [Register].
3. Select [Account ID] using the cursor up/down keys and press [Change #].
4. Enter the department ID code using the numeric keys.
5. Press [Close].
6. Select [Name to Display] using the cursor up/down keys and press [Change #].
7. Enter the department name and press [End].
8. Press [Next].
9. Specify restrictions on copying and press [Registr.].

Deleting accounts

Delete the department accounts registered.

1. Press [Management Edit].
2. Select the department ID code to delete and press [Delete].
3. Check the ID code to delete and press [Yes].

Editing department information

Changes the name and ID code registered for the department.

1. Press [Management Edit].
2. Select the department ID code to modify and press [Mgt. Inf. Correction].
3. Select [Account ID] using the cursor up/down keys and press [Change #].
4. Press [Clear].
5. Enter the new ID code using the numeric keys.
6. Press [Close].
7. Select [Name to Display] using the cursor up/down keys and press [Change #].
8. Press [AllDel.].
9. Enter the new department name and press [End].
10. Press [Close].

Changing restrictions on usage

Changes the restriction on usage per individual department.

1. Press [Management Edit].
2. Select the department ID code to modify and press [Limit in use].
3. Select the usage restriction and press [Close].

Total job accounting

Calculate the total usage count for all departments and print the total in the form of Job Accounting reports. The total usage count can be reset as necessary.

1. Press [Total Job Accounting].
2. The total usage count is displayed.
3. Press [Print Report] and choose the report type to print this information as a management report. Press [Report by Function] to count a list of reports by function. Press [Report by Size] in Total Count by Size, 1-5 of the Job Accounting default settings for a list of reports by paper size.
4. To reset the usage count, press [Counter clear].
5. Press [Yes].

Copy count per department

Tracks the copy count per individual department. The copy count per department can be reset as necessary.

1. Press [Each Job Accounting].
2. Select the ID-code of the department and press [Total].
3. The usage count for the selected department is displayed.
4. To reset the usage count, press [Counter clear].
5. Press [Yes].
6. Press [Close].

Activating and deactivating job accounting

Turn job accounting on or off.

1. Select [On] or [Off].
2. Press [Close].
3. Press [End].

Copy job accounting

Activate or deactivate Job Accounting for copy jobs.

1. Press [Job Acctng Def. Set.].
2. Select [Copy Job Accounting] using the cursor up/down keys and press [Change #].
3. Select [On] or [Off].
4. Press [Close].

Printer job accounting

Activate or deactivate Job Accounting when the device is used as a printer.

This setting is displayed when the optional printer kit is installed.

1. Press [Job Acctng Def. Set.].
2. Select [Print. Job Accounting] using the cursor up/down keys and press [Change #].
3. Select [On] or [Off].
4. Press [Close].



Printer error report

Specify whether an error report is printed in case that the user attempts to print using the incorrect department code.

This item is not shown when Printer Job Accounting is set to [Off].

1. Press [Job Acctng Def. Set.].
2. Select [Printer error report] using the cursor up/down keys and press [Change #].
3. Select [On] or [Off].
4. Press [Close].

Printing from unregistered sources (printer)

Authorize or prohibit printing from computers with printer drivers that do not support Job Accounting.

This item is not shown when Printer Job Accounting is set to [Off].

1. Press [Job Acctng Def. Set.].
2. Select [Other Mgt. reg. (print)] using the cursor up/down keys and press [Change #].
3. Select [On] or [Off].
4. Press [Close].

Copy/Printer output management

Select whether copying and printing are managed together or separately.

1. Press [Job Acctng Def. Set.].
2. Select [Copy/Printer output mgt] using the cursor up/down keys and press [Change #].
3. Select [All] or [Split].
4. Press [Close].

Fax job accounting

Activate or deactivate job accounting when the optional fax function is used.

This setting is displayed when the optional fax kit is installed.

1. Press [Job Acctng Def. Set.].
2. Select [Fax Job Accounting] using the cursor up/down keys and press [Change #].
3. Select [On] or [Off].
4. Press [Close].

Response to unauthorized requests

Specify the actions when users attempt to copy in excess of the specified copy limitation.

1. Press [Job Acctng Def. Set.].
2. Select [Apply Limit] using the cursor up/down keys and press [Change #].
3. Press [Stop job immediately], [Sub-sequently] or [Alert Only].
4. Press [Close].

Default counter limit value

Specify the default of usage limitation when registering a new department.

1. Press [Job Acctng Def. Set.].
2. Select [Def. Val. of coun. Limit] using the cursor up/down keys and press [Change #].
3. Enter the number of pages using the numeric keys.
4. Press [Close].

Total count by size, 1-5

Registers specific paper sizes and types of paper to check the copy count.

1. Press [Job Acctng Def. Set.].
2. Select [Total size 1-5] using the cursor up/down keys and press [Change #].
3. Press [On].
4. Press [Select Size].
5. Select a paper size and press [Close].
6. To specify a paper type, press [Select Media Type].
7. Select the paper type and press [Close].
8. Press [Close].



(3) Default settings for copying

Density

Set the exposure mode for default settings mode.

1. Select [Density Mode] using the cursor up/down keys and press [Change #].
2. Select [Manual] or [Auto].

Density steps

Change the exposure adjustment step amount.

1. Select [Exposure Steps] using the cursor up/down keys and press [Change #].
2. Select [1 step] or [0.5 step].

Original image quality

Set the original image quality for default settings mode.

1. Select [Original Image] using the cursor up/down keys and press [Change #].
2. Select [Text+Photo], [Photo] or [Text].

Setting EcoPrint

Set EcoPrint for default settings mode.

1. Select [EcoPrint] using the cursor up/down keys and press [Change #].
2. Select [Off] or [On].

Adjusting background density

If the background on copies appears too dark, you can lighten it.

1. Select [Background Density Adj] using the cursor up/down keys and press [Change #].
2. Select [Off] or [On].

Correct fine black lines

Set Fine Black Line correction to reduce the black lines that may occur when copying using the optional document processor.

When suppressing black streaks, select [On (Low)].

Select [On (High)] only when the black streaks are not suppressed with the Low setting.

1. Select [Correcting Black Line] using the cursor up/down keys and press [Change #].
2. Select [Off], [On (Low)] or [On (High)].

Paper selection

In default settings mode, set the paper selection method for when an original is set.

1. Select [Paper Selection] using the cursor up/down keys and press [Change #].
2. Select [APS] or [Default cassette].

Setting auto paper selection

Set the paper selection method for Auto Paper Selection mode when changing the zoom ratio.

1. Select [APS Setting] using the cursor up/down keys and press [Change #].
2. Select [Most Suit Size] or [Same as Orig. Size].

Selecting media types

Select Automatic Paper Selection mode for black and white copying to limit the paper types.

1. Select [Select media type (APS)] using the cursor up/down keys and press [Change #].
2. Select [Off] or [On].

Selecting default paper source

Automatically selects the default cassette (1 - 4).

The MP tray may not be set as the default cassette. [Cassette 3] and [Cassette 4] are shown when the optional paper feeder is installed.

1. Select [Default paper source] using the cursor up/down keys and press [Change #].
2. Select the cassette to use as the default.

Specifying paper source for cover

Specify the paper source cassette (1 - 4) or MP tray which is loaded with cover paper.

[Cassette 3] and [Cassette 4] are shown when the optional paper feeder is installed.

1. Select [Paper Source for Cover] using the cursor up/down keys and press [Change #].
2. Select the paper source containing the cover paper.

Setting auto % priority

Specify whether to set auto zoom when the paper in the selected cassette is different from the size of the original.

1. Select [Auto % Priority Setting] using the cursor up/down keys and press [Change #].
2. Select [Off] or [On].

Adjusting auto density

Adjusts the overall lightness or darkness when copying in auto exposure mode.

1. Select [Density Adjustment (Auto)] using the cursor up/down keys and press [Change #].
2. Press [Lighter] or [Darker] to adjust the density.

Adjusting manual density

Adjusts the overall lightness or darkness when copying in manual exposure mode.

1. Select [Density Adjust. (Manual)] using the cursor up/down keys and press [Change #].
2. Press [Lighter] or [Darker] to adjust the density.



Selecting default zoom

Set the reduce/enlarge setting in default settings mode.

1. Select [Zoom] using the cursor up/down keys and press [Change #].
2. Select [Auto %] or [100%].

Selecting collating and offsetting output

Set sorting and offsetting output options in default settings mode.

1. Select [Collate/Offset] using the cursor up/down keys and press [Change #].
2. Under [Collate], select [Off] or [On].
3. Under [Offset], select [Off] or [On].

Selecting auto image rotation

Set auto rotation in default settings mode.

1. Select [Auto Image Rotation] using the cursor up/down keys and press [Change #].
2. Select [Off] or [On].

Setting margin defaults

Sets margin the width default values.

1. Select [Default margin width] using the cursor up/down keys and press [Change #].
2. Press the cursor up/down or left/right keys to set the margin width.

Erasing borders

Set the border erase default values.

1. Select [Default erase width] using the cursor up/down keys and press [Change #].
2. Press [+] or [-] to set the [Border] (outer edges) and [Gutter] (middle) border widths.

Selecting maximum number of copies

Limits the number of sets that can be specified for a single copy.

1. Select [Preset limit] using the cursor up/down keys and press [Change #].
2. Use the numeric keys to specify the preset limit value.

Enabling repeat copy

Disable repeat copy or configure repeat copy in default settings mode.

1. Select [Repeat Copy] using the cursor up/down keys and press [Change #].
2. Under [Function], select [Off] or [On].
3. Under [Default], select [Off] or [On].

Showing the register key

Sets whether to show or hide [Shortcut] ([Register]) used to register/delete register keys.

1. Select [Display register key] ([Display "Register" key]) using the cursor up/down keys and press [Change #].
2. Select [Off] or [On].

Customize (basic screen)

Rearrange the basic screen layout for maximum ease of use.

1. Select [Customize (Basic Screen)] ([Customize (Main function)]) using the cursor up/down keys and press [Change #].
2. Move the item using the cursor up/down keys, [Move Ahead] or [Move Behind] ([Move Backward]).

Customize (user choice)

Rearrange the screen to easily access frequently used functions.

1. Select [Customize (User Choice)] ([Customize (Add function)]) using the cursor up/down keys and press [Change #].
2. Under [Addition Mode], press the cursor up/down keys to select the function to change.
Under [Register Mode], press the cursor up/down keys to select the function that is to be added and press [←] to move the function.

(4) Machine default

Enabling auto cassette switching

Use auto cassette switching to automatically switch the paper source to another cassette loaded with the same size and orientation paper when the current cassette runs out of paper.

1. Select [Auto cassette switching] using the cursor up/down keys and press [Change #].
2. Under [Function], select [Off] or [On].
3. Under [Paper Type], select [All types of paper] or [Feed same paper type].

Specifying the paper size

Specify the paper sizes for Cassettes 1 - 4.

[Cassette 3] and [Cassette 4] are shown when the optional paper feeder is installed.

1. Select [Paper size (Cassette 1 - Cassette 4)] using the cursor up/down keys and press [Change #].
2. Select [Auto Detection] or [Standard sizes].
If [Auto Detection] is selected, choose the unit type.
If [Standard sizes] is selected, choose the paper size.

Specifying the media type

Specify the media type for Cassettes 1 - 4.

[Cassette3] and [Cassette 4] are shown when the optional paper feeder is installed.

1. Select [Media type (Cassette 1 - Cassette 4)] using the cursor up/down keys and press [Change #].
2. Select the media type.

Registering MP tray paper size

Up to 4 custom paper sizes can be pre-registered for use with the MP tray.

1. Select [Store Paper Size for MPT] using the cursor up/down keys and press [Change #].
2. Select the number to register from [Paper size (User reg. 1 - 4)] using the cursor up/down keys and press [Change #].
3. Press [On].
Press [+] or [-] to set the [Height].
Metric models only
Enter the size directly using the numeric keys by pressing [#-Keys].
4. Press [+] or [-] to set the [Width].
Metric models only
Enter the size directly using the numeric keys by pressing [#-Keys].
5. To specify a paper type, press [Select Media Type].
Select the paper type and press [Close].

Enabling quick access to MP tray settings

Set whether to show the [MP tray Settings] screen when the MP tray is selected from the [Basic] screen.

1. Select [Check MP tray sizing] using the cursor up/down keys and press [Change #].
2. Select [Off] or [On].

Setting media type properties (paper weight)

Set the weight (paper thickness) for each type of paper.

1. Select [Media Type (paper weight)] using the cursor up/down keys and press [Change #].
2. Select the media type to set the weight using the cursor up/down keys and press [Change #].
3. Select the weight and press [Close].

Setting media type properties (duplex mode)

Specify whether to allow duplex printing for each of custom media types 1 - 8.

1. Select [Select media type (2 sided)] using the cursor up/down keys and press [Change #].
2. Select the paper type to adjust from [Custom 1] - [Custom 8] using the cursor up/down keys and press [Change #].
3. Select [Off] or [On] and press [Close].

Setting handling for special media types

When printing on prepunched, preprinted, or letterhead paper, use this setting to change the direction of the finished output.

1. Select [Special paper action mode] ([Specif. paper action mode]) using the cursor up/down keys and press [Change #].
2. Select [Adj. Print Direction] or [Speed Priority].

Auto detect originals

Specify the paper size to select when an original with a similar size is automatically detected.

This setting is displayed only for metric models.

1. Select [Org. Auto Detect Setting] using the cursor up/down keys and press [Change #].
2. Select the paper size to specify using the cursor up/down keys and press [Change #].
3. For [Cardstock/A6], select [Cardstock] or [A6] and press [Close].
For [B4/Folio], select [B4] or [Folio] and press [Close].
For 11 x 15", select [On] or [Off] and press [Close].

Orientation of original document

Set the original orientation in default settings mode.

1. Select [Orig. Orient] using the cursor up/down keys and press [Change #].
2. Select [Top Edge Top] or [Top Edge Left].

Setting sleep timer timeout

Set the time until Auto Sleep mode is activated when [On] is selected in Activating Auto Sleep.

1. Select [Sleep mode changing time] using the cursor up/down keys and press [Change #].
2. Press [+] or [-] to set the time until Auto Sleep mode is activated.

Setting low-power timer timeout

Set the time until Auto Low-Power mode is activated.

1. Select [Low power mode chng. time] using the cursor up/down keys and press [Change #].
2. Press [+] or [-] to set the time until Auto Low-Power

Setting auto clear timeout time

Set the time until Auto Clear is activated after the last operation when [On] is selected in Activating Auto Clear.

1. Select [Auto Clear Time Setting] using the cursor up/down keys and press [Change #].
2. Press [+] or [-] to set the time until Auto Clear is activated.

Selecting output destination

Set the default copy output destination.

This setting is displayed when the optional document finisher, job separator or built-in finisher is installed.

1. Select [Select Copy output tray] using the cursor up/down keys and press [Change #].
2. Select the output destination.

Selecting FAX output mode

Set the default output destination for printing originals or reports received by fax.

This setting is displayed when the fax kit and document finisher optional job separator or built-in finisher is installed.

1. Select [Select FAX output tray] using the cursor up/down keys and press [Change #].
2. Select the output destination.

Select the main mode

Specify the screen to be first shown after power-on.

This setting is displayed when the optional fax kit is installed.

1. Select [Select the main mode] ([Select main mode]) using the cursor up/down keys and press [Change #].
2. Select [Copy Mode] or [FAX Mode].

Setting notification sounds

Set the notification sounds made by the machine during operation.

1. Select [Notify (Touch tone)], [Notify (Finish)], [Notify (Ready)] or [Notify (Attention)] using the cursor up/down keys and press [Change #].
2. Select [Off] or [On].

Silent mode

Configures the machine to operate more quietly.

1. Select [Silent Mode] using the cursor up/down keys and press [Change #].
2. Select [Off] or [On].

www.tonerplus.com.ua

Changing management code

Change the machine's management code.

The default setting is 2500 for the 25 ppm model and 3000 for the 30 ppm models.

1. Select [Management code change] ([Change MGMT code with #]) using the cursor up/down keys and press [Change #].
2. Use the numeric keys to enter the new management code.

Activating auto sleep

In Auto Sleep mode, the machine automatically switches to Sleep mode if left idle for a preset period.

1. Select [Auto sleep] using the cursor up/down keys and press [Change #].
2. Select [Off] or [On].

Auto drum refresh

Specify the duration of automatic drum refreshing.

1. Select [Auto Drum Refresh] using the cursor up/down keys and press [Change #].
2. Select [Off], [Standard] or [Long].

(5) Setting MP tray**Auto detect**

The paper size is automatically detected.

1. Press [Auto Detection].
2. Select [Centimeter] ([Centimetre]) or [Inch].

Other standard sizes

Specify special standard sizes.

1. Press [Others Standard] and press [Select size].
2. Select the paper size.
3. Press [Close].

Size entry

Specify the required paper size.

1. Press [Size Entry].
2. Press [+] and [-] to set the [Y] (height) size.
Metric models only
Enter the size directly using the numeric keys by pressing [#-Keys].
3. Press [+] and [-] to set the [X] (width) size.
Metric models only
Enter the size directly using the numeric keys by pressing [#-Keys].

Custom size

Store frequently used paper sizes (1 - 4) as custom sizes.

1. Press [Others Standard] and press [Select size].
2. Select the paper size from [Custom Size] ([Use regist]).
3. Press [Close].

Specifying the media type for the MP tray

1. Press [Select Media Type].
2. Select the media type.
3. Press [Close].

(6) Registering non-standard sizes for originals

Pre-register 4 types of non-standard original sizes.

1. Select the number to register from [Original Size (custom 1 - 4)] and press [Change #].
2. Press [On].
3. Press [+] or [-] to set the Y (height) size.
4. Press [+] or [-] to set the X (width) size.
5. Press [Close]

(7) Drum refresh**Drum refresh**

Refresh the drum when printed images are blurred or white spots appear on the image.

1. Press [Drum refresh].
2. Select [Drum Refresh 1] or [Drum Refresh 2].
Drum refresh begins.
3. Press [Close].

(8) Printing reports

Print the following reports from the operation panel.

- Copy Status Report
- Machine Status Report
- Toner Coverage Report

The toner coverage report includes for each paper size details about the number of sheets printed and black coverage ratio. Print the following 4 report types.

- Total toner coverage report
- Copy toner coverage report
- Printer toner coverage report
- Fax toner coverage report

Before printing reports, verify that either 11 x 8 1/2" or A4 paper is loaded into a cassette.

1. Press the key for the report you would like to print.
2. Report printing begins.

(9) Checking total copy count

Check the total copy count from the operation panel.

Check the following values.

- Number of copies, number of prints, number of faxes, and total of all of these
- Number of original pages scanned for copy mode and fax send mode, and total of all of these

Also, print this information as a counter report.

Before printing reports, verify that either 11 x 8 1/2" or A4 paper is loaded into a cassette.

1. The counts are displayed on the touch panel.
2. To print a counter report, press [Print Report].

1-4-1 Paper misfeed detection

(1) Paper misfeed indication

When a paper misfeed occurs, the machine immediately stops copying and displays the jam location on the operation panel.

Paper misfeed counts sorted by the detection condition can be checked in maintenance item U903.

To remove paper jammed in the machine, open the front cover, left cover or pull the cassette out.

To remove original jammed in the optional DP, open the document processor top cover.

To remove the jammed paper in optional document finisher, detach the finisher from the machine.

Paper misfeed detection can be reset by opening and closing the respective covers to turn safety switch off and on.




Figure 1-4-1

- (1) Misfeed in cassette 1
- (2) Misfeed in cassette 2
- (3) Misfeed in optional cassette 3 or 4
- (4) Misfeed in MP tray
- (5) Misfeed in duplex unit or left cover 1
- (6) Misfeed in left cover 2 or 3
- (7) Misfeed in paper feed unit
- (8) Misfeed in optional built-in finisher
- (9) Misfeed in optional DP
- (10) Misfeed in optional document finisher
- (11) Misfeed in optional job separator

(2) Paper misfeed detection conditions




Figure 1-4-2

| Section | Description | Conditions | Specified time |
|--------------------|---|---|----------------|
| System | 04 Cover open | Cover is open during copying. | - |
| | 05 Secondary paper feed does not start | Secondary paper feed does not start within specified time of arrival of paper at the registration section. | 30 s |
| Paper feed section | 10 No paper feed from cassette 1 | Feed switch 1 (FSW1) does not turn on within the specified time of upper paper feed clutch (PFCL-U) turning on; the clutch is then successively turned off for 1 s and turned back on, but the switch again fails to turn on within the specified time. | 1864 ms |
| | 11 No paper feed from cassette 2 | Feed switch 2 (FSW2) does not turn on within the specified time of lower paper feed clutch (PFCL-L) turning on; the clutch is then successively turned off for 1 s and turned back on, but the switch again fails to turn on within the specified time. | 2121 ms |
| | 12 No paper feed from optional cassette 3 | Feed switch 3 (FSW3) does not turn on within the specified time of paper feeder paper feed clutch 1 (PFPFCL1) turning on; the clutch is then successively turned off for 1 s and turned back on, but the switch again fails to turn on within the specified time. | - |
| | | Left cover 3 is opened in prior to feed switch 3 (FSW3) is turned on. | - |
| | 13 No paper feed from optional cassette 4 | The paper feeder feed switch (PFFSW) does not turn on within the specified time of paper feeder paper feed clutch 2 (PFPFCL2) turning on; the clutch is then successively turned off for 1 s and turned back on, but the switch again fails to turn on within the specified time. | - |
| | | Left cover 3 is opened in prior to the paper feeder feed switch (PFFSW) is turned on. | - |
| | 14 No paper feed from MP tray | The MP feed switch (MPFSW) does not turn on within the specified time of the MP paper feed clutch (MPPFCL) turning on; the clutch is then successively turned off for 1 s and turned back on, but the switch again fails to turn on within the specified time. | 993 ms |
| | 18 Misfeed in vertical paper conveying section | Feed switch 1 (FSW1) does not turn off within specified time of feed switch 2 (FSW2) turning on (paper feed from cassette 2). | 1314 ms |
| | | Feed switch 1 (FSW1) does not turn on within specified time of feed switch 2 (FSW2) turning on (paper feed from cassette 2). | 1314 ms |
| | | Feed switch 1 (FSW1) does not turn off within specified time of feed switch 2 (FSW2) turning on (paper feed from optional cassette 3, 4). | 1386 ms |
| | | Feed switch 1 (FSW1) does not turn on within specified time of feed switch 2 (FSW2) turning on (paper feed from optional cassette 3, 4). | 1386 ms |
| | | Feed switch 2 (FSW2) does not turn off within specified time of feed switch 3 (FSW3) turning on (paper feed from optional cassette 3, 4). | 1686 ms |
| | | Feed switch 2 (FSW2) does not turn on within specified time of feed switch 3 (FSW3) turning on (paper feed from optional cassette 3, 4). | 1686 ms |

| Section | Description | Conditions | Specified time |
|--------------------|--|---|------------------------|
| Paper feed section | 19 Misfeed in paper feeder vertical paper conveying section | The feed switch 3 (FSW3) does not turn off within specified time of its turning on (paper feed from optional cassette 3). | 1429 ms + Paper length |
| | | Feed switch 3 (FSW3) does not turn off within specified time of the paper feeder feed switch (PFFSW) turning on (paper feed from optional cassette 4). | 1064 ms |
| | | The feed switch 3 (FSW3) does not turn off within specified time of its turning on (paper feed from optional cassette 4). | 1064 ms |
| | | Feed switch 3 (FSW3) does not turn on within specified time of the paper feeder feed switch (PFFSW) turning on (paper feed from optional cassette 4). | 2000 ms |
| | 20 Misfeed in MP tray paper conveying section | The registration switch (RSW) does not turn off within specified time of the MP feed switch (MPFSW) turning on. | 1686 ms |
| | | The registration switch (RSW) does not turn on within specified time of the MP feed switch (MPFSW) turning on. | 1686 ms |
| | 21 Multiple sheets in paper feed section | The feed switch 1 (FSW1) does not turn off within specified time of its turning on (paper feed from cassette 1). | 1429 ms + Paper length |
| | | The feed switch 2 (FSW2) does not turn off within specified time of its turning on (paper feed from cassette 2). | 1429 ms + Paper length |
| | | The feed switch 3 (FSW3) does not turn off within specified time of its turning on (paper feed from optional cassette 3, 4/detected by the machine). | 1429 ms + Paper length |
| | | The feed switch 3 (FSW3) does not turn off within specified time of its turning on (paper feed from optional cassette 3, 4/detected by the paper feeder). | 4300 ms |
| | | The feed switch 2 (FSW2) does not turn off within specified time of its turning on (paper feed from optional cassette 3). | 1686 ms |
| | | The paper feeder feed switch (PFFSW) does not turn off within specified time of its turning on (paper feed from optional cassette 4). | 4300 ms |
| | | The feed switch 1 (FSW1) does not turn off within specified time of the upper paper feed clutch (PFCL-U) turning on. | 1864 ms |
| | | The feed switch 2 (FSW2) does not turn off within specified time of the lower paper feed clutch (PFCL-L) turning on. | 2121 ms |
| | | The feed switch 3 (FSW3) does not turn off within specified time of the paper feeder paper feed clutch 1 (PFPFCL1) turning on. | 2036 ms |
| | 23 Multiple sheets in MP tray conveying section | The MP feed switch (MPFSW) does not turn off within specified time of its turning on. | 1429 ms + Paper length |

| Section | Description | Conditions | Specified time |
|-------------------------|---|---|-----------------------|
| Paper conveying section | 30 Misfeed in registration/ transfer section | The registration switch (RSW) does not turn off within specified time of the feed switch 1 (FSW1) turning off. | 1314 ms |
| | | The registration switch (RSW) does not turn off within specified time of the feed switch 1 (FSW1) turning on. | 1100 ms |
| | | The registration switch (RSW) does not turn on within specified time of the feed switch 1 (FSW1) turning on. | 1100 ms |
| | | The registration switch (RSW) does not turn off within specified time of the MP feed switch (MPFSW) turning off. | 1686 ms |
| Fuser section | 40 Misfeed in fuser section (MP tray) | The eject switch (ESW) does not turn on within specified time of the registration clutch (RCL) turning on. | 2321 ms |
| | 41 Misfeed in fuser section (cassette 1) 42 Misfeed in fuser section (cassette 2) 43 Misfeed in fuser section (optional cassette 3) 44 Misfeed in fuser section (optional cassette 4) 47 Misfeed in fuser section (duplex section) | The feedshift switch (FSSW) does not turn on within specified time of the registration clutch (RCL) turning on. | 1336 ms |
| Eject section | 50 Misfeed in eject section | The eject switch (ESW) does not turn off within specified time of the registration switch (RSW) turning off. | 2321 ms |
| | | The eject switch (ESW) does not turn off within specified time of the registration clutch (RCL) turning on. | 2321 ms |
| | 51 Misfeed in job separator eject section | The job separator eject switch (JBESW) does not turn on within specified time of the feedshift switch (FSSW) turning on. | 1350 ms |
| | | The job separator eject switch (JBESW) does not turn off within specified time of the feedshift switch (FSSW) turning off. | 714 ms + Paper length |
| | | The job separator eject switch (JBESW) does not turn off within specified time of the feedshift switch (FSSW) turning on. | 1350 ms |
| Feedshift section | 52 Misfeed in feedshift section | The feedshift switch (FSSW) does not turn on within specified time of the start of eject motor (EM) reverse rotation. | 1121 ms |
| | | During paper switchback operation, the feedshift switch (FSSW) does not turn off within specified time of the its turning on. | 4514 ms |
| | | The feedshift switch (FSSW) does not turn off within specified time of the its turning on. | 4514 ms |
| | | The feedshift switch (FSSW) does not turn off within specified time of the registration clutch (RCL) turning on. | 2321 ms |

| Section | Description | Conditions | Specified time |
|-------------------|--|---|---|
| Duplex section | 60 Duplex paper conveying section 1 | The duplex paper conveying switch (DUPPCSW) does not turn on within specified time of the feedshift switch (FSSW) turning on. | 2621 ms |
| | | The duplex paper conveying switch (DUPPCSW) does not turn off within specified time of the feedshift switch (FSSW) turning off. | 2629 ms |
| | 61 Duplex paper conveying section 2 | The registration switch (RSW) does not turn on within specified time of the duplex paper conveying switch (DUPPCSW) turning on. | 1636 ms |
| | | The registration switch (RSW) does not turn off within specified time of the duplex paper conveying switch (DUPPCSW) turning off. | 1493 ms |
| Optional DP | 70 No original feed | The DP timing switch (DPTSW) does not turn on within specified time during the first sheet feeding (Retry 5 times). | 1468 pulses |
| | | The DP timing switch (DPTSW) does not turn on within specified time during the second sheet feeding (Retry 5 times). | 1468 pulses |
| | 71 An original jam in the original conveying section 1 | DP timing switch (DPTSW) does not turn off within specified time of the original conveying motor (OCM) turning on. | 9900 pulses 30558 pulses for large sizes |
| | 72 An original jam in the original conveying section 2 | DP timing switch (DPTSW) turns off within the specified time of period of the original conveying motor (OCM) turning on. | 1145 pulses |
| | 73 An original jam in the original switchback section | During original switchback operation, DP timing switch (DPTSW) does not turn off within specified time of the original conveying motor (OCM) turning on. | 9900 pulses 30558 pulses for large sizes |
| | 74 An original jam in the original switchback/feed section | DP timing switch (DPTSW) does not turn on within specified time of the original switchback motor (OSBM) turning on. | 2300 pulses |
| | 75 An original jam in the original switchback/conveying section | The original switchback switch (OSBSW) does not turn on within specified time of the DP timing switch (DPTSW) turning off. | 1815 pulses |
| Optional finisher | 78 Document processor cover open | The document processor or document processor top cover is opened during original feeding. DP timing switch (DPTSW) or original switchback switch (OSBSW) turns on when starting the original paper feed. | - |
| | 80 Finisher timeout jam (built-in finisher only) | Paper ejection is not output from the machine to the document finisher within specified time of the paper conveying switch (PCSW) turning on. | 15 s |

| Section | Description | Conditions | Specified time |
|-------------------|--|---|------------------------|
| Optional finisher | 81 Paper entry sensor nonarrival jam | (Document finisher) The paper entry sensor (PES) is not turned on even if a specified time has elapsed after the machine eject signal was received. | 2627 ms |
| | | (Built-in finisher) The paper conveying switch (PCSW) is not turned on even if a specified time has elapsed after the machine eject signal was received. | 2000 ms |
| | | (Built-in finisher) The paper conveying switch (PCSW) does not turn off within specified time of its turning on when paper is conveyed to the process table from the paper conveying unit. | 1429 ms + Paper length |
| | 82 Jam in stapler | (Document finisher) The staple home position sensor (STSPS) is not turned on within the specified time when driving the staple motor (STM). | 1000 ms |
| | | (Built-in finisher) The staple home position sensor (STHPS) is not turned on within the specified time when driving the staple motor (STM). | 600 ms |
| | 83 Exit sensor stay jam | (Document finisher) In the straight mode, the exit sensor (EXS) is not turned off within specified time of its turning on. | 1680 ms |
| | | (Document finisher) In the offset or staple mode, the exit sensor (EXS) is not turned off within specified time of its turning on. | 5375 ms |
| | | (Built-in finisher) The paper conveying switch (PCSW) does not turn off within specified time of its turning on when paper is ejected to the finisher tray from the process table. | 1429 ms + Paper length |
| | 91 Finisher cover open (document finisher only) | The finisher cover becomes open during paper is running. Paper is remaining in paths at power on. | - |
| | 92 Exit sensor non-arrival jam (document finisher only) | In the straight mode, the exit sensor (EXS) is not turned on even if a specified time has elapsed after the paper entry sensor (PES) was turned on. | 1770 ms |
| | 93 Reverse sensor jam (document finisher only) | The reverse sensor (REVS) does not turn on within specified time of paper entry sensor (PES) turning on. | 1125 ms |
| | | The reverse sensor (REVS) is not turned on within specified time. | Depends on paper size |
| | | The reverse sensor (REVS) does not turn off within specified time of paper entry sensor (PES) turning off. | 654 ms |
| | | The reverse sensor (REVS) is not turned off within specified time its turning on. | Depends on paper size |

| Section | Description | Conditions | Specified time |
|-------------------|--|---|-----------------------|
| Optional finisher | 94 Paper entry sensor stay/remaining jam (document finisher only) | The paper entry sensor (PES) is not turned off within specified time its turning on. | Depends on paper size |
| | | The paper entry sensor (PES) is not turned off within specified time its turning on. | - |
| | 95 Paper conveying sensor jam (document finisher only) | The paper conveying sensor (PCS) does not turn on within specified time of reverse sensor (REVS) turning on. | - |
| | | The paper conveying sensor (PCS) does not turn off within specified time of reverse sensor (REVS) turning off. | - |
| | 96 Jam between the built-in finisher and machine (built-in finisher only) | The paper conveying switch (PCSW) is not turned on within the specified time when paper is ejected to the finisher tray from the process table. | 2000 ms |

(3) Paper misfeeds

| Problem | Causes/check procedures | Corrective measures |
|--|--|---|
| (1) A paper jam in the paper feed, conveying or eject section is indicated as soon as the main power switch is turned on. | A piece of paper torn from copy paper is caught around feed switch 1/2/3, registration switch, eject switch or feedshift switch. | Check visually and remove it, if any. |
| | Defective switch. | Run maintenance item U031 and turn switch on and off manually. Replace the switch if indication of the corresponding switch on the touch panel is not displayed in reverse. Feed switch 1/2/3, registration switch, eject switch, feedshift switch |
| (2) A paper jam in the paper feed section is indicated during copying (no paper feed from cassette 1). Jam code 10 | Paper is extremely curled. | Change the paper. |
| | Check if the paper feed pulley, separation pulley or forwarding pulley of the cassette 1 are deformed. | Check visually and replace any deformed pulleys. |
| | Broken feed switch 1 actuator. | Check visually and replace switch. |
| | Defective feed switch 1. | Run maintenance item U031 and turn feed switch 1 on and off manually. Replace the switch if indication of the corresponding switch on the touch panel is not displayed in reverse. |
| | Check if the upper paper feed clutch malfunctions. | Run maintenance item U032 and select the upper paper feed clutch on the touch panel to be turned on and off. Check the status and remedy if necessary. |
| | Electrical problem with the upper paper feed clutch. | Check (see page 1-4-41). |
| (3) A paper jam in the paper feed section is indicated during copying (no paper feed from cassette 2). Jam code 11 | Paper is extremely curled. | Change the paper. |
| | Check if the paper feed pulley, separation pulley or forwarding pulley of the cassette 2 are deformed. | Check visually and replace any deformed pulleys. |
| | Broken feed switch 2 actuator. | Check visually and replace switch. |
| | Defective feed switch 2. | Run maintenance item U031 and turn feed switch 2 on and off manually. Replace feed switch 2 if indication of the corresponding switch on the touch panel is not displayed in reverse. |
| | Check if the lower paper feed clutch malfunctions. | Run maintenance item U032 and select the lower paper feed clutch on the touch panel to be turned on and off. Check the status and remedy if necessary. |
| | Electrical problem with the lower paper feed clutch. | Check (see page 1-4-41). |

| Problem | Causes/check procedures | Corrective measures |
|---|--|--|
| (4) A paper jam in the paper feed section is indicated during copying (no paper feed from optional cassette 3). Jam code 12 | Paper is extremely curled. | Change the paper. |
| | Check if the paper feed pulley, forwarding pulley and separation pulley of optional cassette 3 are deformed. | Check visually and replace any deformed pulleys. |
| | Broken feed switch 3 actuator. | Check visually and replace switch. |
| | Defective feed switch 3. | Run maintenance item U031 and turn feed switch 3 on and off manually. Replace feed switch 3 if indication of the corresponding switch on the touch panel is not displayed in reverse. |
| | Check if paper feeder paper feed clutch 1 malfunctions. | Run maintenance item U247 and select paper feeder paper feed clutch 1 on the touch panel to be turned on and off. Check the status and remedy if necessary. |
| | Electrical problem with paper feeder paper feed clutch 1. | Check (see service manual of paper feeder). |
| (5) A paper jam in the paper feed section is indicated during copying (no paper feed from optional cassette 4). Jam code 13 | Paper is extremely curled. | Change the paper. |
| | Check if the paper feed pulley, forwarding pulley and separation pulley of optional cassette 4 are deformed. | Check visually and replace any deformed pulleys. |
| | Broken paper feeder feed switch actuator. | Check visually and replace switch. |
| | Defective paper feeder feed switch. | With 5 V DC present at YC2-8 on the paper feeder main PWB, check if YC2-7 on the paper feeder main PWB remains low when the paper feeder feed switch is turned on and off. If it does, replace the paper feeder feed switch. |
| | Check if paper feeder paper feed clutch 2 malfunctions. | Run maintenance item U247 and select paper feeder paper feed clutch 2 on the touch panel to be turned on and off. Check the status and remedy if necessary. |
| | Electrical problem with paper feeder paper feed clutch 2. | Check (see service manual of paper feeder). |
| (6) A paper jam in the paper feed section is indicated during copying (no paper feed from MP tray). Jam code 14 | Paper is extremely curled. | Change the paper. |
| | Check if the MP paper feed pulley, MP forwarding pulley and MP separation pulley are deformed. | Check visually and replace any deformed pulleys. |
| | Broken MP feed switch actuator. | Check visually and replace switch. |
| | Defective MP feed switch. | Run maintenance item U031 and turn MP feed switch on and off manually. Replace the switch if indication of the corresponding switch on the touch panel is not displayed in reverse. |
| | Check if the MP paper feed clutch malfunctions. | Run maintenance item U032 and select MP paper feed clutch on the touch panel to be turned on and off. Check the status and remedy if necessary. |
| | Electrical problem with the MP paper feed clutch. | Check (see page 1-4-41). |

| Problem | Causes/check procedures | Corrective measures |
|--|---|--|
| (7) A paper jam in the paper feed section is indicated during copying (jam in vertical paper conveying section). Jam code 18 | Broken feed switch 1/2/3 actuator. | Check visually and replace switch. |
| | Defective switch. | Run maintenance item U031 and turn following switch on and off manually. Replace the switch if indication of the corresponding switch on the touch panel is not displayed in reverse. Feed switch 1/2/3 |
| | Defective feed pulleys or feed rollers. | Check visually and replace. |
| (8) A paper jam in the paper feed section is indicated during copying (jam in optional paper feeder vertical paper conveying section). Jam code 19 | Broken feed switch 3 actuator. | Check visually and replace switch. |
| | Defective feed switch 3. | Run maintenance item U031 and turn feed switch 3 on and off manually. Replace the switch if indication of the corresponding switch on the touch panel is not displayed in reverse. |
| | Broken paper feeder feed switch actuator. | Check visually and replace switch. |
| | Defective paper feeder feed switch. | With 5 V DC present at YC2-8 on the paper feeder main PWB, check if YC2-7 on the paper feeder main PWB remains low when the paper feeder feed switch is turned on and off. If it does, replace the paper feeder feed switch. |
| (9) A paper jam in the paper feed section is indicated during copying (jam in MP tray paper conveying section). Jam code 20 | Broken MP feed switch or registration switch actuator. | Check visually and replace switch. |
| | Defective switch. | Run maintenance item U031 and turn following switch on and off manually. Replace the switch if indication of the corresponding switch on the touch panel is not displayed in reverse. MP feed switch, registration switch |
| (10) A paper jam in the paper feed section is indicated during copying (multiple sheets in paper feed section). Jam code 21 | Broken feed switch 1/2/3 actuator. | Check visually and replace switch. |
| | Defective switch. | Run maintenance item U031 and turn switch on and off manually. Replace the switch if indication of the corresponding switch on the touch panel is not displayed in reverse. Feed switch 1/2/3 |
| | Broken paper feeder feed switch actuator. | Check visually and replace switch. |
| | Defective paper feeder feed switch. | With 5 V DC present at YC2-8 on the paper feeder main PWB, check if YC2-7 on the paper feeder main PWB remains low when the paper feeder feed switch is turned on and off. If it does, replace the paper feeder feed switch. |
| | Check if the clutch malfunctions. | Run maintenance item U032 and select following clutch on the touch panel to be turned on and off. Check the status and remedy if necessary. Upper paper feed clutch, lower paper feed clutch |
| | Electrical problem with clutch. | Check (see page 1-4-41). |
| | Check if paper feeder paper feed clutch 1 malfunctions. | Run maintenance item U247 and select paper feeder paper feed clutch 1 on the touch panel to be turned on and off. Check the status and remedy if necessary. |

| Problem | Causes/check procedures | Corrective measures |
|--|---|---|
| (10) A paper jam in the paper feed section is indicated during copying (multiple sheets in paper feed section). Jam code 21 | Electrical problem with paper feeder paper feed clutch 1. | Check (see service manual of paper feeder). |
| | Defective feed pulleys or feed rollers. | Check visually and replace. |
| (11) A paper jam in the paper feed section is indicated during copying (multiple sheets in MP tray conveying section). Jam code 23 | Broken MP feed switch actuator. | Check visually and replace switch. |
| | Defective switch. | Run maintenance item U031 and turn switch on and off manually. Replace the switch if indication of the corresponding switch on the touch panel is not displayed in reverse. MP feed switch |
| (12) A paper jam in the paper conveying section is indicated during copying (jam in registration/transfer section). Jam code 30 | Broken feed switch 1, registration switch or MP feed switch actuator. | Check visually and replace switch. |
| | Defective switch. | Run maintenance item U031 and turn switch on and off manually. Replace the switch if indication of the corresponding switch on the touch panel is not displayed in reverse. Feed switch 1, registration switch, MP feed switch |
| | The contact between the right and left registration rollers is not correct. | Check visually and replace. |
| (13) A paper jam in the fuser section is indicated during copying (jam in fuser section). Jam codes 40 to 44 and 47 | Broken eject switch or feed-shift switch actuator. | Check visually and replace switch. |
| | Defective switch. | Run maintenance item U031 and turn switch on and off manually. Replace the switch if indication of the corresponding switch on the touch panel is not displayed in reverse. Eject switch, feedshift switch |
| | Check if the registration clutch malfunctions. | Run maintenance item U032 and select the registration clutch on the touch panel to be turned on and off. Check the status and remedy if necessary. |
| | Electrical problem with the registration clutch. | Check (see page 1-4-41). |
| (14) A paper jam in the eject section is indicated during copying (jam in eject section). Jam code 50 | Broken eject switch or registration switch actuator. | Check visually and replace switch. |
| | Defective switch. | Run maintenance item U031 and turn switch on and off manually. Replace the switch if indication of the corresponding switch on the touch panel is not displayed in reverse. Registration switch, eject switch |
| | Check if the registration clutch malfunctions. | Run maintenance item U032 and select the registration clutch on the touch panel to be turned on and off. Check the status and remedy if necessary. |
| | Electrical problem with the registration clutch. | Check (see page 1-4-41). |

| Problem | Causes/check procedures | Corrective measures |
|--|---|---|
| (15) A paper jam in the eject section is indicated during copying (jam in optional job separator eject section). Jam code 51 | Broken feedshift switch or job separator eject switch actuator. | Check visually and replace switch. |
| | Defective switch. | Run maintenance item U031 and turn switch on and off manually. Replace the switch if indication of the corresponding switch on the touch panel is not displayed in reverse. Feedshift switch, job separator eject switch |
| (16) A paper jam in the feedshift section is indicated during copying (jam in feedshift section). Jam code 52 | Check if the feedshift solenoid malfunctions. | Run maintenance item U033 and select the feedshift solenoid on the touch panel to be turned on and off. Check the status and remedy if necessary. |
| | Electrical problem with the feedshift solenoid. | Check (see page 1-4-42). |
| | Broken feedshift switch actuator. | Check visually and replace switch. |
| | Defective switch. | Run maintenance item U031 and turn switch on and off manually. Replace the switch if indication of the corresponding switch on the touch panel is not displayed in reverse. Feedshift switch |
| | Check if the registration clutch malfunctions. | Run maintenance item U032 and select the registration clutch on the touch panel to be turned on and off. Check the status and remedy if necessary. |
| | Electrical problem with the registration clutch. | Check (see page 1-4-41). |
| (17) A paper jam in the duplex section is indicated during copying (jam in duplex paper conveying section 1). Jam code 60 | Broken feedshift switch or duplex paper conveying switch actuator. | Check visually and replace switch. |
| | Defective switch. | Run maintenance item U031 and turn switch on and off manually. Replace the switch if indication of the corresponding switch on the touch panel is not displayed in reverse. Feedshift switch, duplex paper conveying switch |
| (18) A paper jam in the duplex section is indicated during copying (jam in duplex paper conveying section 2). Jam code 61 | Broken duplex paper conveying switch or registration switch actuator. | Check visually and replace switch. |
| | Defective switch. | Run maintenance item U031 and turn switch on and off manually. Replace the switch if indication of the corresponding switch on the touch panel is not displayed in reverse. Duplex paper conveying switch, registration switch |

| Problem | Causes/check procedures | Corrective measures |
|--|--|--|
| (19) An original jams in optional DP is indicated during copying (no original feed). Jam code 70 | Defective DP timing switch. | Run maintenance item U244 and turn the DP timing switch on and off manually. Replace the switch if indication of the corresponding switch on the touch panel is not displayed in reverse. |
| | Check if the original feed motor malfunctions. | Run maintenance item U243 and select the original feed motor on the touch panel to be turned on and off. Check the status and remedy if necessary. |
| (20) An original jams in optional DP is indicated during copying (a jam in the original conveying section 1). Jam code 71 | Defective DP timing switch. | Run maintenance item U244 and turn the DP timing switch on and off manually. Replace the switch if indication of the corresponding switch on the touch panel is not displayed in reverse. |
| (21) An original jams in optional DP is indicated during copying (a jam in the original conveying section 2). Jam code 72 | Defective DP timing switch. | Run maintenance item U244 and turn the DP timing switch on and off manually. Replace the switch if indication of the corresponding switch on the touch panel is not displayed in reverse. |
| | Check if the original conveying motor malfunctions. | Run maintenance item U243 and select the original conveying motor on the touch panel to be turned on and off. Check the status and remedy if necessary. |
| (22) An original jams in optional DP is indicated during copying (a jam in the original switchback section). Jam code 73 | Defective DP timing switch. | Run maintenance item U244 and turn the DP timing switch on and off manually. Replace the switch if indication of the corresponding switch on the touch panel is not displayed in reverse. |
| | Check if the original conveying motor malfunctions. | Run maintenance item U243 and select the original conveying motor on the touch panel to be turned on and off. Check the status and remedy if necessary. |
| (23) An original jams in optional DP is indicated during copying (a jam in the original switchback/feed section). Jam code 74 | Defective DP timing switch. | Run maintenance item U244 and turn the DP timing switch on and off manually. Replace the switch if indication of the corresponding switch on the touch panel is not displayed in reverse. |
| | Check if the original switchback motor malfunctions. | Run maintenance item U243 and select the original switchback motor on the touch panel to be turned on and off. Check the status and remedy if necessary. |
| (24) An original jams in optional DP is indicated during copying (a jam in the original switchback/conveying section). Jam code 75 | Defective switch. | Run maintenance item U244 and turn switch on and off manually. Replace the switch if indication of the corresponding switch on the touch panel is not displayed in reverse. DP timing switch, original switchback switch |
| (25) A paper jam in optional document finisher is indicated during copying (jam between finisher and machine). Jam code 80 | Defective paper entry sensor. | With 5 V DC present at CN14-1 and CN14-3 on the finisher main PWB, check if CN14-2 and CN14-4 on the finisher main PWB remains low or high when the paper entry sensor is turned on and off. If it does, replace the paper entry sensor. |

| Problem | Causes/check procedures | Corrective measures |
|--|--|--|
| (26) A paper jam in optional document finisher is indicated during copying (paper jam during paper insertion to the finisher). Jam code 81 | Document finisher | |
| | Extremely curled paper. | Change the paper. |
| | Defective paper entry sensor. | With 5 V DC present at CN14-1 and CN14-3 on the finisher main PWB, check if CN14-2 and CN14-4 on the finisher main PWB remains low or high when the paper entry sensor is turned on and off. If it does, replace the paper entry sensor. |
| | Defective finisher main PWB. | Replace the finisher main PWB and check for correct operation. |
| | Built-in finisher | |
| | Extremely curled paper. | Change the paper. |
| | Defective paper conveying switch. | With 5 V DC present at YC2-23 on the finisher control PWB, check if YC2-21 on the finisher control PWB remains low or high when the paper conveying switch is turned on and off. If it does, replace the paper conveying switch. |
| | Check if the feedshift roller or feedshift pulley is deformed. | Check and remedy. |
| (27) A paper jam in optional document finisher is indicated during copying (finisher stapler jam). Jam code 82 | Document finisher | |
| | Defective staple home position sensor. | With 5 V DC present at CN10-2 on the finisher main PWB, check if CN10-5 on the finisher main PWB remains low or high. If it does, replace the stapler section. |
| | Built-in finisher | |
| | The stapler is blocked with a staple. | Remove the stapler cartridge, and check the cartridge and the stapling section of the stapler. Remove the staple if any. |
| | Defective stapler section. | With 5 V DC present at YC2-24 on the finisher control PWB, check if YC2-19 on the finisher control PWB remains low or high. If it does, replace the stapler section. |
| (28) A paper jam in optional document finisher is indicated during copying (eject sensor stay jam). Jam code 83 | Document finisher | |
| | Defective eject sensor. | With 5 V DC present at CN5-4 on the finisher main PWB, check if CN5-6 on the finisher main PWB remains low or high when the eject sensor is turned on and off. If it does, replace the eject sensor. |
| | Check if the paper conveying motor malfunctions. | Check and remedy. |
| | Check if the eject roller and eject pulley contact each other. | Check and remedy. |
| | Check if the eject guide is deformed. | Check and remedy. |
| | Defective finisher main PWB. | Replace the finisher main PWB and check for correct operation. |

| Problem | Causes/check procedures | Corrective measures |
|--|--|---|
| (28) A paper jam in optional document finisher is indicated during copying (eject sensor stay jam). Jam code 83 | Built-in finisher | |
| | Defective paper conveying switch. | With 5 V DC present at YC2-23 on the finisher control PWB, check if YC2-21 on the finisher control PWB remains low when the paper conveying switch is turned on and off. If it does, replace the paper conveying switch. |
| | Check if the eject roller or eject pulley is deformed. | Check and remedy. |
| (29) A paper jam in optional document finisher is indicated during copying (eject sensor non-arrival jam). Jam code 92 | Defective eject sensor. | With 5 V DC present at CN5-4 on the finisher main PWB, check if CN5-6 on the finisher main PWB remains low or high when the eject sensor is turned on and off. If it does, replace the eject sensor. |
| | Check if the paper conveying motor malfunctions. | Check. |
| | Check if the eject roller and eject pulley contact each other. | Check and remedy. |
| | Check if the eject guide is deformed. | Check and remedy. |
| | Defective finisher main PWB. | Replace the finisher main PWB and check for correct operation. |
| (30) A paper jam in optional document finisher is indicated during copying (reverse sensor jam). Jam code 93 | Defective reverse sensor. | With 5 V DC present at CN14-5 on the finisher main PWB, check if CN14-7 on the finisher main PWB remains low or high when the reverse sensor is turned on and off. If it does, replace the reverse sensor. |
| | Check if the reverse motor malfunctions. | Check. |
| | Check if the reverse roller and reverse pulley contact each other. | Check and remedy. |
| | Check if the reverse guide is deformed. | Check and remedy. |
| | Defective finisher main PWB. | Replace the finisher main PWB and check for correct operation. |
| (31) A paper jam in optional document finisher is indicated during copying (paper entry sensor stay jam). Jam code 94 | Extremely curled paper. | Change the paper. |
| | Defective paper entry sensor. | With 5 V DC present at CN14-1 and CN14-3 on the finisher main PWB, check if CN14-2 and CN14-4 on the main PCB remains low or high when the paper entry sensor is turned on and off. If it does, replace the paper entry sensor. |
| | Check if the paper entry guide is deformed. | Check and remedy. |
| | Defective finisher main PWB. | Replace the finisher main PWB and check for correct operation. |

| Problem | Causes/check procedures | Corrective measures |
|--|--|--|
| (32) A paper jam in optional document finisher is indicated during copying (paper conveying sensor jam). Jam code 95 | Defective paper conveying sensor. | With 5 V DC present at CN4-4 on the finisher main PWB, check if CN4-6 on the finisher main PWB remains low or high when the paper conveying sensor is turned on and off. If it does, replace the paper conveying sensor. |
| | Check if the paper conveying motor malfunctions. | Check. |
| | Check if the paper conveying roller and paper conveying pulley contact each other. | Check and remedy. |
| | Check if the paper conveying guide is deformed. | Check and remedy. |
| | Defective finisher main PWB. | Replace the finisher main PWB and check for correct operation. |
| (33) A paper jam in optional built-in finisher is indicated during copying (jam between finisher and machine). Jam code 96 | Defective paper conveying switch. | With 5 V DC present at YC2-23 on the finisher control PWB, check if YC2-21 on the finisher control PWB remains low when the paper conveying switch is turned on and off. If it does, replace the paper conveying switch. |
| | Check if the eject roller or eject pulley is deformed. | Check and remedy. |

1-4-2 Self-diagnosis

(1) Self-diagnostic function

This unit is equipped with a self-diagnostic function. When a problem is detected, copying is disabled and the problem displayed as a code consisting of C followed by a number, indicating the nature of the problem.

A message is also displayed requesting the user to call for service.

After removing the problem, the self-diagnostic function can be reset by turning the main power switch off and back on.

List of system errors

When an unexpected error is detected for some reason, a system error will be indicated. After a system error is indicated, the error can be cleared by turning the main power switch off and then on. If the error is detected continuously, however, perform the operation shown in Table 1-4-1. If a system error occurs frequently, a fault may have occurred. Check the details of the C call to take proper measures.

| System error | Contents | Operation |
|--------------|--|---|
| 0420 | Optional paper feeder communication problem | System error → service call → partial operation |
| 0440 | Optional document finisher/built-in finisher communication problem | System error → service call → partial operation |
| 0630 | DMA problem | System error → Normal service call processing |
| 4200 | BD steady-state problem | System error → Normal service call processing |
| 9000 | Optional DP communication problem | System error → service call → partial operation |

Table 1-4-1

In addition, it is a system error if the following error code is displayed. When an error has occurred, clear the error by turning the main power switch off then on.

CF1XX, CF2XX, CF3XX, CF4XX, CF5XX, CF6XX, CF7XX, CFAXX, CFBXX, 0xFBXX

Partial operation control

If any of the following calls for service is detected, partial operation control will be activated. After taking measures against the cause of trouble, run maintenance item U906 to reset partial operation control.

| Code | Contents |
|-------|--|
| C0420 | Optional paper feeder communication problem |
| C0440 | Optional document finisher/built-in finisher communication problem |
| C1010 | Upper lift motor error |
| C1020 | Lower lift motor error |
| C1030 | Paper feeder lift motor 1 error (optional paper feeder) |
| C1040 | Paper feeder lift motor 2 error (optional paper feeder) |
| C2600 | Paper feeder drive motor error (optional paper feeder) |
| C8030 | Tray upper limit detection problem (optional document finisher) |
| C8140 | Tray elevation motor problem (optional document finisher) |
| C8170 | Adjustment motor problem (optional document finisher) |
| | Finisher front side registration motor problem (optional built-in finisher) |
| C8180 | Finisher rear side registration motor problem (optional built-in finisher) |
| C8190 | Finisher trailing edge registration motor problem (optional built-in finisher) |
| C8210 | Stapler problem (optional document finisher) |
| | Finisher stapler problem (optional built-in finisher) |
| C8440 | Sensor adjusting problem (optional document finisher) |
| C8460 | EEPROM problem (optional document finisher) |
| C9000 | Optional DP communication problem |
| C9060 | DP EEPROM error (optional DP) |

Measures against the service codes detecting fuser problems

If one of the following service codes is detected, take actions to clear the cause of the trouble and perform maintenance item U163 to reset the service code.

| Code | Contents |
|-------|---|
| C6000 | Fuser heater break |
| C6020 | Abnormally high fuser thermistor center temperature |
| C6050 | Abnormally low fuser thermistor center temperature |
| C6120 | Abnormally high fuser thermistor edge temperature |
| C6150 | Abnormally low fuser thermistor edge temperature |
| C6400 | Zero-cross signal error |
| C6420 | Fuser unit fuse cut problem |

(2) Self diagnostic codes

| Code | Contents | Remarks | |
|--------------|--|--|--|
| | | Causes | Check procedures/corrective measures |
| C0030 | Fax control PWB system problem (optional fax) Processing with the fax software was disabled due to a hardware or software problem. | Defective fax control PWB. | Replace the fax control PWB and verify the operation. |
| C0060 | Main PWB type mismatch error | Defective PWB. | Run maintenance item U935 to contact the Service Administrative Division. |
| C0070 | Abnormal detection of fax control PWB incompatibility (optional fax) In the initial communication with the fax control PWB, any normal communication command is not transmitted. | Defective fax software. | Install the fax software. |
| | | Defective fax control PWB. | Replace the fax control PWB and verify the operation. |
| C0100 | Main PWB backup memory device problem Writing or erasing has not completed even after a certain time. | Defective main PWB. | Replace the main PWB and check for correct operation. |
| C0110 | Backup memory data problem Data in the specified area of the backup memory does not match the specified values. | Problem with the backup memory data. | Run maintenance item U020 to initialize the backup memory data (see page 1-3-10). |
| C0120 | Drum EEPROM error Reading from or writing to EEPROM cannot be performed. | Poor contact in the connector terminals. | Check the connection of connector on the engine PWB and the continuity across the connector terminals. Repair or replace if necessary. |
| | | Defective drum unit. | Replace the drum unit. |
| C0130 | Backup memory (EEPROM) device problem (Main PWB) Reading from or writing to EEPROM cannot be performed. | Defective main PWB. | Replace the main PWB and check for correct operation. |
| | | Device damage of EEPROM. | Contact the Service Administrative Division. |
| C0140 | Backup memory (EEPROM) data problem (Main PWB) Reading data from EEPROM is abnormal. | Data damage of EEPROM. | Contact the Service Administrative Division. |

| Code | Contents | Remarks | |
|--------------|---|--|---|
| | | Causes | Check procedures/corrective measures |
| C0150 | Backup memory (EEPROM) device problem (Engine PWB) Reading from or writing to EEPROM cannot be performed. | Defective engine PWB. | Replace the engine PWB and check for correct operation. |
| | | Device damage of EEPROM. | Contact the Service Administrative Division. |
| C0160 | Backup memory (EEPROM) data problem (Engine PWB) Reading data from EEPROM is abnormal. Read and write data does not match 5 times continuously. | Problem with the backup memory data. | Run maintenance item U022 to initialize the backup memory data. |
| | | Defective engine PWB. | If the C0160 is displayed after initializing the backup memory, replace the engine PWB and check for correct operation. |
| C0170 | Copy counts problem A checksum error is detected in the main and engine backup memories for the copy counters. | Data damage of EEPROM. | Contact the Service Administrative Division. |
| | | Defective PWB. | Replace the main PWB or engine PWB and check for correct operation. |
| C0180 | Machine number mismatch error Machine number of main PWB and engine PWB does not match. | Data damage of EEPROM. | Contact the Service Administrative Division. |
| C0210 | CPU communication problem There is no reply after 3 retries at communication. | Poor contact in the connector terminals. | Check the connection of the engine PWB and main PWB, and the continuity across the connector terminals. Repair or replace if necessary. |
| | | Defective PWB. | Replace the engine PWB or main PWB and check for correct operation. |
| C0240 | Printer PWB communication problem The printer PWB does not respond 120 s after the power is turned on. | Poor contact in the connector terminals. | Check the connection of the interface PWB and the printer PWB, and the continuity across the connector terminals. Repair or replace if necessary. |
| | | DIMM or DDR installed incorrectly. | Check the connection of DIMM or DDR. Repair or replace if necessary. |
| | | Defective PWB. | Replace the printer PWB or engine PWB and check for correct operation. |
| C0280 | Communication problem between the fax control PWB and main PWB After main PWB status change signal turns on 3 minute, when it does not receive key required command from the fax control PWB, one time it resets the FAX. After that, while main PWB status change signal turns on furthermore 1 minute, when it does not receive key required command from the fax control PWB. When FAX_READY signal continues fake for 6 s, one time it resets the FAX. After that, when FAX_READY fake continues fake for 6 s. | Poor contact in the connector terminals. | Check the connection of the main PWB and the fax control PWB, and the continuity across the connector terminals. Repair or replace if necessary. |
| | | Defective PWB. | Replace the fax control PWB or main PWB and check for correct operation. |
| C0320 | Power CPU communication problem The engine PWB and the power CPU are unable to communicate with each other. | Defective engine PWB. | Replace the engine PWB and check for correct operation. |

| Code | Contents | Remarks | |
|--------------|--|--|---|
| | | Causes | Check procedures/corrective measures |
| C0420 | Optional paper feeder communication problem The engine PWB and the paper feeder are unable to communicate with each other. | Poor contact in the connector terminals. | Check the connection of connector YC22 on the engine PWB and the connector on the paper feeder main PWB, and the continuity across the connector terminals. Repair or replace if necessary. |
| | | Defective PWB. | Replace the engine PWB or paper feeder main PWB and check for correct operation. |
| C0440 | Optional document finisher/built-in finisher communication problem The engine PWB and the document finisher or the built-in finisher are unable to communicate with each other. | Poor contact in the connector terminals. | Check the connection of connector YC5 on the engine PWB and the connector of the document finisher, and the continuity across the connector terminals. Repair or replace if necessary. |
| | | | Check the connection of connector YC4 on the engine PWB and the connector of the built-in finisher, and the continuity across the connector terminals. Repair or replace if necessary. |
| | | Defective PWB. | Replace the engine PWB or finisher main PWB and check for correct operation. |
| C0610 | Bitmap problem The DIMM on the main PWB does not operate correctly. | Defective main PWB. | Replace the main PWB and check for correct operation. |
| | | DDR on the main PWB installed incorrectly. | Check the connection. Repair or replace if necessary. |
| C0630 | DMA problem DMA transmission of compressed, decompressed, rotated, relocated or blanked-out image data does not complete within the specified period of time. | Defective main PWB. | Replace the main PWB and check for correct operation. |
| | | DDR on the main PWB installed incorrectly. | Check the connection. Repair or replace if necessary. |
| C0800 | Image processing problem JAM05 is detected twice. | Defective main PWB. | Replace the main PWB and check for correct operation. |
| C0820 | Fax control PWB CG ROM checksum error (optional fax) A checksum error occurred with the CG ROM data of the fax control PWB. | Defective fax software. | Install the fax software. |
| | | Defective fax control PWB. | Replace the fax control PWB and verify the operation. |
| C0830 | Fax control PWB flash program area checksum error (optional fax) A checksum error occurred with the program of the fax control PWB. | Defective fax software. | Install the fax software. |
| | | Defective fax control PWB. | Replace the fax control PWB and verify the operation. |
| C0860 | Fax control PWB software switch checksum error (optional fax) A checksum error occurred with the software switch value of the fax control PWB. | Defective fax software. | Install the fax software. |
| | | Defective fax control PWB. | Replace the fax control PWB and verify the operation. |
| C0870 | Fax control PWB to main PWB high capacity data transfer problem High-capacity data transfer between the fax control PWB and the scanner MIP PWB was not normally performed even if the data transfer was retried 10 times. | Poor contact in the connector terminals. | Check the connection of the main PWB and the fax control PWB, and the continuity across the connector terminals. Repair or replace if necessary. |
| | | Defective PWB. | Replace the fax control PWB or main PWB and check for correct operation. |

| Code | Contents | Remarks | |
|--------------|---|--|---|
| | | Causes | Check procedures/corrective measures |
| C0880 | Program archive problem (optional fax) When power is turned on, the compressed program in the Flash ROM on the fax control PWB was not successfully decompressed. | Defective fax software. | Install the fax software. |
| | | Defective fax control PWB. | Replace the fax control PWB and verify the operation. |
| C0890 | Fax control PWB CG FONT archive problem (optional fax) When power is turned on, the compressed CG font in the Flash ROM on the fax control PWB was not successfully decompressed. | Defective fax software. | Install the fax software. |
| | | Defective fax control PWB. | Replace the fax control PWB and verify the operation. |
| C0920 | Fax file system error The backup data is not retained for file system abnormality of flash memory of the fax control PWB. | Defective fax control PWB. | Replace the fax control PWB and verify the operation. |
| C0960 | Developing unit EEPROM error Reading from or writing to EEPROM cannot be performed. | Poor contact in the connector terminals. | Check the connection of connector on the engine PWB and the continuity across the connector terminals. Repair or replace if necessary. |
| | | Defective developing unit. | Replace the developing unit. |
| C1010 | Upper lift motor error When cassette 1 is inserted, upper lift limit switch does not turn on within 12 s of upper lift motor turning on. | Poor contact in the connector terminals. | Check the connection of connector of upper lift motor and the connector YC23 on the engine PWB, and the continuity across the connector terminals. Repair or replace if necessary. |
| | | Broken gears or couplings of upper lift motor. | Replace upper lift motor. |
| | | Defective upper lift motor. | Check for continuity across the coil. If none, replace upper lift motor. |
| | | Defective upper lift limit switch. | Check if YC23-B9 on the engine PWB goes low when upper lift limit switch is turned off. If not, replace upper lift limit switch. |
| | | Poor contact in the connector terminals. | Check the connection of connector of upper lift limit switch and the connector YC23 on the engine PWB, and the continuity across the connector terminals. Repair or replace if necessary. |
| | | Defective engine PWB. | Replace the engine PWB and check for correct operation. |

| Code | Contents | Remarks | |
|--------------|--|---|---|
| | | Causes | Check procedures/corrective measures |
| C1020 | Lower lift motor error When cassette 2 is inserted, lower lift limit switch does not turn on within 12 s of lower lift motor turning on. | Poor contact in the connector terminals. | Check the connection of connector of lower lift motor and the connector YC23 on the engine PWB, and the continuity across the connector terminals. Repair or replace if necessary. |
| | | Broken gears or couplings of lower lift motor. | Replace lower lift motor. |
| | | Defective lower lift motor. | Check for continuity across the coil. If none, replace lower lift motor. |
| | | Defective lower lift limit switch. | Check if YC23-A2 on the engine PWB goes low when lower lift limit switch is turned off. If not, replace lower lift limit switch. |
| | | Poor contact in the connector terminals. | Check the connection of connector of lower lift limit switch and the connector YC23 on the engine PWB, and the continuity across the connector terminals. Repair or replace if necessary. |
| | | Defective engine PWB. | Replace the engine PWB and check for correct operation. |
| C1030 | Paper feeder lift motor 1 error (optional paper feeder) When optional cassette 3 is inserted, paper feeder lift switch 1 does not turn on within 12 s of paper feeder lift motor 1 turning on. | Poor contact in the connector terminals. | Check the connection of connector YC22 on the engine PWB and the connector on the paper feeder main PWB, and the continuity across the connector terminals. Repair or replace if necessary. |
| | | Broken gears or couplings of paper feeder lift motor 1. | Replace paper feeder lift motor 1. |
| | | Defective paper feeder lift motor 1. | Check for continuity across the coil. If none, replace paper feeder lift motor 1. |
| | | Defective paper feeder lift switch 1. | Check if YC1-5 on the paper feeder main PWB goes low when paper feeder lift switch 1 is turned off. If not, replace paper feeder lift switch 1. |
| C1040 | Paper feeder lift motor 2 error (optional paper feeder) When optional cassette 4 is inserted, paper feeder lift switch 2 does not turn on within 12 s of paper feeder lift motor 2 turning on. | Poor contact in the connector terminals. | Check the connection of connector YC22 on the engine PWB and the connector on the paper feeder main PWB, and the continuity across the connector terminals. Repair or replace if necessary. |
| | | Broken gears or couplings of paper feeder lift motor 2. | Replace paper feeder lift motor 2. |
| | | Defective paper feeder lift motor 2. | Check for continuity across the coil. If none, replace paper feeder lift motor 2. |
| | | Defective paper feeder lift switch 2. | Check if YC1-7 on the paper feeder main PWB goes low when paper feeder lift switch 2 is turned off. If not, replace paper feeder lift switch 2. |

| Code | Contents | Remarks | |
|--------------|--|--|--|
| | | Causes | Check procedures/corrective measures |
| C2000 | Main motor problem Stable OFF is detected for 1 s continuously after main motor stability. | Poor contact in the connector terminals. | Check the connection of connector YC10 on the engine PWB and the connector on the main motor, and the continuity across the connector terminals. Repair or replace if necessary. |
| | | Defective drive transmission system. | Check if the rollers and gears rotate smoothly. If not, grease the bushings and gears. Check for broken gears and replace if any. |
| | | Defective engine PWB. | Replace the engine PWB and check for correct operation. |
| | | Defective main motor. | Replace the main motor. |
| C2200 | Drum motor problem Stable OFF is detected for 1 s continuously after drum motor stability. | Poor contact in the connector terminals. | Check the connection of connector YC10 on the engine PWB and the connector on the drum motor, and the continuity across the connector terminals. Repair or replace if necessary. |
| | | Defective drive transmission system. | Check if the rollers and gears rotate smoothly. If not, grease the bushings and gears. Check for broken gears and replace if any. |
| | | Defective engine PWB. | Replace the engine PWB and check for correct operation. |
| | | Defective drum motor. | Replace the drum motor. |
| C2500 | Paper feed motor error Stable OFF is detected for 1 s continuously after paper feed motor stability. | Poor contact in the connector terminals. | Check the connection of connector YC10 on the engine PWB and the connector on the paper feed motor, and the continuity across the connector terminals. Repair or replace if necessary. |
| | | Defective drive transmission system. | Check if the rollers and gears rotate smoothly. If not, grease the bushings and gears. Check for broken gears and replace if any. |
| | | Defective engine PWB. | Replace the engine PWB and check for correct operation. |
| | | Defective paper feed motor. | Replace the paper feed motor. |

| Code | Contents | Remarks | |
|--------------|---|--|--|
| | | Causes | Check procedures/corrective measures |
| C2600 | Paper feeder drive motor error (optional paper feeder) The lock signal of the motor is detected above 500 ms. | Poor contact in the connector terminals. | Check the connection of connector YC22 on the engine PWB and the connector on the paper feeder main PWB, and the continuity across the connector terminals. Repair or replace if necessary. |
| | | Paper feeder drive motor does not rotate correctly (the motor is over-loaded). | Check the gears and remedy if necessary. |
| | | Defective PWB. | Replace the paper feeder main PWB or engine PWB and check for correct operation. |
| | | Defective paper feeder drive motor. | Replace the paper feeder drive motor. |
| C3100 | Scanner carriage problem The home position is not correct when the power is turned on or at the start of copying using the table. | Poor contact in the connector terminals. | Check the connection of connector YC17 on the engine PWB and the connector on the scanner home position switch, and the continuity across the connector terminals. Repair or replace if necessary. |
| | | Defective scanner home position switch. | Replace the scanner home position switch. |
| | | Defective scanner motor. | Replace the scanner motor. |
| | | The mirror frame, exposure lamp, or scanner wire is defective. | Check if the mirror frames and exposure lamp are on the rail. And check the scanner wire winds correctly. |
| | | Defective engine PWB. | Replace the engine PWB and check for correct operation. |
| C3200 | Exposure lamp problem After the reading starting, when input value at the time of exposure lamp illumination does not exceed the threshold value between 5 s. | Poor contact in the connector terminals. | Check the connection of connector YC16 on the engine PWB and the connector on the inverter PWB, and the continuity across the connector terminals. Repair or replace if necessary. |
| | | Defective exposure lamp. | Replace the exposure lamp. |
| | | Incorrect shading position. | Adjust the position of the platen (shading plate). If the problem still occurs, replace the scanner home position switch. |
| | | Defective PWB. | Replace the engine PWB or scanner inverter PWB and check for correct operation. |

| Code | Contents | Remarks | |
|--------------|---|---|--|
| | | Causes | Check procedures/corrective measures |
| C3300 | CCD AGC problem After AGC, correct input is not obtained at CCD. | Poor contact in the connector terminals. | Check the connection of connector YC4 on the main PWB and the connector on the CCD PWB, and the continuity across the connector terminals. Repair or replace if necessary. |
| | | Defective exposure lamp. | Replace the exposure lamp. |
| | | Defective PWB. | Replace the main PWB or CCD PWB and check for correct operation. |
| C4000 | Polygon motor synchronization problem The polygon motor does not reach the stable speed within 20 s of the START signal turning on. | Poor contact in the connector terminals. | Check the connection of connector YC2 on the engine PWB and laser scanner unit, and the continuity across the connector terminals. Repair or replace if necessary. |
| | | Defective polygon motor. | Replace the laser scanner unit. |
| | | Defective engine PWB. | Replace the engine PWB and check for correct operation. |
| C4010 | Polygon motor steady-state problem Stable OFF is detected for 5 s continuously after polygon motor stability. | Poor contact in the connector terminals. | Check the connection of connector YC2 on the engine PWB and laser scanner unit, and the continuity across the connector terminals. Repair or replace if necessary. |
| | | Defective polygon motor. | Replace the laser scanner unit. |
| | | Defective engine PWB. | Replace the engine PWB and check for correct operation. |
| C4200 | BD steady-state problem ASIC detects a BD error for 1 s after the polygon motor rotation has been stabilized. | Poor contact in the connector terminals. | Check the connection of connector YC2 on the engine PWB and laser scanner unit, and the continuity across the connector terminals. Repair or replace if necessary. |
| | | Defective laser scanner unit. | Replace the laser scanner unit. |
| | | Defective engine PWB. | Replace the engine PWB and check for correct operation. |
| C6000 | Fuser heater break Fuser thermistor 1 detected less than 40°C/104°F for 10 s during warm-up and ready in. | Defective fuser heater M or S. | Replace the fuser heater M or S. |
| | | Installation defectiveness on fuser thermistor 1. | Check the mounting state of the fuser thermistor 1. If any problem is found, repair it. |
| | | Defective fuser thermostat. | Replace the fuser thermostat. |
| | | Defective PWB. | Replace the power source PWB or engine PWB and check for correct operation. |

| Code | Contents | Remarks | |
|-------|--|---|--|
| | | Causes | Check procedures/corrective measures |
| C6020 | Abnormally high fuser thermistor center temperature Fuser thermistor 2 is detected 230°C/ 446°F or more for 40 ms. | Installation defectiveness on fuser thermistor 2. | Check the mounting state of the fuser thermistor 2. If any problem is found, repair it. |
| | | Defective fuser thermistor 2. | Replace the fuser thermistor 2. |
| | | Defective engine PWB. | Replace the engine PWB and check for correct operation. |
| C6050 | Abnormally low fuser thermistor center temperature Fuser thermistor 2 is detected 100°C/ 212°F less than 1 s continuously during copying. | Defective fuser heater M or S. | Replace the fuser heater M or S. |
| | | Installation defectiveness on fuser thermistor 2. | Check the mounting state of the fuser thermistor 2. If any problem is found, repair it. |
| | | Defective PWB. | Replace the power source PWB or engine PWB and check for correct operation. |
| C6120 | Abnormally high fuser thermistor edge temperature Fuser thermistor 1 is detected 230°C/ 446°F or more for 40 ms. | Installation defectiveness on fuser thermistor 1. | Check the mounting state of the fuser thermistor 1. If any problem is found, repair it. |
| | | Defective fuser thermistor 1. | Replace the fuser thermistor 1. |
| | | Defective engine PWB. | Replace the engine PWB and check for correct operation. |
| C6150 | Abnormally low fuser thermistor edge temperature Fuser thermistor 1 is detected 100°C/ 212°F less than 1 s continuously during copying. | Defective fuser heater M or S. | Replace the fuser heater M or S. |
| | | Installation defectiveness on fuser thermistor 1. | Check the mounting state of the fuser thermistor 1. If any problem is found, repair it. |
| | | Defective PWB. | Replace the power source PWB or engine PWB and check for correct operation. |
| C6400 | Zero-cross signal error While fuser heater ON/OFF control is performed, the zero-cross signal is not input within 3 s. | Defective PWB. | Replace the engine PWB or power source PWB and check for correct operation. |
| C6420 | Fuser unit fuse cut problem The fuse cannot be cut, When replacing the fuser unit, the fuse cannot be cut in 3 s after the fuse cut signal is turned on. | Poor contact in the connector terminals. | Check the connection of connector YC1 on the engine PWB and the continuity across the connector terminals. Repair or replace if necessary. |
| | | Fuser unit connector inserted incorrectly. | Reinsert the fuser unit connector if necessary. |


| Code | Contents | Remarks | |
|--------------|---|---|---|
| | | Causes | Check procedures/corrective measures |
| C7000 | Toner motor problem A motor over-current signal is detected continuously for 1 s or longer. | Poor contact in the connector terminals. | Check the connection of connector YC1 on the engine PWB and the connector on the toner feed motor, and the continuity across the connector terminals. Repair or replace if necessary. |
| | | Broken the gear. | Check visually and replace the gear if necessary. |
| | | Defective toner feed motor. | Run maintenance item U135 and check if the toner feed motor operates. If not, replace the toner feed motor. |
| | | Defective engine PWB. | Replace the engine PWB and check for correct operation. |
| C7200 | Broken inner thermistor wire An abnormal value is detected in the input data to inner thermistor. | Poor contact in the connector terminals. | Check the connection of connector YC32 on the engine PWB and the continuity across the connector terminals. Repair or replace if necessary. |
| | | Defective temperature sensor. | Replace the temperature sensor. |
| C7300 | Toner hopper problem Toner emptiness is detected for 300 s, three times during the toner replenishment. | Poor contact in the connector terminals. | Check the connection of connector YC1 on the engine PWB and the continuity across the connector terminals. Repair or replace if necessary. |
| | | Defective toner sensor. | Replace the developing unit. |
| C7400 | Developing unit connector insertion problem Absence of the developing unit is detected. | Developing unit connector inserted incorrectly. | Reinsert the developing unit connector if necessary. |
| | | Defective developing unit connector. | Replace the developing unit. |
| C7410 | Drum unit connector insertion problem Absence of the drum unit is detected. | Drum unit connector inserted incorrectly. | Reinsert the drum unit connector if necessary. |
| | | Defective drum unit connector. | Replace the drum unit. |
| C7800 | Broken external thermistor wire The thermistor output value is 4.5 V or more. | Poor contact in the connector terminals. | Check the connection of connector YC1 on the engine PWB and the continuity across the connector terminals. Repair or replace if necessary. |
| | | Defective humidity sensor. | Replace the humidity sensor. |

| Code | Contents | Remarks | |
|-------|---|---|---|
| | | Causes | Check procedures/corrective measures |
| C8030 | Tray upper limit detection problem (optional document finisher) When the tray elevation motor raises a tray, the ON status of the tray upper limit sensor is detected. | The tray upper limit sensor/push paper sensor/surface view sensor connector makes poor contact. | Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable. |
| | | Defective tray upper limit sensor/push paper sensor/surface view sensor. | Replace the sensor. |
| | | Defective finisher main PWB. | Replace the finisher main PWB and check for correct operation. |
| C8140 | Tray elevation motor problem (optional document finisher) When the tray elevation motor is driving, the ON status of the tray lower limit sensor or surface view sensor cannot be detected even if 20 s passed. | The tray elevation motor connector makes poor contact. | Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable. |
| | | The tray elevation motor malfunctions. | Replace the tray elevation motor. |
| | | The tray lower limit sensor/push paper sensor/surface view sensor connector makes poor contact. | Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable. |
| | | Defective tray lower limit sensor/push paper sensor/surface view sensor. | Replace the sensor. |
| | | Defective finisher main PWB. | Replace the finisher main PWB and check for correct operation. |

| Code | Contents | Remarks | |
|-------|---|--|---|
| | | Causes | Check procedures/corrective measures |
| C8170 | Adjustment motor problem (optional document finisher) When the adjustment motor is driving, the ON status of the adjustment home position sensor cannot be detected even if a specified time has elapsed. When adjustment operation starts, the ON status of the adjustment home position sensor is not detected. | The adjustment motor connector makes poor contact. | Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable. |
| | | Defective adjustment motor. | Replace adjustment motor. |
| | | The adjustment home position sensor connector makes poor contact. | Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable. |
| | | Defective adjustment home position sensor. | Replace the adjustment home position sensor. |
| | | Defective finisher main PWB. | Replace the finisher main PWB and check for correct operation. |
| | Finisher front side registration motor problem (optional built-in finisher) When the front-side registration home-position sensor is turned on during initialization, the sensor did not turn on while it has moved by 106 pulses. When the front-side registration home-position sensor is turned off during initialization, the sensor did not turn on in 3 s. | The front side registration motor connector makes poor contact. | Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable. |
| | | Defective front side registration motor. | Replace front side registration motor. |
| | | The front side registration home position sensor connector makes poor contact. | Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable. |
| | | Defective front side registration home position sensor. | Replace the front side registration home position sensor. |
| | | Defective finisher control PWB. | Replace the finisher control PWB and check for correct operation. |
| | | | |
| C8180 | Finisher rear side registration motor problem (optional built-in finisher) When the rear-side registration home-position sensor is turned on during initialization, the sensor did not turn on while it has moved by 106 pulses. When the rear-side registration home-position sensor is turned off during initialization, the sensor did not turn on in 3 s. | The rear side registration motor connector makes poor contact. | Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable. |
| | | Defective rear side registration motor. | Replace rear side registration motor. |
| | | The rear side registration home position sensor connector makes poor contact. | Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable. |
| | | Defective rear side registration home position sensor. | Replace the rear side registration home position sensor. |
| | | Defective finisher control PWB. | Replace the finisher control PWB and check for correct operation. |

| Code | Contents | Remarks | |
|-------|---|---|---|
| | | Causes | Check procedures/corrective measures |
| C8190 | Finisher trailing edge registration motor problem (optional built-in finisher) When the trailing edge registration home-position sensor is turned on during initialization, the sensor did not turn on while it has moved by 106 pulses. When the trailing edge registration home-position sensor is turned off during initialization, the sensor did not turn on in 3 s. | The trailing edge registration motor connector makes poor contact. | Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable. |
| | | Defective trailing edge registration motor. | Replace trailing edge registration motor. |
| | | The trailing edge registration home position sensor connector makes poor contact. | Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable. |
| | | Defective trailing edge registration home position sensor. | Replace the trailing edge registration home position sensor. |
| | | Defective finisher control PWB. | Replace the finisher control PWB and check for correct operation. |
| C8210 | Stapler problem (optional document finisher) When the stapler motor is driving, the ON status of the stapler home position sensor cannot be detected even if a specified time has elapsed. | The stapler connector makes poor contact. | Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable. |
| | | The stapler is blocked with a staple. | Remove the stapler cartridge, and check the cartridge and the stapling section of the stapler. |
| | | The stapler is broken. | Replace the stapler and check for correct operation. |
| | | Defective finisher main PWB. | Replace the finisher main PWB and check for correct operation. |
| | Finisher stapler problem (optional built-in finisher) The stapler home position sensor does not change state from nondetection to detection within 200 ms of the start of stapler motor counterclockwise (forward) rotation. During initialization, the stapler home position sensor does not change state from non-detection to detection within 600 ms of the start of stapler motor clockwise (reverse) rotation. | The stapler connector makes poor contact. | Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable. |
| | | The stapler is blocked with a staple. | Remove the stapler cartridge, and check the cartridge and the stapling section of the stapler. |
| | | The stapler is broken. | Replace the front stapler and check for correct operation. |
| | | Defective finisher control PWB. | Replace the finisher control PWB and check for correct operation. |

| Code | Contents | Remarks | |
|--------------|--|--|---|
| | | Causes | Check procedures/corrective measures |
| C8440 | Sensor adjusting problem (optional document finisher) The sensor cannot be adjusted within the specified range. | The paper entry sensor connector makes poor contact. | Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable. |
| | | Defective paper entry sensor. | Replace the paper entry sensor and check for correct operation. |
| | | The optical path of the paper entry sensor is blocked by foreign matter. | Remove the foreign matter. |
| | | Defective finisher main PWB. | Replace the finisher main PWB and check for correct operation. |
| C8460 | EEPROM problem (optional document finisher) Reading from or writing to EEPROM cannot be performed. | Defective EEPROM or finisher main PWB. | Replace the finisher main PWB and check for correct operation. |
| C9000 | Optional DP communication problem A communication error is detected. | Poor contact in the connector terminals. | Check the connection of connector YC24 and YC31 on the engine PWB and the connector of the DP, and the continuity across the connector terminals. Repair or replace if necessary. |
| | | Defective DP main PWB. | Replace the DP main PWB and check for correct operation. |
| C9060 | DP EEPROM error (optional DP) Read and write data does not match. Data in the specified area of the backup memory does not match the specified values. | Defective DP main PWB. | Replace the DP main PWB and check for correct operation. |
| | | Device damage of EEPROM. | Contact the Service Administrative Division. |
| F000 | Operation panel PWB communication error | Defective main PWB. | Replace the main PWB and check for correct operation. |
| | | Defective operation panel PWB. | Replace the operation panel PWB and check for correct operation. |
| F010 | Main PWB checksum error | Defective main PWB. | Replace the main PWB and check for correct operation. |
| F020 | Memory checksum error | Defective main PWB. | Replace the main PWB and check for correct operation. |
| | | Defective expansion memory. | Replace the expansion memory and check for correct operation. |
| F030 | Main PWB system error | Defective main PWB. | Replace the main PWB and check for correct operation. |
| F040 | Engine PWB communication error | Defective main PWB. | Replace the main PWB and check for correct operation. |
| | | Defective engine PWB. | Replace the engine PWB and check for correct operation. |
| F041 | Scanner communication error | Defective main PWB. | Replace the main PWB and check for correct operation. |
| F050 | Engine ROM checksum error | Defective engine PWB. | Replace the engine PWB and check for correct operation. |

| Code | Contents | Remarks | |
|---|---------------------------------------|-----------------------------|---|
| | | Causes | Check procedures/corrective measures |
| F060 | Engine RAM error | Defective engine PWB. | Replace the engine PWB and check for correct operation. |
| F070 | Flash ROM error | Defective flash ROM. | Replace the engine PWB and check for correct operation. |
| F080 | Flash ROM error (during download) | Defective flash ROM. | Replace the engine PWB and check for correct operation. |
| F090 | Fax control PWB communication error | Defective main PWB. | Replace the main PWB and check for correct operation. |
| F14F | Power source PWB secondary side error | Defective power source PWB. | Replace the power source PWB and check for correct operation. |
|  | | | |

1-4-3 Image formation problems

(1) No image appears
(entirely white).



See page 1-4-35.

(2) No image appears
(entirely black).



See page 1-4-35.

(3) Image is too light.



See page 1-4-36.

(4) Background is visible.




See page 1-4-36.

(5) A white line
appears longitudinally.



See page 1-4-36.

(6) A black line
appears longitudinally.



See page 1-4-37.

(7) A black line
appears laterally.



See page 1-4-37.

(8) One side of the
copy image is
darker than the
other.



See page 1-4-37.

(9) Black dots appear
on the image.



See page 1-4-37.

(10) Image is blurred.




See page 1-4-38.

(11) The leading edge
of the image is
consistently mis-
aligned with the
original.




See page 1-4-38.

(12) The leading edge
of the image is
sporadically mis-
aligned with the
original.




See page 1-4-38.

(13) Paper creases.



See page 1-4-38.

(14) Offset occurs.




See page 1-4-39.

(15) Image is partly
missing.



See page 1-4-39.

(16) Fusing is poor.



See page 1-4-39.

(17) Image is out of
focus.




See page 1-4-39.

(18) Image center
does not align with
the original center.




See page 1-4-40.


(1) No image appears (entirely white).

| Copy example | Causes | | Check procedures/corrective measures |
|---|----------------------------|--|--|
|  | No transfer charging. | The connector terminals of the high voltage PWB make poor contact. | Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable. |
| | | Defective engine PWB. | Check if YC12-11 on the engine PWB goes low when maintenance item U101 is run. If not, replace the engine PWB. |
| | | Defective high voltage PWB. | Check if transfer charging takes place when CN1-2 on the high voltage PWB goes low while maintenance item U101 is run. If not, replace the high voltage PWB. |
| | No LSU laser is output. | Defective laser scanner unit. | Replace the laser scanner unit (see page 1-5-30). |
| | | Defective main PWB. | Check if YC5-3 on the main PWB goes low when maintenance item U100 is run. If not, replace the main PWB. |
| | No developing bias output. | The connector terminals of the high voltage PWB make poor contact. | Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable. |
| | | Defective engine PWB. | Check if YC12-2 on the engine PWB goes low when maintenance item U101 is run. If not, replace the engine PWB. |
| | | Defective high voltage PWB. | Check if developing bias is output when CN1-11 on the high voltage PWB goes low while maintenance item U101 is run. If not, replace the high voltage PWB. |


(2) No image appears (entirely black).

| Copy example | Causes | | Check procedures/corrective measures |
|---|-------------------------------|--|---|
|  | No main charging. | Broken main charger wire. | Replace the main charger unit (see page 1-5-37). |
| | | Leaking main charger housing. | Clean the main charger wire and grid. |
| | | The connector terminals of the high voltage PWB make poor contact. | Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable. |
| | | Defective engine PWB. | Check if YC12-5 on the engine PWB goes low when maintenance item U100 is run. If not, replace the engine PWB. |
| | | Defective high voltage PWB. | Check if main charging takes place when CN1-8 on the high voltage PWB goes low while maintenance item U100 is run. If not, replace the high voltage PWB. |
| | Exposure lamp fails to light. | Poor contact in the exposure lamp connector terminals. | Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable. |
| | | Defective scanner inverter PWB. | Check if the exposure lamp lights when YC1-1 and YC1-6 on the scanner inverter PWB goes low while maintenance item U061 is run. If not, replace the scanner inverter PWB. |
| | | Defective engine PWB. | Check if YC16-1 and YC16-6 on the engine PWB goes low when maintenance item U061 is run. If not, replace the engine PWB. |


(3) Image is too light.

| Copy example | Causes | | Check procedures/corrective measures |
|---|-------------------------------------|--|--|
|  | Insufficient toner. | | If the display shows the message requesting toner replenishment, replace the container. |
| | Deteriorated toner. | | Perform the drum refresh operation. |
| | Defective transfer charging output. | The connector terminals of the high voltage PWB make poor contact. | Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable. |
| | | Defective engine PWB. | Check if YC12-11 on the engine PWB goes low when maintenance item U101 is run. If not, replace the engine PWB. |
| | Defective high voltage PWB. | | Check if transfer charging takes place when CN1-2 on the high voltage PWB goes low while maintenance item U101 is run. If not, replace the high voltage PWB. |


(4) Background is visible.

| Copy example | Causes | Check procedures/corrective measures |
|--|--------------------------|--|
|  | Deteriorated toner. | Perform the drum refresh operation. |
| | Dirty main charger wire. | Clean the wire or, if it is extremely dirty, replace it (see page 1-5-37). |


(5) A white line appears longitudinally.

| Copy example | Causes | Check procedures/corrective measures |
|---|--|---|
|  | Foreign matter in the developing unit. | Check if the magnetic brush is formed uniformly. Replace the developing unit if any foreign matter (see page 1-5-39). |
| | Dirty shading plate. | Clean the shading plate. |


(6) A black line appears longitudinally.

| Copy example | Causes | Check procedures/corrective measures |
|---|----------------------------------|---|
|  | Dirty platen. | Clean the platen. |
| | Dirty or flawed drum. | Perform the drum refresh operation. If the drum is flawed, replace the drum unit (see page 1-5-35). |
| | Deformed or worn cleaning blade. | Replace the drum unit (see page 1-5-35). |
| | Dirty scanner mirror. | Clean the scanner mirror. |
| | Dirty main charger wire. | Clean the wire or, if it is extremely dirty, replace it (see page 1-5-37). |


(7) A black line appears laterally.

| Copy example | Causes | Check procedures/corrective measures |
|---|-------------------------------|---|
|  | Flawed drum. | Replace the drum unit (see page 1-5-35). |
| | Dirty developing section. | Clean any part contaminated with toner in the developing section. |
| | Leaking main charger housing. | Clean the main charger wire and grid. |
| | Leaking separation electrode. | Clean the separation electrode. |


(8) One side of the copy image is darker than the other.

| Copy example | Causes | Check procedures/corrective measures |
|---|--------------------------|--|
|  | Dirty main charger wire. | Clean the wire or, if it is extremely dirty, replace it (see page 1-5-37). |
| | Defective exposure lamp. | Check if the exposure lamp light is distributed evenly. If not, replace the exposure lamp (see page 1-5-15). |


(9) Black dots appear on the image.

| Copy example | Causes | Check procedures/corrective measures |
|---|---|---|
|  | Dirty or flawed drum. | Perform the drum refresh operation. If the drum is flawed, replace the drum unit (see page 1-5-35). |
| | Dirty platen. | Clean the platen. |
| | Deformed or worn cleaning blade. | Replace the drum unit (see page 1-5-35). |
| | Dirty drum separation claws. | Clean the drum separation claws. |
| | Dirty the heat roller separation claws. | Clean the heat roller separation claws. |


(10) Image is blurred.

| Copy example | Causes | Check procedures/corrective measures |
|---|--|--|
|  | Scanner moves erratically. | Check if there is any foreign matter on the front and rear scanner rails. If any, remove it. |
| | Deformed press roller. | Replace the press roller (see page 1-5-45). |
| | Paper conveying section drive problem. | Check the gears and belts and, if necessary, grease them. |


(11) The leading edge of the image is consistently misaligned with the original.

| Copy example | Causes | Check procedures/corrective measures |
|---|--|--|
|  | Misadjusted leading edge registration. | Run maintenance mode U034 to readjust the leading edge registration (see page 1-3-12). |
| | Misadjusted scanner leading edge registration. | Run maintenance mode U066 to readjust the scanner leading edge registration (see page 1-3-19). |


(12) The leading edge of the image is sporadically misaligned with the original.

| Copy example | Causes | Check procedures/corrective measures |
|---|---|--|
|  | Feed clutch, paper feed clutch, MP paper feed clutch or registration clutch installed or operating incorrectly. | Check the installation position and operation of each clutch. If any of them operates incorrectly, replace it. |


(13) Paper creases.

| Copy example | Causes | Check procedures/corrective measures |
|---|-----------------------------|---|
|  | Paper curled. | Check the paper storage conditions. |
| | Paper damp. | Check the paper storage conditions. |
| | Defective pressure springs. | Replace the pressure springs. |
| | Defective separation. | Check the drum separation claws and heat roller separation claws. |


(14) Offset occurs.

| Copy example | Causes | Check procedures/corrective measures |
|---|---------------------------|---|
|  | Defective cleaning blade. | Replace the drum unit (see page 1-5-35). |
| | Defective fuser unit. | Check the heat roller and press roller. |
| | Wrong types of paper. | Check if the paper meets specifications. Replace paper. |


(15) Image is partly missing.

| Copy example | Causes | Check procedures/corrective measures |
|---|-----------------------|---|
|  | Paper damp. | Check the paper storage conditions. |
| | Paper creased. | Change the paper. |
| | Drum condensation. | Perform the drum refresh operation. |
| | Dirty or flawed drum. | Perform the drum refresh operation. If the drum is flawed, replace the drum unit (see page 1-5-35). |


(16) Fusing is poor.

| Copy example | Causes | Check procedures/corrective measures |
|---|-----------------------------|---|
|  | Wrong types of paper. | Check if the paper meets specifications. Replace paper. |
| | Defective pressure springs. | Replace the pressure springs. |
| | Flawed press roller. | Replace the press roller (see page 1-5-45). |
| | Flawed fuser heater. | Replace the fuser heaters (see page 1-5-47). |

(17) Image is out of focus.

| Copy example | Causes | Check procedures/corrective measures |
|---|--------------------------------|--|
|  | Defective image scanning unit. | Replace the image scanning unit (see page 1-5-28). |
| | Drum condensation. | Perform the drum refresh operation. |

(18) Image center does not align with the original center.

| Copy example | Causes | Check procedures/corrective measures |
|---|-----------------------------------|--|
|  | Misadjusted image center line. | Run maintenance item U034 to readjust the center line of image printing (see page 1-3-13). |
| | Misadjusted scanner center line. | Run maintenance item U067 to readjust the scanner leading edge registration (see page 1-3-20). |
| | Original is not placed correctly. | Place the original correctly. |

1-4-4 Electric problems

Troubleshooting to each failure must be in the order of the numbered symptoms.

| Problem | Causes | Check procedures/corrective measures |
|---|---|---|
| (1) The machine does not operate when the main power switch is turned on. | 1. The power cord is not plugged in properly. | Check the contact between the power plug and the outlet. |
| | 2. No electricity at the power outlet. | Measure the input voltage. |
| | 3. Broken power cord. | Check for continuity. If none, replace the cord. |
| | 4. Defective main power switch. | Check for continuity across the contacts. If none, replace the main power switch. |
| | 5. Defective power source PWB. | With AC present, check for 24 V DC at YC8-4 on the power source PWB and 5 V DC at YC8-1. If none, replace the power source PWB. |
| (2) The eject motor does not operate. | 1. Poor contact in the connector terminals. | Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable. |
| | 2. Defective drive transmission system. | Check if the rollers and gears rotate smoothly. If not, grease the bushings and gears. Check for broken gears and replace if any. |
| | 3. Defective eject motor. | Run maintenance item U030 and check if the eject motor operates. If not, replace the eject motor. |
| | 4. Defective engine PWB. | Run maintenance item U030 and check if the eject motor operates. If not, replace the engine PWB. |
| (3) The toner feed motor does not operate. | 1. Poor contact in the connector terminals. | Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable. |
| | 2. Defective drive transmission system. | Check if the rollers and gears rotate smoothly. If not, grease the bushings and gears. Check for broken gears and replace if any. |
| | 3. Defective toner feed motor. | Run maintenance item U135 and check if the toner feed motor operates. If not, replace the toner feed motor. |
| | 4. Defective engine PWB. | Run maintenance item U135 and check if the toner feed motor operates. If not, replace the engine PWB. |
| (4) The scanner motor or cooling fan motor 1 to 8 does not operate. | 1. Poor contact in the connector terminals. | Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable. |
| | 2. Broken motor coil. | Check for continuity across the coil. If none, replace the motor. |
| (5) The upper/lower paper feed clutch, feed clutch 1/2/3, MP paper feed clutch, MP paper feed clutch, registration clutch, duplex feed clutch or toner feed clutch does not operate. | 1. Broken clutch coil. | Check for continuity across the coil. If none, replace the clutch. |
| | 2. Poor contact in the connector terminals. | Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable. |
| | 3. Defective engine PWB. | Run maintenance item U032 and check if following terminals on the engine PWB goes low. If not, replace the engine PWB. Upper paper feed clutch: YC8-A13 on the engine PWB Lower paper feed clutch: YC8-A15 on the engine PWB Feed clutch 1: YC8-B8 on the engine PWB Feed clutch 2: YC8-A12 on the engine PWB Feed clutch 3: YC8-A5 on the engine PWB MP paper feed clutch: YC7-9 on the engine PWB MP feed clutch: YC7-11 on the engine PWB Registration clutch: YC8-B15 on the engine PWB Duplex feed clutch: YC8-B9 on the engine PWB Toner feed clutch: YC8-A17 on the engine PWB |

| Problem | Causes | Check procedures/corrective measures |
|---|---|--|
| (6) The feedshift solenoid does not operate. | 1. Broken solenoid coil. | Check for continuity across the coil. If none, replace the solenoid. |
| | 2. Poor contact in the connector terminals. | Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable. |
| | 3. Defective engine PWB. | Run maintenance item U033 and check if the solenoid operates. If not, replace the engine PWB. |
| (7) The exposure lamp does not turn on or off. | 1. Poor contact in the connector terminals. | Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable. |
| | 2. Defective engine PWB. | Run maintenance item U061 and check if YC16-1 and YC16-6 on the engine PWB goes low. If not, replace the engine PWB. |
| | | If YC16-1 and YC16-6 on the engine PWB is always low, replace the engine PWB. |
| | 3. Defective scanner inverter PWB. | Run maintenance item U061 and check if the exposure lamp turns on with YC1-1 and YC1-6 on the scanner inverter PWB go low. If not, replace the scanner inverter PWB. |
| | | If the exposure lamp does not turn off with YC1-1 and YC1-6 on the scanner inverter PWB high, replace the scanner inverter PWB. |
| | 4. Defective exposure lamp. | Replace the exposure lamp even if checking or correcting other measures. |
| (8) Main charging is not performed. | 1. Broken main charger wire. | (See page 1-4-35.) |
| | 2. Leaking main charger housing. | |
| | 3. The connector terminals of the high voltage PWB make poor contact. | |
| | 4. Defective engine PWB. | |
| | 5. Defective high voltage PWB. | |
| (9) No developing bias is output. | 1. The connector terminals of the high voltage PWB make poor contact. | (See page 1-4-35.) |
| | 2. Defective engine PWB. | |
| | 3. Defective high voltage PWB. | |
| (10) Transfer charging is not performed. | 1. The connector terminals of the high voltage PWB make poor contact. | (See page 1-4-35.) |
| | 2. Defective engine PWB. | |
| | 3. Defective high voltage PWB. | |

| Problem | Causes | Check procedures/corrective measures |
|--|---|--|
| (11) The original size is not detected correctly. | 1. Original is not placed correctly. | Check the original and correct if necessary. |
| | 2. Poor contact in the original detection switch or original size detection sensor connector terminals. | Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable. |
| | 3. Defective original detection switch. | If the level of YC17-5 on the engine PWB does not go low when the original detection switch is turned on and off, replace the original detection switch. |
| | 4. Defective original size detection sensor. | Check if sensor operates correctly. If not, replace it. |
| (12) The touch panel keys do not work. | 1. Poor contact in the touch panel connector terminals. | Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable. |
| | 2. Defective touch panel or main PWB. | If any keys do not work after running the maintenance item U201 to initialize the touch panel, replace the touch panel or main PWB. |
| (13) The message requesting paper to be loaded is shown when paper is present on the cassette 1/2 or MP tray. | 1. Poor contact in the connector terminals of upper/lower paper switch or MP paper switch. | Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable. |
| | 2. Defective upper/lower paper switch or MP paper switch. | If the level of following terminal on PWB does not go low when the switch is turned on and off, replace the switch. Upper paper switch: YC23-B12 on the engine PWB Lower paper switch: YC23-A5 on the engine PWB MP paper switch: YC7-6 on the engine PWB |
| (14) The size of paper on the cassette 1/2 or MP tray is not displayed correctly. | 1. Poor contact in the connector terminals of upper/lower paper size length switch, upper/lower paper size width switch, MP paper size length switch or MP paper size width switch. | Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable. |
| | 2. Defective upper/lower paper size length switch or MP paper size length switch. | If the level of following terminal on PWB does not go low when the switch is turned on and off, replace the switch. Upper paper size length switch: YC23-B2 on the engine PWB Lower paper size length switch: YC23-A12 on the engine PWB MP paper size length switch: YC7-13 on the engine PWB |
| | 3. Defective upper/lower paper size width switch or MP paper size width switch. | If the level of following terminal on PWB does not change when the width guide in the cassette 1/2 or insert guide on the MP tray is moved, replace the switch. Upper paper size width switch: YC22-5, 7, 11 on the engine PWB Lower paper size width switch: YC22-6, 8, 12 on the engine PWB MP paper size width switch: YC7-1, 2, 3 on the engine PWB |

| Problem | Causes | Check procedures/corrective measures |
|--|--|--|
| (15) A paper jam in the paper feed, paper conveying, fuser, eject or duplex section is indicated when the main power switch is turned on. | 1. A piece of paper torn from copy paper is caught around feed switch 1/2/3, registration switch, feedshift switch, eject switch or duplex paper conveying switch. | Check visually and remove it, if any. |
| | 2. Defective feed switch 1/2/3, registration switch, feedshift switch, eject switch or duplex paper conveying switch. | Run maintenance item U031 and turn each switch on and off manually. Replace the switch if indication of the corresponding switch on the touch panel is not displayed in reverse. |
| (16) The message requesting cover to be closed is displayed when the front cover or left cover 1/2 is closed. | 1. Poor contact in the connector terminals of safety switch 1/2 or left cover 2 switch. | Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable. |
| | 2. Defective safety switch 1/2 or left cover 2 switch. | Check for continuity across each switch. If there is no continuity when the switch is on, replace it. |
| (17) Others. | 1. Wiring is broken, shorted or makes poor contact. | Check for continuity. If none, repair. |

1-4-5 Mechanical problems

| Problem | Causes/check procedures | Corrective measures |
|--|---|--|
| (1) No primary paper feed. | Check if the surfaces of the following rollers or pulleys are dirty with paper powder: upper/lower forwarding pulleys, upper/lower paper feed pulleys, upper/lower separation pulleys, feed rollers, registration rollers, MP forwarding pulley, MP paper feed pulley and MP separation pulley. | Clean with isopropyl alcohol. |
| | Check if the upper/lower forwarding pulleys, upper/lower paper feed pulleys or upper/lower separation pulleys is deformed. | Replace the pulley if it is deformed (see page 1-5-3). |
| | Check if the MP forwarding pulley, MP paper feed pulley or MP separation pulley is deformed. | Replace the pulley if it is deformed (see page 1-5-6). |
| | Electrical problem with the following clutches: upper/lower paper feed clutches, feed clutches 1/2/3, MP paper feed clutch and MP feed clutch. | See page 1-4-41. |
| (2) No secondary paper feed. | Check if the surfaces of the right and left registration rollers are dirty with paper powder. | Clean with isopropyl alcohol. |
| | Electrical problem with the registration clutch. | See page 1-4-41. |
| (3) Skewed paper feed. | Width guide in a cassette installed incorrectly. | Check the width guide visually and correct or replace if necessary. |
| | Deformed width guide in a cassette. | Check visually and replace any deformed guide. |
| | Check if a pressure spring along the paper conveying path is deformed or out of place. | Repair or replace. |
| (4) The scanner does not travel. | Check if the scanner wire is loose. | Reinstall the scanner wire (see page 1-5-23). |
| | The scanner motor malfunctions. | See page 1-4-41. |
| (5) Multiple sheets of paper are fed at one time. | Paper is extremely curled. | Change the paper. |
| | Check if the upper or lower separation pulley is worn. | Replace the upper or lower separation pulley if it is worn (see page 1-5-3). |
| | Check if the MP separation pulley is worn. | Replace the MP separation pulley if it is worn (see page 1-5-6). |

| Problem | Causes/check procedures | Corrective measures |
|---|---|--|
| (6) Paper jams. | Paper is extremely curled. | Change the paper. |
| | Deformed guides along the paper conveying path. | Check visually and replace any deformed guides. |
| | Check if the contact between the right and left registration rollers is correct. | Check visually and remedy if necessary. |
| | Check if the contact between the feed roller and feed pulley is correct. | Check visually and remedy if necessary. |
| | Check if the press roller is extremely dirty or deformed. | Clean or replace the press roller. |
| | Check if the contact between the heat roller and its separation claws is correct. | Repair if any springs are off the separation claws. |
| | Check if the contact between the eject roller and pulley is correct. | Check visually and remedy if necessary. |
| | The feedshift solenoid malfunctions. | See page 1-4-42. |
| | Check if the duplex feed pulley, upper duplex feed roller or lower duplex feed roller is deformed. | Check visually and replace the pulley or roller if deformed. |
| (7) Toner drops on the paper conveying path. | Check if the developing unit is extremely dirty. | Clean the developing unit. |
| (8) Abnormal noise is heard. | Check if the pulleys, rollers and gears operate smoothly. | Grease the bearings and gears. |
| | Check if the following clutches are installed correctly: upper/lower paper feed clutches, feed clutches 1/2/3, MP paper feed clutch and MP feed clutch. | Correct. |

1-5-1 Precautions for assembly and disassembly

(1) Precautions

Before starting disassembly, press the power key on the operation panel to off. Make sure that the power indicator and the Memory indicator are off before turning off the main power switch. And then unplug the power cable from the wall outlet.

Turning off the main power switch before pressing the power key to off may cause damage to the equipped hard disk.

When fax kit is installed, be sure to disconnect the modular code before starting disassembly.

When handling PWBs (printed wiring boards), do not touch parts with bare hands.

The PWBs are susceptible to static charge. Do not touch any PWB containing ICs with bare hands or any object prone to static charge.

Use only the specified parts to replace the fuser unit thermostat. Never substitute electric wires, as the machine may be seriously damaged.

When replacing battery on a PWB, dispose properly according to laws and regulations.

When removing the hook of the connector, be sure to release the hook.

Take care not to get the wire caught.

(2) Drum

Note the following when handling or storing the drum.

When removing the drum unit, never expose the drum surface to strong direct light.

Keep the drum at an ambient temperature between 0°C/32°F and 35°C/95°F and at a relative humidity not higher than 85% RH. Avoid abrupt changes in temperature and humidity.

Avoid exposure to any substance which is harmful to or may affect the quality of the drum.

Do not touch the drum surface with any object. Should it be touched by hands or stained with oil, clean it.

(3) Toner

Store the toner container in a cool, dark place.

Avoid direct light and high humidity.



(4) How to tell a genuine Kyocera Mita toner container

As a means of brand protection, the Kyocera Mita toner container utilizes an optical security technology to enable visual validation. A validation viewer is required to accomplish this.

Hold the validation viewer over the left side part of the brand protection seal on the toner container. Through each window of the validation viewer, the left side part of the seal should be seen as follows:

A black-colored band when seen through the left side window

A shiny or gold-colored band when seen through the right side window

The above will reveal that the toner container is a genuine Kyocera Mita branded toner container, otherwise, it is a counterfeit.




Figure 1-5-1

The brand protection seal has an incision as shown below to prohibit reuse.




Figure 1-5-2

1-5-2 Paper feed section

(1) Detaching and refitting the forwarding, paper feed and separation pulleys

Follow the procedure below to replace the forwarding, paper feed and separation pulleys.

Procedure

Removing the primary paper feed units

1. Open the front cover and pull out the cassettes 1 and 2.
2. Remove the screw and remove the primary paper feed unit.




Figure 1-5-3

Removing the forwarding pulley

3. Remove the stopper from the primary paper feed unit.
4. Raise the forwarding pulley retainer in the direction of the arrow, and remove the retainer from the primary paper feed unit.




Figure 1-5-4

5. Remove the stop ring from the forwarding pulley retainer.
6. Pull the paper forwarding pulley shaft and remove the forwarding pulley.




Figure 1-5-5

Removing the paper feed pulley

7. Remove two stop rings from the primary paper feed unit.
8. Pull the paper feed pulley shaft in the direction of the arrow and remove the paper feed pulley.




Figure 1-5-6

Removing the separation pulley

9. Remove the stop ring from the primary paper feed unit.
10. Pull the separation pulley shaft in the direction of the arrow and remove the separation pulley.





Figure 1-5-7

11. Replace the forwarding, paper feed and separation pulleys.
12. Refit all the removed parts.
When refitting the forwarding pulley, orient it correctly as shown in Figure 1-5-6.
13. When the forwarding pulley, paper feed pulley, separation pulley or the primary paper feed unit is replaced, perform maintenance mode U903 to clear the jam counter (see page 1-3-61).


**Figure 1-5-8**

(2) Detaching and refitting the MP separation, MP paper feed and MP forwarding pulleys


Follow the procedure below to replace the MP separation, MP paper feed and MP forwarding pulleys.

Procedure**Removing the MP unit**

1. Remove two screws and remove the scanner right cover.

**Figure 1-5-9**

2. Remove four hooks and remove the right upper cover.

**Figure 1-5-10**

3. Open the front cover.
4. Remove the screw and remove the front right cover.




Figure 1-5-11

5. Raise the top tray.
6. Remove ten hooks and remove the right lower cover.




Figure 1-5-12

7. Loosen two screws and remove two MP holder plates.
8. Remove two screws.




Figure 1-5-13

9. Remove two connectors.
10. Release the clamp.
11. Remove the MP unit.







Figure 1-5-14

Removing the MP separation pulley

12. Reverse the MP unit and remove the spring and stop ring from the MP separation pulley shaft.
13. Move the bush inside.

**Figure 1-5-15**

14. Raise the MP separation pulley shaft. Remove the holder plate and the bush, and then remove the MP separation pulley.

**Figure 1-5-16**

Removing the MP paper feed pulley

15. Remove the connector.
16. Release three clamps and remove the wire.




Figure 1-5-17

17. Remove the screw and remove the MP unit cover.




Figure 1-5-18

18. Remove the stop ring and bush.




Figure 1-5-19

- 19. Remove the stop ring.
- 20. Raise the MP paper feed pulley shaft and remove the MP paper feed pulley.





Figure 1-5-20

Removing the MP forwarding pulley

21. Remove the sponge.

22. Remove the stop ring and MP paper feed clutch.

When refitting, insert the cutout in the MP paper feed clutch over the stopper on the machine.




Figure 1-5-21

23. Remove the screw and move the cam and the bush toward the inner side.




Figure 1-5-22

24. Remove the stop ring and slide the bush in the direction of the arrow.




Figure 1-5-23

25. Slide the MP forwarding pulley shaft temporarily toward the rear side and then raise it to remove from the MP unit. Remove the shaft while raising the actuator of the MP paper switch.




Figure 1-5-24

26. Remove the bush and cam.
27. Remove the stop ring.
28. Slide the MP forwarding pulley with the forwarding pulley retainer from the shaft to remove it.
29. Replace the MP separation, MP paper feed and MP forwarding pulleys.




Figure 1-5-25

30. Refit all the removed parts.
When refitting the MP unit cover, the films on the cover are positioned under the MP paper feed pulley shaft.
31. When the MP forwarding pulley, MP paper feed pulley or the MP separation pulley is replaced, perform maintenance mode U903 to clear the jam counter (see page 1-3-61).




Figure 1-5-26

1-5-3 Optical section

(1) Detaching and refitting the exposure lamp

Follow the procedure below to replace the exposure lamp.

Procedure

1. Remove the original cover or the DP.
2. Remove twelve screws and remove the rear cover.




Figure 1-5-27

3. Remove the clip holder.
4. Remove two screws and remove the front left cover.




Figure 1-5-28

5. Remove two screws and remove the scanner right cover.
6. Remove the platen.




Figure 1-5-29

7. Remove the scanner front cover.
8. Remove the screw and remove the scanner rear cover.




Figure 1-5-30

9. Remove the connector of the scanner inverter PWB.
10. Release the clamp and remove the wire.
11. Pull the connector out from the opening on the rear of the scanner unit.




Figure 1-5-31

12. Remove two films.
13. Remove the wire guide lid.
14. Move the mirror 1 frame to notch position.




Figure 1-5-32

15. Remove the screw.
16. Open the lamp wire guide lid.




Figure 1-5-33

17. Remove the hook and remove the exposure lamp.
18. Replace the exposure lamp and install the lamp.
19. Refit all the removed parts.




Figure 1-5-34

(2) Detaching and refitting the scanner unit

Follow the procedure below to replace the scanner unit.

Procedure

1. Remove the original cover or the DP.
2. Remove twelve screws and remove the rear cover.




Figure 1-5-35

3. Remove the clip holder.
4. Remove two screws and remove the front left cover.




Figure 1-5-36

5. Remove two screws and remove the scanner right cover.
6. Remove the platen.




Figure 1-5-37

7. Remove the scanner front cover.
8. Remove the screw and remove the scanner rear cover.




Figure 1-5-38

9. Remove the claw and remove the left upper cover.
10. Remove the scanner left cover.




Figure 1-5-39

11. Remove YC24, YC17 and YC31 connectors of the engine PWB.
12. Remove FFC from YC16 connector of the engine PWB.
13. Remove the relay connector.
14. Release the clamp and remove the wire.
15. Remove FFC from YC4 connector of the main PWB.




Figure 1-5-40

16. Remove four pins.
17. Remove the scanner unit.




Figure 1-5-41

(3) Detaching and refitting the scanner wires

Take the following procedure when the scanner wires are broken or to be replaced.

(3-1) Detaching the scanner wires

Procedure

1. Remove the scanner unit (see page 1-5-19).
2. Remove the exposure lamp (see page 1-5-15).
3. Remove the screw and remove the slit holder plate.
4. Remove the slit glass.




Figure 1-5-42

5. Remove each screw and remove front and rear wire holder plates.
6. Remove the mirror 1 frame from the scanner unit.




Figure 1-5-43

7. Remove the round terminals from the scanner wire springs.
8. Remove the scanner wires.




Figure 1-5-44

(3-2) Fitting the scanner wires**NOTE**

When fitting the wires, be sure to use those specified below.

Machine front: (P/N: 2C912360), gray

Machine rear: (P/N: 2C912350), black


Fitting requires the following tools

Two frame securing tools (P/N 302C968310)


Two scanner wire stoppers (P/N 35968110)

Procedure

1. Remove the screw and remove the scanner wire drum gear.

**Figure 1-5-45**

2. Remove the stop ring and bush from the front of the scanner wire drum shaft.
3. Remove the scanner wire drum shaft from the scanner unit.

**Figure 1-5-46**

4. Insert the locating ball on each of the scanner wires into the hole in the respective scanner wire drum and wind the scanner wire three turns inward and four turns outward.
With the locating ball as the reference point, wind the shorter end of each of the wires outward.
5. Secure the scanner wires using the scanner wire stoppers.




Figure 1-5-47

6. Refit the scanner wire drum shaft to the scanner unit.
7. Insert the two frame securing tools into the positioning holes at the front and rear of the scanner unit to fix the mirror 2 frame in position.




Figure 1-5-48

8. Loop the outer ends of the scanner wires around the outer grooves in the pulleys on the mirror 2 frame, winding from below to above. (1)
9. Hook the round terminals onto the catches inside the scanner unit. (2)
10. Loop the inner ends of the scanner wires around the grooves in the pulleys at the left of the scanner unit, winding from below to above. (3)
11. Loop the scanner wires around the inner grooves in the pulleys on the mirror 2 frame, winding from above to below. (4)
12. Wind the scanner wires around the grooves in the scanner wire guides at the left of the scanner unit. (5)
13. Hook the round terminals onto the scanner wire springs. (6)




Figure 1-5-49

14. Remove the two scanner wire stoppers and frame securing tools.
15. Focusing on the locating ball of the wire drum, move aside the wires to inside.
16. Move the mirror 2 frame from side to side to correctly locate the wires in position.
17. Refit the mirror 1 frame.
18. Move the mirror 1 and 2 frames to the machine left, and insert the two frame securing tools into the positioning holes at the front and rear of the scanner unit to secure the frames in position.
19. Hold the wires and fix each front and rear wire holder plate to mirror 1 frame with the screw.
20. Remove the two frame securing tools.
21. Refit all the removed parts.




Figure 1-5-50

(4) Detaching and refitting the ISU (reference)

Follow the procedure below to replace the ISU.

Procedure

1. Remove two screws and remove the scanner right cover.
2. Remove the platen.




Figure 1-5-51

3. Remove six screws and remove the FFC ground and ISU cover.





Figure 1-5-52

4. Remove the FFC from the connector.
5. Remove four screws and remove the ISU.
6. Replace the ISU.
7. Refit all the removed parts.

**Figure 1-5-53**

(5) Detaching and refitting the laser scanner unit

Follow the procedure below to replace the laser scanner unit.

Procedure

1. Open the front cover.
2. Remove the toner container.
3. Remove the waste toner box.
4. Remove the screw and remove the front right cover.




Figure 1-5-54

5. Remove the claw and remove the toner hopper wire cover.






Figure 1-5-55

6. Remove three screws.
7. Remove the connector.
8. Remove the toner hopper assembly.

**Figure 1-5-56**

9. Remove the top tray.

**Figure 1-5-57**

10. Remove four connectors.
11. Release the clamp.




Figure 1-5-58

12. Remove two screws and remove the cooling fan assembly.




Figure 1-5-59

13. Remove three screws and remove the LSU cover.




Figure 1-5-60

14. Remove two connectors.
 15. Remove four screws and remove the laser scanner unit.
 16. Replace the laser scanner unit and install the unit.
 17. Refit all the removed parts.





Figure 1-5-61

(6) Adjusting the position of the ISU (reference)

Perform the following adjustment if the leading and trailing edges of the copy image are laterally skewed (lateral squareness not obtained).

Caution:

Adjust the deflection in the paper at the registration roller first (see page 1-3-15). Check for the longitudinal squareness of the copy image, and if it is not obtained, perform the longitudinal squareness adjustment.

Before making the following adjustment, output a VTC-PG2 pattern in maintenance item U993 to use as the original for the adjustment.

Procedure




Figure 1-5-62




Figure 1-5-63

1-5-4 Drum section

(1) Detaching and refitting the drum unit

Follow the procedure below to replace the drum unit.

Cautions

Avoid direct sunlight or strong light when detaching and refitting the drum unit.
Never touch the drum surface when holding the drum unit.

Procedure

1. Open the left cover 1.
2. Open the front cover.
3. Remove the toner container.
4. Remove the waste toner box.
5. Remove the claw and remove the toner hopper wire cover.




Figure 1-5-64

6. Remove the connector.
7. Remove three screws.
8. Remove the toner hopper assembly.




Figure 1-5-65

9. Remove the claw and remove the inner cover lid.
10. Remove three connectors.
11. Pull the developing lever.




Figure 1-5-66

12. Remove the screw and remove the drum unit.
13. Replace the drum unit and install the unit.





Figure 1-5-67

(2) Detaching and refitting the main charger unit


Follow the procedure below to replace the main charger unit.

Procedure

1. Open the front cover.

**Figure 1-5-68**

2. Pull the main charger unit.
3. While pressing the lock lever and remove the main charger unit.
4. Replace the main charger unit and install the unit.
The main charger unit, when fully inserted, must be set aside towards the drum unit.

**Figure 1-5-69**

(3) Detaching and refitting the drum separation claws

Follow the procedure below to replace the drum separation claws.

Procedure

1. Remove the drum unit (see page 1-5-35).
2. Remove two screws and remove the lower cleaning seal.




Figure 1-5-70

3. Release the inserted parts and remove the drum separation claws.
4. Replace the drum separation claws and install the claws.
5. Refit all the removed parts.




Figure 1-5-71

1-5-5 Developing section

(1) Detaching and refitting the developing unit

Follow the procedure below to replace the developing unit.

Procedure

1. Remove the drum unit (see page 1-5-35).
2. Remove two connectors.




Figure 1-5-72

3. Remove the developing unit.
 4. Replace the developing unit and install the unit.
 5. Refit all the removed parts.
- When the developing unit is replaced, perform maintenance mode U157 to clear the counter value (see page 1-3-39).




Figure 1-5-73

1-5-6 Transfer section

(1) Detaching and refitting the transfer roller unit

Follow the procedure below to replace the transfer roller unit.

Procedure

1. Open the left cover 1.
2. Remove the claws of the front and rear transfer bushes and remove the transfer roller unit.
3. Replace the transfer roller unit and install the unit.
The front and rear transfer springs must be firmly mounted on the holder.




Figure 1-5-74

1-5-7 Fuser section

(1) Detaching and refitting the fuser unit

Follow the procedure below to check or replace the fuser unit.

Procedure

1. Open the front cover.
2. Remove the clip holder.
3. Remove two screws and remove front left cover.




Figure 1-5-75

4. Open the left cover 1.
5. Remove two screws and remove the left cover hook.




Figure 1-5-76

6. Remove the screw of the front left middle cover.




Figure 1-5-77

7. Remove the front left middle cover.




Figure 1-5-78

8. Remove three connectors.




Figure 1-5-79

9. Remove the screw and remove the fuser unit.
10. Check or replace the fuser unit and install the unit.
11. Refit all the removed parts.
When the fuser unit is replaced, perform maintenance mode U167 to clear the counter value (see page 1-3-40).




Figure 1-5-80

(2) Detaching and refitting the heat roller separation claws

Follow the procedure below to replace the heat roller separation claws.

Procedure

1. Remove the fuser heater (see page 1-5-47).
2. Remove four screws.
3. Remove four claws and remove the rear fuser guide.




Figure 1-5-81

4. Remove the spring and remove the heat roller separation claws.
5. Replace the heat roller separation claws and install the claws.
6. Refit all the removed parts.




Figure 1-5-82

(3) Detaching and refitting the press roller

Follow the procedure below to replace the press roller.

Procedure

1. Remove the fuser unit (see page 1-5-41).
2. Remove four claws and remove the fuser unit cover.
3. Remove two connectors.




Figure 1-5-83

4. Remove four screws.
5. Separate the right fuser frame and left fuser frame.




Figure 1-5-84

6. Remove the press roller.
7. Replace the press roller and install the roller.
8. Refit all the removed parts.




Figure 1-5-85

(4) Detaching and refitting the fuser heater

Follow the procedure below to replace the fuser heater.

Procedure

1. Remove the fuser unit (see page 1-5-41).
2. Remove four claws and remove the fuser unit cover.
3. Remove two connectors.




Figure 1-5-86

4. Remove four screws.
5. Separate the right fuser frame and left fuser frame.




Figure 1-5-87

6. Remove two tabs.




Figure 1-5-88

7. Remove the screw and rear fuser heater cover.
8. Remove the screw and front fuser heater cover.
9. Pull out the fuser heater.
10. Replace the fuser heater and install the heater.
11. Refit all the removed parts.




Figure 1-5-89

(5) Detaching and refitting the heat roller

Follow the procedure below to replace the heat roller.

Procedure

1. Remove the fuser heater (see page 1-5-47).
2. Remove the heat roller separation claws (see page 1-5-44).
3. Remove the front and rear heat bushes from right fuser frame.
4. Remove the fuser gear Z46, front and rear heat bushes from heat roller.
5. Replace the heat roller and install the roller
6. Refit all the removed parts.




Figure 1-5-90

(6) Detaching and refitting the fuser thermistor 1

Follow the procedure below to replace the fuser thermistor 1.

Procedure

1. Remove the heat roller (see page 1-5-49).
2. Remove the screw and remove the fuser thermistor 1.
3. Replace the fuser thermistor 1 and install the thermistor.
4. Refit all the removed parts.




Figure 1-5-91

(7) Detaching and refitting the fuser thermistor 2

Follow the procedure below to replace the fuser thermistor 2.

Procedure

1. Remove the fuser unit (see page 1-5-41).
2. Remove four claws and remove the fuser unit cover.
3. Remove the connector.
4. Remove the band.




Figure 1-5-92

5. Remove the screw and remove the fuser thermistor 2.
6. Replace the fuser thermistor 2 and install the thermistor.
7. Refit all the removed parts.




Figure 1-5-93

(8) Detaching and refitting the fuser thermostats 1 and 2

Follow the procedure below to replace the fuser thermostats 1 and 2.

Procedure

1. Remove the fuser unit (see page 1-5-41).
2. Remove four claws and remove the fuser unit cover.




Figure 1-5-94

3. Remove four tabs.




Figure 1-5-95

4. Remove each two screws and remove two fuser thermostat holders.




Figure 1-5-96

5. Remove two screws and remove fuser thermostats 1 and 2.
6. Replace the fuser thermostats 1 and 2 and install the thermostats.
7. Refit all the removed parts.




Figure 1-5-97

(9) Adjusting front position of the fuser unit (adjusting lateral squareness)

Follow the procedure below if the drum is not parallel to the fuser unit and therefore paper is not fed straight to the fuser section and the trailing edge of image on either the front or rear side becomes longer.

Procedure




Figure 1-5-98




Figure 1-5-99

1-5-8 PWBs

(1) Detaching and refitting the engine PWB

Follow the procedure below to replace the engine PWB.

Procedure

1. Remove twelve screws and remove the rear cover.




Figure 1-5-100

2. Remove three screws.
3. Remove the claw.
4. Remove the connector.
5. Remove the high voltage PWB.




Figure 1-5-101

6. Remove all connectors of engine PWB.
7. Remove six screws and remove the engine PWB.
8. Replace the engine PWB and install the PWB.




Figure 1-5-102

9. Refit all the removed parts.
When replacing the connectors back in place, be sure not to mistake YC14 and YC20 for each other.
YC14: Wire of the eject motor
YC20: Wire of the key counter




Figure 1-5-103

1-5-9 Others

(1) Detaching and refitting the ozone filter 1

Follow the procedure below to replace the ozone filter 1.

Procedure

1. Open the filter cover.
2. Remove the ozone filter 1.
3. Replace the ozone filter 1 and install the filter.




Figure 1-5-104

(2) Detaching and refitting the ozone filter 2

Follow the procedure below to replace the ozone filter 2.

Procedure

1. Remove the filter cover.
2. Remove the ozone filter 2.
3. Replace the ozone filter 2 and install the filter.
4. Refit all the removed parts.




Figure 1-5-105

1-6-1 Upgrading the firmware

Follow the procedure below to upgrade the firmware of main PWB, engine PWB and MMI.

Firmware upgrading requires the following tools:

Compact Flash (Products manufactured by SANDISK are recommended.)

NOTE

When writing data to a new Compact Flash from a computer, be sure to format it in advance.

Procedure

1. Press the power key on the operation panel to off. Make sure that the power indicator and the memory indicator are off before turning off the main power switch. And then unplug the power cable from the wall outlet.
2. Remove two screws and remove the right upper plate lid.
3. Insert Compact Flash in a notch hole of the machine.
Insert the surface of Compact Flash toward the machine rear.

4. Insert the power plug and turn the main power switch on. Upgrading firmware starts.

Caution:

Never turn the main power switch off during upgrading.




Figure 1-6-1

5. [Completed] is displayed on the touch panel when upgrading is complete.
6. Press the power key on the operation panel to off. Make sure that the power indicator and the memory indicator are off before turning off the main power switch. And then unplug the power cable from the wall outlet.
7. Remove Compact Flash from the machine.
8. Refit the right upper plate lid.
9. Insert the power plug and turn the main power switch on.

1-6-2 Adjustment-free variable resistors (VR)

The variable resistors listed below are set at the factory prior to shipping and cannot be adjusted in the field.
High voltage PWB: VR101, VR201, VR302, VR303

1-6-3 Remarks on engine PWB replacement

When replacing the engine PWB, remove the EEPROM from the engine PWB that has been removed and then reattach it to the new engine PWB.




Figure 1-6-2

1-6-4 Remarks on main PWB replacement

When replacing the main PWB, remove two EEPROM from the main PWB that has been removed and then reattach them to the new main PWB.

Be sure to reattach the EEPROM in its original position.




Figure 1-6-3

2-1-1 Paper feed section

(1) Cassette paper feed section

The paper feed section consists of the primary feed and secondary feed subsections. Primary feed conveys paper from the cassettes 1, 2 or MP tray to the left and right registration rollers, at which point secondary feed takes place and the paper travels to the transfer section in sync with the printing timing.

Each cassette consists of a lift driven by the lift motor and other components. Each cassette can hold up to 500 sheets of paper. Paper is fed from the cassette by the rotation of the forwarding pulley and paper feed pulley. The separation pulley prevents multiple sheets from being fed at one time, via the torque limiter.




Figure 2-1-1 Cassette paper feed section

- | | |
|--|-------------------------------------|
| (1) Upper forwarding pulley | (17) Right registration roller |
| (2) Lower forwarding pulley | (18) Left registration roller |
| (3) Upper paper feed pulley | (19) Registration switch (RSW) |
| (4) Lower paper feed pulley | (20) Feed roller 1 |
| (5) Upper separation pulley | (21) Feed pulley |
| (6) Lower separation pulley | (22) Feed switch 1 (FSW1) |
| (7) Upper paper switch (PSW-U) | (23) Feed roller 2 |
| (8) Lower paper switch (PSW-L) | (24) Feed pulley |
| (9) Upper lift limit switch (LICSW-U) | (25) Feed switch 2 (FSW2) |
| (10) Lower lift limit switch (LICSW-L) | (26) Feed roller 3 |
| (11) Upper paper size width switch (PWSW-U) | (27) Feed pulley |
| (12) Lower paper size width switch (PWSW-L) | (28) Feed switch 3 (FSW3) |
| (13) Upper paper size length switch (PLSW-U) | (29) Vertical paper conveying guide |
| (14) Lower paper size length switch (PLSW-L) | (30) Paper conveying guide |
| (15) Cassette bases | (31) Vertical paper conveying frame |
| (16) Lift operation plates | |




Figure 2-1-2 Cassette paper feed section block diagram

(2) MP tray paper feed section

The MP tray can hold up to 200 sheets of paper at one time. Paper is fed from the MP tray by the rotation of the MP forwarding pulley and MP paper feed pulley. Also during paper feed, the MP separation pulley prevents multiple sheets from being fed at one time by the torque limiter.




Figure 2-1-3 MP tray paper feed section

- | | |
|--------------------------|---|
| (1) MP tray | (9) MP feed roller 2 |
| (2) MP lift plate | (10) MP paper switch (MPPSW) |
| (3) MP forwarding pulley | (11) MP feed switch (MPFSW) |
| (4) MP paper feed pulley | (12) MP paper size length switch (MPPLSW) |
| (5) MP separation pulley | (13) MP paper size width switch (MPPWSW) |
| (6) MP feed pulley | |
| (7) MP feed roller 1 | |
| (8) MP feed pulley | |




Figure 2-1-4 MP tray paper feed section block diagram

2-1-2 Main charging section

The main charging section consists of the main charger assembly, drum and so on. The drum is electrically charged uniformly by means of a grid to form a latent image on the surface.

The main charger unit charges the drum so that a latent image is formed on the surface, the shield grid ensuring the charge is applied uniformly.




Figure 2-1-5 Main charging section




Figure 2-1-6 Main charging section block diagram

2-1-3 Optical section

The optical section consists of the image scanner section for scanning and the laser scanner section for printing.

(1) Image scanner section

The original image is illuminated by the exposure lamp (EL) and scanned by the CCD PWB (CCDPWB) in the image scanning unit via the three mirrors, the reflected light being converted to an electrical signal.

The scanner and mirror frames travel to scan on the optical rails on the front and rear of the machine to scan from side to side. The speed of the mirror frames is half the speed of the scanner.

When the DP is used, the scanner and mirror frames stop at the DP original scanning position to start scanning.




Figure 2-1-7 Image scanner section

- (1) Mirror 1 frame
- (2) Mirror 2 frame
- (3) Exposure lamp (EL)
- (4) Mirror 1
- (5) Mirror 2
- (6) Mirror 3
- (7) ISU
- (8) Lens
- (9) CCD PWB (CCDPWB)
- (10) Original size detection sensor (OSDS)
- (11) Original detection switch (ODSW)
- (12) Scanner home position switch (SHPSW)
- (13) Slit glass




Figure 2-1-8 Image scanner section block diagram

(2) Laser scanner section

The image data scanned by the CCD PWB (CCDPWB) is processed on the main PWB (MPWB) and transmitted as image printing data to the laser scanner unit (LSU). By repeatedly turning the laser on and off, the laser scanner unit forms a latent image on the drum surface.




Figure 2-1-9 Laser scanner section

- (1) APC PWB (APCPWB)
- (2) Laser diode
- (3) Cylindrical lens
- (4) Polygon motor (PM)
- (5) Polygon mirror
- (6) fθ lens
- (7) fθ lens
- (8) PD sensor mirror
- (9) Cylindrical correcting lens
- (10) PD PWB (PDPWB)




Figure 2-1-10 Laser scanner section block diagram

2-1-4 Developing section

The developing unit consists of the developing sleeve where a magnetic brush is formed, the magnetic toner blade and the developing spirals that agitate the toner.

When the toner sensor (TNS) detects a low toner level in the developing unit, the toner replenishment signal is output to the engine PWB (EPWB). The engine PWB (EPWB) that has received the signal turns on the toner feed motor (TFM) and replenishes toner from the toner container to the developing unit.




Figure 2-1-11 Developing section

- (1) Drum
- (2) Developing sleeve
- (3) Magnetic toner blade
- (4) Left developing spiral
- (5) Right developing spiral
- (6) Developing housing
- (7) Toner sensor (TNS)




Figure 2-1-12 Developing section block diagram

(1) Single component developing system

This machine uses the single component developing system, and reversal processing is performed with a + charged drum (a-Si) and a + charged magnetic toner.

With the single component developing system, toner is electrically charged by friction with the developing sleeve and + charged when it passes through the magnetic toner blade. The toner that has passed through the magnetic toner blade forms a uniform layer on the developing sleeve. When the toner layer comes to the location where the developing sleeve is the nearest to the drum, toner moves between the drum and the developing sleeve by an electric field of the magnetic pole. Then, when the developing sleeve rotates and passes through the nearest location to the drum, on the portion of the drum that has been exposed to light, toner is attracted toward the drum by potential difference between the developing bias and the drum surface and development is performed. On the other hand, on the portion of the drum that has not been exposed to light, toner is attracted toward the sleeve and development is not performed. When toner comes to an area where the gap between the drum and the developing sleeve is large, an electric field disappears and toner does not leave the developing sleeve. Development is complete.




Figure 2-1-13 Single component developing system

2-1-5 Transfer and separation sections

The transfer and separation section consists mainly of the transfer roller, separation electrode and drum separation claws. A high voltage generated by the high voltage PWB (HVTPWB) is applied to the transfer roller for transfer charging. Paper after transfer is separated from the drum by applying separation charging that is output from the high voltage PWB (HVTPWB) to the separation electrode.




Figure 2-1-14 Transfer and separation sections




Figure 2-1-15 Transfer and separation sections block diagram

2-1-6 Cleaning and charge erasing sections

The cleaning section consists of the cleaning blade that removes residual toner from the drum surface after the transfer process, and the cleaning spiral that carries the residual toner back to the waste toner box. The cleaning lamp (CL) consists of LEDs and removes residual charge on the drum before main charging. Also the toner quantity in the waste toner box is sensed with the overflow sensor (OFS).




Figure 2-1-16 Cleaning and charge erasing sections




Figure 2-1-17 Cleaning and charge erasing sections block diagram

2-1-7 Fuser section

The fuser section consists of the parts shown in Figure 2-1-18. When paper reaches the fuser section after the transfer process, it passes between the press roller and heat roller, which is heated by fuser heaters M or S (FH-M or FH-S). Pressure is applied by the fuser unit pressure springs so that the toner on the paper is melted, fused and fixed onto the paper. The heat roller is heated by fuser heaters M or S (FH-M or FH-S) inside it; its surface temperature is detected by the fuser thermistor 1 and 2 (FTH1/2), and is regulated by the fuser heaters turning on and off.

If the fuser section becomes abnormally hot, fuser thermostat 1 and 2 (FTS1/2) operates shutting the power to the fuser heaters off. When the fusing process is completed, the paper is separated from the heat roller by its separation claws and is conveyed from the machine to eject and switchback section.




Figure 2-1-18 Fuser section

- (1) Left fuser frame
- (2) Right fuser frame
- (3) Heat roller
- (4) Heat roller separation claws
- (5) Fuser heater M (FH-M)
- (6) Fuser heater S (FH-S)
- (7) Fuser thermostat 1 (FTS1)
- (8) Fuser thermostat 2 (FTS2)
- (9) Fuser thermistor 1 (FTH1)
- (10) Fuser thermistor 2 (FTH2)
- (11) Press roller




Figure 2-1-19 Fuser section block diagram

2-1-8 Eject and switchback sections

The eject and switchback sections eject paper on which fixing has ended with the eject roller that is rotated by forward rotation of the eject motor.

In duplex copying, paper is turned over by reverse rotation of the eject motor. When paper is transferred to the job separator or the internal finisher, the feedshift solenoid (FSSOL) is turned on to activate the feedshift guide to switch the paper transfer path.




Figure 2-1-20 Eject and switchback sections

- | | |
|-----------------------|-----------------------------|
| (1) Feedshift guide | (5) Switchback pulley |
| (2) Eject roller | (6) Feedshift guide |
| (3) Eject pulley | (7) Eject switch (ESW) |
| (4) Switchback roller | (8) Feedshift switch (FSSW) |




Figure 2-1-21 Eject and switchback sections block diagram

2-1-9 Duplex section

The duplex section consists of the components shown in figure. In duplex mode, after copying on to the reverse face of the paper, the paper is reversed in the switchback section and conveyed to the duplex section. The paper is then conveyed to the paper feed section by the upper and lower duplex feed rollers.




Figure 2-1-22 Duplex section

- (1) Feedshift guide
- (2) Upper duplex feed roller
- (3) Lower duplex feed roller
- (4) Duplex feed pulley
- (5) Duplex feed pulley
- (6) Duplex paper conveying switch (DUPPCSW)




Figure 2-1-23 Duplex section block diagram

(1) Paper conveying operation in duplex copying

Paper of which copying onto the reverse side is complete is conveyed to the switchback section, the eject motor switches from normal rotation to reverse rotation to switch the eject roller to reverse rotation, and the paper conveying direction is reversed. Paper that has been switched back is conveyed to the duplex section via the eject roller and the switchback roller.

Paper that has been conveyed to the duplex section is conveyed to the paper feed section again by rotation of the upper duplex feed roller and the lower duplex feed roller and copying onto the front side is performed.




Figure 2-1-24

This page is intentionally left blank.



2-2-1 Electrical parts layout

(1) PWBs




Figure 2-2-1 PWBs

1. Engine PWB (EPWB)..... Controls the other PWBs, electrical components and optional devices.
2. Main PWB (MPWB) Controls the image processing and operation panel.
3. Power source PWB (PSPWB) Generates +24 V DC and 5 V DC; controls the fuser heaters.
4. High voltage PWB (HVPWB) Main charging. Generates developing bias and high voltages for transfer.
5. Scanner inverter PWB (SINPWB) Controls the exposure lamp.
6. CCD PWB (CCDPWB)..... Reads the image of originals.
7. LCD PWB (LCDPWB)..... Controls LCD indication.
8. Upper operation unit PWB (OPWB-U) Consists of the operation keys and display LEDs.
9. Right operation unit PWB (OPWB-R) Consists of the operation keys and display LEDs.
10. Left operation unit PWB (OPWB-L) Consists of the operation keys and display LEDs.
11. APC PWB (APCPWB) Generates and controls the laser beam.
12. PD PWB (PDPWB) Controls horizontal synchronizing timing of laser beam.

- 13. Interface PWB (IFPWB) Consists of wiring relay circuits.
- 14. Fuser PWB (FUPWB) Consists of wiring relay circuits.
- 15. Drum PWB (DRPWB) Stores the individual drum unit information.
- 16. Developing PWB (DRPWB) Stores the individual developing unit information.
- 17. Fax control PWB (FCPWB)* Modulates, demodulates, compresses, decompresses and smoothes out
image data, and converts resolution of image data.
- 18. NCU PWB (NCUPWB)* Controls connection to the telephone line.
- 19. Printer PWB (PRNPWB)* Controls the printer functions.

*: Option

(2) Switches and sensors






Figure 2-2-2 Switches and sensors

1. Main power switch (MSW) Turns the AC power on and off.
2. Safety switch 1 (SSW1) Breaks the safety circuit when the left cover 1 is opened.
3. Safety switch 2 (SSW2) Breaks the safety circuit when the front cover is opened.
4. Upper paper switch (PSW-U) Detects the presence of paper in the cassette 1.
5. Lower paper switch (PSW-L) Detects the presence of paper in the cassette 2.
6. Upper lift limit switch (LICSW-U) Detects the cassette 1 lift reaching the upper limit.
7. Lower lift limit switch (LICSW-L) Detects the cassette 2 lift reaching the upper limit.
8. Upper paper size length switch (PLSW-U) Detects the length of paper in the cassette 1.
9. Lower paper size length switch (PLSW-L) Detects the length of paper in the cassette 2.
10. Upper paper size width switch (PWSW-U) Detects the width of paper in the cassette 1.
11. Lower paper size width switch (PWSW-L) Detects the width of paper in the cassette 2.

12. MP paper switch (MPPSW) Detects the presence of paper on the MP tray.
13. MP paper size length switch
(MPPLSW) Detects the length of paper on the MP tray.
14. MP paper size width switch
(MPPWSW) Detects the width of paper on the MP tray.
15. Feed switch 1 (FSW1) Controls feed clutch 1 drive timing.
16. Feed switch 2 (FSW2) Controls feed clutch 2 drive timing
17. Feed switch 3 (FSW3) Controls feed clutch 3 drive timing
18. MP feed switch (MPFSW) Controls MP feed clutch drive timing
19. Scanner home position switch (SHPSW)..... Detects the optical system in the home position.
20. Original detection switch (ODSW) Operates the original size detection sensor.
21. Original size detection sensor (OSDS) Detects the size of the original.
22. Registration switch (RSW) Controls the secondary paper feed start timing.
23. Eject switch (ESW) Detects a paper misfeed in the fuser section.
24. Feedshift switch (FSSW) Detects a paper misfeed in the switchback section in a duplex copy.
25. Toner sensor (TNS)..... Detects the toner density in the developing unit.
26. Toner container detection switch
(TCDSW) Detects the presence of the toner container.
27. Toner container sensor (TCS)..... Detects the quantity of toner in a toner container.
28. Fuser thermistor 1 (FTH1) Detects the heat roller temperature.
29. Fuser thermistor 2 (FTH2) Detects the heat roller temperature.
30. Fuser thermostat 1 (FTS1)..... Prevents overheating in the fuser section.
31. Fuser thermostat 2 (FTS2)..... Prevents overheating in the fuser section.
32. Duplex paper conveying switch
(DUPPCSW) Detects a paper jam in the duplex section.
33. Left cover 2 switch (LC2SW) Detects the opening and closing of the left cover 2.
34. Overflow sensor (OFS) Detects when the waste toner box is full.
35. Humidity sensor (HUMS) Detects absolute humidity.
36. Temperature sensor (TEMS)..... Detects inner temperature.


(3) Motors**Figure 2-2-3 Motors**

- | | |
|-------------------------------------|--|
| 1. Main motor (MM)..... | Drives developing section and fuser section. |
| 2. Drum motor (DM)..... | Drives the drum. |
| 3. Paper feed motor (PFM)..... | Drives paper feed section. |
| 4. Upper lift motor (LM-U)..... | Drives cassette 1 lift. |
| 5. Lower lift motor (LM-L)..... | Drives cassette 2 lift. |
| 6. Scanner motor (SM)..... | Drives the optical system. |
| 7. Eject motor (EM)..... | Drives the eject section. |
| 8. Toner feed motor (TFM)..... | Replenishes toner. |
| 9. Polygon motor (PM)..... | Drives the polygon mirror. |
| 10. Cooling fan motor 1 (CFM1)..... | Cools the machine interior. |
| 11. Cooling fan motor 2 (CFM2)..... | Cools the machine interior. |
| 12. Cooling fan motor 3 (CFM3)..... | Cools the machine interior (around the power source PWB). |
| 13. Cooling fan motor 4 (CFM4)..... | Cools the machine interior and supports paper transfer for duplex copying. |
| 14. Cooling fan motor 5 (CFM5)..... | Cools the machine interior and supports paper transfer for duplex copying. |
| 15. Cooling fan motor 6 (CFM6)..... | Cools the machine interior (eject section). |

(4) Clutches and solenoids**Figure 2-2-4 Clutches and solenoids**


- | | |
|---|---|
| 1. Upper paper feed clutch (PFCL-U) | Primary paper feed from the cassette 1. |
| 2. Lower paper feed clutch (PFCL-L) | Primary paper feed from the cassette 2. |
| 3. Feed clutch 1 (FCL1) | Controls the drive of feed roller. |
| 4. Feed clutch 2 (FCL2) | Controls the drive of feed roller. |
| 5. Feed clutch 3 (FCL3) | Controls the drive of feed roller. |
| 6. MP paper feed clutch (MPPFCL) | Primary paper feed from the MP tray. |
| 7. MP feed clutch (MPFCL) | Controls the drive of MP feed roller. |
| 8. Registration clutch (RCL) | Secondary paper feed. |
| 9. Duplex feed clutch (DUPFCL) | Controls the drive of the duplex feed roller. |
| 10. Toner feed clutch (TFCL) | Replenishes toner. |
| 11. Feedshift solenoid (FSSOL) | Operates the feedshift guide. |

www.tonerplus.com.ua

(5) Other electrical components**Figure 2-2-5 Other electrical components**

- | | |
|--------------------------------|--|
| 1. Exposure lamp (EL) | Exposes originals. |
| 2. Cleaning lamp (CL) | Removes residual charge from the drum surface. |
| 3. Fuser heater M (FH-M) | Heats the heat roller. |
| 4. Fuser heater S (FH-S) | Heats the heat roller. |
| 5. Drum heater (DH) | Dehumidifies the image formation section. |
| 6. Cassette heater (CH) | Dehumidifies the cassette section. |

This page is intentionally left blank.

2-3-1 Power source PWB**Figure 2-3-1 Power source PWB silk-screen diagram**

| Connector | Pin No. | Signal | I/O | Voltage | Description |
|--|---------|---------|-----|------------------------------|------------------------------|
| TB Connected to the AC inlet and main power switch | TB1 | LIVE | I | 120 V AC 220-240 V AC | AC power input |
| | TB2 | NEUTRAL | I | 120 V AC 220-240 V AC | AC power input |
| | TB3 | LIVE | O | 120 V AC 220-240 V AC | AC power output to MSW |
| | TB4 | LIVE | I | 120 V AC 220-240 V AC | AC power input from MSW |
| YC1 Connected to the cassette heater | 1 | LIVE | O | 120 V AC 220-240 V AC | AC power output |
| | 2 | N.C. | - | - | Not used |
| | 3 | N.C. | - | - | Not used |
| | 4 | NEUTRAL | O | 120 V AC 220-240 V AC | AC power output |
| YC2 Connected to the cassette heater | 1 | LIVE | O | 120 V AC 220-240 V AC | AC power output |
| | 2 | N.C. | - | - | Not used |
| | 3 | N.C. | - | - | Not used |
| | 4 | NEUTRAL | O | 120 V AC 220-240 V AC | AC power output |
| YC3 Connected to the fuser heater M/S | 1 | NEUTRAL | O | 120/0 V AC 220-240/0 V AC | FH-M: On/Off |
| | 2 | NEUTRAL | O | 120/0 V AC 220-240/0 V AC | FH-S: On/Off |
| | 3 | LIVE | O | 120 V AC 220-240 V AC | AC power output to FM-M/S |
| YC4 Connected to the interface PWB | 1 | +5V | O | 5 V DC | 5 V DC power output to MPWB |
| | 2 | +5V | O | 5 V DC | 5 V DC power output to MPWB |
| | 3 | +5VSL | O | 5 V DC | 5 V DC power output to MPWB |
| | 4 | N.C. | - | - | Not used |
| | 5 | +24VSL | O | 24 V DC | 24 V DC power output to MPWB |
| | 6 | GND | - | - | Ground |
| | 7 | GND | - | - | Ground |
| | 8 | GND | - | - | Ground |
| | 9 | GND | - | - | Ground |
| | 10 | N.C. | - | - | Not used |
| YC6 Connected to the cooling fan motor 3 | 1 | FAN3DRN | O | 0/24 V DC | CFM3: On/Off |
| | 2 | +24VSL | O | 24 V DC | 24 V DC power output to CFM3 |
| YC7 Connected to the engine PWB | 1 | MHEATN | I | 0/5 V DC | FH-M: On/Off |
| | 2 | SHEATN | I | 0/5 V DC | FH-S: On/Off |
| | 3 | FAN3DRN | I | 0/24 V DC | CFM3: On/Off |
| | 4 | GND | - | - | Ground |
| | 5 | ZCROSSC | O | 0/5 V DC (pulse) | Zero-cross signal |
| | 6 | SLEEPN | O | 0/5 V DC | Sleep signal: On/Off |

| Connector | Pin No. | Signal | I/O | Voltage | Description |
|--|---------|--------|-----|---------|---|
| YC8 Connected to the engine PWB | 1 | +5VSL | O | 5 V DC | 5 V DC power output to EPWB |
| | 2 | GND | - | - | Ground |
| | 3 | GND | - | - | Ground |
| | 4 | +24VSL | O | 24 V DC | 24 V DC power output to EPWB |
| | 5 | +24VSL | O | 24 V DC | 24 V DC power output to EPWB |
| YC9 Connected to the optional document finisher | 1 | GND | - | - | Ground |
| | 2 | GND | - | - | Ground |
| | 3 | GND | - | - | Ground |
| | 4 | GND | - | - | Ground |
| | 5 | GND | - | - | Ground |
| | 6 | GND | - | - | Ground |
| YC10 Connected to the optional paper feeder and optional document finisher | 1 | +5VSL | O | 5 V DC | 5 V DC power output to document finisher |
| | 2 | +24VSL | O | 24 V DC | 24 V DC power output to document finisher |
| | 3 | +24VSL | O | 24 V DC | 24 V DC power output to paper feeder |
| | 4 | GND | - | - | Ground |
| | 5 | GND | - | - | Ground |
| YC11 Connected to the main PWB | 1 | GND | - | - | Ground |
| | 2 | +5VSL | O | 5 V DC | 5 V DC power output to MPWB |
| YC12 Connected to the engine PWB | 1 | N.C. | - | - | Not used |
| | 2 | +24VIL | O | 24 V DC | 24 V DC power output to EPWB |

2-3-2 Engine PWB




Figure 2-3-2 Engine PWB silk-screen diagram

| Connector | Pin No. | Signal | I/O | Voltage | Description |
|--|---------|------------|-----|------------------|--|
| YC1 Connected to the over-flow sensor, cleaning lamp, toner sensor, humidity sensor, toner feed motor, developing PWB, drum PWB and fuser unit | A1 | GND | - | - | Ground |
| | A2 | TONEFUL | I | 0/5 V DC | OFS: On/Off |
| | A3 | +5V | O | 5 V DC | 5 V DC power output to OFS |
| | A4 | +24V | O | 24 V DC | 24 V DC power output to CL |
| | A5 | ERASE3N | O | 0/24 V DC | CL: On/Off |
| | A6 | ERASE2N | O | 0/24 V DC | CL: On/Off |
| | A7 | ERASE1N | O | 0/24 V DC | CL: On/Off |
| | A8 | GND | - | - | Ground |
| | A9 | DEVDET N | I | 0/5 V DC | TNS: On/Off |
| | A10 | +5V | O | 5 V DC | 5 V DC power output to TNS |
| | A11 | +5V | O | 5 V DC | 5 V DC power output to HUMS |
| | A12 | HUMID_SDA | I/O | Analog | HUMS detection voltage signal |
| | A13 | GND | - | - | Ground |
| | A14 | HUMID_SCL | O | 0/5 V DC (pulse) | HUMS clock signal |
| | A15 | TNMOT24V | O | 24 V DC | 24 V DC power output to TFM |
| | A16 | TNMOTREM | O | 0/24 V DC | TFM: On/Off |
| | B1 | IUID1DET N | I | 0/5 V DC | Developing unit detection signal |
| | B2 | GND | - | - | Ground |
| | B3 | IUID1SDA | I/O | 0/5 V DC (pulse) | Developing unit EEPROM data signal |
| | B4 | IUID1SCL | O | 0/5 V DC (pulse) | Developing unit EEPROM clock signal |
| | B5 | +5V | O | 5 V DC | 5 V DC power output to developing unit |
| | B6 | IUID2DET N | I | 0/5 V DC | Drum unit detection signal |
| | B7 | GND | - | - | Ground |
| | B8 | IUID2SDA | I/O | 0/5 V DC (pulse) | Drum unit EEPROM data signal |
| | B9 | IUID2SCL | O | 0/5 V DC (pulse) | Drum unit EEPROM clock signal |
| | B10 | +5V | O | 5 V DC | 5 V DC power output to drum unit |
| | B11 | THEAMA_GND | - | - | Ground |
| | B12 | THEAMA | I | Analog | FTH1 detection voltage signal |
| | B13 | FUFMLTN | O | 0/5 V DC | Fuse cut signal |
| | B14 | FIXTHCEN | I | Analog | FTH2 detection voltage signal |
| | B15 | N.C. | - | - | Not used |
| | B16 | +3.3V | O | 3.3 V DC | 3.3 V DC power output to FUPWB |
| YC2 Connected to the polygon motor, cooling fan motor 1, toner container sensor and toner container detection switch | 1 | +24VSL | O | 24 V DC | 24 V DC power output to PM |
| | 2 | GND | - | - | Ground |
| | 3 | PLGDRN | O | 0/24 V DC | PM: On/Off |
| | 4 | PLGRDYN | I | 0/5 V DC | PM ready signal |
| | 5 | PLGCLKN | O | 0/5 V DC (pulse) | PM clock signal |
| | 6 | FAN1 DRN | O | 0/24 V DC | CFM1: On/Off |
| | 7 | FAN1 POW | O | 24 V DC | 24 V DC power output to CFM1 |
| | 8 | GND | - | - | Ground |
| | 9 | COUNTSENS | I | 0/5 V DC | TCS: On/Off |
| | 10 | +5VSL | O | 5 V DC | 5 V DC power output to TCS |
| | 15 | CONTSW | I | 0/5 V DC | TCDSW: On/Off |
| | 16 | GND | - | - | Ground |

| Connector | Pin No. | Signal | I/O | Voltage | Description |
|--|---------|-----------|-----|------------------|--|
| YC4 Connected to the optional built-in finisher and optional job separator | 1 | RLSOLN | O | 0/24 V DC | FSSOL (return): On/Off |
| | 2 | SLSOLN | O | 0/24 V DC | FSSOL (activate): On/Off |
| | 3 | SCLK | O | 0/5 V DC (pulse) | Built-in finisher/Job separator clock signal |
| | 4 | LOPSDI | I | 0/5 V DC (pulse) | Built-in finisher serial communication data signal/Job separator JBESW: On/Off |
| | 5 | LOPSDO | O | 0/5 V DC (pulse) | Built-in finisher/Job separator serial communication data signal |
| | 6 | LOPRDY | I | 0/5 V DC | Built-in finisher ready signal/Job separator EPDSW: On/Off |
| | 7 | LOPSEL | O | 0/5 V DC | Built-in finisher/Job separator select signal |
| | 8 | GND | - | - | Ground |
| | 9 | +5VSL | O | 5 V DC | 5 V DC power output to built-in finisher/Job separator |
| | 10 | GND | - | - | Ground |
| | 11 | GND | - | - | Ground |
| | 12 | +24VSL | O | 24 V DC | 24 V DC power output to built-in finisher/Job separator |
| | 13 | +24VSL | O | 24 V DC | 24 V DC power output to built-in finisher/Job separator |
| YC5 Connected to the optional document finisher | 1 | DET | I | 0/5 V DC | Document finisher connection signal |
| | 2 | DFSDO | O | 0/5 V DC (pulse) | Document finisher serial communication data signal |
| | 3 | DFSDI | I | 0/5 V DC (pulse) | Document finisher serial communication data signal |
| | 4 | DFSCCLK | O | 0/5 V DC (pulse) | Document finisher clock signal |
| | 5 | DFSEL | O | 0/5 V DC | Document finisher select signal |
| | 6 | SISEL | - | - | Not used |
| | 7 | DFRDY | I | 0/5 V DC | Document finisher ready signal |
| | 8 | SIRDY | - | - | Not used |
| YC7 Connected to the MP tray unit | 1 | MPFSIZE0 | I | 0/5 V DC | MPPWSW: On/Off |
| | 2 | MPFSIZE1 | I | 0/5 V DC | MPPWSW: On/Off |
| | 3 | MPFSIZE2 | I | 0/5 V DC | MPPWSW: On/Off |
| | 4 | GND | - | - | Ground |
| | 5 | +5VSL | O | 5 V DC | 5 V DC power output to MPPSW |
| | 6 | MPFPAPS | I | 0/5 V DC | MPPSW: On/Off |
| | 7 | GND | - | - | Ground |
| | 8 | +24VSL | O | 24 V DC | 24 V DC power output to MPPFCL |
| | 9 | MPFPAPCL | O | 0/24 V DC | MPPFCL: On/Off |
| | 10 | +24VSL | O | 24 V DC | 24 V DC power output to MPFCL |
| | 11 | MPFFECL | O | 0/24 V DC | MPFCL: On/Off |
| | 12 | +5VSL | O | 5 V DC | 5 V DC power output to MPPLSW |
| | 13 | MPFLENGTH | I | 0/5 V DC | MPPLSW: On/Off |
| | 14 | GND | - | - | Ground |

| Connector | Pin No. | Signal | I/O | Voltage | Description |
|---|---------|-------------|-----|-----------|---------------------------------|
| YC8 Connected to the feed switch 1/2/3, feed clutch 1/2/3, left cover 2 switch, upper/lower paper feed clutches, toner feed clutch, registration switch, registration clutch, duplex feed clutch, duplex paper conveying switch and cooling fan motor 4/5 | A1 | GND | - | - | Ground |
| | A2 | LFEED_SW3 | I | 0/5 V DC | FSW3: On/Off |
| | A3 | +5V | O | 5 V DC | 5 V DC power output to FSW3 |
| | A4 | +24VR | O | 24 V DC | 24 V DC power output to FCL3 |
| | A5 | FEED3CL | O | 0/24 V DC | FCL3: On/Off |
| | A6 | GND | - | - | Ground |
| | A7 | LFEED_SW2 | I | 0/5 V DC | FSW2: On/Off |
| | A8 | +5V | O | 5 V DC | 5 V DC power output to FSW2 |
| | A9 | GND | - | - | Ground |
| | A10 | FECOSW | I | 0/5 V DC | LC2SW: On/Off |
| | A11 | +24VR | O | 24 V DC | 24 V DC power output to FCL2 |
| | A12 | FEED2CL | O | 0/24 V DC | FCL2: On/Off |
| | A13 | UPFECL | O | 0/24 V DC | PFCL-U: On/Off |
| | A14 | +24V | O | 24 V DC | 24 V DC power output to PFCL-U |
| | A15 | LOFECL | O | 0/24 V DC | PFCL-L: On/Off |
| | A16 | +24V | O | 24 V DC | 24 V DC power output to PFCL-L |
| | A17 | TONERCLREM | O | 0/24 V DC | TFCL: On/Off |
| | A18 | TONERCL+24V | O | 24 V DC | 24 V DC power output to TFCL |
| | A19 | N.C. | - | - | Not used |
| | B1 | GND | - | - | Ground |
| | B2 | RESISTSW | I | 0/5 V DC | RSW: On/Off |
| | B3 | +5V | O | 5 V DC | 5 V DC power output to RSW |
| | B4 | GND | - | - | Ground |
| | B5 | UFEED_SW | I | 0/5 V DC | FSW1: On/Off |
| | B6 | +5V | O | 5 V DC | 5 V DC power output to FSW1 |
| | B7 | +24VR | O | 24 V DC | 24 V DC power output to FCL1 |
| | B8 | FEED1CL | O | 0/24 V DC | FCL1: On/Off |
| | B9 | DUPCL | O | 0/24 V DC | DUPFCL: On/Off |
| | B10 | +24VR | O | 24 V DC | 24 V DC power output to DUPFCL |
| | B11 | GND | - | - | Ground |
| | B12 | DUPSW | I | 0/5 V DC | DUPPCSW: On/Off |
| | B13 | +5V | O | 5 V DC | 5 V DC power output to DUPPCSW |
| | B14 | +24VR | O | 24 V DC | 24 V DC power output to RCL |
| | B15 | RESFECL | O | 0/24 V DC | RCL: On/Off |
| | B16 | FAN4REM | O | 0/24 V DC | CFM4: On/Off |
| | B17 | +24VR | O | 24 V DC | 24 V DC power output to CFM4 |
| | B18 | FAN5REM | O | 0/24 V DC | CFM5: On/Off |
| | B19 | +24VR | O | 24 V DC | 24 V DC power output to CFM5 |
| YC9 Connected to the feed-shift switch and eject switch | 1 | GND | - | - | Ground |
| | 2 | SEPSWN | I | 0/5 V DC | FSSW: On/Off |
| | 3 | EXTSWN | I | 0/5 V DC | ESW: On/Off |
| | 4 | +5V2 | O | 5 V DC | 5 V DC power output to FSSW/ESW |

| Connector | Pin No. | Signal | I/O | Voltage | Description |
|--|---------|----------|-----|------------------|---------------------------------------|
| YC10 Connected to the main motor, drum motor, paper feed motor and drum heater | 1 | +24VSL | O | 24 V DC | 24 V DC power output to MM |
| | 2 | +24VSL | O | 24 V DC | 24 V DC power output to DM |
| | 3 | +24VSL | O | 24 V DC | 24 V DC power output to MM |
| | 4 | +24VSL | O | 24 V DC | 24 V DC power output to DM |
| | 5 | GND | - | - | Ground |
| | 6 | GND | - | - | Ground |
| | 7 | GND | - | - | Ground |
| | 8 | GND | - | - | Ground |
| | 9 | MMOTLOCK | I | 0/5 V DC | MM lock signal |
| | 10 | DMOTLOCK | I | 0/5 V DC | DM lock signal |
| | 11 | MMOTON | O | 0/24 V DC | MM: On/Off |
| | 12 | DMOTON | O | 0/24 V DC | DM: On/Off |
| | 13 | MMOTCCW | O | 0/5 V DC | MM rotation switch signal |
| | 14 | DMOTCCW | O | 0/5 V DC | DM rotation switch signal |
| | 15 | MMOTCLK | O | 0/5 V DC (pulse) | MM clock signal |
| | 16 | DMOTCLK | O | 0/5 V DC (pulse) | DM clock signal |
| | 17 | +24VSL | O | 24 V DC | 24 V DC power output to PFM |
| | 18 | +24VSL | O | 24 V DC | 24 V DC power output to PFM |
| | 19 | GND | - | - | Ground |
| | 20 | GND | - | - | Ground |
| | 21 | SMOTLOCK | I | 0/5 V DC | PFM lock signal |
| | 22 | SMOTON | O | 0/24 V DC | PFM: On/Off |
| | 23 | SMOTCCW | O | 0/5 V DC | PFM rotation switch signal |
| | 24 | SMOTCLK | O | 0/5 V DC (pulse) | PFM clock signal |
| | 25 | +24VSL | O | 24 V DC | 24 V DC power output to DH |
| | 26 | DHEATREM | O | 0/24 V DC | DH: On/Off |
| YC11 Connected to the feed-shift solenoid | 1 | +24V1 | O | 24 V DC | 24 V DC power output to FSSOL |
| | 2 | DFSOLDR | O | 0/24 V DC | FSSOL (activate): On/Off |
| | 3 | DFSOLRS | O | 0/24 V DC | FSSOL (return): On/Off |
| YC12 Connected to the high voltage PWB | 1 | +24VIL2 | O | 24 V DC | 24 V DC power output to HVTPWB |
| | 2 | DHVSUP | O | 0/5 V DC | Developing slowup signal |
| | 3 | DHVCLKC | O | 0/5 V DC (pulse) | Developing bias clock signal |
| | 4 | SHVDRN | O | 0/5 V DC | Separation high voltage: On/Off |
| | 5 | MHVDRN | O | 0/5 V DC | Main charging high voltage: On/Off |
| | 6 | GND | - | - | Ground |
| | 7 | GND | - | - | Ground |
| | 8 | DHVADJC | O | Analog | Developing bias adjust signal |
| | 9 | SHVISELN | O | 0/5 V DC | Separation high voltage switch signal |
| | 10 | THVADJC | O | Analog | Transfer high voltage adjust signal |
| | 11 | THVDRN | O | 0/5 V DC | Transfer high voltage: On/Off |
| | 12 | +5V | O | 5 V DC | 5 V DC power output to HVTPWB |

| Connector | Pin No. | Signal | I/O | Voltage | Description |
|--|---------|-------------|-----|-------------------|--------------------------------|
| YC13 Connected to the cooling fan motor 2 | 1 | FAN2POW | O | 24 V DC | 24 V DC power output to CFM2 |
| | 2 | FAN2DRN | O | 0/24 V DC | CFM2: On/Off |
| YC14 Connected to the eject motor | 1 | COMDA | O | 0/24 V DC (pulse) | EM drive control signal (A) |
| | 2 | COMDNB | O | 0/24 V DC (pulse) | EM drive control signal (_B) |
| | 3 | COMDNA | O | 0/24 V DC (pulse) | EM drive control signal (_A) |
| | 4 | COMDB | O | 0/24 V DC (pulse) | EM drive control signal (B) |
| YC15 Connected to the cooling fan motor 6 and scanner motor | 1 | ISNDA | O | 0/24 V DC (pulse) | SM drive control signal (A) |
| | 2 | ISMDNB | O | 0/24 V DC (pulse) | SM drive control signal (_B) |
| | 3 | ISMDNA | O | 0/24 V DC (pulse) | SM drive control signal (_A) |
| | 4 | ISMDB | O | 0/24 V DC (pulse) | SM drive control signal (B) |
| | 5 | +24VSL | O | 24 V DC | 24 V DC power output to CFM6 |
| | 6 | SCAN_FAN | O | 0/5 V DC | CFM6: On/Off |
| YC16 Connected to the scanner inverter PWB | 1 | LAMPN | O | 0/24 V DC | EL: On/Off |
| | 2 | PGND | - | - | Ground |
| | 3 | +24V1 | O | 24 V DC | 24 V DC power output to SINPWB |
| | 4 | +24V1 | O | 24 V DC | 24 V DC power output to SINPWB |
| | 5 | PGND | - | - | Ground |
| | 6 | LAMPN | O | 0/24 V DC | EL: On/Off |
| YC17 Connected to the scanner home position switch, original detection switch and original size detection sensor | 1 | +5VSL | O | 5 V DC | 5 V DC power output to SHPSW |
| | 2 | HPSWN | I | 0/5 V DC | SHPSW: On/Off |
| | 3 | GND | - | - | Ground |
| | 4 | +5VSL | O | 5 V DC | 5 V DC power output to ODSW |
| | 5 | OPSWN | I | 0/5 V DC | ODSW: On/Off |
| | 6 | GND | - | - | Ground |
| | 7 | +5VSL | O | 5 V DC | 5 V DC power output to OSDS |
| | 8 | ORGLSWN | I | 0/5 V DC | OSDS: On/Off |
| | 9 | GND | - | - | Ground |
| YC18 Connected to the power source PWB | 1 | +5VSL | I | 5 V DC | 5 V DC input from PSPWB |
| | 2 | +24VSL | I | 24 V DC | 24 V DC power input from PSPWB |
| | 3 | GND | - | - | Ground |
| | 4 | +24VIL1_IN | I | 24 V DC | 24 V DC power input from SSW1 |
| | 5 | +24VIL1_OUT | O | 24 V DC | 24 V DC power output to SSW2 |
| | 6 | GND | - | - | Ground |
| | 7 | +24VIL2 | I | 24 V DC | 24 V DC power input from SSW2 |
| YC19 Connected to the power source PWB | 1 | SLEEPN | I | 0/5 V DC | Sleep signal: On/Off |
| | 2 | ZCROSSC | I | 0/5 V DC (pulse) | Zero-cross signal |
| | 3 | GND | - | - | Ground |
| | 4 | FAN3DRN | O | 0/24 V DC | CFM3: On/Off |
| | 5 | SHEATN | O | 0/5 V DC | FH-S: On/Off |
| | 6 | MHEATN | O | 0/5 V DC | FH-M: On/Off |

| Connector | Pin No. | Signal | I/O | Voltage | Description |
|---|---------|------------|-----|------------------|---|
| YC20 Connected to the key counter | 1 | +24V1 | O | 24 V DC | 24 V DC power output to key counter |
| | 2 | KEYCN | O | 0/5 V DC | Key counter signal |
| | 3 | SGND | - | - | Ground |
| | 4 | KEYENBN | I | 0/5 V DC | Key counter connection signal |
| YC22 Connected to the upper/lower paper size length switches, optional paper feeder and MP feed switch | 1 | +24VIL2PF2 | O | 24 V DC | 24 V DC power output to PWSW-L |
| | 2 | +24VIL2PF1 | O | 24 V DC | 24 V DC power output to PWSW-U |
| | 3 | +24VIL2 | O | 24 V DC | 24 V DC power output to PWSW-L |
| | 4 | +24VIL2 | O | 24 V DC | 24 V DC power output to PWSW-U |
| | 5 | LODIG1 | I | 0/5 V DC | PWSW-L: On/Off |
| | 6 | HIDIG1 | I | 0/5 V DC | PWSW-U: On/Off |
| | 7 | LODIG0 | I | 0/5 V DC | PWSW-L: On/Off |
| | 8 | HIDIG0 | I | 0/5 V DC | PWSW-U: On/Off |
| | 9 | GND | - | - | Ground |
| | 10 | GND | - | - | Ground |
| | 11 | LODIG2 | I | 0/5 V DC | PWSW-L: On/Off |
| | 12 | HIDIG2 | I | 0/5 V DC | PWSW-U: On/Off |
| | 13 | GND | - | - | Ground |
| | 14 | +5VSL | O | 5 V DC | 5 V DC power output to paper feeder |
| | 15 | PFSEL | O | 0/5 V DC | Paper feeder select signal |
| | 16 | PFCLK | O | 0/5 V DC (pulse) | Paper feeder clock signal |
| | 17 | PFSDI | I | 0/5 V DC (pulse) | Paper feeder serial communication data signal |
| | 18 | PFSDO | O | 0/5 V DC (pulse) | Paper feeder serial communication data signal |
| | 19 | PFREADY | I | 0/5 V DC | Paper feeder ready signal |
| | 20 | PFSEED | O | 0/5 V DC | Paper feeder feed signal |
| | 21 | GND | - | - | Ground |
| | 22 | BYPFEEDSW | I | 0/5 V DC | MPFSW: On/Off |
| | 23 | +5VSL | O | 5 V DC | 5 V DC power output to MPFSW |
| | 24 | N.C. | - | - | Not used |
| YC23 Connected to the upper/lower lift limit switches, upper/lower paper switches, upper/lower lift motors and upper/lower paper size length switches | A1 | GND | - | - | Ground |
| | A2 | LOLIFTSW | I | 0/5 V DC | LICSW-L: On/Off |
| | A3 | +5VSL | O | 5 V DC | 5 V DC power output to LICSW-L |
| | A4 | GND | - | - | Ground |
| | A5 | LOPAPSW | I | 0/5 V DC | PSW-L: On/Off |
| | A6 | +5VSL | O | 5 V DC | 5 V DC power output to PSW-L |
| | A7 | LOLIFTSW2 | I | 0/5 V DC | LM-L paper gauge signal |
| | A8 | GND | - | - | Ground |
| | A9 | LOLIFTSW1 | I | 0/5 V DC | LM-L paper gauge signal |
| | A10 | GND | - | - | Ground |
| | A11 | LOLIFTREM | O | 0/24 V DC | LM-L: On/Off |
| | A12 | LOLENGSW | I | 0/5 V DC | PLSW-L: On/Off |
| | A13 | GND | - | - | Ground |
| | B1 | GND | - | - | Ground |
| | B2 | HILENGSW | I | 0/5 V DC | PLSW-U: On/Off |

| Connector | Pin No. | Signal | I/O | Voltage | Description |
|---|---------|-----------|-----|--------------------|-------------------------------------|
| YC23 Connected to the upper/lower lift limit switches, upper/lower paper switches, upper/lower lift motors and upper/lower paper size length switches | B3 | HILIFTSW2 | I | 0/5 V DC | LM-U paper gauge signal |
| | B4 | GND | - | - | Ground |
| | B5 | HILIFTSW1 | I | 0/5 V DC | LM-U paper gauge signal |
| | B6 | GND | - | - | Ground |
| | B7 | HILIFTREM | O | 0/24 V DC | LM-U: On/Off |
| | B8 | GND | - | - | Ground |
| | B9 | HILIFTSW | I | 0/5 V DC | LICSW-U: On/Off |
| | B10 | +5VSL | O | 5 V DC | 5 V DC power output to LICSW-U |
| | B11 | GND | - | - | Ground |
| | B12 | HIPAPSW | I | 0/5 V DC | PSW-U: On/Off |
| | B13 | +5VSL | O | 5 V DC | 5 V DC power output to PSW-U |
| YC24 Connected to the optional DP | 1 | GND | - | - | Ground |
| | 2 | GND | - | - | Ground |
| | 3 | GND | - | - | Ground |
| | 4 | GND | - | - | Ground |
| | 5 | ORGVSYNC | I | 0/5 V DC | Original scanning interval signal |
| | 6 | DP_RDY | I | 0/5 V DC | DP ready signal |
| | 7 | DP_SEL | O | 0/5 V DC | DP select signal |
| | 8 | SCLK | O | 0/5 V DC (pulse) | DP clock signal |
| | 9 | SDO | O | 0/5 V DC (pulse) | DP serial communication data signal |
| | 10 | SDI | I | 0/5 V DC (pulse) | DP serial communication data signal |
| YC25 Connected to the power source PWB | 1 | N.C. | - | - | Not used |
| | 2 | N.C. | - | - | Not used |
| | 3 | N.C. | - | - | Not used |
| | 4 | +24VIL | I | 24V DC | 24 V DC power input from PSPWB |
| YC26 Connected to the main PWB | A1 | +5V1 | O | 5 V DC | 5 V DC power output to MPWB |
| | A2 | GND | - | - | Ground |
| | A3 | AFESEL | O | 0/3.3 V DC | Select signal |
| | A4 | AFERDY | I | 0/3.3 V DC | Ready signal |
| | A5 | AFESI | I | 0/3.3 V DC (pulse) | Serial communication data signal |
| | A6 | AFESCKN | I | 0/3.3 V DC (pulse) | Clock signal |
| | A7 | AFESDO | O | 0/3.3 V DC (pulse) | Serial communication data signal |
| | A8 | E2CSDIR | O | 0/3.3 V DC | E2CSDIR signal |
| | A9 | E2CSBSY | O | 0/3.3 V DC | E2CSBSY signal |
| | A10 | E2CEGSI | I | 0/3.3 V DC (pulse) | Serial communication data signal |
| | A11 | E2CSCKN | I | 0/3.3 V DC (pulse) | Clock signal |
| | A12 | E2CEGSO | O | 0/3.3 V DC (pulse) | Serial communication data signal |
| | A13 | SLEEP | I | 0/3.3 V DC | Sleep signal: On/Off |
| | A14 | 24VDN | O | 0/3.3 V DC | 24 V DC power shut-off signal |
| | A15 | OPSWN | - | - | Not used |
| | B1 | QVSYNC | O | 0/3.3 V DC | Original scanning interval signal |
| | B2 | SCANHLDN | I | 0/3.3 V DC | Scanner hold signal |
| | B3 | EGSCANRDY | I | 0/3.3 V DC | Printing image interval signal |

| Connector | Pin No. | Signal | I/O | Voltage | Description |
|--|---------|-----------|-----|------------|------------------------------------|
| YC26 Connected to the main PWB | B4 | GND | - | - | Ground |
| | B5 | OUTPEN | O | 0/3.3 V DC | Laser diode output signal |
| | B6 | GND | - | - | Ground |
| | B7 | E2CEGIRN | O | 0/3.3 V DC | E2CEGIRN signal |
| | B8 | GND | - | - | Ground |
| | B9 | EGHLDN | I | 0/3.3 V DC | Engine hold signal |
| | B10 | GND | - | - | Ground |
| | B11 | EGRESETN | I | 0/3.3 V DC | Reset signal |
| | B12 | GND | - | - | Ground |
| | B13 | PDMASKN | O | 0/3.3 V DC | Auxiliary scanning interval signal |
| | B14 | GND | - | - | Ground |
| | B15 | +3.3V_EGN | O | 3.3 V DC | 3.3 V DC power output to MPWB |
| YC31 Connected to the optional DP | 1 | +24VSL | O | 24 V DC | 24 V DC power output to DP |
| | 2 | GND | - | - | Ground |
| | 3 | +5VSL | O | 5 V DC | 5 V DC power output to DP |
| | 4 | GND | - | - | Ground |
| YC32 Connected to the temperature sensor | 1 | +5VSL | O | 5 V DC | 5 V DC power output to TEMS |
| | 2 | HUMIDA | I | Analog | TEMS detection voltage signal |
| | 3 | GND | - | - | Ground |
| | 4 | TEMPA | I | Analog | TEMS detection voltage signal |

2-3-3 Main PWB




Figure 2-3-3 Main PWB silk-screen diagram

| Connector | Pin No. | Signal | I/O | Voltage | Description |
|--|---------|---------|-----|--------------------|--------------------------------|
| YC4 Connected to the CCD PWB | 1 | 5V | O | 5 V DC | 5 V DC power output to CCDPWB |
| | 2 | 5V | O | 5 V DC | 5 V DC power output to CCDPWB |
| | 3 | 5V | O | 5 V DC | 5 V DC power output to CCDPWB |
| | 4 | CCDB | I | Analog | CCD output signal |
| | 5 | CCDBN | - | - | Ground |
| | 6 | CCDG | I | Analog | CCD output signal |
| | 7 | CCDGN | - | - | Ground |
| | 8 | CCDR | I | Analog | CCD output signal |
| | 9 | CCDRN | - | - | Ground |
| | 10 | GND | - | - | Ground |
| | 11 | GND | - | - | Ground |
| | 12 | SHBW | O | 0/3.3 V DC | B/W shift signal |
| | 13 | GND | - | - | Ground |
| | 14 | SHRGW | O | 0/3.3 V DC | Color shift signal |
| | 15 | GND | - | - | Ground |
| | 16 | SW | O | 0/3.3 V DC | Color/B/W switch signal |
| | 17 | GND | - | - | Ground |
| | 18 | RSN | O | 0/3.3 V DC | CCD control signal |
| | 19 | GND | - | - | Ground |
| | 20 | CCDCLKN | O | 0/3.3 V DC (pulse) | CCD clock signal |
| | 21 | GND | - | - | Ground |
| | 22 | CPN | O | 0/3.3 V DC | CCD control signal |
| | 23 | N.C. | - | - | Not used |
| | 24 | 10V | O | 10 V DC | 10 V DC power output to CCDPWB |
| YC5 Connected to the LSU | 1 | PDN | I | 0/3.3 V DC | Laser sync signal |
| | 2 | SGND | - | - | Ground |
| | 3 | OUTPEN | O | 0/3.3 V DC | Laser diode output signal |
| | 4 | SAMPLEN | O | 0/3.3 V DC | Sample hold signal |
| | 5 | VDOP | O | - | Image data signal |
| | 6 | VDON | O | - | Image data signal |
| | 7 | +5V1 | O | 5 V DC | 5 V DC power output to APCPWB |
| YC6 Connected to the interface PWB | A1 | 24V | I | 24 V DC | 24 V DC power input from IFPWB |
| | A2 | 24V | I | 24 V DC | 24 V DC power input from IFPWB |
| | A3 | GND | - | - | Ground |
| | A4 | 5VSL | I | 5 V DC | 5 V DC power input from IFPWB |
| | A5 | 5VSL | I | 5 V DC | 5 V DC power input from IFPWB |
| | A6 | 5V | I | 5 V DC | 5 V DC power input from IFPWB |
| | A7 | 5V | I | 5 V DC | 5 V DC power input from IFPWB |
| | A8 | 5V | I | 5 V DC | 5 V DC power input from IFPWB |
| | A9 | 5V | I | 5 V DC | 5 V DC power input from IFPWB |
| | A10 | GND | - | - | Ground |
| | A11 | GND | - | - | Ground |
| | A12 | VD+ | O | Analog | Video data signal |
| | A13 | VD- | O | Analog | Video data signal |
| | A14 | GND | - | - | Ground |

| Connector | Pin No. | Signal | I/O | Voltage | Description |
|---|---------|-----------|-----|--------------------|-----------------------------------|
| YC6 Connected to the inter-face PWB | A15 | EGSO | I | 0/3.3 V DC (pulse) | Serial communication data signal |
| | A16 | SDIR | I | 0/3.3 V DC | SDIR signal |
| | A17 | SBSY | I | 0/3.3 V DC | SBSY signal |
| | A18 | EGIRN | I | 0/3.3 V DC | EGIRN signal |
| | A19 | EGSI | O | 0/3.3 V DC (pulse) | Serial communication data signal |
| | A20 | GND | - | - | Ground |
| | B1 | 24V | I | 24 V DC | 24 V DC power input from IFPWB |
| | B2 | 24V | I | 24 V DC | 24 V DC power input from IFPWB |
| | B3 | GND | - | - | Ground |
| | B4 | 5VSL | I | 5 V DC | 5 V DC power input from IFPWB |
| | B5 | 5VSL | I | 5 V DC | 5 V DC power input from IFPWB |
| | B6 | 5V | I | 5 V DC | 5 V DC power input from IFPWB |
| | B7 | 5V | I | 5 V DC | 5 V DC power input from IFPWB |
| | B8 | 5V | I | 5 V DC | 5 V DC power input from IFPWB |
| | B9 | 5V | I | 5 V DC | 5 V DC power input from IFPWB |
| | B10 | GND | - | - | Ground |
| | B11 | PDN | I | 0/3.3 V DC | Horizontal synchronizing signal |
| | B12 | GND | - | - | Ground |
| | B13 | PDMASK | I | 0/3.3 V DC | PDMASK signal |
| | B14 | LDFAIL | I | 0/3.3 V DC | LDFAIL signal |
| | B15 | OUTPEN | I | 0/3.3 V DC | Laser diode output signal |
| | B16 | GND | - | - | Ground |
| | B17 | SCLK | O | 0/3.3 V DC (pulse) | Clock signal |
| | B18 | GND | - | - | Ground |
| | B19 | SYRSTN | I | 0/3.3 V DC | Reset signal |
| | B20 | GND | - | - | Ground |
| YC7 Connected to the engine PWB | A1 | +5V1 | I | 5 V DC | 5 V DC power input from EPWB |
| | A2 | GND | - | - | Ground |
| | A3 | AFESEL | I | 0/3.3 V DC | Select signal |
| | A4 | AFERDY | O | 0/3.3 V DC | Ready signal |
| | A5 | AFESI | O | 0/3.3 V DC (pulse) | Serial communication data signal |
| | A6 | AFESCLKN | O | 0/3.3 V DC (pulse) | Clock signal |
| | A7 | AFESDO | I | 0/3.3 V DC (pulse) | Serial communication data signal |
| | A8 | E2CSDIR | I | 0/3.3 V DC | E2CSDIR signal |
| | A9 | E2CSBSY | I | 0/3.3 V DC | E2CSBSY signal |
| | A10 | E2CEGSI | O | 0/3.3 V DC (pulse) | Serial communication data signal |
| | A11 | E2CSCKN | O | 0/3.3 V DC (pulse) | Clock signal |
| | A12 | E2CEGSO | I | 0/3.3 V DC (pulse) | Serial communication data signal |
| | A13 | SLEEP | O | 0/3.3 V DC | Sleep signal: On/Off |
| | A14 | 24VDN | I | 0/3.3 V DC | 24 V DC power shut-off signal |
| | A15 | OPSWN | - | - | Not used |
| | B1 | OVSNC | I | 0/3.3 V DC | Original scanning interval signal |
| | B2 | SCANHLDN | O | 0/3.3 V DC | Scanner hold signal |
| | B3 | EGSCANRDY | O | 0/3.3 V DC | Printing image interval signal |
| | B4 | GND | - | - | Ground |

| Connector | Pin No. | Signal | I/O | Voltage | Description |
|--|---------|-----------|-----|------------------|--|
| YC7 Connected to the engine PWB | B5 | OUTPEN | I | 0/3.3 V DC | Laser diode output signal |
| | B6 | GND | - | - | Ground |
| | B7 | E2CEGIRN | I | 0/3.3 V DC | E2CEGIRN signal |
| | B8 | GND | - | - | Ground |
| | B9 | EGHLDN | O | 0/3.3 V DC | Engine hold signal |
| | B10 | GND | - | - | Ground |
| | B11 | EGRESETN | O | 0/3.3 V DC | Reset signal |
| | B12 | GND | - | - | Ground |
| | B13 | PDMASKN | I | 0/3.3 V DC | Auxiliary scanning interval signal |
| | B14 | GND | - | - | Ground |
| | B15 | +3.3V_EGN | I | 3.3 V DC | 3.3 V DC power input from EPWB |
| YC11 Connected to the right operation unit PWB | 1 | DIG_LED_2 | O | 0/5 V DC (pulse) | Operation panel indicator LED drive signal 2 |
| | 2 | DIG_LED_1 | O | 0/5 V DC (pulse) | Operation panel indicator LED drive signal 1 |
| | 3 | SCAN4 | O | 0/5 V DC (pulse) | Scan signal 4 |
| | 4 | SCAN3 | O | 0/5 V DC (pulse) | Scan signal 3 |
| | 5 | SCAN2 | O | 0/5 V DC (pulse) | Scan signal 2 |
| | 6 | SCAN1 | O | 0/5 V DC (pulse) | Scan signal 1 |
| | 7 | DIG_KEY_5 | I | 0/5 V DC (pulse) | Operation panel key scan return signal 5 |
| | 8 | DIG_KEY_4 | I | 0/5 V DC (pulse) | Operation panel key scan return signal 4 |
| | 9 | DIG_KEY_3 | I | 0/5 V DC (pulse) | Operation panel key scan return signal 3 |
| | 10 | DIG_KEY_2 | I | 0/5 V DC (pulse) | Operation panel key scan return signal 2 |
| | 11 | DIG_KEY_1 | I | 0/5 V DC (pulse) | Operation panel key scan return signal 1 |
| | 12 | PH_LED_3 | O | 0/5 V DC (pulse) | LED lighting signal 3 |
| | 13 | PH_KEY_1 | I | 0/5 V DC | Power key: On/Off |
| | 14 | PH_LED_2 | O | 0/5 V DC (pulse) | LED lighting signal 2 |
| | 15 | PH_LED_1 | O | 0/5 V DC (pulse) | LED lighting signal 1 |
| | 16 | SGND | - | - | Ground |
| | 17 | PGND | - | - | Ground |
| | 18 | +24V | O | 24 V DC | 24 V DC power output to OPWB-R |
| | 19 | LAMPOFF | O | 0/5 V DC | LCD back light: On/Off |
| | 20 | N.C | - | - | Not used |
| YC12 Connected to the upper operation unit PWB | A1 | BUZZER | O | 0/5 V DC | Buzzer signal |
| | A2 | X1 | O | Analog | Touch panel X1 position signal |
| | A3 | Y1 | O | Analog | Touch panel Y1 position signal |
| | A4 | X2 | O | Analog | Touch panel X2 position signal |
| | A5 | Y2 | O | Analog | Touch panel Y2 position signal |
| | A6 | DIG_LED_5 | O | 0/5 V DC (pulse) | Operation panel indicator LED drive signal 5 |
| | A7 | DIG_LED_4 | O | 0/5 V DC (pulse) | Operation panel indicator LED drive signal 4 |
| | A8 | DIG_LED_3 | O | 0/5 V DC (pulse) | Operation panel indicator LED drive signal 3 |
| | A9 | DIG_LED_6 | O | 0/5 V DC (pulse) | Operation panel indicator LED drive signal 6 |
| | A10 | SCAN8 | O | 0/5 V DC (pulse) | Scan signal 8 |
| | A11 | SCAN7 | O | 0/5 V DC (pulse) | Scan signal 7 |
| | A12 | SCAN6 | O | 0/5 V DC (pulse) | Scan signal 6 |
| | A13 | SCAN5 | O | 0/5 V DC (pulse) | Scan signal 5 |
| | A14 | DIG_KEY_7 | I | 0/5 V DC (pulse) | Operation panel key scan return signal 7 |

| Connector | Pin No. | Signal | I/O | Voltage | Description |
|--|---------|--------------|-----|------------------|--|
| YC12 Connected to the upper operation unit PWB | A15 | DIG_KEY_6 | I | 0/5 V DC (pulse) | Operation panel key scan return signal 6 |
| | B1 | LCD_VSS1 | - | - | Ground |
| | B2 | LCD_VDD | O | 5 V DC | 5 V DC power output to LCD |
| | B3 | LCD_VSS2 | - | - | Ground |
| | B4 | LCD_FLAME | O | 0/5 V DC | LCD_FLAME signal |
| | B5 | LCD_LOAD | O | 0/5 V DC | LCD_LOAD signal |
| | B6 | LCD_CP | O | 0/5 V DC (pulse) | LCD_CP signal |
| | B7 | LCD_DISP_OFF | O | 0/5 V DC | LCD indicator: On/Off |
| | B8 | LCD_D0 | O | 0/5 V DC (pulse) | LCD indicator data signal 0 |
| | B9 | LCD_D1 | O | 0/5 V DC (pulse) | LCD indicator data signal 1 |
| | B10 | LCD_D2 | O | 0/5 V DC (pulse) | LCD indicator data signal 2 |
| | B11 | LCD_D3 | O | 0/5 V DC (pulse) | LCD indicator data signal 3 |
| | B12 | VEE_OFF | O | 0/5 V DC | LCD power control signal |
| | B13 | GND | - | - | Ground |
| | B14 | GND | - | - | Ground |
| | B15 | N.C. | - | - | Not used |
| YC15 Connected to the power source PWB | 1 | GND | - | - | Ground |
| | 2 | +5VSL | I | 5 V DC | 5 V DC power input from PSPWB |

2-3-4 Upper operation unit PWB




Figure 2-3-4 Upper operation unit PWB silk-screen diagram

| Connector | Pin No. | Signal | I/O | Voltage | Description |
|---|---------|--------------|-----|------------------|--|
| YC1 Connected to the main PWB | 1 | DIG_KEY_6 | O | 0/5 V DC (pulse) | Operation panel key scan return signal 6 |
| | 2 | DIG_KEY_7 | O | 0/5 V DC (pulse) | Operation panel key scan return signal 7 |
| | 3 | SCAN5 | I | 0/5 V DC (pulse) | Scan signal 5 |
| | 4 | SCAN6 | I | 0/5 V DC (pulse) | Scan signal 6 |
| | 5 | SCAN7 | I | 0/5 V DC (pulse) | Scan signal 7 |
| | 6 | SCAN8 | I | 0/5 V DC (pulse) | Scan signal 8 |
| | 7 | DIG_LED_6 | I | 0/5 V DC (pulse) | Operation panel indicator LED drive signal 6 |
| | 8 | DIG_LED_3 | I | 0/5 V DC (pulse) | Operation panel indicator LED drive signal 3 |
| | 9 | DIG_LED_4 | I | 0/5 V DC (pulse) | Operation panel indicator LED drive signal 4 |
| | 10 | DIG_LED_5 | I | 0/5 V DC (pulse) | Operation panel indicator LED drive signal 5 |
| | 11 | Y2 | I | Analog | Touch panel Y2 position signal |
| | 12 | X2 | I | Analog | Touch panel X2 position signal |
| | 13 | Y1 | I | Analog | Touch panel Y1 position signal |
| | 14 | X1 | I | Analog | Touch panel X1 position signal |
| | 15 | BUZZER | I | 0/5 V DC | Buzzer signal |
| YC2 Connected to the main PWB | 1 | GND | - | - | Ground |
| | 2 | GND | - | - | Ground |
| | 3 | VEE_OFF | I | 0/5 V DC | LCD power control signal |
| | 4 | LCD_D3 | I | 0/5 V DC (pulse) | LCD indicator data signal 3 |
| | 5 | LCD_D2 | I | 0/5 V DC (pulse) | LCD indicator data signal 2 |
| | 6 | LCD_D1 | I | 0/5 V DC (pulse) | LCD indicator data signal 1 |
| | 7 | LCD_D0 | I | 0/5 V DC (pulse) | LCD indicator data signal 0 |
| | 8 | LCD_DISP_OFF | I | 0/5 V DC | LCD indicator: On/Off |
| | 9 | LCD_CP | I | 0/5 V DC (pulse) | LCD_CP signal |
| | 10 | LCD_LOAD | I | 0/5 V DC | LCD_LOAD signal |
| | 11 | LCD_FLAME | I | 0/5 V DC | LCD_FLAME signal |
| | 12 | LCD_VSS2 | - | - | Ground |
| | 13 | LCD_VDD | I | 5 V DC | 5 V DC power input from MPWB |
| | 14 | LCD_VSS1 | - | - | Ground |
| YC3 Connected to the LCD PWB | 1 | FLAME | O | 0/5 V DC | FLAME signal |
| | 2 | LOAD | O | 0/5 V DC | LOAD signal |
| | 3 | CP | O | 0/5 V DC (pulse) | CP signal |
| | 4 | SGND | - | - | Ground |
| | 5 | 5V | O | 5 V DC | 5 V DC power output to LCD |
| | 6 | SGND | - | - | Ground |
| | 7 | VEE | O | 0/5 V DC | LCD power control signal |
| | 8 | DISP OFF | O | 0/5 V DC | LCD indicator: On/Off |
| | 9 | D0 | O | 0/5 V DC (pulse) | LCD indicator data signal 0 |
| | 10 | D1 | O | 0/5 V DC (pulse) | LCD indicator data signal 1 |
| | 11 | D2 | O | 0/5 V DC (pulse) | LCD indicator data signal 2 |
| | 12 | D3 | O | 0/5 V DC (pulse) | LCD indicator data signal 3 |

| Connector | Pin No. | Signal | I/O | Voltage | Description |
|--|---------|-----------|-----|------------------|--|
| YC4 Connected to the left operation unit PWB | 1 | N.C. | - | - | Not used |
| | 2 | SGND | - | - | Ground |
| | 3 | DIG_LED_5 | O | 0/5 V DC (pulse) | Operation panel indicator LED drive signal 5 |
| | 4 | DIG_LED_4 | O | 0/5 V DC (pulse) | Operation panel indicator LED drive signal 4 |
| | 5 | DIG_LED_3 | O | 0/5 V DC (pulse) | Operation panel indicator LED drive signal 3 |
| | 6 | SCAN8 | O | 0/5 V DC (pulse) | Scan signal 8 |
| | 7 | SCAN7 | O | 0/5 V DC (pulse) | Scan signal 7 |
| | 8 | SCAN6 | O | 0/5 V DC (pulse) | Scan signal 6 |
| | 9 | SCAN5 | O | 0/5 V DC (pulse) | Scan signal 5 |
| | 10 | DIG_KEY_7 | O | 0/5 V DC (pulse) | Operation panel key scan return signal 7 |
| | 11 | X1 | O | Analog | Touch panel X1 position signal |
| | 12 | Y1 | O | Analog | Touch panel Y1 position signal |
| | 13 | X2 | O | Analog | Touch panel X2 position signal |
| | 14 | Y2 | O | Analog | Touch panel Y2 position signal |

2-3-5 Right operation unit PWB




Figure 2-3-5 Right operation unit PWB silk-screen diagram

| Connector | Pin No. | Signal | I/O | Voltage | Description |
|---|---------|-----------|-----|------------------|--|
| YC1 Connected to the right operation unit PWB | 1 | N.C | - | - | Not used |
| | 2 | LAMPOFF | I | 0/5 V DC | LCD back light: On/Off |
| | 3 | +24V | I | 24 V DC | 24 V DC power output to OPWB-R |
| | 4 | PGND | - | - | Ground |
| | 5 | SGND | - | - | Ground |
| | 6 | PH_LED_1 | I | 0/5 V DC (pulse) | LED lighting signal 1 |
| | 7 | PH_LED_2 | I | 0/5 V DC (pulse) | LED lighting signal 2 |
| | 8 | PH_KEY_1 | O | 0/5 V DC | Power key: On/Off |
| | 9 | PH_LED_3 | I | 0/5 V DC (pulse) | LED lighting signal 3 |
| | 10 | DIG_KEY_1 | O | 0/5 V DC (pulse) | Operation panel key scan return signal 1 |
| | 11 | DIG_KEY_2 | O | 0/5 V DC (pulse) | Operation panel key scan return signal 2 |
| | 12 | DIG_KEY_3 | O | 0/5 V DC (pulse) | Operation panel key scan return signal 3 |
| | 13 | DIG_KEY_4 | O | 0/5 V DC (pulse) | Operation panel key scan return signal 4 |
| | 14 | DIG_KEY_5 | O | 0/5 V DC (pulse) | Operation panel key scan return signal 5 |
| | 15 | SCAN1 | I | 0/5 V DC (pulse) | Scan signal 1 |
| | 16 | SCAN2 | I | 0/5 V DC (pulse) | Scan signal 2 |
| | 17 | SCAN3 | I | 0/5 V DC (pulse) | Scan signal 3 |
| | 18 | SCAN4 | I | 0/5 V DC (pulse) | Scan signal 4 |
| | 19 | DIG_LED_1 | I | 0/5 V DC (pulse) | Operation panel indicator LED drive signal 1 |
| | 20 | DIG_LED_2 | I | 0/5 V DC (pulse) | Operation panel indicator LED drive signal 2 |
| YC2 Connected to the back light | 1 | HOT | O | 515 V AC | Power output to LCD back light |
| | 2 | GND | - | - | Ground |

2-3-6 Left operation unit PWB




Figure 2-3-6 Left operation unit PWB silk-screen diagram

| Connector | Pin No. | Signal | I/O | Voltage | Description |
|---|---------|-----------|-----|------------------|--|
| YC1 Connected to the upper operation unit PWB | 1 | Y2 | I | Analog | Touch panel Y2 position signal |
| | 2 | X2 | I | Analog | Touch panel X2 position signal |
| | 3 | Y1 | I | Analog | Touch panel Y1 position signal |
| | 4 | X1 | I | Analog | Touch panel X1 position signal |
| | 5 | DIG_KEY_7 | I | 0/5 V DC (pulse) | Operation panel key scan return signal 7 |
| | 6 | SCAN5 | I | 0/5 V DC (pulse) | Scan signal 5 |
| | 7 | SCAN6 | I | 0/5 V DC (pulse) | Scan signal 6 |
| | 8 | SCAN7 | I | 0/5 V DC (pulse) | Scan signal 7 |
| | 9 | SCAN8 | I | 0/5 V DC (pulse) | Scan signal 8 |
| | 10 | DIG_LED_3 | I | 0/5 V DC (pulse) | Operation panel indicator LED drive signal 3 |
| | 11 | DIG_LED_4 | I | 0/5 V DC (pulse) | Operation panel indicator LED drive signal 4 |
| | 12 | DIG_LED_5 | I | 0/5 V DC (pulse) | Operation panel indicator LED drive signal 5 |
| | 13 | SGND | - | - | Ground |
| | 14 | N.C. | - | - | Not used |
| YC2 Connected to the touch panel | 1 | Y2 | O | Analog | Touch panel Y2 position signal |
| | 2 | X2 | O | Analog | Touch panel X2 position signal |
| | 3 | Y1 | O | Analog | Touch panel Y1 position signal |
| | 4 | X1 | O | Analog | Touch panel X1 position signal |

This page is intentionally left blank.

Maintenance parts list

| Maintenance part name | | Part No. | Alternative part | Fig. No. | Ref. No. |
|--------------------------------|---------------------------------|--------------|------------------|----------|----------|
| Name used in service manual | Name used in parts list | | | | |
| Upper/lower paper feed pulley | PULLEY,PAPER FEED | 2AR07220 | - | 5 | 2 |
| Upper/lower separation pulley | PULLEY,SEPARATION | 2AR07230 | - | 5 | 3 |
| Upper/lower forwarding pulley | PULLEY FEED A | 2BJ06010 | - | 5 | 7 |
| MP paper feed pulley | UPPER PULLEY,BYPASS | 61706770 | - | 6 | 55 |
| MP separation pulley | PULLEY,SEPARATION | 2AR07230 | - | 6 | 2 |
| MP forwarding pulley | PULLEY FEED A | 2BJ06010 | - | 6 | 6 |
| MP feed roller 1 | PARTS ROLLER MPF FEED A SP | 302H094110 | 2H094110 | 7 | 22 |
| MP feed roller 2 | PARTS ROLLER MPF FEED B SP | 302H094120 | 2H094120 | 7 | 23 |
| MP feed pulley | PULLEY 15 MPF FEED | 302H008220 | 2H008220 | 7 | 14 |
| Left registration roller | PARTS ROLLER REGIST LEFT SP | 302H094140 | 2H094140 | 9 | 36 |
| Right registration roller | ROLLER REGIST RIGHT | 302H024020 | 2H024020 | 9 | 69 |
| Feed pulley | PULLEY 15 DUPLEX | 3HY07120 | - | 4 | 32 |
| Feed pulley | PULLEY 15 DUPLEX | 3HY07120 | - | 9 | 37 |
| Feed roller 1 | PARTS PULLEY MID FEED ASSY SP | 302H094430 | 2H094430 | 8 | A02 |
| Feed roller 2 | PARTS ROLLER VERTICAL FEED A SP | 302H094090 | 2H094090 | 4 | 23 |
| Feed roller 3 | PARTS ROLLER VERTICAL FEED B SP | 302H094100 | 2H094100 | 4 | 24 |
| Registration cleaner | SPONGE CLEANER REG | 302H024240 | 2H024240 | 8 | 19 |
| Laser scanner unit | PARTS LK-670 | 302H093060 | 2H093060 | 11 | 12 |
| Platen | CONTACT GLASS | 2C912250 | - | 11 | 6 |
| Slit glass | PARTS CONTACT GLASS DP | 302H093300 | 2H093300 | 11 | 1 |
| Mirror 1 | MIRROR A | 302H017150 | 2H017150 | 10 | 46 |
| Mirror 2 and mirror 3 | MIRROR B | 2AV12160 | - | 10 | 2 |
| Reflector | REFLECTOR SCANNER | 302H017100 | 2H017100 | 10 | 41 |
| Exposure lamp | PARTS LAMP SCANNER W SP | 302H094130 | 2H094130 | 10 | 42 |
| Original size detection switch | SENSOR ORIGINAL | 302H044110 | 2H044110 | 10 | 32 |
| Transfer roller unit | PARTS TR-670 | 302H093050 | 2H093050 | 9 | A02 |
| Separation electrode | PLATE STA ELIMINATION | 2FT17030 | - | 9 | 9 |
| Developing unit | PARTS,DV-420,SP | 302FT93052 | 2FT93052 | 13 | 1 |
| Drum unit | PARTS DK-670 | 302H093010 | 2H093010 | 12 | A01 |
| Main charger unit | PARTS MC-670 | 302H093310 | 2H093310 | 12 | A02 |
| Fuser unit | PARTS FK-670(E) | 302H093040 | 2H093040 | 14 | A01 |
| Fuser unit | PARTS FK-670(U) | 302H093030 | 2H093030 | 14 | A01 |
| Heat roller | PARTS ROLLER HEAT SP | 302H094160 | 2H094160 | 14 | 30 |
| Press roller | PARTS ROLLER PRESS SP | 302H094450 | 2H094450 | 14 | 32 |
| Heat roller separation claw | SEPARATOR | 5MVX222XN002 | 2A820530 | 14 | 33 |
| Eject roller | PARTS ROLLER EXIT INNER SP | 302H094370 | 2H094370 | 20 | 37 |
| Switchback roller | PARTS ROLLER EXIT FEED SP | 302H094360 | 2H094360 | 20 | 36 |
| Eject pulley | PULLEY EXIT B | 2BL21450 | - | 20 | 1 |
| Feed pulley | PULLEY EXIT FEED | 302H028230 | 2H028230 | 20 | 25 |
| Upper duplex feed roller | PARTS DUPLEX A SP | 302H094380 | 2H094380 | 18 | 18 |
| Lower duplex feed roller | PARTS DUPLEX B SP | 302H094390 | 2H094390 | 18 | 19 |
| Duplex feed pulley | PULLEY 15 DUPLEX | 3HY07120 | - | 18 | 20 |

| Maintenance part name | | Part No. | Alternative part | Fig. No. | Ref. No. |
|-----------------------------|--------------------------|------------|------------------|----------|----------|
| Name used in service manual | Name used in parts list | | | | |
| Right filter | PARTS HOLDER FILTER A SP | 302H094400 | 2H094400 | 17 | A01 |
| Ozone filter 1 | FILTER OZONE B | 302H033180 | 2H033180 | 1 | 42 |
| Ozone filter 2 | FILTER OZONE A | 302H033170 | 2H033170 | 19 | 38 |
| Power source PWB | PARTS LVU 100 | 302H093280 | 2H093280 | 21 | 54 |
| Power source PWB | PARTS LVU 200 | 302H093290 | 2H093290 | 21 | 54 |
| Main PWB | PARTS,PWB MAIN ASS'Y SP | 302JB94020 | 2JB94020 | 21 | 44 |

Maintenance kits

| Maintenance part name | | Part No. | Alternative part No. | Fig. No. | Ref. No. |
|----------------------------------|--------------------------|------------|----------------------|----------|----------|
| Name used in service manual | Name used in parts list | | | | |
| Maintenance kit | | | | | |
| <For 120 V specifications> | MK-670/MAINTENANCE KIT | 1702H07US0 | 072H07US | 27 | - |
| Upper/lower paper feed pulley | PULLEY,PAPER FEED | - | - | - | - |
| Upper/lower separation pulley | PULLEY,SEPARATION | - | - | - | - |
| MP separation pulley | PULLEY,SEPARATION | - | - | - | - |
| Upper/lower forwarding pulley | PULLEY FEED A | - | - | - | - |
| MP forwarding pulley | PULLEY FEED A | - | - | - | - |
| Developing unit | PARTS,DV-420,SP | - | - | - | - |
| Ozone filter 1 | FILTER OZONE B | - | - | - | - |
| Ozone filter 2 | FILTER OZONE A | - | - | - | - |
| Drum unit | PARTS DK-670 | - | - | - | - |
| Fuser unit | PARTS FK-670(U) | - | - | - | - |
| Transfer roller unit | PARTS TR-670 | - | - | - | - |
| Right filter | PARTS HOLDER FILTER A SP | - | - | - | - |
| MP paper feed pulley | UPPER PULLEY,BYPASS | - | - | - | - |
| <For 220 - 240 V specifications> | MK-670/MAINTENANCE KIT | 1702H08NL0 | 072H08NL | 27 | - |
| Upper/lower paper feed pulley | PULLEY,PAPER FEED | - | - | - | - |
| Upper/lower separation pulley | PULLEY,SEPARATION | - | - | - | - |
| MP separation pulley | PULLEY,SEPARATION | - | - | - | - |
| Upper/lower forwarding pulley | PULLEY FEED A | - | - | - | - |
| MP forwarding pulley | PULLEY FEED A | - | - | - | - |
| Developing unit | PARTS,DV-420,SP | - | - | - | - |
| Ozone filter 1 | FILTER OZONE B | - | - | - | - |
| Ozone filter 2 | FILTER OZONE A | - | - | - | - |
| Drum unit | PARTS DK-670 | - | - | - | - |
| Fuser unit | PARTS FK-670(E) | - | - | - | - |
| Transfer roller unit | PARTS TR-670 | - | - | - | - |
| Right filter | PARTS HOLDER FILTER A SP | - | - | - | - |
| MP paper feed pulley | UPPER PULLEY,BYPASS | - | - | - | - |

Periodic maintenance procedures

| Section | Maintenance part/location | Method | Maintenance cycle | Points and cautions | Page |
|--------------------------|----------------------------------|-----------|-------------------|---------------------|------|
| Test copy and test print | Perform at the maximum copy size | Test copy | Every service | | |



| Section | Maintenance part/location | Method | Maintenance cycle | Points and cautions | Page |
|--------------------|-------------------------------|---------|-------------------|---|---------|
| Paper feed section | Upper/lower paper feed pulley | Replace | 300K | Replace. (Check and clean with alcohol when user call occurs.) | P.1-5-3 |
| | Upper/lower separation pulley | Replace | 300K | Replace. (Check and clean with alcohol when user call occurs.) | P.1-5-3 |
| | Upper/lower forwarding pulley | Replace | 300K | Replace. (Check and clean with alcohol when user call occurs.) | P.1-5-3 |
| | MP paper feed pulley | Replace | 300K | Replace. (Check and clean with alcohol when user call occurs.) | P.1-5-6 |
| | MP separation pulley | Replace | 300K | Replace. (Check and clean with alcohol when user call occurs.) | P.1-5-6 |
| | MP forwarding pulley | Replace | 300K | Replace. (Check and clean with alcohol when user call occurs.) | P.1-5-6 |
| | MP feed roller 1 | Clean | 300K | Clean with alcohol. (Check and clean with alcohol when user call occurs.) | |
| | MP feed roller 2 | Clean | 300K | Clean with alcohol. (Check and clean with alcohol when user call occurs.) | |
| | MP feed pulley | Clean | 300K | Clean with alcohol. (Check and clean with alcohol when user call occurs.) | |
| | Left registration roller | Clean | 300K | Clean with alcohol. (Check and clean with alcohol when user call occurs.) | |
| | Right registration roller | Clean | 300K | Clean with alcohol. (Check and clean with alcohol when user call occurs.) | |
| | Feed pulley | Clean | 300K | Clean with alcohol. (Check and clean with alcohol when user call occurs.) | |
| | Feed roller 1 | Clean | 300K | Clean with alcohol. (Check and clean with alcohol when user call occurs.) | |
| | Feed roller 2 | Clean | 300K | Clean with alcohol. (Check and clean with alcohol when user call occurs.) | |
| | Feed roller 3 | Clean | 300K | Clean with alcohol. (Check and clean with alcohol when user call occurs.) | |
| | Registration cleaner | Clean | Every service | Vacuum. | |



| Section | Maintenance part/location | Method | Maintenance cycle | Points and cautions | Page |
|-----------------|--------------------------------|------------------|-------------------|--|----------|
| Optical section | Laser scanner unit | Clean | Every service | Clean the slit glass with a dry cloth. | P.1-5-30 |
| | Platen | Clean | Every service | Clean with alcohol and then a dry cloth. | |
| | Slit glass | Clean | Every service | Clean with a dry cloth or alcohol (do not clean with a wet cloth). | |
| | Mirror 1 | Clean | User call | Clean with a wet cloth and then a dry cloth only if vertical black lines appear on the copy image. | |
| | Mirror 2 and mirror 3 | Clean | User call | Clean with a wet cloth and then a dry cloth only if vertical black lines appear on the copy image. | |
| | Lens | Clean | User call | Clean with a dry cloth only if vertical black lines appear on the copy image. | P.1-5-15 |
| | Reflector | Clean | User call | Clean with a dry cloth only if vertical black lines appear on the copy image. | |
| | Exposure lamp | Check or replace | User call | Replace if an image problem occurs. | |
| | Optical rail | Check or Grease | User call | Check noise and shifting and then apply scanner rail grease EM-50L. | |
| | Original size detection sensor | Check or clean | User call | Clean the sensor emitter and sensor receiver with alcohol or a dry cloth only if there is a problem. | |



| Section | Maintenance part/location | Method | Maintenance cycle | Points and cautions | Page |
|-----------------------------|---------------------------|----------------|-------------------|--|----------|
| Transfer/separation section | Transfer roller unit | Replace | 300K | Replace. (Vacuum or clean with a dry cloth when user call occurs.) | P.1-5-40 |
| | Separation electrode | Check or clean | Every service | Clean with a cleaning brush. | |



| Section | Maintenance part/location | Method | Maintenance cycle | Points and cautions | Page |
|--------------------|---------------------------|---------|-------------------|---|----------|
| Developing section | Developing unit | Replace | 300K | Replace. (Check and replace when user call occurs.) | P.1-5-39 |



| Section | Maintenance part/location | Method | Maintenance cycle | Points and cautions | Page |
|----------------------------|---------------------------|---------|-------------------|---|----------|
| Main charging/drum section | Drum unit | Replace | 300K | Replace. (Check and replace when user call occurs.) | P.1-5-35 |
| | Main charger unit | Clean | User call | Clean with a wet cloth and then a dry cloth. | P.1-5-37 |



| Section | Maintenance part/location | Method | Maintenance cycle | Points and cautions | Page |
|---------------|-----------------------------|-------------------------|-------------------|--|----------|
| Fuser section | Fuser unit | Replace | 300K | Replace. (Check and replace when user call occurs.) | P.1-5-41 |
| | Heat roller | Check or replace | User call | Replace when problem occurs. | P.1-5-49 |
| | Press roller | Check or replace | User call | Replace when problem occurs. | P.1-5-45 |
| | Heat roller separation claw | Check, clean or replace | User call | Check and clean with alcohol. Replace if claw is deformed. | P.1-5-44 |



| Section | Maintenance part/location | Method | Maintenance cycle | Points and cautions | Page |
|---------------|---------------------------|----------------|-------------------|-------------------------------|------|
| Eject section | Eject roller | Check or clean | User call | Check and clean with alcohol. | |
| | Switchback roller | Check or clean | User call | Check and clean with alcohol. | |
| | Eject pulley | Check or clean | User call | Check and clean with alcohol. | |
| | Feed pulley | Check or clean | User call | Check and clean with alcohol. | |



| Section | Maintenance part/location | Method | Maintenance cycle | Points and cautions | Page |
|----------------|---------------------------|--------|-------------------|---|------|
| Duplex section | Upper duplex feed roller | Clean | 300K | Clean with alcohol. (Check and clean with alcohol when user call occurs.) | |
| | Lower duplex feed roller | Clean | 300K | Clean with alcohol. (Check and clean with alcohol when user call occurs.) | |
| | Duplex feed pulley | Clean | 300K | Clean with alcohol. (Check and clean with alcohol when user call occurs.) | |



| Section | Maintenance part/location | Method | Maintenance cycle | Points and cautions | Page |
|---------|---------------------------|----------------|-------------------|--|----------|
| Covers | Covers | Clean | Every service | Clean with alcohol or a dry cloth. | P.1-5-57 |
| | Right filter | Check or clean | Every service | Vacuum. | |
| | Ozone filter 1 | Replace | 300K | Replace. (Check and vacuum when user call occurs.) | |
| | Ozone filter 2 | Replace | 300K | Replace. (Check and vacuum when user call occurs.) | |


















| Section | Maintenance part/location | Method | Maintenance cycle | Points and cautions | Page |
|---------|---------------------------|----------------|-------------------|------------------------|------|
| PWBs | Power source PWB | Check or clean | Every service | Clean (do not vacuum). | |
| | Main PWB | Check or clean | Every service | Clean (do not vacuum). | |



| Section | Maintenance part/location | Method | Maintenance cycle | Points and cautions | Page |
|---------|---------------------------|------------------|-------------------|---------------------|------|
| Other | Image quality | Check and adjust | Every service | | |

Chart of image adjustment procedures

| Adjusting order | Item | Image | Description | Maintenance mode | | Original | Page | Remarks |
|-----------------|--|---|---|------------------|----------------------------------|-------------------|----------------------|--|
| | | | | Item No. | Mode | | | |
| 1 | Adjusting the magnification in the main scanning direction (printing adjustment) |  | Polygon motor speed adjustment | U053 | POLYGON MOTOR | U053 test pattern | P.1-3-16 | |
| 2 | Adjusting the magnification in the auxiliary scanning direction (printing adjustment) |  | Drive motor speed adjustment | U053 | MAIN MOTOR | U053 test pattern | P.1-3-16 | |
| 3 | Adjusting the center line (printing adjustment) |  | Adjusting the LSU print start timing | U034 | LSU OUT LEFT | U034 test pattern | P.1-3-13 | |
| 4 | Adjusting the center line of the cassettes and paper feeder (printing adjustment) |  | Adjusting the position of the rack adjuster | U034 | LSU OUT LEFT | U034 test pattern | - | Adjusts the position of each paper source. |
| 5 | Adjusting the leading edge registration (printing adjustment) |  | Registration clutch turning on timing (secondary paper feed start timing) | U034 | LSU OUT TOP | U034 test pattern | P.1-3-12 | |
| 6 | Adjusting the leading edge margin (printing adjustment) |  | LSU illumination start timing | U402 | LESD | U402 test pattern | P.1-3-55 | |
| 7 | Adjusting the trailing edge margin (printing adjustment) |  | LSU illumination end timing | U402 | TRAIL TRAIL(DUP) TRAIL(MP) | U402 test pattern | P.1-3-55 | To make an adjustment for duplex copying, select TRAIL(DUP). To make an adjustment for MP tray, select TRAIL(MP). |
| 8 | Adjusting the left and right margins (printing adjustment) |  | LSU illumination start/end timing | U402 | A C | U402 test pattern | P.1-3-55 | |
| 9 | Adjusting magnification of the scanner in the main scanning direction (scanning adjustment) |  | Data processing | U065 | MAIN SCAN ADJ | Test chart | P.1-3-18 | |
| 10 | Adjusting magnification of the scanner in the auxiliary scanning direction (scanning adjustment) |  | Original scanning speed | U065 U070 | SUB SCAN ADJ MAIN ADJ/SUB ADJ | Test chart | P.1-3-18 P.1-3-22 | U065: For copying an original placed on the platen. U070: For copying originals from the DP. |

| Adjusting order | Item | Image | Description | Maintenance mode | | Original | Page | Remarks |
|-----------------|---|--|---|------------------|------------------------------------|------------|----------|---|
| | | | | Item No. | Mode | | | |
| 11 | Adjusting the center line (scanning adjustment) |  | Adjusting the original scan data (image adjustment) | U067 | ADJUST DATA1/2 | Test chart | P.1-3-20 | U067: For copying an original placed on the platen. U072: For copying originals from the DP. |
| | | | | U072 | ADJUST DATA1/2 | | P.1-3-25 | |
| 12 | Adjusting the leading edge registration (scanning adjustment) |  | Original scan start timing (image adjustment) | U066 | ADJUST DATA1/2 | Test chart | P.1-3-19 | U066: For copying an original placed on the platen. U071: For copying originals from the DP. |
| | | | | U071 | ADJUST DATA1/2/3/4 | | P.1-3-23 | |
| 13 | Adjusting the leading edge margin (scanning adjustment) |  | Adjusting the original scan data (image adjustment) | U403 | B MARGIN | Test chart | P.1-3-56 | U403: For copying an original placed on the platen. U404: For copying originals from the DP. |
| | | | | U404 | B MARGIN/ | | P.1-3-57 | |
| 14 | Adjusting the trailing edge margin (scanning adjustment) |  | Adjusting the original scan data (image adjustment) | U403 | D MARGIN | Test chart | P.1-3-56 | U403: For copying an original placed on the platen. U404: For copying originals from the DP. |
| | | | | U404 | D MARGIN/ | | P.1-3-57 | |
| 15 | Adjusting the left and right margins (scanning adjustment) |  | Adjusting the original scan data (image adjustment) | U403 | A MARGIN | Test chart | P.1-3-56 | U403: For copying an original placed on the platen. U404: For copying originals from the DP. |
| | | | | U404 | C MARGIN A MARGIN/ C MARGIN/ | | P.1-3-57 | |

When maintenance item U411 (Adjusting the scanner automatically) is run using the specified original (P/N 302FZ56990), the following adjustments are automatically made:

Adjusting the scanner magnification (U065)
Adjusting the scanner leading edge registration (U066)
Adjusting the scanner center line (U067)


When maintenance item U411 (Adjusting the scanner automatically) is run using the specified original (P/N 2AC68241), the following adjustments are automatically made:

Adjusting the DP magnification (U070)
Adjusting the DP scanning timing (U071)
Adjusting the DP center line (U072)

Image quality


| Item | Specifications |
|---------------------------|--|
| 100% magnification | Machine: $\pm 0.8\%$ Using DP: $\pm 1.5\%$ |
| Enlargement/reduction | Machine: $\pm 1.0\%$ Using DP: $\pm 1.5\%$ |
| Lateral squareness | Machine: ± 1.5 mm/375 mm Using DP: ± 3.0 mm/375 mm |
| Leading edge registration | Cassette: ± 2.5 mm MP tray: ± 2.5 mm Duplex mode: ± 2.5 mm |
| Skewed paper feed | Cassette: 1.5 mm or less MP tray: 1.5 mm or less Duplex mode: 2.0 mm or less |
| Left-right difference | Cassette: 2.0 mm or less MP tray: 2.0 mm or less Duplex mode: 3.0 mm or less |
| Curling | Simplex mode: 10.0 mm or less Duplex mode: 10.0 mm or less |

General wiring diagram



INSTALLATION GUIDE FOR DOCUMENT PROCESSOR

Output Connector for Interconnecting Cable is non-LPS.
Output: 357VA max.
Please use the item below Interconnecting Cable/
P/N: 303K546050



English

Supplied parts

| | | |
|---|-------------------------|---|
| A | Document processor (DP) | 1 |
| B | Original mat | 1 |
| C | Angle adjusting plate | 1 |
| D | Pin | 2 |

| | | |
|---|---|---|
| E | M4 × 14 screw | 5 |
| F | Caution label [Do not leave documents at the device.] (except for 100 V specifications) | 1 |
| G | Caution label [Face Up] (except for 100 V specifications) | 1 |
| H | Label [Operation procedure] (Inch models) | 1 |
| I | Label [Operation procedure] (for 100 V specifications) | 1 |

| | | |
|---|---|---|
| J | Label A [Operation procedure] (Metric models except for 100 V specifications) | 1 |
| K | Label B [Operation procedure] (Metric models except for 100 V specifications) | 1 |
| L | Label C [Operation procedure] (Metric models except for 100 V specifications) | 1 |

Français

Pièces fournies

| | | |
|---|---------------------------|---|
| A | Chargeur de document (DP) | 1 |
| B | Tapis d'original | 1 |
| C | Plaque de réglage d'angle | 1 |
| D | Goupille | 2 |

| | | |
|---|--|---|
| E | Vis M4 × 14 | 5 |
| F | Étiquette de précautions [Veillez à ne pas laisser d'originaux dans le bac d'éjection.] (sauf pour les spécifications 100 V) | 1 |
| G | Étiquette de précautions [Face vers le Haut] (sauf pour les spécifications 100 V) | 1 |
| H | Étiquette [Procédure d'utilisation] (modèles en pouces) | 1 |

| | | |
|---|--|---|
| I | Étiquette [Procédure d'utilisation] (pour les spécifications 100 V) | 1 |
| J | Étiquette A [Procédure d'utilisation] (modèles en mètres sauf pour les spécifications 100 V) | 1 |
| K | Étiquette B [Procédure d'utilisation] (modèles en mètres sauf pour les spécifications 100 V) | 1 |
| L | Étiquette C [Procédure d'utilisation] (modèles en mètres sauf pour les spécifications 100 V) | 1 |

Español

Piezas suministradas

| | | |
|---|-------------------------------|---|
| A | Procesador de documentos (DP) | 1 |
| B | Plancha de originales | 1 |
| C | Placa de ajuste de ángulo | 1 |
| D | Pasador | 2 |

| | | |
|---|--|---|
| E | Tornillo M4 × 14 | 5 |
| F | Etiqueta de precaución [No deje documentos en el equipo.] (excepto especificaciones de 100V) | 1 |
| G | Etiqueta de precaución [Cara Arriba] (excepto especificaciones de 100V) | 1 |
| H | Etiqueta [Procedimiento de funcionamiento] (modelos de pulgadas) | 1 |
| I | Etiqueta [Procedimiento de funcionamiento] (especificaciones de 100V) | 1 |

| | | |
|---|--|---|
| J | Etiqueta A [Procedimiento de funcionamiento] (modelos métricos excepto especificaciones de 100V) | 1 |
| K | Etiqueta B [Procedimiento de funcionamiento] (modelos métricos excepto especificaciones de 100V) | 1 |
| L | Etiqueta C [Procedimiento de funcionamiento] (modelos métricos excepto especificaciones de 100V) | 1 |

Deutsch

Gelieferte Teile

| | | |
|---|-----------------------|---|
| A | Vorlageneinzug (DP) | 1 |
| B | Originalmatte | 1 |
| C | Winkelleinstellhalter | 1 |
| D | Rändelschraube | 2 |

| | | |
|---|--|---|
| E | M4 × 14 Schraube | 5 |
| F | Warnaufkleber [Lassen Sie keine Originale auf dem Gerät liegen.] (außer 100-V-Spezifikationen) | 1 |
| G | Warnaufkleber [Vorderseite Oben] (außer 100-V-Spezifikationen) | 1 |
| H | Aufkleber [Bedienungsverfahren] (Zoll-Modelle) | 1 |
| I | Aufkleber [Bedienungsverfahren] (für 100-V-Spezifikationen) | 1 |

| | | |
|---|---|---|
| J | Aufkleber A [Bedienungsverfahren] (Metrische Modelle außer 100-V-Spezifikationen) | 1 |
| K | Aufkleber B [Bedienungsverfahren] (Metrische Modelle außer 100-V-Spezifikationen) | 1 |
| L | Aufkleber C [Bedienungsverfahren] (Metrische Modelle außer 100-V-Spezifikationen) | 1 |

Italiano

Parti di fornitura

| | | |
|---|------------------------------------|---|
| A | Alimentatore di originali (DP) | 1 |
| B | Coprioriginale | 1 |
| C | Piastra di regolazione dell'angolo | 1 |
| D | Perno | 2 |

| | | |
|---|--|---|
| E | Vite M4 × 14 | 5 |
| F | Etichetta di avvertenza [Non lasciare i documenti sul dispositivo.] (eccetto specifiche per 100 V) | 1 |
| G | Etichetta di avvertenza [Faccia Insù] (eccetto specifiche per 100 V) | 1 |
| H | Etichetta [Procedura di funzionamento] (modelli in pollici) | 1 |
| I | Etichetta [Procedura di funzionamento] (specifiche solo per 100 V) | 1 |

| | | |
|---|--|---|
| J | Etichetta A [Procedura di funzionamento] (modelli con il sistema metrico eccetto specifiche per 100 V) | 1 |
| K | Etichetta B [Procedura di funzionamento] (modelli con il sistema metrico eccetto specifiche per 100 V) | 1 |
| L | Etichetta C [Procedura di funzionamento] (modelli con il sistema metrico eccetto specifiche per 100 V) | 1 |

简体中文

同装品

| | | |
|---|----------|---|
| A | 送稿器 (DP) | 1 |
| B | 原稿垫 | 1 |
| C | 调整板 | 1 |
| D | 卡销 | 2 |

| | | |
|---|--------------------------|---|
| E | 螺丝 M4 × 14 | 5 |
| F | 原稿遗忘注意标签 (220V 规格产品除外) | 1 |
| G | 原稿设置方向注意标签 (220V 规格产品除外) | 1 |
| H | 操作标签 (只限英寸规格产品) | 1 |
| I | 操作标签 (只限 220V 规格产品) | 1 |

| | | |
|---|--------------------------------|---|
| J | 操作标签 A (只限 220V 规格产品除外的厘米规格产品) | 1 |
| K | 操作标签 B (只限 220V 规格产品除外的厘米规格产品) | 1 |
| L | 操作标签 C (只限 220V 规格产品除外的厘米规格产品) | 1 |



日本語

同梱品

| | | |
|---|-------------|---|
| A | 原稿送り装置 (DP) | 1 |
| B | 原稿マット | 1 |
| C | 調整板 | 1 |
| D | ピン | 2 |

| | | |
|---|--------------------------|---|
| E | ビス M4 × 14 | 5 |
| F | 原稿忘れ注意ラベル (100V 仕様以外) | 1 |
| G | 原稿セット向き注意ラベル (100V 仕様以外) | 1 |
| H | 操作ラベル (インチ仕様のみ) | 1 |
| I | 操作ラベル (100V 仕様のみ) | 1 |

| | | |
|---|-----------------------------|---|
| J | 操作ラベル A (100V 仕様以外のセンチ仕様のみ) | 1 |
| K | 操作ラベル B (100V 仕様以外のセンチ仕様のみ) | 1 |
| L | 操作ラベル C (100V 仕様以外のセンチ仕様のみ) | 1 |



Precautions

- Be sure to remove any tape and/or cushioning material from supplied parts.
- Before installing the document processor, be sure to turn the main power switch of the machine off and unplug the power cable from the wall outlet.

Procedure Installing the DP

1. Install two pins (D).

2. Insert the pins (D) into the hinge holes (1) of DP (A) and slide the DP (A) toward the front side to install it.

Précautions

- Veillez à retirer les morceaux de bande adhésive et/ou les matériaux de rembourrage des pièces fournies.
- Avant d'installer le chargeur de document, veillez à mettre la machine hors tension et à débrancher le câble d'alimentation de la prise murale.

Procédure Installation du DP

1. Installez deux goupilles (D).

2. Insérez les goupilles (D) dans les orifices de charnière (1) du DP (A), puis faites glisser le DP (A) vers l'avant pour l'installer.

Precauciones

- Asegúrese de despegar todas las cintas y/o material amortiguador de las partes suministradas.
- Antes de instalar el procesador de documentos, asegúrese de desconectar el interruptor principal de la máquina y desenchufar el cable eléctrico del tomacorriente de la pared.

Procedimiento Instalación del DP

1. Instale dos pasadores (D).

2. Inserte los pasadores (D) en los orificios de bisagra (1) del DP (A) y deslice el DP (A) hacia el lado frontal para instalar.

Vorsichtsmaßnahmen

- Entfernen Sie Klebeband und/oder Dämpfungsmaterial vollständig von den mitgelieferten Teilen.
- Schalten Sie unbedingt den Betriebsschalter der Maschine aus, und trennen Sie das Netzkabel von der Netzsteckdose, bevor Sie den Vorlageneinzug installieren.

Verfahren Installieren des DP

1. Zwei Rändelschrauben (D) eindrehen.

2. Die Rändelschrauben (D) in die Scharnierlöcher (1) des DP (A) einführen, und den DP (A) zum Installieren nach vorn schieben.

Precauzioni

- Accertarsi di rimuovere tutti i nastri adesivi e/o il materiale di imbottitura dalle parti fornite.
- Prima di installare l'alimentatore di originali, assicurarsi di spegnere l'interruttore principale di alimentazione della macchina e scollegare la spina del cavo di alimentazione dalla presa a muro della rete elettrica.

Procedura Installazione del DP

1. Inserire due perni (D).

2. Inserire i perni (D) nei fori della cerniera (1) del DP (A) e fare scorrere il DP (A) verso il lato anteriore per installarlo.

注意事項

- 如果在箱内带有固定胶带、缓冲材料时务必揭下。
- 安装 DP 时，必须先关闭机器主机的主电源开关，并拔下电源插头后，再进行安装作业。

安装步骤 安装 DP

1. 装上 2 个卡销 (D)。

2. 将卡销 (D) 插入 DP (A) 的铰链部孔 (1)，向跟前滑动装上 DP。


注意事項

- 同梱品に固定テープ、緩衝材が付いている場合は必ず取り外すこと。
- DP を設置する場合は、機械本体の主電源スイッチを OFF にし、電源プラグを抜いてから作業をおこなう。


設置手順 DP の取り付け

1. ピン (D) 2 本を取り付ける。

2. DP (A) のヒンジ部の穴 (1) にピン (D) を挿入し、手前にスライドして DP を取り付ける。



3. Fix the DP using four M4 × 14 screws (E).
Right: One
Left: Three



Attaching the original mat

4. Place the original mat (B) with its hook and loop fasteners up over the platen.
Align the original mat (B) corner that has not been surface cut with the rear left corner (2) of the platen.
5. Close the DP slowly to attach the original mat (B) onto it with the hook and loop fasteners.

3. Fixez le DP à l'aide de quatre vis M4 × 14 (E).
Côté droit: Une
Côté gauche: Trois

Fixation du tapis d'original

4. Placez le tapis d'original (B) sur la glace d'exposition avec son crochet et ses attaches à boucle orientées vers le haut.
Aligner le coin du tapis d'original (B) ne comportant pas de découpe sur le coin arrière gauche (2) de la glace d'exposition.
5. Refermez progressivement le DP pour fixer le tapis d'original (B) sur celui-ci avec le crochet et les attaches à boucle.

3. Fije el DP utilizando cuatro tornillos M4 × 14 (E).
Derecho: Uno
Izquierdo: Tres

Colocación de la plancha de originales

4. Coloque la plancha de originales (B) en su gancho y fijadores de bucle sobre el crystal de exposición.
Alinee la esquina de la plancha de originales (B) que no tenga corte de superficie con la esquina trasera izquierda (2) del crystal de exposición.
5. Cierre lentamente el DP para colocar la plancha de originales (B) con el gancho y fijadores de bucle.

3. Den DP mit vier M4 × 14 Schrauben (E) befestigen.
Rechts: Eine
Links: Drei

Anbringen der Originalmatte

4. Die Originalmatte (B) mit den Klettverschlüssen nach oben auf das Vorlagenglas legen.
Die nicht abgeschnittene Ecke der Originalmatte (B) auf die hintere linke Ecke (2) des Vorlagenglases ausrichten.
5. Den DP langsam schließen, so dass die Originalmatte (B) mit den Klettverschlüssen an ihm haftet.

3. Fissare il DP utilizzando quattro viti M4 × 14 (E).
Destra: Una
Sinistra: Tre

Montaggio del coprioriginale

4. Collocare il coprioriginale (B) sulla lastra di esposizione con il lato provvisto di nastro velcro autoadesivo rivolto verso l'alto.
Allineare l'angolo integro del coprioriginale (B) con l'angolo posteriore sinistro (2) della lastra di esposizione.
5. Chiudere lentamente il DP in modo che il coprioriginale (B) vi si possa fissare mediante il nastro velcro.

3. 用4个螺丝M4×14(E)固定DP。
右侧:1个
左侧:3个


安装原稿垫

4. 将带有尼龙带的原稿垫(B)朝上,放在原稿玻璃板上。
将原稿垫(B)未缺角处对准原稿玻璃板的左角(2)上。
5. 轻轻地放下DP,使原稿垫(B)粘在DP背面上。

3. ビスM4×14(E)4本でDPを固定する。
右側:1本
左側:3本


原稿マットの取り付け

4. 原稿マット(B)をマジックテープが付いている面を上にして、原稿ガラス上に置く。
原稿マット(B)は、面カットされていない角を原稿ガラスの左奥(2)に合わせる。
5. DPをゆっくりと下ろし、DP裏面に原稿マット(B)を取り付ける。




Connecting the signal cable

6. Connect the connector (3) of the signal cable to the machine.



Adhering the labels (Inch models)

7. After cleaning with alcohol, adhere caution label [Do not leave documents at the device.] (F), caution label [Face Up] (G), and label [Operation procedure] (H) of the corresponding language.



(for 100 V specification models with color touch panel)

7. After cleaning with alcohol, adhere label [Operation procedure] (I).

Connexion du câble de signal

6. Branchez le connecteur (3) du câble de signal sur la machine.

Apposition des étiquettes (modèles en pouces)

7. Après avoir nettoyé avec de l'alcool, apposez l'étiquette de précautions [Veillez à ne pas laisser d'originaux dans le bac d'éjection.] (F), l'étiquette de précautions [Face vers le Haut] (G), et l'étiquette [Procédure d'utilisation] (H) dans la langue voulue.

(pour les modèles à spécifications 100 V avec écran tactile couleur)

7. Après avoir nettoyé avec de l'alcool, apposez l'étiquette [Procédure d'utilisation] (I).

Conexión del cable de señal

6. Conecte el conector (3) del cable de señal en la máquina.

Pegado de etiquetas (modelos de pulgadas)

7. Después de limpiar con alcohol, pegue la etiqueta de precaución [No deje documentos en el equipo.] (F), etiqueta de precaución [Cara Arriba] (G) y la etiqueta [Procedimiento de funcionamiento] (H) del correspondiente idioma.

(para modelos de especificaciones de 100V con panel de toque de color)

7. Después de limpiar con alcohol, pegue la etiqueta [Procedimiento de funcionamiento] (I).

Anschließen des Signalkabels

6. Den Stecker (3) des Signalkabels an die Maschine anschließen.

Anbringen der Aufkleber (Zoll-Modelle)

7. Nach der Reinigung der Klebeflächen mit Alkohol den Warnaufkleber [Lassen Sie keine Originale auf dem Gerät liegen.] (F), den Warnaufkleber [Vorderseite Oben] (G) und den Aufkleber [Bedienungsverfahren] (H) der entsprechenden Sprache anbringen.

(für 100-V-Spezifikations-Modelle mit Farb-Sensorbildschirm)

7. Den Aufkleber [Bedienungsverfahren] (I) anbringen, nachdem die Klebefläche mit Alkohol gereinigt wurde.

Collegamento del cavo del segnale

6. Collegare il connettore (3) del cavo del segnale alla macchina.

Applicazione delle etichette (Modelli in pollici)

7. Dopo avere pulito con alcol, applicare l'etichetta di avvertenza [Non lasciare i documenti sul dispositivo.] (F), l'etichetta di avvertenza [Faccia Insù] (G) e l'etichetta [Procedura di funzionamento] (H) redatte nella lingua corrispondente.

(specifiche solo per modelli 100 V con pannello a sfioramento a colori)

7. Dopo aver pulito con alcol applicare l'etichetta [Procedura di funzionamento] (I).

连接信号线

6. 连接信号线的插头 (3)。

贴上标签

(只限英寸规格产品)

7. 用酒精清洁后, 贴上对应语言的原稿遗忘注意标签 (F)、原稿设置方向注意标签 (G) 和操作标签 (H)。

(只限彩色触控式面板复印机 220V 规格产品)

7. 用酒精清洁后, 贴上操作标签 (I)。

TONER

信号線の接続


6. 信号線のコネクタ (3) を接続する。

ラベルの貼り付け (インチ仕様のみ)

7. アルコール清掃後、該当する言語の原稿忘れ注意ラベル (F)・原稿セット向き注意ラベル (G)・操作ラベル (H) を貼り付ける。

(カラータッチパネル機 100V 仕様のみ)

7. アルコール清掃後、操作ラベル (I) を貼り付ける。



(Metric models except for 100 V specifications)

7. After cleaning with alcohol, adhere caution label [Do not leave documents at the device.] (F) and caution label [Face Up] (G) of the corresponding language.

After cleaning with alcohol, adhere label A [Operation procedure] (J), label B [Operation procedure] (K), and/or label C [Operation procedure] (L).

(Models with color touch panel for English):

Adhere both the illustration label (4) and instructions label (5) of label A [Operation procedure] (J), which A is shown.

(Models with color touch panel except for English):

Adhere the illustration label (4) of label A [Operation procedure] (J), which A is shown.

Adhere label B [Operation procedure] (K), which B is shown, of the corresponding language.

(For models with monochrome touch panel):

Adhere label C [Operation procedure] (L), which C is shown, of the corresponding language.

(Modèles en mètres sauf spécifications 100 V)

7. Après avoir nettoyé avec de l'alcool, apposez l'étiquette de précautions [Veillez à ne pas laisser d'originaux dans le bac d'éjection.] (F) et l'étiquette de précautions [Face vers le Haut] (G) dans la langue voulue.

Après avoir nettoyé avec de l'alcool, apposez l'étiquette A [Procédure d'utilisation] (J), l'étiquette B [Procédure d'utilisation] (K), et/ou l'étiquette C [Procédure d'utilisation] (L).

(Modèles avec écran tactile couleur pour l'anglais):

Apposez l'étiquette d'illustrations (4) et l'étiquette d'instructions (5) de l'étiquette A [Procédure d'utilisation] (J), comme montré en A.

(Modèles avec écran tactile couleur sauf pour l'anglais):

Apposez l'étiquette d'illustrations (4) de l'étiquette A [Procédure d'utilisation] (J), comme montré en A.

Apposez l'étiquette B [Procédure d'utilisation] (K), comme montré en B, dans la langue voulue.

(Modèles avec écran tactile monochrome):

Apposez l'étiquette C [Procédure d'utilisation] (L), comme montré en C, dans la langue voulue.

(Modelos métricos excepto especificaciones de 100V)

7. Después de limpiar con alcohol, pegue la etiqueta de precaución [No deje documentos en el equipo.] (F), etiqueta de precaución [Cara Arriba] (G) del correspondiente idioma.

Después de limpiar con alcohol, pegue la etiqueta A [Procedimiento de funcionamiento] (J), la etiqueta B [Procedimiento de funcionamiento] (K) y/o etiqueta C [Procedimiento de funcionamiento] (L).

(Modelos con panel de toque color para inglés):

Pegue ambas etiquetas de ilustración (4) y etiqueta de instrucciones (5) de la etiqueta A [Procedimiento de funcionamiento] (J), donde se muestra A.

(Modelos con panel de toque color excepto inglés):

Pegue la etiqueta de ilustración (4) de la etiqueta A [Procedimiento de funcionamiento] (J) donde se muestra A.

Pegue la etiqueta B [Procedimiento de funcionamiento] (K), donde se muestra B del correspondiente idioma.

(Para los modelos con panel de toque monocromático):

Pegue la etiqueta C [Procedimiento de funcionamiento] (L), donde se muestra C del correspondiente idioma.

(Metrische Modelle außer 100-V-Spezifikationen)

7. Nach der Reinigung der Klebeflächen mit Alkohol den Warenaufkleber [Lassen Sie keine Originale auf dem Gerät liegen.] (F) und den Warenaufkleber [Vorderseite Oben] (G) der entsprechenden Sprache anbringen.

Nach der Reinigung der Klebeflächen mit Alkohol den Aufkleber A [Bedienungsverfahren] (J), den Aufkleber B [Bedienungsverfahren] (K) und/oder den Aufkleber C [Bedienungsverfahren] (L) anbringen.

(Modelle mit Farb-Sensorbildschirm für Englisch):

Den Abbildungsaufkleber (4) und den Anweisungsaufkleber (5) von Aufkleber A [Bedienungsverfahren] (J) (bei A gezeigt) anbringen.

(Modelle mit Farb-Sensorbildschirm außer Englisch):

Den Abbildungsaufkleber (4) von Aufkleber A [Bedienungsverfahren] (J) (bei A gezeigt) anbringen.

Den Aufkleber B [Bedienungsverfahren] (K) (bei B gezeigt) der entsprechenden Sprache anbringen.

(Für Modelle mit Monochrom-Sensorbildschirm):

Den Aufkleber C [Bedienungsverfahren] (L) (bei C gezeigt) der entsprechenden Sprache anbringen.

(Modelli con il sistema metrico eccetto specifiche per 100 V)

7. Dopo avere pulito con alcol, applicare l'etichetta di avvertenza [Non lasciare i documenti sul dispositivo.] (F) e l'etichetta di avvertenza [Faccia Insù] (G) redatte nella lingua corrispondente.

Dopo avere pulito con alcol, applicare l'etichetta A [Procedura di funzionamento] (J), l'etichetta B [Procedura di funzionamento] (K) e/o l'etichetta C [Procedura di funzionamento] (L).

(Modelli con pannello a sfioramento a colori per la lingua inglese):

Applicare entrambe l'etichetta con l'illustrazione (4) e l'etichetta con le istruzioni (5) dell'etichetta A [Procedura di funzionamento] (J), dove c'è la A.

(Modelli con pannello a sfioramento a colori ad eccezione della lingua inglese):

Applicare l'etichetta con l'illustrazione (4) dell'etichetta A [Procedura di funzionamento] (J), dove c'è la A.

Applicare l'etichetta B [Procedura di funzionamento] (K), dove c'è la B, redatta nella lingua corrispondente.

(Per modelli con pannello monocromatico a sfioramento):

Applicare l'etichetta C [Procedura di funzionamento] (L), dove c'è la C, redatta nella lingua corrispondente.

(只限 220V 规格产品除外的厘米规格产品)

7. 用酒精清洁后，贴上对应语言的原稿遗忘注意标签 (F) 和原稿设置方向注意标签 (G)。

用酒精清洁后，贴上操作标签 A(J)、操作标签 B(K) 和操作标签 C(L)。

(只限彩色触控式面板复印机 英语)

• 贴上操作标签 A(J) (A 和印刷的标签) 的图画标签 (4) 和测试标签 (5)。

(只限彩色触控式面板复印机 英语除外)

• 贴上操作标签 A(J) (A 和印刷的标签) 的图画标签 (4)。

• 贴上对应语言的操作标签 B(K) (B 和印刷的标签)。

(只限单色触控式面板复印机)

• 贴上对应语言的操作标签 C(L) (C 和印刷的标签)。

(100V 仕様以外のセンチ仕様のみ)

7. アルコール清掃後、該当する言語の原稿忘れ注意ラベル (F)・原稿セット向き注意ラベル (G) を貼り付ける。

アルコール清掃後、操作ラベル A(J)・操作ラベル B(K)・操作ラベル C(L) を貼り付ける。

(カラータッチパネル機 英語のみ)

• 操作ラベル A(J) (A と印刷されているラベル) のイラストラベル (4) とテキストラベル (5) を貼り付ける。


(カラータッチパネル機 英語以外)

• 操作ラベル A(J) (A と印刷されているラベル) のイラストラベル (4) を貼り付ける。

• 該当する言語の操作ラベル B(K) (B と印刷されているラベル) を貼り付ける。

(モノクロタッチパネル機のみ)

• 該当する言語の操作ラベル C(L) (C と印刷されているラベル) を貼り付ける。



Checking the operation

1. To check the machine operation, prepare an A3 size original (a) where four lines (b) are drawn 20 mm from the edges and one line (c) is drawn at the center.
2. Connect the power plug to the wall outlet and turn the main power switch on.
3. Set the original (a) in the DP and make a proof copy to check the operation and the copy example.
4. If the gap between the original (a) and the copy example exceeds the reference value, perform adjustments. For the procedure, see the following pages.

Before checking image from the DP, check and adjust image from the machine. For details, see the service manual of the machine.

Vérification du fonctionnement

1. Pour vérifier le fonctionnement de la machine, préparez un original de format A3 (a) sur lequel quatre lignes (b) ont été tracées à 20 mm des bords, et sur lequel une ligne (c) a été tracée au centre.
2. Insérer la fiche d'alimentation de la machine dans la prise murale et mettre la machine sous tension.
3. Placez l'original (a) dans le DP et effectuez une copie de test pour vérifier le fonctionnement et l'exemple de copie.
4. Si l'écart entre l'original (a) et l'exemple de copie est supérieur à la valeur de référence, effectuez les réglages nécessaires. Pour la marche à suivre, reportez-vous aux pages suivantes.

Avant de vérifier l'image sur le DP, vérifier et régler l'image sur la machine. Pour plus de détails, se reporter au manuel de service de la machine.

Verificación del funcionamiento

1. Para verificar el funcionamiento de la máquina, prepare un original de tamaño A3 (a) donde se dibujan cuatro líneas (b) a 20 mm de los bordes y una línea (c) dibujada en el centro.
2. Conecte el enchufe eléctrico de la máquina en un tomacorriente de la pared y conecte el interruptor principal.
3. Coloque el original (a) en el DP y haga una copia de prueba para verificar el funcionamiento y una copia de muestra.
4. Si la separación entre el original (a) y la copia de muestra supera el valor de referencia, haga los ajustes. Para el procedimiento, vea las siguientes páginas.

Antes de verificar la imagen del DP, verifique y ajuste la imagen desde la máquina. Para detalles, vea el manual de servicio de la máquina.

Überprüfen des Betriebs

1. Um den Betrieb der Maschine zu prüfen, ein A3-Original (a) vorbereiten, das vier Linien (b) im Abstand von 20 mm von den Kanten und eine Linie (c) in der Mitte aufweist.
2. Den Netzstecker der Maschine in die Steckdose stecken und den Betriebsschalter einschalten.
3. Das Original (a) in den DP einlegen und eine Probekopie anfertigen, um den Betrieb und das Kopienmuster zu prüfen.
4. Falls die Abweichung zwischen dem Original (a) und dem Kopienmuster den Bezugswert überschreitet, müssen Einstellungen durchgeführt werden. Das Verfahren ist auf den folgenden Seiten beschrieben.

Bevor das Bild vom DP geprüft wird, ist das Bild von der Maschine zu prüfen und einzustellen. Einzelheiten sind der Wartungsanleitung der Maschine zu entnehmen.

Controllo del funzionamento

1. Per controllare il funzionamento della macchina, preparare un originale di formato A3 (a) dove sono state tracciate quattro linee (b) a 20 mm dai bordi e una linea (c) centrale.
2. Collegare la spina del cavo di alimentazione della macchina alla presa a muro della rete elettrica e accendere l'interruttore principale di alimentazione.
3. Collocare l'originale (a) nel DP e fare una copia di prova per controllare il funzionamento della macchina e l'esempio di copia.
4. Se la differenza tra l'originale (a) e la copia di prova supera il valore di riferimento, eseguire le regolazioni. Per la procedura, leggere le seguenti pagine.

Prima di controllare l'immagine dal DP, controllare e regolare l'immagine dalla macchina. Per ulteriori dettagli, leggere il manuale d'istruzioni della macchina.

操作确认

1. 准备好 A3 尺寸的纸张（在边起 20mm 处划有 4 条线 (b)）和操作确认用原稿 (a)（在纸张中心划有 1 条线 (c)）。
2. 将机器主机上的电源插头插入插座中，打开主电源开关。
3. 将原稿 (a) 放在 DP 上，进行测试复印。
确认操作和测印件的状态。
4. 如果原稿 (a) 和测印件的偏移超过标准值时，需要调整。（调整方法参照下页以后）
确认和调整机器主机的图像后，必须对 DP 图像进行确认。详情请参照机器主机的维修手册。

動作確認

1. A3 サイズの用紙の端から 20mm の位置に線 (b) 4 本と、用紙の中心に線 (c) 1 本を引いた動作確認用の原稿 (a) を用意する。
2. 機械本体の電源プラグをコンセントに差し込み、主電源スイッチを ON にする。
3. 原稿 (a) を DP にセットし、テストコピーをおこなう。
動作およびコピーサンプルを確認する。
4. 原稿 (a) とコピーサンプルに基準値以上のずれがある場合は調整をおこなう。（調整方法は、次ページ以降を参照）
機械本体の画像確認および調整をおこなってから、DP の画像確認をおこなうこと。詳細は機械本体のサービスマニュアル参照。

Checking image from the DP

Be sure to adjust in the following order. If not, the adjustment cannot be performed correctly.

| | |
|--|---|
| For checking the angle of leading edge, see page 8. | <Reference value> Simplex copying: within ± 3.0 mm; Duplex copying: within ± 4.0 mm |
| For checking the angle of trailing edge, see page 11. | <Reference value> Simplex copying: within ± 3.0 mm; Duplex copying: within ± 4.0 mm |
| For checking the magnification, see page 15. | <Reference value> Within $\pm 1.5\%$ |
| For checking the leading edge timing, see page 17. | <Reference value> Within ± 2.0 mm |
| For checking the center line, see page 19. | <Reference value> Simplex copying: within ± 2.0 mm; Duplex copying: within ± 3.0 mm |
| When using the original for adjustment, automatic adjustment of magnification, leading edge timing and center line can be performed at a time. | |
| For the automatic adjustment using the original for adjustment, see page 21. | |

Vérification de l'image sur le DP

Veillez à effectuer le réglage en procédant dans l'ordre suivant. Sinon, il sera impossible d'obtenir un réglage correct.

| | |
|---|--|
| Pour vérifier l'angle du bord avant, reportez-vous à la page 8. | <Valeur de référence> Copie recto seul: ± 3.0 mm max.; copie recto verso: ± 4.0 mm max. |
| Pour vérifier l'angle du bord arrière, reportez-vous à la page 11. | <Valeur de référence> Copie recto seul: ± 3.0 mm max.; copie recto verso: ± 4.0 mm max. |
| Pour vérifier l'agrandissement, reportez-vous à la page 15. | <Valeur de référence> $\pm 1.5\%$ max. |
| Pour vérifier la synchronisation du bord avant, reportez-vous à la page 17. | <Valeur de référence> ± 2.0 mm max. |
| Pour vérifier la ligne médiane, reportez-vous à la page 19. | <Valeur de référence> Copie recto seul: ± 2.0 mm max.; copie recto verso: ± 3.0 mm max. |
| Lorsque vous utilisez l'original pour effectuer le réglage, vous pouvez effectuer automatiquement le réglage de l'agrandissement, de la synchronisation du bord avant et de la ligne médiane en une seule fois. | |
| Pour le réglage automatique en utilisant l'original pour effectuer le réglage, reportez-vous à la page 21. | |

Verificación de la imagen del DP

Asegúrese de ajustar en el siguiente orden. De lo contrario, el ajuste no puede hacerse correctamente.

| | |
|---|---|
| Para verificar el ángulo del borde superior, vea la página 8. | <Valor de referencia> Copia simple: dentro de ± 3.0 mm; Copia duplex: dentro de ± 4.0 mm |
| Para verificar el ángulo del borde inferior, vea la página 11. | <Valor de referencia> Copia simple: dentro de ± 3.0 mm; Copia duplex: dentro de ± 4.0 mm |
| Para verificar el cambio de tamaño, vea la página 15. | <Valor de referencia> Dentro de $\pm 1.5\%$ |
| Para verificar la sincronización del borde inferior, vea la página 17. | <Valor de referencia> Dentro de ± 2.0 mm |
| Para verificar la línea central, vea la página 19. | <Valor de referencia> Copia simple: dentro de ± 2.0 mm; Copia duplex: dentro de ± 3.0 mm |
| Cuando utilice el original para el ajuste, puede hacerse un ajuste automático del cambio de tamaño, sincronización del borde superior y línea central al mismo tiempo. Para el ajuste automático utilizando el original para el ajuste, vea la página 21. | |

Überprüfen des Bilds vom DP

Die Einstellung in der folgenden Reihenfolge durchführen. Anderenfalls kann die Einstellung nicht korrekt durchgeführt werden.

| | |
|---|--|
| Angaben zur Prüfung des Winkels der Vorderkante auf Seite 8. | <Bezugswert> Simplexkopie: innerhalb ± 3.0 mm; Duplexkopie: innerhalb ± 4.0 mm |
| Angaben zur Prüfung des Winkels der Hinterkante auf Seite 11. | <Bezugswert> Simplexkopie: innerhalb ± 3.0 mm; Duplexkopie: innerhalb ± 4.0 mm |
| Angaben zur Prüfung der Vergrößerung auf Seite 15. | <Bezugswert> Innerhalb $\pm 1.5\%$ |
| Angaben zur Prüfung des Vorderkanten-Timings auf Seite 17. | <Bezugswert> Innerhalb ± 2.0 mm |
| Angaben zur Prüfung der Mittellinie auf Seite 19. | <Bezugswert> Simplexkopie: innerhalb ± 2.0 mm; Duplexkopie: innerhalb ± 3.0 mm |
| Bei Verwendung des Originals für die Einstellung können die automatischen Einstellungen für Vergrößerung, Vorderkanten-Timing und Mittellinie gleichzeitig durchgeführt werden. | |
| Angaben zur automatischen Einstellung mithilfe des Originals auf Seite 21. | |

Controllo di immagine dal DP

Verificare che la regolazione avvenga nel seguente ordine. Altrimenti, la regolazione non potrà essere seguita correttamente.

| | |
|---|--|
| Per controllare l'angolo del bordo principale, vedere pagina 8. | <Valore di riferimento> Copia simplex: entro ± 3.0 mm; Copia duplex: entro ± 4.0 mm |
| Per controllare l'angolo del bordo di uscita, vedere pagina 11. | <Valore di riferimento> Copia simplex: entro ± 3.0 mm; Copia duplex: entro ± 4.0 mm |
| Per controllare l'ingrandimento, vedere pagina 15. | <Valore di riferimento> Entro $\pm 1.5\%$ |
| Per controllare la sincronizzazione del bordo principale, vedere pagina 17. | <Valore di riferimento> Entro ± 2.0 mm |
| Per controllare la linea centrale, vedere pagina 19. | <Valore di riferimento> Copia simplex: entro ± 2.0 mm; Copia duplex: entro ± 3.0 mm |
| Quando si utilizza l'originale per la regolazione, la regolazione automatica dell'ingrandimento, della sincronizzazione del bordo principale e della linea centrale possono essere eseguiti contemporaneamente. | |
| Per la regolazione automatica eseguita con l'originale, vedere pagina 21. | |

<< 图像确认 >>


必须按照以下步骤进行调整, 否则不能达到准确调整的要求。

| | |
|---------------------------------------|---|
| • 确认前端倾斜度 第 8 页 | <标准值> 单面: ± 3.0 mm 以内、双面: ± 4.0 mm 以内 |
| • 确认后端倾斜度 第 11 页 | <标准值> 单面: ± 3.0 mm 以内、双面: ± 4.0 mm 以内 |
| • 确认等倍度 第 15 页 | <标准值> $\pm 1.5\%$ 以内 |
| • 确认前端定时调整 第 17 页 | <标准值> ± 2.0 mm 以内 |
| • 确认中心线 第 19 页 | <标准值> 单面: ± 2.0 mm 以内、双面: ± 3.0 mm 以内 |
| 使用调整用原稿功能时, 可以同时自动进行等倍度、前端定时以及中心线的调整。 | |
| • 通过调整用原稿进行自动调整 第 21 页 | |

<< 画像の確認 >>

必ず下記の順序で調整を行うこと。順序通りに調整を行わない場合、正しい調整ができない。

| | |
|--|---|
| • 先端斜め確認 8 ページ | <基準値> 片面: ± 3.0 mm 以内、両面: ± 4.0 mm 以内 |
| • 後端斜め確認 11 ページ | <基準値> 片面: ± 3.0 mm 以内、両面: ± 4.0 mm 以内 |
| • 等倍度確認 15 ページ | <基準値> $\pm 1.5\%$ 以内 |
| • 先端タイミング確認 17 ページ | <基準値> ± 2.0 mm 以内 |
| • センターライン確認 19 ページ | <基準値> 片面: ± 2.0 mm 以内、両面: ± 3.0 mm 以内 |
| 調整用原稿を使用すると、等倍度調整、先端タイミング調整、センターライン調整の自動調整が一度におこなえる。 | |
| • 調整用原稿による自動調整 21 ページ | |



Checking the angle of leading edge

Check the gap between line (1) of original (a) and line (2) of copy example. If the gap exceeds the reference value, perform the following adjustment.

<Reference value>

For simplex copying: Within ± 3.0 mm

For duplex copying: Within ± 4.0 mm

Vérification de l'angle du bord avant

Vérifiez l'écart entre la ligne (1) de l'original (a) et la ligne (2) de l'exemple de copie. Si l'écart est supérieur à la valeur de référence, effectuez le réglage suivant.

<Valeur de référence>

Copie recto seul: $\pm 3,0$ mm max.

Copie recto verso: $\pm 4,0$ mm max.

Verificación del ángulo del borde superior

Verifique la separación entre la línea (1) del original (a) y la línea (2) de la copia de muestra. Si la separación supera el valor de referencia, haga el siguiente ajuste.

<Valor de referencia>

Para copia simple: Dentro de $\pm 3,0$ mm

Para copia duplex: Dentro de $\pm 4,0$ mm

Überprüfen des Winkels der Vorderkante

Die Abweichung der Linie (1) des Originals (a) und der Linie (2) des Kopienmusters prüfen. Überschreitet die Abweichung den Bezugswert, ist die folgende Einstellung durchzuführen.

<Bezugswert>

Für Simplexkopie: Innerhalb $\pm 3,0$ mm

Für Duplexkopie: Innerhalb $\pm 4,0$ mm

Controllo dell'angolo del bordo principale

Controllare la differenza tra la linea (1) dell'originale (a) e la linea (2) della copia di esempio. Se la differenza supera il valore di riferimento, effettuare la seguente regolazione.

<Valore di riferimento>

Per copia simplex: Entro $\pm 3,0$ mm

Per copia duplex: Entro $\pm 4,0$ mm

確認前傾斜度

確認原稿 (a) 線 (1) と測印件線 (2) の偏移。如果超过标准值时，必须进行调整。

<标准值>

单面时: ± 3.0 mm 以内

双面时: ± 4.0 mm 以内

先端斜め確認


www.tonerplus.com.ua

原稿 (a) の線 (1) とコピーサンプルの線 (2) のずれを確認する。ずれが基準値外の場合は調整をおこなう。

<基準値>

片面の場合: ± 3.0 mm 以内

両面の場合: ± 4.0 mm 以内



Adjusting the DP

1. Open the DP and loosen two adjusting screws (4) of right hinge.
2. Adjust the position of the DP.
For copy example (d): Move the DP down (·).
For copy example (e): Move the DP up (⇒).
Amount of change per scale: Approx. 0.5 mm

3. Tighten two adjusting screws (4).
4. Remove the original mat (B) and refit it (see steps 4 and 5 on page 3).

Réglage du DP

1. Ouvrez le DP et desserrez les deux vis de réglage (4) de la charnière droite.
2. Réglez la position du DP.
Pour l'exemple de copie (d): Déplacez le DP vers le bas (·).
Pour l'exemple de copie (e): Déplacez le DP vers le haut (⇒).
Quantité de changement par pas: Environ 0,5 mm

3. Resserrez les deux vis de réglage (4).
4. Retirez le tapis d'original (B) et remettez-le en place. (Reportez-vous aux étapes 4 et 5 à la page 3.)

Ajuste del DP

1. Abra el DP y afloje los dos tornillos de ajuste (4) de la bisagra derecha.
2. Ajuste la posición del DP.
Para la copia de muestra (d): Mueva el DP abajo (·).
Para la copia de muestra (e): Mueva el DP arriba (⇒).
Cantidad de cambio de escala: Aprox. 0,5 mm

3. Apriete los tornillos de ajuste (4).
4. Desmonte la plancha de original (B) y vuelva a colocar (vea los pasos 4 y 5 en la página 3).

Einstellen des DP

1. Den DP öffnen, und die zwei Einstellschrauben (4) des rechten Scharniers lösen.
2. Die Position des DP einstellen.
Für Kopienmuster (d): Den DP absenken (·).
Für Kopienmuster (e): Den DP anheben (⇒).
Änderungsbetrag pro Skalenstrich: Ca. 0,5 mm

3. Die zwei Einstellschrauben (4) wieder festziehen.
4. Die Originalmatte (B) abnehmen und wieder anbringen (siehe Schritte 4 und 5 auf Seite 3).

Regolazione del DP

1. Aprire il DP e allentare le due viti di regolazione (4) della cerniera destra.
2. Regolare la posizione del DP.
Per un esempio di copia (d): Muovere il DP verso il basso (·).
Per un esempio di copia (e): Muovere il DP verso l'alto (⇒).
Variazione graduale: Circa 0,5 mm

3. Stringere le due viti di regolazione (4).
4. Rimuovere il coprioriginale (B) e reinserirlo (vedere i passi 4 e 5 a pagina 3).

調整 DP


1. 打开 DP，松弛铰链右侧的 2 个调整螺丝 (4)。
2. 调整 DP 的位置。
测印件 (d) 时：将 DP 盖向下 (·) 移动。
测印件 (e) 时：将 DP 盖向上 (⇒) 移动。
每 1 格的移动量：约 0.5mm

3. 紧固 2 个调整螺丝 (4)。
4. 拆下原稿垫 (B)，参照第 3 页的步骤 4 和 5 再次装上。

DP の調整

1. DP を開き、ヒンジ右側の調整ビス (4) 2 本をゆるめる。
2. DP の位置を調整する。
コピーサンプル (d) の場合：DP 本体を下 (·) へ動かす。
コピーサンプル (e) の場合：DP 本体を上 (⇒) へ動かす。
1 目盛り当たりの変化量：約 0.5mm

3. 調整ビス (4) 2 本を締める。
4. 原稿マット (B) を取り外し、3 ページの手順 4、5 を参考に再度取り付ける。



5. Make a proof copy again.
6. Repeat steps 1 to 5 until line (2) of copy example shows the following the reference values.
<Reference value>
For simplex copying: Within ± 3.0 mm
For duplex copying: Within ± 4.0 mm

5. Effectuez à nouveau une copie de test.
6. Répétez les étapes 1 à 5 jusqu'à ce que la ligne (2) de l'exemple de copie corresponde aux valeurs de référence suivantes.
<Valeur de référence>
Copie recto seul: $\pm 3,0$ mm max.
Copie recto verso: $\pm 4,0$ mm max.


5. Haga otra copia de prueba.
6. Repita los pasos 1 a 5 hasta que la línea (2) de la copia de muestra tenga los siguientes valores de referencia.
<Valor de referencia>
Para copia simple: Dentro de $\pm 3,0$ mm
Para copia duplex: Dentro de $\pm 4,0$ mm

5. Eine erneute Probekopie anfertigen.
6. Die Schritte 1 bis 5 wiederholen, bis die Linie (2) des Kopienmusters die folgenden Bezugswerte aufweist.
<Bezugswert>
Für Simplexkopie: Innerhalb $\pm 3,0$ mm
Für Duplexkopie: Innerhalb $\pm 4,0$ mm

5. Eseguire di nuovo una prova di copia.
6. Ripetere i passi da 1 a 5 fino a che la linea (2) dell'esempio di copia non mostra i seguenti valori di riferimento.
<Valore di riferimento>
Per copia simplex: Entro $\pm 3,0$ mm
Per copia duplex: Entro $\pm 4,0$ mm

5. 再次进行测试复印。
6. 反复操作步骤 1 ~ 5, 直至测印件的线 (2) 为标准值内。
<标准值>
单面时: ± 3.0 mm 以内
双面时: ± 4.0 mm 以内

5. 再度テストコピーをおこなう。
6. コピーサンプルの線 (2) が基準値内になるまで、手順 1 ~ 5 を繰り返す。
<基準値>
片面の場合: ± 3.0 mm 以内
両面の場合: ± 4.0 mm 以内



Checking the angle of trailing edge

Check the gap between line (1) of original (a) and line (2) of copy example. If the gap exceeds the reference value, perform the following adjustment.

<Reference value>

For simplex copying: Within ± 3.0 mm

For duplex copying: Within ± 4.0 mm

Vérification de l'angle du bord arrière

Vérifiez l'écart entre la ligne (1) de l'original (a) et la ligne (2) de l'exemple de copie. Si l'écart est supérieur à la valeur de référence, effectuez le réglage suivant.

<Valeur de référence>

Copie recto seul: $\pm 3,0$ mm max.

Copie recto verso: $\pm 4,0$ mm max.

Verificación del ángulo del borde inferior

Verifique la separación entre la línea (1) del original (a) y la línea (2) de la copia de muestra. Si la separación supera el valor de referencia, haga el siguiente ajuste.

<Valor de referencia>

Para copia simple: Dentro de $\pm 3,0$ mm

Para copia duplex: Dentro de $\pm 4,0$ mm

Überprüfen des Winkels der Hinterkante

Die Abweichung der Linie (1) des Originals (a) und der Linie (2) des Kopienmusters prüfen. Überschreitet die Abweichung den Bezugswert, ist die folgende Einstellung durchzuführen.

<Bezugswert>

Für Simplexkopie: Innerhalb $\pm 3,0$ mm

Für Duplexkopie: Innerhalb $\pm 4,0$ mm

Controllo dell'angolo del bordo di uscita

Controllare la differenza tra la linea (1) dell'originale (a) e la linea (2) della copia di esempio. Se la differenza supera il valore di riferimento, effettuare la seguente regolazione.

<Valore di riferimento>

Per copia simplex: Entro $\pm 3,0$ mm

Per copia duplex: Entro $\pm 4,0$ mm

确认后端倾斜度

确认原稿 (a) 线和测印件线 (2) 的偏移。如果超过标准值时，必须进行调整。

<标准值>

单面时: ± 3.0 mm 以内

双面时: ± 4.0 mm 以内


後端斜め確認

原稿 (a) の線 (1) とコピーサンプルの線 (2) のずれを確認する。ずれが基準値外の場合は調整をおこなう。

<基準値>


片面の場合: ± 3.0 mm 以内

両面の場合: ± 4.0 mm 以内



Adjusting the DP

1. Open the DP and release two latches (5) using a flat-head screwdriver.



2. Release three latches (6) at the rear of the DP using a flat-head screwdriver to remove the cover (7).

Réglage du DP

1. Ouvrez le DP et libérez les deux verrous (5) à l'aide d'un tournevis à tête plate.
2. Libérez les trois verrous (6) situés à l'arrière du DP en utilisant un tournevis à tête plate pour retirer le capot (7).

Ajuste del DP

1. Abra el DP y suelte los dos pestillos (5) utilizando un destornillador de punta plana.
2. Suelte los tres pestillos (6) en el lado trasero del DP utilizando un destornillador de punta plana para desmontar la cubierta (7).

Einstellen des DP

1. Den DP öffnen, und die zwei Rasten (5) mit einem Flachschaubenzieher lösen.
2. Die drei Rasten (6) auf der Rückseite des DP mit einem Flachschaubenzieher lösen, um die Abdeckung (7) zu entfernen.

Regolazione del DP

1. Aprire il DP e rilasciare i due fermi (5) utilizzando un giravite a punta piatta.
2. Rilasciare i tre fermi (6) sul retro del DP utilizzando un giravite a punta piatta per rimuovere il coperchio (7).


調整 DP

1. 打开 DP, 用一字形螺丝刀等松开 2 处嵌入部 (5)。
2. 用一字形螺丝刀等松开 DP 后侧的 3 处嵌入部 (6), 并拆下盖板 (7)。

TONER

DP の調整 www.tonerplus.com.ua

1. DP を開き、はめ込み (5) 2 箇所をマイナスドライバーなどで解除する。
2. DP 後側のはめ込み (6) 3 箇所をマイナスドライバーなどで解除し、カバー (7) を取り外す。



3. Adjust the height of DP.

Loosen the nut (8).

For copy example (f): Loosen the adjusting screw (9). (·)

For copy example (g): Tighten the adjusting screw (9). (⇒)

Amount of change per scale: Approx. 1 mm (10)/ Approx. 0.5 mm (11)

Retighten the nut (8).

4. Refit the cover (7) removed in step 2.

5. Remove the original mat (B) and refit it (see steps 4 and 5 on page 3).

3. Réglez la hauteur du DP.

Desserrez l'écrou (8).

Pour l'exemple de copie (f): Desserrez la vis de réglage (9). (·)

Pour l'exemple de copie (g): Serrez la vis de réglage (9). (⇒)

Quantité de changement par pas: environ 1 mm (10) / environ 0,5 mm (11)

Resserrez l'écrou (8).

4. Remettez en place le capot (7) retiré auparavant à l'étape 2.

5. Retirez le tapis d'original (B) et remettez-le en place. (Reportez-vous aux étapes 4 et 5 à la page 3.)

3. Ajuste la altura del DP.

Afloje la tuerca (8).

Para la copia de muestra (f): Afloje el tornillo de ajuste (9). (·)

Para la copia de muestra (g): Apriete el tornillo de ajuste (9). (⇒)

Cantidad de cambio de escala: Aprox. 1 mm (10)/aprox. 0,5 mm (11)

Vuelva a apretar la tuerca (8).

4. Vuelva a colocar la cubierta (7) desmontada en el paso 2.

5. Desmonte la plancha de original (B) y vuelva a colocar (vea los pasos 4 y 5 en la página 3).

3. Die Höhe des DP einstellen.

Lösen Sie die Mutter (8).

Für Kopienmuster (f): Lösen Sie die Einstellschraube (9). (·)

Für Kopienmuster (g): Die Einstellschraube (9) festziehen. (⇒)

Änderungsbetrag pro Skalenstrich: ca. 1 mm (10)/ca. 0,5 mm (11)

Ziehen Sie die Mutter (8) wieder fest.

4. Die in Schritt 2 entfernte Abdeckung (7) wieder anbringen.

5. Die Originalmatte (B) abnehmen und wieder anbringen (siehe Schritte 4 und 5 auf Seite 3).

3. Regolazione dell'altezza del DP

Allentare il dado (8).

Per un esempio di copia (f): Allentare la vite di regolazione (9). (·)

Per un esempio di copia (g): Stringere la vite di regolazione (9). (⇒)

Variazione graduale: circa 1 mm (10) / circa 0,5 mm (11)

Stringere di nuovo il dado (8).

4. Reinserire il coperchio (7) rimosso nel passo 2.

5. Rimuovere il coprioriginale (B) e reinserirlo (vedere i passi 4 e 5 a pagina 3).

3. 調整 DP の高度。

松弛螺母 (8)。

測印件 (f) 時：松弛調整螺絲 (9)。(·)

測印件 (g) 時：緊固調整螺絲 (9)。(⇒)

每 1 格的移動量：約 1mm(10)/ 約 0.5mm(11)

將螺母 (8) 按原樣緊固好。

4. 在步驟 2 拆下的蓋板 (7) 按原樣裝好。

5. 拆下原稿墊 (B)，參照第 3 頁的步驟 4 和 5 再次裝上。

3. DP の高さを調整する。

ナット (8) をゆるめる。

コピーサンプル (f) の場合：調整ビス (9) をゆるめる。(·)


コピーサンプル (g) の場合：調整ビス (9) を締める。(⇒)

1 目盛り当たりの変化量：約 1mm(10)/ 約 0.5mm(11)

ナット (8) を元通り締める。

4. 手順 2 で取り外したカバー (7) を元通り取り付け。

5. 原稿マット (B) を取り外し、3 ページの手順 4、5 を参考に再度取り付け。



6. Make a proof copy again.

7. Repeat steps 1 to 6 until line (2) of copy example shows the following the reference values.

<Reference value>

For simplex copying: Within ± 3.0 mm

For duplex copying: Within ± 4.0 mm

6. Effectuez à nouveau une copie de test.

7. Répétez les étapes 1 à 6 jusqu'à ce que la ligne (2) de l'exemple de copie corresponde aux valeurs de référence suivantes.

<Valeur de référence>

Copie recto seul: $\pm 3,0$ mm max.

Copie recto verso: $\pm 4,0$ mm max.

6. Haga otra copia de prueba.

7. Repita los pasos 1 a 6 hasta que la línea (2) de la copia de muestra tenga los siguientes valores de referencia.

<Valor de referencia>

Para copia simple: Dentro de $\pm 3,0$ mm

Para copia duplex: Dentro de $\pm 4,0$ mm

6. Eine erneute Probekopie anfertigen.

7. Die Schritte 1 bis 6 wiederholen, bis die Linie (2) des Kopienmusters die folgenden Bezugswerte aufweist.

<Bezugswert>

Für Simplexkopie: Innerhalb $\pm 3,0$ mm

Für Duplexkopie: Innerhalb $\pm 4,0$ mm

6. Eseguire di nuovo una prova di copia.

7. Ripetere i passi da 1 a 6 fino a che la linea (2) dell'esempio di copia non mostra i seguenti valori di riferimento.

<Valore di riferimento>

Per copia simplex: Entro $\pm 3,0$ mm

Per copia duplex: Entro $\pm 4,0$ mm

6. 再次进行测试复印。

7. 反复操作步骤 1 ~ 6, 直至测印件的线 (2) 为标准值内。

<标准值>

单面时: ± 3.0 mm 以内

双面时: ± 4.0 mm 以内


6. 再度テストコピーをおこなう。

7. コピーサンプルの線 (2) が基準値内になるまで、手順 1 ~ 6 を繰り返す。

<基準値>

片面の場合: ± 3.0 mm 以内

両面の場合: ± 4.0 mm 以内



Checking the magnification

Check the gap between line (1) of original (a) and line (2) of copy example. If the gap exceeds the reference value, perform the following adjustment.

Reference value: Within $\pm 1.5\%$

Adjusting the DP magnification

1. Enter the maintenance mode and run the maintenance item U070 to adjust.

For first side: Select [MAIN ADJ].

For second side: Select [SUB ADJ].

Vérification de l'agrandissement

Vérifiez l'écart entre la ligne (1) de l'original (a) et la ligne (2) de l'exemple de copie. Si l'écart est supérieur à la valeur de référence, effectuez le réglage suivant.

Valeur de référence: $\pm 1,5\%$ max.

Réglage de l'agrandissement du DP

1. Passez en mode de maintenance et exécutez l'élément de maintenance U070 pour effectuer le réglage.

Pour le recto: Sélectionnez [MAIN ADJ].

Pour le verso: Sélectionnez [SUB ADJ].

Verificación del cambio de tamaño

Verifique la separación entre la línea (1) del original (a) y la línea (2) de la copia de muestra. Si la superación supera el valor de referencia, haga el siguiente ajuste.

Valor de referencia: Dentro de $\pm 1,5\%$

Ajuste del cambio de tamaño

1. Entre en el modo de mantenimiento e ingrese en el ítem de mantenimiento U070 para ajustar.

Para el primer lado: Seleccione [MAIN ADJ].

Para el segundo lado: Seleccione [SUB ADJ].

Überprüfen der Vergrößerung

Die Abweichung der Linie (1) des Originals (a) und der Linie (2) des Kopienmusters prüfen. Überschreitet die Abweichung den Bezugswert, ist die folgende Einstellung durchzuführen.

Bezugswert: Innerhalb $\pm 1,5\%$

Einstellen der DP-Vergrößerung

1. Den Wartungsmodus aktivieren, und den Wartungsposten U070 zur Einstellung ausführen.

Für erste Seite: [MAIN ADJ] wählen.

Für zweite Seite: [SUB ADJ] wählen.

Controllo dell'ingrandimento

Controllare la differenza tra la linea (1) dell'originale (a) e la linea (2) della copia di esempio. Se la differenza supera il valore di riferimento, effettuare la seguente regolazione.

Valore di riferimento: Entro $\pm 1,5\%$

Regolazione dell'ingrandimento DP

1. Entrare in modalità manutenzione e avviare la voce di manutenzione U070 per la regolazione.

Per il primo lato: selezionare [MAIN ADJ].

Per il secondo lato: selezionare [SUB ADJ].

确认等倍値

确认原稿 (a) 线 (1) 和复印件线 (2) 的偏移。如果超过标准值时，必须进行调整。

< 标准值 > $\pm 1.5\%$ 以内

调整 DP 等倍値

1. 设定为 U070 维护模式，进行调整。

表面时：选择“MAIN ADJ”。

背面时：选择“SUB ADJ”。

等倍度確認

原稿 (a) の線 (1) とコピーサンプルの線 (2) のずれを確認する。ずれが基準値外の場合は調整をおこなう。


< 基準値 > $\pm 1.5\%$ 以内

DP 等倍度調整


1. メンテナンスモード U070 をセットし、調整をおこなう。

表面の場合：「MAIN ADJ」を選択する。

裏面の場合：「SUB ADJ」を選択する。



- | | |
|--|--|
| <p>2. Change the setting value. For copy example (h): Increase the setting value. For copy example (i): Decrease the setting value. Amount of change per step: 0.21 mm</p> | <p>3. Make a proof copy again. 4. Repeat steps 1 to 3 until line (2) of copy example shows the following reference values. Reference value: Within ±1.5 %</p> |
| <p>2. Changez la valeur de réglage. Pour l'exemple de copie (h): Augmentez la valeur de réglage. Pour l'exemple de copie (i): Diminuez la valeur de réglage. Quantité de changement par pas: 0,21 mm</p> | <p>3. Effectuez à nouveau une copie de test. 4. Répétez les étapes 1 à 3 jusqu'à ce que la ligne (2) de l'exemple de copie corresponde aux valeurs de référence suivantes. Valeur de référence: ±1,5% max.</p> |
| <p>2. Cambie el valor de configuración. Para la copia de muestra (h): aumente el valor de configuración. Para la copia de muestra (i): reduzca el valor de configuración. Cantidad de cambio por paso: 0,21 mm</p> | <p>3. Haga otra copia de prueba. 4. Repita los pasos 1 a 3 hasta que la línea (2) de la copia de muestra tenga los siguientes valores de referencia. Valor de referencia: Dentro de ±1,5 %</p> |
| <p>2. Den Einstellwert ändern. Für Kopienmuster (h): Den Einstellwert erhöhen. Für Kopienmuster (i): Den Einstellwert erniedrigen. Änderungsbetrag pro Stufe: 0,21 mm</p> | <p>3. Eine erneute Probekopie anfertigen. 4. Die Schritte 1 bis 3 wiederholen, bis die Linie (2) des Kopienmusters die folgenden Bezugswerte aufweist. Bezugswert: Innerhalb ±1,5 %</p> |
| <p>2. Cambiare il valore dell'impostazione. Per un esempio di copia (h): aumentare il valore dell'impostazione. Per un esempio di copia (i): diminuire il valore dell'impostazione. Variazione graduale: 0,21 mm</p> | <p>3. Eseguire di nuovo una prova di copia. 4. Ripetere i passi da 1 a 3 fino a che la linea (2) dell'esempio di copia non mostra i seguenti valori di riferimento. Valore di riferimento: Entro ±1,5 %</p> |
| <p>2. 調整設定値。 測印件 (h) 時：提高設定値。 測印件 (i) 時：降低設定値。 1 级的移动量：约 0.21mm</p> | <p>3. 再次进行测试复印。 4. 反复操作步骤 1 ~ 3，直至测印件的线 (2) 为标准值内。 < 标准值 > ± 1.5% 以内</p> |
| <p>2. 設定値を調整する。 コピーサンプル (h) の場合: 設定値を上げる コピーサンプル (i) の場合: 設定値を下げる 1 ステップの変化量: 0.21mm</p> | <p>3. 再度テストコピーをおこなう。 4. コピーサンプルの線 (2) が基準値内になるまで、手順 1 ~ 3 を繰り返す。 < 基準値 > ± 1.5% 以内</p> |



Checking the leading edge timing

Check the gap between line (1) of original (a) and line (2) of copy example. If the gap exceeds the reference value, perform the following adjustment.

Reference value: Within ± 2.0 mm

Adjusting the DP leading edge timing

1. Enter the maintenance mode and run the maintenance item U071 to adjust.

Select [ADJUST DATA1] to adjust both the simplex and duplex copying at once.

(Use [ADJUST DATA3] only if you need to adjust the duplex copying individually.)

Vérification de la synchronisation du bord avant

Vérifiez l'écart entre la ligne (1) de l'original (a) et la ligne (2) de l'exemple de copie. Si l'écart est supérieur à la valeur de référence, effectuez le réglage suivant.

Valeur de référence: $\pm 2,0$ max.

Réglage de la synchronisation du bord avant du DP

1. Passez en mode de maintenance et exécutez l'élément de maintenance U071 pour effectuer le réglage.

Sélectionnez [ADJUST DATA1] pour régler en une seule fois la copie recto seul et la copie recto verso.

(Utilisez [ADJUST DATA3] seulement si vous voulez régler la copie recto verso individuellement.)

Cambio de la sincronización de borde superior

Verifique la separación entre la línea (1) del original (a) y la línea (2) de la copia de muestra. Si la superación supera el valor de referencia, haga el siguiente ajuste.

Valor de referencia: Dentro de $\pm 2,0$ mm

Ajuste de la sincronización de borde superior del DP

1. Entre en el modo de mantenimiento e ingrese en el ítem de mantenimiento U071 para ajustar.

Seleccione [ADJUST DATA1] para ajustar ambas copias simple y duplex al mismo tiempo.

(Utilice [ADJUST DATA3] sólo si necesita ajustar el copiado duplex individualmente.)

Überprüfen des Vorderkanten-Timings

Die Abweichung der Linie (1) des Originals (a) und der Linie (2) des Kopienmusters prüfen. Überschreitet die Abweichung den Bezugswert, ist die folgende Einstellung durchzuführen.

Bezugswert: Innerhalb $\pm 2,0$ mm

Einstellen des DP-Vorderkanten-Timings

1. Den Wartungsmodus aktivieren, und den Wartungsposten U071 zur Einstellung ausführen.

Wählen Sie [ADJUST DATA1], um Simplex- und Duplexkopie auf einmal einzustellen.

(Verwenden Sie [ADJUST DATA3] nur, wenn Duplexkopie individuell eingestellt werden muss.)

Controllo della sincronizzazione del bordo principale

Controllare la differenza tra la linea (1) dell'originale (a) e la linea (2) della copia di esempio. Se la differenza supera il valore di riferimento, effettuare la seguente regolazione.

Valore di riferimento: Entro $\pm 2,0$ mm

Regolazione della sincronizzazione del bordo principale DP

1. Entrare in modalità manutenzione e avviare la voce di manutenzione U071 per la regolazione.

Selezionare [ADJUST DATA1] per regolare simultaneamente entrambe le copie simplex e duplex.

(Usare [ADJUST DATA3] solo se è necessario regolare la copia duplex singolarmente.)

确认前端定时调整

确认原稿 (a) 线 (1) 和复印件线 (2) 的偏移。如果超过标准值时，必须进行调整。

< 标准值 > ± 2.0 mm 以内

DP 前端定时调整

1. 设定为 U071 维护模式，进行调整。

选择“ADJUST DATA1”可同时调整单面和双面。

(只有在需要单独调整双面时才可以使使用“ADJUST DATA3”。)

先端タイミング確認

原稿 (a) の線 (1) とコピーサンプルの線 (2) のずれを確認する。ずれが基準値外の場合は調整をおこなう。


< 基準値 > ± 2.0 mm 以内

DP 先端タイミング調整

1. メンテナンスモード U071 をセットし、調整をおこなう。

「ADJUST DATA1」を選択する。(片面、両面同時に調整できる)

(両面コピーモードのみを調整する場合は、「ADJUST DATA3」を選択する。)



2. Change the setting value.

For copy example (j): Decrease the setting value.

For copy example (k): Increase the setting value.

Amount of change per step: 0.196 mm

3. Make a proof copy again.

4. Repeat steps 1 to 3 until line (2) of copy example shows the following the reference values.

Reference value: Within ± 2.0 mm

2. Changez la valeur de réglage.

Pour l'exemple de copie (j): Diminuez la valeur de réglage.

Pour l'exemple de copie (k): Augmentez la valeur de réglage.

Quantité de changement par pas: 0,196 mm

3. Effectuez à nouveau une copie de test.

4. Répétez les étapes 1 à 3 jusqu'à ce que la ligne (2) de l'exemple de copie corresponde aux valeurs de référence suivantes.

Valeur de référence: $\pm 2,0$ max.

2. Cambio del valor de configuración.

Para la copia de muestra (j): Reduzca el valor de configuración.

Para la copia de muestra (k): Aumente el valor de configuración.

Cantidad de cambio por paso: 0,196 mm

3. Haga otra copia de prueba.

4. Repita los pasos 1 a 3 hasta que la línea (2) de la copia de muestra tenga los siguientes valores de referencia.

Valor de referencia: Dentro de $\pm 2,0$ mm

2. Den Einstellwert ändern.

Für Kopienmuster (j): Den Einstellwert erniedrigen.

Für Kopienmuster (k): Den Einstellwert erhöhen.

Änderungsbetrag pro Stufe: 0,196 mm

3. Eine erneute Probekopie anfertigen.

4. Die Schritte 1 bis 3 wiederholen, bis die Linie (2) des Kopienmusters die folgenden Bezugswerte aufweist.

Bezugswert: Innerhalb $\pm 2,0$ mm

2. Cambio del valore d'impostazione.

Per un esempio di copia (j): Diminuire il valore d'impostazione.

Per un esempio di copia (k): Aumentare il valore d'impostazione.

Variazione graduale: 0, 196 mm

3. Eseguire di nuovo una prova di copia.

4. Ripetere i passi da 1 a 3 fino a che la linea (2) dell'esempio di copia non mostra i seguenti valori di riferimento.

Valore di riferimento: Entro $\pm 2,0$ mm

2. 調整設定値。

測印件 (j) 時：提高設定値。

測印件 (k) 時：降低設定値。

1 级的移动量：约 0.196mm

3. 再次进行测试复印。

4. 反复操作步骤 1 ~ 3，直至测印件的线 (2) 为标准值内。

< 标准值 > ± 2.0 mm 以内

2. 設定値を調整する。

コピーサンプル (j) の場合：設定値を下げる


コピーサンプル (k) の場合：設定値を上げる

1 ステップの変化量：0.196mm

3. 再度テストコピーをおこなう。

4. コピーサンプルの線 (2) が基準値内になるまで、手順 1 ~ 3 を繰り返す。

< 基準値 > ± 2.0 mm 以内



Checking the center line

Check the gap between line (1) of original (a) and line (2) of copy example. If the gap exceeds the reference value, perform the following adjustment.

<Reference value>

For simplex copying: Within ± 2.0 mm

For duplex copying: Within ± 3.0 mm

Adjusting the DP center line

1. Enter the maintenance mode and run the maintenance item U072 to adjust.

For models with color touch panel

Select [ADJUST DATA1] to adjust both the simplex and duplex copying at once.

(Use [ADJUST DATA2] only if you need to adjust the second side of duplex copying individually.)

For models with monochrome touch panel

Select [DATA(simplex)] to adjust both the simplex and duplex copying at once.

(Use [DATA(duplex 1)] only if you need to adjust the first side of duplex copying individually.)

(Use [DATA(duplex 2)] only if you need to adjust the second side of duplex copying individually.)

Vérification de la ligne médiane

Vérifiez l'écart entre la ligne (1) de l'original (a) et la ligne (2) de l'exemple de copie. Si l'écart est supérieur à la valeur de référence, effectuez le réglage suivant.

<Valeur de référence>

Copie recto seul: $\pm 2,0$ mm max.

Copie recto verso: $\pm 3,0$ mm max.

Réglage de la ligne médiane du DP

1. Passez en mode de maintenance et exécutez l'élément de maintenance U072 pour effectuer le réglage.

Pour les modèles équipés d'un écran tactile couleur

Sélectionnez [ADJUST DATA1] pour régler en une seule fois la copie recto seul et la copie recto verso. (Utilisez [ADJUST DATA2] uniquement si vous voulez régler individuellement le verso de la copie recto verso.)

Pour les modèles équipés d'un écran tactile monochrome

Sélectionnez [DATA(simplex)] pour régler en une seule fois la copie recto seul et la copie recto verso. (Utilisez [DATA(duplex 1)] uniquement si vous voulez régler individuellement le recto de la copie recto verso.)

(Utilisez [DATA(duplex 2)] uniquement si vous voulez régler individuellement le verso de la copie recto verso.)

Verificación de la línea central

Verifique la separación entre la línea (1) del original (a) y la línea (2) de la copia de muestra. Si la superación supera el valor de referencia, haga el siguiente ajuste.

<Valor de referencia>

Para copia simple: Dentro de $\pm 2,0$ mm

Para copia duplex: Dentro de $\pm 3,0$ mm

Ajuste de la línea central del DP

1. Entre en el modo de mantenimiento e ingrese en el ítem de mantenimiento U072 para ajustar.

Para modelos con panel de toque de color

Seleccione [ADJUST DATA1] para ajustar ambas copias simple y duplex al mismo tiempo. (Utilice [ADJUST DATA2] sólo si necesita ajustar individualmente el segundo lado de la copia duplex.)

Para modelos con panel de toque monocromático

Seleccione [DATA(simplex)] para ajustar ambas copias simple y duplex al mismo tiempo.

(Utilice [DATA(duplex 1)] sólo si necesita ajustar individualmente el primer lado de la copia duplex.)

(Utilice [DATA(duplex 2)] sólo si necesita ajustar individualmente el segundo lado de la copia duplex.)

Überprüfen der Mittellinie

Die Abweichung der Linie (1) des Originals (a) und der Linie (2) des Kopienmusters prüfen. Überschreitet die Abweichung den Bezugswert, ist die folgende Einstellung durchzuführen.

<Bezugswert>

Für Simplexkopie: Innerhalb $\pm 2,0$ mm

Für Duplexkopie: Innerhalb $\pm 3,0$ mm

Einstellen der DP-Mittellinie

1. Den Wartungsmodus aktivieren, und den Wartungsposten U072 zur Einstellung ausführen.

Für Modelle mit Farb-Sensorbildschirm

Wählen Sie [ADJUST DATA1], um Simplex- und Duplexkopie auf einmal einzustellen. (Verwenden Sie [ADJUST DATA2] nur, wenn die zweite Seite der Duplexkopie individuell eingestellt werden muss.)

Für Modelle mit Monochrom-Sensorbildschirm

Wählen Sie [DATA(simplex)], um Simplex- und Duplexkopie auf einmal einzustellen.

(Verwenden Sie [DATA(duplex 1)] nur, wenn die erste Seite der Duplexkopie individuell eingestellt werden muss.)

(Verwenden Sie [DATA(duplex 2)] nur, wenn die zweite Seite der Duplexkopie individuell eingestellt werden muss.)

Controllo della linea centrale

Controllare la differenza tra la linea (1) dell'originale (a) e la linea (2) della copia di esempio. Se la differenza supera il valore di riferimento, effettuare la seguente regolazione.

<Valore di riferimento>

Per copia simplex: Entro $\pm 2,0$ mm

Per copia duplex: Entro $\pm 3,0$ mm

Regolazione della linea centrale del DP

1. Entrare in modalità manutenzione e avviare la voce di manutenzione U072 per la regolazione.

Per i modelli con pannello a sfioramento a colori

Selezionare [ADJUST DATA1] per regolare simultaneamente entrambe le copie simplex e duplex.

(Usare [ADJUST DATA2] solo se è necessario regolare il secondo lato della copia duplex singolarmente.)

Per i modelli con pannello monocromatico a sfioramento

Selezionare [DATA(simplex)] per regolare simultaneamente entrambe le copie simplex e duplex.

(Usare [DATA(duplex 1)] solo se è necessario regolare il primo lato della copia duplex singolarmente.)

(Usare [DATA(duplex 2)] solo se è necessario regolare il secondo lato della copia duplex singolarmente.)

确认中心线

确认原稿 (a) 线 (1) 和复印件线 (2) 的偏移。如果超过标准值时, 必须进行调整。

<标准值>

单面时: ± 2.0 mm 以内

双面时: ± 3.0 mm 以内

调整 DP 中心线

1. 选定维护模式 U072, 进行调整。

彩色触摸屏板时

选择“ADJUST DATA1”可同时调整单面和双面。

(只限于调整双背面时, 选择“ADJUST DATA2”。)

黑白触摸屏板时

选择“DATA(simplex)”同时调整单面和双面。

(只限于调整双表面时, 选择“DATA(duplex 1)”。

(只限于调整双背面时, 选择“DATA(duplex 2)”。

センターライン確認

原稿 (a) のセンターライン (1) とコピーサンプルのセンターライン (2) のずれを確認する。ずれが基準値外の場合は調整をおこなう。

<基準値>

片面の場合: ± 2.0 mm 以内

両面の場合: ± 3.0 mm 以内

DP センターライン調整

1. メンテナンスモード U072 をセットし、調整をおこなう。

カラータッチパネル機の場合

「ADJUST DATA1」を選択する。(片面、両面同時に調整できる)


(両面裏面のみを調整する場合は、「ADJUST DATA2」を選択する。)

モノクロタッチパネル機の場合

「DATA(片面)」を選択する。(片面、両面同時に調整できる)

(両面表面のみを調整する場合は、「DATA(両面表)」を選択する。)

(両面裏面のみを調整する場合は、「DATA(両面裏)」を選択する。)



2. Change the setting value.

For copy example (l): Increase the setting value.

For copy example (m): Decrease the setting value.

Amount of change per step: 0.086 mm

3. Make a proof copy again.

4. Repeat steps 1 to 3 until line (2) of copy example shows the following the reference values.

<Reference value>

For simplex copying: Within ± 2.0 mm

For duplex copying: Within ± 3.0 mm

2. Changez la valeur de réglage.

Pour l'exemple de copie (l): Augmentez la valeur de réglage.

Pour l'exemple de copie (m): Diminuez la valeur de réglage.

Quantité de changement par pas: 0,086 mm

3. Effectuez à nouveau une copie de test.

4. Répétez les étapes 1 à 3 jusqu'à ce que la ligne (2) de l'exemple de copie corresponde aux valeurs de référence suivantes.

<Valeur de référence>

Copie recto seul: $\pm 2,0$ mm max.

Copie recto verso: $\pm 3,0$ mm max.

2. Cambie el valor de configuración.

Para la copia de muestra (l): Aumente el valor de configuración.

Para la copia de muestra (m): Reduzca el valor de configuración.

Cantidad de cambio por paso: 0,086 mm

3. Haga otra copia de prueba.

4. Repita los pasos 1 a 3 hasta que la línea (2) de la copia de muestra tenga los siguientes valores de referencia.

<Valor de referencia>

Para copia simple: Dentro de $\pm 2,0$ mm

Para copia duplex: Dentro de $\pm 3,0$ mm

2. Den Einstellwert ändern.

Für Kopienmuster (l): Den Einstellwert erhöhen.

Für Kopienmuster (m): Den Einstellwert erniedrigen.

Änderungsbetrag pro Stufe: 0,086 mm

3. Eine erneute Probekopie anfertigen.

4. Die Schritte 1 bis 3 wiederholen, bis die Linie (2) des Kopienmusters die folgenden Bezugswerte aufweist.

<Bezugswert>

Für Simplexkopie: Innerhalb $\pm 2,0$ mm

Für Duplexkopie: Innerhalb $\pm 3,0$ mm

2. Cambiare il valore dell'impostazione.

Per un esempio di copia (l): Aumentare il valore dell'impostazione.

Per un esempio di copia (m): Diminuire il valore dell'impostazione.

Variazione graduale: 0,086 mm

3. Eseguire di nuovo una prova di copia.

4. Ripetere i passi da 1 a 3 fino a che la linea (2) dell'esempio di copia non mostra i seguenti valori di riferimento.

<Valore di riferimento>

Per copia simplex: Entro $\pm 2,0$ mm

Per copia duplex: Entro $\pm 3,0$ mm

2. 調整設定値。

測印件 (1) 時: 提高設定値。

測印件 (m) 時: 降低設定値。

1 级的移动量: 约 0.086mm

3. 再次进行测试复印。

4. 反复操作步骤 1 ~ 3, 直至测印件的线 (2) 为标准值内。

<标准值>

单面时: ± 2.0 mm 以内

双面时: ± 3.0 mm 以内

2. 設定値を調整する。

コピーサンプル (1) の場合: 設定値を上げる

コピーサンプル (m) の場合: 設定値を下げる

1 ステップの変化量: 0.086mm


3. 再度テストコピーをおこなう。

4. コピーサンプルのセンターライン (2) が基準値内になるまで、手順 1 ~ 3 を繰り返す。

<基準値>

片面の場合: ± 2.0 mm 以内

両面の場合: ± 3.0 mm 以内



Automatic adjustment using the original for adjustment

Before performing this adjustment, be sure to adjust the angle of leading edge and the angle of trailing edge (see pages 8 and 11).

1. Cut the trailing edge of an original for adjustment as shown in a figure.
2. Place the original for adjustment in the DP with the F and R surface up.
3. Enter the maintenance mode and run the maintenance item U411. Select [DP], press [INPUT] and then press the start key.
Adjustments of the DP magnification, DP leading edge timing and DP center line are performed automatically.
4. When [RESULT OK 00] is displayed, the adjustments are properly completed. If a problem occurs during automatic adjustments, [ERROR XX] (XX is replaced with an error code) is displayed.
Check the original set position and repeat the steps 2 to 3 until [RESULT OK 00] is displayed. For details, see the service manual.

Réglage automatique en utilisant l'original pour effectuer le réglage

Avant d'effectuer ce réglage, veiller à régler l'angle du bord avant et l'angle du bord arrière (se reporter aux pages 8 et 11).

1. Découpez le bord arrière de l'original utilisé pour le réglage comme indiqué sur l'illustration.
2. Placez l'original utilisé pour le réglage dans le DP, en orientant les surfaces F et R vers le haut.
3. Passez en mode de maintenance et exécutez l'élément de maintenance U411. Sélectionnez [DP], appuyez sur [INPUT], puis appuyez sur la touche de démarrer.
Les réglages de l'agrandissement du DP, de la synchronisation du bord avant du DP et de la ligne médiane du DP sont alors effectués automatiquement.
4. Lorsque [RESULT OK 00] s'affiche, les réglages ont été accomplis correctement. Si une anomalie se produit pendant la réalisation des réglages automatiques, le message [ERROR XX] (XX désignant le code d'erreur) s'affiche.
Vérifiez la position de mise en place de l'original et répétez les étapes 2 et 3 jusqu'à ce que [RESULT OK 00] s'affiche. Pour plus de détails, reportez-vous au manuel de service.

Ajuste automático utilizando el original para el ajuste

Antes de hacer el ajuste, asegúrese de ajustar el ángulo del borde superior y el ángulo del borde inferior (vea las páginas 8 y 11).

1. Corte el borde inferior de un original para el ajuste como se indica en la figura.
2. Coloque el original para el ajuste en el DP con la superficie F y R arriba.
3. Entre en el modo de mantenimiento e ingrese en el ítem de mantenimiento U411. Seleccione [DP], presione [INPUT] y presione la tecla de inicio.
Los ajustes de cambio de tamaño de DP, sincronización de borde superior d DP y línea central de DP se hacen automáticamente.
4. Cuando aparece [RESULT OK 00], se completa correctamente el ajuste. Si se produce un problema durante los ajustes automáticos, aparece [ERROR XX] (donde XX cambia por un código de error).
Verifique la posición de colocación del original y repita los pasos 2 a 3 hasta que aparezca [RESULT OK 00]. Para más detalles, vea el manual de servicio.

Automatische Einstellung mithilfe des Originals

Bevor diese Einstellung durchgeführt wird, muss der Winkel der Vorder- und Hinterkante eingestellt werden (siehe die Seiten 8 und 11).

1. Die Vorderkante eines Originals für die Einstellung einschneiden, wie in der Abbildung gezeigt.
2. Das Original für die Einstellung mit der Fläche F und R nach oben in den DP einlegen.
3. Den Wartungsmodus aktivieren, und den Wartungsposten U411 ausführen. [DP] wählen, [INPUT] drücken, und dann die Start drücken.
Die Einstellungen von DP-Vergrößerung, DP-Vorderkanten-Timing und DP-Mittellinie werden automatisch durchgeführt.
4. Wenn [RESULT OK 00] angezeigt wird, sind die Einstellungen ordnungsgemäß abgeschlossen. Falls während der automatischen Einstellungen eine Störung auftritt, wird [ERROR XX] (XX wird durch einen Fehlercode ersetzt) angezeigt.
Die Original-Einlegeposition überprüfen, und die Schritte 2 bis 3 wiederholen, bis [RESULT OK 00] angezeigt wird. Einzelheiten sind der Wartungsanleitung zu entnehmen.

Regolazione automatica eseguita con l'originale

Prima di eseguire questa regolazione, verificare che l'angolo del bordo principale e l'angolo del bordo di uscita siano regolati (vedere le pagine 8 e 11).

1. Tagliare il bordo di uscita di un originale per la regolazione come si vede nel disegno.
2. Collocare l'originale per la regolazione nel DP con la superficie F e R rivolta verso l'alto.
3. Entrare in modalità manutenzione e avviare la voce di manutenzione U411. Selezionare [DP], premere [INPUT] e poi premere il tasto di avvio.
Le regolazioni dell'ingrandimento DP, della sincronizzazione del bordo principale e della linea centrale del DP saranno eseguite automaticamente.
4. Quando [RESULT OK 00] viene visualizzato, le regolazioni sono state completate correttamente. Se durante le regolazioni automatiche si verifica qualche problema, nel display viene visualizzato [ERROR XX] (XX viene sostituito da un codice di errore).
Controllare la posizione d'impostazione dell'originale e ripetere i passi da 2 a 3 fino a che [RESULT OK 00] non viene visualizzato. Per ulteriori dettagli, vedere il manuale d'istruzioni.

通过调整用原稿进行自动调整


先完成前端倾斜和后端倾斜的调整后, 再进行以下操作。(参照第 8 页和第 11 页)

1. 按图所示切断调整用原稿的后端。
2. 记有 F 和 R 的面朝上, 将调整用原稿放在 DP 上。
3. 选定维修模式 U411。选择“DP”, 按下“INPUT”, 再按下起动键。
自动进行等倍值、前端定时、中心线的调整。
4. 自动调整正常结束时显示出“RESULT OK 00”表示。执行调整中发生异常时、显示出“ERROR XX”。
确认原稿设定位置后, 再次进行调整(详情请参照维修手册)。

調整用原稿による自動調整


先端斜め調整および後端斜め調整をおこなってから実施する。(8 ページ、11 ページ参照)

1. 調整用原稿の後端をイラストのようにカットする。
2. F・R が記載されている面を上にして、調整用原稿を DP にセットする。
3. メンテナンスモード U411 をセットする。「DP」を選択し、「INPUT」を押して次にスタートキーを押す。
等倍度・先端タイミング・センターライン調整が自動的にこなわれる。
4. 自動調整が正常に終了すると「RESULT OK 00」が表示される。調整実行中にエラーが発生した場合は、「ERROR XX」が表示される。
原稿のセット位置を確認し、再度調整をおこなう(詳細はサービスマニュアル参照)。




**Adjusting the DP open/close angle
To adjust the DP open/close angle to 60
degrees**

1. Insert the angle adjusting plate (C) and fit it using M4 x 14 screw (E).



**To adjust the DP open/close angle to 30
degrees**

1. Remove two stop rings (12) and pull the shaft (13) out.
2. Insert the shaft (13) into the holes (14) and refit two stop rings (12).



3. Insert the angle adjusting plate (C) and fit it using M4 x 14 screw (E).

**Réglage de l'angle d'ouverture/
fermeture du DP**

**Pour régler l'angle d'ouverture/fermeture du
DP à 60 degrés**

1. Insérez la plaque de réglage d'angle (C), et fixez-la à l'aide d'une vis M4 x 14 (E).

**Pour régler l'angle d'ouverture/fermeture du
DP à 30 degrés**

1. Retirez deux bagues d'arrêt (12) et tirez l'arbre (13) vers l'extérieur.
2. Insérez l'arbre (13) dans les orifices (14) et remettez les deux bagues d'arrêt (12) en place.

3. Insérez la plaque de réglage d'angle (C), et fixez-la à l'aide d'une vis M4 x 14 (E).

**Ajuste del ángulo de apertura/cierre del
DP**

**Para ajustar el ángulo de apertura/cierre del
DP a 60 grados**

1. Inserte la placa de ajuste de ángulo (C) y fije con el tornillo M4 x 14 (E).

**Para ajustar el ángulo de apertura/cierre del
DP a 30 grados**

1. Desmonte los dos aros de tope (12) y tire del eje (13) hacia fuera.
2. Inserte el eje (13) en los orificios (14) y vuelva a colocar los dos aros de tope (12).

3. Inserte la placa de ajuste de ángulo (C) y fije con el tornillo M4 x 14 (E).

**Einstellen des DP-Öffnungs-/
Schließungswinkels**

**Einstellung des DP-Öffnungs-/
Schließungswinkels auf 60 Grad**

1. Den Winkleinstellhalter (C) einsetzen und mit einer M4 x 14 Schraube (E) befestigen.

**Einstellung des DP-Öffnungs-/
Schließungswinkels auf 30 Grad**

1. Die zwei Sicherungsringe (12) entfernen, und die Achse (13) herausziehen.
2. Die Achse (13) in die Löcher (14) einführen, und die zwei Sicherungsringe (12) wieder anbringen.

3. Den Winkleinstellhalter (C) einsetzen und mit einer M4 x 14 Schraube (E) befestigen.

**Regolazione dell'angolo di apertura e
chiusura del DP**

**Per regolare l'angolo di apertura e chiusura
del DP a 60 gradi**

1. Inserire la piastra di regolazione dell'angolo (C) e fissarla con una vite M4 x 14 (E).

**Per regolare l'angolo di apertura e chiusura
del DP a 30 gradi**

1. Rimuovere i due anelli di arresto (12) ed estrarre l'albero (13).
2. Inserire l'albero (13) nei fori (14) e fissare nuovamente i due anelli di arresto (12).

3. Inserire la piastra di regolazione dell'angolo (C) e fissarla con una vite M4 x 14 (E).

調整 DP の角度

設定 60 度の DP 開閉角度時

1. 調整板 (C) を挿入し、ビス M4 x 14 (E) を固定する。

設定 30 度の DP 角度時

1. 拆下 2 个止动环 (12)，拔下轴 (13)。
2. 将轴 (13) 插入孔 (14)，并将 2 个止动环 (12) 按原样装好。

3. 插入调整板 (C)，用 1 个螺丝 M4 x 14 (E) 进行固定。

DP 開閉角度の調整

DP 開閉角度を 60° に設定する場合

1. 調整板 (C) を挿入し、ビス M4 x 14 (E) 1 本で固定する。

DP 開閉角度を 30° に設定する場合

1. ストップリング (12) 2 個を外し、軸 (13) を引き抜く。
2. 軸 (13) を穴 (14) に挿入し、ストップリング (12) 2 個を元通り取り付け。

3. 調整板 (C) を挿入し、ビス M4 x 14 (E) 1 本で固定する。

INSTALLATION GUIDE FOR PAPER FEEDER

CAUTION

ATTENTION


PRECAUCION


VORSICHT

ATTENZIONE

注 意

注 意





English

Supplied parts

| | | |
|---|-----------------|---|
| A | Paper feeder | 1 |
| B | Pin | 2 |
| C | Joint plate | 1 |
| D | M3 × 6 screw | 1 |
| E | Paper size card | 6 |

| | | |
|---|---------------|---|
| F | Stay | 4 |
| G | M4 × 20 screw | 2 |
| H | M4 × 10 screw | 2 |

Use the paper size card (E) which is the same specification paper size used in the machine.

Français

Pièces fournies

| | | |
|---|----------------------------|---|
| A | Bureau papier | 1 |
| B | Broches | 2 |
| C | Plaque de raccord | 1 |
| D | Vis M3 × 6 | 1 |
| E | Cartes de format de papier | 6 |

| | | |
|---|-------------|---|
| F | Supports | 4 |
| G | Vis M4 × 20 | 2 |
| H | Vis M4 × 10 | 2 |

Utiliser la carte de format de papier (E) possédant le même format de papier que celui spécifié pour la machine.

Español

Partes suministradas

| | | |
|---|----------------------------|---|
| A | Alimentador de papel | 1 |
| B | Clavija | 2 |
| C | Placa de unión | 1 |
| D | Tornillo M3 × 6 | 1 |
| E | Tarjeta de tamaño de papel | 6 |

| | | |
|---|------------------|---|
| F | Base | 4 |
| G | Tornillo M4 × 20 | 2 |
| H | Tornillo M4 × 10 | 2 |

Utilice la tarjeta de tamaño de papel (E) que sea del mismo tamaño de papel especificado utilizado en la máquina.

Deutsch

Gelieferte Teile

| | | |
|---|-------------------|---|
| A | Papiereinzug | 1 |
| B | Stift | 2 |
| C | Verbindungsplatte | 1 |
| D | M3 × 6 Schraube | 1 |
| E | Papierformatkarte | 6 |

| | | |
|---|------------------|---|
| F | Stütze | 4 |
| G | M4 × 20 Schraube | 2 |
| H | M4 × 10 Schraube | 2 |

Benutzen Sie die Papierformatkarte (E), deren Format mit demjenigen des für die Maschine vorgeschriebenen Papiers übereinstimmt.

Italiano

Parti di fornitura

| | | |
|---|------------------------------------|---|
| A | Unità di alimentazione della carta | 1 |
| B | Perno | 2 |
| C | Piastra di giunzione | 1 |
| D | Vite M3 × 6 | 1 |
| E | Scheda formato carta | 6 |

| | | |
|---|--------------|---|
| F | Sospensione | 4 |
| G | Vite M4 × 20 | 2 |
| H | Vite M4 × 10 | 2 |

Utilizzare la scheda formato carta (E) corrispondente al formato carta utilizzato nella macchina.

简体中文

同装品

| | | |
|---|-----------|---|
| A | 供纸盒 | 1 |
| B | 固定插销 | 2 |
| C | 连接金属件 | 1 |
| D | 螺丝 M3 × 6 | 1 |

| | | |
|---|------------|---|
| E | 复印纸 | 6 |
| F | 防倒金属件 | 4 |
| G | 螺丝 M4 × 20 | 2 |
| H | 螺丝 M4 × 10 | 2 |

请使用与机器本体的用纸尺寸相同规格的复印纸 (E)。

日本語


同梱品

| | | |
|---|-----------|---|
| A | ペーパーフィーダ | 1 |
| B | ピン | 2 |
| C | 接続金具 | 1 |
| D | ビス M3 × 6 | 1 |

| | | |
|---|--------------------------------|---|
| E | 用紙シート | 6 |
| F | 転倒防止金具 (100V 仕様では使用しない) | 4 |
| G | ビス M4 × 20 (100V 仕様では使用しない) | 2 |
| H | ビス M4 × 10 (100V 仕様では使用しない) | 2 |


用紙シート (E) は、機械本体の用紙サイズと同じ仕様のシートを使用してください。

www.tonerplus.com.ua



Precaution for unpacking

Hold the positions shown in the figure and remove the paper feeder from the outer case.



Procedure

Releasing lift plate stopper

1. Pull each cassette out and then remove the lift plate stopper (1) from each cassette and attach it to the storage location (2).
2. Gently close each cassette.

Precautions

- Be sure to remove any tape and/or cushioning material from supplied parts.
- Before installing the paper feeder, be sure to turn the main power switch of the machine off and unplug the power cable from the wall outlet.

Précautions

- Veillez à retirer les morceaux de bande adhésive et/ou les matériaux de rembourrage des pièces fournies.
- Avant d'installer le bureau papier, veiller à mettre la machine hors tension et à débrancher le câble d'alimentation de la prise murale.

Précaution pour le déballage

Saisir les emplacements indiqués sur l'illustration et retirer le bureau papier du boîtier extérieur.

Procédure

Libération de la butée de plaque d'élévation

1. Tirer chaque tiroir vers l'extérieur puis retirer la butée de plaque d'élévation (1) de chaque tiroir et la fixer à l'emplacement de rangement (2).
2. Refermer progressivement chaque tiroir.

Precauciones

- Asegúrese de despegar todas las cintas y/o material amortiguador de las partes suministradas.
- Antes de instalar el alimentador de papel, asegúrese de desconectar el interruptor principal de la máquina y desenchufar el cable eléctrico del tomacorriente de la pared.

Precauciones para el desembalaje

Sujete por las posiciones indicadas en la figura y desmonte el alimentador de papel de la caja de embalaje.

Procedimiento

Soltado del tope de placa de elevación

1. Abra la bandeja y quite el tope de la placa de elevación (1) de cada bandeja y colóquela en su lugar de depósito (2).
2. Cierre suavemente cada bandeja.

Vorsichtsmaßnahmen

- Entfernen Sie Klebeband und/oder Dämpfungsmaterial vollständig von den mitgelieferten Teilen.
- Schalten Sie unbedingt den Betriebsschalter der Maschine aus, und trennen Sie das Netzkabel von der Netzsteckdose, bevor Sie den Papiereinzug installieren.

Vorsichtsmaßnahme beim Auspacken

Halten Sie den Papiereinzug an den in der Abbildung gezeigten Stellen, und heben Sie ihn aus dem äußeren Karton heraus.

Verfahren

Lösen des Hebeplattenanschlages

1. Die einzelnen Kassetten herausziehen, dann den Hebeplattenanschlag (1) von jeder Kasette entfernen und an der Speicherposition (2) anbringen.
2. Alle Kassetten sanft schließen.

Precauzioni

- Accertarsi di rimuovere tutti i nastri adesivi e/o il materiale di imbottitura dalle parti fornite.
- Prima di installare l'unità di alimentazione della carta, assicurarsi di spegnere l'interruttore principale di alimentazione della macchina e scollegare la spina del cavo di alimentazione dalla presa a muro della rete elettrica.

Precauzioni per il disinballaggio

Mantenere le posizioni indicate nella figura e rimuovere l'unità di alimentazione della carta dall'involucro esterno.

Procedura

Rimozione del fermo della piastra di sollevamento

1. Estrarre ciascun cassetto e poi rimuovere il fermo della piastra di sollevamento (1) da ciascun cassetto e fissarlo nella posizione di immagazzinaggio (2).
2. Chiudere delicatamente ciascun cassetto.

注意事項

- 如果同裝品上帶有固定膠帶、緩衝材料時務必揭下。
- 安裝供紙盒時，必須先關閉機器主機上的主電源開關，並拔下電源插頭後再進行工作。

開包時的注意事項

開包時，拿住圖示的位置從外箱內取出。

安裝步驟

解除升降板的固定

1. 拉出各供紙盒，拆下各 1 個升降板擋塊 (1)，並安裝在保管場所 (2) 上。
2. 輕輕地推入各供紙盒。

注意事項

- 同梱品に固定テープ、緩衝材が付いている場合は必ず取り外すこと。
- ペーパーフィーダを設置する場合は、機械本体の主電源スイッチを OFF にし、電源プラグを抜いてから作業をおこなう。


開梱時の注意

開梱時は、イラストの位置を持って外ケースから取り出す。

設置手順


リフト板の固定解除

1. 各カセットを引き出し、リフト板ストップ (1) の各 1 個を外して保管場所 (2) に取り付ける。
2. 各カセットを静かに押し込む。




Installing the paper feeder

3. Pull out and remove cassette 2 (3) from the machine.



4. Place the machine on the paper feeder (A) to fit the positioning pins (4) at the front left and right of the paper feeder to the holes (5) in the machine.



5. Fix the machine using two pins (B).
6. Insert cassette 2 (3) into the machine.

Installation du bureau papier

3. Tirer le tiroir 2 (3) hors de la machine.

4. Placer la machine sur le bureau papier (A) pour engager les broches de positionnement (4) situées des côtés avant gauche et droit du bureau papier dans les orifices (5) de la machine.

5. Fixer la machine à l'aide de deux broches (B).
6. Insérer le tiroir 2 (3) dans la machine.

Instalación del alimentador de papel

3. Quite y desmonte la bandeja 2 (3) de la máquina.

4. Coloque la máquina sobre el alimentador de papel (A) para que se introduzcan las clavijas de posicionamiento (4) en el lado delantero izquierdo y derecho del alimentador de papel en los orificios (5) en la máquina.

5. Fije la máquina utilizando dos clavijas (B).
6. Coloque la bandeja 2 (3) en la máquina.

Installieren des Papiereinzugs

3. Die Kassette 2 (3) herausziehen und von der Maschine entfernen.

4. Die Maschine so auf den Papiereinzug (A) setzen, dass die Passstifte (4) auf der linken und rechten Vorderseite des Papiereinzugs in den Löchern (5) der Maschine sitzen.

5. Die Maschine mit den zwei Stiften (B) befestigen.
6. Die Kassette 2 (3) in die Maschine einsetzen.

Installazione dell'unità di alimentazione della carta

3. Estrarre e rimuovere il cassetto 2 (3) dalla macchina.

4. Installare la macchina sopra l'unità di alimentazione della carta (A) in modo da mantenere i perni di posizionamento (4) situati sul lato anteriore sinistro e destro dell'unità di alimentazione della carta stessa allineati ai fori (5) nella macchina.

5. Fissare la macchina utilizzando due perni (B).
6. Inserire il cassetto 2 (3) nella macchina.

供紙盒的安装

3. 取出机器主机上的供纸盒 2(3)。

4. 供纸盒前侧的左右插销 (4) 分别对准机器主机的各相应销孔 (5) 后, 将机器主机放在供纸盒 (A) 上。

5. 用 2 个固定插销 (B) 固定机器主机。
6. 将供纸盒 2(3) 装回原来的位置。

ペーパーフィーダの設置


3. 機械本体のカセット 2(3) を引き抜く。

4. ペーパーフィーダ前側の左右のピン (4) と機械本体の穴 (5) が一致するように、機械本体をペーパーフィーダ (A) にのせる。


5. ピン (B) 2 本で機械本体を固定する。
6. カセット 2(3) を元通り挿入する。

TONER


www.tonerplus.com.ua



7. Remove the screw (6) at the rear side of the paper feeder to remove the cover (7).



8. Remove the screw (8) to remove the metal plate (9).
The removed metal plate (9) is no longer required.



9. Connect the connector (10) to the machine.

7. Retirer la vis (6) située sur le côté arrière du bureau papier pour retirer le couvercle (7).

8. Retirer la vis (8) pour déposer la plaque métallique (9).
La plaque métallique déposée (9) n'est plus nécessaire.

9. Brancher le connecteur (10) à la machine.

7. Quite el tornillo (6) en el lado trasero del alimentador de papel para desmontar la tapa (7).

8. Quite el tornillo (8) para desmontar la placa de metal (9).
La placa de metal desmontada (9) ya no es necesaria.

9. Conecte el conector (10) en la máquina.

7. Die Schraube (6) auf der Rückseite des Papiereinzugs herausdrehen, um die Abdeckung (7) abzunehmen.

8. Die Schraube (8) herausdrehen, um die Metallplatte (9) abzunehmen.
Die abgenommene Metallplatte (9) wird nicht mehr benötigt.

9. Den Steckverbinder (10) an die Maschine anschließen.

7. Rimuovere la vite (6) dal retro dell'unità di alimentazione della carta per togliere il coperchio (7).

8. Rimuovere la vite (8) per togliere la piastra di metallo (9).
La piastra di metallo (9) rimossa non è più necessaria.

9. Collegare il connettore (10) alla macchina.

7. 拆除供纸盒后侧的 1 个螺丝 (6)，拆下盖板 (7)。


8. 拆除 1 个螺丝 (8)，拆下金属件 (9)。
不要安装金属件 (9)。

9. 将接头 (10) 连接在机器主机上。


7. ペーパーフィーダ後側のビス (6) 1 本を外し、カバー (7) を取り外す。

8. ビス (8) 1 本を外し、金具 (9) を取り外す。
金具 (9) は取り付けない。

9. コネクタ (10) を機械本体に接続する。



10. Attach the joint plate (C) using two screws.
Right: Use the screw (8) removed in step 8
Left: Use M3 x 6 screw (D)



11. Pass the wires (12) through the clamp (11).
Be sure to pass the wires (12) through the clamp (11) because the wires (12) may touch the motor.

12. Refit the cover (7) using the screw (6) removed in step 7.

10. Fixer la plaque de raccord (C) à l'aide de deux vis.
A droite: Utiliser la vis (8) retirée auparavant à l'étape 8.
A gauche: Utiliser la vis M3 x 6 (D).

11. Faire passer les fils (12) par le collier (11).
Veiller à faire passer les fils (12) par le collier (11) car les fils (12) risqueraient d'entrer en contact avec le moteur.

12. Remettre le couvercle (7) en place à l'aide de la vis (6) retirée auparavant à l'étape 7.

10. Instale la placa de unión (C) utilizando dos tornillos.
Derecho: Utilice el tornillo (8) quitado en el paso 8.
Izquierdo: Utilice el tornillo M3 x 6 (D)

11. Pase los cables (12) por la ménsula (11).
Asegúrese de pasar los cables (12) por la ménsula (11) porque los cables (12) pueden tocar el motor.

12. Vuelva a colocar la tapa (7) utilizando el tornillo (6) quitado en el paso 7.

10. Die Verbindungsplatte (C) mit zwei Schrauben befestigen.
Rechts: Die in Schritt 8 entfernte Schraube (8) benutzen.
Links: Die M3 x 6 Schraube (D) benutzen.

11. Die Kabel (12) durch die Klemme (11) führen.
Die Kabel (12) müssen unbedingt durch die Klemme (11) geführt werden, weil sie sonst den Motor berühren können.

12. Bringen Sie die Abdeckung (7) wieder mit der in Schritt 7 entfernten Schraube (6) an.

10. Montare la piastra di giunzione (C) utilizzando due viti.
Destra: utilizzare la vite (8) rimossa nel passo 8.
Sinistra: utilizzare la vite M3 x 6 (D).

11. Fare passare i cavi (12) attraverso il morsetto (11).
Assicurarsi di fare passare i cavi (12) attraverso il morsetto (11) perché potrebbero toccare il motore.

12. Inserire il pannello posteriore (7) usando le viti (6) rimosse al punto 7.

10. 用2个螺丝固定连接金属件 (C)。
右侧: 在步骤8上拆下的螺丝 (8)。
左侧: 螺丝 M3 x 6 (D)。


11. 将电线 (12) 穿过夹钳 (11)。
务必将电线 (12) 穿过夹钳 (11), 以免电线 (12) 碰触马达。

12. 用步骤7拆除的1个螺丝 (6) 将盖板 (7) 装回原来的位置。

10. ビス2本で接続金具 (C) を取り付け。
右側: 手順8で外したビス (8)
左側: ビス M3 x 6 (D)


11. クランプ (11) に電線 (12) を通す。
電線 (12) がモータに接触する恐れがあるので、必ずクランプ (11) に電線 (12) を通すこと。

12. 手順7で外したビス (6) 1本でカバー (7) を元通り取り付け。



Adjusting the height

13. Turn four adjusters (13) until they reach the floor and then adjust them so that the machine becomes level.



Attaching the stays (For 110V, 120 V, and 220-240 V specifications)

14. Attach two stays (F) at the rear side of the paper feeder using an M4 × 20 screw (G) for each. Also, attach two stays (F) at the left side using an M4 × 10 screw (H) for each.

Do not attach the stays (F) at the left side when installing the document finisher.

Réglage de la hauteur

13. Tourner les quatre pieds réglables (13) jusqu'à ce qu'ils atteignent le sol, puis les ajuster de manière que la machine soit bien horizontale.

Fixation des supports (pour spécifications 110 V, 120 V, et 220-240 V)

14. Fixer deux supports (F) sur le côté arrière du bureau papier à l'aide d'une vis M4 × 20 (G) pour chaque support.

Fixer aussi deux supports (F) sur le côté gauche à l'aide d'une vis M4 × 10 (H) pour chaque support.

Ne pas fixer les supports (F) sur le côté gauche lors de l'installation du retoucheur de document.

Ajuste de la altura

13. Gire los cuatro ajustadores (13) hasta que lleguen al piso y ajústelos hasta que la máquina quede horizontal.

Colocación de las bases (especificaciones de 110V, 120V y 220-240V)

14. Coloque las dos bases (F) en el lado trasero del alimentador de papel utilizando un tornillo M4 × 20 (G) para cada uno.

Además, coloque dos bases (F) en el lado izquierdo utilizando un tornillo M4 × 10 (H) para cada uno.

No instale las bases (F) en el lado izquierdo cuando instale el finalizador de documentos.

Einstellen der Höhe

13. Die vier Einstellfüße (13) drehen, bis sie den Boden erreichen, und dann so einstellen, dass die Maschine waagrecht steht.

Anbringen der Stützen (Für 110-V-, 120-V- und 220-240-V-Spezifikationen)

14. Die zwei Stützen (F) mit je einer M4 × 20 Schraube (G) auf der Rückseite des Papiereinzugs befestigen.

Außerdem zwei Stützen (F) mit je einer M4 × 10 Schraube (H) auf der linken Seite befestigen.

Bei Installation des Dokumentenfinishers die Stützen (F) nicht auf der linken Seite anbringen.

Regolazione dell'altezza

13. Ruotare i quattro piedini regolabili (13) sino a quando vengono a contatto con il pavimento e poi regolarli in modo da livellare la macchina.

Inserimento delle sospensioni (specifiche solo per 110 V, 120 V e 220-240 V)

14. Inserire le due sospensioni (F) nel retro dell'unità di alimentazione della carta utilizzando una vite M4 × 20 (G) per ciascuna.

Inserire, inoltre, due sospensioni (F) nel lato sinistro utilizzando una vite M4 × 10 (H) per ciascuna.

Non inserire le sospensioni (F) nel lato sinistro quando si installa la finitrice di documenti.

調整高度

13. 旋转4个角落的高度调节器(13)直至碰到地板,以调整整个机器的水平。

防倒金属件的安装(仅适用于110V、120V、220-240V)

14. 在供纸盒的后侧2处各用1个螺丝M4 × 20(G)安装防倒金属件(F)。在供纸盒的左侧2处各用1个螺丝M4 × 10(H)安装防倒金属件(F)。

若安装装订器时,则不需要在供纸盒左侧安装防倒金属件(F)。

TONER

高さ調整

www.tonerplus.com.ua

13. 4隅のアジャスター(13)を床に接触するまで回転し、機械全体を水平に調整する。

転倒防止金具の取り付け(110V・120V・220-240V仕様のみ)

14. ビスM4 × 20(G)各1本で転倒防止金具(F)をペーパーフィーダ後側2箇所に取り付ける。ビスM4 × 10(H)各1本で転倒防止金具(F)をペーパーフィーダ左側2箇所に取り付ける。

ドキュメントフィニッシャーを設置する場合は、ペーパーフィーダ左側に転倒防止金具(F)の取り付けは必要ない。

Checking the center line

15. Connect the power plug of the machine to the wall outlet and turn the main power switch on.
16. Load paper in each cassette.

Make a proof copy to check the operation.

17. Enter the maintenance mode and run maintenance item U993.

18. Select [PG1] to print a test pattern.

Vérification de la ligne médiane

15. Insérer la fiche d'alimentation de la machine dans la prise murale et mettre la machine sous tension.

16. Mettre du papier dans chaque tiroir.

Effectuer une copie d'essai pour vérifier le fonctionnement.

17. Passer en mode de maintenance et exécuter le point de maintenance U993.

18. Sélectionner [PG1] pour imprimer une mire.

Verificación de la línea central

15. Conecte el enchufe eléctrico de la máquina en un tomacorriente de la pared y conecte el interruptor principal.

16. Coloque el papel en cada bandeja.

Haga una copia de prueba para verificar e funcionamiento.

17. Ingrese en el modo de mantenimiento y utilice el elemento de mantenimiento U993.

18. Seleccione (PG1) para imprimirán patrón de prueba.

Überprüfen der Mittellinie

15. Den Netzstecker der Maschine in die Steckdose stecken, und den Betriebsschalter einschalten.

16. Papier in jede Kassette einlegen.

Eine Probekopie anfertigen, um den Betrieb zu überprüfen.

17. Den Wartungsmodus aktivieren, und den Wartungsposten U993 ausführen.

18. [PG1] zum Drucken eines Testmusters wählen.

Controllare la linea centrale

15. Collegare la spina del cavo di alimentazione della macchina alla presa a muro della rete elettrica e accendere l'interruttore principale di alimentazione.

16. Caricare la carta in ciascun cassetto.

Eseguire una copia di prova per controllare il funzionamento.

17. Entrare in modalità manutenzione ed eseguire la voce manutenzione U993.

18. Selezionare [PG1] per stampare un modello di prova.

中心线的确认

15. 将机器主机上的电源插头插入插座中，打开主电源开关。

16. 将复印纸装入供纸盒。

进行测试复印，确认复印动作状态。

17. 选定维修模式 U993。

18. 选择“PG1”测试图案的输出。

センターラインの確認


15. 機械本体の電源プラグをコンセントに差し込み、主電源スイッチを ON にする。

16. 各カセットに用紙をセットする。


テストコピーをおこない、動作を確認する。

17. メンテナンスモード U993 をセットする。

18. 「PG1」を選択し、テストパターンを出力する。



19. Check the center line of paper (14) and the center line of test pattern (15).
If the gap of lines (14) and (15) exceeds the reference value, proceed to step 20.
Reference value: 2.0 mm or less



- Adjusting the center line**
20. Pull the cassette out and loosen the screw (16) of the adjusting plate.

19. Vérifier la ligne médiane du papier (14) et la ligne médiane de la mire (15).
Si l'écart des lignes (14) et (15) est supérieur à la valeur de référence, passer à l'étape 20.
Valeur de référence: 2,0 mm ou moins

- Réglage de la ligne médiane**
20. Tirer le tiroir vers l'extérieur et desserrer la vis (16) de la plaque de réglage.

19. Verifique la línea central del papel (14) y la línea central del patrón de prueba (15).
Si la separación entre las líneas (14) y (15) supera el valor de referencia, vaya al paso 20.
Valor de referencia: 2,0 mm o menos

- Ajuste de la línea central**
20. Abra la bandeja y afloje el tornillo (16) de la placa de ajuste.

19. Die Mittellinie des Papiers (14) mit der Mittellinie des Testmusters (15) vergleichen.
Falls die Abweichung zwischen den Linien (14) und (15) den Bezugswert überschreitet, zu Schritt 20 übergehen.
Bezugswert: maximal 2,0 mm

- Einstellen der Mittellinie**
20. Die Kassette herausziehen, und die Schraube (16) der Einstellplatte lösen.

19. Controllare la linea centrale della carta (14) e la linea centrale del modello di prova (15).
Se la distanza tra le linee (14) e (15) supera il valore di riferimento, continuare con il passo 20.
Valore di riferimento: fino a 2,0 mm


- Regolazione della linea centrale**
20. Estrarre il cassetto e allentare la vite (16) della piastra di regolazione.

19. 确认复印纸的中心线 (14) 与测试图案的中心线 (15)。
超过偏移标准值时, 操作步骤 20 以后的项目。
< 标准值 > 2.0mm 以下

- 中心线的调整**
20. 拉出供纸盒, 松开调整板的 1 个螺丝 (16)。

19. 用紙のセンターライン (14) とテストパターン of センターライン (15) を確認する。
ずれが基準値外の場合は、手順 20 以降をおこなう。
< 基準値 > 2.0mm 以下

- センターライン調整**
20. カセットを引き出し、調整板のビス (16) 1 本を緩める。



21. For a test pattern example (a):

Turn the adjusting screw (17) clockwise, move the adjusting plate in the direction of black arrow (➡) and then tighten the screw (16).

For a test pattern example (b):

Turn the adjusting screw (17) counterclockwise, move the adjusting plate in the direction of white arrow (➡) and then tighten the screw (16).

22. Gently close the cassette.

23. Print a test pattern again.

24. Repeat steps 20 to 23 until the gap of the center lines of paper and the test pattern shows the following reference value.
Reference value: 2.0 mm or less

21. Pour un exemple de mire (a):

Tourner la vis de réglage (17) dans le sens des aiguilles d'une montre, déplacer la plaque de réglage dans le sens de la flèche noire (➡), puis serrer la vis (16).

Pour un exemple de mire (b):

Tourner la vis de réglage (17) dans le sens inverse des aiguilles d'une montre, déplacer la plaque de réglage dans le sens de la flèche blanche (➡), puis serrer la vis (16).

22. Refermer progressivement le tiroir.

23. Imprimer à nouveau une mire.

24. Répéter les étapes 20 à 23 jusqu'à ce que l'écart entre les lignes médianes du papier et la mire corresponde bien à la valeur de référence suivante.

Valeur de référence: 2,0 mm ou moins

21. Para un ejemplo de patrón de prueba (a):

Gire el tornillo de ajuste (17) en sentido horario, mueva la placa de ajuste en el sentido de la flecha negra (➡) y apriete el tornillo (16).

Para un ejemplo de patrón de prueba (b):

Gire el tornillo de ajuste (17) en sentido antihorario, mueva la placa de ajuste en el sentido de la flecha blanca (➡) y apriete el tornillo (16).

22. Cierre suavemente la bandeja.

23. Vuelva a imprimir un patrón de prueba.

24. Repita los pasos 20 a 23 hasta que la separación entre las líneas del papel y del patrón de prueba muestre el siguiente valor de referencia.

Valor de referencia: 2,0 mm o menos

21. Für das Testmuster-Beispiel (a):

Die Einstellschraube (17) im Uhrzeigersinn drehen, die Einstellplatte in Richtung des schwarzen Pfeils (➡) verschieben, und dann die Schraube (16) festziehen.

Für das Testmuster-Beispiel (b):

Die Einstellschraube (17) entgegen dem Uhrzeigersinn drehen, die Einstellplatte in Richtung des weißen Pfeils (➡) verschieben, und dann die Schraube (16) festziehen.

22. Die Kassette sanfte schließen.

23. Das Testmuster erneut drucken.

24. Die Schritte 20 bis 23 wiederholen, bis die Abweichung zwischen den Mittellinien des Papiers und des Testmusters innerhalb des folgenden Bezugswerts liegt.

Bezugswert: maximal 2,0 mm

21. Per un esempio di un modello di prova (a):

Girare la vite di regolazione (17) in senso orario, spostare la piastra di regolazione nella direzione della freccia nera (➡) e poi serrare la vite (16).

Per un esempio di un modello di prova (b):

Girare la vite di regolazione (17) in senso antiorario, spostare la piastra di regolazione nella direzione della freccia bianca (➡) e poi serrare la vite (16).

22. Chiudere delicatamente il cassetto.

23. Stampare nuovamente un modello di prova.

24. Ripetere i passi da 20 a 23 fino a quando la distanza tra le linee centrali della carta e del modello di prova indica il seguente valore di riferimento.

Valore di riferimento: fino 2,0 mm

21. 测试图案 (a) 时

向右旋转调整螺丝 (17), 按箭头方向 (➡) 移动调整板, 并紧固 1 个螺丝 (16)。

测试图案 (b) 时

向左旋转调整螺丝 (17), 按箭头方向 (➡) 移动调整板, 并紧固 1 个螺丝 (16)。

22. 轻轻地推入供纸盒。

23. 再次进行测试图案的输出。

24. 重复操作步骤 20 ~ 23, 直到复印纸的中心线与测试图案的中心线为标准值内为止。

< 标准值 > 2.0mm 以下

21. テストパターン (a) の場合

調整ネジ (17) を右に回し、矢印 (➡) 方向に調整板を動かしてビス (16) 1 本を締め付ける。

テストパターン (b) の場合

調整ネジ (17) を左に回し、矢印 (➡) 方向に調整板を動かしてビス (16) 1 本を締め付ける。

22. カセットを静かに押し込む。


23. テストパターンを再度出力する。

24. 用紙のセンターラインとテストパターンのセンターラインが基準値内になるまで、手順 20 ~ 23 を繰り返す。

< 基準値 > 2.0mm 以下

INSTALLATION GUIDE FOR DOCUMENT FINISHER

Output Connector for Interconnecting Cable is non-LPS.
Output: 24 V dc (426 VA max.)
Please use the item below Interconnecting Cables.
P/N: 305H180180



English

Supplied parts

| | |
|---------------------------|---|
| A Document finisher | 1 |
| B Latch catch | 1 |
| C Rail retainer | 1 |
| D Guide rail | 1 |

| | |
|---|---|
| E Binding screw M4 × 6 | 4 |
| F Binding screw M4 × 10 | 4 |
| G Clamp (Not used for full-color machines) | 1 |
| K Curl eliminator | 1 |
| For monochrome MFP's: AK-700 | |
| For monochrome printers: AK-705 | |

For full-color machines, two pieces of (F) are not used.

For monochrome machines, part (K) is needed separately.

For full-color machines, part (K) is not needed.

Français

Pièces fournies

| | |
|--------------------------------------|---|
| A Retoucheur de document | 1 |
| B Pontet du loquet | 1 |
| C Élément de rétention du rail | 1 |
| D Glissière | 1 |

| | |
|--|---|
| E Vis de raccordement M4 × 6 | 4 |
| F Vis de raccordement M4 × 10 | 4 |
| G Bride (Non utilisé pour les machines entièrement en couleurs) | 1 |
| K Élément d'élimination des boucles | 1 |
| Pour les MFP monochromes: AK-700 | |
| Pour les imprimantes monochromes: AK-705 | |

Sur les machines entièrement en couleurs, deux pièces de (F) ne sont pas utilisées.

Sur les machines monochromes, il faut utiliser la pièce (K) séparément.

Pour les machines entièrement en couleurs, la pièce (K) n'est pas nécessaire.

Español

Partes suministradas

| | |
|-----------------------------------|---|
| A Finalizador de documentos | 1 |
| B Cerrojo | 1 |
| C Retén del carril | 1 |
| D Carril guía | 1 |

| | |
|---|---|
| E Tornillo de sujeción M4 × 6 | 4 |
| F Tornillo de sujeción M4 × 10 | 4 |
| G Abrazadera (No utilizado para máquinas a todo color) | 1 |
| K Eliminador de enrollado | 1 |
| Para las MFP monocromáticas: AK-700 | |
| Para las impresoras monocromáticas: AK-705 | |

Para las máquinas a todo color, no se utilizan dos piezas de (F).

Para las máquinas monocromáticas, es necesario por separado la pieza (K).

Para las máquinas a todo color, la pieza (K) no es necesaria.

Deutsch

Gelieferte Teile

| | |
|-----------------------------------|---|
| A Dokument Finishers | 1 |
| B Riegelschloßbausatz | 1 |
| C Schienenhalterungseinheit | 1 |
| D Führungsschieneneneinheit | 1 |

| | |
|---|---|
| E Verbundschraube M4 × 6 | 4 |
| F Verbundschraube M4 × 10 | 4 |
| G Klemme (Nicht für Vollfarbenmaschinen verwendet) | 1 |
| K Glättungseinrichtung | 1 |
| Für monochrome MFP: AK-700 | |
| Für Monochromedruker: AK-705 | |

Für Vollfarbenmaschinen werden zwei Teile von (F) nicht benutzt.

Für Monochrommaschinen wird Teil (K) getrennt benötigt.

Für Vollfarbenmaschinen wird Teil (K) nicht benötigt.

Italiano

Parti fornite

| | |
|--------------------------------|---|
| A Finitrice di documenti | 1 |
| B Dispositivo di arresto | 1 |
| C Fermo della guida | 1 |
| D Guida della rotaia | 1 |

| | |
|---|---|
| E Vite di serraggio M4 × 6 | 4 |
| F Vite di serraggio M4 × 10 | 4 |
| G Morsetto (Non utilizzato per le macchine a colori) | 1 |
| K Eliminatore di pieghe | 1 |
| Per gli MFP in bianco e nero: AK-700 | |
| Per gli stampatori in bianco e nero: AK-705 | |

Per le macchine a colori, due pezzi di (F) non sono utilizzati.

Per le macchine in bianco e nero, separatamente è necessaria la parte (K).

Per le macchine a colori, la parte (K) non è necessaria.

简体中文

附属品

| | |
|----------------|---|
| (A)装订器 | 1 |
| (B)挂钩承支架 | 1 |
| (C)轨道座 | 1 |
| (D)导向轨道 | 1 |

| | |
|--------------------------|---|
| (E) M4 × 6 固结螺钉 | 4 |
| (F) M4 × 10 固结螺钉 | 4 |
| (G) 夹紧件 (全彩色机上不使用) | 1 |
| (K) 防卷曲部件 | 1 |
| 黑白MFP: AK-700 | |
| 黑白打印机: AK-705 | |

全彩色机时(F)剩下2个连接螺钉。
黑白机时另外需要安装(K)部件。
全彩色机时, 不需要安装(K)部件。


日本語

付属品

| | |
|-----------------------|---|
| A ドキュメントフィニッシャー | 1 |
| B ラッチ受け板 | 1 |
| C レール取付板 | 1 |
| D ガイドレール | 1 |

| | |
|----------------------------------|---|
| E ビス M4 × 6 バインド | 4 |
| F ビス M4 × 10 バインド | 4 |
| G クランプ (フルカラー機では使用しません) | 1 |
| K デカーラー | 1 |
| モノクロ MFP 用: AK-700 | |
| モノクロプリンタ用: AK-705 | |

フルカラー機では、(F) が 2 本余ります。
モノクロ機では、(K) が別途必要です。
フルカラー機では、(K) は不要です。



| | | |
|---|----------------------|---|
| H | Fixing plate F | 1 |
| I | Fixing plate R | 1 |
| J | S Tite screw M4 × 10 | 9 |
| N | Cover AT | 1 |
| M | Shoulder screw | 1 |
| L | Guide plate | 1 |

When installing the document finisher to a full-color MFP, use parts (H), (I), (J), (L), (M) and (N) supplied with the job separator.

| | | |
|---|----------------------------|---|
| H | Plaque de fixation avant | 1 |
| I | Plaque de fixation arrière | 1 |
| J | Vis S Tite M4 × 10 | 9 |
| N | Couvercle AT | 1 |
| M | Vis d'épaule | 1 |
| L | Plaque guide | 1 |

Lors de l'installation du retoucheur de documents sur une MFP polychrome, les pièces (H), (I), (J), (L), (M) et (N) avec le séparateur de travaux sont requises.

| | | |
|---|-------------------------|---|
| H | Placa de fijación F | 1 |
| I | Placa de fijación R | 1 |
| J | Tornillo S Tite M4 × 10 | 9 |
| N | Cubierta AT | 1 |
| M | Tornillo de hombro | 1 |
| L | Placa guía | 1 |

Cuando instale el finalizador de documentos en una MFP a todo color serán necesarias las partes (H), (I), (J), (L), (M), y (N) suministradas con el separador de tareas.

| | | |
|---|-------------------------|---|
| H | Fixierplatte F | 1 |
| I | Fixierplatte R | 1 |
| J | S-Tite-Schraube M4 × 10 | 9 |
| N | Abdeckung AT | 1 |
| M | Bundschraube | 1 |
| L | Führungsplatte | 1 |

Wenn der Dokument-Finisher auf einem Farbmultifunktionsgerät angebracht wird, sind die Teile (H), (I), (J), (L), (M) und (N), die mit dem Jobtrenner geliefert werden erforderlich.

| | | |
|---|------------------------|---|
| H | Piastra di fissaggio F | 1 |
| I | Piastra di fissaggio R | 1 |
| J | Vite S Tite M4 × 10 | 9 |
| N | Coperchio AT | 1 |
| M | Vite a colletto | 1 |
| L | Piastra della guida | 1 |



Per l'installazione della finitrice di documenti su un MFP a colori, sono necessarie le parti (H), (I), (J), (L), (M) e (N) fornite in dotazione con il separatore dei lavori.

| | | |
|-----|---------------|---|
| (H) | 固定板 F | 1 |
| (I) | 固定板 R | 1 |
| (J) | 紧固螺钉 M4 × 10S | 9 |
| (N) | 盖板 AT | 1 |
| (M) | 阶梯螺钉 | 1 |
| (L) | 导向板 | 1 |

全彩色 MFP 上安装装订器时，请使用作业分离器上附属的部件 (H)、(I)、(J)、(L)、(M) 和 (N)。

| | | |
|---|-----------------|---|
| H | 固定板 F | 1 |
| I | 固定板 R | 1 |
| J | ビス M4 × 10S タイト | 9 |
| N | カバー AT | 1 |
| M | 段付きビス | 1 |
| L | ガイド板 | 1 |

フルカラーMFP 機にドキュメントフィニッシャを設置する場合、ジョブセパレータに付属する (H)、(I)、(J)、(L)、(M)、(N) が必要となる。



Installation Procedure

When installing the document finisher to a full-color MFP, install the job separator in advance. Be sure to turn the main switch of the MFP or the printer off and disconnect the power plug of the MFP or the printer from the wall outlet before installing the document finisher.

[Steps 1 to 5 below are only for full-color machines.]

1. Place the document finisher (A) sideways, remove the eight screws (1), and remove the two pieces of fittings (2).

2. To align the document finisher with the paper outlet of the MFP or the printer, slide the legs of the document finisher (A) to the uppermost positions indicated in the illustration, attach the two pieces of fittings (2) that have been removed in step 1, and secure them using the eight screws (1).

Procédure d'installation

Installer le séparateur de travaux, puis installer le retoucheur de documents sur la MFP polychrome. Veiller à bien mettre l'interrupteur principal de la MFP ou de l'imprimante hors tension et à débrancher la fiche d'alimentation de la MFP ou de l'imprimante de la prise murale avant de commencer l'installation du retoucheur de documents.

[Les étapes 1 à 5 ci-dessous concernent les machines entièrement en couleurs seulement.]

1. Placer le retoucheur de documents (A) sur le côté, retirer les huit vis (1), et retirer les deux pièces de fixation (2).

2. Pour aligner le retoucheur de document sur la sortie de papier du MFP ou imprimante, faire glisser les pieds du retoucheur de document (A) jusqu'aux positions les plus hautes indiquées sur l'illustration, fixer les deux pièces de fixation (2) qui avaient été retirées auparavant à l'étape 1, et les fixer à l'aide des huit vis (1).

Procedimiento de instalación

Instale el separador de tareas y luego instale el finalizador de documentos en la MFP a todo color. Asegúrese de apagar el interruptor principal de la MFP o de la impresora y de desconectar la clavija de alimentación de la MFP o de la impresora de la toma de corriente de la pared, antes de empezar a instalar el finalizador de documentos.

[Los pasos 1 a 5 a continuación son solo para máquinas a todo color.]

1. Apoye el finalizador de documentos (A) sobre un lado, saque los ocho tornillos (1) y saque dos piezas de herrajes (2).

2. Para alinear el finalizador de documentos con la salida de papel del MFP o impresora, deslice las patas del finalizador de documentos (A) a las posiciones superiores indicadas en la figura, instale las dos piezas de herrajes (2) desmontadas en el paso 1 y asegúrelos con los ocho tornillos (1).

Einbauverfahren

Bauen Sie zuerst den Jobtrenner und dann den Dokument-Finisher in den Farbmultifunktionsgerät ein. Schalten Sie den MFP-Hauptschalter oder den Drucker-Hauptschalter aus, und ziehen Sie den MFP-Netzstecker oder den Drucker-Netzstecker von der Netzsteckdose ab, bevor Sie mit der Installation des Dokument Finishers beginnen.

[Die folgenden Schritte 1 bis 5 gelten nur für Vollfarbmaschinen.]

1. Den Dokument Finisher (A) auf die Seite legen, die acht Schrauben (1) entfernen, und die zwei Befestigungsteile (2) abnehmen.

2. Um den Dokument Finisher auf den Papierausslass des MFP oder Drucker auszurichten, die Beine des Dokument Finishers (A) auf die in der Abbildung gezeigte oberste Position schieben, dann die zwei in Schritt 1 entfernten Befestigungsteile (2) anbringen und mit den acht Schrauben (1) befestigen.

Procedura di installazione

Installare il separatore dei lavori e poi procedere all'installazione della finitrice di documenti sul MFP a colori. Prima di dare inizio alla procedura di installazione della finitrice di documenti, non mancare di spegnere l'MFP o lo stampatore usando l'interruttore principale di alimentazione e disinserire la spina dell'MFP o dello stampatore dalla presa a muro della rete elettrica.

[I seguenti passi da 1 a 5 sono solo per le macchine a colori.]

1. Collocare la finitrice di documenti (A) lateralmente, rimuovere le otto viti (1) e rimuovere i due pezzi di raccordo (2).

2. Per allineare la finitrice di documenti con l'uscita della carta dell'MFP o stampatore, fare scivolare i piedini della finitrice di documenti (A) sulle posizioni più in alto indicate nel disegno, montare i due pezzi di raccordo (2) che sono stati rimossi nel passo 1 e fissarli utilizzando le otto viti (1).

安装步骤

将装订器安装到全彩色MFP时，请提前安装作业分离器。请务必关闭MFP或打印机的主开关并从墙壁插座拔下MFP或打印机的电源插头再安装装订器。

[步骤1~5仅限于全彩色机]

1. 将装订器(A)横向放置，卸下8个螺钉(1)，然后，取下2个固定件(2)。

2. 为了对准主机排纸口，先将装订器(A)的机脚滑动到最上面的位置(如图所示的位置)，然后，安装在步骤1取下的2个固定件(2)，并用8个螺钉(1)加以固定。

設置手順


www.tonerplus.com.ua

フルカラーMFP機にドキュメントフィニッシャーを取り付ける際には、先にジョブセパレータを装着すること。
ドキュメントフィニッシャーを取り付ける際は、必ずMFP本体またはプリンタ本体のメインスイッチをOFFにし、電源プラグを外して作業をおこなうこと。


[手順1～5はフルカラー機のみ]

1. ドキュメントフィニッシャー(A)を横向きにおき、ビス(1)8本を外し、固定金具(2)2個を取り外す。


2. 本体用紙排出口に合わせる為、ドキュメントフィニッシャー(A)の脚を最上の位置(図の位置)までスライドさせ、手順1で取り外した固定金具(2)2個を取り付け、ビス(1)8本で固定する。



3. Secure the guide plate (L) using the shoulder screw (M) and an S Tite screw M4 × 10 (J).



4. Fit the fixing plate F (H) and the fixing plate R (I) to the left cover (3) using two S Tite screws M4 × 10 (J) for each and fit the cover AT (N) to the fixing plate F (H) using two S Tite screws M4 × 10 (J).



5. Fit the latch catch (B) to the fixing plate F (H) and the fixing plate R (I) using two S Tite screws M4 × 10 (J). (Proceed to step 7.)

3. Fixez la plaque guide (L) à l'aide de la vis d'épaule (M) et d'une vis S Tite M4 × 10 (J).

4. Fixer la plaque de fixation avant (H) et la plaque de fixation arrière (I) sur le couvercle de gauche (3) à l'aide de deux vis S Tite M4 × 10 (J) chaque et fixer le couvercle AT (N) sur la plaque de fixation avant (H) à l'aide de deux vis S Tite M4 × 10 (J).

5. Fixer le pontet du loquet (B) sur la plaque de fixation avant (H) et sur la plaque de fixation arrière (I) à l'aide de deux vis S Tite M4 × 10 (J). (Passer à l'étape 7.)

3. Asegure la placa guía (L) utilizando el tornillo de hombro (M) y un tornillo S Tite M4 × 10(J).

4. Encaje la placa de fijación F (H) y la placa de fijación R (I) en la cubierta izquierda (3) utilizando dos tornillos S Tite M4 × 10 (J) para cada una y encaje la cubierta AT (N) en la placa de fijación F (H) utilizando dos tornillos S Tite M4 × 10 (J).

5. Encaje el cerrojo (B) en la placa de fijación F (H) y la placa de fijación R (I) utilizando los dos tornillos S Tite M4 × 10 (J). (Vaya al paso 7.)

3. Die Führungsplatte (L) mit der Bundschraube (M) und einer S-Tite-Schraube M4 × 10 (J) befestigen.

4. Die Fixierplatte F (H) und die Fixierplatte R (I) mit je zwei S-Tite-Schrauben M4 × 10 (J) an der linken Abdeckung (3) anbringen, und die Abdeckung AT (N) mit zwei S-Tite-Schrauben M4 × 10 (J) an der Fixierplatte F (H) anbringen.

5. Die Riegelschloßbausatz (B) mit zwei S-Tite-Schrauben M4 × 10 (J) an der Fixierplatte F (H) und die Fixierplatte R (I) anbringen. (Zu Schritt 7 übergehen.)

3. Fissare la piastra della guida (L) utilizzando la vite a colletto (M) e la vite S Tite M4 × 10 (J).

4. Montare la piastra di fissaggio F (H) e la piastra di fissaggio R (I) sul coperchio sinistro (3) usando due vite S Tite M4 × 10 (J) per ciascuna di esse e montare il coperchio AT (N) sulla piastra di fissaggio F (H) usando due vite S Tite M4 × 10 (J).

5. Montare il dispositivo di arresto (B) sulla piastra di fissaggio F (H) e sulla piastra di fissaggio R (I) usando due vite S Tite M4 × 10 (J). (Procedere con il passo 7.)

3. 在用阶梯螺钉(M)和紧固螺钉M4×10S(J)各1个固定导板(L)。


4. 将固定板F(H)和固定板R(I)分别用2个紧固螺丝M4×10S(J)固定在左盖板(3)上, 将盖板AT(N)用2个紧固螺丝M4×10S(J)固定在固定板F(H)上。

5. 挂钩承支架(B)用2个紧固螺丝M4×10S(J)固定在固定板F(H)和固定板R(I)上。(接着操作步骤7)

3. ガイド板 (L) を段付きビス (M) とビス M4 × 10S タイプ (J) 各 1 本で固定する。


4. 固定板 F(H) と固定板 R(I) を左カバー (3) にビス M4 × 10S タイプ (J) 各 2 本で固定し、カバーAT(N) をビス M4 × 10S タイプ (J) 2 本で固定板 F(H) に固定する。

5. ラッチ受け板 (B) をビス M4 × 10S タイプ (J) 2 本で固定板 F(H) と固定板 R(I) に固定する。(手順 7 に進む)




[Steps 1 to 6 below are only for monochrome machines.]

1. Open the eject cover (1) of the MFP or the printer.
2. Remove the two screws (2) securing the feedshift guide assembly (3) and then the assembly.



3. Fit the curl eliminator (K) to the eject cover (1) such that the projections (4) on the cover fit into the two ends of the curl eliminator (K).
4. Secure the curl eliminator (K) using the two screws (2) removed in step 2.



5. Close the eject cover (1).
6. Fit the latch catch (B) to the eject cover (1) using two M4 x 10 binding screws (F).

[Les étapes 1 à 6 ci-dessous concernent les machines monochromes seulement.]

1. Ouvrir le couvercle d'éjection (1) du MFP ou imprimante.
2. Retirer les deux vis (2) fixant l'assemblage de la glissière d'alimentation (3) puis retirer l'assemblage.

3. Fixer l'élément d'élimination des boucles (K) au couvercle d'éjection (1) de telle façon que les projections (4) du couvercle s'insèrent dans les deux extrémités de cet élément (K).
4. Fixer l'élément d'élimination des boucles (K) à l'aide des deux vis (2) retirées à l'étape 2.

5. Fermer le couvercle d'éjection (1).
6. Fixer le pontet du loquet (B) au couvercle d'éjection (1) à l'aide de deux vis de raccordement M4 x 10 (F).

[Los pasos 1 a 6 a continuación son sólo para máquinas monocromáticas.]

1. Abra la cubierta de expulsión (1) del MFP o impresora.
2. Quite los dos tornillos (2) que aseguran el ensamble guía de la unidad de cambio de alimentación de papel (3) y luego el ensamble.

3. Coloque el eliminador de enrollamiento (K) en la cubierta de expulsión (1) de modo que las proyecciones (4) de la cubierta encajen en los dos extremos del eliminador de enrollamiento (K).
4. Asegure el eliminador de enrollamiento (K) usando los dos tornillos (2) que quitó en el paso 2.

5. Cierre la cubierta de expulsión (1).
6. Coloque el cerrojo (B) en la cubierta de expulsión (1) usando dos tornillos de sujeción M4 x 10 (F).

[Die folgenden Schritte 1 bis 6 gelten nur für Monochrommaschinen.]

1. Öffnen Sie die Auswurfabdeckung (1) des MFP oder Drucker.
2. Entfernen Sie die zwei Schrauben (2), die den Zuführungswechsel-Bausatz (3) befestigen und dann den Bausatz.

3. Bringen Sie den Wellenverhinderer (K) so an die Auswurfabdeckung (1) an, daß die Vorsprünge (4) auf der Abdeckung in die zwei Enden des Wellenverhinderers (K) passen.
4. Befestigen Sie den Wellenverhinderer (K) mittels der in Schritt 2 entfernten zwei Schrauben (2).

5. Schliessen Sie die Auswurfabdeckung (1).
6. Bringen Sie den Riegelschloßbausatz (B) mittels der zwei M4 x 10 Verbundschrauben (F) an die Auswurfabdeckung (1) an.

[I seguenti passi da 1 a 6 sono solo per le macchine in bianco e nero.]

1. Aprire la copertura dell'uscita carta (1) dell'MFP o stampatore.
2. Rimuovere le due viti (2) che fissano il gruppo di guida di cambio alimentazione (3) e quindi il gruppo.

3. Inserire l'eliminatore degli accartocciamenti (K) nella copertura dell'uscita carta (1) in modo tale che le proiezioni (4) sulla copertura siano inserite nelle due estremità dell'eliminatore degli accartocciamenti (K).
4. Fissare l'eliminatore degli accartocciamenti (K) utilizzando le due viti (2) rimosse al punto 2.

5. Chiudere la copertura dell'uscita carta (1).
6. Inserire il dispositivo di arresto (B) nella copertura dell'uscita carta (1) utilizzando due viti di serraggio M4 x 10 (F).

[步骤1~6仅限于黑白机]

1. 将MFP或打印机的出纸盖板(1)打开。
2. 将两个小螺钉(2)摘下,并将分支导向组件(3)卸下。

3. 将带凸肩压板的凸部(4)嵌入防卷曲部件(K)两端后,将防卷曲部件(K)安装于出纸盖板(1)上。
4. 用依步骤2摘下的两个小螺钉(2)来固定防卷曲部件(K)。


5. 将出纸盖板(1)关上。
6. 用两个M4 x 10固结螺钉(F)将挂钩承支架(B)安装于出纸盖板(1)上。

[手順1~6はモノクロ機のみ]


1. MFP本体またはプリンタ本体の排出カバー(1)を開く。
2. ビス(2)2本を外し、分岐ガイド組立(3)を取り外す。

3. デカーラー(K)の両端に半押し(4)がはまる位置で、デカーラー(K)を排出カバー(1)に取り付ける。
4. 手順2で外したビス(2)2本でデカーラー(K)を固定する。


5. 排出カバー(1)を閉じる。
6. ラッチ受け板(B)をビス M4 x 10 バインド(F)2本で排出カバー(1)に取り付ける。



7. Align the rail retainer (C) with the groove of the guide rail (D) and attach the rail retainer (C) to the guide rail (D). Make sure that the plate spring (4) of the rail retainer (C) fits into the groove and the edge of the guide rail (D) fits between the pulleys on the reverse side of the rail retainer (C).



8. Orient the guide rail (D) such that its pulley (5) is positioned toward the MFP or the printer.



9. Secure the rail retainer (C) to the MFP or the printer using two M4 x 10 binding screws (F) such that the front and the rear gaps between the floor and the rail retainer (C) are approximately 8.0 mm.

7. Aligner l'élément de rétention du rail (C) sur le sillon de la glissière (D) et le fixer à l'élément de rétention du rail (C) à la glissière (D). Veiller à ce que le ressort de plaque (4) de l'élément de rétention du rail (C) s'adapte au sillon et que l'extrémité de la glissière (D) puisse passer entre les poulies sur le côté opposé de l'élément de rétention du rail (C).

8. Orienter la glissière (D) de manière que sa poulie (5) soit orientée vers le MFP ou imprimante.

9. Fixer l'élément de rétention du rail (C) au MFP ou imprimante à l'aide de deux vis de raccordement M4 x 10 (F) de manière que les écarts avant et arrière entre le sol et l'élément de rétention du rail (C) soient d'environ 8.0 mm.

7. Alinee el retén del carril (C) con la acanaladura del carril guía (D) y anexe el retén del carril (C) al carril guía (D). Asegúrese de que el resorte de la placa (4) del retén del carril (C) encaje en la acanaladura y que el borde del carril guía (D) encaje entre las poleas del lado inverso del retén del carril (C).

8. Oriente el carril guía (D) de modo que su polea (5) se encuentre ubicada hacia el MFP o impresora.

9. Asegure el retén del carril (C) a el MFP o impresora usando dos tornillos de sujeción M4 x 10 (F) de modo que los espacios frontal y trasero entre el piso y el retén del carril (C) sean de aproximadamente 8.0 mm.

7. Richten Sie die Schienenhalterungseinheit (C) mit der Rille der Führungsschiene (D) aus, und bringen Sie die Schienenhalterungseinheit (C) an die Führungsschiene (D) an. Stellen Sie sicher, daß die Tellerfeder (4) der Schienenhalterungseinheit (C) in die Rille paßt und die Kante der Führungsschiene (D) zwischen den Seilzügen auf der Rückseite der Schienenhalterungseinheit (C) sitzt.

8. Richten Sie die Führungsschiene (D) so aus, daß die Riemenscheibe (5) zum MFP oder Drucker ausgerichtet ist.

9. Bringen Sie die Schienenhalterung (C) am MFP oder Drucker mit zwei M4 x 10 Verbundschrauben (F) so an, daß die vorderen und hinteren Abstände zwischen Boden und Schienenhalterung (C) etwa 8.0 mm betragen.

7. Allineare il fermo della guida (C) con la scanalatura della guida della rotaia (D) e fissare il fermo della guida (C) alla guida della rotaia (D). Assicurarsi che la molla della piastra (4) del fermo della guida (C) sia collocata nella scanalatura e che il bordo della guida della rotaia (D) sia inserito tra le pulegge sul lato opposto del fermo della guida (C).

8. Orientare la guida della rotaia (D) in modo da posizionare la puleggia (5) in direzione dell'MFP o stampatore.

9. Assicurare il fermo della guida (C) all'MFP o stampatore utilizzando le due viti di serraggio M4 x 10 (F), in modo che la distanza anteriore e posteriore tra il pavimento ed il fermo della guida (C) sia di circa 8.0 mm.

7. 将轨道座 (C) 沿着导向轨道 (D) 的凹槽嵌入。此时, 应将片簧部 (4) 插入于凹槽中并将导向轨道 (D) 的一端插入于轨道座 (C) 背面的滚轮与滚轮之间。


8. 使导向轨道 (D) 的滚轮部 (5) 朝向 MFP 或打印机。

9. 用两个 M4 x 10 固结螺钉 (F) 将轨道座 (C) 固定于 MFP 或打印机上。此时, 轨道座 (C) 与地板之间的距离应约为 8.0 毫米。


7. レール取付板 (C) をガイドレール (D) の溝に合わせてはめ込む。板バネ部 (4) が溝の中に入り、レール取付板 (C) 裏側のコロとコロの間にガイドレール (D) の端が入るようにする。

8. ガイドレール (D) のコロ部 (5) を MFP 本体またはプリンタ本体側に向ける。

9. レール取付板 (C) と床面の前後隙間が約 8.0mm になるように、レール取付板 (C) を MFP 本体またはプリンタ本体にビス M4 x 10 バインド (F) 2 本で固定する。



10. Insert the guide rail (D) into the bottom of the document finisher (A).




Fitting and adjusting the guide rail

11. While pressing the guide rail (D) to the document finisher (A) so that the gap between the guide rail (D) and the floor is approximately 10 mm, secure it using two M4 × 6 binding screws (E).

Note

If the guide rail is not properly adjusted, the guide rail may not move when the document finisher is separated.



12. Separate the document finisher (A) from the MFP or the printer and secure it using two M4 × 6 binding screws (E) so that the gap between the guide rail (D) and the floor is approximately 10 mm.

10. Insérer la glissière (D) en bas du retoucheur de document (A).

Fixation et réglage de la glissière

11. Tout en pressant la glissière (D) contre le retoucheur de document (A) de façon que l'écart entre la glissière (D) et le sol soit d'environ 10 mm, la fixer à l'aide de deux vis de raccordement M4 × 6 (E).

Remarque

Si la glissière n'est pas réglée correctement, la glissière risquera de ne pas se déplacer lorsque le retoucheur de document sera séparé.

12. Séparer le retoucheur de document (A) du MFP ou imprimante, puis le fixer à l'aide de deux vis de raccordement M4 × 6 (E) de façon que l'écart entre la glissière (D) et le sol soit d'environ 10 mm.

10. Inserte el carril de guía (D) en la parte inferior del finalizador de documentos (A).

Fijación y ajuste del carril de guía

11. Mientras presiona el carril de guía (D) en el finalizador de documentos (A) para que la separación entre el carril de guía (D) y el piso sea de unos 10 mm, asegúrelo utilizando dos tornillos de fijación M4 × 6 (E).

Nota

Si el carril de guía no está bien ajustado, el carril de guía puede no moverse cuando se separa el finalizador de documentos.

12. Separe el finalizador de documentos (A) del MFP o impresora y asegúrelo utilizando dos tornillos de fijación M4 × 6 (E) para que la separación entre el carril de guía (D) y el piso sea de unos 10 mm.

10. Die Führungsschiene (D) in das Unterteil des Dokument Finishers (A) einschieben.

Anbringen und Einstellen der Führungsschieneinheit

11. Die Führungsschiene (D) gegen den Dokument Finisher (A) gedrückt halten, so dass der Abstand zwischen der Führungsschiene (D) und dem Boden ca. 10 mm beträgt, und mit zwei M4 × 6 Befestigungsschrauben (E) sichern.

Hinweis

Falls die Führungsschieneinheit nicht korrekt eingestellt ist, bewegt sie sich beim Trennen des Dokument Finishers eventuell nicht.

12. Den Dokument Finisher (A) vom MFP oder Drucker trennen und mit zwei M4 × 6 Befestigungsschrauben (E) sichern, so dass der Abstand zwischen der Führungsschiene (D) und dem Boden ca. 10 mm beträgt.

10. Inserire la guida della rotaia (D) nella parte inferiore della finitrice di documenti (A).

Montaggio e regolazione della guida della rotaia

11. Mentre si tiene premuta la guida della rotaia (D) alla finitrice di documenti (A) in modo che lo spazio tra la guida della rotaia (D) e il pavimento sia di circa 10 mm, fissarla a mezzo di due viti di serraggio M4 × 6 (E).

Nota

Se la guida della rotaia non è regolata correttamente, potrebbe non muoversi quando il separatore la finitrice di documenti verrà staccato.

12. Separare la finitrice di documenti (A) dall'MFP o stampatore per fissarla a mezzo di due viti di serraggio M4 × 6 (E) in modo che lo spazio tra la guida della rotaia (D) e il pavimento sia di circa 10 mm.

10. 将导向轨道(D)插入装订器(A)的底部。

导向轨道的安装调整

11. 调整导向轨道(D)与地板之间的间距为10毫米左右, 将导向轨道(D)插入装订器(A)到底, 用两个M4×6固结螺钉(E)进行固定。

注意

如果不能正确调整导向轨道的话, 在分离装订器时, 可能会发生导向轨道不能移动的情况。

12. 将装订器(A)分离MFP或打印机, 调整导向轨道(D)与地板之间的间距为10毫米左右后, 用两支M4×6固结螺钉(E)进行固定。

10. ドキュメントフィニッシャー(A)の底部にガイドレール(D)を挿入する。


ガイドレールの取付調整

11. ガイドレール(D)と床面の隙間が約10mmになるように、ガイドレール(D)をドキュメントフィニッシャー(A)に突き当てながら、ビスM4×6 バインド(E)2本で固定する。

注意

正しく調整しないと、ドキュメントフィニッシャーの切り離し時、ガイドレールが動かない恐れがある。

12. ドキュメントフィニッシャー(A)をMFP本体またはプリンタ本体より切り離し、ガイドレール(D)と床面の隙間が約10mmになるように、ビスM4×6 バインド(E)2本で固定する。



13. Loosen temporarily the two screws (7) that secure the sheet metal (6) of the rail mounting plate (C) on the MFP or the printer, raise the sheet metal (6) by two divisions of the scale from the guide rail (D), and tighten the two screws (7).

Note

If the guide rail is not properly adjusted, the guide rail may not move smoothly or the document finisher may fall down.

Slide the document finisher to engage it with the latch catch of the MFP or the printer. If the document finisher and the MFP or the printer do not engage securely, perform the following document finisher height adjustment.

13. Desserrer provisoirement les deux vis (7) qui fixent la feuille métallique (6) de la plaque de montage du rail (C) sur le MFP ou imprimante, élever la feuille métallique (6) de deux crans sur l'échelle de la glissière (D), puis resserrer les deux vis (7).

Remarque

Si la glissière n'est pas réglée correctement, la glissière risquera de ne pas se déplacer soûplement ou le retoucheur de document risquera de tomber.

Faire glisser le retoucheur de document pour l'engager dans le pontet du loquet du MFP ou imprimante. Si le retoucheur de document et le MFP ou imprimante ne s'engagent pas correctement, effectuer le réglage de hauteur suivant sur le retoucheur de document.

13. Afloje temporalmente los dos tornillos (7) que aseguran la hoja de metal (6) de la placa de montaje de carril (C) en el MFP o impresora, levante la hoja de metal (6) con dos divisiones de la escala del carril de guía (D) y apriete los dos tornillos (7).

Nota

Si no se ajusta correctamente el carril de guía, el carril de guía puede no moverse suavemente o el finalizador de documentos puede caer.

Deslice el finalizador de documentos hasta que enganche con el cerrojo del MFP o impresora. Si el finalizador de documentos y el MFP o impresora no se acoplan de manera segura, realice el siguiente ajuste de la altura del finalizador de documentos.

13. Die zwei Schrauben (7), die das Blech (6) der Schienenmontageplatte (C) am MFP oder Drucker sichern, vorübergehend lösen, das Blech (6) um zwei Teilstriche der Skala von der Führungsschiene (D) aus anheben, und die zwei Schrauben (7) wieder anziehen.

Hinweis

Falls die Führungsschieneinheit nicht korrekt eingestellt ist, bewegt sie sich eventuell nicht reibungslos, oder der Dokument Finisher kann herunterfallen.

Den Dokument Finisher verschieben, um ihn mit dem Riegelschloßbausatz des MFP oder Drucker in Eingriff zu bringen. Wenn der Dokument Finisher und der MFP oder Drucker nicht richtig ineinander eingreifen, führen Sie die folgende Höheneinstellung für den Dokument Finisher aus.

13. Allentare temporaneamente le due viti (7) che fissano il foglio metallico (6) della piastra di montaggio della rotaia (C) dell'MFP o stampatore, sollevare il foglio di metallo (6) di due posizioni sulla guida della rotaia (D) e serrare le due viti (7).

Nota

Se la guida della rotaia non è regolata correttamente, potrebbe non muoversi scorrevolmente oppure la finitrice di documenti potrebbe cadere.

Fare scivolare la finitrice di documenti per farla innestare con il dispositivo di arresto dell'MFP o stampatore. Qualora la finitrice di documenti e l'MFP o stampatore non si innestino saldamente, osservare la seguente procedura di regolazione dell'altezza della finitrice di documenti.

13. 松动固定在MFP或打印机侧轨道座(C)的金属板(6)上的两支固接螺钉(7), 在金属板(6)碰及导向轨道(D)的状态下, 抬升到第2个刻度的位置, 然后用两支螺钉(7)固定。

注意

如果不能正确调整的话, 导向轨道则不能顺利移动, 并会发生装订器倒置的情况。


滑动装订器并连接于MFP或打印机的挂钩承支架上。
如无法吻合, 请按下述步骤调整装订器的高度。

13. MFP 本体またはプリンタ本体側のレール取付板 (C) の板金 (6) を固定しているビス (7) 2 本をいったん緩め、板金 (6) をガイドレール (D) に当てた状態から 2 目盛り上の位置にあげて、ビス (7) 2 本を固定する。

注意


正しく調整しないと、ガイドレールがスムーズに動かない。又ドキュメントフィニッシャが倒れる恐れがある。

ドキュメントフィニッシャをスライドさせて MFP 本体またはプリンタ本体のラッチ受け板に連結させる。確実に連結しない場合は、次のドキュメントフィニッシャの高さ調整をおこなう。



Adjusting the height of the document finisher

1. Remove the front and rear covers (9) from the document finisher (A) by removing two screws (8) each.



2. Loosen the two screws (10) on the rear right caster of the document finisher (A). Adjust the height of the rear right caster by turning its adjustment bolt (13) using a cross-headed screwdriver so that the axis of the pin (11) of the latch catch is aligned with the marking of the slot (12) of the document finisher (A) when the document finisher (A) is joined to the MFP or the printer (viewed from the machine front).

Note: Turning the adjustment bolt (13) clockwise lifts the document finisher (A), while turning it counterclockwise lowers the document finisher (A).

Réglage de la hauteur du retoucheur de document

1. Retirer les couvercles avant et arrière (9) du retoucheur de document (A) en retirant deux vis (8) sur chacun des couvercles.

2. Desserrer les deux vis (10) de la roulette arrière droite du retoucheur de document (A). Régler la hauteur de la roulette arrière droite en tournant son boulon de réglage (13) à l'aide d'un tournevis cruciforme de manière que l'axe de la broche (11) du pontet du loquet soit aligné sur la marque de la fente (12) du retoucheur de document (A) lorsque le retoucheur de document (A) est fixé au MFP ou imprimante (vue à partir de l'avant de la machine).

Remarque: Si l'on tourne le boulon de réglage (13) dans le sens des aiguilles d'une montre, le retoucheur de document (A) s'élève; si on le tourne dans le sens inverse des aiguilles d'une montre, le retoucheur de document (A) s'abaisse.

Ajuste de altura del finalizador de documentos

1. Desmonte las tapas delantera y trasera (9) del finalizador de documentos (A) sacando los dos tornillos (8) cada uno.

2. Afloje los dos tornillos (10) en la rueda trasera del finalizador de documentos (A). Ajuste la altura de la rueda trasera derecha girando su perno de ajuste (13) utilizando un destornillador de punta en cruz para que el eje del pasador (11) en el pestillo esté alineado con la marca de la ranura (12) del finalizador de documentos (A) cuando el finalizador de documentos (A) esté unido a el MFP o impresora (vista del frente de la máquina).

Nota: Al girar el perno de ajuste (13) en la dirección de las manecillas del reloj se levanta el finalizador de documentos (A) y al girar contra las manecillas del reloj baja el finalizador de documentos (A).

Einstellen der Dokument Finisherhöhe

1. Die Vorder- und Rückabdeckung (9) nach Entfernen von je zwei Schrauben (8) vom Dokument Finisher (A) abnehmen.

2. Die zwei Schrauben (10) an der hinteren rechten Laufrolle des Dokument Finishers (A) lösen. Die Höhe der hinteren rechten Laufrolle durch Drehen ihrer Einstellschraube (13) mit einem Kreuzschlitzschraubenzieher so einstellen, dass die Achse des Stifts (11) der Verriegelungsklaue auf die Markierung des Schlitzes (12) des Dokument Finishers (A) ausgerichtet ist, wenn der Dokument Finisher (A) an den MFP oder Drucker angesetzt ist (von der Gerätevorderseite gesehen).

Hinweis: Durch Drehen der Einstellschraube (13) im Uhrzeigersinn wird der Dokument Finisher (A) angehoben, während er durch Drehen entgegen dem Uhrzeigersinn abgesenkt wird.

Regolazione dell'altezza della finitrice di documenti

1. Rimuovere i pannelli anteriore e posteriore (9) dalla finitrice di documenti (A) togliendo 2 viti (8) per ciascuno.

2. Allentare le due viti (10) sulla ruota orientabile posteriore destra della finitrice di documenti (A). Regolare l'altezza della ruota orientabile posteriore destra ruotandone il suo bullone di regolazione (13) a mezzo di un cacciavite a croce, in modo che l'asse del perno (11) del dispositivo di arresto risulti allineato ai contrassegni del foro (12) della finitrice di documenti (A) una volta che la finitrice stessa (A) viene unita all'MFP o stampatore (vista dal lato frontale della macchina).

Nota: Ruotando il bullone di regolazione (13) in senso orario si solleva la finitrice di documenti (A), mentre ruotandolo in senso antiorario si abbassa la finitrice di documenti (A).

[調整装订器の高度]

1. ビス (8) 各 2 本を外し、ドキュメントフィニッシャ (A) の前後カバー (9) を取り外す。

2. 将装订器 (A) 后右侧滚轮的两支固定螺钉 (10) 拧松。


将装订器 (A) 与 MFP 或打印机连接，为了使 (从前面看时) 挂钩承支架销 (11) 的中心与装订器 (A) 的长孔 (12) 的刻度相对准，用十字螺丝刀旋转调节用螺钉 (13)，对后右侧滚轮的高度进行调整。将调节用螺钉 (13) 往顺时针方向旋转时，可调高装订器 (A)，而往逆时针方向旋转螺钉时，则可调低高度。

[ドキュメントフィニッシャの高さ調整]


1. ビス (8) 各 2 本を外し、ドキュメントフィニッシャ (A) の前後カバー (9) を取り外す。

2. ドキュメントフィニッシャ (A) 右後のキャストの固定ビス (10) 2 本を緩める。

ドキュメントフィニッシャ (A) を MFP 本体またはプリンタ本体に連結し、前から見た時に、ラッチ受け板のピン (11) の中心が、ドキュメントフィニッシャ (A) の長穴 (12) の刻印に合うように、ブラスドライバーを用いて調整用ボルト (13) を回し、右後のキャストの高さ調整をおこなう。調整用ボルト (13) を時計方向に回すとドキュメントフィニッシャ (A) が上がり、反時計方向に回すと下がる。



3. Adjust the height of the front right caster in the same manner as in step 2 so that each center of the hooking portions (15) of the latch catch is aligned with the center of the two hooks (14) on the document finisher (A) when the document finisher (A) is joined to the MFP or the printer (viewed from above).



4. Adjust the height of the left two casters in the same manner as in step 2 so that the gaps (16a) and (16b) between the document finisher (A) and the MFP or the printer are the same when the document finisher (A) is detached from the MFP or the printer.

3. Régler la hauteur de la roulette avant droite en procédant comme à l'étape 2, de manière que chacun des centres des parties d'accrochage (15) du pontet du loquet soit aligné sur le centre des deux crochets (14) du retoucheur de document (A) lorsque le retoucheur de document (A) est fixé au MFP ou imprimante (vue à partir du haut).

4. Régler la hauteur des deux roulettes gauches en procédant comme à l'étape 2, de manière que les écarts (16a) et (16b) entre le retoucheur de documents (A) et la MFP ou l'imprimante soient identiques lorsque le retoucheur de documents (A) est détaché de la MFP ou de l'imprimante.

3. Ajuste la altura de la rueda delantera derecha de la misma forma que en el paso 2 para que cada centro de las partes de enganche (15) de cada pestillo esté alineado con el centro de los dos ganchos (14) en el finalizador de documentos (A) cuando el finalizador de documentos (A) está unido a el MFP o impresora (vista de arriba).

4. Ajuste la altura de las dos ruedas izquierdas de la misma forma que en el paso 2 para que las separaciones (16a) y (16b) entre el finalizador de documentos (A) y la MFP o la impresora sean las mismas cuando el finalizador de documentos (A) está soltado de la MFP o la impresora.

3. Die Höhe der vorderen rechten Laufrolle auf die in Schritt 2 beschriebene Weise einstellen, so dass die Mitte der Rasten (15) der Verriegelungsklaue auf die Mitte der zwei Haken (14) am Dokument Finisher (A) ausgerichtet ist, wenn der Dokument Finisher (A) an den MFP oder Drucker angesetzt ist (von oben gesehen).

4. Die Höhe der beiden linken Laufrollen auf die in Schritt 2 beschriebene Weise einstellen, so dass die Abstände (16a) und (16b) zwischen dem Dokument Finisher (A) und dem MFP oder dem Drucker gleich groß sind, wenn der Dokument Finisher (A) vom MFP oder vom Drucker abgenommen wird.

3. Regolare l'altezza della ruota orientabile anteriore destra allo stesso modo descritto al passo 2, in modo che ciascun centro delle parti di aggancio (15) del dispositivo di arresto sia allineato al centro dei due ganci (14) della finitrice di documenti (A), una volta che la finitrice di documenti (A) viene unita all'MFP o stampatore (vista dall'alto).


4. Regolare l'altezza delle due ruote orientabili sinistre allo stesso modo descritto al passo 2, in modo che le distanze (16a) e (16b) tra la finitrice di documenti (A) e l'MFP o lo stampatore siano le stesse una volta che la finitrice di documenti (A) viene separata dall'MFP o dallo stampatore.

3. 将装订器(A)与MFP或打印机连接, 使(从上面看时)装订器(A)的两个挂钩(14)与挂钩承支架的孔(15)中心相对准, 并按与步骤2相同的方法来调整前右侧滚轮的高度。

4. 按照步骤2中相同的方式调整左侧两个轮脚的高度, 使得装订器(A)和MFP或打印机之间的间隙(16a)和(16b)在从MFP或打印机上拆下装订器(A)时为相同的。

3. ドキュメントフィニッシャー(A)をMFP本体またはプリンタ本体に連結し、上から見た時に、ドキュメントフィニッシャー(A)のフック(14)2ヶ所とラッチ受け板の引っ掛け部(15)の中心が合うように、手順2と同様にして右前のキャスターの高さ調整をおこなう。


4. ドキュメントフィニッシャー(A)をMFP本体またはプリンタ本体から切り離した時に、ドキュメントフィニッシャー(A)とMFP本体またはプリンタ本体の間隔(16a)(16b)が等しくなるように、手順2と同様にして左側のキャスター2カ所の高さ調整をおこなう。



5. Reattach the removed parts to their original positions.

Connecting the signal cable (monochrome machines only)

1. Connect the signal cable (17) of the document finisher (A) to the MFP or the printer, pass the cable through the clamp (G), and secure the clamp by tightening the screw (18) of the MFP or the printer. The cable length to the clamp (G) must be approximately 100 mm.



Connecting the signal cable (full-color machines only)

1. Connect the signal cable (17) of the document finisher (A) to the MFP or the printer.

5. Remettez les pièces enlevées à leur position d'origine.

Connexion du câble d'interconnexion (machines monochromes seulement)

1. Connecter le câble d'interconnexion (17) du retoucheur de document (A) au MFP ou imprimante, passer le câble par la bride (G), puis fixer la bride en serrant la vis (18) du MFP ou imprimante. La longueur du câble jusqu'à la bride (G) doit être d'environ 100 mm.

Connexion du câble d'interconnexion (machines entièrement en couleurs seulement)

1. Connecter le câble d'interconnexion (17) du retoucheur de document (A) au MFP ou imprimante.

5. Vuelva a instalar las piezas desmontadas en sus posiciones originales.

Conexión del cable de señal (sólo para máquinas monocromáticas)

1. Conecte el cable de señal (17) del finalizador de documentos (A) en el MFP o impresora, pase el cable por la abrazadera (G) y asegure la abrazadera apretando el tornillo (18) del MFP o impresora. La longitud del cable a la abrazadera (G) debe ser de unos 100 mm.

Conexión del cable de señal (sólo para máquinas a todo color)

1. Conecte el cable de señal (17) del finalizador de documentos (A) en el MFP o impresora.

5. Die entfernten Teile wieder an ihren ursprünglichen Positionen anbringen.

Anschließen des Signalkabels (nur Monochrommaschinen)

1. Das Signalkabel (17) des Dokument Finishers (A) an den MFP oder Drucker anschließen, das Kabel durch die Klemme (G) führen, und die Klemme durch Anziehen der Schraube (18) des MFP oder Drucker befestigen. Die Kabellänge bis zur Klemme (G) muss ungefähr 100 mm betragen.

Anschließen des Signalkabels (nur Vollfarbenmaschinen)

1. Das Signalkabel (17) des Dokument Finishers (A) an den MFP oder Drucker anschließen.

5. Rimontare le parti rimosse nelle loro posizioni originali.

Connessione del cavo del segnale (solo per macchine in bianco e nero)

1. Collegare il cavo del segnale (17) della finitrice di documenti (A) all'MFP o stampatore, fare passare il cavo attraverso il morsetto (G) e fissare il morsetto stringendo la vite (18) dell'MFP o stampatore. La lunghezza del cavo al morsetto (G) deve essere di circa 100 mm.

Connessione del cavo del segnale (solo per le macchine a colori)

1. Collegare il cavo del segnale (17) della finitrice di documenti (A) all'MFP o stampatore.

5. 卸下的部品を元通りに取り付け。

[连接信号电线：仅限于黑白机]

1. 连接装订器(A)的信号电线(17)，将电线穿过夹紧件(G)，然后，用螺钉(18)一起紧固。到夹紧件(G)处的电线长度约需100mm。

[连接信号电线：仅限于全彩色机]

1. 装订器(A)的信号电线(17)连接在MFP或打印机上。

5. 取り外した部品を元通りに取り付け。

[信号線の接続: モノクロ機のみ]

1. ドキュメントフィニッシャ(A)の信号線(17)を接続し、ケーブルをクランプ(G)を通して、ビス(18)で共締めする。クランプ(G)までのケーブルの長さは約100mmにすること。

[信号線の接続: フルカラー機のみ]

1. ドキュメントフィニッシャ(A)の信号線(17)をMFP本体またはプリンタ本体に接続する。

Operation check

1. Insert the MFP or the printer power plug to the wall outlet and turn the main switch on.
2. Check that the paper is fed and that the document finisher (A) operates correctly.

Vérification du fonctionnement

1. Insérer la fiche d'alimentation du MFP ou imprimante dans la prise murale et mettre l'interrupteur principal sous tension.
2. Vérifier que le papier est fourni et que le retoucheur de document (A) fonctionne correctement.

Comprobación operacional

1. Inserte el enchufe del MFP o impresora en el receptáculo de la pared y encienda el interruptor principal.
2. Asegúrese de que avance el papel y verifique que el finalizador de documentos (A) funcione correctamente.

Betriebstest

1. Stecken Sie den Netzstecker des MFP oder Drucker in die Netzsteckdose ein und schalten Sie den Hauptschalter ein.
2. Vergewissern dass der Papiervorschub funktioniert und dass der Dokument Finisher (A) einwandfrei funktioniert.

Controllo del funzionamento

1. Inserire il cavo di alimentazione dell'MFP o stampatore nella presa di rete e quindi premere il pulsante generale di accensione.
2. Verificare che la carta di prova sia alimentata e controllare che la finitrice di documenti (A) funzioni correttamente.


[确认运作]

1. 将MFP主机的电源插头插入插座后，开启总电源。
2. 确认已经送纸并且装订器(A)运行正常。

[動作確認]

1. MFP 本体またはプリンタ本体の電源プラグをコンセントに差し込み、メインスイッチを ON にする。
2. 通紙確認をおこない、ドキュメントフィニッシャ (A) が正常に動作することを確認する。

INSTALLATION GUIDE FOR BUILT-IN FINISHER



English

Supplied parts

| | | |
|---|------------------------|---|
| A | Paper conveying unit | 1 |
| B | Sub staple cover | 1 |
| C | Staple cover | 1 |
| D | Hook holder | 1 |
| E | Finisher process table | 1 |

| | | |
|---|-------------------|---|
| F | Upper left cover | 1 |
| G | Front eject cover | 1 |
| H | Rear eject cover | 1 |
| I | Finisher tray | 1 |
| J | Staple cartridge | 1 |
| K | Blindfold seal | 1 |
| L | Large pin | 1 |
| M | Small pin | 1 |
| N | M3 x 6 screw | 3 |

Français

Pièces fournies

| | | |
|---|--|---|
| A | Unité de transport du papier | 1 |
| B | Capot de l'agrafeuse auxiliaire | 1 |
| C | Capot de l'agrafeuse | 1 |
| D | Support de crochet | 1 |
| E | Table de processus du module de finition | 1 |

| | | |
|---|-------------------------------|---|
| F | Capot supérieur gauche | 1 |
| G | Capot d'éjection avant | 1 |
| H | Capot d'éjection arrière | 1 |
| I | Plateau du module de finition | 1 |
| J | Cartouche d'agrafes | 1 |
| K | Étiquette de masquage | 1 |
| L | Grande goupille | 1 |
| M | Petite goupille | 1 |
| N | Vis M3 x 6 | 3 |

Español

Partes suministradas

| | | |
|---|---------------------------------|---|
| A | Unidad de transporte de papel | 1 |
| B | Cubierta secundaria de grapas | 1 |
| C | Cubierta de grapas | 1 |
| D | Soporte de gancho | 1 |
| E | Tabla de proceso de finalizador | 1 |

| | | |
|---|-------------------------------|---|
| F | Cubierta superior izquierda | 1 |
| G | Cubierta de expulsión frontal | 1 |
| H | Cubierta de expulsión trasera | 1 |
| I | Bandeja de finalizador | 1 |
| J | Cartucho de grapas | 1 |
| K | Sello ciego | 1 |
| L | Pasador grande | 1 |
| M | Pasador pequeño | 1 |
| N | Tornillo M3 x 6 | 3 |

Deutsch

Gelieferte Teile

| | | |
|---|----------------------|---|
| A | Papierfördereinheit | 1 |
| B | Hefterhilfsabdeckung | 1 |
| C | Hefterabdeckung | 1 |
| D | Hakenhalter | 1 |
| E | Finisher-Druckablage | 1 |

| | | |
|---|-----------------------|---|
| F | Obere linke Abdeckung | 1 |
| G | Frontauswurfabdeckung | 1 |
| H | Rückauswurfabdeckung | 1 |
| I | Finisher-Ablage | 1 |
| J | Heftklammermagazin | 1 |
| K | Blindaufkleber | 1 |
| L | Großer Stift | 1 |
| M | Kleiner Stift | 1 |
| N | M3 x 6 Schraube | 3 |

Italiano

Parti di fornitura

| | | |
|---|---------------------------------------|---|
| A | Unità di trasporto carta | 1 |
| B | Coperchio secondario della pinzatrice | 1 |
| C | Coperchio pinzatrice | 1 |
| D | Supporto a gancio | 1 |
| E | Tabella di elaborazione del finitore | 1 |

| | | |
|---|--|---|
| F | Coperchio superiore sinistro | 1 |
| G | Coperchio anteriore di espulsione carta | 1 |
| H | Coperchio posteriore di espulsione carta | 1 |
| I | Vassoio finitore | 1 |
| J | Cartuccia punti metallici | 1 |
| K | Sigillo mascherina | 1 |
| L | Perno grande | 1 |
| M | Perno piccolo | 1 |
| N | Vite M3 x 6 | 3 |

简体中文

同装品

| | | |
|---|--------|---|
| A | 输送组件 | 1 |
| B | 副装订器盖板 | 1 |
| C | 装订器盖板 | 1 |
| D | 钩夹 | 1 |

| | | |
|---|-----------|---|
| E | 装订分页器处理托盘 | 1 |
| F | 左上盖板 | 1 |
| G | 排纸盖板 (前) | 1 |
| H | 排纸盖板 (后) | 1 |
| I | 装订分页器托盘 | 1 |
| J | 订书钉盒 | 1 |
| K | 标贴 | 1 |
| L | 大卡销 | 1 |

| | | |
|---|-----------|---|
| M | 小卡销 | 1 |
| N | 螺丝 M3 x 6 | 3 |

日本語


同梱品

| | | |
|---|------------|---|
| A | 搬送ユニット | 1 |
| B | サブステーブルカバー | 1 |
| C | ステーブルカバー | 1 |
| D | フックホルダ | 1 |

| | | |
|---|--------------|---|
| E | フィニッシャー処理トレイ | 1 |
| F | 左上カバー | 1 |
| G | 排出カバー前 | 1 |
| H | 排出カバー後 | 1 |
| I | フィニッシャトレイ | 1 |
| J | ステーブルカートリッジ | 1 |
| K | シール | 1 |
| L | ピン大 | 1 |

| | | |
|---|-----------|---|
| M | ピン小 | 1 |
| N | ビス M3 x 6 | 3 |

www.tonerplus.com.ua




Precautions

- Be sure to remove any tape and/or cushioning material from supplied parts.
- Before installing the finisher, be sure to turn the main power switch of the machine off and unplug the power cable from the wall outlet.

Important

When placing the paper conveying unit (A) on the floor or the like, be sure to place it upside down because the staple mounting plate may be deformed.



Procedure

Removing the covers

1. Open the front cover (1) and left cover 1 (2).
2. Remove the clip holder (3).
3. Remove two screws (4) and release three latches (5) to remove the cover (6).

Précautions

- Veillez à retirer les morceaux de bande adhésive et/ou les matériaux de rembourrage des pièces fournies.
- Avant d'installer le module de finition, veillez à mettre la machine hors tension et à débrancher le câble d'alimentation de la prise murale.

Important

Lorsque vous placez l'unité de transport du papier (A) sur le sol ou sur une surface équivalente, veillez à la placer sens dessus dessous, car la plaque de montage d'agrafes risque d'être déformée.

Procédure

Retrait des capots

1. Ouvrez le capot avant (1) et le capot gauche 1 (2).
2. Retirez le support à pince (3).
3. Retirez deux vis (4) et libérez trois verrous (5) pour retirer le capot (6).

Precauciones

- Asegúrese de despegar todas las cintas y/o material amortiguador de las partes suministradas.
- Antes de instalar el finalizador, asegúrese de desconectar el interruptor principal de la máquina y desenchufar el cable eléctrico del tomacorriente de la pared.

Importante

Cuando coloca la unidad de transporte de papel (A) en el piso o similar, asegúrese de colocarlo invertido porque la placa de montaje de grapas puede deformarse.

Procedimiento

Desmontaje de las cubiertas

1. Abra la cubierta frontal (1) y la cubierta izquierda 1 (2).
2. Desmonte el soporte de clip (3).
3. Saque los dos tornillos (4) y suelte los tres pestillos (5) para desmontar la cubierta (6).

Vorsichtsmaßnahmen

- Entfernen Sie Klebeband und/oder Dämpfungsmaterial vollständig von den mitgelieferten Teilen.
- Schalten Sie unbedingt den Betriebsschalter der Maschine aus, und trennen Sie das Netzkabel von der Netzsteckdose, bevor Sie den Finisher installieren.

Wichtig

Wenn die Papierfördereinheit (A) auf den Boden oder dergleichen gestellt wird, muss sie auf den Kopf gestellt werden, weil sonst die Heftermontageplatte verformt werden kann.

Verfahren

Entfernen der Abdeckungen

1. Die Frontabdeckung (1) und die linke Abdeckung 1 (2) öffnen.
2. Den Büroklemhalter (3) entfernen.
3. Die zwei Schrauben (4) herausdrehen, und die drei Rasten (5) lösen, um die Abdeckung (6) abzunehmen.

Precauzioni

- Accertarsi di rimuovere tutti i nastri adesivi e/o il materiale di imbottitura dalle parti fornite.
- Prima di installare il finitore, assicurarsi di spegnere l'interruttore principale di alimentazione della macchina e scollegare la spina del cavo di alimentazione dalla presa a muro della rete elettrica.

Importante

Quando collocate l'unità di trasporto della carta (A) sul pavimento o in un altro luogo simile, accertatevi che sia posto capovolto, perché la piastra di montaggio della pinzatrice potrebbe deformarsi.

Procedura

Rimozione dei coperchi

1. Aprite il coperchio anteriore (1) e il coperchio sinistro 1 (2).
2. Rimuovete il contenitore delle graffette (3).
3. Togliete due viti (4) e rilasciate i tre fermi (5) per rimuovere il coperchio (6).

注意事項

- 如果同裝品上帶有固定膠帶、緩衝材料時務必揭下。
- 安裝裝訂分頁器時，必須先關閉機器主機的主電源開關，並拔下電源插頭後，再進行安裝作業。

注意事項

將輸送組件 (A) 放在地板等上時，為了防止裝訂器安裝板變形，必須翻過來放置。

安裝步驟

拆下蓋板類

1. 打開前蓋板 (1) 和左蓋板 1 (2)。
2. 拆下夾子盒 (3)。
3. 卸下 2 個螺絲 (4)，鬆解 3 處嵌入板 (5)，然後，取下蓋板 (6)。

注意事項

- 同梱品に固定テープ、緩衝材が付いている場合は必ず取り外すこと。
- フィニッシャを設置する場合は、機械本体の主電源スイッチを OFF にし、電源プラグを抜いてから作業をおこなう。


注意事項

搬送ユニット (A) を床などに置く場合は、ステーブル取付板変形防止のため必ず裏返しにして置く。


設置手順

カバー類の取り外し


1. 前カバー (1) および左カバー 1 (2) を開く。
2. クリップ入れ (3) を取り外す。
3. ビス (4) 2 本を外し、はめ込み (5) 3 箇所を解除してカバー (6) を取り外す。



4. Release the latch (7) using a flat-head screwdriver to remove the cover (8).



5. Remove the screw (9) to remove the metal plate (10). The removed metal plate (10) is no longer required.



6. Release the latch (11) using a flat-head screwdriver and slide the cover (12) to the front to remove.
7. Remove the screw (13) to remove the cover (14).

4. Libérez le verrou (7) à l'aide d'un tournevis à tête plate pour retirer le capot (8).

5. Retirez la vis (9) pour déposer la plaque métallique (10). La plaque métallique déposée (10) n'est plus nécessaire.

6. Libérez le verrou (11) à l'aide d'un tournevis à tête plate, puis faites glisser le capot (12) vers l'avant pour le déposer.
7. Retirez la vis (13) pour déposer le capot (14).

4. Suelte el pestillo (7) utilizando un destornillador de cabeza plana para desmontar la cubierta (8).

5. Quite el tornillo (9) para desmontar la placa de metal (10). La placa de metal desmontada (10) ya no es necesaria.

6. Suelte el pestillo (11) utilizando un destornillador de cabeza plana y deslice la cubierta (12) hacia delante para desmontarla.
7. Saque el tornillo (13) para desmontar la cubierta (14).

4. Die Raste (7) mit einem Flachschaubenzieher lösen, um die Abdeckung (8) abzunehmen.

5. Die Schraube (9) herausdrehen, um die Metallplatte (10) abzunehmen. Die abgenommene Metallplatte (10) wird nicht mehr benötigt.

6. Die Raste (11) mit einem Flachschaubenzieher lösen, und die Abdeckung (12) nach vorn schieben, um sie abzunehmen.
7. Die Schraube (13) herausdrehen, um die Abdeckung (14) abzunehmen.

4. Rilasciate il fermo (7) utilizzando un giravite a punta piatta per rimuovere il coperchio (8).

5. Rimuovere la vite (9) per togliere la piastra di metallo (10). La piastra di metallo (10) rimossa non è più necessaria.

6. Rilasciate il fermo (11) utilizzando un giravite a punta piatta e fate scivolare il coperchio (12) verso il lato anteriore per rimuoverlo.
7. Togliete la vite (13) per rimuovere il coperchio (14).

4. 用一字形螺丝刀等松解嵌入板 (7)，取下盖板 (8)。

5. 卸下 1 个螺丝 (9)，取下金属件 (10)。不安装金属件 (10)。


6. 用一字形螺丝刀等松解嵌入板 (11)，将盖板 (12) 向跟前拉并取下。
7. 卸下 1 个螺丝 (13)，取下盖板 (14)。




4. はめ込み (7) をマイナスドライバーなどで解除し、カバー (8) を取り外す。

5. ビス (9) 1 本を外し、金具 (10) を取り外す。金具 (10) は取り付けない。

6. はめ込み (11) をマイナスドライバーなどで解除し、カバー (12) を手前側に引いて取り外す。
7. ビス (13) 1 本を外し、カバー (14) を取り外す。



8. Remove the screw (15) from the rear side of the machine to remove the cover (16).



Attaching the sub staple cover

9. Insert the hook (17) of the sub staple cover (B) and turn the cover (B) in the direction of arrow until it clicks to attach.

8. Retirez la vis (15) du côté arrière de la machine pour déposer le capot (16).

Fixation du capot de l'agrafeuse auxiliaire

9. Insérez le crochet (17) du capot de l'agrafeuse auxiliaire (B), puis faites tourner le capot (B) dans le sens de la flèche jusqu'à ce qu'il s'encliquète pour le fixer.

8. Saque el tornillo (15) del lado trasero de la máquina para desmontar la cubierta (16).

Colocación de la cubierta secundaria de grapas

9. Inserte el gancho (17) en la cubierta secundaria de grapas (B) y gire la cubierta (B) en el sentido de la flecha hasta que se produzca un chasquido para colocarlo.

8. Die Schraube (15) auf der Rückseite der Maschine herausdrehen, um die Abdeckung (16) abzunehmen.

Anbringen der Hefterhilfsabdeckung

9. Den Haken (17) der Hefterhilfsabdeckung (B) einsetzen, und die Abdeckung (B) in Pfeilrichtung drehen, bis sie mit einem Klicken einrastet.

8. Togliete la vite (15) dal lato posteriore della macchina per rimuovere il coperchio (16).

Montaggio del coperchio secondario della pinzatrice

9. Inserite il gancio (17) del coperchio secondario della pinzatrice (B) e fate ruotare il coperchio (B) nella direzione della freccia fino a quando non si mette in posizione con un clic.

8. 卸下机器主机后面的 1 个螺丝 (15)，取下盖板 (16)。


安装副装订器盖板

9. 将副装订器盖板 (B) 的钩件 (17) 插入后，朝箭头方向转动安装，直至听到咔叽声为止。

8. 機械本体後側のビス (15) 1 本を外し、カバー (16) を取り外す。

サブステープルカバーの取り付け

9. サブステープルカバー (B) のフック (17) を挿入し、カチッと音がするまで矢印方向に回転し取り付ける。



Installing the paper conveying unit

10. Insert the paper conveying unit (A) from the machine front and slide it to the left.
11. Fix the paper conveying unit (A) using two pins.
Front: Use the large pin (L).
Rear: Use the small pin (M).

Installation de l'unité de transport du papier

10. Insérez l'unité de transport du papier (A) depuis l'avant de la machine et faites-le glisser vers la gauche.
11. Fixez l'unité de transport du papier (A) à l'aide de deux goupilles.
Avant: Utilisez la grande goupille (L).
Arrière: Utilisez la petite goupille (M).

Instalación de la unidad de transporte de papel

10. Inserte la unidad de transporte de papel (A) desde el frente de la máquina y deslice hacia la izquierda.
11. Fije la unidad de transporte de papel (A) utilizando dos pasadores.
Frente: Utilice el pasador grande (L).
Atrás: Utilice el pasador pequeño (M).

Installieren der Papierfördereinheit

10. Die Papierfördereinheit (A) von der Vorderseite der Maschine einführen und nach links schieben.
11. Die Papierfördereinheit (A) mit zwei Stiften befestigen.
Vorn: Den großen Stift (L) verwenden.
Hinten: Den kleinen Stift (M) verwenden.

Montaggio dell'unità di trasporto della carta


10. Inserite l'unità di trasporto della carta (A) dal lato anteriore della macchina e fatelo scivolare verso sinistra.
11. Fissate l'unità di trasporto della carta (A) utilizzando due perni.
Lato anteriore: utilizzate il perno grande (L).
Lato posteriore: utilizzate il perno piccolo (M).

安装输送组件

10. 从机器主机前面插入输送组件 (A)，向左侧滑动。
11. 用 2 个卡销固定输送组件 (A)。
前面：大卡销 (L)
后面：小卡销 (M)


搬送ユニットの取り付け

10. 搬送ユニット (A) を機械本体前側から挿入し、左側にスライドする。
11. 搬送ユニット (A) をピン 2 本で固定する。
前側：ピン大 (L)
後側：ピン小 (M)



Releasing the lever holding plate

12. Loosen the screw (18) of the paper conveying unit (A) and release the lever holding plate (19) in the direction of arrow.
13. Tighten the screw (18).



Installing the finisher process table

14. Loosen the screw (20) approx. 3 turns.
Do not turn the screw (20) too far, otherwise it may drop into the machine.
15. Fit the hook holder (D) to the screw (20).
16. Fit the hole of the hook holder (D) to the positioning projection (21) and then tighten the screw (20) to fix the hook holder (D).

Libération de la plaque de support de levier

12. Desserrez la vis (18) de l'unité de transport du papier (A) et libérez la plaque de support de levier (19) dans le sens de la flèche.
13. Resserrez la vis (18).

Installation de la table de processus du module de finition

14. Desserrez la vis (20) d'environ trois tours.
Ne pas tourner la vis (20) excessivement, sinon elle risquerait de tomber dans la machine.
15. Placez le support de crochet (D) sur la vis (20).
16. Faites coïncider l'orifice du support de crochet (D) avec la saillie de positionnement (21), puis serrez la vis (20) pour fixer le support de crochet (D).

Alojado de la placa de soporte de palanca

12. Afloje el tornillo (18) de la unidad de transporte de papel (A) y suelte la placa de soporte de la palanca (19) en el sentido de la flecha.
13. Apriete el tornillo (18).

Instalación de la tabla de proceso de finalizador

14. Afloje el tornillo (20) aprox. 3 giros.
No gire demasiado el tornillo (20) porque puede caerse dentro de la máquina.
15. Encaje el soporte de gancho (D) en el tornillo (20).
16. Encaje el orificio del soporte de gancho (D) en la saliente de proyección (21) y apriete el tornillo (20) para fijar el soporte de gancho (D).

Freigeben der Hebelhalteplatte

12. Die Schraube (18) der Papierfördereinheit (A) lösen, und die Hebelhalteplatte (19) in Pfeilrichtung freigeben.
13. Die Schraube (18) festziehen.

Installieren der Finisher-Druckablage

14. Die Schraube (20) um etwa 3 Umdrehungen lösen.
Die Schraube (20) nicht zu weit lösen, weil sie sonst in die Maschine fallen kann.
15. Den Hakenhalter (D) an der Schraube (20) anbringen.
16. Das Loch des Hakenhalters (D) auf den Positioniersprung (21) ausrichten, und dann die Schraube (20) zur Befestigung des Hakenhalters (D) festziehen.

Rilascio della leva che fissa la piastra

12. Allentate la vite (18) dell'unità di trasporto della carta (A) e rilasciate la leva che fissa la piastra (19) nella direzione della freccia.
13. Stringete la vite (18).

Installazione del tabella di elaborazione del finitore.

14. Allentate di 3 giri circa la vite (20).
Non girate troppo la vite (20), altrimenti potrebbe cadere nella macchina.
15. Montate il supporto a gancio (D) sulla vite (20).
16. Montate il foro del supporto a gancio (D) sulla posizione (21) e poi stringete la vite (20) per fissare il supporto a gancio (D).

松解固定金属柄

12. 松弛输送组件 (A) の 1 个螺丝 (18), 朝箭头方向松解固定金属柄 (19)。
13. 然后, 紧固 1 个螺丝 (18)。

安装装订分页器处理托盘


14. 松弛 1 个螺丝 (20) (约 3 圈)。
不可过度松弛 1 个螺丝 (20), 否则会导致螺丝掉落机器内部。
15. 将钩夹 (D) 插入 1 个螺丝 (20)。
16. 将定位突起部 (21) 对准钩夹 (D) 孔的位置, 用 1 个螺丝 (20) 紧固。

レバー固定金具の解除

12. 搬送ユニット (A) のビス (18) 1 本をゆるめ、レバー固定金具 (19) を矢印方向に解除する。
13. ビス (18) 1 本を締める。

フィニッシャー処理トレイの取り付け

14. ビス (20) 1 本を緩める (約 3 回転)。
ビス (20) 1 本を緩めすぎると、機械内部に落下する恐れがある。
15. フックホルダ (D) をビス (20) 1 本に挿入する。
16. 位置決め突起 (21) とフックホルダ (D) の穴の位置を合わせて、ビス (20) 1 本を締めて固定する。



17. Extend the wires of connectors (22) of the finisher process table (E) straight.
 18. Insert the finisher process table (E) from the front side of the machine and hang the hooks (23) on the right and left of the table (E) onto the machine.
Pass the connectors of the finisher process table (E) through the opening at the rear side of the machine.


17. Allongez tout droit les fils des connecteurs (22) de la table de processus du module de finition (E).
 18. Insérez la table de processus du module de finition (E) depuis l'avant de la machine, et suspendez sur la machine les crochets (23) se trouvant sur les côtés droit et gauche du plateau (E).
Faire passer les connecteurs de la table de processus du module de finition (E) par l'ouverture du côté arrière de la machine.

17. Alargue los cables de los conectores (22) de la tabla de proceso de finalizador (E) para que queden extendidos.
 18. Inserte la tabla de proceso de finalizador (E) por el lado delantero de la máquina y cuelgue los ganchos (23) en los lados derecho e izquierdo de la tabla (E) de la máquina.
Pase los conectores de la tabla de proceso de finalizador (E) por la abertura en el lado trasero de la máquina.

17. Die Kabel der Steckverbinder (22) der Finisher-Druckablage (E) gerade ziehen.
 18. Die Finisher-Druckablage (E) von der Vorderseite der Maschine einführen, und die Haken (23) auf der rechten und linken Seite der Ablage (E) in die Maschine einhängen.
Die Steckverbinder der Finisher-Druckablage (E) durch die Öffnung auf der Rückseite der Maschine führen.

17. Allungate i cavi dei connettori (22) del tabella di elaborazione del finitore (E).
 18. Inserite la tabella di elaborazione del finitore (E) dal lato anteriore della macchina e appendete i ganci (23) a destra e a sinistra del tabella (E) sulla macchina.
Fate passare i connettori della tabella di elaborazione del finitore (E) attraverso l'apertura sul lato posteriore della macchina.

17. 将装订分页器处理托盘 (E) 插头的电线 (22) 伸直。
 18. 从机器主机前面插入装订分页器处理托盘 (E)，挂在左右钩件 (23) 上。
将装订分页器处理托盘 (E) 的插头通过机器主机后面的开口部。



19. At the rear side of the machine, connect the connector (24) of the finisher process table to the connector (25) of the paper conveying unit.
 20. Connect the connector (26) of the finisher process table to YC4 (27) on the engine PWB.
 21. Replace the cover (16) using the screw (15) removed in step 8.

19. Sur le côté arrière de la machine, branchez le connecteur (24) de la table de processus du module de finition au connecteur (25) de l'unité de transport du papier.
 20. Branchez le connecteur (26) de la table de processus du module de finition à YC4 (27) sur le PWB du moteur.
 21. Remettez le capot (16) en place en utilisant la vis (15) retirée auparavant lors de l'étape 8.

19. En el lado trasero de la máquina, conecte el conector (24) de la tabla de proceso de finalizador en el conector (25) de la unidad de transporte de papel.
 20. Conecte el conector (26) de la tabla de proceso de finalizador en YC4 (27) en el PWB del motor.
 21. Vuelva a colocar la cubierta (16) utilizando el tornillo (15) sacado en el paso 8.


19. Den Steckverbinder (24) der Finisher-Druckablage auf der Rückseite der Maschine mit dem Steckverbinder (25) der Papierfördereinheit verbinden.
 20. Den Steckverbinder (26) der Finisher-Druckablage an YC4 (27) der Motorplatine anschließen.
 21. Die Abdeckung (16) wieder mit der in Schritt 8 entfernten Schraube (15) anbringen.

19. Sul lato posteriore della macchina, collegate il connettore (24) della tabella di elaborazione del finitore al connettore (25) dell'unità di trasporto della carta.
 20. Collegate il connettore (26) della tabella di elaborazione del finitore al YC4 (27) sul motore PWB.
 21. Rimettete a posto il coperchio (16) utilizzando la vite (15) rimossa nel passo 8.

19. 绕到机器主机后面，将装订分页器处理托盘的插头 (24) 连接在输送组件的插头 (25) 上。
 20. 将装订分页器处理托盘的插头 (26) 连接在引擎主板的 YC4 (27) 上。
 21. 在步骤 8 拆下的盖板 (16)，用 1 个螺丝 (15) 按原样装好。


17. フィニッシャ処理トレイ (E) のコネクタ電線 (22) をまっすぐに伸ばす。
 18. フィニッシャ処理トレイ (E) を機械本体前側から挿入し、左右のフック (23) を引っ掛ける。
フィニッシャ処理トレイ (E) のコネクタを機械本体後側の開口部に通す。

19. 機械本体後側にまわり、フィニッシャ処理トレイのコネクタ (24) を搬送ユニットのコネクタ (25) に接続する。
 20. フィニッシャ処理トレイのコネクタ (26) をエンジン回路基板の YC4 (27) に接続する。
 21. 手順 8 で取り外したカバー (16) をビス (15) 1 本で元通り取り付け。



Attaching the upper left cover

22. Insert five catches (28) to attach the upper left cover (F).



Installing the staple cover

23. Release two latches (29) of the cover (6) removed in step 3 using a flat-head screwdriver to remove the lower clip holder (30).

24. Attach the lower clip holder (30) to the staple cover (C).

Fixation du capot supérieur gauche

22. Insérez les cinq fermetoirs (28) pour fixer le capot supérieur gauche (F).

Installation du capot de l'agrafeuse

23. Libérez les deux verrous (29) du capot (6) retiré auparavant lors de l'étape 3 en utilisant un tournevis à tête plate pour retirer le support de pince inférieur (30).

24. Fixez le support de pince inférieur (30) sur le capot de l'agrafeuse (C).

Colocación de la cubierta superior izquierda

22. Inserte las uñas (28) para instalar la cubierta superior izquierda (F).

Instalación de la cubierta de grapas

23. Suelte los dos pestillos (29) de la cubierta (6) desmontada en el paso 3 utilizando el destornillador de punta plana para desmontar el soporte de clip inferior (30).

24. Coloque el soporte de clip inferior (30) en la cubierta de grapas (C).

Anbringen der oberen linken Abdeckung

22. Die fünf Klauen (28) zur Anbringung der oberen linken Abdeckung (F) einhängen.

Installieren der Hefterabdeckung

23. Die zwei Rasten (29) der in Schritt 3 entfernten Abdeckung (6) mit einem Flachschaubenzieher lösen, um den unteren Büroklammerhalter (30) abzunehmen.

24. Den unteren Büroklammerhalter (30) an der Hefterabdeckung (C) anbringen.

Montaggio del coperchio superiore sinistro

22. Inserite cinque ganci (28) per fissare il coperchio superiore sinistro (F).

Installazione del coperchio della pinzatrice

23. Rilasciate due fermi (29) del coperchio (6) rimosso nel passo 3 utilizzando un giravite a punta piatta per rimuovere il contenitore inferiore delle graffette (30).

24. Montate il contenitore inferiore delle graffette (30) al coperchio della pinzatrice (C).

安装左上盖板

22. 将 5 处钩件 (28) 插入后, 装上左上盖板 (F)。

安装装订器盖板

23. 用一字形螺丝刀等松解在步骤 3 卸下的盖板 (6) 的 2 处嵌入板 (29), 并取下夹子盒下 (30)。

24. 将夹子盒下 (30) 装在装订器盖板 (C) 上。

TONER


左上カバーの取り付け

22. 引っ掛け (28) 5箇所を挿入し、左上カバー (F) を取り付ける。

ステーブルカバーの取り付け


23. 手順 3 で取り外したカバー (6) のはめ込み (29) 2箇所をマイナスドライバーなどで解除し、クリップ入れ下 (30) を取り外す。

24. クリップ入れ下 (30) をステーブルカバー (C) に取り付ける。



25. Fix the staple cover (C) using three screws.
Upper/Lower right: Use two screws (4)
removed in step 3.
Upper right: Use M3 × 6 screw (N).

26. Replace the clip holder (3) removed in step 2.
27. Close left cover 1 (2) and the front cover (1).



Attaching the finisher tray
28. Fix the front eject cover (G) and the rear eject cover (H) using an M3 × 6 screw (N) each.

25. Fixez le capot de l'agrafeuse (C) à l'aide de trois vis.
Côté supérieur/inférieur droit: Utilisez les deux vis (4) retirées auparavant lors de l'étape 3.
Côté supérieur droit: Utilisez une vis M3 × 6 (N).

26. Remettez en place le support à pince (3) retiré auparavant lors de l'étape 2.
27. Refermez le capot gauche 1 (2) et le capot avant (1).

Fixation du plateau du module de finition
28. Fixez le capot d'éjection avant (G) et le capot d'éjection arrière (H) à l'aide d'une vis M3 × 6 (N) pour chaque capot.

25. Fije la cubierta de grapas (C) utilizando tres tornillos.
Superior/inferior derecho: Utilice dos tornillos (4) sacados en el paso 3.
Superior derecho: Utilice el tornillo M3 × 6 (N).

26. Vuelva a colocar el soporte de clip (3) desmontado en el paso 2.
27. Cierre la cubierta izquierda 1 (2) y la cubierta frontal (1).

Colocación de la bandeja de finalizador
28. Fije la cubierta de expulsión frontal (G) y la cubierta de expulsión trasera (H) utilizando un tornillo M3 × 6 (N) en cada lugar.

25. Die Hefterabdeckung (C) mit drei Schrauben befestigen.
Oben/Unten rechts: Die in Schritt 3 entfernten zwei Schrauben (4) benutzen.
Oben rechts: Die M3 × 6 Schraube (N) benutzen.

26. Den in Schritt 2 entfernten Büroklammerhalter (3) wieder anbringen.
27. Die linke Abdeckung 1 (2) und die Frontabdeckung (1) schließen.

Anbringen der Finisher-Ablage
28. Die Frontauswurfabdeckung (G) und die Rückauswurfabdeckung (H) mit je einer M3 × 6 Schraube (N) befestigen.

25. Fissate il coperchio della pinzatrice (C) utilizzando tre viti.
Lato superiore/inferiore destro: utilizzate due viti (4) rimosse nel passo 3.
Lato superiore destro: utilizzate una vite M3 × 6 (N).

26. Rimettete al suo posto il contenitore delle graffette (3) rimosso nel passo 2.
27. Chiudete il coperchio sinistro 1 (2) e il coperchio anteriore (1).

Montaggio del vassoio del finitore
28. Fissate il coperchio anteriore di espulsione carta (G) e il coperchio posteriore di espulsione carta (H) utilizzando una vite M3 × 6 (N) per ciascuno.

25. 用 3 个螺丝固定装订器盖板 (C)。
上侧、右下侧：在步骤 3 拆下的 2 个螺丝 (4)
右上侧：1 个螺丝 M3 × 6 (N)


26. 在步骤 2 拆下的夹子盒 (3) 按原样装好。
27. 关闭左盖板 1 (2) 和前盖板 (1)。

安装装订分页器托盘
28. 用各 1 个螺丝 M3 × 6 (N) 固定排纸盖板前 (G) 和后 (H)。


25. ビス 3 本でステーブルカバー (C) を固定する。
上側・右下側: 手順 3 で外したビス (4) 2 本
右上側: ビス M3 × 6 (N) 1 本

26. 手順 2 で取り外したクリップ入れ (3) を元通り取り付け。
27. 左カバー 1 (2) および前カバー (1) を閉じる。

フィニッシュトレイの取り付け
28. ビス M3 × 6 (N) 各 1 本で排出カバー前 (G) および後 (H) を固定する。




29. Insert the front and rear hooks of the finisher tray (I) into the front eject cover (G) and the rear eject cover (H) respectively and then attach the finisher tray (I).



Attaching the staple cartridge

30. Open the cover (31) and insert the staple cartridge (J).

31. Close the cover (31).



Adhering the blindfold seal (For models with monochrome touch panel only)

32. Clean the staple cover with alcohol and then adhere the blindfold seal (K).

29. Insérez les crochets avant et arrière du plateau du module de finition (I) dans le capot d'éjection avant (G) et dans le capot d'éjection arrière (H) respectivement, puis fixez le plateau du module de finition (I).

Fixation de la cartouche d'agrafes

30. Ouvrez le capot (31) et insérez la cartouche d'agrafes (J).

31. Refermez le capot (31).

Collage de l'étiquette de masquage (pour les modèles équipés d'un écran tactile monochrome seulement)

32. Nettoyez le capot de l'agrafeuse avec de l'alcool, puis collez l'étiquette de masquage (K).

29. Inserte los ganchos delantero y trasero de la bandeja de finalizador (I) en la cubierta de expulsión frontal (G) y la cubierta de expulsión trasera (H) respectivamente y coloque la bandeja de finalizador (I).

Colocación del cartucho de grapas

30. Abra la cubierta (31) e inserte el cartucho de grapas (J).

31. Cierre la cubierta (31).

Pegado del sello ciego (Sólo modelos con panel de toque monocromático)

32. Limpie la cubierta de grapas con alcohol y pegue el sello ciego (K).

29. Die vorderen und hinteren Haken der Finisher-Ablage (I) jeweils in die Frontauswurfabdeckung (G) und die Rückauswurfabdeckung (H) einführen, und dann die Finisher-Ablage (I) anbringen.

Anbringen des Heftklammermagazins

30. Die Abdeckung (31) öffnen, und das Heftklammermagazin (J) einsetzen.

31. Die Abdeckung (31) schließen.

Anbringen des Blindaufklebers (nur für Modelle mit Monochrom-Sensorbildschirm)

32. Die Hefterabdeckung mit Alkohol reinigen, und dann den Blindaufkleber (K) anbringen.

29. Inserite i ganci anteriori e posteriori del vassoio del finitore (I) rispettivamente nel coperchio anteriore di espulsione carta (G) e nel coperchio posteriore di espulsione carta (H) e poi montate il vassoio del finitore (I).

Montaggio della cartuccia dei punti metallici

30. Aprite il coperchio (31) e inserite la cartuccia dei punti metallici (J).

31. Chiudete il coperchio (31).

Applicate il sigillo mascherina (solo per i modelli con pannello monocromatico a sfioramento)

32. Pulite il coperchio della pinzatrice con alcol e poi applicate il sigillo mascherina (K).

29. 将装订分页器托盘 (I) 的构件插入排纸盖板前 (G) 和后 (H), 然后装上装订分页器托盘 (I)。

安装订书钉盒

30. 打开盖板 (31) 后, 插入订书钉盒 (J)。

31. 关闭盖板 (31)。

贴标贴

(只限单色触控式面板机)

32. 用酒精清洁后, 贴上标贴 (K)。

TONER

29. フィニッシュャートレイ (I) のフックを排出カバー前 (G) および後 (H) に挿入し、フィニッシュャートレイ (I) を取り付ける。

ステーブルカートリッジの取り付け

30. カバー (31) を開き、ステーブルカートリッジ (J) を挿入する。

31. カバー (31) を閉じる。

シールの貼り付け

(モノクロタッチパネル機のみ)

32. アルコール清掃後、シール (K) を貼り付ける。

Checking the operation

1. Connect the power plug of the machine to the wall outlet and turn the main power switch on.
2. Make a proof copy in the staple mode to check the finishing and stapling.

Vérification du fonctionnement

1. Insérer la fiche d'alimentation de la machine dans la prise murale et mettre la machine sous tension.
2. Effectuez une copie de test en mode d'agrafage pour vérifier la finition et l'agrafage.

Verificación del funcionamiento

1. Conecte el enchufe eléctrico de la máquina en un tomacorriente de la pared y conecte el interruptor principal.
2. Haga una copia de prueba en el modo de grapas para verificar el finalizado y grapado.

Überprüfen des Betriebs

1. Den Netzstecker der Maschine in die Steckdose stecken und den Betriebsschalter einschalten.
2. Eine Probekopie im Heftermodus anfertigen, um die Verarbeitung und Heftung zu überprüfen.

Verifica di funzionamento

1. Collegare la spina del cavo di alimentazione della macchina alla presa a muro della rete elettrica e accendere l'interruttore principale di alimentazione.
2. Nel modo graffatrice eseguite una copia di prova per verificare la cucitura e la rifinitura.

操作確認


1. 将机器主机上的电源插头插入插座中，打开主电源开关。
2. 选择装订复印模式，确认装订分页器和装订器的操作状况。

動作確認

1. 機械本体の電源プラグをコンセントに差し込み、主電源スイッチを ON にする。
2. ステープルコピーをおこない、フィニッシャーおよびステープル動作を確認する。

www.tonerplus.com.ua

INSTALLATION GUIDE FOR JOB SEPARATOR



English

Supplied parts

| | | |
|---|--------------------|---|
| A | Job separator | 1 |
| B | LED PWB unit | 1 |
| C | Tray holder | 1 |
| D | Job separator tray | 1 |
| E | Left front cover | 1 |

| | | |
|---|----------------|---|
| F | Blindfold seal | 1 |
| G | Large pin | 1 |
| H | Small pin | 1 |
| I | M3 x 6 screw | 1 |

Français

Pièces fournies

| | | |
|---|----------------------------------|---|
| A | Séparateur de travaux | 1 |
| B | Unité LED PWB | 1 |
| C | Support de plateau | 1 |
| D | Plateau du séparateur de travaux | 1 |
| E | Capot avant gauche | 1 |

| | | |
|---|-----------------------|---|
| F | Étiquette de masquage | 1 |
| G | Grande goupille | 1 |
| H | Petite goupille | 1 |
| I | Vis M3 x 6 | 1 |

Español

Partes suministradas

| | | |
|---|----------------------------------|---|
| A | Separador de trabajos | 1 |
| B | Unidad PWB LED | 1 |
| C | Soporte de bandeja | 1 |
| D | Bandeja de separador de trabajos | 1 |
| E | Cubierta delantera izquierda | 1 |

| | | |
|---|-----------------|---|
| F | Sello ciego | 1 |
| G | Pasador grande | 1 |
| H | Pasador pequeño | 1 |
| I | Tornillo M3 x 6 | 1 |

Deutsch

Gelieferte Teile

| | | |
|---|----------------------|---|
| A | Job-Separator | 1 |
| B | LED-Platineneinheit | 1 |
| C | Fachhalter | 1 |
| D | Job-Separator-Fach | 1 |
| E | Linke Frontabdeckung | 1 |

| | | |
|---|-----------------|---|
| F | Blindaufkleber | 1 |
| G | Großer Stift | 1 |
| H | Kleiner Stift | 1 |
| I | M3 x 6 Schraube | 1 |

Italiano

Parti di fornitura

| | | |
|---|-------------------------------|---|
| A | Separatore lavori | 1 |
| B | Unità LED PWB | 1 |
| C | Supporto vassoio | 1 |
| D | Vassoio del separatore lavori | 1 |
| E | Coperchio frontale sinistro | 1 |

| | | |
|---|--------------------|---|
| F | Sigillo mascherina | 1 |
| G | Perno grande | 1 |
| H | Perno piccolo | 1 |
| I | Vite M3 x 6 | 1 |

简体中文

同装品

| | | |
|---|-----------|---|
| A | 作业分离器 | 1 |
| B | LED 电路板组件 | 1 |
| C | 托盘座 | 1 |
| D | 作业分离器托盘 | 1 |

| | | |
|---|-----------|---|
| E | 左前盖板 | 1 |
| F | 标贴 | 1 |
| G | 大卡销 | 1 |
| H | 小卡销 | 1 |
| I | 螺丝 M3 x 6 | 1 |

日本語

同梱品


| | | |
|---|-------------|---|
| A | ジョブセパレータ | 1 |
| B | LED 基板ユニット | 1 |
| C | トレイホルダ | 1 |
| D | ジョブセパレータトレイ | 1 |

| | | |
|---|-----------|---|
| E | 左前カバー | 1 |
| F | シール | 1 |
| G | ピン大 | 1 |
| H | ピン小 | 1 |
| I | ビス M3 x 6 | 1 |

www.tonerplus.com.ua

Precautions


- Be sure to remove any tape and/or cushioning material from supplied parts.
- Before installing the job separator, be sure to turn the main power switch of the machine off and unplug the power cable from the wall outlet.



Procedure

Removing the covers

1. Open the front cover (1) and left cover 1 (2).
2. Remove the clip holder (3).
3. Remove two screws (4) and release three latches (5) to remove the cover (6).



4. Release the latch (7) using a flat-head screwdriver to remove the cover (8).

Précautions

- Veillez à retirer les morceaux de bande adhésive et/ou les matériaux de rembourrage des pièces fournies.
- Avant d'installer le séparateur de travaux, veillez à mettre la machine hors tension et à débrancher le câble d'alimentation de la prise murale.

Procédure

Retrait des capots

1. Ouvrez le capot avant (1) et le capot gauche 1 (2).
2. Retirez le support à pince (3).
3. Retirez deux vis (4) et libérez trois verrous (5) pour retirer le capot (6).

4. Libérez le verrou (7) à l'aide d'un tournevis à tête plate pour retirer le capot (8).

Precauciones

- Asegúrese de despegar todas las cintas y/o material amortiguador de las partes suministradas.
- Antes de instalar el separador de trabajos, asegúrese de desconectar el interruptor principal de la máquina y desenchufar el cable eléctrico del tomacorriente de la pared.

Procedimiento

Desmontaje de las cubiertas

1. Abra la cubierta frontal (1) y la cubierta izquierda 1 (2).
2. Desmonte el soporte de clip (3).
3. Saque los dos tornillos (4) y suelte los tres pestillos (5) para desmontar la cubierta (6).

4. Suelte el pestillo (7) utilizando un destornillador de cabeza plana para desmontar la cubierta (8).

Vorsichtsmaßnahmen

- Entfernen Sie Klebeband und/oder Dämpfungsmaterial vollständig von den mitgelieferten Teilen.
- Schalten Sie unbedingt den Betriebsschalter der Maschine aus, und trennen Sie das Netzkabel von der Netzsteckdose, bevor Sie den Job-Separator installieren.

Verfahren

Entfernen der Abdeckungen

1. Die Frontabdeckung (1) und die linke Abdeckung 1 (2) öffnen.
2. Den Büroklammerhalter (3) entfernen.
3. Die zwei Schrauben (4) herausdrehen, und die drei Rasten (5) lösen, um die Abdeckung (6) abzunehmen.

4. Die Raste (7) mit einem Flachsraubenzieher lösen, um die Abdeckung (8) abzunehmen.

Precauzioni

- Accertarsi di rimuovere tutti i nastri adesivi e/o il materiale di imbottitura dalle parti fornite.
- Prima di installare il separatore lavori, assicurarsi di spegnere l'interruttore principale di alimentazione della macchina e scollegare la spina del cavo di alimentazione dalla presa a muro della rete elettrica.

Procedura

Rimozione dei coperchi

1. Aprite il coperchio anteriore (1) e il coperchio sinistro 1 (2).
2. Rimuovete il contenitore delle graffette (3).
3. Togliete due viti (4) e rilasciate i tre fermi (5) per rimuovere il coperchio (6).

4. Rilasciate il fermo (7) utilizzando un giravite a punta piatta per rimuovere il coperchio (8).

注意事項

- 如果同裝品上帶有固定膠帶、緩衝材料時務必揭下。
- 安裝分離器時，必須先關閉機器主機的主電源開關，並拔下電源插頭後，再進行安裝作業。

安裝步驟

拆下蓋板類

1. 打開前蓋板 (1) 和左蓋板 1 (2)。
2. 拆下夾子盒 (3)。
3. 卸下 2 個螺絲 (4)，鬆解 3 處嵌入板 (5)，然後，取下蓋板 (6)。

4. 用一字形螺絲刀等鬆解嵌入板 (7)，取下蓋板 (8)。

注意事項


- 同梱品に固定テープ、緩衝材が付いている場合は必ず取り外すこと。
- ジョブセパレータを設置する場合は、機械本体の主電源スイッチを OFF にし、電源プラグを抜いてから作業をおこなう。

設置手順


カバー類の取り外し

1. 前カバー (1) および左カバー 1 (2) を開く。
2. クリップ入れ (3) を取り外す。
3. ビス (4) 2 本を外し、はめ込み (5) 3 箇所を解除してカバー (6) を取り外す。


4. はめ込み (7) をマイナスドライバーなどで解除し、カバー (8) を取り外す。



5. Remove the screw (9) to remove the metal plate (10). The removed metal plate (10) is no longer required.



6. Release the latch (11) using a flat-head screwdriver and slide the cover (12) to the front to remove.
7. Remove the screw (13) to remove the cover (14).



8. Remove the screw (15) from the rear side of the machine to remove the cover (16).

5. Retirez la vis (9) pour déposer la plaque métallique (10). La plaque métallique déposée (10) n'est plus nécessaire.

6. Libérez le verrou (11) à l'aide d'un tournevis à tête plate, puis faites glisser le capot (12) vers l'avant pour le déposer.
7. Retirez la vis (13) pour déposer le capot (14).

8. Retirez la vis (15) du côté arrière de la machine pour déposer le capot (16).

5. Quite el tornillo (9) para desmontar la placa de metal (10). La placa de metal desmontada (10) ya no es necesaria.

6. Suelte el pestillo (11) utilizando un destornillador de cabeza plana y deslice la cubierta (12) hacia delante para desmontarla.
7. Saque el tornillo (13) para desmontar la cubierta (14).

8. Saque el tornillo (15) del lado trasero de la máquina para desmontar la cubierta (16).

5. Die Schraube (9) herausdrehen, um die Metallplatte (10) abzunehmen. Die abgenommene Metallplatte (10) wird nicht mehr benötigt.

6. Die Raste (11) mit einem Flachschaubenzieher lösen, und die Abdeckung (12) nach vorn schieben, um sie abzunehmen.
7. Die Schraube (13) herausdrehen, um die Abdeckung (14) abzunehmen.

8. Die Schraube (15) auf der Rückseite der Maschine herausdrehen, um die Abdeckung (16) abzunehmen.

5. Rimuovere la vite (9) per togliere la piastra di metallo (10). La piastra di metallo rimossa non è più necessaria.

6. Rilasciate il fermo (11) utilizzando un giravite a punta piatta e fate scivolare il coperchio (12) verso il lato anteriore per rimuoverlo.
7. Togliete la vite (13) per rimuovere il coperchio (14).

8. Togliete la vite (15) dal lato posteriore della macchina per rimuovere il coperchio (16).

5. 卸下 1 个螺丝 (9), 取下金属件 (10)。不安装金属件 (10)。

6. 用一字形螺丝刀等松解嵌入板 (11), 将盖板 (12) 向跟前拉并取下。
7. 卸下 1 个螺丝 (13), 取下盖板 (14)。


8. 卸下机器主机后面的 1 个螺丝 (15), 取下盖板 (16)。

TONER

5. ビス (9) 1 本を外し、金具 (10) を取り外す。金具 (10) は取り付けない。

6. はめ込み (11) をマイナスドライバーなどで解除し、カバー (12) を手前側に引いて取り外す。
7. ビス (13) 1 本を外し、カバー (14) を取り外す。

8. 機械本体後側のビス (15) 1 本を外し、カバー (16) を取り外す。



Installing the job separator

9. Insert the job separator (A) from the machine front and slide it to the left.
10. Fix the job separator (A) using two pins.
Front: Use the large pin (G).
Rear: Use the small pin (H).

Installation du séparateur de travaux

9. Insérez le séparateur de travaux (A) depuis l'avant de la machine et faites-le glisser vers la gauche.
10. Fixez le séparateur de travaux (A) à l'aide de deux goupilles.
Avant: Utilisez la grande goupille (G).
Arrière: Utilisez la petite goupille (H).

Instalación del separador de trabajos

9. Inserte el separador de trabajos (A) en el frente de la máquina y deslícelo a la izquierda.
10. Fije el separador de trabajo (A) utilizando dos pasadores.
Frente: Utilice el pasador grande (G).
Atrás: Utilice el pasador pequeño (H).

Installieren des Job-Separators

9. Den Job-Separator (A) von der Vorderseite der Maschine einführen und nach links schieben.
10. Den Job-Separator (A) mit zwei Stiften befestigen.
Vorn: Den großen Stift (G) verwenden.
Hinten: Den kleinen Stift (H) verwenden.

Installazione del separatore lavori


9. Inserire il separatore lavori (A) dal lato frontale della macchina e farlo scorrere a sinistra.
10. Fissare il separatore lavori (A) utilizzando due perni.
Lato frontale: utilizzare il perno grande (G).
Lato posteriore: utilizzare il perno piccolo (H).

安装作业分离器

9. 从机器主机前面插入作业分离器 (A)，向左侧滑动。
10. 用 2 个卡销固定作业分离器 (A)。
前面：大卡销 (G)
后面：小卡销 (H)

ジョブセパレータの取り付け

9. ジョブセパレータ (A) を機械本体前側から挿入し、左側にスライドする。
10. ジョブセパレータ (A) をピン 2 本で固定する。
前側：ピン大 (G)
後側：ピン小 (H)



11. Connect the connector (17) at the rear of the job separator to YC4 (18) on the engine PWB.
12. Loosen the screw (19) to make the drive unit of the job separator ready for starting to drive.
13. Tighten the screw (19).
14. Refit the cover (16) using the screw (15) removed in step 8.

-
11. Branchez le connecteur (17) situé à l'arrière du séparateur de travaux à YC4 (18) sur le PWB du moteur.
 12. Desserrez la vis (19) pour que l'unité d'entraînement du séparateur de travaux soit prête à démarrer.
 13. Resserrez la vis (19).
 14. Remettez le capot (16) en place en utilisant la vis (15) retirée auparavant lors de l'étape 8.


-
11. Conecte el conector (17) en el lado trasero del separador de trabajos a YC4 (18) en el PWB de motor.
 12. Afloje el tornillo (19) para que la unidad de accionamiento del separador de trabajos esté lista para accionar.
 13. Apriete el tornillo (19).
 14. Vuelva a colocar la cubierta (16) utilizando el tornillo (15) sacado en el paso 8.

-
11. Den Steckverbinder (17) auf der Rückseite des Job-Separators an YC4 (18) der Motorplatine anschließen.
 12. Die Schraube (19) lösen, um die Antriebseinheit des Job-Separators für den Antriebsstart bereit zu machen.
 13. Die Schraube (19) festziehen.
 14. Die Abdeckung (16) wieder mit der in Schritt 8 entfernten Schraube (15) anbringen.

-
11. Collegare il connettore (17) sul lato posteriore del separatore lavori al YC4 (18) del motore PWB.
 12. Allentare la vite (19) per preparare l'unità guida del separatore lavori al funzionamento.
 13. Stringere la vite (19).
 14. Rimettete a posto il coperchio (16) utilizzando la vite (15) rimossa nel passo 8.


-
11. 将作业分离器后面的插头 (17) 插在引擎主板的 YC4(18) 上。
 12. 松弛 1 个螺丝 (19)，使驱动组件处于始动状态。
 13. 然后，紧固 1 个螺丝 (19)。
 14. 在步骤 8 拆下的盖板 (16)，用 1 个螺丝 (15) 按原样装好。

-
11. ジョブセパレータ後側のコネクタ (17) をエンジン回路基板の YC4(18) に接続する。
 12. ビス (19) 1 本をゆるめ、駆動ユニットを駆動がかかる状態にする。
 13. ビス (19) 1 本を締める。
 14. 手順 8 で取り外したカバー (16) をビス (15) 1 本で元通り取り付け。



Attaching the LED PWB unit

15. Connect the connector (20) of the job separator to the connector (21) of the LED PWB unit (B).
16. Pass the wires through the space (22) and fix the LED PWB unit (B) using the M3 × 6 screw (I).



Installing the job separator tray

17. Insert the tray holder (C) into two openings (23) and then slide the holder to the right until it clicks.

Fixation de l'unité LED PWB

15. Branchez le connecteur (20) du séparateur de travaux au connecteur (21) de l'unité LED PWB (B).
16. Faites passer les fils par l'espace (22) et fixez l'unité LED PWB (B) à l'aide de la vis M3 × 6 (I).

Installation du plateau du séparateur de travaux

17. Insérez le support de plateau (C) dans les deux ouvertures (23), puis faites glisser le support vers la droite jusqu'à ce qu'il s'encliquète.

Colocación de la unidad PWB LED

15. Conecte el conector (20) del separador de trabajos en el conector (21) de la unidad PWB LED (B).
16. Pase los cables por el espacio (22) y fije la unidad PWB LED (B) utilizando el tornillo M3 × 6 (I).

Instalación de la bandeja de separador de trabajos

17. Inserte el soporte de bandeja (C) en dos aberturas (23) y deslice el soporte a la derecha hasta escuchar un chasquido.

Anbringen der LED-Platineneinheit

15. Den Steckverbinder (20) des Job-Separators mit dem Steckverbinder (21) der LED-Platineneinheit (B) verbinden.
16. Die Kabel durch den Spalt (22) führen, und die LED-Platineneinheit (B) mit der M3 × 6 Schraube (I) befestigen.

Installieren des Job-Separator-Fachs

17. Den Fachhalter (C) in die zwei Öffnungen (23) einführen, und dann den Halter nach rechts schieben, bis er mit einem Klicken einrastet.

Montaggio dell'unità LED PWB

15. Collegare il connettore (20) del separatore lavori al connettore (21) dell'unità LED PWB (B).
16. Fare passare i cavi attraverso lo spazio (22) e fissare l'unità LED PWB (B) utilizzando la vite M3 × 6 (I).

Installazione del vassoio del separatore lavori

17. Inserire il supporto del vassoio (C) nelle due aperture (23) e poi fare scorrere il supporto a destra fino a che non si mette in posizione con un clic.

安装 LED 电路板组件

15. 将作业分离器的插头 (20) 插在 LED 电路板组件 (B) 的插座 (21) 上。
16. 将电线穿过间隙 (22)，用 1 个螺丝 M3 × 6 (I) 固定 LED 电路板组件 (B)。

安装作业分离器托盘

17. 将托盘座 (C) 插入 2 处开口部 (23)，向右侧滑动直至听到咔叽声为止。




LED 基板ユニットの取り付け

15. ジョブセパレータのコネクタ (20) を LED 基板ユニット (B) のコネクタ (21) に接続する。
16. 電線をすきま (22) に通し、ビス M3 × 6 (I) 1 本で LED 基板ユニット (B) を取り付け。

ジョブセパレータトレイの取り付け

17. トレイホルダ (C) を開口部 (23) 2 箇所に挿入し、カチッと音がするまで右側にスライドする。



18. Install the job separator tray (D) from the front side of the machine.

Left: Insert the tray into the groove (24).

Right: Hang the hook (25) on the tray holder (C).

18. Installez le plateau du séparateur de travaux (D) depuis le côté avant de la machine.

Gauche: Insérez le plateau dans la rainure (24).

Droite: Suspendez le crochet (25) au support de plateau (C).

18. Instale la bandeja de separador de trabajos (D) desde el lado delantero de la máquina.

Izquierda: Inserte la bandeja en la ranura (24).

Derecha: Cuelgue el gancho (25) en el soporte de bandeja (C).

18. Das Job-Separator-Fach (D) von der Vorderseite der Maschine installieren.

Links: Das Fach in die Nut (24) einführen.

Rechts: Den Haken (25) in den Fachhalter (C) einhängen.

18. Installare il vassoio del separatore lavori (D) dal lato anteriore della macchina.

Lato sinistro: inserire il vassoio nell'incavo (24).

Lato destro: appendere il gancio (25) sul supporto del vassoio (C).

18. 从机器主机前面插入作业分离器托盘 (D)，进行安装。

左侧：插在沟槽 (24) 上。


右侧：将钩件 (25) 挂在托盘座 (C) 上。

TONER

18. ジョブセパレータトレイ (D) を機械本体前側から挿入し、取り付ける。

左側：溝 (24) に挿入する。


右側：フック (25) をトレイホルダ (C) に引っ掛ける。



Installing the left front cover

19. Release two latches (26) of the cover (6) removed in step 3 using a flat-head screwdriver to remove the lower clip holder (27).

20. Attach the lower clip holder (27) to the left front cover (E).



21. Replace the cover (8) removed in step 4.

22. Install the left front cover (E) using the two screws (4) removed in step 3.

23. Replace the clip holder (3) removed in step 2.

24. Close left cover 1 (2) and the front cover (1).

Installation du capot avant gauche

19. Libérez les deux verrous (26) du capot (6) retiré auparavant lors de l'étape 3 en utilisant un tournevis à tête plate pour retirer le support de pince inférieur (27).

20. Fixez le support à pince inférieur (27) sur le capot avant gauche (E).

21. Remettez en place le capot (8) retiré auparavant lors de l'étape 4.

22. Installez le capot avant gauche (E) à l'aide des deux vis (4) retirées auparavant lors de l'étape 3.

23. Remettez en place le support à pince (3) retiré auparavant lors de l'étape 2.

24. Refermez le capot gauche 1 (2) et le capot avant (1).

Instalación de la cubierta delantera izquierda

19. Suelte los dos pestillos (26) de la cubierta (6) desmontada en el paso 3 utilizando el destornillador de punta plana para desmontar el soporte de clip inferior (27).

20. Coloque el soporte de clip inferior (27) en la cubierta delantera izquierda (E).

21. Vuelva a colocar la cubierta (8) desmontada en el paso 4.

22. Instale la cubierta delantera izquierda (E) utilizando los dos tornillos (4) sacados en el paso 3.

23. Vuelva a colocar el soporte de clip (3) desmontado en el paso 2.

24. Cierre la cubierta izquierda 1 (2) y la cubierta frontal (1).

Installieren der linken Frontabdeckung

19. Die zwei Rasten (26) der in Schritt 3 entfernten Abdeckung (6) mit einem Flachschrabenzieher lösen, um den unteren Büroklammerhalter (27) abzunehmen.

20. Den unteren Büroklammerhalter (27) an der linken Frontabdeckung (E) anbringen.

21. Die in Schritt 4 entfernte Abdeckung (8) wieder anbringen.

22. Die linke Frontabdeckung (E) mit den in Schritt 3 entfernten zwei Schrauben (4) installieren.

23. Den in Schritt 2 entfernten Büroklammerhalter (3) wieder anbringen.

24. Die linke Abdeckung 1 (2) und die Frontabdeckung (1) schließen.

Installazione del coperchio frontale sinistro

19. Rilasciate due fermi (26) del coperchio (6) rimosso nel passo 3 utilizzando un giravite a punta piatta per rimuovere il contenitore inferiore delle graffette (27).

20. Montare il contenitore inferiore delle graffette (27) al coperchio frontale sinistro (E).

21. Rimettere a posto il coperchio (8) rimosso nel passo 4.

22. Installare il coperchio frontale sinistro (E) utilizzando due viti (4) rimosse nel passo 3.

23. Rimettere al suo posto il contenitore delle graffette (3) rimosso nel passo 2.

24. Chiudete il coperchio sinistro 1 (2) e il coperchio anteriore (1).

安装左前盖板

19. 用一字形螺丝刀等松解在步骤 3 卸下的盖板 (6) 的 2 处嵌入板 (26), 并取下夹子盒下 (27)。

20. 将夹子盒下 (27) 装在左前盖板 (E) 上。

21. 将步骤 4 拆下的盖板 (8) 按原样装好。

22. 用步骤 3 卸下的 2 个螺丝 (4) 装上左前盖板 (E)。

23. 在步骤 2 拆下的夹子盒 (3) 按原样装好。

24. 关闭左盖板 1 (2) 和前盖板 (1)。

左前カバーの取り付け

19. 手順 3 で取り外したカバー (6) のはめ込み (26) 2 箇所をマイナスドライバーなどで解除し、クリップ入れ下 (27) を取り外す。


20. クリップ入れ下 (27) を左前カバー (E) に取り付ける。

21. 手順 4 で取り外したカバー (8) を元通り取り付ける。

22. 手順 3 で外したビス (4) 2 本で左前カバー (E) を取り付ける。

23. 手順 2 で取り外したクリップ入れ (3) を元通り取り付ける。

24. 左カバー 1 (2) および前カバー (1) を閉じる。



Adhering the blindfold seal (For models with monochrome touch panel only)

25. Clean the left front cover with alcohol and then adhere the blindfold seal (F).

Checking the operation

1. Connect the power plug of the machine to the wall outlet and turn the main power switch on.
2. Specify the output tray to the job separator tray from the system menu.

3. Make a proof copy to check that a copy is ejected to the job separator tray.

Collage de l'étiquette de masquage (pour les modèles équipés d'un écran tactile monochrome seulement)

25. Nettoyez le capot avant gauche avec de l'alcool, puis collez l'étiquette de masquage (F).

Vérification du fonctionnement

1. Insérer la fiche d'alimentation de la machine dans la prise murale et mettre la machine sous tension.
2. Définissez le bac de sortie sur le plateau du séparateur de travaux dans le menu système.

3. Effectuez une copie de test pour vérifier si une copie est bien éjectée sur le plateau du séparateur de travaux.

Pegado del sello ciego (Sólo modelos con panel de toque monocromático)

25. Limpie la cubierta delantera izquierda con alcohol y pégue el sello ciego (F).

Verificación del funcionamiento

1. Conecte el enchufe eléctrico de la máquina en un tomacorriente de la pared y conecte el interruptor principal.
2. Especifique como bandeja de salida a la bandeja del separador de trabajos en el menú del sistema.

3. Haga una copia de prueba para verificar que la copia sale a la bandeja del separador de trabajos.

Anbringen des Blindaufklebers (nur für Modelle mit Monochrom-Sensorbildschirm)

25. Die linke Frontabdeckung mit Alkohol reinigen, und dann den Blindaufkleber (F) anbringen.

Überprüfen des Betriebs

1. Den Netzstecker der Maschine in die Steckdose stecken und den Betriebsschalter einschalten.
2. Das Job-Separator-Fach über das Systemmenü als Ausgabefach angeben.

3. Eine Probekopie anfertigen, um zu prüfen, ob eine Kopie in das Job-Separator-Fach ausgeworfen wird.

Applicate il sigillo mascherina (solo per i modelli con pannello monocromatico a sfioramento)

25. Pulite il coperchio frontale sinistro con alcol e poi applicate il sigillo mascherina (F).

Verifica di funzionamento

1. Collegare la spina del cavo di alimentazione della macchina alla presa a muro della rete elettrica e accendere l'interruttore principale di alimentazione.
2. Specificare il vassoio di uscita al vassoio del separatore lavori mediante il menu sistema.

3. Effettuare una copia di prova per verificare che essa venga espulsa sul vassoio del separatore lavori.

貼上标貼

(只限单色触控式面板机)

25. 用酒精清洁后, 贴上标贴 (F)。

操作确认

1. 将机器主机上的电源插头插入插座中, 打开主电源开关。
2. 将系统菜单的排纸处设定在作业分离器托盘上。

3. 进行测试复印, 确认纸张是否排在作业分离器托盘上。

シールの貼り付け

(モノクロタッチパネル機のみ)


25. アルコール清掃後、シール (F) を貼り付ける。

動作確認

1. 機械本体の電源プラグをコンセントに差し込み、主電源スイッチを ON にする。
2. システムメニューの排紙先をジョブセパレータトレイに設定する。

3. テストコピーをおこない、用紙がジョブセパレータトレイに排出されるかどうか確認する。

INSTALLATION GUIDE FOR FAX System (P)



English

Supplied parts

| | | |
|---|--|---|
| A | FAX unit | 1 |
| B | JATE label (100 V specifications only) | 1 |
| C | FCC approval label (120 V specifications only) | 1 |

| | | |
|---|---|---|
| D | Line approval label (Australian/New Zealand specifications only) | 2 |
| E | Alphabet label (except for 100 V specifications) | 1 |
| F | Modular connector cable (100 V/120 V/ Australian specifications only) | 1 |
| G | M3 x 6 screw | 3 |
| I | PTT label (110V specification only) | 1 |

Option

| | | |
|---|---------------------|---|
| H | Memory DIMM (32 MB) | 1 |
|---|---------------------|---|

100 V/110V/120 V/Australian/New Zealand specifications only

See page 10 for adhering the JATE label (B)/ PTT label (I)/ FCC approval label (C)/ Line approval label (D).

Français

Pièces fournies

| | | |
|---|--|---|
| A | Unité FAX | 1 |
| B | Étiquette JATE (spécifications 100 V seulement) | 1 |
| C | Étiquette d'approbation FCC (spécifications 120 V seulement) | 1 |

| | | |
|---|---|---|
| D | Étiquette d'approbation de ligne (spécifications pour l'Australie/Nouvelle-Zélande seulement) | 2 |
| E | Étiquette de l'alphabet (sauf spécifications 100 V) | 1 |
| F | Câble du connecteur modulaire (spécifications pour l'Australie/100 V/120 V seulement) | 1 |
| G | Vis M3 x 6 | 3 |

Option

| | | |
|---|----------------------|---|
| H | Mémoire DIMM (32 MB) | 1 |
|---|----------------------|---|

Spécifications pour l'Australie/Nouvelle-Zélande/100 V/120 V seulement

Pour plus de détails concernant l'apposition de l'étiquette JATE (B)/de l'étiquette d'approbation FCC (C)/de l'étiquette d'approbation de ligne (D), se reporter à la page 10.

Español

Partes suministradas

| | | |
|---|---|---|
| A | Unidad de FAX | 1 |
| B | Etiqueta JATE (sólo especificaciones de 100V) | 1 |
| C | Etiqueta de aprobación de FCC (sólo especificaciones de 120V) | 1 |

| | | |
|---|---|---|
| D | Etiqueta de aprobación de línea (sólo especificaciones Australianas/Nuevo Zelandesas) | 2 |
| E | Etiqueta de alfabeto (excepto para especificaciones de 100V) | 1 |
| F | Cable conector modular (sólo especificaciones de 100V/120V/ Australianas) | 1 |
| G | Tornillo M3 x 6 | 3 |

Opción

| | | |
|---|----------------------|---|
| H | Memoria DIMM (32 MB) | 1 |
|---|----------------------|---|

Sólo especificaciones para 100V/120V/ Australianas/Nuevo Zelandesas

Vea la página 10 para pegar la etiqueta JATE (B)/etiqueta de aprobación FCC (C)/etiqueta de aprobación de línea (D).

Deutsch

Gelieferte Teile

| | | |
|---|---|---|
| A | FAX-Einheit | 1 |
| B | JATE-Aufkleber (nur 100-V-Spezifikationen) | 1 |
| C | FCC-Genehmigungsaufkleber (nur 120-V-Spezifikationen) | 1 |

| | | |
|---|---|---|
| D | Leitungsgenehmigungsaufkleber (nur Australien/Neuseeland-Spezifikationen) | 2 |
| E | Alphabetaufkleber (außer 100-V-Spezifikationen) | 1 |
| F | Modulkabel (nur 100-V/120-V/Australien-Spezifikationen) | 1 |
| G | M3 x 6 Schraube | 3 |

Option

| | | |
|---|-----------------------|---|
| H | Speicher-DIMM (32 MB) | 1 |
|---|-----------------------|---|

Nur 100-V/120-V/Australien/Neuseeland-Spezifikationen

Angaben zur Anbringung von JATE-Aufkleber (B)/FCC-Genehmigungsaufkleber (C)/ Leitungsgenehmigungsaufkleber (D) auf Seite 10.

Italiano

Parti di fornitura

| | | |
|---|---|---|
| A | Unità FAX | 1 |
| B | Etichetta JATE (solo specifiche per 100 V) | 1 |
| C | Etichetta di approvazione FCC (solo specifiche per 120 V) | 1 |

| | | |
|---|---|---|
| D | Etichetta di approvazione linea (solo specifiche Australiano/Nuova Zelanda) | 2 |
| E | Etichetta alfabetica (eccetto specifiche per 100 V) | 1 |
| F | Cavo connettore modulare (solo specifiche per 100 V/120 V/Australiano) | 1 |
| G | Vite M3 x 6 | 3 |

Opzioni

| | | |
|---|----------------------|---|
| H | Memoria DIMM (32 MB) | 1 |
|---|----------------------|---|

Solo specifiche per 100 V/120 V/Australiano/ Nuova Zelanda

Vedere pagina 10 per l'applicazione dell'etichetta JATE (B)/dell'etichetta di approvazione FCC (C)/Dell'etichetta di approvazione linea (D).

简体中文

同装品

| | | |
|---|--------------------------|---|
| A | FAX 组件 | 1 |
| B | JATE 认可标签 (仅适用于 100V 型号) | 1 |
| C | FCC 认可标签 (仅适用于 120V 型号) | 1 |

| | | |
|---|-------------------------------|---|
| D | 电线认可标签 (仅适用于澳大利亚 / 新西兰型号) | 2 |
| E | 英文字母标签 (100V 型号以外) | 1 |
| F | 电话线 (仅适用于 100V/120V / 澳大利亚型号) | 1 |
| G | 螺丝 M3 x 6 | 3 |

选购件

| | | |
|---|------------------|---|
| H | 内存模组 DIMM (32MB) | 1 |
|---|------------------|---|

仅适用于 100V/120V / 澳大利亚 / 新西兰型号
有关 JATE 认可标签 (B)/FCC 认可标签 (C)/ 电线认可标签 (D) 的粘贴方法, 请参照第 10 页。

日本語

同梱品

| | | |
|---|------------------------|---|
| A | FAX ユニット | 1 |
| B | JATE 認可ラベル (100V 仕様のみ) | 1 |
| C | FCC 認可ラベル (120V 仕様のみ) | 1 |


| | | |
|---|------------------------------------|---|
| D | 回線認可ラベル (オーストラリア / ニュージーランド仕様のみ) | 2 |
| E | アルファベットラベル (100V 仕様以外) | 1 |
| F | モジュラーコード (100V, 120V, オーストラリア仕様のみ) | 1 |
| G | ビス M3 x 6 | 3 |
| I | PTT ラベル (110V 仕様のみ) | 1 |

オプション

| | | |
|---|-----------------|---|
| H | メモリ DIMM (32MB) | 1 |
|---|-----------------|---|

100V 仕様・110V 仕様・120V 仕様・オーストラリア / ニュージーランド仕様のみ

JATE 認可ラベル (B)/PTT ラベル (I)/FCC 認可ラベル (C)/ 回線認可ラベル (D) の貼り付けについては、10 ページを参照する。



Precautions

- Be sure to remove any tape and/or cushioning material from supplied parts.
- Before installing the FAX System, be sure to turn the main power switch of the machine off and unplug the power cable from the wall outlet.
- Do not touch the PWB with bare hands or something which has the static electricity.

Procedure

Installing the optional memory DIMM

1. Insert the memory DIMM (H) at an angle into the memory slot (1) on the FAX unit (A).
The notch (2) of the memory DIMM (H) is positioned to the projection (3) of the memory slot (1) on the FAX unit (A). <1>
2. Descend the memory DIMM (H) in the direction of arrows until it clicks. <2>

Précautions

- Veillez à retirer les morceaux de bande adhésive et/ou les matériaux de rembourrage des pièces fournies.
- Avant d'installer le système FAX, veiller à mettre la machine hors tension et à débrancher le câble d'alimentation de la prise murale.
- Ne pas toucher le PWB avec les mains nues ou avec un objet possédant de l'électricité statique.

Procédure

Installation de la mémoire DIMM en option

1. Insérer la mémoire DIMM (H) en l'inclinant dans la fente de mémoire (1) de l'unité FAX (A).
L'encoche (2) de la mémoire DIMM (H) est placée sur la saillie (3) de la fente de mémoire (1) de l'unité FAX (A). <1>
2. Abaisser la mémoire DIMM (H) dans le sens indiqué par les flèches jusqu'à ce qu'elle s'encliquète. <2>

Precauciones

- Asegúrese de despegar todas las cintas y/o material amortiguador de las partes suministradas.
- Antes de instalar el sistema de FAX, asegúrese de desconectar el interruptor principal de la máquina y desenchufar el cable eléctrico del tomacorriente de la pared.
- No toque el PWB con las manos desnudas o algo que tenga electricidad estática.

Procedimiento

Instalación de la memoria DIMM opcional

1. Inserte la memoria DIMM a un ángulo en la ranura de memoria (1) o unidad de FAX (A).
La muesca (2) de la memoria DIMM (H) está ubicada en la saliente (3) de la ranura de memoria (1) en la unidad de FAX (A). <1>
2. Baje la memoria DIMM (H) en el sentido de las flechas hasta que se escuche un chasquido. <2>

Vorsichtsmaßnahmen

- Entfernen Sie Klebeband und/oder Dämpfungsmaterial vollständig von den mitgelieferten Teilen.
- Schalten Sie unbedingt den Betriebsschalter der Maschine aus, und trennen Sie das Netzkabel von der Netzsteckdose, bevor Sie das FAX-System installieren.
- Berühren Sie die PWB nicht mit bloßen Händen oder einem statisch geladenen Gegenstand.

Verfahren

Installieren des optionalen Speicher-DIMM

1. Das Speicher-DIMM (H) schräg in den Speichersteckplatz (1) an der FAX-Einheit (A) einführen.
Die Kerbe (2) des Speicher-DIMM (H) muss auf den Vorsprung (3) des Speichersteckplatzes (1) an der FAX-Einheit (A) ausgerichtet sein. <1>
2. Das Speicher-DIMM (H) in Pfeilrichtung andrücken, bis es einrastet. <2>

Precauzioni

- Accertarsi di rimuovere tutti i nastri adesivi e/o il materiale di imbottitura dalle parti fornite.
- Prima di installare il sistema FAX, assicurarsi di spegnere l'interruttore principale di alimentazione della macchina e scollegare la spina del cavo di alimentazione dalla presa a muro della rete elettrica.
- Non toccare il PWB a mani nude o con un oggetto caricato elettrostaticamente.

Procedura

Installazione della memoria DIMM opzionale

1. Inserire la memoria DIMM (H) inclinata nello slot della memoria (1) dell'unità FAX (A).
L'incavo (2) della memoria DIMM (H) è posizionato verso la sporgenza (3) dello slot della memoria (1) sull'unità FAX (A). <1>
2. Far scendere la memoria DIMM (H) nella direzione delle frecce finché non si mette in posizione con uno scatto. <2>

注意事項

- 如果同裝品上帶有固定膠帶、緩衝材料時務必揭下。
- 安裝傳真組件時，必須先關閉機器主機的主電源開關，並拔下電源插頭後，再進行安裝作業。
- 切勿用裸手或帶靜電的物品觸碰電路板。

安裝步驟

安裝選購件內存模組

1. 將內存模組 DIMM(H) 斜行插入 FAX 組件 (A) 上的內存模組插入口中 (1)。
必須使內存模組 DIMM(H) 的缺口 (2) 與 FAX 組件 (A) 的內存模組插入口 (1) 的突起部 (3) 相一致後再插入。<1>
2. 朝箭頭方向按下內存模組 DIMM(H) 直至聽見咔叭聲為止。<2>


注意事項

- 同梱品に固定テープ、緩衝材が付いている場合は必ず取り外すこと。
- FAX System を設置する場合は、必ず機械本体の主電源スイッチを OFF にし、電源プラグを抜いてから作業をおこなう。
- 基板に素手または静電気を帯びているもので触れないこと。

設置手順


オプションメモリの取り付け

1. メモリ DIMM(H) を FAX ユニット (A) のメモリ挿入口 (1) に斜めに挿入する。
メモリ DIMM(H) の切り欠き (2) と FAX ユニット (A) のメモリ挿入口 (1) の突起 (3) を一致させて挿入する。<1>
2. カチッと音がするまで、矢印方向にメモリ DIMM(H) を倒す。<2>




Removing the covers

3. If the printing system has been installed, remove three screws (4) to remove the printing system (5).



4. Remove nine screws (6) to remove the cover (7).



5. Remove two screws (8) to remove the cover (9).

Retrait des couvercles

3. Si le système d'imprimante a été installé, retirer les trois vis (4) pour retirer le système d'imprimante (5).

4. Retirer les neuf vis (6) pour retirer le couvercle (7).

5. Retirer les deux vis (8) pour retirer le couvercle (9).

Desmontaje de las cubiertas

3. Si se instaló el sistema de impresión, quite los tres tornillos (4) para desmontar el sistema de impresión (5).

4. Quite los nueve tornillos (6) para desmontar la cubierta (7).

5. Quite los dos tornillos (8) para desmontar la cubierta (9).

Entfernen der Abdeckungen

3. Wenn das Drucksystem installiert worden ist, die drei Schrauben (4) entfernen, um das Drucksystem (5) abzunehmen.

4. Die neun Schrauben (6) herausdrehen, um die Abdeckung (7) abzunehmen.

5. Die zwei Schrauben (8) herausdrehen, um die Abdeckung (9) abzunehmen.

Rimozione dei coperchi

3. Se il sistema di stampa (5) è stato installato, togliere tre viti (4) per rimuoverlo.

4. Togliere nove viti (6) per rimuovere il coperchio (7).

5. Togliere due viti (8) per rimuovere il coperchio (9).

拆下盖板

3. 装有打印组件时, 拆下 3 个螺丝 (4), 然后然后拆下打印组件 (5)。

4. 拆下 9 个螺丝 (6), 然后拆下盖板 (7)。

5. 拆下 2 个螺丝 (8), 然后拆下盖板 (9)。


TONER

カバー類の取り外し


3. プリンティングシステムを装着している場合は、ビス (4) 3 本を外してプリンティングシステム (5) を取り外す。

4. ビス (6) 9 本を外し、カバー (7) を取り外す。

5. ビス (8) 2 本を外し、カバー (9) を取り外す。



6. Remove wires from two wire saddles (10) of the shield box inner side.



7. Remove five screws (11) to remove the shield box (12).

6. Retirer les fils des deux serre-fils (10) du côté intérieur de la boîte de blindage.

7. Retirer les cinq vis (11) pour retirer la boîte de blindage (12).

6. Desmonte los cables de los dos asientos de cable (10) del lado interior de la caja blindada.

7. Quite los cinco tornillos (11) para desmontar la caja blindada (12).

6. Die Kabel von den beiden Kabelschellen (10) an der Innenseite der Abschirmungsbox entfernen.

7. Die fünf Schrauben (11) herausdrehen, um die Abschirmungsbox (12) abzunehmen.

6. Rimuovere i fili dalle due selle dei fili (10) nel lato interno della scatola protettiva.

7. Togliere cinque viti (11) per rimuovere la scatola protettiva (12).


6. 打开 2 处屏蔽盒内侧的鞍型夹 (10) 后拆下电线。

7. 拆下 5 个螺丝 (11)，然后拆下屏蔽盒 (12)。

TONER

6. シールドボックス内側のワイヤーサドル (10) 2 箇所から電線を外す。

7. ビス (11) 5 本を外し、シールドボックス (12) を取り外す。



Installing the FAX unit

8. Insert the FAX unit (A) from the bottom and connect the connector (13) of the FAX unit to the YC9 connector (14) of the main PWB.

Do not allow the FAX unit (A) to contact the sponge (15).

9. Fix the FAX unit (A) using two M3 x 6 screws (G).

Installation de l'unité FAX

8. Insérer l'unité FAX (A) à partir du bas, et brancher le connecteur (13) de l'unité FAX au connecteur YC9 (14) du PWB principal.

Veiller à ce que l'unité FAX (A) n'entre pas en contact avec l'éponge (15).

9. Fixer l'unité FAX (A) en utilisant deux vis M3 x 6 (G).

Instalación de la unidad de FAX

8. Inserte la unidad de FAX (A) de la parte inferior y conecte el conector (13) de la unidad de FAX en el conector YC9 (14) del PWB principal.

No permita que la unidad de FAX (A) entre en contacto con la esponja (15).

9. Fije la unidad de FAX (A) utilizando dos tornillos M3 x 6 (G).

Installieren der FAX-Einheit

8. Die FAX-Einheit (A) von der Unterseite einführen, und den Stecker (13) der FAX-Einheit an den Stecker YC9 (14) der Haupt-PWB anschließen.

Die FAX-Einheit (A) darf nicht den Schaumstoff (15) berühren.

9. Die FAX-Einheit (A) mit den zwei M3 x 6 Schrauben (G) befestigen.

Installazione dell'unità FAX

8. Inserire l'unità FAX (A) dal basso e collegare il connettore (13) dell'unità FAX al connettore YC9 (14) del PWB principale.

Non permettere all'unità FAX (A) di toccare la spugna (15).

9. Fissare l'unità FAX (A) utilizzando due viti M3 x 6 (G).

安装 FAX 组件

8. 将 FAX 组件 (A) 从下侧插入, 并将 FAX 组件的插头 (13) 与主电路板的 YC9 (14) 连接。

FAX 组件 (A) 不得与海绵 (15) 接触。


9. 用 2 个螺丝 M3 x 6 (G) 固定 FAX 组件 (A)。

FAX ユニットの取り付け


8. FAX ユニット (A) を下側から挿入し、FAX ユニットのコネクタ (13) を主回路基板の YC9 (14) に接続する。

FAX ユニット (A) がスポンジ (15) に接触しないこと。

9. ビス M3 x 6 (G) 2 本で FAX ユニット (A) を固定する。



10. Replace the shield box (12) using five screws (11) removed in step 7.
Insert the projection (16) on the upper side of the shield box.
Be careful not to catch the wires (17) at the right side of the shield box (12).



11. Secure the wires with two wire saddles (10) as before.

10. Remettre la boîte de blindage (12) en place en utilisant les cinq vis (11) retirées auparavant lors de l'étape 7.
Insérer la saillie (16) sur le côté supérieur de la boîte de blindage.
Veiller à ne pas coincer les fils (17) situés sur le côté droit de la boîte de blindage (12).

11. Fixer les fils en utilisant deux serre-fils (10), comme auparavant.

10. Cambie la caja blindada (12) utilizando los cinco tornillos (11) desmontados en el paso 7.
Inserte la saliente (16) en el lado superior de la caja blindada.
Tenga cuidado de no atrapar los cables (17) en el lado derecho de la caja blindada (12).

11. Asegure los cables con dos asientos de cable (10) como antes.

10. Die Abschirmungsbox (12) wieder mit den in Schritt 7 entfernten fünf Schrauben (11) anbringen.
Den Vorsprung (16) an der Oberseite der Abschirmungsbox einführen.
Darauf achten, dass die Kabel (17) nicht an der rechten Seite der Abschirmungsbox (12) hängen bleiben.

11. Die Kabel wie zuvor mit den zwei Kabelschellen (10) sichern.

10. Rimettere a posto la scatola protettiva (12) utilizzando le viti (11) rimosse nel passo 7.
Inserire la sporgenza (16) sul lato superiore della scatola protettiva.
Fare attenzione a non intrappolare i fili (17) sul lato destro della scatola protettiva (12).

11. Fissare i fili con le due selle dei fili (10) come prima.


10. 用 5 个螺丝 (11) 将在步骤 7 中拆下的屏蔽盒 (12) 装回原处。
 插入屏蔽盒上侧的突起 (16)。
注意不得夹住屏蔽盒 (12) 右侧的电线 (17)。

11. 将电线按原样从 2 处鞍型夹 (10) 插入。


TONER
www.tonerplus.com.ua

10. 手順 7 で取り外したシールドボックス (12) をビス (11) 5 本で元通り取り付け。
 シールドボックス上側の突起 (16) を挿入する。
シールドボックス (12) 右側の電線 (17) を挟み込まないように注意する。

11. 電線をワイヤーサドル (10) 2 箇所に元通り挿入する。



- 12.** Remove the modular cover (18) from the cover (9) removed in step 5.
100 V specifications: Remove three covers (L, T1, T2)
New Zealand specifications: Remove upper one cover (L)
Except for 100 V/New Zealand specifications: Remove upper two covers (L, T1)



- 13.** Replace the cover (9) using three screws.
Upper/Lower: Use two screws (8) removed in step 5.
Center: M3 × 6 screw (G)

- 14.** Replace the cover (7) using nine screws (6) removed in step 4.

- 15.** Replace the printing system (5) using three screws (4) if removed in step 3.

- 12.** Retirer le couvercle modulaire (18) du couvercle (9) retiré auparavant lors de l'étape 5.
Spécifications 100 V: Retirer trois couvercles (L, T1, T2)
Spécifications pour la Nouvelle-Zélande: Retirer un couvercle supérieur (L)
Sauf spécifications pour la Nouvelle-Zélande/100 V: Retirer deux couvercles supérieurs (L, T1)

- 13.** Remettre le couvercle (9) en place en utilisant trois vis.
Supérieur/Inférieur: Utilisez les deux vis (8) retirées auparavant lors de l'étape 5.
Centre: Vis M3 × 6 (G)

- 14.** Remettre le couvercle (7) en place en utilisant les neuf vis (6) retirées auparavant lors de l'étape 4.

- 15.** Remettre le système d'imprimante (5) en place en utilisant les trois vis (4) retirées auparavant lors de l'étape 3.

- 12.** Desmonte la cubierta modular (18) de la cubierta (9) desmontadas en el paso 5.
Especificaciones de 100V: Desmonte las tres cubiertas (L, T1, T2)
Especificaciones Nuevo Zelandesas: Desmonte una cubierta (L)
Excepto para especificaciones de 100V/Nuevo Zelandesas: Desmonte las dos cubiertas superiores (L, T1)

- 13.** Vuelva a colocar la cubierta (9) utilizando tres tornillos.
Superior/Inferior: Utilice los dos tornillos (8) quitados en el paso 5.
Centro: Tornillo M3 × 6 (G)

- 14.** Vuelva a colocar la cubierta (7) utilizando los nueve tornillos (6) quitados en el paso 4.

- 15.** Vuelva a colocar el sistema de impresión (5) utilizando los tres tornillos (4) quitados en el paso 3.

- 12.** Die Modulabdeckung (18) von der in Schritt 5 entfernten Abdeckung (9) entfernen.
100-V-Spezifikationen: Drei Abdeckungen (L, T1, T2) entfernen
Neuseeland-Spezifikationen: Die obere Abdeckung (L) entfernen
Außer 100-V/Neuseeland-Spezifikationen: Die oberen zwei Abdeckungen (L, T1) entfernen

- 13.** Die Abdeckung (9) mit drei Schrauben anbringen.
Oben/Unten: Die in Schritt 5 entfernten zwei Schrauben (8) benutzen.
Mitte: M3 × 6 Schraube (G)

- 14.** Die Abdeckung (7) wieder mit den in Schritt 4 entfernten neun Schrauben (6) anbringen.

- 15.** Das Drucksystem (5) wieder mit den in Schritt 3 entfernten drei Schrauben (4) anbringen.

- 12.** Rimuovere il coperchio modulare (18) dal coperchio (9) rimosso nel passo 5.
Specifiche per 100 V: Rimuovere tre coperchi (L, T1, T2)
Specifiche per Nuova Zelanda: Rimuovere un coperchio superiore (L)
Eccetto specifiche per 100 V/Nuova Zelanda: Rimuovere due coperchi superiori (L, T1)

- 13.** Rimettere a posto il coperchio (9) utilizzando tre viti.
Superiore/Inferiore: utilizzare le due viti (8) rimosse nel passo 5.
Centro: Vite M3 × 6 (G)

- 14.** Rimettere a posto il coperchio (7) utilizzando le nove viti (6) rimosse nel passo 4.

- 15.** Rimettere a posto il sistema di stampa (5) utilizzando tre viti (4) se è stato rimosso nel passo 3.

- 12.** 拆下在步骤 5 中拆下的盖板 (9) 的电话线盖板 (18)。
100V 型号: 3 处 (L、T1、T2)
新西兰型号: 上侧 1 处 (L)
100V/新西兰型号以外: 上侧 2 处 (L、T1)

- 13.** 用 3 个螺丝将盖板 (9) 按原样装回。
上、下侧: 用在步骤 5 中拆下的 2 个螺丝 (8)
中央: 螺丝 M3 × 6 (G)

- 14.** 用 9 个螺丝 (6) 将在步骤 4 中拆下的盖板 (7) 装回原处。


- 15.** 用 3 个螺丝 (4) 将在步骤 3 中拆下的打印组件 (5) 装回原处。

- 12.** 手順 5 で取り外したカバー (9) のモジュラーカバー (18) を取り外す。
100V 仕様: 3 箇所 (L、T1、T2)
ニュージーランド仕様: 上側 1 箇所 (L)
100V・ニュージーランド仕様以外: 上側 2 箇所 (L、T1)

- 13.** ビス 3 本でカバー (9) を元通り取り付け。
上・下側: 手順 5 で外したビス (8) 2 本
中央: ビス M3 × 6 (G)


- 14.** 手順 4 で取り外したカバー (7) をビス (6) 9 本で元通り取り付け。

- 15.** 手順 3 でプリンティングシステム (5) を取り外した場合は、ビス (4) 3 本でプリンティングシステム (5) を元通り取り付け。



Adhering the alphabet labels (except for 100 V specifications)

- 16.** Wipe the area above the numeric keys at the right side of the operation panel with alcohol and adhere the alphabet labels (E).
For Asia and Oceania, adhere PQRS TUV WXYZ label, and do not use PRS TUV WXY and OPER labels.



Connecting the machine to the telephone line

- 17.** Plug the modular connector cable (20) into the line terminal (19), and then connect the line terminal to the telephone line.
For 100 V/120 V/Australian specifications, use the supplied modular connector cable (F).

Apposition des étiquettes de l'alphabet (sauf spécifications 100 V)

- 16.** Nettoyer la surface au-dessus des touches numériques à droite du panneau de commande avec de l'alcool et y apposer les étiquettes de l'alphabet (E).
En Asie et Océanie, apposer l'étiquette PQRS TUV WXYZ, et pas les étiquettes PRS TUV WXY et OPER.

Connexion de la machine à la ligne de téléphone

- 17.** Brancher le câble du connecteur modulaire (20) à la borne de la ligne (19), puis brancher la borne de la ligne à la ligne de téléphone.
Pour les spécifications pour l'Australie/100 V/120 V, utiliser le câble du connecteur modulaire fourni (F).

Pegado de las etiquetas de alfabeto (excepto para las especificaciones de 100V)

- 16.** Limpie la zona situada encima de las teclas numéricas, en el lado derecho del panel de trabajo, y pegue aquí las etiquetas de alfabeto (E).
Para Asia y Oceanía, pegue la etiqueta PQRS TUV WXYZ y no utilice las etiquetas PRS TUV WXY y OPER.

Conexión de la máquina a una línea telefónica

- 17.** Enchufe el cable conector modular (20) en el terminal de línea (19) y después conecte el terminal de línea a la línea telefónica.
Para las especificaciones de 100 V/120 V/ Australianas, utilice el cable conector modular entregado (F).

Anbringen der Alphabetaufkleber (außer 100-V-Spezifikationen)

- 16.** Den Bereich über den Zifferntasten auf der rechten Seite des Bedienfeldes abwischen und die Alphabetaufkleber (E) hier anbringen.
Für Asien und Ozeanien den Aufkleber PQRS TUV WXYZ anbringen, und die Aufkleber PRS TUV WXY und OPER nicht benutzen.

Anschließen der Maschine an die Telefonleitung

- 17.** Das Modulkabel (20) in die Leitungsbuchse (19) stecken, und dann die Leitungsbuchse mit der Telefonleitung verbinden.
Für die 100-V/120-V/Australien-Spezifikationen das mitgelieferte Modulkabel (F) verwenden.

Applicazione delle etichette alfabetiche (eccetto specifiche per 100 V)

- 16.** Pulire l'area sopra i tasti numerici sul lato destro del pannello operativo con alcol e applicare le etichette alfabetiche (E).
Per l'Asia e l'Oceania, applicare l'etichetta PQRS TUV WXYZ, non utilizzare le etichette PRS TUV WXY e OPER.

Collegamento della macchina alla linea del telefono

- 17.** Collegare il cavo connettore modulare (20) alla linea del terminale (19) e poi collegare la linea del terminale alla linea del telefono.
Specifiche per 100 V/120 V/Australiano, utilizzare il cavo connettore modulare in dotazione (F).

粘貼英文字母标签 (100V 型号以外)

- 16.** 擦拭操作面板右侧数字键上的区域, 然后将英文字母标签 (E) 粘贴在此处。
在亚洲和大洋州, 请使用 PQRS TUV WXYZ 标签, 而不要使用 PRS TUV WXY 和 OPER 标签。

连接电话线

- 17.** 将电话线 (20) 插入电话线端子 (19) 与电话线连接。
100V/120V/ 澳大利亚型号务必使用同装品的电话线 (F)。

アルファベットのラベルの貼り付け (100V 仕様以外)

- 16.** 操作パネル右側のテンキー上側をアルコール清掃し、アルファベットのラベル (E) を貼り付ける。
アジア・オセアニアでは「PRS TUV WXY」および「OPER」のラベルを使用せず、「PQRS TUV WXYZ」のラベルを使用すること。

電話回線との接続

- 17.** ライン端子 (19) にモジュラーコード (20) を差し込み電話回線に接続する。
100V, 120V, オーストラリア仕様は同梱品のモジュラーコード (F) を使用する。

Executing the maintenance mode

After completion of installation, the FAX control PWB of the FAX unit must be initialized by executing the maintenance items U601/U602.
For details, see the service manual.

Exécution du mode de maintenance

Après avoir terminé l'installation, il faut initialiser le PWB de commande FAX de l'unité FAX en exécutant les éléments de maintenance U601/U602.
Pour plus de détails, se reporter au manuel d'entretien.

Ejecución del modo de mantenimiento

Después de terminar la instalación, el PWB de control de FAX de la unidad de FAX debe iniciarse ejecutando los ítems de mantenimiento U601/U602.
Para más detalles, vea el manual de servicio.

Ausführen des Wartungsmodus

Nach Abschluss der Installation muss die FAX-Steuer-PWB der FAX-Einheit durch Ausführen der Wartungsposten U601/U602 initialisiert werden.
Einzelheiten sind der Wartungsanleitung zu entnehmen.

Esecuzione del modo di manutenzione

Dopo aver completato l'installazione, il comando PWB del FAX dell'unità FAX deve essere inizializzato eseguendo le voci di manutenzione U601/U602.
Per ulteriori dettagli, vedere il manuale d'istruzioni.


执行维修保养模式

安装结束后, 执行维修保养模式 U601、U602, 进行 FAX 组件的传真控制电路板的初始化处理。
有关详细信息, 请参见维修手册。



メンテナンスモードの実行

設置後、メンテナンスモード U601・U602 を実行して FAX ユニットの FAX 制御回路基板を初期化する。
詳細はサービスマニュアルを参照する。




Adhering the line approval label (for 120 V specifications only)
Wipe the area shown in the figure with alcohol and adhere the FCC approval label (C).


Apposition de l'étiquette d'approbation de ligne (spécifications 120 V seulement)
Nettoyer la zone indiquée sur l'illustration avec de l'alcool, et y apposer l'étiquette d'approbation FCC (C).

Adhesión de la etiqueta de aprobación de línea (sólo para especificaciones de 120 V)
Limpie la zona que aparece en la figura con alcohol y pegue la etiqueta de aprobación FCC (C).

Adhering the line approval label (for 110V specifications only)
Wipe the area shown in the figure with alcohol and adhere the PTT label(I).




Adhering the line approval label (for Australian/New Zealand specifications only)
Wipe the area shown in the figure with alcohol and adhere the line approval label (D).




回線認可ラベルの貼り付け (100V 仕様のみ)
アルコール清掃後、JATE 認可ラベル (B) をイラストの位置に貼り付ける。

INSTALLATION GUIDE FOR Printing System (Y)




English

INSTALLATION GUIDE FOR Printing System (Y)




- Supplied parts
- A Printing System 1
 - B CF cover 1




- Option
- C Printer Network Kit 1
 - D HD-5 Hard Disk 1
 - E Memory DIMM 1

- Precautions
- Be sure to remove any tape and/or cushioning material from supplied parts.
 - Before installing the Printing System, be sure to turn the main power switch of the machine off and unplug the power cable from the wall outlet.
 - Do not touch the PWB with bare hands or something which has the static electricity.



- Procedure
- Installing the printing system
1. Remove three screws (1) to remove the cover (2).



2. Insert the printing system (A) along the rails (3).
3. Fix the printing system (A) using three screws (1) removed in step 1.

Français

GUIDE D'INSTALLATION DU Printing System (Y)

- Pièces fournies
- A Système d'imprimante 1
 - B Couvercle CF 1

- Option
- C Kit de réseau d'imprimante 1
 - D Disque dur HD-5 1
 - E Mémoire DIMM 1

- Précautions
- Veillez à retirer les morceaux de bande adhésive et/ou les matériaux de rembourrage des pièces fournies.
 - Avant d'installer le système d'imprimante, veiller à mettre la machine hors tension et à débrancher le câble d'alimentation de la prise murale.
 - Ne pas toucher le PWB avec les mains nues ou avec un objet possédant de l'électricité statique.

- Procédure
- Installation du système d'imprimante
1. Retirer les trois vis (1) pour retirer le couvercle (2).

2. Insérer le système d'imprimante (A) le long des rails (3).
3. Fixer le système d'imprimante (A) en utilisant les trois vis (1) retirées auparavant lors de l'étape 1.

Español

GUÍA DE INSTALACIÓN PARA EL Printing System (Y)

- Partes suministradas
- A Sistema de impresión 1
 - B Cubierta CF 1

- Opción
- C Kit de impresora en red 1
 - D Disco duro HD-5 1
 - E Memoria DIMM 1

- Precauciones
- Asegúrese de despegar todas las cintas y/o material amortiguador de las partes suministradas.
 - Antes de la instalación del sistema de impresión, asegúrese de desconectar el interruptor principal de la máquina y desenchufar el cable eléctrico del tomacorriente de la pared.
 - No toque el PWB con las manos desnudas o algo que tenga electricidad estática.

- Procedimiento
- Instalación del sistema de impresión
1. Quite los tres tornillos (1) para desmontar la cubierta (2).

2. Inserte el sistema de impresión (A) por los carriles (3).
3. Fije el sistema de impresión (A) utilizando los tres tornillos (1) quitados en el paso 1.

Deutsch

INSTALLATIONSANLEI TUNG FÜR DAS Printing System (Y)

- Delieferte Teile
- A Drucksystem 1
 - B CF-Abdeckung 1

- Option
- C Drucker-Netzwerksatz 1
 - D HD-5 Festplatte 1
 - E Speicher-DIMM 1

- Vorsichtsmaßnahmen
- Entfernen Sie Klebeband und/oder Dämpfungsmaterial vollständig von den mitgelieferten Teilen.
 - Schalten Sie unbedingt den Betriebsschalter der Maschine aus, und trennen Sie das Netzkabel von der Netzsteckdose, bevor Sie das Drucksystem installieren.
 - Berühren Sie die PWB nicht mit bloßen Händen oder einem statisch geladenen Gegenstand.

- Verfahren
- Installieren des Drucksystems
1. Die drei Schrauben (1) herausdrehen, um die Abdeckung (2) abzunehmen.

2. Das Drucksystem (A) entlang den Schienen (3) einführen.
3. Das Drucksystem (A) mit den in Schritt 1 entfernten drei Schrauben (1) befestigen.

Italiano

GUIDA ALL'INSTALLAZIONE DEL Printing System (Y)

- Parti di forniture
- A Sistema di stampa 1
 - B Coperchio CF 1

- Opzioni
- C Kit per stampante di rete 1
 - D Hard disk HD-5 1
 - E Memoria DIMM 1

- Precauzioni
- Accertarsi di rimuovere tutti i nastri adesivi e/o il materiale di imbottitura dalle parti fornite.
 - Prima di installare il sistema di stampa, assicurarsi di spegnere l'interruttore principale di alimentazione della macchina e scollegare la spina del cavo di alimentazione dalla presa a muro della rete elettrica.
 - Non toccare il PWB a mani nude o con un oggetto caricato elettrostaticamente.

- Procedura
- Installazione del sistema di stampa
1. Togliere tre viti (1) per rimuovere il coperchio (2).

2. Inserire il sistema di stampa (A) lungo le guide (3).
3. Fissare il sistema di stampa (A) utilizzando le tre viti (1) rimosse nel passo 1.

简体中文

Printing System (Y) 安装手册

- 同装品
- A 打印组件 1
 - B CF 盖板 1

- 选购件
- C 打印机网络组件 1
 - D 硬盘 HD-5 1
 - E 内存模组 DIMM 1

- 注意事项
- 如果同装品上带有固定胶带、缓冲材料时务必揭下。
 - 安装打印组件时，必须先关闭机器主机的主电源开关，并拔下电源插头后，再进行安装作业。
 - 切勿用裸手或带静电的物品触碰电路板。

- 安装步骤
- 安装打印组件
1. 拆下 3 个螺丝 (1)，然后拆下盖板 (2)。

2. 沿着导轨 (3) 插入打印组件 (A)。
3. 用在步骤 1 中拆下的 3 个螺丝 (1) 固定打印组件 (A)。

日本語

Printing System (Y) 設置手順書


- 同梱品
- A プリンティングシステム 1
 - B CF カバー 1

- オプション
- C プリントネットワークキット 1
 - D ハードディスク HD-5 1
 - E メモリ DIMM 1


- 注意事項
- 同梱品に固定テープ、緩衝材が付いている場合は必ず取り外すこと。
 - プリンティングシステムを設置する場合は、必ず機械本体の主電源スイッチを OFF にし、電源プラグを抜いてから作業をおこなう。
 - 基板に素手または静電気を帯びているもので触れないこと。

- 設置手順
- プリンティングシステムの取り付け
1. ビス (1) 3 本を外し、カバー (2) を取り外す。


2. プリンティングシステム (A) をレール (3) に沿って挿入する。
3. 手順 1 で外したビス (1) 3 本でプリンティングシステム (A) を固定する。




Attaching the CF cover
4. Open the MP tray (4) and attach the CF cover (B) to the storage location (5).
5. Close the MP tray (4).



Installing the printer network kit (option)
1. Remove two pins (6) to remove the OPT1 cover (7).
2. Insert the printer network kit (C) along the rails.
3. Fix the printer network kit (C) using two pins (6) removed in step 1.



Installing the HD-5 hard disk (option)
1. Remove two pins (8) to remove the HDD cover (9).
2. Insert the HD-5 hard disk (D) along the rails.
3. Fix the HD-5 hard disk (D) using two pins (8) removed in step 1.



Installing the memory DIMM (option)
1. Remove three screws to remove the printing system (A).
2. Insert the memory DIMM (E) into the memory slot (11) so that two notches (10) of the memory DIMM (E) are positioned to two projections (12) of the memory slot (11).
3. Push the memory DIMM (E) firmly into the memory slot (11) until two hooks (13) are snap closed.
4. Replace the printing system (A) using three screws.

Fixation du couvercle CF
4. Ouvrir le bac MF (4) et fixer le couvercle CF (B) sur l'emplacement de rangement (5).
5. Refermer le bac MF (4).

Installation du kit de réseau d'imprimante (en option)
1. Retirer les deux goupilles (6) pour retirer le couvercle OPT1 (7).
2. Insérer le kit de réseau d'imprimante (C) le long des rails.
3. Fixer le kit de réseau d'imprimante (C) en utilisant les deux goupilles (6) retirées auparavant lors de l'étape 1.

Installation du disque dur HD-5 (en option)
1. Retirer les deux goupilles (8) pour retirer le couvercle HDD (9).
2. Insérer le disque dur HD-5 (D) le long des rails.
3. Fixer le disque dur HD-5 (D) en utilisant les deux goupilles (8) retirées auparavant lors de l'étape 1.

<After installing the hard disk, be sure to format the hard disk.>
4. Connect the power plug of the machine to the wall outlet and turn the main power switch on.
5. Press the Print key to enter the printer screen. Select [Printer menu], [Hard Disk], and [Format].

<Après avoir installé le disque dur, veiller à formater le disque dur.>
4. Insérer la fiche d'alimentation de la machine dans la prise murale et mettre la machine sous tension.
5. Appuyer sur la touche Imprimer pour faire apparaître l'écran de l'imprimante. Sélectionner [Printer menu], [Disque dur] et [Formatage].

Installation de la mémoire DIMM (en option)
1. Retirer les trois vis pour retirer le système d'imprimante (A).
2. Insérer la mémoire DIMM (E) dans la fente de mémoire (11) de manière que les deux encoches (10) de la mémoire DIMM (E) soient placées sur les deux saillies (12) de la fente de mémoire (11).
3. Pousser la mémoire DIMM (E) fermement dans la fente de mémoire (11) jusqu'à ce que les deux crochets (13) se ferment en s'encliquetant.
4. Remettre le système d'imprimante (A) en place en utilisant trois vis.

Colocación de la cubierta CF
4. Abra la bandeja manual (4) y coloque la cubierta CF (B) en el lugar de almacenamiento (5).
5. Cierre la bandeja manual (4).

Instalación del kit de impresora de red (opcional)
1. Quite los dos pasadores (6) para desmontar la cubierta OPT1 (7).
2. Inserte el kit de impresora de red (C) por los carriles.
3. Fije el kit de impresora de red (C) utilizando los dos pasadores (6) quitados en el paso 1.

Instalación del disco duro HD-5 (opcional)
1. Quite los dos pasadores (8) para desmontar la cubierta del HDD (9).
2. Insrte el disco duro HD-5 (D) por los carriles.
3. Fije el disco duro HD-5 (D) utilizando los dos pasadores (8) quitados en el paso 1.

<Después de la instalación del disco duro, asegúrese de formatear el disco duro.>
4. Conecte el enchufe eléctrico de la máquina en un tomacorriente de la pared y conecte el interruptor principal.
5. Presione la tecla Imprimir para entrar en la pantalla de impresión. Seleccione el [Menú impresión], [Disco duro] y [Formato].

Instalación de la memoria DIMM (opcional)
1. Quite los tres tornillos para desmontar el sistema de impresión (A).
2. Inserte la memoria DIMM (E) en la ranura de memoria (11) para que dos muescas (10) de la memoria DIMM (E) están ubicadas en las dos salientes (12) de la ranura de memoria (11).
3. Presione la memoria DIMM (E) firmemente en la ranura de memoria (11) hasta que los dos ganchos (13) cierren como un resorte.
4. Cambie el sistema de impresión (A) utilizando tres tornillos.

Anbringen der CF-Abdeckung
4. Die Universalzufuhr (4) öffnen, und die CF-Abdeckung (B) an der Speicherposition (5) anbringen.
5. Die Universalzufuhr (4) schließen.

Installieren des Druck-Netzwerksatzes (Option)
1. Die zwei Stifte (6) entfernen, um die OPT1-Abdeckung (7) abzunehmen.
2. Den Drucker-Netzwerksatz (C) entlang der Schienen einführen.
3. Den Drucker-Netzwerksatz (C) mit den in Schritt 1 entfernten zwei Stiften (6) befestigen.

Installieren der HD-5 Festplatte (Option)
1. Die zwei Stifte (8) entfernen, um die HDD-Abdeckung (9) abzunehmen.
2. Die HD-5 Festplatte (D) entlang der Schienen einführen.
3. Die HD-5 Festplatte (D) mit den in Schritt 1 entfernten zwei Stiften (8) befestigen.

<Nach der Installation muss die Festplatte formatiert werden.>
4. Den Netzstecker der Maschine in die Steckdose stecken und den Betriebsschalter einschalten.
5. Drücken Sie die Drucken-Taste, um den Druckanzei aufzurufen. Wählen Sie [Druckermenü], [Festplatte] und [Formatieren].

Installieren des Speicher-DIMM (Option)
1. Drei Schrauben herausdrehen, um das Drucksystem (A) zu entfernen.
2. Das Speicher-DIMM (E) so in den Speichersteckplatz (11) einführen, dass die zwei Kerben (10) des Speicher-DIMM (E) auf die zwei Vorsprünge (12) des Speichersteckplatzes (11) ausgerichtet sind.
3. Das Speicher-DIMM (E) fest in den Speichersteckplatz (11) hineindrücken, bis die zwei Haken (13) einrasten.
4. Das Drucksystem (A) mit drei Schrauben wieder anbringen.

Montaggio del coperchio CF
4. Aprire il vassoio bypass (4) e montare il coperchio CF (B) nel contenitore di immagazzinaggio (5).
5. Chiudere il vassoio bypass (4).

Installazione del kit per stampante di rete (opzione)
1. Togliere i due perni (6) per rimuovere il coperchio OPT1 (7).
2. Inserire il kit per stampante di rete (C) lungo le guide.
3. Fissare il kit per stampante di rete (C) utilizzando i due perni (6) rimossi nel passo 1.

Installazione dell'Hard disk HD-5 (opzione)
1. Togliere i due perni (8) per rimuovere il coperchio dell'HDD (9).
2. Inserire l'Hard disk HD-5 (D) lungo le guide.
3. Fissare l'Hard disk HD-5 (D) utilizzando i due perni (8) rimossi nel passo 1.

<Dopo avere installato l'Hard disk, assicurarsi di formattarlo.>
4. Collegare la spina del cavo di alimentazione della macchina alla presa a muro della rete elettrica e accendere l'interruttore principale di alimentazione.
5. Premere il tasto Stampare per passare alla videata stampa. Selezionare [Menu stampante], [Hard disk], e [Formatt-azione].

Installazione della memoria DIMM (opzione)
1. Togliere tre viti per rimuovere il sistema di stampa (A).
2. Inserire la memoria DIMM (E) nello slot della memoria (11) in modo che i due incavi (10) della memoria DIMM (E) siano posizionati in direzione delle due sporgenze (12) dello slot della memoria (11).
3. Spingere la memoria DIMM (E) saldamente nello slot della memoria (11) finché due ganci (13) si chiudono con uno scatto.
4. Rimettere a posto il sistema di stampa (A) utilizzando tre viti.

安装 CF 盖板
4. 打开多功能手送纸盘 (4), 将 CF 盖板 (B) 安装在保管位置 (5) 上。
5. 关闭多功能手送纸盘 (4)。

安装打印网络组件 (选购件)
1. 拆下 2 个卡销 (6), 然后拆下 OPT1 盖板 (7)。
2. 沿着导轨插入打印网络组件 (C)。
3. 用在步骤 1 中拆下的 2 个卡销 (6) 固定打印网络组件 (C)。

安装硬盘 HD-5 (选购件)
1. 拆下 2 个卡销 (8), 然后拆下 HDD 盖板 (9)。
2. 沿着导轨插入硬盘 HD-5 (D)。
3. 用在步骤 1 中拆下的 2 个卡销 (8) 固定硬盘 HD-5 (D)。

<安装后进行硬盘的初始化处理>
4. 将机器主机上的电源插头插入插座中, 打开主电源开关。
5. 按下打印键, 显示出打印画面。
选择“打印菜单”、“硬盘”、“初始化”模式。

安装内存模组 DIMM (选购件)
1. 拆下 3 个螺丝, 然后拆下打印组件 (A)。
2. 将 2 处内存模组 DIMM (E) 的缺口 (10) 与 2 处打印组件 (A) 的内存模组插入口 (11) 的突出部 (12) 相一致后再插入。
3. 插入内存模组口插入口 (11), 直至内存模组 DIMM (E) 两侧的挂钩 (13) 关闭为止。
4. 用 3 个螺丝将打印组件 (A) 装回原处。

CF カバーの取り付け
4. 手差しトレイ (4) を開き、CF カバー (B) を保管場所 (5) に取り付けます。
5. 手差しトレイ (4) を閉じます。

プリンタネットワークキットの取り付け (オプション)
1. ペン (6) 2 本を外し、OPT1 カバー (7) を取り外す。
2. プリンタネットワークキット (C) をレールに沿って挿入する。
3. 手順 1 で外したペン (6) 2 本でプリンタネットワークキット (C) を固定する。

ハードディスク HD-5 の取り付け (オプション)
1. ペン (8) 2 本を外し、HDD カバー (9) を取り外す。
2. ハードディスク HD-5 (D) をレールに沿って挿入する。
3. 手順 1 で外したペン (8) 2 本でハードディスク HD-5 (D) を固定する。

<設置後にハードディスクのフォーマット (初期化) をおこなう>
4. 機械本体の電源プラグをコンセントに差し込み、主電源スイッチを ON にする。
5. プリンタキーを押し、プリンタ画面を表示する。「プリンタメニュー」「ハードディスク」「フォーマット」を選択する。

メモリ DIMM の取り付け (オプション)
1. ビス 3 本を外し、プリンティングシステム (A) を取り外す。
2. メモリ DIMM (E) の切り欠き (10) 2 箇所とプリンティングシステム (A) のメモリ挿入口 (11) の突起 (12) 2 箇所を一致させて挿入する。
3. メモリ DIMM (E) を両側のフック (13) が閉じるまでメモリ挿入口 (11) に差し込む。
4. ビス 3 本でプリンティングシステム (A) を元通り取り付けます。

KYOCERA MITA EUROPE B.V.

Hoeksteen 40, 2132 MS Hoofddorp,
The Netherlands
Phone: +31.20.654.0000
Home page: <http://www.kyoceramita-europe.com>
Email: info@kyoceramita-europe.com

KYOCERA MITA NEDERLAND B.V.
Beechavenue 25, 1119RA Schiphol-Rijk
The Netherlands
Phone: +31.20.58.77.200

KYOCERA MITA (UK) LTD
8 Beacontree Plaza
Gillette Way Reading Berks RG2 0BS,
U.K.
Phone: +44.1189.311.500

KYOCERA MITA ITALIA S.p.A.
Via G. Verdi, 89 / 91, 20063 Cernusco s/N
Milano, Italy
Phone: +39.02.92179.1

S.A. KYOCERA MITA BELGIUM N.V.
Hermesstraat 8A, 1930 Zaventem,
Belgium
Phone: +32.2.720.9270

KYOCERA MITA FRANCE S.A.
Parc Les Algorithmes Saint Aubin
91194 GIF-SUR-YVETTE,
France
Phone: +33.1.6985.2600

KYOCERA MITA ESPAÑA S.A.
Edificio Kyocera, Avda de Manacor No. 2,
28290 Las Matas (Madrid),
Spain
Phone: +34.91.631.8392

KYOCERA MITA FINLAND OY
Kirvesmiehenkatu 4, 00880 Helsinki,
Finland
Phone: +358.9.4780.5200

KYOCERA MITA (SCHWEIZ)
Hohlstrasse 614, 8048 Zürich
Switzerland
Phone: +41.1.908.4949

KYOCERA MITA DEUTSCHLAND GMBH
Otto-Hahn-Str. 12 D-40670 Meerbusch,
Germany
Phone: +49.2159.918.0

KYOCERA MITA GMBH AUSTRIA
Eduard-Kittenberger-Gasse 95,
1230 Wien,
Austria
Phone: +43.1.86338.210

KYOCERA MITA SVENSKA AB
Esbogatan 16B 164 75 Kista,
Sweden
Phone: +46.8.546.55000

KYOCERA MITA NORGE
Postboks 150 Oppsal, NO 0619 Oslo
Olaf Helsetsvai 6, NO 0694 Oslo,
Norway
Phone: +47.22.62.73.00

KYOCERA MITA DANMARK A/S
Ejby Industrivej 1, DK-2600 Glostrup,
Denmark
Phone: +45.5687.1100

KYOCERA MITA PORTUGAL LDA.
Rua do Centro Cultural, 41 (Alvalade) 1700-106 Lisbon,
Portugal
Phone: +351.21.842.9100

KYOCERA MITA SOUTH AFRICA (PTY) LTD.
527 Kyalami Boulevard,
Kyalami Business Park Midrand,
South Africa
Phone: +27.(0)11.540.2600

KYOCERA MITA AMERICA, INC.

Headquarters:
225 Sand Road,
Fairfield, New Jersey 07004-0008,
U.S.A.
Phone: (973) 808-8444

KYOCERA MITA AUSTRALIA PTY. LTD.
Level 3, 6-10 Talavera Road, North Ryde,
N.S.W. 2113 Australia
Phone: (02) 9888-9999

KYOCERA MITA NEW ZEALAND LTD.
1-3 Parkhead Place, Albany
P.O. Box 302 125 NHPC, Auckland,
New Zealand
Phone: (09) 415-4517

KYOCERA MITA (THAILAND) CORP., LTD.
9/209 Ratchada-Prachachem Road,
Bang Sue, Bangkok 10800, Thailand
Phone: (02) 586-0320

KYOCERA MITA SINGAPORE PTE LTD.
121 Genting Lane, 3rd Level,
Singapore 349572
Phone: 67418733

KYOCERA MITA HONG KONG LIMITED
11/F., Mita Centre,
552-566, Castle Peak Road,
Tsuen Wan, New Territories,
Hong Kong
Phone: 24297422

KYOCERA MITA TAIWAN Corporation.
7F-1~2, No.41, Lane 221, Gangchi Rd.
Neihu District, Taipei, Taiwan, 114. R.O.C.
Phone: (02) 87511560

KYOCERA MITA Corporation

2-28, 1-chome, Tamatsukuri, Chuo-ku
Osaka 540-8585, Japan
Phone: (06) 6764-3555
<http://www.kyoceramita.com>

KYOCERA MITA AMERICA, INC.

Headquarters:

225 Sand Road,
Fairfield, New Jersey 07004-0008
TEL : (973) 808-8444
FAX : (973) 882-6000

New York Branch:

1410 Broadway 23rd floor
New York, NY 10018
TEL : (917) 286-5400
FAX : (917) 286-5402

Northeastern Region:

225 Sand Road,
Fairfield, New Jersey 07004-0008
TEL : (973) 808-8444
FAX : (973) 882-4401

Midwestern Region:

201 Hansen Court Suite 119
Wood Dale, Illinois 60191
TEL : (630) 238-9982
FAX : (630) 238-9487

Western Region:

14101 Alton Parkway,
Irvine, California 92618-7006
TEL : (949) 457-9000
FAX : (949) 457-9119

Southeastern Region:

1500 Oakbrook Drive,
Norcross, Georgia 30093
TEL : (770) 729-9786
FAX : (770) 729-9873

Southwestern Region:

2825 West Story Road,
Irving, Texas 75038-5299
TEL : (972) 550-8987
FAX : (972) 252-9786

National Operation Center & National Training Center:

2825 West Story Road,
Irving, Texas 75038-5299
TEL : (972) 659-0055
FAX : (972) 570-5816

Latin America Division:

8240 N.W. 52nd. Terrace Dawson Building,
Suite 108 Miami, Florida 33166
TEL : (305) 421-6640
FAX : (305) 421-6666

KYOCERA MITA CANADA, LTD.

6120 Kestrel Road, Mississauga,
Ontario L5T 1S8, Canada
TEL : (905) 670-4425
FAX : (905) 670-8116

KYOCERA MITA MEXICO, S.A. DE C.V.

Av. 16 de Septiembre #407
Col. Santa Inés,
Azcapotzalco México,
D.F. 02130, México
TEL : (55) 5383-2741
FAX : (55) 5383-7804