



DF-75

PH-2C

PH-2D

PARTS LIST

Published in Oct.'01
845FG120

NOTE

1. Indicate parts number and machine model when placing an order.

eg.	Parts Number	Parts Name	Machine Model	Cycle	Quantity
	5FG04120	FRONT COVER	DF-75	50Hz	1

2. Service calls and freight will be charged separately.

3. Symbols in the "Parts Number" column.

- Parts with "●" indicates the service parts and the parts without "●" can not be supplied.
- Parts with "•" are component parts or sub-assemblies of the assembly appearing immediately above them.

eg.	Parts Number	Parts Name	Parts Number	Parts Name
	3AK27510	WIRE, MIDDLE TRAY	•J0150900	CONTACTOR, 175161-1(AMP)
			•J0250900	SOCKET, BHF-001T-0.8SS

———— CONTENTS ————

FIG. Q01	MOUNTING HARDWARE	2	FIG. Q40	STAPLE ASSEMBLY (1/2)	26
FIG. Q10	EXTERNAL COVERS, PANELS, ETC.	4	FIG. Q40	STAPLE ASSEMBLY (2/2)	28
FIG. Q11	INTERNAL COMPONENTS 1	6	FIG. Q90	DC CONTROLLER PCB ASSEMBLY	30
FIG. Q12	INTERNAL COMPONENTS 2	8	FIG. QB1	LIST OF CONNECTORS (1/2)	32
FIG. Q20	STACK MOTOR DRIVER ASSEMBLY	10	FIG. QB1	LIST OF CONNECTORS (2/2)	34
FIG. Q22	DRIVE ASSEMBLY	12	FIG. QB2	LIST OF ELECTRIC PARTS (1/2)	36
FIG. Q24	BUNDLE SUPPORT COVER ASSEMBLY	14	FIG. QB2	LIST OF ELECTRIC PARTS (2/2)	38
FIG. Q30	DISPOSE ASSEMBLY	16	FIG. Q13	PUNCHER ASSEMBLY	40
FIG. Q32	PAPER FEEDER ASSEMBLY	18	FIG. Q14	PUNCHER TOTAL ASSEMBLY	42
FIG. Q35	FOLD ASSEMBLY (1/3)	20	FIG. QB1P	LIST OF CONNECTORS (PUNCHER)	44
FIG. Q35	FOLD ASSEMBLY (2/3)	22	FIG. QB2P	LIST OF ELECTRIC PARTS (PUNCHER)	46
FIG. Q35	FOLD ASSEMBLY (3/3)	24			
				• INDEX	48




FIG. Q01 MOUNTING HARDWARE

5FG

SP	Ref. No.	Part. No.	Description	Quantity		
				120V	230V	240V
	1	5FG02010	BASE,LATCH	1	1	1
	2	5FG02020	RETAINER A,RAIL	1	1	1
	3	5FG02030	RETAINER B,RAIL	1	1	1
	4	5FG02040	BRACKET,CASTER	4	4	4
●	5	5FG04280	FRONT COVER,SUPPORT	1	1	1
●	6	5FG04290	REAR COVER,SUPPORT	1	1	1
●	7	5FG04300	COVER,FOOT	1	1	1
●	8	5FG04310	COVER,SUPPORT PLATE	1	1	1
●	9	5FG04320	FRONT COVER,ADJUSTING PLATE	1	1	1
●	10	5FG04330	REAR COVER,ADJUSTING PLATE	1	1	1
●	11	5FG04340	CAP,SUPPORT PLATE	4	4	4
	12	5FG02050	GUIDE A,RAIL	1	1	1
	13	5FG02060	GUIDE B,RAIL	1	1	1
	14	5C120620	SLIDE CHOU	1	1	1
	15	5C120700	PULLEY MOUNT UNIT(KM)	1	1	1
	16	5C120750	CASTER RAIL	2	2	2
	17	5FG11680	SPACER RAIL	2	2	2
	18	5C120930	SPRING,GROUNDING	1	1	1
	19	5FG11690	ASSY,STAND	1	1	1
	20	5FG11700	STAY,STAND	1	1	1
	21	5FG11710	SUTAND BEES	1	1	1
	22	5FG11720	SUTAND KABA	1	1	1
●	23	5FG11410	SD-BKT-F	1	1	1
	24	5FG11730	SUTANDBURAKETO(BAKU)	1	1	1
	25	5FG11740	SUTAND	1	1	1
	26	5FG11750	SUTAND,	1	1	1
	27	5FG11760	FUT	1	1	1
	501	5FG13710	SCREW MACH,TRUSS HEAD.M4X10	2	2	2
	502	5C119790	BIND(N)M4X6	13	13	13
	503	59916200	WASHER,TOOTHED LOCK	1	1	1
	505	5C120660	SCREW,BIND M4X4	1	1	1
	506	5C120030	M4TP	8	8	8
	507	5FG11860	SCREW M4X7	14	14	14
	508	5FG12340	SCREW M4X8	8	8	8

- Parts with "●" are component parts or sub-assemblies of the assembly appearing immediately above them.
- Parts with "●" indicates the Service parts.




FIG. Q10 EXTERNAL COVERS, PANELS, ETC

SP	Ref. No.	Part. No.	Description	Quantity		
				120V	230V	240V
●	1	5FG04010	HANDLE A,JAM RELEASE	1	1	1
●	2	5FG04020	REAR COVER	1	1	1
●	3	5FG04030	COVER,JAM FRAME	1	1	1
●	4	5FG04040	COVER,JAM RELEASE	1	1	1
	5	5FG13700	CABLE,INTERFACE	1	1	1
	6	5FG11770	CLIP	2	2	2
●	7	5FG04050	COVER,PUNCH LID	1	1	1
●	8	5FG10520	SPRING,TENSION	1	1	1
●	9	5FG04060	UPPER GUIDE,PUNCH DUMMY	1	1	1
●	10	5FG04070	GUIDE,PUNCH DUMMY	1	1	1
●	11	5FG04080	COVER,SIDE	1	1	1
●	12	5FG11360	LEVER,TRAY UP/DOWN EMPTY	1	1	1
	13	5FG11780	FIAG,PAPER SENSING REAR	1	1	1
	14	5FG11790	SPRING,TENSION	1	1	1
	15	5FG11800	LATCH,UPPER PANEL	2	2	2
●	16	5FG04090	UPPER COVER,SUB	1	1	1
●	17	5FG04100	UPPER COVER	1	1	1
	18	5FG11810	SPRING,TORSION	1	1	1
	19	5FG11820	SPRING,TORSION	1	1	1
	20	5FG11830	HOLDER,ROLLER	1	1	1
●	21	5FG11430	ROLLER,PAPER FEED	1	1	1
●	22	5FG04110	COVER,RETAINING	1	1	1
●	23	5FG04120	FRONT COVER	1	1	1
	24	5FG11840	BAND PANEL	3	3	3
	25	5FG11850	SUPPORT,PANEL BAND,2	2	2	2
●	26	5FG04130	TRAY A,STACK	1	1	1
●	27	5FG04140	TRAY B,STACK	1	1	1
	28	5FG11860	SCREW M4X7	3	3	3
	29	5FG11870	PLATE GROUNDING	1	1	1
●	30	5FG04150	COVER A,BRIDGE	1	1	1
●	31	5FG04160	COVER B,BRIDGE	1	1	1
	32	5FG11880	FLAG BASE TRAY	1	1	1
●	33	5FG04170	TRAY,MAIN	1	1	1
●	34	5FG04180	ARM,STOPPER	1	1	1
	35	5FG11890	SPRING,TENSION	1	1	1
	36	5FG11900	SPRING,TENSION	1	1	1
	37	5FG11910	CLIP,SHAFT	1	1	1
	38	5FG11920	CLIP,SHAFT	1	1	1
	39	5FG11930	GUIDO,DUMMY PUNCHER PAPER	1	1	1
	40	5FG11940	LABEL STAPLE REMOVING	1	1	1

5FG

SP	Ref. No.	Part. No.	Description	Quantity		
				120V	230V	240V
●	41	5FG10170	GEAR,48T/PULLEY,15T	1	1	1
	43	5FG11960	SUPPORT,PANEL BAND,1	2	2	2
	44	5FG11970	TRAY	1	1	1
	45	5FG11980	TRAY	1	1	1
	46	5FG11990	SHEET	1	1	1
	47	5FG13720	SPACER	2	2	2
	48	5FG13730	SCREW,STEPPED	2	2	2
	49	5FG13740	TRAY,	1	1	1
	50	5FG04350	TRAY,RIB	1	1	1
	51	5FG13750	TENSION	2	2	2
	501	5C119790	BIND(N)M4X6	8	8	8
	502	5AH10870	SCREW,TAPPING,PAN HEAD,M4X10	8	8	8
	503	5AH14100	SCREW,TAPPING,TRUSS HEAD,M3X6	1	1	1
	504	5FG13760	SCREW M4X6	1	1	1
	505	5C118090	TAPPING M4X6	2	2	2

- Parts with "●" are component parts or sub-assemblies of the assembly appearing immediately above them.
- Parts with "●" indicates the Service parts.




FIG. Q11 INTERNAL COMPONENTS 1

SP	Ref. No.	Part. No.	Description	Quantity		
				120V	230V	240V
●	1	5FG10060	GEAR,24T/PULLEY,24T	1	1	1
	2	5FG12230	LEVER STACK	1	1	1
●	3	5FG10010	GEAR,16T/PULLEY,18T	1	1	1
	4	5FG11860	SCREW M4X7	14	14	14
	5	57306720	SCREW STEPPED M3	1	1	1
	6	5FG12240	HOLDER BELT REAR	1	1	1
	7	5FG12250	HOLDER BELT FRONT	1	1	1
	8	5FG10490	ROLLER,TENSIONER	2	2	2
	9	5FG12260	SPRING TENSION	1	1	1
●	10	5FG10660	SPRING,TENSION	2	2	2
●	11	5FG10680	SPRING,TENSION	2	2	2
●	12	5FG10700	SPRING,TENSION	1	1	1
●	13	5FG10760	PULLEY,18T/24T	1	1	1
	14	5FG12270	LATCH 1	1	1	1
	15	5FG12280	LATCH (2)	1	1	1
	16	5FG12290	CABLE STACK SENSOR	1	1	1
	17	5FG12300	BUSHING	1	1	1
●	18	5FG10770	PULLEY,18T	1	1	1
●	19	5FG10780	BUSHING	1	1	1
	20	5FG12310	FLANGE	4	4	4
●	21	5FG11920	CLIP,SHAFT	5	5	5
●	22	5FG10840	BUSHING	2	2	2
	23	5FG12330	SPRING LEAF	2	2	2
●	24	5FG10180	PULLEY,40T	1	1	1
●	25	5C111230	PHOTO INTERRUPTER B	1	1	1
	26	5FG12340	SCREW M4X8	2	2	2
	27	5FG12350	PLATE PAPER FEED TENSIONER 1	1	1	1
●	28	5FG11770	CLIP	4	4	4
	29	5FG12360	CAP MOTOR	4	4	4
	30	5FG12370	ROLLER RAIL	1	1	1
	31	5FG12380	GUIDO STOPPER	1	1	1
	32	5FG12390	LINK,1	2	2	2
	33	5FG12400	LINK,2	2	2	2
●	34	5FG10820	SPRING,TENSION	2	2	2
●	35	5FG11280	MOTOR,STEPPING	1	1	1
	36	5FG12410	SCREW,W/WASHER,M3X6	3	3	3
●	37	5FG10390	PULLEY,18T	2	2	2
●	38	5FG11140	BELT,TIMING	2	2	2
●	39	5FG11120	BELT,TIMING	1	1	1
●	40	5FG11110	BELT,TIMING	1	1	1

5FG

SP	Ref. No.	Part. No.	Description	Quantity		
				120V	230V	240V
	41	5FG12420	CABLE,SENSOR (1)	1	1	1
	42	5FG12430	CABLE,FEED PADDLE MOTOR	1	1	1
	43	5FG12440	CABLE,DC MOTOR	1	1	1
	44	5FG12450	ARM,STOPPER	1	1	1
	45	5FG11890	SPRING,TENSION	1	1	1
●	46	5C117320	TIMING BELT50	1	1	1
	47	5FG12480	TRAY FRONT KUMI	1	1	1
	48	5FG12490	TRAY REAR KUMI	1	1	1
	49	5FG13640	SUPPORT,KARRU	2	2	2
	50	5FG13650	SHEET	2	2	2
	51	5FG13770	PAD	1	1	1
	52	5FG13780	STOPPER,PAD	2	2	2
	501	5FG12460	PIN,DOWEL	1	1	1
	502	5AH10870	SCREW,TAPPING,PAN HEAD,M4X10	3	3	3
	502	5C117780	B TIGHT	3	3	3
	503	5FG12470	PIN,DOWEL	2	2	2

- Parts with "●" are component parts or sub-assemblies of the assembly appearing immediately above them.
- Parts with "●" indicates the Service parts.




FIG. Q12 INTERNAL COMPONENTS 2

5FG

SP	Ref. No.	Part. No.	Description	Quantity		
				120V	230V	240V
●	1	5FG11370	COVER,STOPPER	1	1	1
	2	5FG12340	SCREW M4X8	2	2	2
	3	5FG11860	SCREW M4X7	15	15	15
	4	5FG12000	PLATE,STAPLER FRAME STOPPER	1	1	1
●	5	5FG11770	CLIP	5	5	5
●	6	5FG11050	BUSHING	2	2	2
●	7	5C111230	PHOTO INTERRUPTER B	5	5	5
	8	5FG12010	COVER BLANKING	1	1	1
	9	5FG12020	ROLLER FRAME TRAY	2	2	2
	10	5FG12030	GUIDE PAPER LOWER	1	1	1
●	11	5FG11190	FLAG,SENSOR	1	1	1
●	12	5FG10690	SPRING,TENSION	1	1	1
	13	5FG12040	CABLE SENSOR	1	1	1
	14	5FG10490	ROLLER,TENSIONER	1	1	1
	15	5FG12050	PLATE PAPER FEED TENSIONER,2	1	1	1
	17	5FG11240	MICROSWITCH	2	2	2
●	18	5FG11090	BELT,TIMING	1	1	1
●	19	5FG11200	FLAG, TOP SENSOR	1	1	1
●	20	5FG11210	LEVER,SWITCH	1	1	1
	21	5FG12060	HOLDER LEVER SUPPORT	1	1	1
	22	5FG12070	HOLDER,SENSOR/MICROSWITCH	1	1	1
	23	5FG12080	GEAR,24T	1	1	1
	24	5FG12090	GUIDE,PAPER WEIGHT,1	1	1	1
	25	5FG12100	PLATE,WEIGHT,1	1	1	1
	26	5FG12110	PLATE,WEIGHT,2	1	1	1
	27	5FG12120	GUIDE,PAPER WEIGHT,2	1	1	1
	28	5FG12130	PANEL,FRAME COVER	1	1	1
	29	5FG12140	SPRING,LEAF,GROUNDING	1	1	1
	30	5FG12150	CABLE,FRONT DOOR SENSOR	1	1	1
	31	5FG12160	CABLE,LEVER TRAY SENSOR	1	1	1
	32	5FG12170	CABLE SENSOR (2)	1	1	1
	33	5FG12180	CABLE,SENSOR,3	1	1	1
	34	5FG12190	SPRING TENSION	1	1	1
	35	5FG12200	CABLE,JOG MOTOR	1	1	1
	36	5FG12210	CABLE,SWITCH	1	1	1
	37	5FG12220	CABLE,BIND CLUTCH	1	1	1
●	38	5FG11480	ROLLER,PAPER FEED	1	1	1
	40	5FG13790	SENSOR	1	1	1
	41	5FG13800	HOLDER,JOINT,SW	1	1	1
	42	5FG13810	LEAF,GROUNDING	1	1	1

SP	Ref. No.	Part. No.	Description	Quantity		
				120V	230V	240V
	43	5FG13820	TENSION	1	1	1
	44	5FG13830	LEVER,	1	1	1
	45	5FG13840	GUIDE,PIN	1	1	1
	501	5AH10870	SCREW,TAPPING,PAN HEAD,M4X10	1	1	1
	502	5AH10890	PIN,DOWEL	1	1	1

- Parts with "●" are component parts or sub-assemblies of the assembly appearing immediately above them.
- Parts with "●" indicates the Service parts.




FIG. Q20 STACK MOTOR DRIVER ASSEMBLY

5FG

SP	Ref. No.	Part. No.	Description	Quantity		
				120V	230V	240V
●	1	5FG13520	STACK MOTOR DRIVER ASSEMBLY	1	1	1
●	2	•5FG10020	GEAR,16T/40T	1	1	1
●	3	•5FG10030	GEAR,16T/45T	1	1	1
●	4	•5FG10040	GEAR,16T/45T	1	1	1
●	5	•5FG10050	PULLEY,56T	1	1	1
●	6	•5FG12500	CABLE,SHIFT MOTOR	1	1	1
●	7	•5FG11310	MOTOR,DC24V	1	1	1
●	8	•5FG11860	SCREW M4X7	3	3	3
●	9	•5FG12410	SCREW,W/WASHER,M3X6	2	2	2
●	10	•5FG11770	CLIP	5	5	5
●	11	•5FG11050	BUSHING	2	2	2
●	12	•5C111230	PHOTO INTERRUPTER B	2	2	2
●	13	•5FG12510	BELT,TIMING	1	1	1
●	501	•5FG12520	FIAG,CLOCK SENSOR	1	1	1
●	502	•5AH10890	PIN,DOWEL	2	2	2
●		•5FG12460	PIN,DOWEL	1	1	1

- Parts with "•" are component parts or sub-assemblies of the assembly appearing immediately above them.
- Parts with "●" indicates the Service parts.




FIG. Q22 DRIVE ASSEMBLY

5FG

SP	Ref. No.	Part. No.	Description	Quantity		
				120V	230V	240V
		5FG13530	DRIVE ASSEMBLY	1	1	1
●	1	•5FG10250	GEAR,58T	1	1	1
●	2	•5FG10260	GEAR,23T	2	2	2
●	3	•5FG10270	GEAR,17T/65T	1	1	1
●	4	•5FG10280	GEAR,15T/54T	1	1	1
●	5	•5FG10290	GEAR,17T/29T	1	1	1
●	6	•5FG10300	GEAR,20T	1	1	1
●	7	•5FG10310	PULLEY,45T	1	1	1
●	8	•5FG10360	GEAR,82T	1	1	1
●	9	•5FG12530	CLIP,SHAFT	1	1	1
●	10	•5FG11920	CLIP,SHAFT	1	1	1
●	11	•5FG10840	BUSHING	1	1	1
●	12	•5FG10850	BUSHING	1	1	1
	13	•5FG11860	SCREW M4X7	1	1	1
●	14	•5FG11040	BEARING,BALL	1	1	1
●	15	•5FG11130	BELT,TIMING	1	1	1
●	16	•5FG10240	GEAR,29T	1	1	1
	17	•5FG12540	SCREW,M4X6	1	1	1
●	18	•5FG10320	FLAG,CLOCK SENSOR	1	1	1
●	19	•5FG11320	MOTOR,DC24V	1	1	1
●	20	•5FG11350	PHOTO-INTERRUPTER	1	1	1
●	21	•5FG10640	SPRING,COMPRESSION	1	1	1
	22	•5FG12550	CABLE,STEPLER	1	1	1
	23	•5FG12560	SCREW,STEPPED,M4	1	1	1
●	501	•5FG12460	PIN,DOWEL	1	1	1
●	502	•5FG12570	PIN,DOWEL	1	1	1
●	503	•5AH10890	PIN,DOWEL	1	1	1

- Parts with "•" are component parts or sub-assemblies of the assembly appearing immediately above them.
- Parts with "●" indicates the Service parts.




FIG. Q24 BUNDLE SUPPORT COVER ASSEMBLY

5FG

SP	Ref. No.	Part. No.	Description	Quantity		
				120V	230V	240V
		5FG13540	BUNDLE SUPPORT COVER ASSEMBLY	1	1	1
	1	•5FG12040	CABLE SENSOR	1	1	1
	2	•5FG11860	SCREW M4X7	2	2	2
●	3	•5FG10670	SPRING,TENSION	1	1	1
●	4	•5FG10710	SPRING,COMPRESSION	1	1	1
●	5	•5FG10490	ROLLER,TENSIONER	1	1	1
	6	•5FG11770	CLIP	1	1	1
	7	•5FG12580	SHAFT,SUPPORT	1	1	1
●	8	•5FG10190	GEAR,20T/28T	1	1	1
	9	•5FG12590	FIAG,PAPER SENSOR	1	1	1
●	10	•5FG10330	GEAR,5T	1	1	1
●	11	•5FG12600	BUSHING	1	1	1
●	12	•5FG10720	SPRING,TORSION	1	1	1
●	13	•5FG10730	SPRING,TORSION	1	1	1
●	14	•5FG10740	SPRING,TORSION	1	1	1
	15	•5FG12010	COVER BLANKING	1	1	1
●	16	•5FG11230	FLAG,BUNDLE ROLLER	1	1	1
	17	•5FG12620	SUPPORT,PAPER	1	1	1
	18	•5FG12630	HOLDER,PAPER SUPPORT	1	1	1
	19	•5FG13850	TENSION,HOLDERGEAR	1	1	1

- Parts with "•" are component parts or sub-assemblies of the assembly appearing immediately above them.
- Parts with "●" indicates the Service parts.


FIG. Q30 DISPOSE ASSEMBLY

SP	Ref. No.	Part. No.	Description	Quantity		
				120V	230V	240V
		5FG13550	DISPOSE ASSEMBLY	1	1	1
●	1	•5FG10580	SPRING TENSION	1	1	1
	2	•5FG12040	CABLE SENSOR	1	1	1
	3	•5FG11860	SCREW M4X7	18	18	18
●	4	•5FG11070	BELT,TIMING	2	2	2
●	5	•5FG11160	LEVER,BELT SENSOR	1	1	1
●	6	•5FG10530	BELT,TIMING	2	2	2
●	7	•5FG10600	SPRING,TORSION	1	1	1
	8	•5FG12640	COVER,DISPOSE	1	1	1
	9	•5FG12650	DEFLECTOR,WEIGHT	1	1	1
	10	•5FG12660	CABLE,TRAY	1	1	1
●	11	•5FG11300	MOTOR,STEPPING	2	2	2
	12	•5FG12410	SCREW,W/WASHER,M3X6	6	6	6
	13	•5FG12670	GUIDE,TRAY,FRONT	1	1	1
●	14	•5C111230	PHOTO INTERRUPTER B	5	5	5
●	15	•5FG10090	GEAR,30T	1	1	1
●	16	•5FG11380	COVER,DISPOSE,SUB	1	1	1
●	17	•5FG10480	PULLEY,22T	1	1	1
●	18	•5FG11470	ROLLER,BUNDLE,LOWER	2	2	2
●	19	•5FG11920	CLIP,SHAFT	5	5	5
●	20	•5FG10840	BUSHING	2	2	2
●	21	•5FG10880	SPRING,COMPRESSION	1	1	1
	22	•5FG12680	FLANGE	2	2	2
	23	•5FG12690	SUPPORT,SENSOR FLAG	1	1	1
●	24	•5FG11170	FLAG,SENSOR	1	1	1
●	25	•5FG10620	SPRING,TENSION	1	1	1
	26	•5FG12700	CABLE,EJECT MOTOR	1	1	1
●	27	•5FG10110	PULLEY,22T	2	2	2
	28	•5FG12710	GUIDE,TRAY,REAR	1	1	1
	29	•5FG11770	CLIP	2	2	2
●	30	•5FG11050	BUSHING	2	2	2
	31	•5FG12720	SPRING,LEAT	2	2	2
	32	•5FG13560	GUIDE,PAPER FEED,FRONT	1	1	1
●	33	•5FG11230	FLAG,BUNDLE ROLLER	1	1	1
●	34	•5FG11290	MOTOR,STEPPING	2	2	2
	35	•5FG12730	GUIDE,PAPER FEED,REAR	1	1	1
	36	•5FG12740	RACK,ADJUSTMENT,FRONT	1	1	1
●	37	•5FG04230	FRONT COVER A,SIDE REGISTRATION	1	1	1
●	38	•5FG04240	FRONT COVER B,SIDE REGISTRATION	1	1	1
●	39	•5FG10590	SPRING,COMPRESSION	3	3	3

5FG

SP	Ref. No.	Part. No.	Description	Quantity		
				120V	230V	240V
	40	•5FG12750	RACK,ADJUSTMENT,REAR	1	1	1
●	41	•5FG04250	REAR COVER,SIDE REGISTRATION	1	1	1
	42	•5FG12760	HOLDER,MICROSWITCH	1	1	1
	43	•5FG12770	COVER,MICROSWITCH	1	1	1
●	44	•5FG11240	MICROSWITCH	2	2	2
	45	•5FG13860	DEFLECTOR,WEIGHT,R	1	1	1
	46	•5FG13870	DEFLECTOR,WEIGHT,F	1	1	1
	47	•5FG13880	SHEET,DW,F	1	1	1
	48	•5FG13690	SHEET,DW,R	1	1	1
	49	•5FG13890	SHEET DISPOSE,TRAY	1	1	1
	50	•5FG13900	SHEET SEIGO	1	1	1
	51	•5FG13910	SHEET,DW,M	2	2	2
	52	•5FG13920	WEIGHT,PAPER,SENSOR	1	1	1
	53	•5FG13660	COVER,PAPER,GUIDE	1	1	1
	54	•5FG13930	WEIGHT,LIB	1	1	1
	55	•5FG13940	HOLDER,MICROSWITCH,F	1	1	1
	56	•5FG13950	HOLDER,MICROSWITCH,R	1	1	1
	501	•5AH10870	SCREW,TAPPING,PAN HEAD,M4X10	2	2	2
	502	•5AH10890	PIN,DOWEL	3	3	3
	503	•59904480	PIN,DOWEL	2	2	2

- Parts with "•" are component parts or sub-assemblies of the assembly appearing immediately above them.
- Parts with "●" indicates the Service parts.



NOTE : This assembly is included in the assembly shown in Figure Q30.

FIG. Q32 PAPER FEEDER ASSEMBLY

5FG

SP	Ref. No.	Part. No.	Description	Quantity		
				120V	230V	240V
		5FG13570	PAPER FEEDER ASSEMBLY	1	1	1
●	1	•5FG12780	FLANGE	1	1	1
●	2	•5FG10140	PULLEY,20T	1	1	1
●	3	•5FG12790	GUIDE,PAPER AUXILIARY	1	1	1
●	4	•5FG10520	SPRING,TENSION	2	2	2
●	5	•5FG10610	SPRING,TENSION	2	2	2
●	6	•5FG10790	CLAW,FRONT	1	1	1
●	7	•5FG10800	CLAW,REAR	1	1	1
●	8	•5FG11860	SCREW M4X7	4	4	4
●	9	•5FG11770	CLIP	12	12	12
●	10	•5FG10070	PULLEY,40T	1	1	1
●	11	•5FG10080	PULLEY,18T/29T	1	1	1
●	12	•5FG10100	GEAR,20T/PULLEY,32T	1	1	1
●	13	•5FG12800	FLANGE	2	2	2
●	14	•5FG10120	GEAR,20T	1	1	1
●	15	•5FG10130	GEAR,30T/PULLEY,20T	1	1	1
●	16	•5FG11180	FLAG,SENSOR	1	1	1
●	17	•5FG10340	CAM	2	2	2
	18	•5FG12810	ARM,LINK(1)	1	1	1
	19	•5FG12820	SUPPORT,PADDLE SHAFT	1	1	1
	20	•5FG12830	ARM,LINK(2)	2	2	2
	21	•5FG12840	ARM LINK (3)	2	2	2
●	22	•5FG10380	PULLEY,24T	1	1	1
●	23	•5FG12850	ARM,LINK(4)	1	1	1
●	24	•5FG11010	SPRING,COMPRESSION	1	1	1
	25	•5FG12860	FLANGE	1	1	1
●	26	•5FG12870	GUIDE,SAFTY,REAR 1	1	1	1
●	27	•5FG11050	BUSHING	6	6	6
●	28	•5FG11230	FLAG,BUNDLE ROLLER	2	2	2
●	29	•5FG11060	BELT,TIMING	1	1	1
●	30	•5FG11100	BELT,TIMING	1	1	1
●	31	•5FG12880	GUIDE,PAPER OUTLET,UPPER	1	1	1
●	32	•5FG10750	ELIMINATOR,STATIC CHARGE	1	1	1
●	33	•5FG12890	GUIDE,SAFTY,REAR 2	1	1	1
●	34	•5FG11520	ROLLER,PAPER OUTLET	2	2	2
●	35	•5FG12900	ROLLER,PAPER OUTLET	1	1	1
●	36	•5FG11620	ROLLER,FEED	2	2	2
●	37	•5FG11540	ROLLER,PAPER OUTLET,1	2	2	2
●	38	•5FG11550	ROLLER,PAPER OUTLET,2	2	2	2
●	41	•5FG11220	CAM,SENSOR FLAG	1	1	1

SP	Ref. No.	Part. No.	Description	Quantity		
				120V	230V	240V
	42	•5FG12920	FLANGE	1	1	1
	43	•5FG13590	GUIDE,PAPER,LOWER	1	1	1
●	44	•5FG10160	GEAR,14T	2	2	2
●	45	•5FG10150	GEAR,14T	2	2	2
	46	•5FG12930	HOLDER,ROLLER,FRONT 1	1	1	1
	47	•5FG12940	HOLDER,ROLLER,FRONT 2	1	1	1
●	48	•5FG11460	ROLLER,BUNDLE,UPPER	2	2	2
	49	•5FG13600	GUIDE,SAFTY,FRONT 2	1	1	1
	50	•5FG14840	HOLDER,ROLLER,REAR 1	1	1	1
	51	•5FG14850	HOLDER,ROLLER,REAR 2	1	1	1
	52	•5FG12950	GUIDE,SAFTY,FRONT 1	1	1	1
	53	•5FG13670	HOLDER,PADDLE,1	1	1	1
	54	•5FG13580	PADDLE,1	4	4	4
	55	•5FG13960	JUMP,GUIDE	4	4	4
	56	•5FG13970	PADDLE(2)	3	3	3
	57	•5FG13980	HOLDER PADDLE(2)	6	6	6
	58	•5FG13990	GUIDO RIBU	4	4	4
	59	•5FG14000	ARM,LINK	1	1	1
●	501	•5AH10890	PIN,DOWEL	21	21	21
	502	•5AH10870	SCREW,TAPPING,PAN HEAD,M4X10	2	2	2

- Parts with "●" are component parts or sub-assemblies of the assembly appearing immediately above them.
- Parts with "●" indicates the Service parts.




FIG. Q35 FOLD ASSEMBLY (1/3)

5FG

SP	Ref. No.	Part. No.	Description	Quantity		
				120V	230V	240V
		5FG13610	FOLD ASSEMBLY	1	1	1
	1	•5FG12980	GUIDE, SWING, FRONT	1	1	1
	2	•5FG12990	GUIDE, SWING REAR	1	1	1
●	3	•5FG10200	GEAR, 8T	1	1	1
●	4	•5FG10210	CAM, FRONT	1	1	1
●	5	•5FG10220	CAM, REAR	1	1	1
●	6	•5FG10230	CAM, SADDLE, FRONT	1	1	1
●	7	•5FG10350	PULLEY, 36T	1	1	1
	8	•5FG13620	FLANGE	1	1	1
●	9	•5FG10370	GEAR, 16T	2	2	2
	10	•5FG13000	PIN, SADDLE, SLIDER	2	2	2
●	11	•5FG10400	PULLEY, 27T	1	1	1
●	12	•5FG10410	GEAR, 16T/41T	1	1	1
●	13	•5FG10420	GEAR, 15T/38T	1	1	1
●	14	•5FG10430	GEAR, 24T	1	1	1
	15	•5FG13010	HOLDER, ROLLER	2	2	2
●	16	•5FG10440	GEAR, 24T	1	1	1
●	17	•5FG10450	CAM, SADDLE REAR	1	1	1
●	18	•5FG10460	GEAR, 24T	1	1	1
●	19	•5FG10470	GEAR, 16T	1	1	1
●	20	•5FG10500	GEAR, 16T/42T	1	1	1
●	21	•5FG10510	GEAR, 21T	1	1	1
●	22	•5FG11500	ROLLER, FOLD	1	1	1
●	23	•5FG10540	SPRING COMPRESSION	1	1	1
●	24	•5FG10550	SPRING TENSION	2	2	2
●	25	•5FG10560	SPRING TENSION	2	2	2
●	26	•5FG10570	SPRING TENSION	2	2	2
●	27	•5FG10630	SPRING, TENSION	2	2	2
●	28	•5FG11510	ROLLER	1	1	1
	29	•5FG13020	PULLEY, 27T	1	1	1
	30	•5FG13030	HOOK, SPRING	4	4	4
	31	•5FG13040	WASHER	2	2	2
	32	•5FG13050	BUSHING	2	2	2
●	33	•5FG12530	CLIP, SHAFT	8	8	8
●	34	•5FG11920	CLIP, SHAFT	9	9	9
	35	•5FG13060	SCREW	1	1	1
	36	•5FG10850	BUSHING	8	8	8
	37	•5FG13070	ROLLER, LINK	2	2	2
●	38	•5FG11020	GEAR, 18T	1	1	1
●	39	•5FG11030	GEAR, 17T	1	1	1
	40	•5FG13080	GUIDE, PAPER DELIVERY, LOWER	1	1	1
	41	•5FG13090	CABLE, CONNECTING	1	1	1

SP	Ref. No.	Part. No.	Description	Quantity		
				120V	230V	240V
●	42	•5FG11340	CLUTCH, ELECTROMAGNETIC	1	1	1
	43	•5FG13100	SCREW, STEPPED, M3	2	2	2
	44	•5FG11860	SCREW M4X7	30	30	30
●	45	•5FG11250	LED PCB UNIT	1	1	1
●	46	•5FG13110	CLIP	12	12	12
●	47	•5FG11040	BEARING, BALL	4	4	4
●	48	•5FG11050	BUSHING	5	5	5
	49	•5FG13120	BELT, TIMING	1	1	1
	50	•5FG13130	SPRING, LEAF	1	1	1
●	51	•5FG13140	CLIP, SHAFT	4	4	4
●	52	•5FG11560	ROLLER, FOLD	2	2	2
●	53	•5FG11570	ROLLER, FOLD, SUB	4	4	4
●	54	•5C11230	PHOTO INTERRUPTER B	2	2	2
	55	•5FG13150	SPRING, LEAF	2	2	2
	56	•5FG13160	SPRING, LEAF	4	4	4
	57	•5FG13170	GUIDE, DELIVERY PAPER	1	1	1
	58	•5FG13180	PLATE, REINFORCEMENT	2	2	2
	59	•5FG13190	ROLLER, FOLD	1	1	1
	60	•5FG13200	HOLDER, DELIVERY ROLLER	1	1	1
	61	•5FG13210	GUIDE, FOLD ROLLER, 1	1	1	1
	62	•5FG13220	HOLDER, GUIDE, FRONT 1	1	1	1
	63	•5FG13230	HOLDER, GUIDE REAR 1	1	1	1
	64	•5FG13240	GUIDE, FOLD ROLLER, 2	1	1	1
	65	•5FG13250	HOLDER, GUIDE, FRONT, 2	1	1	1
	66	•5FG13260	HOLDER, GUIDE, REAR, 2	1	1	1
	67	•5FG13270	GUIDE, PAPER, UPPER	1	1	1
	68	•5FG13280	ROLLER, LINK	2	2	2
	69	•5FG13290	GUIDE, PAPER, LOWER	1	1	1
	70	•5FG13300	SPRING, LEAF, GROUNDING	1	1	1
	71	•5FG13310	SHAFT, LINK	2	2	2
●	72	•5FG11530	ROLLER	2	2	2
●	73	•5FG10810	SPRING, TENSION	2	2	2
●	74	•5FG11420	ROLLER, SADDLE	2	2	2
	75	•5FG13320	PLATE, OPENER, FRONT	1	1	1
	76	•5FG13330	PLATE, OPENER, REAR	1	1	1
	77	•5FG13340	LINK, COVER	2	2	2
	501	•5FG13350	SCREW, MACH, TRUSS HEAD, M4X10	2	2	2
●	502	•5AH14160	PIN, DOWEL	2	2	2
●	503	•5FG12460	PIN, DOWEL	2	2	2
●	504	•5FG12470	PIN, DOWEL	4	4	4
●	505	•5C114200	PARALLEL PIN	2	2	2
●	506	•5FG12570	PIN, DOWEL	3	3	3

- Parts with "•" are component parts or sub-assemblies of the assembly appearing immediately above them.
- Parts with "●" indicates the Service parts.




FIG. Q35 FOLD ASSEMBLY (2/3)

5FG

SP	Ref. No.	Part. No.	Description	Quantity		
				120V	230V	240V
		5FG13610	FOLD ASSEMBLY	1	1	1
	1	•5FG12980	GUIDE, SWING, FRONT	1	1	1
	2	•5FG12990	GUIDE, SWING REAR	1	1	1
●	3	•5FG10200	GEAR, 8T	1	1	1
●	4	•5FG10210	CAM, FRONT	1	1	1
●	5	•5FG10220	CAM, REAR	1	1	1
●	6	•5FG10230	CAM, SADDLE, FRONT	1	1	1
●	7	•5FG10350	PULLEY, 36T	1	1	1
	8	•5FG13620	FLANGE	1	1	1
●	9	•5FG10370	GEAR, 16T	2	2	2
	10	•5FG13000	PIN, SADDLE, SLIDER	2	2	2
●	11	•5FG10400	PULLEY, 27T	1	1	1
●	12	•5FG10410	GEAR, 16T/41T	1	1	1
●	13	•5FG10420	GEAR, 15T/38T	1	1	1
●	14	•5FG10430	GEAR, 24T	1	1	1
	15	•5FG13010	HOLDER, ROLLER	2	2	2
●	16	•5FG10440	GEAR, 24T	1	1	1
●	17	•5FG10450	CAM, SADDLE REAR	1	1	1
●	18	•5FG10460	GEAR, 24T	1	1	1
●	19	•5FG10470	GEAR, 16T	1	1	1
●	20	•5FG10500	GEAR, 16T/42T	1	1	1
●	21	•5FG10510	GEAR, 21T	1	1	1
●	22	•5FG11500	ROLLER, FOLD	1	1	1
●	23	•5FG10540	SPRING COMPRESSION	1	1	1
●	24	•5FG10550	SPRING TENSION	2	2	2
●	25	•5FG10560	SPRING TENSION	2	2	2
●	26	•5FG10570	SPRING TENSION	2	2	2
●	27	•5FG10630	SPRING, TENSION	2	2	2
●	28	•5FG11510	ROLLER	1	1	1
	29	•5FG13020	PULLEY, 27T	1	1	1
	30	•5FG13030	HOOK, SPRING	4	4	4
	31	•5FG13040	WASHER	2	2	2
	32	•5FG13050	BUSHING	2	2	2
●	33	•5FG12530	CLIP, SHAFT	8	8	8
●	34	•5FG11920	CLIP, SHAFT	9	9	9
	35	•5FG13060	SCREW	1	1	1
	36	•5FG10850	BUSHING	8	8	8
	37	•5FG13070	ROLLER, LINK	2	2	2
●	38	•5FG11020	GEAR, 18T	1	1	1
●	39	•5FG11030	GEAR, 17T	1	1	1
	40	•5FG13080	GUIDE, PAPER DELIVERY, LOWER	1	1	1
	41	•5FG13090	CABLE, CONNECTING	1	1	1

SP	Ref. No.	Part. No.	Description	Quantity		
				120V	230V	240V
●	42	•5FG11340	CLUTCH, ELECTROMAGNETIC	1	1	1
	43	•5FG13100	SCREW, STEPPED, M3	2	2	2
	44	•5FG11860	SCREW M4X7	30	30	30
●	45	•5FG11250	LED PCB UNIT	1	1	1
●	46	•5FG13110	CLIP	12	12	12
●	47	•5FG11040	BEARING, BALL	4	4	4
●	48	•5FG11050	BUSHING	5	5	5
	49	•5FG13120	BELT, TIMING	1	1	1
	50	•5FG13130	SPRING, LEAF	1	1	1
●	51	•5FG13140	CLIP, SHAFT	4	4	4
●	52	•5FG11560	ROLLER, FOLD	2	2	2
●	53	•5FG11570	ROLLER, FOLD, SUB	4	4	4
●	54	•5C11230	PHOTO INTERRUPTER B	2	2	2
	55	•5FG13150	SPRING, LEAF	2	2	2
	56	•5FG13160	SPRING, LEAF	4	4	4
	57	•5FG13170	GUIDE, DELIVERY PAPER	1	1	1
	58	•5FG13180	PLATE, REINFORCEMENT	2	2	2
	59	•5FG13190	ROLLER, FOLD	1	1	1
	60	•5FG13200	HOLDER, DELIVERY ROLLER	1	1	1
	61	•5FG13210	GUIDE, FOLD ROLLER, 1	1	1	1
	62	•5FG13220	HOLDER, GUIDE, FRONT 1	1	1	1
	63	•5FG13230	HOLDER, GUIDE REAR 1	1	1	1
	64	•5FG13240	GUIDE, FOLD ROLLER, 2	1	1	1
	65	•5FG13250	HOLDER, GUIDE, FRONT, 2	1	1	1
	66	•5FG13260	HOLDER, GUIDE, REAR, 2	1	1	1
	67	•5FG13270	GUIDE, PAPER, UPPER	1	1	1
	68	•5FG13280	ROLLER, LINK	2	2	2
	69	•5FG13290	GUIDE, PAPER, LOWER	1	1	1
	70	•5FG13300	SPRING, LEAF, GROUNDING	1	1	1
	71	•5FG13310	SHAFT, LINK	2	2	2
●	72	•5FG11530	ROLLER	2	2	2
●	73	•5FG10810	SPRING, TENSION	2	2	2
●	74	•5FG11420	ROLLER, SADDLE	2	2	2
	75	•5FG13320	PLATE, OPENER, FRONT	1	1	1
	76	•5FG13330	PLATE, OPENER, REAR	1	1	1
	77	•5FG13340	LINK, COVER	2	2	2
	501	•5FG13350	SCREW, MACH, TRUSS HEAD, M4X10	2	2	2
●	502	•5AH14160	PIN, DOWEL	2	2	2
●	503	•5FG12460	PIN, DOWEL	2	2	2
●	504	•5FG12470	PIN, DOWEL	4	4	4
●	505	•5C114200	PARALLEL PIN	2	2	2
●	506	•5FG12570	PIN, DOWEL	3	3	3

- Parts with "•" are component parts or sub-assemblies of the assembly appearing immediately above them.
- Parts with "●" indicates the Service parts.




FIG. Q35 FOLD ASSEMBLY (3/3)

5FG

SP	Ref. No.	Part. No.	Description	Quantity		
				120V	230V	240V
		5FG13610	FOLD ASSEMBLY	1	1	1
	1	•5FG12980	GUIDE, SWING, FRONT	1	1	1
	2	•5FG12990	GUIDE, SWING REAR	1	1	1
●	3	•5FG10200	GEAR, 8T	1	1	1
●	4	•5FG10210	CAM, FRONT	1	1	1
●	5	•5FG10220	CAM, REAR	1	1	1
●	6	•5FG10230	CAM, SADDLE, FRONT	1	1	1
●	7	•5FG10350	PULLEY, 36T	1	1	1
	8	•5FG13620	FLANGE	1	1	1
●	9	•5FG10370	GEAR, 16T	2	2	2
	10	•5FG13000	PIN, SADDLE, SLIDER	2	2	2
●	11	•5FG10400	PULLEY, 27T	1	1	1
●	12	•5FG10410	GEAR, 16T/41T	1	1	1
●	13	•5FG10420	GEAR, 15T/38T	1	1	1
●	14	•5FG10430	GEAR, 24T	1	1	1
	15	•5FG13010	HOLDER, ROLLER	2	2	2
●	16	•5FG10440	GEAR, 24T	1	1	1
●	17	•5FG10450	CAM, SADDLE REAR	1	1	1
●	18	•5FG10460	GEAR, 24T	1	1	1
●	19	•5FG10470	GEAR, 16T	1	1	1
●	20	•5FG10500	GEAR, 16T/42T	1	1	1
●	21	•5FG10510	GEAR, 21T	1	1	1
●	22	•5FG11500	ROLLER, FOLD	1	1	1
●	23	•5FG10540	SPRING COMPRESSION	1	1	1
●	24	•5FG10550	SPRING TENSION	2	2	2
●	25	•5FG10560	SPRING TENSION	2	2	2
●	26	•5FG10570	SPRING TENSION	2	2	2
●	27	•5FG10630	SPRING, TENSION	2	2	2
●	28	•5FG11510	ROLLER	1	1	1
	29	•5FG13020	PULLEY, 27T	1	1	1
	30	•5FG13030	HOOK, SPRING	4	4	4
	31	•5FG13040	WASHER	2	2	2
	32	•5FG13050	BUSHING	2	2	2
●	33	•5FG12530	CLIP, SHAFT	8	8	8
●	34	•5FG11920	CLIP, SHAFT	9	9	9
	35	•5FG13060	SCREW	1	1	1
	36	•5FG10850	BUSHING	8	8	8
	37	•5FG13070	ROLLER, LINK	2	2	2
●	38	•5FG11020	GEAR, 18T	1	1	1
●	39	•5FG11030	GEAR, 17T	1	1	1
	40	•5FG13080	GUIDE, PAPER DELIVERY, LOWER	1	1	1
	41	•5FG13090	CABLE, CONNECTING	1	1	1

SP	Ref. No.	Part. No.	Description	Quantity		
				120V	230V	240V
●	42	•5FG11340	CLUTCH, ELECTROMAGNETIC	1	1	1
	43	•5FG13100	SCREW, STEPPED, M3	2	2	2
	44	•5FG11860	SCREW M4X7	30	30	30
●	45	•5FG11250	LED PCB UNIT	1	1	1
●	46	•5FG13110	CLIP	12	12	12
●	47	•5FG11040	BEARING, BALL	4	4	4
●	48	•5FG11050	BUSHING	5	5	5
	49	•5FG13120	BELT, TIMING	1	1	1
	50	•5FG13130	SPRING, LEAF	1	1	1
●	51	•5FG13140	CLIP, SHAFT	4	4	4
●	52	•5FG11560	ROLLER, FOLD	2	2	2
●	53	•5FG11570	ROLLER, FOLD, SUB	4	4	4
●	54	•5C111230	PHOTO INTERRUPTER B	2	2	2
	55	•5FG13150	SPRING, LEAF	2	2	2
	56	•5FG13160	SPRING, LEAF	4	4	4
	57	•5FG13170	GUIDE, DELIVERY PAPER	1	1	1
	58	•5FG13180	PLATE, REINFORCEMENT	2	2	2
	59	•5FG13190	ROLLER, FOLD	1	1	1
	60	•5FG13200	HOLDER, DELIVERY ROLLER	1	1	1
	61	•5FG13210	GUIDE, FOLD ROLLER, 1	1	1	1
	62	•5FG13220	HOLDER, GUIDE, FRONT 1	1	1	1
	63	•5FG13230	HOLDER, GUIDE REAR 1	1	1	1
	64	•5FG13240	GUIDE, FOLD ROLLER, 2	1	1	1
	65	•5FG13250	HOLDER, GUIDE, FRONT, 2	1	1	1
	66	•5FG13260	HOLDER, GUIDE, REAR, 2	1	1	1
	67	•5FG13270	GUIDE, PAPER, UPPER	1	1	1
	68	•5FG13280	ROLLER, LINK	2	2	2
	69	•5FG13290	GUIDE, PAPER, LOWER	1	1	1
	70	•5FG13300	SPRING, LEAF, GROUNDING	1	1	1
	71	•5FG13310	SHAFT, LINK	2	2	2
●	72	•5FG11530	ROLLER	2	2	2
●	73	•5FG10810	SPRING, TENSION	2	2	2
●	74	•5FG11420	ROLLER, SADDLE	2	2	2
	75	•5FG13320	PLATE, OPENER, FRONT	1	1	1
	76	•5FG13330	PLATE, OPENER, REAR	1	1	1
	77	•5FG13340	LINK, COVER	2	2	2
	501	•5FG13350	SCREW, MACH, TRUSS HEAD, M4X10	2	2	2
●	502	•5AH14160	PIN, DOWEL	2	2	2
●	503	•5FG12460	PIN, DOWEL	2	2	2
●	504	•5FG12470	PIN, DOWEL	4	4	4
●	505	•5C114200	PARALLEL PIN	2	2	2
●	506	•5FG12570	PIN, DOWEL	3	3	3

- Parts with "•" are component parts or sub-assemblies of the assembly appearing immediately above them.
- Parts with "●" indicates the Service parts.




FIG. Q40 STAPLE ASSEMBLY (1/2)

SP	Ref. No.	Part. No.	Description	Quantity		
				120V	230V	240V
●	1	5FG13630	STAPLE ASSEMBLY	1	1	1
●	2	•5FG11520	ROLLER,PAPER OUTLET	1	1	1
●	3	•5FG10860	SPRING,TENSION	1	1	1
	4	•5FG13360	COVER,MOTOR	1	1	1
	5	•5FG13370	FRAME,COUPLING	1	1	1
	6	•5FG13380	SUPPORT,CAM STOPPER,1	1	1	1
●	7	•5FG10870	COUPLING	1	1	1
●	8	•5FG10880	SPRING,COMPRESSION	1	1	1
	9	•5FG13390	HOLDER,STAPLE GUIDE ROLLER	1	1	1
	10	•5FG13400	ROLLER,STAPLE GUIDE	2	2	2
	11	•5FG13410	SPRING,TORSION	1	1	1
●	12	•5FG10900	PULLEY,38T	1	1	1
●	13	•5FG10910	GEAR,36T/PULLEY,38T	1	1	1
●	14	•5FG11390	KNOB,STAPLE MOVABLE	1	1	1
●	15	•5FG10920	GEAR,42T/PULLEY,32T	1	1	1
●	16	•5FG10930	PULLEY,24T	1	1	1
	17	•5FG13420	BELT,TIMING	1	1	1
	18	•5FG04260	HANDLE B,JAM RELEASE	1	1	1
	19	•5FG13430	CLIP	1	1	1
	20	•5FG12410	SCREW,W/WASHER,M3X6	2	2	2
	21	•5FG13440	SCREW,W/WASHER,M3X6	1	1	1
	22	•5FG13450	SCREW,M3X6	1	1	1
●	23	•5FG11400	PANEL,FRONT	1	1	1
	24	•5FG04270	COVER,HANDLE	1	1	1
	25	•5FG13460	COVER,SIDE,RIGHT	1	1	1
	26	•5FG13470	COVER,SIDE,LEFT	1	1	1
	27	•5FG13480	GUIDE,PAPER	1	1	1
●	28	•5FG10990	GEAR,32T	1	1	1
	29	•5FG13490	GUIDE,PAPER,SUB	1	1	1
	30	•5FG13500	PIN,MARKER	1	1	1
	31	•5FG14010	COVER,GEAR	1	1	1
	32	•5FG14020	GEAR,42T	1	1	1
	33	•5FG14030	PLATE,TENSIONER	1	1	1
	34	•5FG14040	SCREW,TAPPING,M3X6	4	4	4
	35	•5FG11630	STAPLE CARTRIDGE UNIT	1	1	1
	36	•5FG14050	PIN,SLIDE	2	2	2
	37	•5FG11580	ROLLER	2	2	2
	38	•5FG14060	STAPLER BASE PCP ASSEMBLY	1	1	1
	39	•5FG14070	STAPLER IN PCB ASSEMBLY	1	1	1
		•5FG14080	CABLE,STAPLER	1	1	1

5FG

SP	Ref. No.	Part. No.	Description	Quantity		
				120V	230V	240V
	40	•5FG14090	CABLE,STAPLE 1	1	1	1
	41	•5FG14100	CABLE,STAPLE 2	1	1	1
	42	•5FG11330	MOTOR,STEPPING	1	1	1
	43	•5FG14110	FLANGE	1	1	1
	44	•5FG14120	GEAR	1	1	1
	45	•5FG14130	SPRING,TENSION	1	1	1
	46	•5FG14140	SUPPORT,STAPLE TENSIONER	1	1	1
	47	•5FG14150	ROLLER,TENSIONER	1	1	1
	48	•5FG10940	GEAR,18T/66T	1	1	1
	49	•5FG14160	BELT,TIMING	1	1	1
	50	•5FG14170	GUIDO	1	1	1
	51	•5FG14180	PAD,STAPLE GUIDE	1	1	1
	52	•5FG14190	BUSHING	1	1	1
	53	•5FG14200	GEAR,16T/PULLEY29T	1	1	1
	54	•5FG11860	SCREW M4X7	1	1	1
	501	•5AH08970	RING,E	4	4	4
	502	•5FG14210	SCREW,MACH,TRUSS HEAD,M3X6	1	1	1
	503	•5AH10870	SCREW,TAPPING,PAN HEAD,M4X10	2	2	2
	504	•5AG10080	RING,E	8	8	8
	505	•5C119790	BIND(N)M4X6	1	1	1
	506	•5FG14220	PIN,DOWEL	3	3	3
	507	•5FG12470	PIN,DOWEL	1	1	1
	508	•5FG12460	PIN,DOWEL	1	1	1

- Parts with "●" are component parts or sub-assemblies of the assembly appearing immediately above them.
- Parts with "●" indicates the Service parts.




FIG. Q40 STAPLE ASSEMBLY (2/2)

5FG

SP	Ref. No.	Part. No.	Description	Quantity		
				120V	230V	240V
●	1	5FG13630	STAPLE ASSEMBLY	1	1	1
●	2	•5FG11520	ROLLER,PAPER OUTLET	1	1	1
	3	•5FG10860	SPRING,TENSION	1	1	1
	4	•5FG13360	COVER,MOTOR	1	1	1
	5	•5FG13370	FRAME,COUPLING	1	1	1
	6	•5FG13380	SUPPORT,CAM STOPPER,1	1	1	1
●	7	•5FG10870	COUPLING	1	1	1
●	8	•5FG10880	SPRING,COMPRESSION	1	1	1
	9	•5FG13390	HOLDER,STAPLE GUIDE ROLLER	1	1	1
	10	•5FG13400	ROLLER,STAPLE GUIDE	2	2	2
	11	•5FG13410	SPRING,TORSION	1	1	1
●	12	•5FG10900	PULLEY,38T	1	1	1
●	13	•5FG10910	GEAR,36T/PULLEY,38T	1	1	1
●	14	•5FG11390	KNOB,STAPLE MOVABLE	1	1	1
●	15	•5FG10920	GEAR,42T/PULLEY,32T	1	1	1
●	16	•5FG10930	PULLEY,24T	1	1	1
	17	•5FG13420	BELT,TIMING	1	1	1
	18	•5FG04260	HANDLE B,JAM RELEASE	1	1	1
	19	•5FG13430	CLIP	1	1	1
	20	•5FG12410	SCREW,W/WASHER,M3X6	2	2	2
	21	•5FG13440	SCREW,W/WASHER,M3X6	1	1	1
	22	•5FG13450	SCREW,M3X6	1	1	1
●	23	•5FG11400	PANEL,FRONT	1	1	1
	24	•5FG04270	COVER,HANDLE	1	1	1
	25	•5FG13460	COVER,SIDE,RIGHT	1	1	1
	26	•5FG13470	COVER,SIDE,LEFT	1	1	1
	27	•5FG13480	GUIDE,PAPER	1	1	1
●	28	•5FG10990	GEAR,32T	1	1	1
	29	•5FG13490	GUIDE,PAPER,SUB	1	1	1
	30	•5FG13500	PIN,MARKER	1	1	1
	31	•5FG14010	COVER,GEAR	1	1	1
	32	•5FG14020	GEAR,42T	1	1	1
	33	•5FG14030	PLATE,TENSIONER	1	1	1
	34	•5FG14040	SCREW,TAPPING,M3X6	4	4	4
	35	•5FG11630	STAPLE CARTRIDGE UNIT	1	1	1
	36	•5FG14050	PIN,SLIDE	2	2	2
	37	•5FG11580	ROLLER	2	2	2
	38	•5FG14060	STAPLER BASE PCP ASSEMBLY	1	1	1
	39	•5FG14070	STAPLER IN PCB ASSEMBLY	1	1	1
		•5FG14080	CABLE,STAPLER	1	1	1

SP	Ref. No.	Part. No.	Description	Quantity		
				120V	230V	240V
	40	•5FG14090	CABLE,STAPLE 1	1	1	1
	41	•5FG14100	CABLE,STAPLE 2	1	1	1
	42	•5FG11330	MOTOR,STEPPING	1	1	1
	43	•5FG14110	FLANGE	1	1	1
	44	•5FG14120	GEAR	1	1	1
	45	•5FG14130	SPRING,TENSION	1	1	1
	46	•5FG14140	SUPPORT,STAPLE TENSIONER	1	1	1
	47	•5FG14150	ROLLER,TENSIONER	1	1	1
	48	•5FG10940	GEAR,18T/66T	1	1	1
	49	•5FG14160	BELT,TIMING	1	1	1
	50	•5FG14170	GUIDO	1	1	1
	51	•5FG14180	PAD,STAPLE GUIDE	1	1	1
	52	•5FG14190	BUSHING	1	1	1
	53	•5FG14200	GEAR,16T/PULLEY29T	1	1	1
	54	•5FG11860	SCREW M4X7	1	1	1
	501	•5AH08970	RING,E	4	4	4
	502	•5FG14210	SCREW,MACH,TRUSS HEAD,M3X6	1	1	1
	503	•5AH10870	SCREW,TAPPING,PAN HEAD,M4X10	2	2	2
	504	•5AG10080	RING,E	8	8	8
	505	•5C119790	BIND(N)M4X6	1	1	1
	506	•5FG14220	PIN,DOWEL	3	3	3
	507	•5FG12470	PIN,DOWEL	1	1	1
	508	•5FG12460	PIN,DOWEL	1	1	1

- Parts with "●" are component parts or sub-assemblies of the assembly appearing immediately above them.
- Parts with "●" indicates the Service parts.




FIG. Q90 DC CONTROLLER PCB ASSEMBLY

5FG

SP	Ref. No.	Part. No.	Description	Quantity		
				120V	230V	240V
●		5FG14230	DC,CONTROLLER PCP ASSEMBLY	1	1	1
●	1	•5FG14240	IC,M27C1001-80XF,EP-ROM	1	1	1
●	2	•5FG14250	IC,S-93C66ADP,ECP-ROM	1	1	1
●	3	•5FG14260	DOCONTROLLER SUBASSEHPLY	1	1	1

- Parts with "•" are component parts or sub-assemblies of the assembly appearing immediately above them.
- Parts with "●" indicates the Service parts.




FIG. QB1 LIST OF CONNECTORS (1/2)

SP	Ref. No.	Part. No.	Description	Quantity		
				120V	230V	240V
	CN1	5FG14270	CABLE,INTERFACE	1	1	1
	CN2	5FG14270	CABLE,INTERFACE	1	1	1
	CN3	5FG12200	CABLE,JOG MOTOR	1	1	1
	CN4	5FG12150	CABLE,FRONT DOOR SENSOR	1	1	1
	CN5	5FG12160	CABLE,LEVER TRAY SENSOR	1	1	1
	CN6	5FG12440	CABLE,DC MOTOR	1	1	1
	CN7	5FG12550	CABLE,STAPLER	1	1	1
	CN8	5FG14280	CABLE,STWITCH	1	1	1
	CN9	5FG12180	CABLE,SENSOR,3	1	1	1
	CN10	5FG12430	CABLE,FEED PADDLE MOTOR	1	1	1
	CN11	5FG12550	CABLE,STAPLER	1	1	1
	CN13	5FG12700	CABLE,EJECT MOTOR	1	1	1
	CN15	5FG12420	CABLE,SENSOR (1)	1	1	1
	CN16	5FG12170	CABLE SENSOR (2)	1	1	1
	CN18	5FG12220	CABLE,BIND CLUTCH	1	1	1
	CN19	5FG12290	CABLE STACK SENSOR	1	1	1
	CN20	5FG14270	CABLE,INTERFACE	1	1	1
	CN23	5FG12150	CABLE,FRONT DOOR SENSOR	1	1	1
	CN24	5FG12150	CABLE,FRONT DOOR SENSOR	1	1	1
	CN25	5FG12150	CABLE,FRONT DOOR SENSOR	1	1	1
	CN28	5FG12160	CABLE,LEVER TRAY SENSOR	1	1	1
	CN29	5FG12660	CABLE,TRAY	1	1	1
	CN30	5FG12660	CABLE,TRAY	1	1	1
	CN31	5FG12660	CABLE,TRAY	1	1	1
	CN32	5FG12660	CABLE,TRAY	1	1	1
	CN33	5FG12160	CABLE,LEVER TRAY SENSOR	1	1	1
	CN34	5FG12040	CABLE SENSOR	1	1	1
	CN35	5FG12040	CABLE SENSOR	1	1	1
	CN36	5FG12160	CABLE,LEVER TRAY SENSOR	1	1	1
	CN37	5FG12170	CABLE SENSOR (2)	1	1	1
	CN38	5FG13090	CABLE,CONNECTING	1	1	1
	CN39	5FG13090	CABLE,CONNECTING	1	1	1
	CN40	5FG13090	CABLE,CONNECTING	1	1	1
	CN41	5FG13090	CABLE,CONNECTING	1	1	1
	CN42	5FG12170	CABLE SENSOR (2)	1	1	1
	CN43	5FG12040	CABLE SENSOR	1	1	1
	CN44	5FG12040	CABLE SENSOR	1	1	1
	CN47	5FG12420	CABLE,SENSOR (1)	1	1	1
	CN48	5FG12420	CABLE,SENSOR (1)	1	1	1
	CN49	5FG12420	CABLE,SENSOR (1)	1	1	1

5FG

SP	Ref. No.	Part. No.	Description	Quantity		
				120V	230V	240V
	CN50	5FG12420	CABLE,SENSOR (1)	1	1	1
	CN52	5FG12180	CABLE,SENSOR,3	1	1	1
	CN53	5FG12180	CABLE,SENSOR,3	1	1	1
	CN54	5FG12040	CABLE SENSOR	1	1	1
	CN55	5FG12040	CABLE SENSOR	1	1	1
	CN56	5FG12430	CABLE,FEED PADDLE MOTOR	1	1	1
	CN57	5FG12430	CABLE,FEED PADDLE MOTOR	1	1	1
	CN59	5FG12700	CABLE,EJECT MOTOR	1	1	1
	CN62	5FG12200	CABLE,JOG MOTOR	1	1	1
	CN64	5FG12200	CABLE,JOG MOTOR	1	1	1
	CN66	5FG14280	CABLE,SWITCH	1	1	1
	CN68	5FG14280	CABLE,SWITCH	1	1	1
	CN69	5FG14280	CABLE,SWITCH	1	1	1
	CN70/74	5FG12500	CABLE,SHIFT MOTOR	1	1	1
	CN74	5FG12440	CABLE,DC MOTOR	1	1	1
	CN70	5FG12500	CABLE,SHIFT MOTOR	1	1	1
	CN71	5FG12440	CABLE,DC MOTOR	1	1	1
	CN73	5FG12220	CABLE,BIND CLUTCH	1	1	1
	CN72	5FG12550	CABLE,STAPLER	1	1	1
	CN72	5FG14100	CABLE,STAPLE 2	1	1	1
	CN58	5FG12290	CABLE STACK SENSOR	1	1	1
	J1	5FG14080	CABLE,STAPLER	1	1	1
	J1	5FG14100	CABLE,STAPLE 2	1	1	1
	J2	5FG14080	CABLE,STAPLER	1	1	1
	J2	5FG14090	CABLE,STAPLE 1	1	1	1
	JS1	5FG14270	CABLE,INTERFACE	1	1	1
	CN51	5FG12180	CABLE,SENSOR,3	1	1	1

- Parts with "•" are component parts or sub-assemblies of the assembly appearing immediately above them.
- Parts with "●" indicates the Service parts.




FIG. QB1 LIST OF CONNECTORS (2/2)

SP	Ref. No.	Part. No.	Description	Quantity		
				120V	230V	240V
	CN1	5FG14270	CABLE,INTERFACE	1	1	1
	CN2	5FG14270	CABLE,INTERFACE	1	1	1
	CN3	5FG12200	CABLE,JOG MOTOR	1	1	1
	CN4	5FG12150	CABLE,FRONT DOOR SENSOR	1	1	1
	CN5	5FG12160	CABLE,LEVER TRAY SENSOR	1	1	1
	CN6	5FG12440	CABLE,DC MOTOR	1	1	1
	CN7	5FG12550	CABLE,STAPLER	1	1	1
	CN8	5FG14280	CABLE,STWITCH	1	1	1
	CN9	5FG12180	CABLE,SENSOR,3	1	1	1
	CN10	5FG12430	CABLE,FEED PADDLE MOTOR	1	1	1
	CN11	5FG12550	CABLE,STAPLER	1	1	1
	CN13	5FG12700	CABLE,EJECT MOTOR	1	1	1
	CN15	5FG12420	CABLE,SENSOR (1)	1	1	1
	CN16	5FG12170	CABLE SENSOR (2)	1	1	1
	CN18	5FG12220	CABLE,BIND CLUTCH	1	1	1
	CN19	5FG12290	CABLE STACK SENSOR	1	1	1
	CN20	5FG14270	CABLE,INTERFACE	1	1	1
	CN23	5FG12150	CABLE,FRONT DOOR SENSOR	1	1	1
	CN24	5FG12150	CABLE,FRONT DOOR SENSOR	1	1	1
	CN25	5FG12150	CABLE,FRONT DOOR SENSOR	1	1	1
	CN28	5FG12160	CABLE,LEVER TRAY SENSOR	1	1	1
	CN29	5FG12660	CABLE,TRAY	1	1	1
	CN30	5FG12660	CABLE,TRAY	1	1	1
	CN31	5FG12660	CABLE,TRAY	1	1	1
	CN32	5FG12660	CABLE,TRAY	1	1	1
	CN33	5FG12160	CABLE,LEVER TRAY SENSOR	1	1	1
	CN34	5FG12040	CABLE SENSOR	1	1	1
	CN35	5FG12040	CABLE SENSOR	1	1	1
	CN36	5FG12160	CABLE,LEVER TRAY SENSOR	1	1	1
	CN37	5FG12170	CABLE SENSOR (2)	1	1	1
	CN38	5FG13090	CABLE,CONNECTING	1	1	1
	CN39	5FG13090	CABLE,CONNECTING	1	1	1
	CN40	5FG13090	CABLE,CONNECTING	1	1	1
	CN41	5FG13090	CABLE,CONNECTING	1	1	1
	CN42	5FG12170	CABLE SENSOR (2)	1	1	1
	CN43	5FG12040	CABLE SENSOR	1	1	1
	CN44	5FG12040	CABLE SENSOR	1	1	1
	CN47	5FG12420	CABLE,SENSOR (1)	1	1	1
	CN48	5FG12420	CABLE,SENSOR (1)	1	1	1
	CN49	5FG12420	CABLE,SENSOR (1)	1	1	1

5FG

SP	Ref. No.	Part. No.	Description	Quantity		
				120V	230V	240V
	CN50	5FG12420	CABLE,SENSOR (1)	1	1	1
	CN52	5FG12180	CABLE,SENSOR,3	1	1	1
	CN53	5FG12180	CABLE,SENSOR,3	1	1	1
	CN54	5FG12040	CABLE SENSOR	1	1	1
	CN55	5FG12040	CABLE SENSOR	1	1	1
	CN56	5FG12430	CABLE,FEED PADDLE MOTOR	1	1	1
	CN57	5FG12430	CABLE,FEED PADDLE MOTOR	1	1	1
	CN59	5FG12700	CABLE,EJECT MOTOR	1	1	1
	CN62	5FG12200	CABLE,JOG MOTOR	1	1	1
	CN64	5FG12200	CABLE,JOG MOTOR	1	1	1
	CN66	5FG14280	CABLE,SWITCH	1	1	1
	CN68	5FG14280	CABLE,SWITCH	1	1	1
	CN69	5FG14280	CABLE,SWITCH	1	1	1
	CN70/74	5FG12500	CABLE,SHIFT MOTOR	1	1	1
	CN74	5FG12440	CABLE,DC MOTOR	1	1	1
	CN70	5FG12500	CABLE,SHIFT MOTOR	1	1	1
	CN71	5FG12440	CABLE,DC MOTOR	1	1	1
	CN73	5FG12220	CABLE,BIND CLUTCH	1	1	1
	CN72	5FG12550	CABLE,STAPLER	1	1	1
	CN72	5FG14100	CABLE,STAPLE 2	1	1	1
	CN58	5FG12290	CABLE STACK SENSOR	1	1	1
	J1	5FG14080	CABLE,STAPLER	1	1	1
	J1	5FG14100	CABLE,STAPLE 2	1	1	1
	J2	5FG14080	CABLE,STAPLER	1	1	1
	J2	5FG14090	CABLE,STAPLE 1	1	1	1
	JS1	5FG14270	CABLE,INTERFACE	1	1	1
	CN51	5FG12180	CABLE,SENSOR,3	1	1	1

- Parts with "•" are component parts or sub-assemblies of the assembly appearing immediately above them.
- Parts with "●" indicates the Service parts.




FIG. QB2 LIST OF ELECTRIC PARTS (1/2)

5FG

SP	Ref. No.	Part. No.	Description	Quantity		
				120V	230V	240V
●	1	5FG14300	DC,CONTROLLER PCP ASSEMBLY,KM	1	1	1
●	CL1	5FG11340	CLUTCH,ELECTROMAGNETIC	1	1	1
●	M1	5FG14860	MOTOR,STEPPING	1	1	1
●	M2	5FG11290	MOTOR,STEPPING	1	1	1
●	M3	5FG11290	MOTOR,STEPPING	1	1	1
●	M4	5FG11300	MOTOR,STEPPING	1	1	1
●	M5	5FG11300	MOTOR,STEPPING	1	1	1
●	M6	5FG14870	MOTOR,DC24V	1	1	1
●	M7	5FG11320	MOTOR,DC24V	1	1	1
●	M8	5FG11330	MOTOR,STEPPING	1	1	1
●	MS1	5FG11240	MICROSWITCH	1	1	1
●	MS2	5FG11240	MICROSWITCH	1	1	1
●	MS3	5FG11240	MICROSWITCH	1	1	1
●	PI1	5C111230	PHOTO INTERRUPTER B	1	1	1
●	PI2	5C111230	PHOTO INTERRUPTER B	1	1	1
●	PI3	5C111230	PHOTO INTERRUPTER B	1	1	1
●	PI4	5C111230	PHOTO INTERRUPTER B	1	1	1
●	PI5	5C111230	PHOTO INTERRUPTER B	1	1	1
●	PI6	5C111230	PHOTO INTERRUPTER B	1	1	1
●	PI7	5C111230	PHOTO INTERRUPTER B	1	1	1
●	PI8	5C111230	PHOTO INTERRUPTER B	1	1	1
●	PI9	5C111230	PHOTO INTERRUPTER B	1	1	1
●	PI10	5FG11250	LED PCB UNIT	1	1	1
●	PI11	5C111230	PHOTO INTERRUPTER B	1	1	1
●	PI12	5C111230	PHOTO INTERRUPTER B	1	1	1
●	PI13	5C111230	PHOTO INTERRUPTER B	1	1	1
●	PI14	5FG11350	PHOTO-INTERRUPTER	1	1	1
●	PI15	5C111230	PHOTO INTERRUPTER B	1	1	1
●	PI16	5C111230	PHOTO INTERRUPTER B	1	1	1
●	PI17	5C111230	PHOTO INTERRUPTER B	1	1	1
●	PI18	5FG11270	STAPLER IN PCB ASSEMBLY	1	1	1
●	PI22	5C111230	PHOTO INTERRUPTER B	1	1	1
●	PI23	5FG11350	PHOTO-INTERRUPTER	1	1	1
●	PI24	5FG11350	PHOTO-INTERRUPTER	1	1	1

- Parts with "●" are component parts or sub-assemblies of the assembly appearing immediately above them.
- Parts with "●" indicates the Service parts.





FIG. QB2 LIST OF ELECTRIC PARTS (2/2)

SP	Ref. No.	Part. No.	Description	Quantity		
				120V	230V	240V
●	1	5FG14300	DC,CONTROLLER PCP ASSEMBLY,KM	1	1	1
●	CL1	5FG11340	CLUTCH,ELECTROMAGNETIC	1	1	1
●	M1	5FG14860	MOTOR,STEPPING	1	1	1
●	M2	5FG11290	MOTOR,STEPPING	1	1	1
●	M3	5FG11290	MOTOR,STEPPING	1	1	1
●	M4	5FG11300	MOTOR,STEPPING	1	1	1
●	M5	5FG11300	MOTOR,STEPPING	1	1	1
●	M6	5FG14870	MOTOR,DC24V	1	1	1
●	M7	5FG11320	MOTOR,DC24V	1	1	1
●	M8	5FG11330	MOTOR,STEPPING	1	1	1
●	MS1	5FG11240	MICROSWITCH	1	1	1
●	MS2	5FG11240	MICROSWITCH	1	1	1
●	MS3	5FG11240	MICROSWITCH	1	1	1
●	PI1	5C111230	PHOTO INTERRUPTER B	1	1	1
●	PI2	5C111230	PHOTO INTERRUPTER B	1	1	1
●	PI3	5C111230	PHOTO INTERRUPTER B	1	1	1
●	PI4	5C111230	PHOTO INTERRUPTER B	1	1	1
●	PI5	5C111230	PHOTO INTERRUPTER B	1	1	1
●	PI6	5C111230	PHOTO INTERRUPTER B	1	1	1
●	PI7	5C111230	PHOTO INTERRUPTER B	1	1	1
●	PI8	5C111230	PHOTO INTERRUPTER B	1	1	1
●	PI9	5C111230	PHOTO INTERRUPTER B	1	1	1
●	PI10	5FG11250	LED PCB UNIT	1	1	1
●	PI11	5C111230	PHOTO INTERRUPTER B	1	1	1
●	PI12	5C111230	PHOTO INTERRUPTER B	1	1	1
●	PI13	5C111230	PHOTO INTERRUPTER B	1	1	1
●	PI14	5FG11350	PHOTO-INTERRUPTER	1	1	1
●	PI15	5C111230	PHOTO INTERRUPTER B	1	1	1
●	PI16	5C111230	PHOTO INTERRUPTER B	1	1	1
●	PI17	5C111230	PHOTO INTERRUPTER B	1	1	1
●	PI18	5FG11270	STAPLER IN PCB ASSEMBLY	1	1	1
●	PI22	5C111230	PHOTO INTERRUPTER B	1	1	1
●	PI23	5FG11350	PHOTO-INTERRUPTER	1	1	1
●	PI24	5FG11350	PHOTO-INTERRUPTER	1	1	1

- Parts with "●" are component parts or sub-assemblies of the assembly appearing immediately above them.
- Parts with "●" indicates the Service parts.



NOTE : This assembly does not include the parts shown with key No. 1,1A and 1B.

FIG. Q13 PUNCHER ASSEMBLY

5FG

SP	Ref. No.	Part. No.	Description	Quantity		
				120V	230V	240V
		5FG14320	PUNCHER ASSEMBLY K1	1		
		5FG14330	PUNCHER ASSEMBLY G1		1	1
		5FG14340	PUNCHER ASSEMBLY H1		1	
●	1	•5FG14350	PUNCHER CONTROLLER PCP ASSEMBLY	1	1	1
●	1A	•5FG14360	IC,M38039FFSP,CPU	1	1	1
●	1B	•5FG14370	IC,S-93C46ADP,EP-ROM	1	1	1
	2	•5FG14380	SHUTTER,PUNCHER	1	1	1
	3	•5FG14390	CABLE,POWER CONNECTING	1	1	1
	4	•5FG14400	CABLE,INTERFACE	1	1	1
	5	•5FG14410	SPRING,TENSION	1	1	1
	6	•5FG14420	CABLE,SENSOR	1	1	1
	7	•5FG11860	SCREW M4X7	3	3	3
	8	•5FG14430	LABEL,PUNCH DIAL	1	1	1
	9	•5FG14440	MOUNT,PUNCHER	1	1	1
	10	•5FG14450	COVER,HARNESS	1	1	1
●	11	•5FG14460	DUST LED PCB UNIT	1	1	1
●	12	•5FG14470	DUST PTR PCB UNIT	1	1	1
●	13	•5FG14480	GEAR,16T/33T	1	1	1
●	14	•5FG14490	GEAR,19T/32T	1	1	1
	15	•5FG14500	DUCT,PUNCHER	1	1	1
●	16	•5C111230	PHOTO INTERRUPTER B	1	1	1
●	17	•5FG14510	PANEL,DUST BOX	1	1	1
●	18	•5FG14520	COVER,DUST BOX	1	1	1
●	19	•5FG14530	MOTOR,STEPPING	1	1	1
	20	•5FG14540	CABLE,DUST SENSOR	1	1	1
	21	•5FG14550	COVER,PUNCHER BASE	1	1	1
	22	•5FG14590	SPONGE,DUST BOX	2	2	2
	23	•5FG14600	SHEET	1	1	1
●	24	•5FG14610	SHEET	2	2	2
	501	•5FG14560	SCREW,MACH,TRUSS HEAD,M4X6	3	3	3
	502	•5AH09510	SCREW,TP	8	8	8
	503	•5FG14570	SHIM	1	1	1
	504	•5FG14580	SCREW,W/WASHER,M3X6	2	2	2

- Parts with "•" are component parts or sub-assemblies of the assembly appearing immediately above them.
- Parts with "●" indicates the Service parts.




FIG. Q14 PUNCHER TOTAL ASSEMBLY

5FG

SP	Ref. No.	Part. No.	Description	Quantity		
				120V	230V	240V
	1	5FG14620	ROLLER,PUNCHER	3	3	3
	2	5FG14630	CABLE,REGISTRATION SENSOR	1	1	1
	3	58002380	SCREW,STEPPED M3	4	4	4
	4	5C119720	GROUND PULLEY	1	1	1
	5	5FG14640	COVER,REGISTRATION	1	1	1
●	6	5C111230	PHOTO INTERRUPTER B	2	2	2
	7	5FG14650	HOLDER,SENSOR,UPPER	1	1	1
	8	5FG14660	HOLDER,SENSOR,LOWER	1	1	1
	9	5FG14670	PLATE,SENSOR FLAG	1	1	1
●	10	5FG14680	COVER,JAM CLEARING	1	1	1
	11	5FG14690	RACK,SLIDE	1	1	1
	12	5FG14700	KNOB,JAM CLEARING	1	1	1
●	13	5FG14720	PUNCH UNIT,K1	1		
●	13	5FG14730	PUNCH UNIT,G1		1	1
●	13	5FG14740	PUNCH UNIT,H1		1	
●	14	5FG14750	MOTOR,DC	1	1	1
	15	5FG14760	CABLE,MOTOR	1	1	1
●	16	5FG14770	PCB UNIT	1	1	1
●	17	5FG14780	PCB UNIT	1	1	1
	501	5FG14790	SCREW,MACH,TRUSS HEAD,M3X6	5	5	5
	502	5AH14100	SCREW,TAPPING,TRUSS HEAD,M3X6	2	2	2
	503	5AH08970	RING,E	1	1	1
	504	5FG14800	SCREW,TAPPING,TRUSS HEAD,M3X12	1	1	1
	505	5FG14810	SCREW,W/WASHER,M3X8	1	1	1
	506	5AG10080	RING,E	1	1	1
	507	5FG14820	SCREW,MACH,TRUSS HEAD,M3X5	2	2	2
	508	5FG14830	SCREW,MACH,TRUSS HEAD,M4X8	1	1	1

- Parts with "●" are component parts or sub-assemblies of the assembly appearing immediately above them.
- Parts with "●" indicates the Service parts.





FIG. QB1P LIST OF CONNECTORS (PUNCHER)

5FG

SP	Ref. No.	Part. No.	Description	Quantity		
				120V	230V	240V
	J1002	5FG14760	CABLE,MOTOR	1	1	1
	J1003	5FG14400	CABLE,INTERFACE	1	1	1
	J1004	5FG14390	CABLE,POWER CONNECTING	1	1	1
	J1005	5FG14540	CABLE,DUST SENSOR	1	1	1
	J1006	5FG14420	CABLE,SENSOR	1	1	1
	J1007	5FG14630	CABLE,REGISTRATION SENSOR	1	1	1
	J2002	5FG14760	CABLE,MOTOR	1	1	1
	J2003	5FG14400	CABLE,INTERFACE	1	1	1
	J2004	5FG14390	CABLE,POWER CONNECTING	1	1	1
	J2005	5FG14540	CABLE,DUST SENSOR	1	1	1
	J2006	5FG14540	CABLE,DUST SENSOR	1	1	1
	J2007	5FG14420	CABLE,SENSOR	1	1	1
	J2008	5FG14420	CABLE,SENSOR	1	1	1
	J2009	5FG14420	CABLE,SENSOR	1	1	1
	J2010	5FG14630	CABLE,REGISTRATION SENSOR	1	1	1
	J2011	5FG14630	CABLE,REGISTRATION SENSOR	1	1	1

- Parts with "•" are component parts or sub-assemblies of the assembly appearing immediately above them.
- Parts with "●" indicates the Service parts.




FIG. QB2P LIST OF ELECTRIC PARTS

5FG

SP	Ref. No.	Part. No.	Description	Quantity		
				120V	230V	240V
●	1	5FG14350	PUNCHER CONTROLLER PCP ASSEMBLY	1	1	1
●	2	5FG14780	PCB UNIT	1	1	1
●	3	5FG14770	PCB UNIT	1	1	1
●	4	5FG14470	DUST PTR PCB UNIT	1	1	1
●	5	5FG14460	DUST LED PCB UNIT	1	1	1
●	M1P	5FG14750	MOTOR,DC	1	1	1
●	M2P	5FG14530	MOTOR,STEPPING	1	1	1
●	PI1p	5C111230	PHOTO INTERRUPTER B	1	1	1
●	PI2p	5C111230	PHOTO INTERRUPTER B	1	1	1
●	PI3p	5C111230	PHOTO INTERRUPTER B	1	1	1

- Parts with "●" are component parts or sub-assemblies of the assembly appearing immediately above them.
- Parts with "●" indicates the Service parts.

INDEX

5FG

SP	Part. No.	Description	Quantity			Fig. No.
			120V	230V	240V	
	5AG10080	RING,E	9	9	9	Q40,Q14
	5AH08970	RING,E	5	5	5	Q40,Q14
	5AH09510	SCREW,TP	8	8	8	Q13
	5AH10870	SCREW,TAPPING,PAN HEAD,M4X10	18	18	18	Q10,Q11, Q12,Q30, Q32,Q40
	5AH10890	PIN,DOWEL	28	28	28	Q12,Q20, Q22,Q30, Q32
	5AH14100	SCREW,TAPPING,TRUSS HEAD,M3X6	3	3	3	Q10,Q14
●	5AH14160	PIN,DOWEL	2	2	2	Q35
●	5C111230	PHOTO INTERRUPTER B	-	-	-	Q11,Q12, Q20,Q30, Q35,QB2, Q13,Q14, QB2P
●	5C114200	PARALLEL PIN	2	2	2	Q35
	5C117780	B TIGHT	3	3	3	Q11
	5C118090	TAPPING M4X6	2	2	2	Q10
	5C119720	GROUND PULLEY	1	1	1	Q14
	5C119790	BIND(N)M4X6	22	22	22	Q01,Q10, Q40
	5C120030	M4TP	8	8	8	Q01
	5C120620	SLIDE CHOU	1	1	1	Q01
	5C120660	SCREW,BIND M4X4	1	1	1	Q01
	5C120700	PULLEY MOUNT UNIT(KM)	1	1	1	Q01
	5C120750	CASTER RAIL	2	2	2	Q01
	5C120930	SPRING,GROUNDING	1	1	1	Q01
	5FG02010	BASE,LATCH	1	1	1	Q01
	5FG02020	RETAINER A,RAIL	1	1	1	Q01
	5FG02030	RETAINER B,RAIL	1	1	1	Q01
	5FG02040	BRACKET,CASTER	4	4	4	Q01
	5FG02050	GUIDE A,RAIL	1	1	1	Q01
	5FG02060	GUIDE B,RAIL	1	1	1	Q01
●	5FG04010	HANDLE A,JAM RELEASE	1	1	1	Q10
●	5FG04020	REAR COVER	1	1	1	Q10
●	5FG04030	COVER,JAM FRAME	1	1	1	Q10
●	5FG04040	COVER,JAM RELEASE	1	1	1	Q10
●	5FG04050	COVER,PUNCH LID	1	1	1	Q10
●	5FG04060	UPPER GUIDE,PUNCH DUMMY	1	1	1	Q10

SP	Part. No.	Description	Quantity			Fig. No.
			120V	230V	240V	
●	5FG04070	GUIDE,PUNCH DUMMY	1	1	1	Q10
●	5FG04080	COVER,SIDE	1	1	1	Q10
●	5FG04090	UPPER COVER,SUB	1	1	1	Q10
●	5FG04100	UPPER COVER	1	1	1	Q10
●	5FG04110	COVER,RETAINING	1	1	1	Q10
●	5FG04120	FRONT COVER	1	1	1	Q10
●	5FG04130	TRAY A,STACK	1	1	1	Q10
●	5FG04140	TRAY B,STACK	1	1	1	Q10
●	5FG04150	COVER A,BRIDGE	1	1	1	Q10
●	5FG04160	COVER B,BRIDGE	1	1	1	Q10
●	5FG04170	TRAY,MAIN	1	1	1	Q10
●	5FG04180	ARM,STOPPER	1	1	1	Q10
●	5FG04230	FRONT COVER A,SIDE REGISTRATION	1	1	1	Q30
●	5FG04240	FRONT COVER B,SIDE REGISTRATION	1	1	1	Q30
●	5FG04250	REAR COVER,SIDE REGISTRATION	1	1	1	Q30
	5FG04260	HANDLE B,JAM RELEASE	1	1	1	Q40
	5FG04270	COVER,HANDLE	1	1	1	Q40
●	5FG04280	FRONT COVER,SUPPORT	1	1	1	Q01
●	5FG04290	REAR COVER,SUPPORT	1	1	1	Q01
●	5FG04300	COVER,FOOT	1	1	1	Q01
●	5FG04310	COVER,SUPPORT PLATE	1	1	1	Q01
●	5FG04320	FRONT COVER,ADJUSTING PLATE	1	1	1	Q01
●	5FG04330	REAR COVER,ADJUSTING PLATE	1	1	1	Q01
●	5FG04340	CAP,SUPPORT PLATE	4	4	4	Q01
	5FG04350	TRAY,RIB	1	1	1	Q10
●	5FG10010	GEAR,16T/PULLEY,18T	1	1	1	Q11
●	5FG10020	GEAR,16T/40T	1	1	1	Q20
●	5FG10030	GEAR,16T/45T	1	1	1	Q20
●	5FG10040	GEAR,16T/45T	1	1	1	Q20
●	5FG10050	PULLEY,56T	1	1	1	Q20
●	5FG10060	GEAR,24T/PULLEY,24T	1	1	1	Q11
●	5FG10070	PULLEY,40T	1	1	1	Q32
●	5FG10080	PULLEY,18T/29T	1	1	1	Q32
●	5FG10090	GEAR,30T	1	1	1	Q30
●	5FG10100	GEAR,20T/PULLEY,32T	1	1	1	Q32
●	5FG10110	PULLEY,22T	2	2	2	Q30
●	5FG10120	GEAR,20T	1	1	1	Q32
●	5FG10130	GEAR,30T/PULLEY,20T	1	1	1	Q32
●	5FG10140	PULLEY,20T	1	1	1	Q32
●	5FG10150	GEAR,14T	2	2	2	Q32

• Parts with "●" indicates the Service parts.

5FG

SP	Part. No.	Description	Quantity			Fig. No.
			120V	230V	240V	
●	5FG10160	GEAR,14T	2	2	2	Q32
●	5FG10170	GEAR,48T/PULLEY,15T	1	1	1	Q10
●	5FG10180	PULLEY,40T	1	1	1	Q11
●	5FG10190	GEAR,20T/28T	1	1	1	Q24
●	5FG10200	GEAR,8T	1	1	1	Q35
●	5FG10210	CAM,FRONT	1	1	1	Q35
●	5FG10220	CAM,REAR	1	1	1	Q35
●	5FG10230	CAM,SADDLE,FRONT	1	1	1	Q35
●	5FG10240	GEAR,29T	1	1	1	Q22
●	5FG10250	GEAR,58T	1	1	1	Q22
●	5FG10260	GEAR,23T	2	2	2	Q22
●	5FG10270	GEAR,17T/65T	1	1	1	Q22
●	5FG10280	GEAR,15T/54T	1	1	1	Q22
●	5FG10290	GEAR,17T/29T	1	1	1	Q22
●	5FG10300	GEAR,20T	1	1	1	Q22
●	5FG10310	PULLEY,45T	1	1	1	Q22
●	5FG10320	FLAG,CLOCK SENSOR	1	1	1	Q22
●	5FG10330	GEAR,5T	1	1	1	Q24
●	5FG10340	CAM	2	2	2	Q32
●	5FG10350	PULLEY,36T	1	1	1	Q35
●	5FG10360	GEAR,82T	1	1	1	Q22
●	5FG10370	GEAR,16T	2	2	2	Q35
●	5FG10380	PULLEY,24T	1	1	1	Q32
●	5FG10390	PULLEY,18T	2	2	2	Q11
●	5FG10400	PULLEY,27T	1	1	1	Q35
●	5FG10410	GEAR,16T/41T	1	1	1	Q35
●	5FG10420	GEAR,15T/38T	1	1	1	Q35
●	5FG10430	GEAR,24T	1	1	1	Q35
●	5FG10440	GEAR,24T	1	1	1	Q35
●	5FG10450	CAM,SADDLE REAR	1	1	1	Q35
●	5FG10460	GEAR,24T	1	1	1	Q35
●	5FG10470	GEAR,16T	1	1	1	Q35
●	5FG10480	PULLEY,22T	1	1	1	Q30
●	5FG10490	ROLLER,TENSIONER	4	4	4	Q11,Q12,
●	5FG10500	GEAR,16T/42T	1	1	1	Q35
●	5FG10510	GEAR,21T	1	1	1	Q35
●	5FG10520	SPRING,TENSION	3	3	3	Q10,Q32
●	5FG10530	BELT,TIMING	2	2	2	Q30
●	5FG10540	SPRING COMPRESSION	1	1	1	Q35

SP	Part. No.	Description	Quantity			Fig. No.
			120V	230V	240V	
●	5FG10550	SPRING TENSION	2	2	2	Q35
●	5FG10560	SPRING TENSION	2	2	2	Q35
●	5FG10570	SPRING TENSION	2	2	2	Q35
●	5FG10580	SPRING TENSION	1	1	1	Q30
●	5FG10590	SPRING,COMPRESSION	3	3	3	Q30
●	5FG10600	SPRING,TORSION	1	1	1	Q30
●	5FG10610	SPRING,TENSION	2	2	2	Q32
●	5FG10620	SPRING,TENSION	1	1	1	Q30
●	5FG10630	SPRING,TENSION	2	2	2	Q35
●	5FG10640	SPRING,COMPRESSION	1	1	1	Q22
●	5FG10660	SPRING,TENSION	2	2	2	Q11
●	5FG10670	SPRING,TENSION	1	1	1	Q24
●	5FG10680	SPRING,TENSION	2	2	2	Q11
●	5FG10690	SPRING,TENSION	1	1	1	Q12
●	5FG10700	SPRING,TENSION	1	1	1	Q11
●	5FG10710	SPRING,COMPRESSION	1	1	1	Q24
●	5FG10720	SPRING,TORSION	1	1	1	Q24
●	5FG10730	SPRING,TORSION	1	1	1	Q24
●	5FG10740	SPRING,TORSION	1	1	1	Q24
●	5FG10750	ELIMINATOR,STATIC CHARGE	1	1	1	Q32
●	5FG10760	PULLEY,18T/24T	1	1	1	Q11
●	5FG10770	PULLEY,18T	1	1	1	Q11
●	5FG10780	BUSHING	1	1	1	Q11
●	5FG10790	CLAW,FRONT	1	1	1	Q32
●	5FG10800	CLAW,REAR	1	1	1	Q32
●	5FG10810	SPRING,TENSION	2	2	2	Q35
●	5FG10820	SPRING,TENSION	2	2	2	Q11
●	5FG10840	BUSHING	5	5	5	Q11,Q22, Q30
●	5FG10850	BUSHING	9	9	9	Q22,Q35
●	5FG10860	SPRING,TENSION	1	1	1	Q40
●	5FG10870	COUPLING	1	1	1	Q40
●	5FG10880	SPRING,COMPRESSION	2	2	2	Q30,Q40
●	5FG10900	PULLEY,38T	1	1	1	Q40
●	5FG10910	GEAR,36T/PULLEY,38T	1	1	1	Q40
●	5FG10920	GEAR,42T/PULLEY,32T	1	1	1	Q40
●	5FG10930	PULLEY,24T	1	1	1	Q40
●	5FG10940	GEAR,18T/66T	1	1	1	Q40
●	5FG10990	GEAR,32T	1	1	1	Q40
●	5FG11010	SPRING,COMPRESSION	1	1	1	Q32

• Parts with "●" indicates the Service parts.

SP	Part. No.	Description	Quantity			Fig. No.	SP	Part. No.	Description	Quantity			Fig. No.
			120V	230V	240V					120V	230V	240V	
●	5FG11020	GEAR,18T	1	1	1	Q35	●	5FG11410	SD-BKT-F	1	1	1	Q01
●	5FG11030	GEAR,17T	1	1	1	Q35	●	5FG11420	ROLLER,SADDLE	2	2	2	Q35
●	5FG11040	BEARING,BALL	5	5	5	Q22,Q35	●	5FG11430	ROLLER,PAPER FEED	1	1	1	Q10
●	5FG11050	BUSHING	17	17	17	Q12,Q20, Q30,Q32, Q35	●	5FG11460	ROLLER,BUNDLE,UPPER	2	2	2	Q32
●	5FG11060	BELT,TIMING	1	1	1	Q32	●	5FG11470	ROLLER,BUNDLE,LOWER	2	2	2	Q30
●	5FG11070	BELT,TIMING	2	2	2	Q30	●	5FG11480	ROLLER,PAPER FEED	1	1	1	Q12
●	5FG11090	BELT,TIMING	1	1	1	Q12	●	5FG11500	ROLLER,FOLD	1	1	1	Q35
●	5FG11100	BELT,TIMING	1	1	1	Q32	●	5FG11510	ROLLER	1	1	1	Q35
●	5FG11110	BELT,TIMING	1	1	1	Q11	●	5FG11520	ROLLER,PAPER OUTLET	3	3	3	Q32,Q40
●	5FG11120	BELT,TIMING	1	1	1	Q11	●	5FG11530	ROLLER	2	2	2	Q35
●	5FG11130	BELT,TIMING	1	1	1	Q22	●	5FG11540	ROLLER,PAPER OUTLET,1	2	2	2	Q32
●	5FG11140	BELT,TIMING	2	2	2	Q11	●	5FG11550	ROLLER,PAPER OUTLET,2	2	2	2	Q32
●	5FG11160	LEVER,BELT SENSOR	1	1	1	Q30	●	5FG11560	ROLLER,FOLD	2	2	2	Q35
●	5FG11170	FLAG,SENSOR	1	1	1	Q30	●	5FG11570	ROLLER,FOLD,SUB	4	4	4	Q35
●	5FG11180	FLAG,SENSOR	1	1	1	Q32	●	5FG11580	ROLLER	2	2	2	Q40
●	5FG11190	FLAG,SENSOR	1	1	1	Q12	●	5FG11620	ROLLER,FEED	2	2	2	Q32
●	5FG11200	FLAG, TOP SENSOR	1	1	1	Q12	●	5FG11630	STAPLE CARTRIDGE UNIT	1	1	1	Q40
●	5FG11210	LEVER,SWITCH	1	1	1	Q12	●	5FG11680	SPACER RAIL	2	2	2	Q01
●	5FG11220	CAM,SENSOR FLAG	1	1	1	Q32	●	5FG11690	ASSY,STAND	1	1	1	Q01
●	5FG11230	FLAG,BUNDLE ROLLER	4	4	4	Q24,Q30, Q32	●	5FG11700	STAY,STAND	1	1	1	Q01
	5FG11240	MICROSWITCH	-	-	-	Q12,Q30, QB2	●	5FG11710	SUTAND BEES	1	1	1	Q01
●	5FG11250	LED PCB UNIT	-	-	-	Q35,QB2	●	5FG11720	SUTAND KABA	1	1	1	Q01
●	5FG11270	STAPLER IN PCB ASSEMBLY	1	1	1	QB2	●	5FG11730	SUTANDBURAKETO(BAKU)	1	1	1	Q01
●	5FG11280	MOTOR,STEPPING	1	1	1	Q11	●	5FG11740	SUTAND	1	1	1	Q01
●	5FG11290	MOTOR,STEPPING	-	-	-	Q30,QB2	●	5FG11750	SUTAND,	1	1	1	Q01
●	5FG11300	MOTOR,STEPPING	-	-	-	Q30,QB2	●	5FG11760	FUT	1	1	1	Q01
●	5FG11310	MOTOR,DC24V	1	1	1	Q20	●	5FG11770	CLIP	31	31	31	Q10,Q11, Q12,Q20, Q24,Q30, Q32
●	5FG11320	MOTOR,DC24V	-	-	-	Q22,QB2	●	5FG11780	FIAG,PAPER SENSING REAR	1	1	1	Q10
●	5FG11330	MOTOR,STEPPING	-	-	-	Q40,QB2	●	5FG11790	SPRING,TENSION	1	1	1	Q10
●	5FG11340	CLUTCH,ELECTROMAGNETIC	-	-	-	Q35,QB2	●	5FG11800	LATCH,UPPER PANEL	2	2	2	Q10
●	5FG11350	PHOTO-INTERRUPTER	-	-	-	Q22,QB2	●	5FG11810	SPRING,TORSION	1	1	1	Q10
●	5FG11360	LEVER,TRAY UP/DOWN EMPTY	1	1	1	Q10	●	5FG11820	SPRING,TORSION	1	1	1	Q10
●	5FG11370	COVER,STOPPER	1	1	1	Q12	●	5FG11830	HOLDER,ROLLER	1	1	1	Q10
●	5FG11380	COVER,DISPOSE,SUB	1	1	1	Q30	●	5FG11840	BAND PANEL	3	3	3	Q10
●	5FG11390	KNOB,STAPLE MOVABLE	1	1	1	Q40	●	5FG11850	SUPPORT,PANEL BAND,2	2	2	2	Q10
●	5FG11400	PANEL,FRONT	1	1	1	Q40	●	5FG11860	SCREW M4X7	108	108	108	Q01,Q10, Q11,Q12,

• Parts with "●" indicates the Service parts.

5FG

SP	Part. No.	Description	Quantity			Fig. No.
			120V	230V	240V	
						Q20,Q22, Q24,Q30, Q32,Q35, Q40,Q13
	5FG11870	PLATE GROUNDING	1	1	1	Q10
	5FG11880	FLAG BASE TRAY	1	1	1	Q10
	5FG11890	SPRING,TENSION	2	2	2	Q10,Q11
	5FG11900	SPRING,TENSION	1	1	1	Q10
	5FG11910	CLIP,SHAFT	1	1	1	Q10
	5FG11920	CLIP,SHAFT	21	21	21	Q10,Q11, Q22,Q30, Q35
	5FG11930	GUIDO,DUMMY PUNCHER PAPER	1	1	1	Q10
	5FG11940	LABEL STAPLE REMOVING	1	1	1	Q10
	5FG11960	SUPPORT,PANEL BAND,1	2	2	2	Q10
	5FG11970	TRAY	1	1	1	Q10
	5FG11980	TRAY	1	1	1	Q10
	5FG11990	SHEET	1	1	1	Q10
	5FG12000	PLATE,STAPLER FRAME STOPPER	1	1	1	Q12
	5FG12010	COVER BLANKING	2	2	2	Q12,Q24
	5FG12020	ROLLER FRAME TRAY	2	2	2	Q12
	5FG12030	GUIDE PAPER LOWER	1	1	1	Q12
	5FG12040	CABLE SENSOR	-	-	-	Q12,Q24, Q30,QB1
	5FG12050	PLATE PAPER FEED TENSIONER,2	1	1	1	Q12
	5FG12060	HOLDER LEVER SUPPORT	1	1	1	Q12
	5FG12070	HOLDER,SENSOR/MICROSWITCH	1	1	1	Q12
	5FG12080	GEAR,24T	1	1	1	Q12
	5FG12090	GUIDE,PAPER WEIGHT,1	1	1	1	Q12
	5FG12100	PLATE,WEIGHT,1	1	1	1	Q12
	5FG12110	PLATE,WEIGHT,2	1	1	1	Q12
	5FG12120	GUIDE,PAPER WEIGHT,2	1	1	1	Q12
	5FG12130	PANEL,FRAME COVER	1	1	1	Q12
	5FG12140	SPRING,LEAF,GROUNDING	1	1	1	Q12
	5FG12150	CABLE,FRONT DOOR SENSOR	-	-	-	Q12,QB1
	5FG12160	CABLE,LEVER TRAY SENSOR	-	-	-	Q12,QB1
	5FG12170	CABLE SENSOR (2)	-	-	-	Q12,QB1
	5FG12180	CABLE,SENSOR,3	-	-	-	Q12,QB1
	5FG12190	SPRING TENSION	1	1	1	Q12
	5FG12200	CABLE,JOE MOTOR	-	-	-	Q12,QB1

SP	Part. No.	Description	Quantity			Fig. No.
			120V	230V	240V	
	5FG12210	CABLE,SWITCH	1	1	1	Q12
	5FG12220	CABLE,BIND CLUTCH	-	-	-	Q12,QB1
	5FG12230	LEVER STACK	1	1	1	Q11
	5FG12240	HOLDER BELT REAR	1	1	1	Q11
	5FG12250	HOLDER BELT FRONT	1	1	1	Q11
	5FG12260	SPRING TENSION	1	1	1	Q11
	5FG12270	LATCH 1	1	1	1	Q11
	5FG12280	LATCH (2)	1	1	1	Q11
	5FG12290	CABLE STACK SENSOR	-	-	-	Q11,QB1
	5FG12300	BUSHING	1	1	1	Q11
	5FG12310	FLANGE	4	4	4	Q11
	5FG12330	SPRING LEAF	2	2	2	Q11
	5FG12340	SCREW M4X8	12	12	12	Q01,Q11, Q12
	5FG12350	PLATE PAPER FEED TENSIONER 1	1	1	1	Q11
	5FG12360	CAP MOTOR	4	4	4	Q11
	5FG12370	ROLLER RAIL	1	1	1	Q11
	5FG12380	GUIDO STOPPER	1	1	1	Q11
	5FG12390	LINK,1	2	2	2	Q11
	5FG12400	LINK,2	2	2	2	Q11
	5FG12410	SCREW,W/WASHER,M3X6	13	13	13	Q11,Q20, Q30,Q40
	5FG12420	CABLE,SENSOR (1)	-	-	-	Q11,QB1
	5FG12430	CABLE,FEED PADDLE MOTOR	-	-	-	Q11,QB1
	5FG12440	CABLE,DC MOTOR	-	-	-	Q11,QB1
	5FG12450	ARM,STOPPER	-	-	-	Q11,QB1
	5FG12460	PIN,DOWEL	6	6	6	Q11,Q20, Q22,Q35, Q40
	5FG12470	PIN,DOWEL	7	7	7	Q11,Q35, Q40
	5FG12480	TRAY FRONT KUMI	1	1	1	Q11
	5FG12490	TRAY REAR KUMI	1	1	1	Q11
	5FG12500	CABLE,SHIFT MOTOR	-	-	-	Q20,QB1
●	5FG12510	BELT,TIMING	1	1	1	Q20
	5FG12520	FIAG,CLOCK SENSOR	1	1	1	Q20
●	5FG12530	CLIP,SHAFT	9	9	9	Q22,Q35
	5FG12540	SCREW,M4X6	1	1	1	Q22
	5FG12550	CABLE,STEPLER	1	1	1	Q22
	5FG12560	SCREW,STEPPED,M4	1	1	1	Q22

• Parts with "●" indicates the Service parts.

SP	Part. No.	Description	Quantity			Fig. No.
			120V	230V	240V	
●	5FG12570	PIN,DOWEL	4	4	4	Q22,Q35
	5FG12580	SHAFT,SUPPORT	1	1	1	Q24
	5FG12590	FIAG,PAPER SENSOR	1	1	1	Q24
●	5FG12600	BUSHING	1	1	1	Q24
	5FG12620	SUPPORT,PAPER	1	1	1	Q24
	5FG12630	HOLDER,PAPER SUPPORT	1	1	1	Q24
	5FG12640	COVER,DISPOSE	1	1	1	Q30
	5FG12650	DEFLECTOR,WEIGHT	1	1	1	Q30
	5FG12660	CABLE,TRAY	-	-	-	Q30,QB1
	5FG12670	GUIDE,TRAY,FRONT	1	1	1	Q30
	5FG12680	FLANGE	2	2	2	Q30
	5FG12690	SUPPORT,SENSOR FLAG	1	1	1	Q30
	5FG12700	CABLE,EJECT MOTOR	-	-	-	Q30,QB1
	5FG12710	GUIDE,TRAY,REAR	1	1	1	Q30
	5FG12720	SPRING,LEAT	2	2	2	Q30
	5FG12730	GUIDE,PAPER FEED,REAR	1	1	1	Q30
	5FG12740	RACK,ADJUSTMENT,FRONT	1	1	1	Q30
	5FG12750	RACK,ADJUSTMENT,REAR	1	1	1	Q30
	5FG12760	HOLDER,MICROSWITCH	1	1	1	Q30
	5FG12770	COVER,MICROSWITCH	1	1	1	Q30
	5FG12780	FLANGE	1	1	1	Q32
	5FG12790	GUIDE,PAPER AUXILIARY	1	1	1	Q32
	5FG12800	FLANGE	2	2	2	Q32
	5FG12810	ARM,LINK(1)	1	1	1	Q32
	5FG12820	SUPPORT,PADDLE SHAFT	1	1	1	Q32
	5FG12830	ARM,LINK(2)	2	2	2	Q32
	5FG12840	ARM LINK (3)	2	2	2	Q32
	5FG12850	ARM,LINK(4)	1	1	1	Q32
	5FG12860	FLANGE	1	1	1	Q32
	5FG12870	GUIDE,SAFTY,REAR 1	1	1	1	Q32
	5FG12880	GUIDE,PAPER OUTLET,UPPER	1	1	1	Q32
	5FG12890	GUIDE,SAFTY,REAR 2	1	1	1	Q32
	5FG12900	ROLLER,PAPER OUTLET	1	1	1	Q32
	5FG12920	FLANGE	1	1	1	Q32
	5FG12930	HOLDER,ROLLER,FRONT 1	1	1	1	Q32
	5FG12940	HOLDER,ROLLER,FRONT 2	1	1	1	Q32
	5FG12950	GUIDE,SAFTY,FRONT 1	1	1	1	Q32
	5FG12980	GUIDE,SWING,FRONT	1	1	1	Q35
	5FG12990	GUIDE,SWING REAR	1	1	1	Q35
	5FG13000	PIN,SADDLE,SLIDER	2	2	2	Q35

SP	Part. No.	Description	Quantity			Fig. No.
			120V	230V	240V	
	5FG13010	HOLDER,ROLLER	2	2	2	Q35
	5FG13020	PULLEY,27T	1	1	1	Q35
	5FG13030	HOOK,SPRING	4	4	4	Q35
	5FG13040	WASHER	2	2	2	Q35
	5FG13050	BUSHING	2	2	2	Q35
	5FG13060	SCREW	1	1	1	Q35
	5FG13070	ROLLER,LINK	2	2	2	Q35
	5FG13080	GUIDE,PAPER DELIVERY,LOWER	1	1	1	Q35
	5FG13090	CABLE,CONNECTING	-	-	-	Q35,QB1
	5FG13100	SCREW,STEPPED,M3	2	2	2	Q35
●	5FG13110	CLIP	12	12	12	Q35
	5FG13120	BELT,TIMING	1	1	1	Q35
	5FG13130	SPRING,LEAF	1	1	1	Q35
●	5FG13140	CLIP,SHAFT	4	4	4	Q35
	5FG13150	SPRING,LEAF	2	2	2	Q35
	5FG13160	SPRING,LEAF	4	4	4	Q35
	5FG13170	GUIDE,DELIVERY PAPER	1	1	1	Q35
	5FG13180	PLATE,REINFORCEMENT	2	2	2	Q35
	5FG13190	ROLLER,FOLD	1	1	1	Q35
	5FG13200	HOLDER,DELIVERY ROLLER	1	1	1	Q35
	5FG13210	GUIDE,FOLD ROLLER,1	1	1	1	Q35
	5FG13220	HOLDER,GUIDE,FRONT 1	1	1	1	Q35
	5FG13230	HOLDER,GUIDE REAR 1	1	1	1	Q35
	5FG13240	GUIDE,FOLD ROLLER,2	1	1	1	Q35
	5FG13250	HOLDER,GUIDE,FRONT,2	1	1	1	Q35
	5FG13260	HOLDER,GUIDE,REAR,2	1	1	1	Q35
	5FG13270	GUIDE,PAPER,UPPER	1	1	1	Q35
	5FG13280	ROLLER,LINK	2	2	2	Q35
	5FG13290	GUIDE,PAPER,LOWER	1	1	1	Q35
	5FG13300	SPRING,LEAF,GROUNDING	1	1	1	Q35
	5FG13310	SHAFT,LINK	2	2	2	Q35
	5FG13320	PLATE,OPENER,FRONT	1	1	1	Q35
	5FG13330	PLATE,OPENER,REAR	1	1	1	Q35
	5FG13340	LINK,COVER	2	2	2	Q35
	5FG13350	SCREW,MACH,TRUSS HEAD,M4X10	2	2	2	Q35
	5FG13360	COVER,MOTOR	1	1	1	Q40
	5FG13370	FRAME,COUPLING	1	1	1	Q40
	5FG13380	SUPPORT,CAM STOPPER,1	1	1	1	Q40
	5FG13390	HOLDER,STAPLE GUIDE ROLLER	1	1	1	Q40
	5FG13400	ROLLER,STAPLE GUIDE	2	2	2	Q40

• Parts with "●" indicates the Service parts.

5FG

SP	Part. No.	Description	Quantity			Fig. No.
			120V	230V	240V	
	5FG13410	SPRING,TORSION	1	1	1	Q40
	5FG13420	BELT,TIMING	1	1	1	Q40
	5FG13430	CLIP	1	1	1	Q40
	5FG13440	SCREW,W/WASHER,M3X6	1	1	1	Q40
	5FG13450	SCREW,M3X6	1	1	1	Q40
	5FG13460	COVER,SIDE,RIGHT	1	1	1	Q40
	5FG13470	COVER,SIDE,LEFT	1	1	1	Q40
	5FG13480	GUIDE,PAPER	1	1	1	Q40
	5FG13490	GUIDE,PAPER,SUB	1	1	1	Q40
	5FG13500	PIN,MARKER	1	1	1	Q40
	5FG13520	STACK MOTOR DRIVER ASSEMBLY	1	1	1	Q20
	5FG13530	DRIVE ASSEMBLY	1	1	1	Q22
	5FG13540	BUNDLE SUPPORT COVER ASSEMBLY	1	1	1	Q24
	5FG13550	DISPOSE ASSEMBLY	1	1	1	Q30
	5FG13560	GUIDE,PAPER FEED,FRONT	1	1	1	Q30
	5FG13570	PAPER FEEDER ASSEMBLY	1	1	1	Q32
	5FG13580	PADDLE,1	4	4	4	Q32
	5FG13590	GUIDE,PAPER,LOWER	1	1	1	Q32
	5FG13600	GUIDE,SAFTY,FRONT 2	1	1	1	Q32
	5FG13610	FOLD ASSEMBLY	1	1	1	Q35
	5FG13620	FLANGE	1	1	1	Q35
	5FG13630	STAPLE ASSEMBLY	1	1	1	Q40
	5FG13640	SUPPORT,KARRU	2	2	2	Q11
	5FG13650	SHEET	2	2	2	Q11
	5FG13660	COVER,PAPER,GUIDE	1	1	1	Q30
	5FG13670	HOLDER,PADDLE,1	1	1	1	Q32
	5FG13690	SHEET,DW,R	1	1	1	Q30
	5FG13700	CABLE,INTERFACE	1	1	1	Q10
	5FG13710	SCREW MACH,TRUSS HEAD.M4X10	2	2	2	Q01
	5FG13720	SPACER	2	2	2	Q10
	5FG13730	SCREW,STEPPED	2	2	2	Q10
	5FG13740	TRAY,	1	1	1	Q10
	5FG13750	TENSION	2	2	2	Q10
	5FG13760	SCREW M4X6	1	1	1	Q10
	5FG13770	PAD	1	1	1	Q11
	5FG13780	STOPPER,PAD	2	2	2	Q11
	5FG13790	SENSOR	1	1	1	Q12
	5FG13800	HOLDER,JOINT,SW	1	1	1	Q12
	5FG13810	LEAF,GROUNDING	1	1	1	Q12
	5FG13820	TENSION	1	1	1	Q12

SP	Part. No.	Description	Quantity			Fig. No.
			120V	230V	240V	
	5FG13830	LEVER,	1	1	1	Q12
	5FG13840	GUIDE,PIN	1	1	1	Q12
	5FG13850	TENSION,HOLDERGEAR	1	1	1	Q24
	5FG13860	DEFLECTOR,WEIGHT,R	1	1	1	Q30
	5FG13870	DEFLECTOR,WEIGHT,F	1	1	1	Q30
	5FG13880	SHEET,DW,F	1	1	1	Q30
	5FG13890	SHEET DISPOSE,TRAY	1	1	1	Q30
	5FG13900	SHEET SEIGO	1	1	1	Q30
	5FG13910	SHEET,DW,M	2	2	2	Q30
	5FG13920	WEIGHT,PAPER,SENSOR	1	1	1	Q30
	5FG13930	WEIGHT,LIB	1	1	1	Q30
	5FG13940	HOLDER,MICROSWITCH,F	1	1	1	Q30
	5FG13950	HOLDER,MICROSWITCH,R	1	1	1	Q30
	5FG13960	JUMP,GUIDE	4	4	4	Q32
	5FG13970	PADDLE(2)	3	3	3	Q32
	5FG13980	HOLDER PADDLE(2)	6	6	6	Q32
	5FG13990	GUIDO RIBU	4	4	4	Q32
	5FG14000	ARM,LINK	1	1	1	Q32
	5FG14010	COVER,GEAR	1	1	1	Q40
	5FG14020	GEAR,42T	1	1	1	Q40
	5FG14030	PLATE,TENSIONER	1	1	1	Q40
	5FG14040	SCREW,TAPPING,M3X6	4	4	4	Q40
	5FG14050	PIN,SLIDE	2	2	2	Q40
	5FG14060	STAPLER BASE PCP ASSEMBLY	1	1	1	Q40
	5FG14070	STAPLER IN PCB ASSEMBLY	1	1	1	Q40
	5FG14080	CABLE,STAPLER	-	-	-	Q40,QB1
	5FG14090	CABLE,STAPLE 1	-	-	-	Q40,QB1
	5FG14100	CABLE,STAPLE 2	-	-	-	Q40,QB1
	5FG14110	FLANGE	1	1	1	Q40
	5FG14120	GEAR	1	1	1	Q40
	5FG14130	SPRING,TENSION	1	1	1	Q40
	5FG14140	SUPPORT,STAPLE TENSIONER	1	1	1	Q40
	5FG14150	ROLLER,TENSIONER	1	1	1	Q40
	5FG14160	BELT,TIMING	1	1	1	Q40
	5FG14170	GUIDO	1	1	1	Q40
	5FG14180	PAD,STAPLE GUIDE	1	1	1	Q40
	5FG14190	BUSHING	1	1	1	Q40
	5FG14200	GEAR,16T/PULLEY29T	1	1	1	Q40
	5FG14210	SCREW,MACH,TRUSS HEAD,M3X6	1	1	1	Q40
	5FG14220	PIN,DOWEL	3	3	3	Q40

• Parts with "●" indicates the Service parts.

SP	Part. No.	Description	Quantity			Fig. No.
			120V	230V	240V	
●	5FG14230	DC,CONTROLLER PCP ASSEMBLY	1	1	1	Q90
●	5FG14240	IC,M27C1001-80XF,EP-ROM	1	1	1	Q90
●	5FG14250	IC,S-93C66ADP,EEP-ROM	1	1	1	Q90
●	5FG14260	DOCONTROLLER SUBASSEHBLY	1	1	1	Q90
	5FG14270	CABLE,INTERFACE	-	-	-	QB1,QB1
	5FG14280	CABLE,STAPLER	-	-	-	QB1,QB1
●	5FG14300	DC,CONTROLLER PCP ASSEMBLY,KM	1	1	1	QB2
	5FG14310	PUNCHER ASSEMBLY,J1	1	1	1	Q13
	5FG14320	PUNCHER ASSEMBLY K1	1	1	1	Q13
	5FG14330	PUNCHER ASSEMBLY G1	1	1	1	Q13
	5FG14340	PUNCHER ASSEMBLY H1	1	1	1	Q13
●	5FG14350	PUNCHER CONTROLLER PCP ASSEMBLY	-	-	-	Q13,QB2P
●	5FG14360	IC,M38039FFSP,CPU	1	1	1	Q13
●	5FG14370	IC,S-93C46ADP,EP-ROM	1	1	1	Q13
	5FG14380	SHUTTER,PUNCHER	1	1	1	Q13
	5FG14390	CABLE,POWER CONNECTING	-	-	-	Q13,QB1P
	5FG14400	CABLE,INTERFACE	-	-	-	Q13,QB1P
	5FG14410	SPRING,TENSION	1	1	1	Q13
	5FG14420	CABLE,SENSOR	-	-	-	Q13,QB1P
	5FG14430	LABEL,PUNCH DIAL	1	1	1	Q13
	5FG14440	MOUNT,PUNCHER	1	1	1	Q13
	5FG14450	COVER,HARNESS	1	1	1	Q13
●	5FG14460	DUST LED PCB UNIT	-	-	-	Q13,QB2P
●	5FG14470	DUST PTR PCB UNIT	-	-	-	Q13,QB2P
●	5FG14480	GEAR,16T/33T	1	1	1	Q13
●	5FG14490	GEAR,19T/32T	1	1	1	Q13
	5FG14500	DUCT,PUNCHER	1	1	1	Q13
●	5FG14510	PANEL,DUST BOX	1	1	1	Q13
●	5FG14520	COVER,DUST BOX	1	1	1	Q13
●	5FG14530	MOTOR,STEPPING	-	-	-	Q13,QB2P
	5FG14540	CABLE,DUST SENSOR	-	-	-	Q13,QB1P
	5FG14550	COVER,PUNCHER BASE	1	1	1	Q13
	5FG14560	SCREW,MACH,TRUSS HEAD,M4X6	3	3	3	Q13
	5FG14570	SHIM	1	1	1	Q13
	5FG14580	SCREW,W/WASHER,M3X6	2	2	2	Q13
	5FG14590	SPONGE,DUST BOX	2	2	2	Q13
	5FG14600	SHEET	1	1	1	Q13
●	5FG14610	SHEET	2	2	2	Q13
	5FG14620	ROLLER,PUNCHER	3	3	3	Q14
	5FG14630	CABLE,REGISTRATION SENSOR	-	-	-	Q14,QB1P

SP	Part. No.	Description	Quantity			Fig. No.
			120V	230V	240V	
	5FG14640	COVER,REGISTRATION	1	1	1	Q14
	5FG14650	HOLDER,SENSOR,UPPER	1	1	1	Q14
	5FG14660	HOLDER,SENSOR,LOWER	1	1	1	Q14
	5FG14670	PLATE,SENSOR FLAG	1	1	1	Q14
●	5FG14680	COVER,JAM CLEARING	1	1	1	Q14
	5FG14690	RACK,SLIDE	1	1	1	Q14
	5FG14700	KNOB,JAM CLEARING	1	1	1	Q14
●	5FG14710	PUNCH UNIT,J1	1	1	1	Q14
●	5FG14720	PUNCH UNIT,K1	1	1	1	Q14
●	5FG14730	PUNCH UNIT,G1	1	1	1	Q14
●	5FG14740	PUNCH UNIT,H1	1	1	1	Q14
●	5FG14750	MOTOR,DC	-	-	-	Q14,QB2P
	5FG14760	CABLE,MOTOR	-	-	-	Q14,QB1P
●	5FG14770	PCB UNIT	-	-	-	Q14,QB2P
●	5FG14780	PCB UNIT	-	-	-	Q14,QB2P
	5FG14790	SCREW,MACH,TRUSS HEAD,M3X6	5	5	5	Q14
	5FG14800	SCREW,TAPPING,TRUSS HEAD,M3X12	1	1	1	Q14
	5FG14810	SCREW,W/WASHER,M3X8	1	1	1	Q14
	5FG14820	SCREW,MACH,TRUSS HEAD,M3X5	2	2	2	Q14
	5FG14830	SCREW,MACH,TRUSS HEAD,M4X8	1	1	1	Q14
	5FG14840	HOLDER,ROLLER,REAR 1	1	1	1	Q32
	5FG14850	HOLDER,ROLLER,REAR 2	1	1	1	Q32
	57306720	SCREW STEPPED M3	1	1	1	Q11
	58002380	SCREW,STEPPED M3	4	4	4	Q14
	59904480	PIN,DOWEL	2	2	2	Q30
	59916200	WASHER,TOOTHED LOCK	1	1	1	Q01

• Parts with "●" indicates the Service parts.

KYOCERA MITA EUROPE B.V.

Hoeksteen 40, 2132 MS Hoofddorp,
The Netherlands
Phone: (020) 6540000
Home page: <http://www.kyoceramita-europe.com>
Email: info@kyoceramita-europe.com

KYOCERA MITA NEDERLAND B.V.

Hoeksteen 40, 2132 MS Hoofddorp,
The Netherlands
Phone: (020) 5877200

KYOCERA MITA (UK) LIMITED

8 Beacontree Plaza
Gillette Way,
Reading RG2 0BS UK
Phone: (0118) 931 1500

KYOCERA MITA ITALIA S.P.A.

Via Verdi 89/91 20063 Cernusco sul Naviglio
(Milano) Italy
Phone: 02-92179 1

S.A. KYOCERA MITA BELGIUM N.V.

Hermesstraat 8A, 1930 Zaventem, Belgium
Phone: (02) 7209270

KYOCERA MITA FRANCE S.A.

Parc les Algorithmes
SAINT AUBIN
91194 GIF-SUR-YVETTE
France
Phone: (01) 69852600

KYOCERA MITA ESPAÑA S.A.

Edificio Mita, Avda. De Manacor N°2,
Urb. Parque Rozas, Apartado de Correos 76,
28230 Las Rozas, Madrid, Spain
Phone: (91) 631-8392

KYOCERA MITA FINLAND OY

Kirvesmiehenkatu 4, 00810 Helsinki,
Finland
Phone: (09) 478-05200

KYOCERA MITA (SCHWEIZ) AG

Hölzliwisen, Industriestrasse 28,
8604 Volketswil, Switzerland
Phone: (01) 908 4949

KYOCERA MITA DEUTSCHLAND GMBH

Mollsfeld 12 40670 Meerbusch,
Germany
Phone: 02159-918120

KYOCERA MITA GMBH AUSTRIA

Eduard-Kittenberger-Gasse 95,
1230, Wien, Austria
Phone: (01) 86338-0

KYOCERA MITA SVENSKA AB

Siktgatan 2,
162 50 Vällingby, Sweden
Phone: (08) 4719999

KYOCERA MITA DANMARK A/S

Industrivej 11, DK-4632 Bjæverskov,
Denmark
Phone: 56871100

KYOCERA MITA PORTUGAL LDA.

CASCAISTOCK-Armazem nº8,
Rua das Físgas, Alcoitão,
2765 Estoril, Portugal
Phone: (21) 4602221

KYOCERA MITA SOUTH AFRICA (PTY) LTD.

UNIT 3, "Kyalami Crescent,"
Kyalami Business Park,
1685 Midrand, South Africa
Phone: (11) 466-3290

KYOCERA MITA AMERICA, INC.

Headquarters:
225 Sand Road, P.O. Box 40008,
Fairfield, New Jersey 07004-0008,
U.S.A.
Phone: (973) 808-8444

KYOCERA MITA AUSTRALIA PTY. LTD.

Level 3, 6-10 Talavera Road, North Ryde,
N.S.W. 2113 Australia
Phone: (02) 9888-9999

KYOCERA MITA NEW ZEALAND LTD.

1-3 Parkhead Place,
Albany, Auckland,
New Zealand
Phone: (09) 415-4517

KYOCERA MITA (THAILAND) CORP., LTD.

9/209 Ratchada-Prachachem Road,
Bang Sue, Bangkok 10800, Thailand
Phone: (02) 586-0320

KYOCERA MITA SINGAPORE PTE LTD.

121 Genting Lane, 3rd Level,
Singapore 349572
Phone: (65) 7418733

KYOCERA MITA HONG KONG LIMITED

11/F., Mita Centre,
552-566, Castle Peak Road,
Tsuen Wan, New Territories,
Hong Kong
Phone: (852) 24297422

KYOCERA MITA CORPORATION

2-28, 1-chome, Tamatsukuri, Chuo-ku
Osaka 540-8585, Japan
Phone: (06) 6764-3555

© 2001 KYOCERA MITA CORPORATION

 **KYOCERA** is a trademark of Kyocera Corporation

mita is a registered trademark of KYOCERA MITA CORPORATION

Printed in Holland