

PIXMA MP760

PARTS CATALOG

REVISION 0

PIXMA MP760	H12-4602	120V	USA
PIXMA MP760	H12-4603	230V	EMB
PIXMA MP760	H12-4604	230V	GB
PIXMA MP760	H12-4605	230V	EUM
PIXMA MP760	H12-4606	120V	CND
PIXMA MP760	H12-4608	230V	AUS
PIXMA MP760	H12-4609	230V	AE



Canon

NOV. 2004

HY8-33A4-000

Application

This manual has been issued by Canon Inc. for qualified persons to learn technical theory, installation, maintenance, and repair of products. This manual covers all localities where the products are sold. For this reason, there may be information in this manual that does not apply to your locality.

Corrections

This manual may contain technical inaccuracies or typographical errors due to improvements or changes in products. When changes occur in applicable products or in the content of this manual, Canon will release technical information as the need arises. In the event of major changes in the contents of this manual, Canon will issue a new editions of this manual.

The following paragraph does not apply to any countries where such provisions are inconsistent with local law.

Trademarks

The product names and company names described in this manual are the registered trademarks of the individual companies.

Copyright

This manual is copyrighted with all rights reserved. Under the copyright laws, this manual may not be copied, reproduced or translated into another language, in whole or in part, without the written consent of Canon Inc.

Copyright © 2004 by Canon Inc.

CANON INC.

InkJet MFP Quality Assurance Div.

5-1 Hakusan 7-Chome, Toride-city, Ibaraki 302-8501, Japan

DTP System

The data contained on this manual were created using Windows 2000 computers.

Document creation and page layout were performed using Adobe® PageMaker® 6.5.

Logos and illustrations were created using Adobe® Illustrator® 10.0J.

I. CONTENTS

1. ILLUSTRATION INDEX
2. PARTS LAYOUT & PARTS LIST
3. TOOL
4. NUMERICAL INDEX

II. ABOUT THIS MANUAL

1. ILLUSTRATION INDEX

For illustration index, the parts layout illustrations in this parts catalog are listed in abbreviated form in order of illustration number to identify the pages they appear on. To find an illustration of a part, see the ILLUSTRATION INDEX.

2. PARTS LAYOUT & PARTS LIST

Parts layout illustration

a) Parts search

Find a part from the parts layout illustration and find its key number from the parts list to identify the part number and name.

Further, screws, nuts, washers, grip rings, pins and spacers are mentioned in the parts list.

Note: If parts have the same or similar shape but different specifications, their key number is assigned to several part numbers and names in the parts list.

b) Parts replacement procedure

The parts layout illustrations are arranged according to the disassembly procedure of the product. When a unit in the illustration can be disassemble further, a reference illustration page of the disassembly will be included.

The letters (A , B etc.) in the illustration indicate the connection locations of cables and screws.

Parts list

a) FIGURE & KEY No.

The FIGURE & KEY No. column corresponds to the key numbers assigned to the parts in the parts layout illustration.

It also corresponds to the part locations printed on the PC board.

b) PART NUMBER

The PART NUMBER column gives the part numbers corresponding to the key numbers. To order a part, indicate the part number clearly.

Note: Parts marked NPN are not service parts.

c) RANK

The service parts with N in the RANK column are order parts.

d) QTY

The QTY column gives the number of parts in the corresponding components layout illustration.

e) DESCRIPTION

The DESCRIPTION column gives the part names in English.

To order a part, indicate the part name, too.

3. TOOL

This is a list of tools used for servicing products.

4. NUMERICAL INDEX

All the parts listed in this parts catalog are arranged in order of part number. You can identify part locations and names from the NUMERICAL INDEX.

This page intentionally left blank

1. ILLUSTRATION INDEX





FIGURE 1	PIXMA MP760 PACKAGE CONTENTS	See Page 2-1	FIGURE 2	OUTER COVER, PRESSURE PLATE ASS'Y	See Page 2-3
					
FIGURE 3	PRESSURE PLATE ASS'Y (1)	See Page 2-5	FIGURE 4	SCANNER UNIT, MIDDLE FRAME	See Page 2-7
					





FIGURE 5	SPCNT BOARD ASS'Y, MULTI-CARD READER ASS'Y, PAPER EXIT TRAY ASS'Y	See Page 2-9	FIGURE 6	PRINT & ASF ASS'Y, INK ABSORBER, BOTTOM FRAME ASS'Y	See Page 2-11
					
FIGURE 7	PRINT ASS'Y, SHEET FEED ASS'Y, POWER SUPPLY UNIT, RELAY BOARD ASS'Y	See Page 2-13	FIGURE 8	CARRIAGE UNIT	See Page 2-15
					

FIGURE 9 CARRIAGE MOTOR, PAPER FEED MOTOR

See Page 2-17




FIGURE 10 PURGE UNIT, PLATEN UNIT, PAPER FEED ROLLER ASS'Y

See Page 2-19






FIGURE 11 TOOLS

See Page 3-1



This page intentionally left blank

2. PARTS LAYOUT & PARTS LIST

FIGURE 1 PIXMA MP760 PACKAGE CONTENTS




FIGURE & KEY No.	PART No.	R A N K	Q T Y	DESCRIPTION	REMARKS
1 - 1	HY7-3084-000		1	CORD, POWER SUPPLY (US)	USA CND
	HY7-3085-000		1	CORD, POWER SUPPLY (EURO)	EMB EUM AE
	HY7-3087-000		1	CORD, POWER SUPPLY (GB)	GB
	HY7-3089-000		1	CORD, POWER SUPPLY (AUS)	AUS
2	HT7-0222-000	N	1	BASIC GUIDE (ENGLISH)	USA AUS AE
	HT7-0223-000	N	1	BASIC GUIDE (GB/FR/ES/PT)	EUM CND GB
	HT7-0224-000	N	1	BASIC GUIDE (DE/IT/NL/GR)	EUM
	HT7-0225-000	N	1	BASIC GUIDE (DK/FI/NO/SE)	EUM
	HT7-0226-000	N	1	BASIC GUIDE (CZ/HU/PL/SI/HR)	EMB
	HT7-0227-000	N	1	BASIC GUIDE(RU/UA/EE/LV/LT/GB)	EMB
3	NPN		1	INK TANK	
4	NPN		1	INK TANK	
5	NPN		1	INK TANK	
6	NPN		1	INK TANK	
7	NPN		1	INK TANK	
8	QY6-0049-000		1	PRINT HEAD	
9	QA4-1117-000		1	TRAY, CD SUB	EUM AUS EMB GB AE
10	QC1-4249-000		1	TRAY, CD MAIN	EUM AUS EMB GB AE
11	HK1-0600-000	N	1	CD-ROM, PRINTER DRIVER (WIN)	USA
	HK1-0601-000	N	1	CD-ROM, PRINTER DRIVER 1 (WIN)	EUM AUS GB AE
12	HK1-0602-000	N	1	CD-ROM, PRINTER DRIVER 2 (WIN)	EUM GB
	HK1-0603-000	N	1	CD-ROM, PRINTER DRIVER 3 (WIN)	EMB
	HK1-0604-000	N	1	CD-ROM, PRINTER DRIVER 4 (WIN)	CND
	HK1-0607-000	N	1	CD-ROM, PRINTER DRIVER (MAC)	USA
	HK1-0608-000	N	1	CD-ROM, PRINTER DRIVER 1 (MAC)	EUM AUS EMB GB AE
	HK1-0609-000	N	1	CD-ROM, PRINTER DRIVER 4 (MAC)	CND

FIGURE 2 OUTER COVER, PRESSURE PLATE ASS'Y



FIGURE & KEY No.	PART No.	R A N K	Q T Y	DESCRIPTION	REMARKS
2- 1	HY7-3219-000		1	COVER, LEFT	
2	HY7-2937-000		1	SPRING, OPEN BUTTON	
3	HY7-3209-000		1	BUTTON, OPEN	
4	HY7-3221-000		1	COVER, RIGHT	
5	HY7-3211-000		1	COVER, CARD	
6	HY7-2865-000		1	CASSETTE UNIT	
7	HY7-2950-000		1	TRAY, PAPER	
8	HY7-3224-000		1	COVER, IRDA	

FIGURE 3 PRESSURE PLATE ASS'Y (1)




FIGURE & KEY No.	PART No.	R A N K	Q T Y	DESCRIPTION	REMARKS
3- 1	HY7-3229-000		1	PRESSURE PLATE ASS'Y	
2	HY7-3226-000		1	GUIDE, MOUNT FILM	
3	HY7-3225-000		1	GUIDE, SLEEVE FILM	
4	HY7-3227-000		1	WHITE SHEET UNIT	
5	HY7-3061-000		1	SHEET, DOCUMENT, PRESSURE	
6	HY7-3216-000		2	HINGE	
7	HY7-3067-000		1	PLATE, LOGO, PIXMA	
8	HY7-3230-000		1	LOGO, CANON	

FIGURE 4 SCANNER UNIT, MIDDLE FRAME





FIGURE & KEY No.	PART No.	R A N K	Q T Y	DESCRIPTION	REMARKS
4- 1	HY7-3215-000		1	COVER, OPERATION PANEL, RIGHT	USA CND AUS AE
	HY7-3231-000		1	COVER, OPERATION PANEL, RIGHT	EMB GB EUM
2	HY7-3222-000		1	SCANNER UNIT	
3	HY7-2920-000		2	RAIL, SCANNER	
4	HY7-3218-000		1	COVER, LCD	
5	HY7-2949-000		1	SCANNER OPEN ARM ASS'Y	
6	HY7-2939-000		2	SPRING, SCANNER	
7	HY7-2946-000		1	BUSHING, SCANNER, RIGHT	
8	HY7-2900-000		1	FRAME, MIDDLE	
9	HY7-2490-000		1	SPRING, SCANNER ARM	
10	HY7-2853-000		1	ARM, SCANNER SENSOR	
11	HY7-2859-000		1	BUSHING, SCANNER, LEFT	
12	HY7-2871-000		1	COVER, CARRIAGE	
13	HY7-3213-000		1	COVER, OPERATION PANEL, LEFT	USA CND AUS AE
	HY7-3232-000		1	COVER, OPERATION PANEL, LEFT	EMB GB EUM

FIGURE 5 SPCNT BOARD ASS'Y,
MULTI-CARD READER ASS'Y,
PAPER EXIT TRAY ASS'Y



[illegible]

FIGURE 6 PRINT & ASF ASS'Y, INK ABSORBER,
BOTTOM FRAME ASS'Y






FIGURE & KEY No.	PART No.	R A N K	Q T Y	DESCRIPTION	REMARKS
6- 1	HY7-2869-000		1	COVER, BOTTOM, CABLE	
2	HY7-2856-000		1	BOTTOM FRAME ASS'Y	
3	HY7-2890-000		1	ABSORBER, INK	
4	HY7-2889-000		1	ABSORBER, INK	
5	HY7-2888-000		1	ABSORBER, INK	
6	HY7-2887-000		1	ABSORBER, INK	
7	HY7-2891-000		3	ABSORBER, INK	
8	HY7-2886-000		1	ABSORBER, INK	
9	HY7-2885-000		1	ABSORBER, INK	
10	HY7-2953-000		1	ABSORBER, INK	

**FIGURE 7 PRINT ASS'Y, SHEET FEED ASS'Y,
POWER SUPPLY UNIT, RELAY BOARD ASS'Y**




[illegible]

FIGURE 8 CARRIAGE UNIT




[illegible]

FIGURE 9 CARRIAGE MOTOR, PAPER FEED MOTOR



[illegible]



FIGURE 10 PURGE UNIT, PLATEN UNIT,
PAPER FEED ROLLER ASS'Y



[illegible]

3.TOOL

FIGURE 11 TOOLS



[illegible]

4. NUMERICAL INDEX

PART NUMBER	FIGURE & KEY No.	DESCRIPTION	PART NUMBER	FIGURE & KEY No.	DESCRIPTION
CK-8012-000	11 - T1	LUBE, MOLYKOTE HP300 GREASE	HY7-2946-000	4 - 7	BUSHING, SCANNER, RIGHT
HC1-2490-000	5 - 7	LABEL, SCANNER OPEN	HY7-2949-000	4 - 5	SCANNER OPEN ARM ASS'Y
HK1-0600-000	1 - 11	CD-ROM, PRINTER DRIVER (WIN)	HY7-2950-000	2 - 7	TRAY, PAPER
HK1-0601-000	1 - 11	CD-ROM, PRINTER DRIVER 1 (WIN)	HY7-2951-000	7 - 2	SHEET FEED ASS'Y
HK1-0602-000	1 - 11	CD-ROM, PRINTER DRIVER 2 (WIN)	HY7-2952-000	7 - 5	PAPER FEED GUIDE ASS'Y
HK1-0603-000	1 - 11	CD-ROM, PRINTER DRIVER 3 (WIN)	HY7-2953-000	6 - 10	ABSORBER, INK
HK1-0604-000	1 - 11	CD-ROM, PRINTER DRIVER 4 (WIN)	HY7-2954-000	10 - 3	BUSHING
HK1-0607-000	1 - 12	CD-ROM, PRINTER DRIVER (MAC)	HY7-3061-000	3 - 5	SHEET, DOCUMENT, PRESSURE
HK1-0608-000	1 - 12	CD-ROM, PRINTER DRIVER 1 (MAC)	HY7-3063-000	8 - 5	SHAFT, CARRIAGE
HK1-0609-000	1 - 12	CD-ROM, PRINTER DRIVER 4 (MAC)	HY7-3064-000	8 - 6	CLIP, CARRIAGE SHAFT
HT7-0222-000	1 - 2	BASIC GUIDE (ENGLISH)	HY7-3067-000	3 - 7	PLATE, LOGO, PIXMA
HT7-0223-000	1 - 2	BASIC GUIDE (GB/FR/ES/PT)	HY7-3068-000	5 - 5	CD-R TRAY UNIT
HT7-0224-000	1 - 2	BASIC GUIDE (DE/IT/NL/GR)	HY7-3080-000	7 - 3	RELAY BOARD ASS'Y
HT7-0225-000	1 - 2	BASIC GUIDE (DK/FI/NO/SE)	HY7-3083-000	10 - 5	FILM, TIMING SLIT DISK
HT7-0226-000	1 - 2	BASIC GUIDE (CZ/HU/PL/SI/HR)	HY7-3084-000	1 - 1	CORD, POWER SUPPLY (US)
HT7-0227-000	1 - 2	BASIC GUIDE(RU/UA/EE/LV/LT/GB)	HY7-3085-000	1 - 1	CORD, POWER SUPPLY (EURO)
HY7-2490-000	4 - 9	SPRING, SCANNER ARM	HY7-3087-000	1 - 1	CORD, POWER SUPPLY (GB)
HY7-2853-000	4 - 10	ARM, SCANNER SENSOR	HY7-3089-000	1 - 1	CORD, POWER SUPPLY (AUS)
HY7-2856-000	6 - 2	BOTTOM FRAME ASS'Y	HY7-3209-000	2 - 3	BUTTON, OPEN
HY7-2859-000	4 - 11	BUSHING, SCANNER, LEFT	HY7-3210-000	5 - 3	IRDA BOARD ASS'Y
HY7-2862-000	8 - 1	CARRIAGE UNIT	HY7-3211-000	2 - 5	COVER, CARD
HY7-2863-000	8 - 3	FILM, TIMING SLIT STRIP	HY7-3213-000	4 - 13	COVER, OPERATION PANEL, LEFT
HY7-2864-000	9 - 1	MOTOR, CARRIAGE	HY7-3215-000	4 - 1	COVER, OPERATION PANEL, RIGHT
HY7-2865-000	2 - 6	CASSETTE UNIT	HY7-3216-000	3 - 6	HINGE
HY7-2866-000	5 - 5	CD-R TRAY UNIT	HY7-3218-000	4 - 4	COVER, LCD
HY7-2867-000	8 - 2	SPRING, CARRIAGE SHAFT R	HY7-3219-000	2 - 1	COVER, LEFT
HY7-2868-000	8 - 4	SPRING, CARRIAGE SHAFT L	HY7-3220-000	5 - 6	PAPER EXIT TRAY ASS'Y
HY7-2869-000	6 - 1	COVER, BOTTOM, CABLE	HY7-3221-000	2 - 4	COVER, RIGHT
HY7-2871-000	4 - 12	COVER, CARRIAGE	HY7-3222-000	4 - 2	SCANNER UNIT
HY7-2885-000	6 - 9	ABSORBER, INK	HY7-3223-000	5 - 2	SPCNT BOARD ASS'Y
HY7-2886-000	6 - 8	ABSORBER, INK	HY7-3224-000	2 - 8	COVER, IRDA
HY7-2887-000	6 - 6	ABSORBER, INK	HY7-3225-000	3 - 3	GUIDE, SLEEVE FILM
HY7-2888-000	6 - 5	ABSORBER, INK	HY7-3226-000	3 - 2	GUIDE, MOUNT FILM
HY7-2889-000	6 - 4	ABSORBER, INK	HY7-3227-000	3 - 4	WHITE SHEET UNIT
HY7-2890-000	6 - 3	ABSORBER, INK	HY7-3228-000	5 - 1	MULTI-CARD READER ASS'Y
HY7-2891-000	6 - 7	ABSORBER, INK	HY7-3229-000	3 - 1	PRESSURE PLATE ASS'Y
HY7-2896-000	9 - 8	MOTOR, PAPER FEED	HY7-3230-000	3 - 8	LOGO, CANON
HY7-2897-000	10 - 1	PAPER FEED ROLLER ASS'Y	HY7-3231-000	4 - 1	COVER, OPERATION PANEL, RIGHT
HY7-2900-000	4 - 8	FRAME, MIDDLE	HY7-3232-000	4 - 13	COVER, OPERATION PANEL, LEFT
HY7-2902-000	9 - 3	LIFT CAM SHAFT ASS'Y	QA4-1117-000	1 - 9	TRAY, CD SUB
HY7-2903-000	9 - 7	PAPER GUIDE UNIT	QC1-4249-000	1 - 10	TRAY, CD MAIN
HY7-2904-000	9 - 6	SPRING, ARM	QY6-0049-000	1 - 8	PRINT HEAD
HY7-2913-000	9 - 2	PHOTO INTERRUPTER	QY9-0057-000	11 - T2	LUBE,FLOIL KG-107A,OIL
HY7-2915-000	10 - 2	PLATEN UNIT			
HY7-2916-000	7 - 4	POWER SUPPLY UNIT			
HY7-2917-000	9 - 5	PRESSURE ROLLER ASS'Y			
HY7-2918-000	7 - 1	PRINT ASS'Y			
HY7-2919-000	10 - 4	PURGE UNIT			
HY7-2920-000	4 - 3	RAIL, SCANNER			
HY7-2930-000	5 - 4	SOLENOID			
HY7-2937-000	2 - 2	SPRING, OPEN BUTTON			
HY7-2938-000	9 - 4	SPRING, TORSION			
HY7-2939-000	4 - 6	SPRING, SCANNER			

Canon