



DP-670/DP-670(B)

SERVICE MANUAL

CAUTION

RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE. DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS.

It may be illegal to dispose of this battery into the municipal waste stream. Check with your local solid waste officials for details in your area for proper disposal.

ATTENTION

IL Y A UN RISQUE D'EXPLOSION SI LA BATTERIE EST REMPLACÉE PAR UN MODÈLE DE TYPE INCORRECT. METTRE AU REBUT LES BATTERIES UTILISÉES SELON LES INSTRUCTIONS DONNÉES.

Il peut être illégal de jeter les batteries dans des eaux d'égout municipales. Vérifiez avec les fonctionnaires municipaux de votre région pour les détails concernant des déchets solides et une mise au rebut appropriée.

Revision history

Revision	Date	Replaced pages	Remarks
1	October 31, 2007	1-1-1, 1-2-1, 1-3-2, 1-3-5, 1-3-6, 1-3-18, 1-3-21, 1-3-22, 1-3-24, 1-5-6, 1-5-8, 1-6-2, 2-4-2, 2-4-3	-
2	October 5, 2009	Contents, 1-3-1, 1-3-9, 1-3-17, 1-3-25, 1-3-32 to 1-3-47, 1-4-4, 1-5-1, 1-6-1 to 1-6-3	-
3	February 4, 2010	1-4-2, 1-4-3, 2-4-1 to 2-4-3	-




This page is intentionally left blank.


Safety precautions


This booklet provides safety warnings and precautions for our service personnel to ensure the safety of their customers, their machines as well as themselves during maintenance activities. Service personnel are advised to read this booklet carefully to familiarize themselves with the warnings and precautions described here before engaging in maintenance activities.

Safety warnings and precautions

Various symbols are used to protect our service personnel and customers from physical danger and to prevent damage to their property. These symbols are described below:

 **DANGER:** High risk of serious bodily injury or death may result from insufficient attention to or incorrect compliance with warning messages using this symbol.

 **WARNING:** Serious bodily injury or death may result from insufficient attention to or incorrect compliance with warning messages using this symbol.

 **CAUTION:** Bodily injury or damage to property may result from insufficient attention to or incorrect compliance with warning messages using this symbol.

Symbols

The triangle (△) symbol indicates a warning including danger and caution. The specific point of attention is shown inside the symbol.



General warning.



Warning of risk of electric shock.



Warning of high temperature.

⊘ indicates a prohibited action. The specific prohibition is shown inside the symbol.



General prohibited action.



Disassembly prohibited.

● indicates that action is required. The specific action required is shown inside the symbol.



General action required.



Remove the power plug from the wall outlet.



Always ground the copier.

1. Installation Precautions

WARNING

- Do not use a power supply with a voltage other than that specified. Avoid multiple connections to one outlet: they may cause fire or electric shock. When using an extension cable, always check that it is adequate for the rated current.
- Connect the ground wire to a suitable grounding point. Not grounding the copier may cause fire or electric shock. Connecting the earth wire to an object not approved for the purpose may cause explosion or electric shock. Never connect the ground cable to any of the following: gas pipes, lightning rods, ground cables for telephone lines and water pipes or faucets not approved by the proper authorities.



CAUTION:

- Do not place the copier on an infirm or angled surface: the copier may tip over, causing injury.
- Do not install the copier in a humid or dusty place. This may cause fire or electric shock.
- Do not install the copier near a radiator, heater, other heat source or near flammable material.



This may cause fire.



- Allow sufficient space around the copier to allow the ventilation grills to keep the machine as cool as possible. Insufficient ventilation may cause heat buildup and poor copying performance.



- Always handle the machine by the correct locations when moving it.
- Always use anti-toppling and locking devices on copiers so equipped. Failure to do this may cause the copier to move unexpectedly or topple, leading to injury.
- Avoid inhaling toner or developer excessively. Protect the eyes. If toner or developer is accidentally ingested, drink a lot of water to dilute it in the stomach and obtain medical attention immediately. If it gets into the eyes, rinse immediately with copious amounts of water and obtain medical attention.













- Advise customers that they must always follow the safety warnings and precautions in the copier's instruction handbook.







2.Precautions for Maintenance

WARNING

- Always remove the power plug from the wall outlet before starting machine disassembly. 
- Always follow the procedures for maintenance described in the service manual and other related brochures. 
- Under no circumstances attempt to bypass or disable safety features including safety mechanisms and protective circuits. 
- Always use parts having the correct specifications. 
- Always use the thermostat or thermal fuse specified in the service manual or other related brochure when replacing them. Using a piece of wire, for example, could lead to fire or other serious accident. 
- When the service manual or other serious brochure specifies a distance or gap for installation of a part, always use the correct scale and measure carefully. 
- Always check that the copier is correctly connected to an outlet with a ground connection. 
- Check that the power cable covering is free of damage. Check that the power plug is dust-free. If it is dirty, clean it to remove the risk of fire or electric shock. 
- Never attempt to disassemble the optical unit in machines using lasers. Leaking laser light may damage eyesight. 
- Handle the charger sections with care. They are charged to high potentials and may cause electric shock if handled improperly. 

CAUTION

- Wear safe clothing. If wearing loose clothing or accessories such as ties, make sure they are safely secured so they will not be caught in rotating sections. 
- Use utmost caution when working on a powered machine. Keep away from chains and belts. 
- Handle the fixing section with care to avoid burns as it can be extremely hot. 
- Check that the fixing unit thermistor, heat and press rollers are clean. Dirt on them can cause abnormally high temperatures. 

• Do not remove the ozone filter, if any, from the copier except for routine replacement.



• Do not pull on the AC power cord or connector wires on high-voltage components when removing them; always hold the plug itself.



• Do not route the power cable where it may be stood on or trapped. If necessary, protect it with a cable cover or other appropriate item.



• Treat the ends of the wire carefully when installing a new charger wire to avoid electric leaks.



• Remove toner completely from electronic components.



• Run wire harnesses carefully so that wires will not be trapped or damaged.



• After maintenance, always check that all the parts, screws, connectors and wires that were removed, have been refitted correctly. Special attention should be paid to any forgotten connector, trapped wire and missing screws.



• Check that all the caution labels that should be present on the machine according to the instruction handbook are clean and not peeling. Replace with new ones if necessary.



• Handle greases and solvents with care by following the instructions below:



- Use only a small amount of solvent at a time, being careful not to spill. Wipe spills off completely.
- Ventilate the room well while using grease or solvents.
- Allow applied solvents to evaporate completely before refitting the covers or turning the power switch on.
- Always wash hands afterwards.

• Never dispose of toner or toner bottles in fire. Toner may cause sparks when exposed directly to fire in a furnace, etc.



• Should smoke be seen coming from the copier, remove the power plug from the wall outlet immediately.



3.Miscellaneous

WARNING

• Never attempt to heat the drum or expose it to any organic solvents such as alcohol, other than the specified refiner; it may generate toxic gas.



This page is intentionally left blank.

CONTENTS

1-1 Specifications	
1-1-1 Specifications	1-1-1
1-1-2 Parts names	1-1-2
1-1-3 Machine cross section	1-1-3
1-2 Installation	
1-2-1 Installation environment	1-2-1
1-2-2 Unpacking	1-2-2
(1) Unpacking	1-2-2
(2) Removing the tapes and the spacer.....	1-2-3
1-3 Maintenance Mode	
1-3-1 Maintenance mode (DP-670/models with color touch panel)	1-3-1
(1) Executing a maintenance item	1-3-1
(2) Maintenance mode item list.....	1-3-2
(3) Contents of maintenance mode items.....	1-3-3
1-3-2 Maintenance mode (DP-670/models with monochrome touch panel)	1-3-17
(1) Executing a maintenance item	1-3-17
(2) Maintenance mode item list.....	1-3-18
(3) Contents of maintenance mode items.....	1-3-19
1-3-3 Maintenance mode (DP-670(B)/models with color touch panel).....	1-3-32
(1) Executing a maintenance item	1-3-32
(2) Maintenance mode item list.....	1-3-33
(3) Contents of maintenance mode items.....	1-3-34
1-4 Troubleshooting	
1-4-1 Original misfeed detection	1-4-1
(1) Original misfeed indication	1-4-1
(2) Original misfeed detection conditions.....	1-4-1
(3) Paper misfeeds	1-4-3
1-4-2 Self-diagnosis	1-4-4
(1) Self-diagnostic function	1-4-4
(2) Self diagnostic codes (DP-670).....	1-4-4
(3) Self diagnostic codes (DP-670(B)).....	1-4-4
1-4-3 Electric problems	1-4-5
1-4-4 Mechanical problems	1-4-6
1-5 Assembly and Disassembly	
1-5-1 Precautions for assembly and disassembly	1-5-1
(1) Precautions	1-5-1
1-5-2 Original feed section	1-5-2
(1) Detaching and refitting the DP forwarding pulley and DP feed pulley.....	1-5-2
(2) Detaching and refitting the DP separation pad.....	1-5-5
1-5-3 Image adjustment	1-5-6
(1) Adjusting the angle of leading edge	1-5-6
(2) Adjusting the angle of trailing edge	1-5-7
1-6 Requirements on PWB Replacement	
1-6-1 Upgrading the firmware (DP-670/models with color touch panel).....	1-6-1
1-6-2 Upgrading the firmware (DP-670/models with monochrome touch panel)	1-6-2
1-6-3 Upgrading the firmware (DP-670(B)/models with color touch panel).....	1-6-3
2-1 Mechanical construction	
2-1-1 Mechanical construction	2-1-1
(1) Operation of original switchback	2-1-3

2-2 Electrical Parts Layout

2-2-1 Electrical parts layout.....	2-2-1
(1) PWBs	2-2-1
(2) Switches and sensors	2-2-2
(3) Motors	2-2-3
(4) Solenoids.....	2-2-4

2-3 Operation of the PWBs

2-3-1 DP main PWB	2-3-1
-------------------------	-------

2-4 Appendixes

List of maintenance parts.....	2-4-1
Periodic maintenance procedures	2-4-2
Wiring diagram.....	2-4-4

1-1-1 Specifications

Type	Machine mounted type duplex sheet-through document feeder
Original feed method	Automatic feed
Original weight	Single-sided original mode: 45 to 160 g/m ² Double-sided original mode: 50 to 120 g/m ²
Original type	Sheet originals
Original size	A3 to A5R/Ledger (11 x 17") to StatementR (5 1/2 x 8 1/2")
Original No. of sheets	75 sheets or less (50 to 80 g/m ²) Mixed original sizes: 30 sheets or less (50 to 80 g/m ²)
Original scanning speed	Monochrome (normal): 78.5 to 157 mm/s Monochrome (hi-speed): 350 mm/s Color: 78.5 mm/s
Power source	Electrically connected to the machine
Dimensions	559 (W) x 487 (D) x 131 (H) mm 22" (W) x 19 3/16" (D) x 5 3/16" (H)
Weight	7 kg/15.4 lbs or less

a: 559 mm/22"

b: 487 mm/19 3/16"

c: 131 mm/5 3/16"




Figure 1-1-1

NOTE: These specifications are subject to change without notice.

1-1-2 Parts names





Figure 1-1-2

1. Original table
2. Original width guides
3. Original eject table
4. Document processor top cover
5. Original placement indicator
6. Original stopper
7. Cleaning cloth compartment

1-1-3 Machine cross section**Figure 1-1-3 Machine cross section**

1. Original feed section
2. Original conveying section
3. Original switchback section

This page is intentionally left blank.

1-2-1 Installation environment

Installation location (Be based on the machine establishment place.)

Avoid direct sunlight or bright lighting. Ensure that the photo-conductor will not be exposed to direct sunlight or other strong light when removing paper jams.

Avoid locations subject to high temperature and high humidity or low temperature and low humidity; an abrupt change in the environmental temperature; and cool or hot, direct air.

Avoid places subject to dust and vibrations.

Choose a surface capable of supporting the weight of the machine.

Place the machine on a level surface (maximum allowance inclination: 1°).

Avoid air-borne substances that may adversely affect the machine or degrade the photo-conductor, such as mercury, acidic or alkaline vapors, inorganic gasses, NOx, SOx gases and chlorine-based organic solvents.

Select a well-ventilated location.

1-2-2 Unpacking

(1) Unpacking




Figure 1-2-1 Unpacking

- 1. Document processor
- 2. Outer case
- 3. Inner case
- 4. Rear upper pad
- 5. Rear lower pad
- 6. Front pad
- 7. Spacer
- 8. Plastic sheet
- 9. Plastic bag

- 10. Cloth
- 11. Tray spacer
- 12. Plastic bag
- 13. Original mat
- 14. Plastic bag
- 15. M4 x 14 screws
- 16. Pins
- 17. Angle adjusting plate
- 18. Plastic bag

- 19. Installation guide
- 20. Caution label
- 21. Caution label
- 22. Operation label*¹
- 23. Operation label A*²
- 24. Operation label B*²
- 25. Operation label C*²

*1: Inch models only

*2: Metric models only

Caution: See the Installation Guide for installation.

www.tonerplus.com.ua

(2) Removing the tapes and the spacer

Procedure

1. Remove two tapes.




Figure 1-2-2

2. Open the document processor top cover.
3. Raise the DP feed pulley unit.
4. Open the spacer.
5. Raise the original table.
6. Remove the spacer.
7. Remove the plastic bag.





Figure 1-2-3

This page is intentionally left blank.

1-3-1 Maintenance mode (DP-670/models with color touch panel)

The machine is equipped with a maintenance function which can be used to maintain and service the machine.

(1) Executing a maintenance item



(2) Maintenance mode item list




Section	Item No.	Content of maintenance item	Initial setting*
General	U019	Displaying the ROM version	-
Optical	U068	Adjusting the scanning position for originals from the DP	0/0 ^{*1}
	U070	Adjusting the DP magnification	0/0 ^{*1}
	U071	Adjusting the DP scanning timing	0/0/0/0/0/0/0 ^{*1}
	U072	Adjusting the DP center line	0/0 ^{*1}
	U074	Adjusting the DP input light luminosity	0/0/0/0 ^{*1}
	U087	Setting DP reading position modification operation	125/125/120 ^{*1}
Operation panel and support equipment	U203	Checking DP operation	-
	U243	Checking the operation of the DP motors	-
	U244	Checking the DP switches	-
Mode setting	U326	Setting the black line cleaning indication	ON/8 ^{*1,*2}
Image processing	U404	Adjusting margins for scanning an original from the DP	3.0/2.5/3.0/4.0 ^{*1}
	U411	Adjusting the scanner automatically	-
Other	U905	Checking/clearing counts by optional devices	-
	U942	Setting of deflection for feeding from DP	0/0 ^{*1}




*Initial setting for executing U020, *1: The item initialized for executing U020, *2: The item initialized for executing U021

(3) Contents of maintenance mode items

Maintenance item No.	Description																																				
U019	<p>Displaying the ROM version</p> <p>Description Displays the part number of the ROM fitted to each PWB.</p> <p>Purpose To check the part number or to decide, if the newest version of ROM is installed.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. The ROM version are displayed. 2. Change the screen using the cursor up/down keys. <table border="1"> <thead> <tr> <th>Display</th><th>Description</th></tr> </thead> <tbody> <tr> <td>MAIN</td><td>Main PWB ROM IC</td></tr> <tr> <td>MMI</td><td>Operation PWB ROM IC</td></tr> <tr> <td>ENGINE</td><td>Engine PWB ROM IC</td></tr> <tr> <td>ENGINE BOOT</td><td>Engine PWB booting</td></tr> <tr> <td>OPTION LANGUAGE</td><td>Optional language ROM IC</td></tr> <tr> <td>DICTIONARY</td><td>-</td></tr> <tr> <td>DP</td><td>DP main PWB ROM IC</td></tr> <tr> <td>OPTION CASSETTE</td><td>Optional paper feeder main PWB ROM IC</td></tr> <tr> <td>INNER DF</td><td>Optional built-in finisher main PWB ROM IC</td></tr> <tr> <td>SIMPLE DF MAIN</td><td>Optional document sheet finisher main PWB ROM IC</td></tr> <tr> <td>ENGINE POWER</td><td>Engine power CPU</td></tr> <tr> <td>FAX BOOT1</td><td>Optional fax control PWB booting (port 1)</td></tr> <tr> <td>FAX APL1</td><td>Optional fax control PWB APL (port 1)</td></tr> <tr> <td>FAX IPL1</td><td>Optional fax control PWB IPL (port 1)</td></tr> <tr> <td>FAX BOOT2</td><td>Fax control PWB booting (port 2: optional dual FAX)</td></tr> <tr> <td>FAX APL2</td><td>Fax control PWB APL (port 2: optional dual FAX)</td></tr> <tr> <td>FAX IPL2</td><td>Fax control PWB IPL (port 2: optional dual FAX)</td></tr> </tbody> </table> <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	MAIN	Main PWB ROM IC	MMI	Operation PWB ROM IC	ENGINE	Engine PWB ROM IC	ENGINE BOOT	Engine PWB booting	OPTION LANGUAGE	Optional language ROM IC	DICTIONARY	-	DP	DP main PWB ROM IC	OPTION CASSETTE	Optional paper feeder main PWB ROM IC	INNER DF	Optional built-in finisher main PWB ROM IC	SIMPLE DF MAIN	Optional document sheet finisher main PWB ROM IC	ENGINE POWER	Engine power CPU	FAX BOOT1	Optional fax control PWB booting (port 1)	FAX APL1	Optional fax control PWB APL (port 1)	FAX IPL1	Optional fax control PWB IPL (port 1)	FAX BOOT2	Fax control PWB booting (port 2: optional dual FAX)	FAX APL2	Fax control PWB APL (port 2: optional dual FAX)	FAX IPL2	Fax control PWB IPL (port 2: optional dual FAX)
Display	Description																																				
MAIN	Main PWB ROM IC																																				
MMI	Operation PWB ROM IC																																				
ENGINE	Engine PWB ROM IC																																				
ENGINE BOOT	Engine PWB booting																																				
OPTION LANGUAGE	Optional language ROM IC																																				
DICTIONARY	-																																				
DP	DP main PWB ROM IC																																				
OPTION CASSETTE	Optional paper feeder main PWB ROM IC																																				
INNER DF	Optional built-in finisher main PWB ROM IC																																				
SIMPLE DF MAIN	Optional document sheet finisher main PWB ROM IC																																				
ENGINE POWER	Engine power CPU																																				
FAX BOOT1	Optional fax control PWB booting (port 1)																																				
FAX APL1	Optional fax control PWB APL (port 1)																																				
FAX IPL1	Optional fax control PWB IPL (port 1)																																				
FAX BOOT2	Fax control PWB booting (port 2: optional dual FAX)																																				
FAX APL2	Fax control PWB APL (port 2: optional dual FAX)																																				
FAX IPL2	Fax control PWB IPL (port 2: optional dual FAX)																																				

Maintenance item No.	Description															
U068	<p>Adjusting the scanning position for originals from the DP</p> <p>Description Adjusts the position for scanning originals from the DP. Performs the test copy at the four scanning positions after adjusting.</p> <p>Purpose Used when the image fogging occurs because the scanning position is not proper when the DP is used. Run U071 to adjust the timing of DP leading edge when the scanning position is changed.</p> <p>Setting</p> <p>1. Press the start key.</p> <table><tr><th>Display</th><th>Description</th><th>Setting range</th><th>Initial setting</th><th>Change in value per step</th></tr><tr><td>ADJUST DATA</td><td>Starting position adjustment for scanning originals</td><td>-33 to 33</td><td>0</td><td>0.086 mm</td></tr><tr><td>TEST POSITION</td><td>Scanning position for the test copy originals</td><td>0 to 3</td><td>0</td><td>0.22 mm</td></tr></table> <p>2. Select [ADJUST DATA] of the screen for selecting an item.</p> <p>3. Change the setting using the +/- or numeric keys. When the setting value is increased, the scanning position moves to the right and it moves to the left when the setting value is decreased.</p> <p>4. Press the start key. The value is set.</p> <p>5. Select [TEST POSITION] of the screen for selecting an item.</p> <p>6. Select the scanning position using the +/- or numeric keys.</p> <p>7. Press the start key. The value is set.</p> <p>8. Set the original (the one which density is known) in the DP and press the system menu key. The screen for the test copy mode is displayed.</p> <p>9. Press the start key. Test copy is executed.</p> <p>10. Perform the test copy at each scanning position with the setting value from 0 to 3 and check that no black line appears and the image is normally scanned.</p> <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Setting range	Initial setting	Change in value per step	ADJUST DATA	Starting position adjustment for scanning originals	-33 to 33	0	0.086 mm	TEST POSITION	Scanning position for the test copy originals	0 to 3	0	0.22 mm
Display	Description	Setting range	Initial setting	Change in value per step												
ADJUST DATA	Starting position adjustment for scanning originals	-33 to 33	0	0.086 mm												
TEST POSITION	Scanning position for the test copy originals	0 to 3	0	0.22 mm												

Maintenance item No.	Description															
U070	<p>Adjusting the DP magnification</p> <p>Description Adjusts the DP original scanning speed.</p> <p>Purpose Make the adjustment if the magnification is incorrect in the main scanning direction or auxiliary scanning direction when the DP is used.</p> <p>Method</p> <ol style="list-style-type: none">1. Press the start key.2. Select the item to be adjusted. <table><tr><th>Display</th><th>Description</th><th>Setting range</th><th>Initial setting</th><th>Change in value per step</th></tr><tr><td>MAIN ADJ</td><td>Magnification in the main scanning direction (first page)</td><td>-25 to 25</td><td>0</td><td>0.1 %</td></tr><tr><td>SUB ADJ</td><td>Magnification in the auxiliary scanning direction (second page)</td><td>-25 to 25</td><td>0</td><td>0.1 %</td></tr></table> <p>Adjustment</p> <ol style="list-style-type: none">1. Press the system menu key.2. Place an original on the DP and press the start key to make a test copy.3. Press the system menu key.4. Change the setting value using the +/- or numeric keys. For copy example 1, increase the value. For copy example 2, decrease the value. <div><div></div><div>Original</div></div> <div><div></div><div>Copy example 1</div></div> <div><div></div><div>Copy example 2</div></div> <p>Figure 1-3-1</p> <ol style="list-style-type: none">5. Press the start key. The value is set. <p>Caution Check the copy image after the adjustment. If the image is still incorrect, perform the following adjustments in maintenance mode.</p> <div><div>U070</div><div>→</div><div>U071 (P.1-3-6)</div><div>→</div><div>U404 (P.1-3-12)</div></div> <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Setting range	Initial setting	Change in value per step	MAIN ADJ	Magnification in the main scanning direction (first page)	-25 to 25	0	0.1 %	SUB ADJ	Magnification in the auxiliary scanning direction (second page)	-25 to 25	0	0.1 %
Display	Description	Setting range	Initial setting	Change in value per step												
MAIN ADJ	Magnification in the main scanning direction (first page)	-25 to 25	0	0.1 %												
SUB ADJ	Magnification in the auxiliary scanning direction (second page)	-25 to 25	0	0.1 %												

Maintenance item No.	Description																																													
U071	<p>Adjusting the DP scanning timing</p> <p>Description Adjusts the DP original scanning timing.</p> <p>Purpose Make the adjustment if there is a regular error between the leading or trailing edges of the original and the copy image when the DP is used.</p> <p>Method</p> <ol style="list-style-type: none">1. Press the start key.2. Select the item to be adjusted. <table><thead><tr><th>Display</th><th>Description</th><th>Setting range</th><th>Initial setting</th><th>Change in value per step</th></tr></thead><tbody><tr><td>ADJUST DATA1</td><td>Leading edge registration (first page)</td><td>-32 to 32</td><td>0</td><td>0.196 mm</td></tr><tr><td>ADJUST DATA2</td><td>Trailing edge registration (first page)</td><td>-32 to 28</td><td>0</td><td>0.196 mm</td></tr><tr><td>ADJUST DATA3</td><td>Leading edge registration (second page)</td><td>-32 to 32</td><td>0</td><td>0.196 mm</td></tr><tr><td>ADJUST DATA4</td><td>Trailing edge registration (second page)</td><td>-32 to 28</td><td>0</td><td>0.196 mm</td></tr><tr><td>ADJUST DATA1(H)</td><td>Leading edge registration at high-speed scanning (first page)</td><td>-32 to 32</td><td>0</td><td>0.196 mm</td></tr><tr><td>ADJUST DATA2(H)</td><td>Trailing edge registration at high-speed scanning (first page)</td><td>-32 to 28</td><td>0</td><td>0.196 mm</td></tr><tr><td>ADJUST DATA3(H)</td><td>Leading edge registration at high-speed scanning (second page)</td><td>-32 to 32</td><td>0</td><td>0.196 mm</td></tr><tr><td>ADJUST DATA4(H)</td><td>Trailing edge registration at high-speed scanning (second page)</td><td>-32 to 28</td><td>0</td><td>0.196 mm</td></tr></tbody></table> <p>Adjustment: leading edge registration</p> <ol style="list-style-type: none">1. Press the system menu key.2. Place an original on the DP and press the start key to make a test copy.3. Press the system menu key.4. Change the setting value using the +/- or numeric keys. For copy example 1, increase the value. For copy example 2, decrease the value. <div><div><p>Original</p></div><div><p>Copy example 1</p></div><div><p>Copy example 2</p></div></div> <p>Figure 1-3-2</p> <ol style="list-style-type: none">5. Press the start key. The value is set. <p>Caution Check the copy image after the adjustment. If the image is still incorrect, perform the following adjustments in maintenance mode.</p> <div><div>U071</div><div>→</div><div>U404 (P.1-3-12)</div></div>	Display	Description	Setting range	Initial setting	Change in value per step	ADJUST DATA1	Leading edge registration (first page)	-32 to 32	0	0.196 mm	ADJUST DATA2	Trailing edge registration (first page)	-32 to 28	0	0.196 mm	ADJUST DATA3	Leading edge registration (second page)	-32 to 32	0	0.196 mm	ADJUST DATA4	Trailing edge registration (second page)	-32 to 28	0	0.196 mm	ADJUST DATA1(H)	Leading edge registration at high-speed scanning (first page)	-32 to 32	0	0.196 mm	ADJUST DATA2(H)	Trailing edge registration at high-speed scanning (first page)	-32 to 28	0	0.196 mm	ADJUST DATA3(H)	Leading edge registration at high-speed scanning (second page)	-32 to 32	0	0.196 mm	ADJUST DATA4(H)	Trailing edge registration at high-speed scanning (second page)	-32 to 28	0	0.196 mm
Display	Description	Setting range	Initial setting	Change in value per step																																										
ADJUST DATA1	Leading edge registration (first page)	-32 to 32	0	0.196 mm																																										
ADJUST DATA2	Trailing edge registration (first page)	-32 to 28	0	0.196 mm																																										
ADJUST DATA3	Leading edge registration (second page)	-32 to 32	0	0.196 mm																																										
ADJUST DATA4	Trailing edge registration (second page)	-32 to 28	0	0.196 mm																																										
ADJUST DATA1(H)	Leading edge registration at high-speed scanning (first page)	-32 to 32	0	0.196 mm																																										
ADJUST DATA2(H)	Trailing edge registration at high-speed scanning (first page)	-32 to 28	0	0.196 mm																																										
ADJUST DATA3(H)	Leading edge registration at high-speed scanning (second page)	-32 to 32	0	0.196 mm																																										
ADJUST DATA4(H)	Trailing edge registration at high-speed scanning (second page)	-32 to 28	0	0.196 mm																																										

Maintenance item No.	Description
U071	<p>Adjustment: trailing edge registration</p> <ol style="list-style-type: none"> 1. Press the system menu key. 2. Place an original on the DP and press the start key to make a test copy. 3. Press the system menu key. 4. Change the setting value using the +/- or numeric keys. For copy example 1, increase the value. For copy example 2, decrease the value. <div data-bbox="671 465 1031 696" data-label="Image"> </div> <p style="text-align: center;">Figure 1-3-3</p> <ol style="list-style-type: none"> 5. Press the start key. The value is set. <p>Caution Check the copy image after the adjustment. If the image is still incorrect, perform the following adjustments in maintenance mode.</p> <div data-bbox="287 873 624 943" data-label="Diagram"> <pre> graph LR U071[U071] --> U404[U404 (P.1-3-12)] </pre> </div> <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>

Maintenance item No.	Description															
U072	<p>Adjusting the DP center line</p> <p>Description Adjusts the scanning start position for the DP original.</p> <p>Purpose Make the adjustment if there is a regular error between the centers of the original and the copy image when the DP is used.</p> <p>Adjustment</p> <div><div><div>1. Press the start key.</div><div>2. Select the item to be adjusted.</div></div><table><tr><th>Display</th><th>Description</th><th>Setting range</th><th>Initial setting</th><th>Change in value per step</th></tr><tr><td>ADJUST DATA1</td><td>Center line (first page)</td><td>-78 to 78</td><td>0</td><td>0.085 mm</td></tr><tr><td>ADJUST DATA2</td><td>Center line (second page)</td><td>-78 to 78</td><td>0</td><td>0.085 mm</td></tr></table><div><div><div>3. Press the system menu key.</div><div>4. Place an original on the DP and press the start key to make a test copy.</div><div>5. Press the system menu key.</div><div>6. Change the setting value using the +/- or numeric keys.</div></div><div>For copy example 1, increase the value. For copy example 2, decrease the value.</div></div><div><div><div>Reference</div><div><div><div></div></div><div>Original</div></div><div><div><div></div></div><div>Copy example 1</div></div><div><div><div></div></div><div>Copy example 2</div></div></div></div><p>Figure 1-3-4</p><div><div><div>7. Press the start key. The value is set.</div></div></div><p>Caution Check the copy image after the adjustment. If the image is still incorrect, perform the following adjustments in maintenance mode.</p><div><div><div>U072</div><div></div><div>U404 (P.1-3-12)</div></div></div><p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p></div>	Display	Description	Setting range	Initial setting	Change in value per step	ADJUST DATA1	Center line (first page)	-78 to 78	0	0.085 mm	ADJUST DATA2	Center line (second page)	-78 to 78	0	0.085 mm
Display	Description	Setting range	Initial setting	Change in value per step												
ADJUST DATA1	Center line (first page)	-78 to 78	0	0.085 mm												
ADJUST DATA2	Center line (second page)	-78 to 78	0	0.085 mm												

Maintenance item No.	Description																						
U074	<p>Adjusting the DP input light luminosity</p> <p>Description Sets the luminosity correction for scanning originals from the DP.</p> <p>Purpose Used if the exposure amount differs significantly between when scanning an original on the platen and when scanning an original from the DP.</p> <p>Setting</p> <ol style="list-style-type: none">1. Press the start key.2. Select the item to be set. <table><tr><th>Display</th><th>Description</th><th>Setting range</th><th>Initial setting</th></tr><tr><td>R</td><td>DP input light luminosity of R image</td><td>-12 to 12</td><td>0</td></tr><tr><td>G</td><td>DP input light luminosity of G image</td><td>-12 to 12</td><td>0</td></tr><tr><td>B</td><td>DP input light luminosity of B image</td><td>-12 to 12</td><td>0</td></tr><tr><td>K</td><td>DP input light luminosity of K image</td><td>-12 to 12</td><td>0</td></tr></table> <ol style="list-style-type: none">3. Change the setting using the +/- or numeric keys. Increasing the setting makes the luminosity higher, and decreasing it makes the luminosity lower.4. Press the start key. The value is set. <p>Supplement While this maintenance item is being executed, copying from an original is available in interrupt copying mode (which is activated by pressing the system menu key).</p> <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Setting range	Initial setting	R	DP input light luminosity of R image	-12 to 12	0	G	DP input light luminosity of G image	-12 to 12	0	B	DP input light luminosity of B image	-12 to 12	0	K	DP input light luminosity of K image	-12 to 12	0		
Display	Description	Setting range	Initial setting																				
R	DP input light luminosity of R image	-12 to 12	0																				
G	DP input light luminosity of G image	-12 to 12	0																				
B	DP input light luminosity of B image	-12 to 12	0																				
K	DP input light luminosity of K image	-12 to 12	0																				
U087	<p>Setting DP reading position modification operation</p> <p>Description The presence or absence of dust is determined by comparing the scan data of the original trailing edge and that taken after the original is conveyed past the DP original scanning position. If dust is identified, the DP original scanning position is adjusted for the following originals.</p> <p>Purpose When using DP, to solve the problem when black lines occurs due to the dust with respect to original reading position.</p> <p>Method</p> <ol style="list-style-type: none">1. Press the start key.2. Select the item to be set. The setting screen for the selected item is displayed. <table><tr><th>Display</th><th>Description</th></tr><tr><td>CCD</td><td>Setting of standard data when dust is detected.</td></tr><tr><td>BLACK</td><td>Initialization of original reading position.</td></tr></table> <p>Setting: standard data when dust is detected</p> <ol style="list-style-type: none">1. Select the item to be set.2. Change the value using the +/- or numeric keys. <table><tr><th>Display</th><th>Description</th><th>Setting range</th><th>Initial setting</th></tr><tr><td>CCD R</td><td>Lowest density of the R regard as the dust</td><td>0 to 255</td><td>125</td></tr><tr><td>CCD G</td><td>Lowest density of the G regard as the dust</td><td>0 to 255</td><td>125</td></tr><tr><td>CCD B</td><td>Lowest density of the B regard as the dust</td><td>0 to 255</td><td>120</td></tr></table> <ol style="list-style-type: none">3. Press the start key. The value is set. <p>Setting: Initialization of original reading position</p> <ol style="list-style-type: none">1. Select [CLEAR].2. Press the start key. The setting is cleared. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	CCD	Setting of standard data when dust is detected.	BLACK	Initialization of original reading position.	Display	Description	Setting range	Initial setting	CCD R	Lowest density of the R regard as the dust	0 to 255	125	CCD G	Lowest density of the G regard as the dust	0 to 255	125	CCD B	Lowest density of the B regard as the dust	0 to 255	120
Display	Description																						
CCD	Setting of standard data when dust is detected.																						
BLACK	Initialization of original reading position.																						
Display	Description	Setting range	Initial setting																				
CCD R	Lowest density of the R regard as the dust	0 to 255	125																				
CCD G	Lowest density of the G regard as the dust	0 to 255	125																				
CCD B	Lowest density of the B regard as the dust	0 to 255	120																				

Maintenance item No.	Description																								
U203	<p>Checking DP operation</p> <p>Description Simulates the original conveying operation separately in the DP.</p> <p>Purpose To check the DP operation.</p> <p>Method</p> <ol style="list-style-type: none">1. Press the start key.2. Place an original in the DP if running this simulation with paper.3. Select the item to be operated.4. When selecting [ADP] or [RADP], to set the magnification using the +/- keys. <table><tr><th>Display</th><th>Operation</th><th>Setting range</th><th>Initial setting</th></tr><tr><td>ADP</td><td>With paper, single-sided original</td><td>100 to 200 (%)</td><td>100</td></tr><tr><td>RADP</td><td>With paper, double-sided original</td><td>100 to 200 (%)</td><td>100</td></tr><tr><td>ADP (NON P)</td><td>Without paper, single-sided original (continuous operation)</td><td>-</td><td>-</td></tr><tr><td>RADP (NON P)</td><td>Without paper, double-sided original (continuous operation)</td><td>-</td><td>-</td></tr><tr><td>SPEED</td><td>Switching between normal reading (600 dpi) and high-speed reading</td><td>0 (Normal)/ 1 (high-speed)</td><td>0</td></tr></table> <ol style="list-style-type: none">5. Press the start key. The operation starts.6. To stop continuous operation, press the stop key. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Operation	Setting range	Initial setting	ADP	With paper, single-sided original	100 to 200 (%)	100	RADP	With paper, double-sided original	100 to 200 (%)	100	ADP (NON P)	Without paper, single-sided original (continuous operation)	-	-	RADP (NON P)	Without paper, double-sided original (continuous operation)	-	-	SPEED	Switching between normal reading (600 dpi) and high-speed reading	0 (Normal)/ 1 (high-speed)	0
Display	Operation	Setting range	Initial setting																						
ADP	With paper, single-sided original	100 to 200 (%)	100																						
RADP	With paper, double-sided original	100 to 200 (%)	100																						
ADP (NON P)	Without paper, single-sided original (continuous operation)	-	-																						
RADP (NON P)	Without paper, double-sided original (continuous operation)	-	-																						
SPEED	Switching between normal reading (600 dpi) and high-speed reading	0 (Normal)/ 1 (high-speed)	0																						
U243	<p>Checking the operation of the DP motors</p> <p>Description Turns the motors and solenoids in the DP on.</p> <p>Purpose To check the operation of the DP motors or solenoids.</p> <p>Method</p> <ol style="list-style-type: none">1. Press the start key.2. Select the item to be operated.3. Press the start key. The operation starts. <table><tr><th>Display</th><th>Motors and solenoids</th></tr><tr><td>DP FEED MOTOR</td><td>Original feed motor (OFM) is turned on.</td></tr><tr><td>DP CONV MOTOR</td><td>Original conveying motor (OCM) is turned on.</td></tr><tr><td>DP REV MOTOR</td><td>Original switchback motor (OSBM) is turned on.</td></tr><tr><td>DP RJ SOL</td><td>Switchback feedshift solenoid (SBFSSOL) is turned on.</td></tr><tr><td>DP RP SOL</td><td>Switchback pressure solenoid (SBPSOL) is turned on.</td></tr></table> <ol style="list-style-type: none">4. To stop operation, press the stop key. <p>Completion Press the stop key when operation stops. The screen for selecting a maintenance item No. is displayed.</p>	Display	Motors and solenoids	DP FEED MOTOR	Original feed motor (OFM) is turned on.	DP CONV MOTOR	Original conveying motor (OCM) is turned on.	DP REV MOTOR	Original switchback motor (OSBM) is turned on.	DP RJ SOL	Switchback feedshift solenoid (SBFSSOL) is turned on.	DP RP SOL	Switchback pressure solenoid (SBPSOL) is turned on.												
Display	Motors and solenoids																								
DP FEED MOTOR	Original feed motor (OFM) is turned on.																								
DP CONV MOTOR	Original conveying motor (OCM) is turned on.																								
DP REV MOTOR	Original switchback motor (OSBM) is turned on.																								
DP RJ SOL	Switchback feedshift solenoid (SBFSSOL) is turned on.																								
DP RP SOL	Switchback pressure solenoid (SBPSOL) is turned on.																								

Maintenance item No.	Description														
U244	<p>Checking the DP switches</p> <p>Description Displays the status of the respective switches in the DP.</p> <p>Purpose To check if respective switches in the DP operate correctly.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Turn the respective switches on and off manually to check the status. <p>When a switch is detected to be in the ON position, the display for that switch will be highlighted.</p> <table border="1"> <thead> <tr> <th>Display</th><th>Switches</th></tr> </thead> <tbody> <tr> <td>DP SET SW</td><td>Original set switch (OSSW)</td></tr> <tr> <td>DP PSD SW</td><td>Original size length switch (OSLSW)</td></tr> <tr> <td>DP REV SW</td><td>Original switchback switch (OSBSW)</td></tr> <tr> <td>CCD TMING SW</td><td>DP timing switch (DPTSW)</td></tr> <tr> <td>DP COVER SW</td><td>DP interlock switch (DPILSW)</td></tr> <tr> <td>DP OPEN SW</td><td>DP open/close switch (DPOCSW)</td></tr> </tbody> </table> <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Switches	DP SET SW	Original set switch (OSSW)	DP PSD SW	Original size length switch (OSLSW)	DP REV SW	Original switchback switch (OSBSW)	CCD TMING SW	DP timing switch (DPTSW)	DP COVER SW	DP interlock switch (DPILSW)	DP OPEN SW	DP open/close switch (DPOCSW)
Display	Switches														
DP SET SW	Original set switch (OSSW)														
DP PSD SW	Original size length switch (OSLSW)														
DP REV SW	Original switchback switch (OSBSW)														
CCD TMING SW	DP timing switch (DPTSW)														
DP COVER SW	DP interlock switch (DPILSW)														
DP OPEN SW	DP open/close switch (DPOCSW)														
U326	<p>Setting the black line cleaning indication</p> <p>Description Sets whether to display the cleaning guidance when detecting the black line.</p> <p>Purpose Displays the cleaning guidance in order to make the call for service with the black line decrease by the rubbish on the platen when scanning from the DP.</p> <p>Setting</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select ON or OFF. <table border="1"> <thead> <tr> <th>Display</th><th>Description</th></tr> </thead> <tbody> <tr> <td>ON</td><td>Displays the cleaning guidance</td></tr> <tr> <td>OFF</td><td>Not to display the cleaning guidance</td></tr> <tr> <td>COUNT</td><td>Setting counts of the cleaning guidance indication</td></tr> </tbody> </table> <p>Initial setting: ON</p> <ol style="list-style-type: none"> 3. Press the start key. The setting is set. <p>Setting the count value</p> <ol style="list-style-type: none"> 1. Enter a count using the +/- or numeric keys. Setting range: 0 to 999 Initial setting: 8 When setting is 0, the black line cleaning indication is displayed only if the black line is detected. 2. Press the start key. The count is set. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	ON	Displays the cleaning guidance	OFF	Not to display the cleaning guidance	COUNT	Setting counts of the cleaning guidance indication						
Display	Description														
ON	Displays the cleaning guidance														
OFF	Not to display the cleaning guidance														
COUNT	Setting counts of the cleaning guidance indication														

Maintenance item No.	Description																									
U404	<p>Adjusting margins for scanning an original from the DP</p> <p>Description Adjusts margins for scanning the original from the DP.</p> <p>Purpose Make the adjustment if margins are incorrect when the DP is used.</p> <p>Caution Before making this adjustment, ensure that the following adjustments have been made in maintenance mode.</p> <div><div>U402 (See the service manual for the machine.)</div><div>→</div><div>U403 (See the service manual for the machine.)</div><div>→</div><div>U404</div></div> <p>Adjustment</p> <div><div><div>1. Press the start key.</div><div>2. Select the item to be adjusted.</div></div><table><tr><th>Display</th><th>Description</th><th>Setting range</th><th>Initial setting</th><th>Change in value per step</th></tr><tr><td>A MARGIN</td><td>Left margin</td><td>0 to 10.0</td><td>3.0</td><td>0.5 mm</td></tr><tr><td>B MARGIN</td><td>Leading edge margin</td><td>0 to 10.0</td><td>2.5</td><td>0.5 mm</td></tr><tr><td>C MARGIN</td><td>Right margin</td><td>0 to 10.0</td><td>3.0</td><td>0.5 mm</td></tr><tr><td>D MARGIN</td><td>Trailing edge margin</td><td>0 to 10.0</td><td>4.0</td><td>0.5 mm</td></tr></table><div><div><div>3. Press the system menu key.</div><div>4. Place an original on the DP and press the start key to make a test copy.</div><div>5. Press the system menu key.</div><div>6. Change the setting value using the +/- keys.</div></div><div>Increasing the value makes the margin wider, and decreasing it makes the margin narrower.</div></div><div><div><div>Leading edge margin (3±1.5 mm)</div><div>Left margin (2±1.0 mm)</div><div>Right margin (2±1.0 mm)</div><div>Trailing edge margin (2±1.0 mm)</div></div></div><p>Figure 1-3-5</p><div><div><div>7. Press the start key. The value is set.</div><div>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</div></div></div></div>	Display	Description	Setting range	Initial setting	Change in value per step	A MARGIN	Left margin	0 to 10.0	3.0	0.5 mm	B MARGIN	Leading edge margin	0 to 10.0	2.5	0.5 mm	C MARGIN	Right margin	0 to 10.0	3.0	0.5 mm	D MARGIN	Trailing edge margin	0 to 10.0	4.0	0.5 mm
Display	Description	Setting range	Initial setting	Change in value per step																						
A MARGIN	Left margin	0 to 10.0	3.0	0.5 mm																						
B MARGIN	Leading edge margin	0 to 10.0	2.5	0.5 mm																						
C MARGIN	Right margin	0 to 10.0	3.0	0.5 mm																						
D MARGIN	Trailing edge margin	0 to 10.0	4.0	0.5 mm																						

Maintenance item No.	Description																				
U411	Adjusting the scanner automatically																				
	Description																				
	Uses a specified original and automatically adjusts the following items in the scanner and the DP scanning sections.																				
	Purpose																				
	To perform automatic adjustment of various items in the scanner and the DP scanning sections.																				
	To adjust scanner automatically when initializing the machine using the maintenance item U020 or U022.																				
	Method																				
	1. Press the start key.																				
	2. Select the item. The screen for executing is displayed.																				
	<table><tr><th>Display</th><th>Description</th><th>Original to be used for adjustment (P/N)</th></tr><tr><td>SCANNER</td><td>Automatic adjustment in the scanner section</td><td>302FZ56990</td></tr><tr><td>DP</td><td>Automatic adjustment in the DP scanning section</td><td>2AC68241</td></tr></table>			Display	Description	Original to be used for adjustment (P/N)	SCANNER	Automatic adjustment in the scanner section	302FZ56990	DP	Automatic adjustment in the DP scanning section	2AC68241									
Display	Description	Original to be used for adjustment (P/N)																			
SCANNER	Automatic adjustment in the scanner section	302FZ56990																			
DP	Automatic adjustment in the DP scanning section	2AC68241																			
Method: SCANNER																					
1. Select [SCANNER].																					
2. Enter the target values which are shown on the specified original (P/N: 302FZ56990) executing maintenance item U425.																					
3. Set a specified original (P/N: 302FZ56990) on the platen.																					
4. Select the item.																					
<table><tr><th>Display</th><th>Description</th></tr><tr><td>ALL</td><td>Automatic adjustment using the platen for: original size magnification/leading edge timing/center line, input gamma, chromatic aberration filter, MTF filter, matrix, input gamma in monochrome mode and MTF filter in monochrome mode</td></tr><tr><td>INPUT</td><td>Automatic adjustment using the platen for: original size magnification/leading edge timing/center line</td></tr><tr><td>GAMMA</td><td>Automatic adjustment using the platen for: input gamma</td></tr><tr><td>C.A.</td><td>Automatic adjustment using the platen for: chromatic aberration filter</td></tr><tr><td>MTF</td><td>Automatic adjustment using the platen for: MTF filter</td></tr><tr><td>MATRIX</td><td>Automatic adjustment using the platen for: matrix</td></tr><tr><td>MONO GAMMA</td><td>Automatic adjustment using the platen for: input gamma in monochrome mode</td></tr><tr><td>MONO MTF</td><td>Automatic adjustment using the platen for: MTF filter in monochrome mode</td></tr></table>				Display	Description	ALL	Automatic adjustment using the platen for: original size magnification/leading edge timing/center line, input gamma, chromatic aberration filter, MTF filter, matrix, input gamma in monochrome mode and MTF filter in monochrome mode	INPUT	Automatic adjustment using the platen for: original size magnification/leading edge timing/center line	GAMMA	Automatic adjustment using the platen for: input gamma	C.A.	Automatic adjustment using the platen for: chromatic aberration filter	MTF	Automatic adjustment using the platen for: MTF filter	MATRIX	Automatic adjustment using the platen for: matrix	MONO GAMMA	Automatic adjustment using the platen for: input gamma in monochrome mode	MONO MTF	Automatic adjustment using the platen for: MTF filter in monochrome mode
Display	Description																				
ALL	Automatic adjustment using the platen for: original size magnification/leading edge timing/center line, input gamma, chromatic aberration filter, MTF filter, matrix, input gamma in monochrome mode and MTF filter in monochrome mode																				
INPUT	Automatic adjustment using the platen for: original size magnification/leading edge timing/center line																				
GAMMA	Automatic adjustment using the platen for: input gamma																				
C.A.	Automatic adjustment using the platen for: chromatic aberration filter																				
MTF	Automatic adjustment using the platen for: MTF filter																				
MATRIX	Automatic adjustment using the platen for: matrix																				
MONO GAMMA	Automatic adjustment using the platen for: input gamma in monochrome mode																				
MONO MTF	Automatic adjustment using the platen for: MTF filter in monochrome mode																				
5. Press the start key. Auto adjustment starts.																					
When automatic adjustment has normally completed, [RESULT OK 00] is displayed. If a problem occurs during auto adjustment, [ERROR XX] (XX is replaced by an error code) is displayed and operation stops. Should this happen, determine the details of the problem and either repeat the procedure from the beginning, or adjust the remaining items manually by running the corresponding maintenance items.																					
6. To return to the screen for selecting an item, press the stop key.																					

Maintenance item No.	Description				
U411	<p>Method: DP</p> <ol style="list-style-type: none"> 1. Select [DP]. 2. Set a specified original (P/N: 2AC68241) in the DP. Cut the trailing edge of the original. <div data-bbox="646 409 1059 799" data-label="Image"> <p>128±1 mm 60±1 mm</p> <p>Cut with the edge of black belt.</p> </div> <p style="text-align: center;">Figure 1-3-6</p> <ol style="list-style-type: none"> 3. Press [INPUT]. <table border="1" data-bbox="331 896 1399 1008"> <thead> <tr> <th>Display</th><th>Description</th></tr> </thead> <tbody> <tr> <td>INPUT</td><td>Automatic adjustment of first page using the DP for: original size magnification/leading edge timing/center line</td></tr> </tbody> </table> <ol style="list-style-type: none"> 4. Press the start key. Auto adjustment starts. When automatic adjustment has normally completed, [RESULT OK 00] is displayed. If a problem occurs during auto adjustment, [ERROR XX] (XX is replaced by an error code) is displayed and operation stops. Should this happen, determine the details of the problem and either repeat the procedure from the beginning, or adjust the remaining items manually by running the corresponding maintenance items. 5. To return to the screen for selecting an item, press the stop key. 	Display	Description	INPUT	Automatic adjustment of first page using the DP for: original size magnification/leading edge timing/center line
Display	Description				
INPUT	Automatic adjustment of first page using the DP for: original size magnification/leading edge timing/center line				


Maintenance item No.	Description		
U411	Error Codes		
	Codes	Description	
	ERROR 01	Black band detection error (scanner leading edge registration)	
	ERROR 02	Black band detection error (scanner center line)	
	ERROR 03	Black band detection error (scanner main scanning direction magnification)	
	ERROR 04	Black band is not detected (scanner leading edge registration)	
	ERROR 05	Black band is not detected (scanner center line)	
	ERROR 06	Black band is not detected (scanner main scanning direction magnification)	
	ERROR 07	Black band is not detected (scanner auxiliary scanning direction magnification)	
	ERROR 08	Black band is not detected (DP main scanning direction magnification far end)	
	ERROR 09	Black band is not detected (DP main scanning direction magnification near end)	
	ERROR 0a	Black band is not detected (DP auxiliary scanning direction magnification leading edge)	
	ERROR 0b	Black band is not detected (DP auxiliary scanning direction magnification leading edge original check)	
	ERROR 0c	Black band is not detected (DP auxiliary scanning direction trailing edge)	
	ERROR 0d	Black band is not detected (DP auxiliary scanning direction trailing edge 2)	
	ERROR 0e	DMA time out	
	ERROR 0f	Auxiliary scanning direction magnification error	
	ERROR 10	Auxiliary scanning direction leading edge detection error	
	ERROR 11	Auxiliary scanning direction trailing edge detection error	
	ERROR 12	Auxiliary scanning direction skew 1.5 error	
	ERROR 13	Maintenance request error	
	ERROR 14	Main scanning direction center line error	
	ERROR 15	Main scanning direction skew 1.5 error	
	ERROR 16	Main scanning direction magnification error	
	ERROR 17	Carriage error	
	ERROR 18	Service call error	
	ERROR 19	DP status error	
	ERROR 1a	DP open error	
	ERROR 1b	Original is not detected	
	ERROR ff	Other error	
	ERROR 65	Memory over error	
	Completion		
	Press the stop key. The screen for selecting a maintenance item is displayed.		

Maintenance item No.	Description																		
U905	<p>Checking/clearing counts by optional devices</p> <p>Description Displays or clears the counts of DP or finisher.</p> <p>Purpose To check the use of DP and finisher. Also to clear the counts after replacing consumable parts.</p> <p>Method</p> <ol style="list-style-type: none">1. Press the start key.2. Select the device, the count of which is to be checked. The count of the selected device is displayed. <table><tr><th>Display</th><th>Description</th></tr><tr><td>DP</td><td>Counts of optional DP</td></tr><tr><td>FINISHER</td><td>Counts of optional finisher</td></tr></table> <p>DP</p> <table><tr><th>Display</th><th>Description</th></tr><tr><td>ADP</td><td>No. of single-sided originals that has passed through the DP</td></tr><tr><td>RADP</td><td>No. of double-sided originals that has passed through the DP</td></tr></table> <p>Finisher</p> <table><tr><th>Display</th><th>Description</th></tr><tr><td>CP CNT</td><td>No. of copies that has passed</td></tr><tr><td>STAPLE</td><td>Frequency the stapler has been activated</td></tr></table> <p>Clearing</p> <ol style="list-style-type: none">1. Select the item to be cleared. To clear the counts for all, press the clear key.2. Press the start key. The count is cleared. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	DP	Counts of optional DP	FINISHER	Counts of optional finisher	Display	Description	ADP	No. of single-sided originals that has passed through the DP	RADP	No. of double-sided originals that has passed through the DP	Display	Description	CP CNT	No. of copies that has passed	STAPLE	Frequency the stapler has been activated
Display	Description																		
DP	Counts of optional DP																		
FINISHER	Counts of optional finisher																		
Display	Description																		
ADP	No. of single-sided originals that has passed through the DP																		
RADP	No. of double-sided originals that has passed through the DP																		
Display	Description																		
CP CNT	No. of copies that has passed																		
STAPLE	Frequency the stapler has been activated																		
U942	<p>Setting of deflection for feeding from DP</p> <p>Description Adjusts the deflection generated when the DP is used.</p> <p>Purpose Use this mode if an original non-feed jam, oblique feed or wrinkling of original occurs when the DP is used.</p> <p>Setting</p> <ol style="list-style-type: none">1. Press the start key.2. Select the item to be adjusted. <table><tr><th>Display</th><th>Description</th><th>Setting range</th><th>Initial setting</th><th>Change in value per step</th></tr><tr><td>FEED MOT</td><td>Deflection in the original feed motor</td><td>-31 to 31</td><td>0</td><td>0.098 mm</td></tr><tr><td>REV MOT</td><td>Deflection in the original switchback motor</td><td>-31 to 31</td><td>0</td><td>0.098 mm</td></tr></table> <ol style="list-style-type: none">3. Press the system menu key.4. Place an original on the DP and press the start key to make a test copy.5. Press the system menu key.6. Change the setting value using the +/- or numeric keys. The greater the value, the larger the deflection; the smaller the value, the smaller the deflection. If an original non-feed jam or oblique feed occurs, increase the setting value. If wrinkling of original occurs, decrease the value.7. Press the start key. The setting is set. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Setting range	Initial setting	Change in value per step	FEED MOT	Deflection in the original feed motor	-31 to 31	0	0.098 mm	REV MOT	Deflection in the original switchback motor	-31 to 31	0	0.098 mm			
Display	Description	Setting range	Initial setting	Change in value per step															
FEED MOT	Deflection in the original feed motor	-31 to 31	0	0.098 mm															
REV MOT	Deflection in the original switchback motor	-31 to 31	0	0.098 mm															

1-3-2 Maintenance mode (DP-670/models with monochrome touch panel)

The machine is equipped with a maintenance function which can be used to maintain and service the machine.

(1) Executing a maintenance item



(2) Maintenance mode item list




Section	Item No.	Content of maintenance item	Initial setting*
General	U019	Displaying the ROM version	-
Optical	U068	Adjusting the scanning position for originals from the DP	0/0 ^{*1}
	U070	Adjusting the DP magnification	0/0 ^{*1}
	U071	Adjusting the DP scanning timing	0/0/0/0 ^{*1}
	U072	Adjusting the DP center line	0/0/0 ^{*1}
	U074	Adjusting the DP input light luminosity	0 ^{*1}
	U087	Setting DP reading position modification operation	35 ^{*1}
Operation panel and support equipment	U203	Checking DP operation	-
	U243	Checking the operation of the DP motors	-
	U244	Checking the DP switches	-
Mode setting	U326	Setting the black line cleaning indication	ON/8 ^{*1,*2}
Image processing	U404	Adjusting margins for scanning an original from the DP	3.0/2.5/3.0/4.0 ^{*1}
	U411	Adjusting the scanner automatically	-
Other	U905	Checking counts by optional devices	-
	U942	Setting of deflection for feeding from DP	0/0 ^{*1}




*Initial setting for executing U020, *1: The item initialized for executing U020, *2: The item initialized for executing U021

(3) Contents of maintenance mode items

Maintenance item No.	Description																												
U019	<p>Displaying the ROM version</p> <p>Description Displays the part number of the ROM fitted to each PWB.</p> <p>Purpose To check the part number or to decide, if the newest version of ROM is installed.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. The ROM version are displayed. 2. Change the screen using the * or # keys. <table border="1"> <thead> <tr> <th>Display</th><th>Description</th></tr> </thead> <tbody> <tr> <td>MAIN</td><td>Main PWB ROM IC</td></tr> <tr> <td>MAIN BOOT</td><td>Main PWB booting</td></tr> <tr> <td>ENGINE</td><td>Engine PWB ROM IC</td></tr> <tr> <td>ENGINE BOOT</td><td>Engine PWB booting</td></tr> <tr> <td>LANGUAGE</td><td>Standard language ROM IC</td></tr> <tr> <td>OPTION LANGUAGE</td><td>Optional language ROM IC</td></tr> <tr> <td>DICTIONARY</td><td>-</td></tr> <tr> <td>PRINTER</td><td>Optional printer board ROM IC</td></tr> <tr> <td>DP</td><td>DP main PWB ROM IC</td></tr> <tr> <td>OPTION CASSETTE</td><td>Optional paper feeder main PWB ROM IC</td></tr> <tr> <td>INNER DF</td><td>Optional built-in finisher main PWB ROM IC</td></tr> <tr> <td>SIMPLE DF MAIN</td><td>Optional document finisher main PWB ROM IC</td></tr> <tr> <td>ENGINE POWER</td><td>Engine power CPU</td></tr> </tbody> </table> <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	MAIN	Main PWB ROM IC	MAIN BOOT	Main PWB booting	ENGINE	Engine PWB ROM IC	ENGINE BOOT	Engine PWB booting	LANGUAGE	Standard language ROM IC	OPTION LANGUAGE	Optional language ROM IC	DICTIONARY	-	PRINTER	Optional printer board ROM IC	DP	DP main PWB ROM IC	OPTION CASSETTE	Optional paper feeder main PWB ROM IC	INNER DF	Optional built-in finisher main PWB ROM IC	SIMPLE DF MAIN	Optional document finisher main PWB ROM IC	ENGINE POWER	Engine power CPU
Display	Description																												
MAIN	Main PWB ROM IC																												
MAIN BOOT	Main PWB booting																												
ENGINE	Engine PWB ROM IC																												
ENGINE BOOT	Engine PWB booting																												
LANGUAGE	Standard language ROM IC																												
OPTION LANGUAGE	Optional language ROM IC																												
DICTIONARY	-																												
PRINTER	Optional printer board ROM IC																												
DP	DP main PWB ROM IC																												
OPTION CASSETTE	Optional paper feeder main PWB ROM IC																												
INNER DF	Optional built-in finisher main PWB ROM IC																												
SIMPLE DF MAIN	Optional document finisher main PWB ROM IC																												
ENGINE POWER	Engine power CPU																												

Maintenance item No.	Description															
U068	<p>Adjusting the scanning position for originals from the DP</p> <p>Description Adjusts the position for scanning originals from the DP. Performs the test copy at the four scanning positions after adjusting.</p> <p>Purpose Used when the image fogging occurs because the scanning position is not proper when the DP is used. Run U071 to adjust the timing of DP leading edge when the scanning position is changed.</p> <p>Setting</p> <p>1. Press the start key.</p> <table><tr><th>Display</th><th>Description</th><th>Setting range</th><th>Initial setting</th><th>Change in value per step</th></tr><tr><td>ADJUST DATA</td><td>Starting position adjustment for scanning originals</td><td>-33 to 33</td><td>0</td><td>0.086 mm</td></tr><tr><td>TEST POSITION</td><td>Scanning position for the test copy originals</td><td>0 to 3</td><td>0</td><td>0.22 mm</td></tr></table> <p>2. Select [ADJUST DATA] of the screen for selecting an item.</p> <p>3. Change the setting using the cursor up/down keys. When the setting value is increased, the scanning position moves to the right and it moves to the left when the setting value is decreased.</p> <p>4. Press the start key. The value is set.</p> <p>5. Select [TEST POSITION] of the screen for selecting an item.</p> <p>6. Select the scanning position using the cursor up/down keys.</p> <p>7. Press the start key. The value is set.</p> <p>8. Set the original (the one which density is known) in the DP and press the interrupt key. The screen for the test copy mode is displayed.</p> <p>9. Press the start key. Test copy is executed.</p> <p>10. Perform the test copy at each scanning position with the setting value from 0 to 3 and check that no black line appears and the image is normally scanned.</p> <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Setting range	Initial setting	Change in value per step	ADJUST DATA	Starting position adjustment for scanning originals	-33 to 33	0	0.086 mm	TEST POSITION	Scanning position for the test copy originals	0 to 3	0	0.22 mm
Display	Description	Setting range	Initial setting	Change in value per step												
ADJUST DATA	Starting position adjustment for scanning originals	-33 to 33	0	0.086 mm												
TEST POSITION	Scanning position for the test copy originals	0 to 3	0	0.22 mm												

Maintenance item No.	Description															
U070	<p>Adjusting the DP magnification</p> <p>Description Adjusts the DP original scanning speed.</p> <p>Purpose Make the adjustment if the magnification is incorrect in the auxiliary scanning direction when the DP is used.</p> <p>Method</p> <ol style="list-style-type: none">1. Press the start key.2. Select the item to be adjusted. <table><tr><th>Display</th><th>Description</th><th>Setting range</th><th>Initial setting</th><th>Change in value per step</th></tr><tr><td>MAIN ADJ</td><td>Magnification in the main scanning direction (first page)</td><td>-25 to 25</td><td>0</td><td>0.1 %</td></tr><tr><td>SUB ADJ</td><td>Magnification in the auxiliary scanning direction (second page)</td><td>-25 to 25</td><td>0</td><td>0.1 %</td></tr></table> <p>Adjustment</p> <ol style="list-style-type: none">1. Press the interrupt key.2. Place an original on the DP and press the start key to make a test copy.3. Press the interrupt key.4. Change the setting value using the cursor up/down keys. For copy example 1, increase the value. For copy example 2, decrease the value. <div><div></div><div>Original</div><div></div><div>Copy example 1</div><div></div><div>Copy example 2</div></div> <p>Figure 1-3-7</p> <ol style="list-style-type: none">5. Press the start key. The value is set. <p>Caution Check the copy image after the adjustment. If the image is still incorrect, perform the following adjustments in maintenance mode.</p> <div><div>U070</div><div>→</div><div>U071 (P.1-3-22)</div><div>→</div><div>U404 (P.1-3-28)</div></div> <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Setting range	Initial setting	Change in value per step	MAIN ADJ	Magnification in the main scanning direction (first page)	-25 to 25	0	0.1 %	SUB ADJ	Magnification in the auxiliary scanning direction (second page)	-25 to 25	0	0.1 %
Display	Description	Setting range	Initial setting	Change in value per step												
MAIN ADJ	Magnification in the main scanning direction (first page)	-25 to 25	0	0.1 %												
SUB ADJ	Magnification in the auxiliary scanning direction (second page)	-25 to 25	0	0.1 %												

Maintenance item No.	Description																									
U071	<p>Adjusting the DP scanning timing</p> <p>Description Adjusts the DP original scanning timing.</p> <p>Purpose Make the adjustment if there is a regular error between the leading or trailing edges of the original and the copy image when the DP is used.</p> <p>Method</p> <ol style="list-style-type: none">1. Press the start key.2. Select the item to be adjusted. <table><tr><th>Display</th><th>Description</th><th>Setting range</th><th>Initial setting</th><th>Change in value per step</th></tr><tr><td>ADJUST DATA1</td><td>Leading edge registration (first page)</td><td>-32 to 32</td><td>0</td><td>0.196 mm</td></tr><tr><td>ADJUST DATA2</td><td>Trailing edge registration (first page)</td><td>-32 to 28</td><td>0</td><td>0.196 mm</td></tr><tr><td>ADJUST DATA3</td><td>Leading edge registration (second page)</td><td>-45 to 45</td><td>0</td><td>0.196 mm</td></tr><tr><td>ADJUST DATA4</td><td>Trailing edge registration (second page)</td><td>-45 to 28</td><td>0</td><td>0.196 mm</td></tr></table> <p>Adjustment: Leading edge registration</p> <ol style="list-style-type: none">1. Press the interrupt key.2. Place an original on the DP and press the start key to make a test copy.3. Press the interrupt key.4. Change the setting value using the cursor up/down keys. For copy example 1, increase the value. For copy example 2, decrease the value. <div><div> Original</div><div> Copy example 1</div><div> Copy example 2</div></div> <p>Figure 1-3-8</p> <ol style="list-style-type: none">5. Press the start key. The value is set. <p>Caution Check the copy image after the adjustment. If the image is still incorrect, perform the following adjustments in maintenance mode.</p> <div><div>U071</div><div>→</div><div>U404 (P.1-3-28)</div></div>	Display	Description	Setting range	Initial setting	Change in value per step	ADJUST DATA1	Leading edge registration (first page)	-32 to 32	0	0.196 mm	ADJUST DATA2	Trailing edge registration (first page)	-32 to 28	0	0.196 mm	ADJUST DATA3	Leading edge registration (second page)	-45 to 45	0	0.196 mm	ADJUST DATA4	Trailing edge registration (second page)	-45 to 28	0	0.196 mm
Display	Description	Setting range	Initial setting	Change in value per step																						
ADJUST DATA1	Leading edge registration (first page)	-32 to 32	0	0.196 mm																						
ADJUST DATA2	Trailing edge registration (first page)	-32 to 28	0	0.196 mm																						
ADJUST DATA3	Leading edge registration (second page)	-45 to 45	0	0.196 mm																						
ADJUST DATA4	Trailing edge registration (second page)	-45 to 28	0	0.196 mm																						

Maintenance item No.	Description
U071	<p>Adjustment: Trailing edge registration</p> <ol style="list-style-type: none"> 1. Press the interrupt key. 2. Place an original on the DP and press the start key to make a test copy. 3. Press the interrupt key. 4. Change the setting value using the cursor up/down keys. For copy example 1, increase the value. For copy example 2, decrease the value. <div data-bbox="671 465 1031 696" data-label="Image"> </div> <p style="text-align: center;">Figure 1-3-9</p> <ol style="list-style-type: none"> 5. Press the start key. The value is set. <p>Caution Check the copy image after the adjustment. If the image is still incorrect, perform the following adjustments in maintenance mode.</p> <div data-bbox="287 902 624 972" data-label="Diagram"> <pre> graph LR U071[U071] --> U404[U404 (P.1-3-28)] </pre> </div> <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p>

Maintenance item No.	Description																				
U072	<p>Adjusting the DP center line</p> <p>Description Adjusts the scanning start position for the DP original.</p> <p>Purpose Make the adjustment if there is a regular error between the centers of the original and the copy image when the DP is used.</p> <p>Adjustment</p> <ol style="list-style-type: none">1. Press the start key.2. Select the item to be adjusted. <table><thead><tr><th>Display</th><th>Description</th><th>Setting range</th><th>Initial setting</th><th>Change in value per step</th></tr></thead><tbody><tr><td>DATA(simplesx)</td><td>DP center line (simplesx mode)</td><td>-39 to 39</td><td>0</td><td>0.086 mm</td></tr><tr><td>DATA(duplex 1)</td><td>DP center line (first page of duplex mode)</td><td>-39 to 39</td><td>0</td><td>0.086 mm</td></tr><tr><td>DATA(duplex 2)</td><td>DP center line (second page of duplex mode)</td><td>-39 to 39</td><td>0</td><td>0.086 mm</td></tr></tbody></table> <ol style="list-style-type: none">3. Press the interrupt key.4. Place an original on the DP and press the start key to make a test copy.5. Press the interrupt key.6. Change the setting value using the cursor up/down keys. For copy example 1, increase the value. For copy example 2, decrease the value. <div><p>Reference</p><p>Original Copy example 1 Copy example 2</p></div> <p>Figure 1-3-10</p> <ol style="list-style-type: none">7. Press the start key. The value is set. <p>Caution Check the copy image after the adjustment. If the image is still incorrect, perform the following adjustments in maintenance mode.</p> <div><div>U072</div><div>→</div><div>U404 (P.1-3-28)</div></div> <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Setting range	Initial setting	Change in value per step	DATA(simplesx)	DP center line (simplesx mode)	-39 to 39	0	0.086 mm	DATA(duplex 1)	DP center line (first page of duplex mode)	-39 to 39	0	0.086 mm	DATA(duplex 2)	DP center line (second page of duplex mode)	-39 to 39	0	0.086 mm
Display	Description	Setting range	Initial setting	Change in value per step																	
DATA(simplesx)	DP center line (simplesx mode)	-39 to 39	0	0.086 mm																	
DATA(duplex 1)	DP center line (first page of duplex mode)	-39 to 39	0	0.086 mm																	
DATA(duplex 2)	DP center line (second page of duplex mode)	-39 to 39	0	0.086 mm																	

Maintenance item No.	Description												
U074	<p>Adjusting the DP input light luminosity</p> <p>Description Sets the luminosity correction for scanning originals from the DP.</p> <p>Purpose Used if the exposure amount differs significantly between when scanning an original on the platen and when scanning an original from the DP.</p> <p>Setting</p> <ol style="list-style-type: none">1. Press the start key.2. Select the item to be set. <table><tr><th>Description</th><th>Setting range</th><th>Initial setting</th></tr><tr><td>DP input light luminosity</td><td>-12 to 12</td><td>0</td></tr></table> <ol style="list-style-type: none">3. Change the setting using the cursor up/down keys. Increasing the setting makes the luminosity higher, and decreasing it makes the luminosity lower.4. Press the start key. The value is set. <p>Supplement While this maintenance item is being executed, copying from an original is available in the interrupt copying mode.</p> <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p>	Description	Setting range	Initial setting	DP input light luminosity	-12 to 12	0						
Description	Setting range	Initial setting											
DP input light luminosity	-12 to 12	0											
U087	<p>Setting DP reading position modification operation</p> <p>Description The presence or absence of dust is determined by comparing the scan data of the original trailing edge and that taken after the original is conveyed past the DP original scanning position. If dust is identified, the DP original scanning position is adjusted for the following originals.</p> <p>Purpose When using DP, to solve the problem when black lines occurs due to the dust with respect to original reading position.</p> <p>Method</p> <ol style="list-style-type: none">1. Press the start key.2. Select the item. <table><tr><th>Display</th><th>Description</th><th>Setting range</th><th>Initial setting</th></tr><tr><td>CCD</td><td>Setting of standard data when dust is detected.</td><td>10 to 95</td><td>35</td></tr><tr><td>BLACK LINE</td><td>Initialization of original reading position.</td><td>-</td><td>-</td></tr></table> <p>Setting: Standard data when dust is detected</p> <ol style="list-style-type: none">1. Change the value using the cursor up/down keys.2. Press the start key. The value is set. <p>Setting: Initialization of original reading position</p> <ol style="list-style-type: none">1. Select [CLEAR].2. Press the start key. The setting is cleared. <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Setting range	Initial setting	CCD	Setting of standard data when dust is detected.	10 to 95	35	BLACK LINE	Initialization of original reading position.	-	-
Display	Description	Setting range	Initial setting										
CCD	Setting of standard data when dust is detected.	10 to 95	35										
BLACK LINE	Initialization of original reading position.	-	-										

Maintenance item No.	Description																				
U203	<p>Checking DP operation</p> <p>Description Simulates the original conveying operation separately in the DP.</p> <p>Purpose To check the DP operation.</p> <p>Method</p> <ol style="list-style-type: none">1. Press the start key.2. Place an original in the DP if running this simulation with paper.3. Select the item to be operated.4. When selecting [ADF] or [RADF], to set the magnification using the cursor up/down keys. <table><tr><th>Display</th><th>Operation</th><th>Setting range</th><th>Initial setting</th></tr><tr><td>ADF</td><td>With paper, single-sided original</td><td>100 to 200 (%)</td><td>100</td></tr><tr><td>RADF</td><td>With paper, double-sided original</td><td>100 to 200 (%)</td><td>100</td></tr><tr><td>ADF (NON P)</td><td>Without paper, single-sided original (continuous operation)</td><td>-</td><td>-</td></tr><tr><td>RADF (NON P)</td><td>Without paper, double-sided original (continuous operation)</td><td>-</td><td>-</td></tr></table> <ol style="list-style-type: none">5. Press the start key. The operation starts.6. To stop continuous operation, press the stop/clear key. <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Operation	Setting range	Initial setting	ADF	With paper, single-sided original	100 to 200 (%)	100	RADF	With paper, double-sided original	100 to 200 (%)	100	ADF (NON P)	Without paper, single-sided original (continuous operation)	-	-	RADF (NON P)	Without paper, double-sided original (continuous operation)	-	-
Display	Operation	Setting range	Initial setting																		
ADF	With paper, single-sided original	100 to 200 (%)	100																		
RADF	With paper, double-sided original	100 to 200 (%)	100																		
ADF (NON P)	Without paper, single-sided original (continuous operation)	-	-																		
RADF (NON P)	Without paper, double-sided original (continuous operation)	-	-																		
U243	<p>Checking the operation of the DP motors</p> <p>Description Turns the motors and solenoids in the DP on.</p> <p>Purpose To check the operation of the DP motors or solenoids.</p> <p>Method</p> <ol style="list-style-type: none">1. Press the start key.2. Select the item to be operated.3. Press the start key. The operation starts. <table><tr><th>Display</th><th>Motors and solenoids</th></tr><tr><td>DP FEED MOTOR</td><td>Original feed motor (OFM) is turned on.</td></tr><tr><td>DP CONV MOTOR</td><td>Original conveying motor (OCM) is turned on.</td></tr><tr><td>DP REV MOTOR</td><td>Original switchback motor (OSBM) is turned on.</td></tr><tr><td>DP RJ SOL</td><td>Switchback feedshift solenoid (SBFSSOL) is turned on.</td></tr><tr><td>DP RP SOL</td><td>Switchback pressure solenoid (SBPSOL) is turned on.</td></tr></table> <ol style="list-style-type: none">4. To stop operation, press the stop/clear key. <p>Completion Press the stop/clear key when operation stops. The screen for selecting a maintenance item No. is displayed.</p>	Display	Motors and solenoids	DP FEED MOTOR	Original feed motor (OFM) is turned on.	DP CONV MOTOR	Original conveying motor (OCM) is turned on.	DP REV MOTOR	Original switchback motor (OSBM) is turned on.	DP RJ SOL	Switchback feedshift solenoid (SBFSSOL) is turned on.	DP RP SOL	Switchback pressure solenoid (SBPSOL) is turned on.								
Display	Motors and solenoids																				
DP FEED MOTOR	Original feed motor (OFM) is turned on.																				
DP CONV MOTOR	Original conveying motor (OCM) is turned on.																				
DP REV MOTOR	Original switchback motor (OSBM) is turned on.																				
DP RJ SOL	Switchback feedshift solenoid (SBFSSOL) is turned on.																				
DP RP SOL	Switchback pressure solenoid (SBPSOL) is turned on.																				

Maintenance item No.	Description														
U244	<p>Checking the DP switches</p> <p>Description Displays the status of the respective switches in the DP.</p> <p>Purpose To check if respective switches in the DP operate correctly.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Turn the respective switches on and off manually to check the status. <p>When a switch is detected to be in the ON position, the display for that switch will be highlighted.</p> <table border="1"> <thead> <tr> <th>Display</th><th>Switches</th></tr> </thead> <tbody> <tr> <td>DP SET SW</td><td>Original set switch (OSSW)</td></tr> <tr> <td>DP PSD SW</td><td>Original size length switch (OSLSW)</td></tr> <tr> <td>DP REV SW</td><td>Original switchback switch (OSBSW)</td></tr> <tr> <td>CCD TIMING SW</td><td>DP timing switch (DPTSW)</td></tr> <tr> <td>DP COVER SW</td><td>DP interlock switch (DPILSW)</td></tr> <tr> <td>DP OPEN SW</td><td>DP open/close switch (DPOCSW)</td></tr> </tbody> </table> <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Switches	DP SET SW	Original set switch (OSSW)	DP PSD SW	Original size length switch (OSLSW)	DP REV SW	Original switchback switch (OSBSW)	CCD TIMING SW	DP timing switch (DPTSW)	DP COVER SW	DP interlock switch (DPILSW)	DP OPEN SW	DP open/close switch (DPOCSW)
Display	Switches														
DP SET SW	Original set switch (OSSW)														
DP PSD SW	Original size length switch (OSLSW)														
DP REV SW	Original switchback switch (OSBSW)														
CCD TIMING SW	DP timing switch (DPTSW)														
DP COVER SW	DP interlock switch (DPILSW)														
DP OPEN SW	DP open/close switch (DPOCSW)														
U326	<p>Setting the black line cleaning indication</p> <p>Description Sets whether to display the cleaning guidance when detecting the black line.</p> <p>Purpose Displays the cleaning guidance in order to make the call for service with the black line decrease by the rubbish on the platen when scanning from the DP.</p> <p>Setting</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Select ON or OFF. <table border="1"> <thead> <tr> <th>Display</th><th>Description</th></tr> </thead> <tbody> <tr> <td>ON</td><td>Displays the cleaning guidance</td></tr> <tr> <td>OFF</td><td>Not to display the cleaning guidance</td></tr> <tr> <td>COUNT</td><td>Setting counts of the cleaning guidance indication</td></tr> </tbody> </table> <p>Initial setting: ON</p> <ol style="list-style-type: none"> 3. Press the start key. The setting is set. <p>Setting the count value</p> <ol style="list-style-type: none"> 1. Enter a count using the cursor up/down keys. Setting range: 0 to 999 Initial setting: 8 When setting is 0, the black line cleaning indication is displayed only if the black line is detected. 2. Press the start key. The count is set. <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	ON	Displays the cleaning guidance	OFF	Not to display the cleaning guidance	COUNT	Setting counts of the cleaning guidance indication						
Display	Description														
ON	Displays the cleaning guidance														
OFF	Not to display the cleaning guidance														
COUNT	Setting counts of the cleaning guidance indication														

Maintenance item No.	Description																									
U404	<p>Adjusting margins for scanning an original from the DP</p> <p>Description Adjusts margins for scanning the original from the DP.</p> <p>Purpose Make the adjustment if margins are incorrect when the DP is used.</p> <p>Caution Before making this adjustment, ensure that the following adjustments have been made in maintenance mode.</p> <div><div>U402 (See the service manual for the machine.)</div><div>→</div><div>U403 (See the service manual for the machine.)</div><div>→</div><div>U404</div></div> <p>Adjustment</p> <div><div><div>1. Press the start key.</div><div>2. Select the item to be adjusted.</div></div><table><tr><th>Display</th><th>Description</th><th>Setting range</th><th>Initial setting</th><th>Change in value per step</th></tr><tr><td>A MARGIN</td><td>Left margin</td><td>0 to 10.0</td><td>3.0</td><td>0.5 mm</td></tr><tr><td>B MARGIN</td><td>Leading edge margin</td><td>0 to 10.0</td><td>2.5</td><td>0.5 mm</td></tr><tr><td>C MARGIN</td><td>Right margin</td><td>0 to 10.0</td><td>3.0</td><td>0.5 mm</td></tr><tr><td>D MARGIN</td><td>Trailing edge margin</td><td>0 to 10.0</td><td>4.0</td><td>0.5 mm</td></tr></table><div><div><div>3. Press the interrupt key.</div><div>4. Place an original on the DP and press the start key to make a test copy.</div><div>5. Press the interrupt key.</div><div>6. Change the setting value using the cursor up/down keys. Increasing the value makes the margin wider, and decreasing it makes the margin narrower.</div></div><div><div>Leading edge margin (3±1.5 mm)</div><div>Left margin (2±1.0 mm)</div><div>Right margin (2±1.0 mm)</div><div>Trailing edge margin (2±1.0 mm)</div></div><p>Figure 1-3-11</p><div><div>7. Press the start key. The value is set.</div><p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p></div></div></div>	Display	Description	Setting range	Initial setting	Change in value per step	A MARGIN	Left margin	0 to 10.0	3.0	0.5 mm	B MARGIN	Leading edge margin	0 to 10.0	2.5	0.5 mm	C MARGIN	Right margin	0 to 10.0	3.0	0.5 mm	D MARGIN	Trailing edge margin	0 to 10.0	4.0	0.5 mm
Display	Description	Setting range	Initial setting	Change in value per step																						
A MARGIN	Left margin	0 to 10.0	3.0	0.5 mm																						
B MARGIN	Leading edge margin	0 to 10.0	2.5	0.5 mm																						
C MARGIN	Right margin	0 to 10.0	3.0	0.5 mm																						
D MARGIN	Trailing edge margin	0 to 10.0	4.0	0.5 mm																						

Maintenance item No.	Description																	
U411	<p>Adjusting the scanner automatically</p> <p>Description</p> <p>Uses a specified original and automatically adjusts the following items in the scanner and the DP scanning sections.</p> <p>Purpose</p> <p>To perform automatic adjustment of various items in the scanner and the DP scanning sections.</p> <p>To adjust scanner automatically when initializing the machine using the maintenance item U020 or U022.</p> <p>Method</p> <ol style="list-style-type: none">Press the start key.Select the item. The screen for executing is displayed. <table><tr><th>Display</th><th>Description</th><th>Original to be used for adjustment (P/N)</th></tr><tr><td>SCANNER</td><td>Automatic adjustment in the scanner section</td><td>302FZ56990</td></tr><tr><td>DP</td><td>Automatic adjustment in the DP scanning section</td><td>2AC68241</td></tr></table> <p>Method: SCANNER</p> <ol style="list-style-type: none">Select [SCANNER].Set a specified original (P/N: 302FZ56990) on the platen.Select the item. <table><tr><th>Display</th><th>Description</th></tr><tr><td>ALL</td><td>Automatic adjustment using the platen for: original size magnification/leading edge timing/center line and input gamma</td></tr><tr><td>INPUT</td><td>Automatic adjustment using the platen for: original size magnification/leading edge timing/center line</td></tr><tr><td>GAMMA</td><td>Automatic adjustment using the platen for: input gamma</td></tr></table> <ol style="list-style-type: none">Press the start key. Auto adjustment starts. <p>When automatic adjustment has normally completed, [RESULT OK 00] is displayed. If a problem occurs during auto adjustment, [ERROR XX] (XX is replaced by an error code) is displayed and operation stops. Should this happen, determine the details of the problem and either repeat the procedure from the beginning, or adjust the remaining items manually by running the corresponding maintenance items.</p> <ol style="list-style-type: none">To return to the screen for selecting an item, press the stop/clear key. <p>Method: DP</p> <ol style="list-style-type: none">Select [DP].Set a specified original (P/N: 2AC68241) in the DP. <p>Cut the trailing edge of the original.</p> <div><p>128±1 mm 60±1 mm</p><p>Cut with the edge of black belt.</p></div>	Display	Description	Original to be used for adjustment (P/N)	SCANNER	Automatic adjustment in the scanner section	302FZ56990	DP	Automatic adjustment in the DP scanning section	2AC68241	Display	Description	ALL	Automatic adjustment using the platen for: original size magnification/leading edge timing/center line and input gamma	INPUT	Automatic adjustment using the platen for: original size magnification/leading edge timing/center line	GAMMA	Automatic adjustment using the platen for: input gamma
Display	Description	Original to be used for adjustment (P/N)																
SCANNER	Automatic adjustment in the scanner section	302FZ56990																
DP	Automatic adjustment in the DP scanning section	2AC68241																
Display	Description																	
ALL	Automatic adjustment using the platen for: original size magnification/leading edge timing/center line and input gamma																	
INPUT	Automatic adjustment using the platen for: original size magnification/leading edge timing/center line																	
GAMMA	Automatic adjustment using the platen for: input gamma																	

TONER

Figure 1-3-12

Figure 1-3-12


Maintenance item No.	Description																																																																
U411	<p>3. Press [INPUT].</p> <table border="1"> <tr> <th>Display</th><th>Description</th></tr> <tr> <td>INPUT</td><td>Automatic adjustment of first page using the DP for: original size magnification/leading edge timing/center line</td></tr> </table> <p>4. Press the start key. Auto adjustment starts. When automatic adjustment has normally completed, [RESULT OK 00] is displayed. If a problem occurs during auto adjustment, [ERROR XX] (XX is replaced by an error code) is displayed and operation stops. Should this happen, determine the details of the problem and either repeat the procedure from the beginning, or adjust the remaining items manually by running the corresponding maintenance items.</p> <p>5. To return to the screen for selecting an item, press the stop/clear key.</p> <p>Error Codes</p> <table border="1"> <tr> <th>Codes</th><th>Description</th></tr> <tr><td>ERROR 01</td><td>Black band detection error (scanner leading edge registration)</td></tr> <tr><td>ERROR 02</td><td>Black band detection error (scanner center line)</td></tr> <tr><td>ERROR 03</td><td>Black band detection error (scanner main scanning direction magnification)</td></tr> <tr><td>ERROR 04</td><td>Black band is not detected (scanner leading edge registration)</td></tr> <tr><td>ERROR 05</td><td>Black band is not detected (scanner center line)</td></tr> <tr><td>ERROR 06</td><td>Black band is not detected (scanner main scanning direction magnification)</td></tr> <tr><td>ERROR 07</td><td>Black band is not detected (scanner auxiliary scanning direction magnification)</td></tr> <tr><td>ERROR 08</td><td>Black band is not detected (DP main scanning direction magnification far end)</td></tr> <tr><td>ERROR 09</td><td>Black band is not detected (DP main scanning direction magnification near end)</td></tr> <tr><td>ERROR 0a</td><td>Black band is not detected (DP auxiliary scanning direction magnification leading edge)</td></tr> <tr><td>ERROR 0b</td><td>Black band is not detected (DP auxiliary scanning direction magnification leading edge original check)</td></tr> <tr><td>ERROR 0c</td><td>Black band is not detected (DP auxiliary scanning direction trailing edge)</td></tr> <tr><td>ERROR 0d</td><td>Black band is not detected (DP auxiliary scanning direction trailing edge 2)</td></tr> <tr><td>ERROR 0e</td><td>DMA time out</td></tr> <tr><td>ERROR 0f</td><td>Auxiliary scanning direction magnification error</td></tr> <tr><td>ERROR 10</td><td>Auxiliary scanning direction leading edge detection error</td></tr> <tr><td>ERROR 11</td><td>Auxiliary scanning direction trailing edge detection error</td></tr> <tr><td>ERROR 12</td><td>Auxiliary scanning direction skew 1.5 error</td></tr> <tr><td>ERROR 13</td><td>Maintenance request error</td></tr> <tr><td>ERROR 14</td><td>Main scanning direction center line error</td></tr> <tr><td>ERROR 15</td><td>Main scanning direction skew 1.5 error</td></tr> <tr><td>ERROR 16</td><td>Main scanning direction magnification error</td></tr> <tr><td>ERROR 17</td><td>Carriage error</td></tr> <tr><td>ERROR 18</td><td>Service call error</td></tr> <tr><td>ERROR 19</td><td>DP status error</td></tr> <tr><td>ERROR 1a</td><td>DP open error</td></tr> <tr><td>ERROR 1b</td><td>Original is not detected</td></tr> <tr><td>ERROR ff</td><td>Other error</td></tr> <tr><td>ERROR 65</td><td>Memory over error</td></tr> </table> <p>Completion Press the stop/clear key. The screen for selecting a maintenance item is displayed.</p>	Display	Description	INPUT	Automatic adjustment of first page using the DP for: original size magnification/leading edge timing/center line	Codes	Description	ERROR 01	Black band detection error (scanner leading edge registration)	ERROR 02	Black band detection error (scanner center line)	ERROR 03	Black band detection error (scanner main scanning direction magnification)	ERROR 04	Black band is not detected (scanner leading edge registration)	ERROR 05	Black band is not detected (scanner center line)	ERROR 06	Black band is not detected (scanner main scanning direction magnification)	ERROR 07	Black band is not detected (scanner auxiliary scanning direction magnification)	ERROR 08	Black band is not detected (DP main scanning direction magnification far end)	ERROR 09	Black band is not detected (DP main scanning direction magnification near end)	ERROR 0a	Black band is not detected (DP auxiliary scanning direction magnification leading edge)	ERROR 0b	Black band is not detected (DP auxiliary scanning direction magnification leading edge original check)	ERROR 0c	Black band is not detected (DP auxiliary scanning direction trailing edge)	ERROR 0d	Black band is not detected (DP auxiliary scanning direction trailing edge 2)	ERROR 0e	DMA time out	ERROR 0f	Auxiliary scanning direction magnification error	ERROR 10	Auxiliary scanning direction leading edge detection error	ERROR 11	Auxiliary scanning direction trailing edge detection error	ERROR 12	Auxiliary scanning direction skew 1.5 error	ERROR 13	Maintenance request error	ERROR 14	Main scanning direction center line error	ERROR 15	Main scanning direction skew 1.5 error	ERROR 16	Main scanning direction magnification error	ERROR 17	Carriage error	ERROR 18	Service call error	ERROR 19	DP status error	ERROR 1a	DP open error	ERROR 1b	Original is not detected	ERROR ff	Other error	ERROR 65	Memory over error
Display	Description																																																																
INPUT	Automatic adjustment of first page using the DP for: original size magnification/leading edge timing/center line																																																																
Codes	Description																																																																
ERROR 01	Black band detection error (scanner leading edge registration)																																																																
ERROR 02	Black band detection error (scanner center line)																																																																
ERROR 03	Black band detection error (scanner main scanning direction magnification)																																																																
ERROR 04	Black band is not detected (scanner leading edge registration)																																																																
ERROR 05	Black band is not detected (scanner center line)																																																																
ERROR 06	Black band is not detected (scanner main scanning direction magnification)																																																																
ERROR 07	Black band is not detected (scanner auxiliary scanning direction magnification)																																																																
ERROR 08	Black band is not detected (DP main scanning direction magnification far end)																																																																
ERROR 09	Black band is not detected (DP main scanning direction magnification near end)																																																																
ERROR 0a	Black band is not detected (DP auxiliary scanning direction magnification leading edge)																																																																
ERROR 0b	Black band is not detected (DP auxiliary scanning direction magnification leading edge original check)																																																																
ERROR 0c	Black band is not detected (DP auxiliary scanning direction trailing edge)																																																																
ERROR 0d	Black band is not detected (DP auxiliary scanning direction trailing edge 2)																																																																
ERROR 0e	DMA time out																																																																
ERROR 0f	Auxiliary scanning direction magnification error																																																																
ERROR 10	Auxiliary scanning direction leading edge detection error																																																																
ERROR 11	Auxiliary scanning direction trailing edge detection error																																																																
ERROR 12	Auxiliary scanning direction skew 1.5 error																																																																
ERROR 13	Maintenance request error																																																																
ERROR 14	Main scanning direction center line error																																																																
ERROR 15	Main scanning direction skew 1.5 error																																																																
ERROR 16	Main scanning direction magnification error																																																																
ERROR 17	Carriage error																																																																
ERROR 18	Service call error																																																																
ERROR 19	DP status error																																																																
ERROR 1a	DP open error																																																																
ERROR 1b	Original is not detected																																																																
ERROR ff	Other error																																																																
ERROR 65	Memory over error																																																																

Maintenance item No.	Description																		
U905	<p>Checking counts by optional devices</p> <p>Description Displays the counts of DP or finisher.</p> <p>Purpose To check the use of DP and finisher.</p> <p>Method</p> <ol style="list-style-type: none">1. Press the start key.2. Select the device, the count of which is to be checked. The count of the selected device is displayed. <table><tr><th>Display</th><th>Description</th></tr><tr><td>DP</td><td>Counts of optional DP</td></tr><tr><td>FINISHER</td><td>Counts of optional finisher</td></tr></table> <p>DP</p> <table><tr><th>Display</th><th>Description</th></tr><tr><td>ADP</td><td>No. of single-sided originals that has passed through the DP</td></tr><tr><td>RADP</td><td>No. of double-sided originals that has passed through the DP</td></tr></table> <p>Finisher</p> <table><tr><th>Display</th><th>Description</th></tr><tr><td>CP CNT</td><td>No. of copies that has passed</td></tr><tr><td>STAPLE</td><td>Frequency the stapler has been activated</td></tr></table> <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	DP	Counts of optional DP	FINISHER	Counts of optional finisher	Display	Description	ADP	No. of single-sided originals that has passed through the DP	RADP	No. of double-sided originals that has passed through the DP	Display	Description	CP CNT	No. of copies that has passed	STAPLE	Frequency the stapler has been activated
Display	Description																		
DP	Counts of optional DP																		
FINISHER	Counts of optional finisher																		
Display	Description																		
ADP	No. of single-sided originals that has passed through the DP																		
RADP	No. of double-sided originals that has passed through the DP																		
Display	Description																		
CP CNT	No. of copies that has passed																		
STAPLE	Frequency the stapler has been activated																		
U942	<p>Setting of deflection for feeding from DP</p> <p>Description Adjusts the deflection generated when the DP is used.</p> <p>Purpose Use this mode if an original non-feed jam, oblique feed or wrinkling of original occurs when the DP is used.</p> <p>Setting</p> <ol style="list-style-type: none">1. Press the start key.2. Select the item to be adjusted. <table><tr><th>Display</th><th>Description</th><th>Setting range</th><th>Initial setting</th><th>Change in value per step</th></tr><tr><td>FEED MOT</td><td>Deflection in the original feed motor</td><td>-31 to 31</td><td>0</td><td>0.098 mm</td></tr><tr><td>REV MOT</td><td>Deflection in the original switchback motor</td><td>-31 to 31</td><td>0</td><td>0.098 mm</td></tr></table> <ol style="list-style-type: none">3. Press the interrupt key.4. Place an original on the DP and press the start key to make a test copy.5. Press the interrupt key.6. Change the setting value using the cursor up/down keys. The greater the value, the larger the deflection; the smaller the value, the smaller the deflection. If an original non-feed jam or oblique feed occurs, increase the setting value. If wrinkling of original occurs, decrease the value.7. Press the start key. The setting is set. <p>Completion Press the stop/clear key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Setting range	Initial setting	Change in value per step	FEED MOT	Deflection in the original feed motor	-31 to 31	0	0.098 mm	REV MOT	Deflection in the original switchback motor	-31 to 31	0	0.098 mm			
Display	Description	Setting range	Initial setting	Change in value per step															
FEED MOT	Deflection in the original feed motor	-31 to 31	0	0.098 mm															
REV MOT	Deflection in the original switchback motor	-31 to 31	0	0.098 mm															

1-3-3 Maintenance mode (DP-670(B)/models with color touch panel)

The machine is equipped with a maintenance function which can be used to maintain and service the machine.

(1) Executing a maintenance item



(2) Maintenance mode item list




Section	Item No.	Content of maintenance item	Initial setting*
General	U019	Displaying the ROM version	-
Optical	U068	Adjusting the scanning position for originals from the DP	0/0
	U070	Adjusting the DP magnification	0/0
	U071	Adjusting the DP scanning timing	0/0/0/0
	U072	Adjusting the DP center line	0/0
	U074	Adjusting the DP input light luminosity	0
	U087	Setting DP reading position modification operation	125/125/125
Operation panel and support equipment	U203	Checking DP operation	-
	U243	Checking the operation of the DP motors	-
	U244	Checking the DP switches	-
Mode setting	U326	Setting the black line cleaning indication	ON/8*1
Image processing	U404	Adjusting margins for scanning an original from the DP	3.0/2.5/3.0/4.0*1
	U411	Adjusting the scanner automatically	-
Other	U905	Checking/clearing counts by optional devices	-
	U942	Setting of deflection for feeding from DP	0/0




*: Factory initial setting, *1: The item initialized for executing U021

(3) Contents of maintenance mode items




Maintenance item No.	Description																																												
U019	<p>Displaying the ROM version</p> <p>Description Displays the part number of the ROM fitted to each PWB.</p> <p>Purpose To check the part number or to decide, if the newest version of ROM is installed.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. The ROM version are displayed. 2. Change the screen using the cursor up/down keys. <table border="1"> <thead> <tr> <th>Display</th><th>Description</th></tr> </thead> <tbody> <tr><td>MAIN</td><td>Main ROM</td></tr> <tr><td>MMI</td><td>Operation ROM</td></tr> <tr><td>ENGINE</td><td>Engine ROM</td></tr> <tr><td>ENGINE BOOT</td><td>Engine booting</td></tr> <tr><td>ENGINE POWER</td><td>Engine power</td></tr> <tr><td>SCANNER</td><td>Scanner ROM</td></tr> <tr><td>BROWSER</td><td>Browser ROM</td></tr> <tr><td>OPTION LANGUAGE</td><td>Optional language ROM</td></tr> <tr><td>DICTIONARY</td><td>-</td></tr> <tr><td>DBA</td><td>Database connection</td></tr> <tr><td>Solution Framework</td><td>Solution framework</td></tr> <tr><td>DP</td><td>DP ROM</td></tr> <tr><td>500x2PF</td><td>Optional paper feeder ROM</td></tr> <tr><td>1000DF</td><td>Optional document finisher ROM</td></tr> <tr><td>INNER DF</td><td>Optional built-in finisher ROM</td></tr> <tr><td>FAX BOOT1</td><td>Optional fax control PWB booting (port 1)</td></tr> <tr><td>FAX APL1</td><td>Optional fax control PWB APL (port 1)</td></tr> <tr><td>FAX IPL1</td><td>Optional fax control PWB IPL (port 1)</td></tr> <tr><td>FAX BOOT2</td><td>Fax control PWB booting (port 2: optional dual FAX)</td></tr> <tr><td>FAX APL2</td><td>Fax control PWB APL (port 2: optional dual FAX)</td></tr> <tr><td>FAX IPL2</td><td>Fax control PWB IPL (port 2: optional dual FAX)</td></tr> </tbody> </table> <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	MAIN	Main ROM	MMI	Operation ROM	ENGINE	Engine ROM	ENGINE BOOT	Engine booting	ENGINE POWER	Engine power	SCANNER	Scanner ROM	BROWSER	Browser ROM	OPTION LANGUAGE	Optional language ROM	DICTIONARY	-	DBA	Database connection	Solution Framework	Solution framework	DP	DP ROM	500x2PF	Optional paper feeder ROM	1000DF	Optional document finisher ROM	INNER DF	Optional built-in finisher ROM	FAX BOOT1	Optional fax control PWB booting (port 1)	FAX APL1	Optional fax control PWB APL (port 1)	FAX IPL1	Optional fax control PWB IPL (port 1)	FAX BOOT2	Fax control PWB booting (port 2: optional dual FAX)	FAX APL2	Fax control PWB APL (port 2: optional dual FAX)	FAX IPL2	Fax control PWB IPL (port 2: optional dual FAX)
Display	Description																																												
MAIN	Main ROM																																												
MMI	Operation ROM																																												
ENGINE	Engine ROM																																												
ENGINE BOOT	Engine booting																																												
ENGINE POWER	Engine power																																												
SCANNER	Scanner ROM																																												
BROWSER	Browser ROM																																												
OPTION LANGUAGE	Optional language ROM																																												
DICTIONARY	-																																												
DBA	Database connection																																												
Solution Framework	Solution framework																																												
DP	DP ROM																																												
500x2PF	Optional paper feeder ROM																																												
1000DF	Optional document finisher ROM																																												
INNER DF	Optional built-in finisher ROM																																												
FAX BOOT1	Optional fax control PWB booting (port 1)																																												
FAX APL1	Optional fax control PWB APL (port 1)																																												
FAX IPL1	Optional fax control PWB IPL (port 1)																																												
FAX BOOT2	Fax control PWB booting (port 2: optional dual FAX)																																												
FAX APL2	Fax control PWB APL (port 2: optional dual FAX)																																												
FAX IPL2	Fax control PWB IPL (port 2: optional dual FAX)																																												

Maintenance item No.	Description															
U068	<p>Adjusting the scanning position for originals from the DP</p> <p>Description Adjusts the position for scanning originals from the DP. Performs the test copy at the four scanning positions after adjusting.</p> <p>Purpose Used when the image fogging occurs because the scanning position is not proper when the DP is used. Run U071 to adjust the timing of DP leading edge when the scanning position is changed.</p> <p>Setting</p> <p>1. Press the start key.</p> <table><tr><th>Display</th><th>Description</th><th>Setting range</th><th>Initial setting</th><th>Change in value per step</th></tr><tr><td>DP READ</td><td>Starting position adjustment for scanning originals</td><td>-55 to 55</td><td>0</td><td>0.11 mm</td></tr><tr><td>BLACK LINE</td><td>Scanning position for the test copy originals</td><td>0 to 3</td><td>0</td><td>-</td></tr></table> <p>2. Select [DP READ] of the screen for selecting an item.</p> <p>3. Change the setting using the +/- or numeric keys. When the setting value is increased, the scanning position moves to the right and it moves to the left when the setting value is decreased.</p> <p>4. Press the start key. The value is set.</p> <p>5. Select [BLACK LINE] of the screen for selecting an item.</p> <p>6. Select the scanning position using the +/- or numeric keys.</p> <p>7. Press the start key. The value is set.</p> <p>8. Set the original (the one which density is known) in the DP and press the system menu key. The screen for the test copy mode is displayed.</p> <p>9. Press the start key. Test copy is executed.</p> <p>10. Perform the test copy at each scanning position with the setting value from 0 to 3 and check that no black line appears and the image is normally scanned.</p> <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Setting range	Initial setting	Change in value per step	DP READ	Starting position adjustment for scanning originals	-55 to 55	0	0.11 mm	BLACK LINE	Scanning position for the test copy originals	0 to 3	0	-
Display	Description	Setting range	Initial setting	Change in value per step												
DP READ	Starting position adjustment for scanning originals	-55 to 55	0	0.11 mm												
BLACK LINE	Scanning position for the test copy originals	0 to 3	0	-												

Maintenance item No.	Description															
U070	<p>Adjusting the DP magnification</p> <p>Description Adjusts the DP original scanning speed.</p> <p>Purpose Make the adjustment if the magnification is incorrect in the auxiliary scanning direction when the DP is used.</p> <p>Method</p> <ol style="list-style-type: none">1. Press the start key.2. Select the item to be adjusted. <table><tr><th>Display</th><th>Description</th><th>Setting range</th><th>Initial setting</th><th>Change in value per step</th></tr><tr><td>MOTOR ADJ (FRONT)</td><td>Magnification in the auxiliary scanning direction (first side)</td><td>-25 to 25</td><td>0</td><td>0.05 %</td></tr><tr><td>MOTOR ADJ (BACK)</td><td>Magnification in the auxiliary scanning direction (second side)</td><td>-25 to 25</td><td>0</td><td>0.05 %</td></tr></table> <p>Adjustment: Auxiliary scanning direction</p> <ol style="list-style-type: none">1. Press the system menu key.2. Place an original on the DP and press the start key to make a test copy.3. Press the system menu key.4. Change the setting value using the +/- or numeric keys. For copy example 1, increase the value. For copy example 2, decrease the value. <div><div></div><div>Original</div></div> <div><div></div><div>Copy example 1</div></div> <div><div></div><div>Copy example 2</div></div> <p>Figure 1-3-13</p> <ol style="list-style-type: none">5. Press the start key. The value is set. <p>Caution Check the copy image after the adjustment. If the image is still incorrect, perform the following adjustments in maintenance mode.</p> <div><div>U070</div><div>→</div><div>U071 (P.1-3-37)</div><div>→</div><div>U404 (P.1-3-44)</div></div> <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Setting range	Initial setting	Change in value per step	MOTOR ADJ (FRONT)	Magnification in the auxiliary scanning direction (first side)	-25 to 25	0	0.05 %	MOTOR ADJ (BACK)	Magnification in the auxiliary scanning direction (second side)	-25 to 25	0	0.05 %
Display	Description	Setting range	Initial setting	Change in value per step												
MOTOR ADJ (FRONT)	Magnification in the auxiliary scanning direction (first side)	-25 to 25	0	0.05 %												
MOTOR ADJ (BACK)	Magnification in the auxiliary scanning direction (second side)	-25 to 25	0	0.05 %												

Maintenance item No.	Description																									
U071	<p>Adjusting the DP scanning timing</p> <p>Description Adjusts the DP original scanning timing.</p> <p>Purpose Make the adjustment if there is a regular error between the leading or trailing edges of the original and the copy image when the DP is used.</p> <p>Method</p> <ol style="list-style-type: none">1. Press the start key.2. Select the item to be adjusted. <table><tr><th>Display</th><th>Description</th><th>Setting range</th><th>Initial setting</th><th>Change in value per step</th></tr><tr><td>FRONT HEAD</td><td>Leading edge registration (first side)</td><td>-66 to 66</td><td>0</td><td>0.08 mm</td></tr><tr><td>FRONT TAIL</td><td>Trailing edge registration (first side)</td><td>-66 to 66</td><td>0</td><td>0.08 mm</td></tr><tr><td>BACK HEAD</td><td>Leading edge registration (second side)</td><td>-66 to 66</td><td>0</td><td>0.08 mm</td></tr><tr><td>BACK TAIL</td><td>Trailing edge registration (second side)</td><td>-66 to 66</td><td>0</td><td>0.08 mm</td></tr></table> <p>Adjustment: Leading edge registration</p> <ol style="list-style-type: none">1. Press the system menu key.2. Place an original on the DP and press the start key to make a test copy.3. Press the system menu key.4. Change the setting value using the +/- or numeric keys. For copy example 1, increase the value. For copy example 2, decrease the value. <div><div><p>Original</p></div><div><p>Copy example 1</p></div><div><p>Copy example 2</p></div></div> <p>Figure 1-3-14</p> <ol style="list-style-type: none">5. Press the start key. The value is set. <p>Caution If the CCD first side is adjusted, check the CCD second side and if adjustment is required, carry out the adjustment. Check the copy image after the adjustment. If the image is still incorrect, perform the following adjustments in maintenance mode.</p> <div><div>U071</div><div>→</div><div>U404 (P.1-3-44)</div></div>	Display	Description	Setting range	Initial setting	Change in value per step	FRONT HEAD	Leading edge registration (first side)	-66 to 66	0	0.08 mm	FRONT TAIL	Trailing edge registration (first side)	-66 to 66	0	0.08 mm	BACK HEAD	Leading edge registration (second side)	-66 to 66	0	0.08 mm	BACK TAIL	Trailing edge registration (second side)	-66 to 66	0	0.08 mm
Display	Description	Setting range	Initial setting	Change in value per step																						
FRONT HEAD	Leading edge registration (first side)	-66 to 66	0	0.08 mm																						
FRONT TAIL	Trailing edge registration (first side)	-66 to 66	0	0.08 mm																						
BACK HEAD	Leading edge registration (second side)	-66 to 66	0	0.08 mm																						
BACK TAIL	Trailing edge registration (second side)	-66 to 66	0	0.08 mm																						

Maintenance item No.	Description
U071	<p>Adjustment: Trailing edge registration</p> <ol style="list-style-type: none"> 1. Press the system menu key. 2. Place an original on the DP and press the start key to make a test copy. 3. Press the system menu key. 4. Change the setting value using the +/- or numeric keys. For copy example 1, increase the value. For copy example 2, decrease the value. <div data-bbox="673 461 1031 692" data-label="Image"> </div> <p style="text-align: center;">Figure 1-3-15</p> <ol style="list-style-type: none"> 5. Press the start key. The value is set. <p>Caution If the CCD first side is adjusted, check the CCD second side and if adjustment is required, carry out the adjustment. Check the copy image after the adjustment. If the image is still incorrect, perform the following adjustments in maintenance mode.</p> <div data-bbox="285 990 624 1061" data-label="Diagram"> <pre> graph LR U071[U071] --> U404[U404 (P.1-3-44)] </pre> </div> <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>

Maintenance item No.	Description															
U072	<p>Adjusting the DP center line</p> <p>Description Adjusts the scanning start position for the DP original.</p> <p>Purpose Make the adjustment if there is a regular error between the centers of the original and the copy image when the DP is used.</p> <p>Adjustment</p> <ol style="list-style-type: none">1. Press the start key.2. Select the item to be adjusted. <table><tr><th>Display</th><th>Description</th><th>Setting range</th><th>Initial setting</th><th>Change in value per step</th></tr><tr><td>FRONT</td><td>DP center line (first side)</td><td>-40 to 40</td><td>0</td><td>0.08 mm</td></tr><tr><td>BACK</td><td>DP center line (second side)</td><td>-40 to 40</td><td>0</td><td>0.08 mm</td></tr></table> <ol style="list-style-type: none">3. Press the system menu key.4. Place an original on the DP and press the start key to make a test copy.5. Press the system menu key.6. Change the setting value using the +/- or numeric keys. For copy example 1, increase the value. For copy example 2, decrease the value. <div><div></div><div>Original</div><div></div><div>Copy example 1</div><div></div><div>Copy example 2</div></div> <p style="text-align: center;">Figure 1-3-16</p> <ol style="list-style-type: none">7. Press the start key. The value is set. <p>Caution If the CCD first side is adjusted, check the CCD second side and if adjustment is required, carry out the adjustment. Check the copy image after the adjustment. If the image is still incorrect, perform the following adjustments in maintenance mode.</p> <div><div>U072</div><div>→</div><div>U404 (P.1-3-44)</div></div> <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Setting range	Initial setting	Change in value per step	FRONT	DP center line (first side)	-40 to 40	0	0.08 mm	BACK	DP center line (second side)	-40 to 40	0	0.08 mm
Display	Description	Setting range	Initial setting	Change in value per step												
FRONT	DP center line (first side)	-40 to 40	0	0.08 mm												
BACK	DP center line (second side)	-40 to 40	0	0.08 mm												


Maintenance item No.	Description																						
U074	<p>Adjusting the DP input light luminosity</p> <p>Description Sets the luminosity correction for scanning originals from the DP.</p> <p>Purpose Modify the setting only if a spotted background appears when a bluish original is scanned from the DP.</p> <p>Setting</p> <ol style="list-style-type: none">1. Press the start key.2. Change the setting using the +/- or numeric keys. <table><tr><th>Display</th><th>Description</th><th>Setting range</th><th>Initial setting</th></tr><tr><td>INPUT DATA</td><td>DP input light luminosity correction</td><td>0 to 3</td><td>0</td></tr></table> <p>Settings 0: No correction / 1: Slight correction / 2: Medium correction / 3: Strong correction</p> <ol style="list-style-type: none">3. Press the start key. The value is set. <p>Supplement While this maintenance item is being executed, copying from an original is available in interrupt copying mode (which is activated by pressing the system menu key).</p> <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Setting range	Initial setting	INPUT DATA	DP input light luminosity correction	0 to 3	0														
Display	Description	Setting range	Initial setting																				
INPUT DATA	DP input light luminosity correction	0 to 3	0																				
U087	<p>Setting DP reading position modification operation</p> <p>Description The presence or absence of dust is determined by comparing the scan data of the original trailing edge and that taken after the original is conveyed past the DP original scanning position. If dust is identified, the DP original scanning position is adjusted for the following originals.</p> <p>Purpose When using DP, to solve the problem when black lines occurs due to the dust with respect to original reading position.</p> <p>Method</p> <ol style="list-style-type: none">1. Press the start key.2. Select the item to be set. The setting screen for the selected item is displayed. <table><tr><th>Display</th><th>Description</th></tr><tr><td>CCD</td><td>Setting of standard data when dust is detected</td></tr><tr><td>BLACK LINE</td><td>Initialization of original reading position</td></tr></table> <p>Setting: Standard data when dust is detected</p> <ol style="list-style-type: none">1. Select the item to be set.2. Change the value using the +/- or numeric keys. <table><tr><th>Display</th><th>Description</th><th>Setting range</th><th>Initial setting</th></tr><tr><td>CCD R</td><td>Lowest density of the R regard as the dust</td><td>0 to 255</td><td>125</td></tr><tr><td>CCD G</td><td>Lowest density of the G regard as the dust</td><td>0 to 255</td><td>125</td></tr><tr><td>CCD B</td><td>Lowest density of the B regard as the dust</td><td>0 to 255</td><td>125</td></tr></table> <ol style="list-style-type: none">3. Press the start key. The value is set. <p>Setting: Initialization of original reading position</p> <ol style="list-style-type: none">1. Select [CLEAR].2. Press the start key. The setting is cleared. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	CCD	Setting of standard data when dust is detected	BLACK LINE	Initialization of original reading position	Display	Description	Setting range	Initial setting	CCD R	Lowest density of the R regard as the dust	0 to 255	125	CCD G	Lowest density of the G regard as the dust	0 to 255	125	CCD B	Lowest density of the B regard as the dust	0 to 255	125
Display	Description																						
CCD	Setting of standard data when dust is detected																						
BLACK LINE	Initialization of original reading position																						
Display	Description	Setting range	Initial setting																				
CCD R	Lowest density of the R regard as the dust	0 to 255	125																				
CCD G	Lowest density of the G regard as the dust	0 to 255	125																				
CCD B	Lowest density of the B regard as the dust	0 to 255	125																				

Maintenance item No.	Description																								
U203	<p>Checking DP operation</p> <p>Description Simulates the original conveying operation separately in the DP.</p> <p>Purpose To check the DP operation.</p> <p>Method</p> <ol style="list-style-type: none">1. Press the start key.2. Place an original in the DP if running this simulation with paper.3. Select the item to be operated. <table><tr><th>Display</th><th>Description</th><th>Setting range</th><th>Initial setting</th></tr><tr><td>CCD ADP (NON P)</td><td>Without paper, single-sided original (continuous operation)</td><td>-</td><td>-</td></tr><tr><td>CCD ADP</td><td>With paper, single-sided original</td><td>-</td><td>-</td></tr><tr><td>CCD RADP (NON P)</td><td>Without paper, double-sided original (continuous operation)</td><td>-</td><td>-</td></tr><tr><td>CCD RADP</td><td>With paper, double-sided original</td><td>-</td><td>-</td></tr><tr><td>SPEED</td><td>Switching between normal reading (600 dpi) and high-speed reading</td><td>0 (Normal)/ 1 (High-speed)</td><td>0</td></tr></table> <ol style="list-style-type: none">4. Press the start key. The operation starts.5. To stop continuous operation, press the stop key. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Setting range	Initial setting	CCD ADP (NON P)	Without paper, single-sided original (continuous operation)	-	-	CCD ADP	With paper, single-sided original	-	-	CCD RADP (NON P)	Without paper, double-sided original (continuous operation)	-	-	CCD RADP	With paper, double-sided original	-	-	SPEED	Switching between normal reading (600 dpi) and high-speed reading	0 (Normal)/ 1 (High-speed)	0
Display	Description	Setting range	Initial setting																						
CCD ADP (NON P)	Without paper, single-sided original (continuous operation)	-	-																						
CCD ADP	With paper, single-sided original	-	-																						
CCD RADP (NON P)	Without paper, double-sided original (continuous operation)	-	-																						
CCD RADP	With paper, double-sided original	-	-																						
SPEED	Switching between normal reading (600 dpi) and high-speed reading	0 (Normal)/ 1 (High-speed)	0																						
U243	<p>Checking the operation of the DP motors</p> <p>Description Turns the motors or solenoids in the DP on.</p> <p>Purpose To check the operation of the DP motors and solenoids.</p> <p>Method</p> <ol style="list-style-type: none">1. Press the start key.2. Select the item to be operated.3. Press the start key. The operation starts. <table><tr><th>Display</th><th>Motor and solenoid</th><th>Operation</th></tr><tr><td>DP FEED MOT</td><td>Original feed motor (OFM)</td><td>In operation</td></tr><tr><td>DP CON MOT</td><td>Original conveying motor (OCM)</td><td>In operation</td></tr><tr><td>DP REV MOT</td><td>Original switchback motor (OSBM)</td><td>In operation</td></tr><tr><td>DP RP SOL</td><td>Switchback pressure solenoid (SBPSOL)</td><td>On for 0.5 s</td></tr><tr><td>DP RJ SOL</td><td>Switchback feedshift solenoid (SBFSSOL)</td><td>On for 0.5 s</td></tr></table> <ol style="list-style-type: none">4. To turn each motor off, press the stop key. <p>Completion Press the stop key when operation stops. The screen for selecting a maintenance item No. is displayed.</p>	Display	Motor and solenoid	Operation	DP FEED MOT	Original feed motor (OFM)	In operation	DP CON MOT	Original conveying motor (OCM)	In operation	DP REV MOT	Original switchback motor (OSBM)	In operation	DP RP SOL	Switchback pressure solenoid (SBPSOL)	On for 0.5 s	DP RJ SOL	Switchback feedshift solenoid (SBFSSOL)	On for 0.5 s						
Display	Motor and solenoid	Operation																							
DP FEED MOT	Original feed motor (OFM)	In operation																							
DP CON MOT	Original conveying motor (OCM)	In operation																							
DP REV MOT	Original switchback motor (OSBM)	In operation																							
DP RP SOL	Switchback pressure solenoid (SBPSOL)	On for 0.5 s																							
DP RJ SOL	Switchback feedshift solenoid (SBFSSOL)	On for 0.5 s																							

Maintenance item No.	Description														
U244	<p>Checking the DP switches</p> <p>Description Displays the status of the respective switches in the DP.</p> <p>Purpose To check if respective switches in the DP operate correctly.</p> <p>Method</p> <ol style="list-style-type: none"> 1. Press the start key. 2. Turn the respective switches on and off manually to check the status. If the on-status of a switch is detected, the corresponding switch is displayed in reverse. <table border="1"> <thead> <tr> <th>Display</th><th>Switches</th></tr> </thead> <tbody> <tr> <td>TMG SW</td><td>DP timing switch (DPTSW)</td></tr> <tr> <td>REV SW</td><td>Original switchback switch (OSBSW)</td></tr> <tr> <td>SET SW</td><td>Original set switch (OSSW)</td></tr> <tr> <td>SZ SW A</td><td>Original size length switch (OSLSW)</td></tr> <tr> <td>COV OP SW</td><td>DP interlock switch (DPILSW)</td></tr> <tr> <td>DP OP SW</td><td>DP open/close switch (DPOCSW)</td></tr> </tbody> </table> <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Switches	TMG SW	DP timing switch (DPTSW)	REV SW	Original switchback switch (OSBSW)	SET SW	Original set switch (OSSW)	SZ SW A	Original size length switch (OSLSW)	COV OP SW	DP interlock switch (DPILSW)	DP OP SW	DP open/close switch (DPOCSW)
Display	Switches														
TMG SW	DP timing switch (DPTSW)														
REV SW	Original switchback switch (OSBSW)														
SET SW	Original set switch (OSSW)														
SZ SW A	Original size length switch (OSLSW)														
COV OP SW	DP interlock switch (DPILSW)														
DP OP SW	DP open/close switch (DPOCSW)														

Maintenance item No.	Description																				
U326	<p>Setting the black line cleaning indication</p> <p>Description Sets whether to display the cleaning guidance when detecting the black line.</p> <p>Purpose Displays the cleaning guidance in order to make the call for service with the black line decrease by the rubbish on the contact glass when scanning from the DP.</p> <p>Setting</p> <ol style="list-style-type: none">Press the start key.Select the item to set. The screen for setting each item is displayed. <table><tr><th>Display</th><th>Description</th></tr><tr><td>BLACK LINE MODE</td><td>Black line cleaning guidance ON/OFF setting</td></tr><tr><td>BLACK LINE COUNT</td><td>Setting counts of the cleaning guidance indication</td></tr></table> <p>Setting: [BLACK LINE MODE]</p> <ol style="list-style-type: none">Select ON or OFF. <table><tr><th>Display</th><th>Description</th></tr><tr><td>ON</td><td>Displays the cleaning guidance</td></tr><tr><td>OFF</td><td>Not to display the cleaning guidance</td></tr></table> <p>Initial setting: ON Setting count value is displayed only if the setting is ON.</p> <ol style="list-style-type: none">Press the start key. The setting is set. <p>Setting: [BLACK LINE COUNT]</p> <ol style="list-style-type: none">Change the setting value using the +/- or numeric keys. <table><tr><th>Display</th><th>Description</th><th>Setting range</th><th>Initial setting</th></tr><tr><td>COUNT *1000</td><td>Setting counts of the cleaning guidance indication (x 1000 sheets)</td><td>0 to 255</td><td>8</td></tr></table> <p>When setting is 0, the black line cleaning indication is displayed only if the black line is detected.</p> <ol style="list-style-type: none">Press the start key. The value is set. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	BLACK LINE MODE	Black line cleaning guidance ON/OFF setting	BLACK LINE COUNT	Setting counts of the cleaning guidance indication	Display	Description	ON	Displays the cleaning guidance	OFF	Not to display the cleaning guidance	Display	Description	Setting range	Initial setting	COUNT *1000	Setting counts of the cleaning guidance indication (x 1000 sheets)	0 to 255	8
Display	Description																				
BLACK LINE MODE	Black line cleaning guidance ON/OFF setting																				
BLACK LINE COUNT	Setting counts of the cleaning guidance indication																				
Display	Description																				
ON	Displays the cleaning guidance																				
OFF	Not to display the cleaning guidance																				
Display	Description	Setting range	Initial setting																		
COUNT *1000	Setting counts of the cleaning guidance indication (x 1000 sheets)	0 to 255	8																		

Maintenance item No.	Description																									
U404	<p>Adjusting margins for scanning an original from the DP</p> <p>Description Adjusts margins for scanning the original from the DP.</p> <p>Purpose Make the adjustment if margins are incorrect when the DP is used.</p> <p>Caution Before making this adjustment, ensure that the following adjustments have been made in maintenance mode.</p> <div><div>U402 (See the service manual for the machine.))</div><div>U403 (See the service manual for the machine.)</div><div>U404</div></div> <p>Adjustment</p> <div><div><div>1. Press the start key.</div><div>2. Select the item to be adjusted.</div></div><table><tr><th>Display</th><th>Description</th><th>Setting range</th><th>Initial setting</th><th>Change in value per step</th></tr><tr><td>A MARGIN</td><td>Left margin</td><td>0 to 10.0</td><td>3.0</td><td>0.5 mm</td></tr><tr><td>B MARGIN</td><td>Leading edge margin</td><td>0 to 10.0</td><td>2.5</td><td>0.5 mm</td></tr><tr><td>C MARGIN</td><td>Right margin</td><td>0 to 10.0</td><td>3.0</td><td>0.5 mm</td></tr><tr><td>D MARGIN</td><td>Trailing edge margin</td><td>0 to 10.0</td><td>4.0</td><td>0.5 mm</td></tr></table><div><div>3. Press the system menu key.</div><div>4. Place an original on the DP and press the start key to make a test copy.</div><div>5. Press the system menu key.</div><div>6. Change the setting value using the +/- keys. Increasing the value makes the margin wider, and decreasing it makes the margin narrower.</div></div><div><div>Leading edge margin (3±1.5 mm)</div><div>Left margin (2±1.0 mm)</div><div>Right margin (2±1.0 mm)</div><div>Trailing edge margin (2±1.0 mm)</div></div><p>Figure 1-3-17</p><div><div>7. Press the start key. The value is set.</div></div><p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p></div>	Display	Description	Setting range	Initial setting	Change in value per step	A MARGIN	Left margin	0 to 10.0	3.0	0.5 mm	B MARGIN	Leading edge margin	0 to 10.0	2.5	0.5 mm	C MARGIN	Right margin	0 to 10.0	3.0	0.5 mm	D MARGIN	Trailing edge margin	0 to 10.0	4.0	0.5 mm
Display	Description	Setting range	Initial setting	Change in value per step																						
A MARGIN	Left margin	0 to 10.0	3.0	0.5 mm																						
B MARGIN	Leading edge margin	0 to 10.0	2.5	0.5 mm																						
C MARGIN	Right margin	0 to 10.0	3.0	0.5 mm																						
D MARGIN	Trailing edge margin	0 to 10.0	4.0	0.5 mm																						

Maintenance item No.	Description		
U411	Adjusting the scanner automatically Description Uses a specified original and automatically adjusts the following items in the scanner and the DP scanning sections. Purpose To perform automatic adjustment of various items in the scanner and the DP scanning sections. Method 1. Press the start key. 2. Select the item. The screen for executing is displayed.		
	Display	Description	Original to be used for adjustment (P/N)
	SCANNER	Automatic adjustment in the scanner section	302FZ56990
	DP(FACE UP)	Automatic adjustment in the DP scanning section (first page)	302AC68243
Method: [SCANNER] 1. Enter the target values which are shown on the specified original (P/N: 302FZ56990) executing maintenance item U425. 2. Set a specified original (P/N: 302FZ56990) on the platen. 3. Select the item.			
	Display	Description	
	ALL	Automatic adjustment using the platen for: original size magnification/leading edge timing/center line, input gamma, chromatic aberration filter, MTF filter and matrix.	
	INPUT	Automatic adjustment using the platen for: original size magnification/leading edge timing/center line.	
	C.A.	Automatic adjustment using the platen for: chromatic aberration filter.	
	MTF	Automatic adjustment using the platen for: MTF filter.	
	GAMMA	Automatic adjustment using the platen for: input gamma.	
	MATRIX	Automatic adjustment using the platen for: matrix.	
4. Press the start key. Auto adjustment starts. When automatic adjustment has normally completed, [Complete] is displayed. If a problem occurs during auto adjustment, [ERROR XX] (XX is replaced by an error code) is displayed and operation stops. Should this happen, determine the details of the problem and either repeat the procedure from the beginning, or adjust the remaining items manually by running the corresponding maintenance items.			
Method: [DP(FACE UP)] 1. Measure the leading edge, main scanning, and auxiliary scanning of the specified original (P/N: 302AC68243) and enter the values by executing maintenance item U425. 2. Set a specified original (P/N: 302AC68243) in the DP. Cut the trailing edge of the original.			
			

TONER

Figure 1-3-18

Figure 1-3-18

Maintenance item No.	Description	
U411	3. Press [INPUT].	
	Display	Description
	INPUT	Automatic adjustment of first page using the DP for: original size magnification/leading edge timing/center line.
	4. Press the start key. Auto adjustment starts.	
	When automatic adjustment has normally completed, [Complete] is displayed. If a problem occurs during auto adjustment, [ERROR XX] (XX is replaced by an error code) is displayed and operation stops.	
	Should this happen, determine the details of the problem and either repeat the procedure from the beginning, or adjust the remaining items manually by running the corresponding maintenance items.	
	Error Codes	
	Codes	Description
	ERROR 01	Black band detection error (scanner leading edge registration)
	ERROR 02	Black band detection error (scanner center line)
ERROR 03	Black band detection error (scanner main scanning direction magnification)	
ERROR 04	Black band is not detected (scanner leading edge registration)	
ERROR 05	Black band is not detected (scanner center line)	
ERROR 06	Black band is not detected (scanner main scanning direction magnification)	
ERROR 07	Black band is not detected (scanner auxiliary scanning direction magnification)	
ERROR 08	Black band is not detected (DP main scanning direction magnification far end)	
ERROR 09	Black band is not detected (DP main scanning direction magnification near end)	
ERROR 0a	Black band is not detected (DP auxiliary scanning direction magnification leading edge)	
ERROR 0b	Black band is not detected (DP auxiliary scanning direction magnification leading edge original check)	
ERROR 0c	Black band is not detected (DP auxiliary scanning direction trailing edge)	
ERROR 0d	Black band is not detected (DP auxiliary scanning direction trailing edge 2)	
ERROR 0e	DMA time out	
ERROR 0f	Auxiliary scanning direction magnification error	
ERROR 10	Auxiliary scanning direction leading edge detection error	
ERROR 11	Auxiliary scanning direction trailing edge detection error	
ERROR 12	Auxiliary scanning direction skew 1.5 error	
ERROR 13	Maintenance request error	
ERROR 14	Main scanning direction center line error	
ERROR 15	Main scanning direction skew 1.5 error	
ERROR 16	Main scanning direction magnification error	
ERROR 17	Service call error	
ERROR 18	DP JAM error	
ERROR 19	PWB error	
ERROR 1a	Original error	
Completion		
Press the stop key. The screen for selecting a maintenance item is displayed.		

Maintenance item No.	Description																		
U905	<p>Checking/clearing counts by optional devices</p> <p>Description Displays the counts of DP or finisher.</p> <p>Purpose To check the use of DP and finisher.</p> <p>Method</p> <ol style="list-style-type: none">1. Press the start key.2. Select the device, the count of which is to be checked.3. Press the start key. The count of the selected device is displayed. <table><tr><th>Display</th><th>Description</th></tr><tr><td>DP</td><td>Counts of optional DP</td></tr><tr><td>FINISHER</td><td>Counts of optional document finisher or built-in finisher</td></tr></table> <p>DP</p> <table><tr><th>Display</th><th>Description</th></tr><tr><td>ADP</td><td>No. of single-sided originals that has passed through the DP</td></tr><tr><td>RADP</td><td>No. of double-sided originals that has passed through the DP</td></tr></table> <p>Document finisher/Built-in finisher</p> <table><tr><th>Display</th><th>Description</th></tr><tr><td>CP CNT</td><td>No. of copies that has passed</td></tr><tr><td>STAPLE</td><td>Frequency the stapler has been activated</td></tr></table> <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	DP	Counts of optional DP	FINISHER	Counts of optional document finisher or built-in finisher	Display	Description	ADP	No. of single-sided originals that has passed through the DP	RADP	No. of double-sided originals that has passed through the DP	Display	Description	CP CNT	No. of copies that has passed	STAPLE	Frequency the stapler has been activated
Display	Description																		
DP	Counts of optional DP																		
FINISHER	Counts of optional document finisher or built-in finisher																		
Display	Description																		
ADP	No. of single-sided originals that has passed through the DP																		
RADP	No. of double-sided originals that has passed through the DP																		
Display	Description																		
CP CNT	No. of copies that has passed																		
STAPLE	Frequency the stapler has been activated																		
U942	<p>Setting of deflection for feeding from DP</p> <p>Description Adjusts the deflection generated when the DP is used.</p> <p>Purpose Use this mode if an original non-feed jam, oblique feed or wrinkling of original occurs when the DP is used.</p> <p>Setting</p> <ol style="list-style-type: none">1. Press the start key.2. Select the item to be adjusted. <table><tr><th>Display</th><th>Description</th><th>Setting range</th><th>Initial setting</th><th>Change in value per step</th></tr><tr><td>FEED MOT</td><td>Deflection in the original feed motor</td><td>-31 to 31</td><td>0</td><td>0.31 mm</td></tr><tr><td>REV MOT</td><td>Deflection in the original switchback motor</td><td>-31 to 31</td><td>0</td><td>0.39 mm</td></tr></table> <ol style="list-style-type: none">3. Press the system menu key.4. Place an original on the DP and press the start key to make a test copy.5. Press the system menu key.6. Change the setting value using the +/- or numeric keys. The greater the value, the larger the deflection; the smaller the value, the smaller the deflection. If an original non-feed jam or oblique feed occurs, increase the setting value. If wrinkling of original occurs, decrease the value.7. Press the start key. The setting is set. <p>Completion Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Setting range	Initial setting	Change in value per step	FEED MOT	Deflection in the original feed motor	-31 to 31	0	0.31 mm	REV MOT	Deflection in the original switchback motor	-31 to 31	0	0.39 mm			
Display	Description	Setting range	Initial setting	Change in value per step															
FEED MOT	Deflection in the original feed motor	-31 to 31	0	0.31 mm															
REV MOT	Deflection in the original switchback motor	-31 to 31	0	0.39 mm															

This page is intentionally left blank.

1-4-1 Original misfeed detection

(1) Original misfeed indication

When an original jams, the machine immediately stops operation and a message is shown on the machine operation panel.

To remove the jammed original, open the document processor top cover.

To reset the original misfeed detection, open and close the document processor top cover.

(2) Original misfeed detection conditions




Figure 1-4-1

Section	Jam code	Conditions	Specified time
DP	70 No original feed	The DP timing switch (DPTSW) does not turn on within specified time during the first sheet feeding (Retry 5 times).	1468 pulses
		The DP timing switch (DPTSW) does not turn on within specified time during the second sheet feeding (Retry 5 times).	1468 pulses
	71 An original jam in the original conveying section 1	DP timing switch (DPTSW) does not turn off within specified time of the original conveying motor (OCM) turning on.	9900 pulses
	72 An original jam in the original conveying section 2	DP timing switch (DPTSW) turns off within the specified time of period of the original conveying motor (OCM) turning on.	1145 pulses
	73 An original jam in the original switchback section	DP timing switch (DPTSW) does not turn off within specified time of the original switchback motor (OSBM) turning on.	9900 pulses
	74 An original jam in the original switchback/feed section	DP timing switch (DPTSW) does not turn on within specified time of the original switchback motor (OSBM) turning on.	10700 pulses
	75 An original jam in the original switchback/conveying section	The original switchback switch (OSBSW) does not turn on within specified time of the DP timing switch (DPTSW) turning off.	1724 pulses
	78 Document processor cover open	The document processor or document processor top cover is opened during original feeding. DP timing switch (DPTSW) or original switchback switch (OSBSW) turns on when starting the original paper feed.	-

(3) Paper misfeeds

Problem	Causes/check procedures	Corrective measures
(1) An original jams in DP is indicated during copying (no original feed). Jam code 70	Defective DP timing switch.	Run maintenance item U244 and turn the DP timing switch on and off manually. Replace the switch if indication of the corresponding switch on the touch panel is not displayed in reverse.
	Check if the original feed motor malfunctions.	Run maintenance item U243 and select the original feed motor on the touch panel to be turned on and off. Check the status and remedy if necessary.
(2) An original jams in DP is indicated during copying (a jam in the original conveying section 1). Jam code 71	Defective DP timing switch.	Run maintenance item U244 and turn the DP timing switch on and off manually. Replace the switch if indication of the corresponding switch on the touch panel is not displayed in reverse.
(3) An original jams in DP is indicated during copying (a jam in the original conveying section 2). Jam code 72	Defective DP timing switch.	Run maintenance item U244 and turn the DP timing switch on and off manually. Replace the switch if indication of the corresponding switch on the touch panel is not displayed in reverse.
	Check if the original conveying motor malfunctions.	Run maintenance item U243 and select the original conveying motor on the touch panel to be turned on and off. Check the status and remedy if necessary.
(4) An original jams in DP is indicated during copying (a jam in the original switchback section). Jam code 73	Defective DP timing switch.	Run maintenance item U244 and turn the DP timing switch on and off manually. Replace the switch if indication of the corresponding switch on the touch panel is not displayed in reverse.
	Check if the original switchback motor malfunctions.	Run maintenance item U243 and select the original switchback motor on the touch panel to be turned on and off. Check the status and remedy if necessary.
(5) An original jams in DP is indicated during copying (a jam in the original switchback/feed section). Jam code 74	Defective DP timing switch.	Run maintenance item U244 and turn the DP timing switch on and off manually. Replace the switch if indication of the corresponding switch on the touch panel is not displayed in reverse.
	Check if the original switchback motor malfunctions.	Run maintenance item U243 and select the original switchback motor on the touch panel to be turned on and off. Check the status and remedy if necessary.
(6) An original jams in DP is indicated during copying (a jam in the original switchback/conveying section). Jam code 75	Defective switch.	Run maintenance item U244 and turn switch on and off manually. Replace the switch if indication of the corresponding switch on the touch panel is not displayed in reverse. DP timing switch, original switchback switch

1-4-2 Self-diagnosis

(1) Self-diagnostic function

This unit is equipped with a self-diagnostic function. When a problem is detected, copying is disabled and the problem displayed as a code consisting of C followed by a number, indicating the nature of the problem. A message is also displayed requesting the user to call for service.

After removing the problem, the self-diagnostic function can be reset by turning the main power switch off and back on.

(2) Self diagnostic codes (DP-670)

Code	Contents	Remarks	
		Causes	Check procedures/corrective measures
C9000	DP communication problem A communication error is detected.	Poor contact in the connector terminals.	Check the connection of connector YC24 and YC31 on the engine PWB and the connector of the DP, and the continuity across the connector terminals. Repair or replace if necessary.
		Defective DP main PWB.	Replace the DP main PWB and check for correct operation.
C9060	DP EEPROM error Read and write data does not match. Data in the specified area of the backup memory does not match the specified values.	Defective DP main PWB.	Replace the DP main PWB and check for correct operation.
		Device damage of EEPROM.	Contact the Service Administrative Division.

(3) Self diagnostic codes (DP-670(B))

Code	Contents	Remarks	
		Causes	Check procedures/corrective measures
C9000	DP communication problem A communication error is detected.	Poor contact in the connector terminals.	Check the connection of connector YC7 and YC8 on the scanner PWB and the connector of the DP, and the continuity across the connector terminals. Repair or replace if necessary.
		Defective DP main PWB.	Replace the DP main PWB and check for correct operation.
C9060	DP EEPROM error Read and write data does not match. Data in the specified area of the backup memory does not match the specified values.	Defective DP main PWB.	Replace the DP main PWB and check for correct operation.
		Device damage of EEPROM.	Contact the Service Administrative Division.

1-4-3 Electric problems

Troubleshooting to each failure must be in the order of the numbered symptoms.

Problem	Causes	Check procedures/corrective measures
(1) The original feed motor, original conveying motor or original switchback motor does not operate.	1. Poor contact in the connector terminals.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable.
	2. Defective drive transmission system.	Check if the rollers and gears rotate smoothly. If not, grease the bushings and gears. Check for broken gears and replace if any.
	3. Defective motor.	Run maintenance item U243 and check if the motor operates. If not, replace the motor.
	4. Defective DP main PWB.	Run maintenance item U243 and check if the motor operates. If not, replace the DP main PWB.
(2) The DP cooling fan motor does not operate.	1. Poor contact in the connector terminals.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable.
	2. Broken motor coil.	Check for continuity across the coil. If none, replace the motor.
(3) The switchback feed-shift solenoid or switchback pressure solenoid does not operate.	1. Defective solenoid coil.	Check for continuity across the coil. If none, replace the solenoid.
	2. Poor contact in the connector terminals.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable.
	3. Defective DP main PWB.	Run maintenance item U243 and check if the solenoid operates. If not, replace the DP main PWB.
(4) A message indicating cover open is displayed when the document processor top cover is closed correctly.	1. Poor contact in the connector terminals of DP interlock switch.	Reinsert the connector. Also check for continuity within the connector cable. If none, remedy or replace the cable.
	2. Defective DP interlock switch.	Check for continuity across the contacts of the switch. If none when the switch is on, replace DP interlock switch.
(5) An original jams when the main power switch is turned on.	1. A piece of paper torn from an original is caught around the switch.	Remove any found.
	2. Defective DP timing switch or original switchback switch.	Run maintenance item U244 and turn the switch on and off manually. Replace the switch if indication of the corresponding switch on the touch panel is not displayed in reverse.

1-4-4 Mechanical problems

Problem	Causes/check procedures	Corrective measures
(1) No primary original feed.	The surfaces of the DP forwarding pulley, DP feed pulley or DP separation pad are dirty with paper powder.	Check and clean them with isopropyl alcohol if they are dirty.
	Check if the DP forwarding pulley or the DP feed pulley is deformed.	If so, replace (see page 1-5-2).
	Electrical problem with the original feed motor.	See page 1-4-5.
(2) Originals jam.	Originals outside the specifications are used.	Use only originals conforming to the specifications.
	The surfaces of the DP forwarding pulley, DP original feed pulley or DP separation pad are dirty with paper powder.	Check and clean them with isopropyl alcohol if they are dirty.
	Check if the contact between the eject roller and eject pulley is correct.	Check visually and remedy if necessary.
	Check if the contact between the switchback roller and switchback pulley is correct.	Check visually and remedy if necessary.

1-5-1 Precautions for assembly and disassembly

(1) Precautions

Before starting disassembly, press the Power key on the operation panel to off. Make sure that the Power lamp is off before turning off the main power switch. And then unplug the power cable from the wall outlet. Turning off the main power switch before pressing the Power key to off may cause damage to the equipped hard disk.

When handling PWBs (printed wiring boards), do not touch parts with bare hands. The PWBs are susceptible to static charge.

Do not touch any PWB containing ICs with bare hands or any object prone to static charge.

When removing the hook of the connector, be sure to release the hook.

Take care not to get the cables caught.

To reassemble the parts, use the original screws. If the types and the sizes of screws are not known, refer to the PARTS LIST.

Output Connector for Interconnecting Cable is non-LPS.

Output: 357VA max.

Please use the item below Interconnecting Cable/

P/N: 303K546050

1-5-2 Original feed section

(1) Detaching and refitting the DP forwarding pulley and DP feed pulley

Follow the procedure below to clean or replace the DP forwarding pulley or DP feed pulley.

Procedure

Removing the DP forwarding pulley

1. Open the document processor top cover.
2. Raise the DP feed pulley unit.
Release the claw holding the DP forwarding pulley shaft and then pull out the shaft.
3. Remove the DP forwarding pulley.




Figure 1-5-1

Removing the DP feed pulley

4. Remove the stop ring and two original feed guides of the DP feed pulley shaft.
When mounting the original feed guide, fit the projection of the original feed guide into the groove of the DP feed pulley shaft. Align the original feed guide with the side affixed with a C label facing the front side of the machine.
5. Remove the DP feed pulley unit from the DP.





Figure 1-5-2

6. Remove two stop rings and then remove DP feed pulley shaft from the DP feed pulley unit.
7. Remove DP feed pulley from the DP feed pulley shaft.
8. Clean or replace the DP forwarding pulley and the DP feed pulley. Refit all the removed parts.

**Figure 1-5-3**

(2) Detaching and refitting the DP separation pad

Follow the procedure below to clean or replace the DP separation pad.

Procedure

1. Remove the DP feed pulley unit. (see page 1-5-2)
2. Push the inserted parts of the DP separation pad and then remove the DP separation pad.
3. Clean or replace the DP separation pad.
Refit all the removed parts.




Figure 1-5-4

1-5-3 Image adjustment

(1) Adjusting the angle of leading edge

Perform the following adjustment if the leading edge of the copy image is laterally skewed.

Procedure

1. Place an original on the DP and press the start key to make a test copy.
2. If the gap of leading edge exceeds the reference value, perform the following adjustment.
Reference value
For simplex copying: Within ± 3.0 mm
For duplex copying: Within ± 4.0 mm




Figure 1-5-5

3. Open the DP and loosen two adjusting screws of right hinge.
4. Adjust the position of the DP.
For copy example 1: Move the DP down (⇓).
For copy example 2: Move the DP up (⇑).
Amount of change per scale: Approx. 0.5 mm
5. Tighten two adjusting screws.




Figure 1-5-6

6. Remove the original mat.
7. Place the original mat with its hook and loop fasteners up over the platen.
Align the original mat corner that has not been surface cut with the rear left corner of the platen.
8. Close the DP slowly to attach the original mat.
9. Make a test copy again.
10. Repeat steps 3 to 9 above until the gap of the leading edge falls within the reference values.




Figure 1-5-7

(2) Adjusting the angle of trailing edge

Perform the following adjustment if the trailing edge of the copy image is laterally skewed.

Procedure

1. Place an original on the DP and press the start key to make a test copy.
2. If the gap of trailing edge exceeds the reference value, perform the following adjustment.

Reference value

For simplex copying: Within ± 3.0 mm

For duplex copying: Within ± 4.0 mm




Figure 1-5-8

3. Open the DP and release two latches using a flat-head screwdriver.




Figure 1-5-9

4. Release three latches using a flat-head screwdriver and remove the DP rear cover.




Figure 1-5-10

5. Adjust the height of DP.
 - 1) Loosen the nut.
 - 2) For copy example 1:
Loosen the adjusting screw (➡).
 - For copy example 2:
Tighten the adjusting screw (⇨).
 - 3) Tighten the nut.
6. Refit the DP rear cover.




Figure 1-5-11




Figure 1-5-12

7. Remove the original mat.
8. Place the original mat with its hook and loop fasteners up over the platen.
Align the original mat corner that has not been surface cut with the rear left corner of the platen.
9. Close the DP slowly to attach the original mat.
10. Make a test copy again.
11. Repeat steps 3 to 10 above until the gap of the trailing edge falls within the reference values.




Figure 1-5-13

1-6-1 Upgrading the firmware (DP-670/models with color touch panel)

Follow the procedure below to upgrade the firmware.

Firmware upgrading requires the following tools:

Compact Flash (Products manufactured by SANDISK are recommended.) or USB memory

NOTE

When writing data to a new Compact Flash from a computer, be sure to format it in advance.

Procedure

1. Press the power key on the operation panel to off. Make sure that the power indicator and the memory indicator are off before turning off the main power switch. And then unplug the power cable from the wall outlet.
2. Insert Compact Flash or USB memory in a notch hole of the machine.
Insert the surface of Compact Flash toward the machine rear.
3. Insert the power plug and turn the main power switch on. Upgrading firmware starts for 3 minutes.

Caution:

Never turn the main power switch off during upgrading.




Figure 1-6-1

4. [Completed] is displayed on the touch panel when upgrading is complete.
5. Press the power key on the operation panel to off. Make sure that the power indicator and the memory indicator are off before turning off the main power switch. And then unplug the power cable from the wall outlet.
6. Remove Compact Flash or USB memory from the machine.
7. Insert the power plug and turn the main power switch on.

1-6-2 Upgrading the firmware (DP-670/models with monochrome touch panel)

Follow the procedure below to upgrade the firmware.

Firmware upgrading requires the following tools:

Compact Flash (Products manufactured by SANDISK are recommended.)

NOTE

When writing data to a new Compact Flash from a computer, be sure to format it in advance.

Procedure

1. Press the power key on the operation panel to off. Make sure that the power indicator and the memory indicator are off before turning off the main power switch. And then unplug the power cable from the wall outlet.
2. Remove two screws and remove the right upper plate lid.
3. Insert Compact Flash in a notch hole of the machine.
Insert the surface of Compact Flash toward the machine rear.
4. Insert the power plug and turn the main power switch on. Upgrading firmware starts .

Caution:

Never turn the main power switch off during upgrading.




Figure 1-6-2

5. [Completed] is displayed on the touch panel when upgrading is complete.
6. Press the power key on the operation panel to off. Make sure that the power indicator and the memory indicator are off before turning off the main power switch. And then unplug the power cable from the wall outlet.
7. Remove Compact Flash from the machine.
8. Refit the right upper plate lid.
9. Insert the power plug and turn the main power switch on.

1-6-3 Upgrading the firmware (DP-670(B)/models with color touch panel)

Follow the procedure below to upgrade the firmware.

Firmware upgrading requires the following tools:

USB memory

Procedure

1. Press the power key on the operation panel to off. Make sure that the power indicator and the memory indicator are off before turning off the main power switch. And then unplug the power cable from the wall outlet.
2. Insert the USB memory in the USB memory slot.
Insert the power plug and turn the main power switch on. Upgrading firmware starts.

Caution:

Never turn the main power switch off during upgrading.




Figure 1-6-3

3. [100% Completed] is displayed on the touch panel when upgrading is complete.
4. Press the power key on the operation panel to off. Make sure that the power indicator and the memory indicator are off before turning off the main power switch. And then unplug the power cable from the wall outlet.
5. Remove the USB memory from the USB memory slot.
6. Insert the power plug and turn the main power switch on.

This page is intentionally left blank.

2-1-1 Mechanical construction

The DP consists of the original feed section, original conveying section and original switchback section.

The original feed section conveys an original set on the original table to the original conveying section in synchronization with original scanning of the scanner on the machine.

The original conveying section conveys an original onto the slit glass and ejects it after scanning is complete.

The original switchback section reverses an original conveyed from the original conveying section and conveys it again to the original conveying section in the double-sided original mode.




Figure 2-1-1 Original feed section

- | | |
|--------------------------------|---|
| (1) DP forwarding pulleys | (13) Original set switch (OSSW) |
| (2) DP original feed pulley | (14) DP timing switch (DPTSW) |
| (3) DP separation pad | (15) Original switchback switch (OSBSW) |
| (4) Conveying pulley | (16) Original size length switch (OSLSW) |
| (5) Conveying roller | (17) Scanning guide |
| (6) Conveying pulley | (18) Conveying upper guide |
| (7) Conveying pulley | (19) Document processor top cover |
| (8) Switchback feedshift guide | (20) Actuator (Original set switch) |
| (9) Switchback roller | (21) Actuator (DP timing switch) |
| (10) Switchback pulley | (22) Actuator (Original switchback switch) |
| (11) Eject pulley | (23) Actuator (Original size length switch) |
| (12) Eject roller | (24) Original size width switch (OSWSW) |





Figure 2-1-2

(1) Operation of original switchback

In the double-sided original mode, after the first side of an original is scanned, the switchback feedshift guide is activated to switch the conveying path to the switchback tray side and the original is fed to the switchback tray. Then, the original is reversed by the reverse rotation of the original switchback motor (OSBM) and conveyed again to the original conveying section. After the second side is scanned, the original is fed temporarily to the switchback tray, is reversed, is conveyed without scanning, and then is ejected to the exit tray. Also the switchback press solenoid (SBPSOL) is activated to release the switchback pulley for preventing original jams in the original switchback section.




First side scanning → Switchback tray

Original conveying motor (OCM): Forward rotation

Original switchback motor (OSBM): Forward rotation

Switchback feedshift solenoid (SBFSSOL): ON




Original switchback operate

Original conveying motor (OCM): Stop

Original switchback motor (OSBM): Reverse rotation

Switchback feedshift solenoid (SBFSSOL): OFF




Second side scanning → Switchback tray

Original conveying motor (OCM): Forward rotation

Original switchback motor (OSBM): Forward rotation

Switchback feedshift solenoid (SBFSSOL): ON




Original switchback operate

Original conveying motor (OCM): Stop

Original switchback motor (OSBM): Reverse rotation

Switchback feedshift solenoid (SBFSSOL): OFF



Conveyed without scanning → Eject tray

Original conveying motor (OCM): Forward rotation

Original switchback motor (OSBM): Forward rotation

Switchback feedshift solenoid (SBFSSOL): OFF

Figure 2-1-3

This page is intentionally left blank.

2-2-1 Electrical parts layout

(1) PWBs






Figure 2-2-1 PWBs


1. DP main PWB (DPMPWB) Controls electrical components of the DP.
2. Original set LED PWB (OSLEDPWB)..... Indicates presence of originals on the DP or an original jam.

(2) Switches and sensors**Figure 2-2-2 Switches and sensors**

1. DP interlock switch (DPILSW) Breaks the safety circuit when the document processor top cover is opened; resets original misfeed detection.
2. Original set switch (OSSW) Detects the presence of an original.
3. DP timing switch (DPTSW) Detects the original scanning timing.
4. Original switchback switch (OSBSW) Detects an original misfeed in the original switchback section.
5. Original size width switch (OSWSW) Detects the width of the original.
6. Original size length switch (OSLSW) Detects the length of the original.
7. DP open/close switch (OPOCSW) Detects the opening/closing of the DP.

(3) Motors**Figure 2-2-3 Motors**

1. Original feed motor (OFM) Drives the original feed section.
2. Original conveying motor (OCM) Drives the original conveying section.
3. Original switchback motor (OSBM)..... Drives the original switchback section.
4. DP cooling fan motor (DPCFM) Cools the drive section.

(4) Solenoids**Figure 2-2-4 Solenoids**

1. Switchback feedshift solenoid (SBFSSOL).. Operates the switchback feedshift guide.
2. Switchback pressure solenoid (SBPSOL).... Operates the switchback pulley.

2-3-1 DP main PWB




Figure 2-3-1 DP main PWB block diagram




Figure 2-3-2 DP main PWB silk-screen diagram

Connector	Pin No.	Signal	I/O	Voltage	Description
YC1 Connected to the machine.	1	FG	-	-	Ground
	2	5V	I	5 V DC	5 V DC supply
	3	GND	-	-	Ground
	4	24V	I	24 V DC	24 V DC supply
YC2 Connected to the machine.	1	SDI	I	0/5 V DC (pulse)	Serial communication data signal
	2	SDO	O	0/5 V DC (pulse)	Serial communication data signal
	3	SCLK	I	0/5 V DC (pulse)	Serial communication clock signal
	4	DPSEL	I	0/5 V DC	DP select signal
	5	DPRDY	O	0/5 V DC	DP ready signal
	6	ORGVSYNC	O	5 V DC	DP original scanning interval signal
	7	GND	-	-	Ground
	8	GND	-	-	Ground
	9	GND	-	-	Ground
	10	GND	-	-	Ground
YC3 Connected to the original feed motor.	1	B	O	0/24 V DC (pulse)	OFM drive control signal (B)
	2	COM_A(R24V)	O	24 V DC	24 V DC supply
	3	A	O	0/24 V DC (pulse)	OFM drive control signal (A)
	4	_B	O	0/24 V DC (pulse)	OFM drive control signal (_B)
	5	COM_B(R24V)	O	24 V DC	24 V DC supply
	6	_A	O	0/24 V DC (pulse)	OFM drive control signal (_A)
YC4 Connected to the original conveying motor and original switchback motor.	1	B	O	0/24 V DC (pulse)	OCM drive control signal (B)
	2	COM_A(R24V)	O	24 V DC	24 V DC supply
	3	A	O	0/24 V DC (pulse)	OCM drive control signal (A)
	4	_B	O	0/24 V DC (pulse)	OCM drive control signal (_B)
	5	COM_B(R24V)	O	24 V DC	24 V DC supply
	6	_A	O	0/24 V DC (pulse)	OCM drive control signal (_A)
	7	B	O	0/24 V DC (pulse)	OSBM drive control signal (B)
	8	COM_A(R24V)	O	24 V DC	24 V DC supply
	9	A	O	0/24 V DC (pulse)	OSBM drive control signal (A)
	10	_B	O	0/24 V DC (pulse)	OSBM drive control signal (_B)
	11	COM_B(R24V)	O	24 V DC	24 V DC supply
	12	_A	O	0/24 V DC (pulse)	OSBM drive control signal (_A)
YC5 Connected to the DP interlock switch.	1	24V	O	24 V DC	24 V DC supply
	2	N.C.	-	-	Not used
	3	R24V	I	0/24 V DC	24 V DC supply
	4	N.C.	-	-	Not used
	5	COV_OPN	I	24/0 V DC	DPILSW: On/Off
YC6 Connected to the DP timing switch.	1	5V	O	5 V DC	5 V DC supply
	2	TMG SW	I	0/5 V DC	DPTSW: On/Off
	3	GND	-	-	Ground

Connector	Pin No.	Signal	I/O	Voltage	Description
YC7 Connected to the switchback presser solenoid and switch-back feed-shift solenoid.	1	24V	O	24 V DC	24 V DC supply
	2	ACT	O	0/24 V DC	SBPSOL (ACT): On/Offd
	3	RET	O	0/24 V DC	SBPSOL (RET): On/Off
	4	24V	O	24 V DC	24 V DC supply
	5	ACT	O	0/24 V DC	SBFSSOL: On/Off
YC8 Connected to the original set LED PWB.	1	LED_RD	O	2.1/0 V DC	OSLEDPWB (red): On/Off
	2	GND	-	-	Ground
	3	LED_GN	O	2.1/0 V DC	OSLEDPWB (green): On/Off
	4	N.C.	-	-	Not used
YC9 Connected to the original switch-back switch, original size length switch and original size width switch.	1	5V	O	5 V DC	5 V DC supply
	2	REV SW	I	0/5 V DC	OSBSW: On/Off
	3	GND	-	-	Ground
	4	SZ_SW_L	I	0/5 V DC	OSLSW: On/Off
	5	5V	O	5 V DC	5 V DC supply
	6	GND	-	-	Ground
	7	SZ_SW_W	I	Analog	OSWSW: On/Off
	8	5V	O	5 V DC	5 V DC supply
YC10 Connected to original set switch.	1	GND	-	-	Ground
	2	SET SW	I	0/5 V DC	OSSW: On/Off
	3	5V	O	5 V DC	5 V DC supply
YC11 Connected to DP cooling fan motor.	1	5V	O	5 V DC	5 V DC supply
	2	N.C.	-	-	Not used
	3	N.C.	-	-	Not used
	4	N.C.	-	-	Not used
	5	GND	-	-	Ground

List of maintenance parts

Maintenance part name		Part No.	Alternative part No.
Name used in service manual	Name used in parts list		
DP forwarding pulley	PULLEY, LEADING FEED ADF	36211110	-
DP feed pulley	PULLEY PAPER FEED	3BR07040	-
DP separation pad	PAD SEPARATION	303K507060	3K507060
Friction plate	FRICTION PLATE LF	3HK07240	-
Conveying roller	PARTS CONVEYING ROLLER ASSY	303K594010	3K594010
Conveying pulley	PULLEY CONVEYING	3HL08080	-
Conveying pulley	PULLEY CONVEYING	3HL08080	-
Conveying pulley	PULLEY LOOP	3HL10140	-
Scanning guide	GUIDE READING	303K524010	3K524010
Switchback roller	PARTS ROLLER LOOP SP	303K594050	3K594050
Switchback pulley	PULLEY LOOP	3HL10140	-
Eject roller	PARTS ROLLER EJECT SP	303K594040	3K594040
Eject pulley	PULLEY CONVEYING	3HL08080	-
Original holder mat	PLARTE ORIGINAL	303JC04200	3JC04200

Periodic maintenance procedures

Section	Maintenance part/location	User call	150K	Points and cautions	Page
Test copy and test print	Perform at the maximum copy size	Test copy	Test copy		



Section	Maintenance part/location	User call	150K	Points and cautions	Page
Original feed section	DP forwarding pulley	Clean	Replace	Clean with alcohol. Replace after feeding 150,000 sheets.	P.1-5-2
	DP feed pulley	Clean	Replace	Clean with alcohol. Replace after feeding 150,000 sheets.	P.1-5-2
	DP separation pad	Clean	Replace	Clean with alcohol. Replace after feeding 150,000 sheets.	P.1-5-5
	Friction plate	Clean	Clean	Clean with alcohol.	



Section	Maintenance part/location	User call	150K	Points and cautions	Page
Original conveying section	Conveying roller	Clean	Clean	Clean with alcohol or a dry cloth.	
	Conveying pulley	-	Check Clean	Clean with alcohol or a dry cloth.	
	Scanning guide	Clean	Clean	Clean with alcohol or a dry cloth.	



Section	Maintenance part/location	User call	150K	Points and cautions	Page
Original switchback section	Switchback roller	Clean	Clean	Clean with alcohol or a dry cloth.	
	Switchback pulley	-	Check Clean	Clean with alcohol or a dry cloth.	
	Eject roller	Clean	Clean	Clean with alcohol or a dry cloth.	
	Eject r pulley	-	Check Clean	Clean with alcohol or a dry cloth.	




Section	Maintenance part/location	User call	150K	Points and cautions	Page
Other	Original holder mat	-	Clean	Clean with alcohol or a dry cloth.	



Section	Maintenance part/location	User call	150K	Points and cautions	Page
Covers	Covers	Clean	Clean	Clean with alcohol.	
	Slit glass*	Check Clean	Clean	Clean with alcohol or a dry cloth.	

*: Equipped with the machine.

Wiring diagram



KYOCERA MITA EUROPE B.V.

Hoeksteen 40, 2132 MS Hoofddorp,
The Netherlands
Phone: +31.20.654.0000
Home page: <http://www.kyoceramita-europe.com>
Email: info@kyoceramita-europe.com

KYOCERA MITA NEDERLAND B.V.
Beechavenue 25, 1119RA Schiphol-Rijk
The Netherlands
Phone: +31.20.58.77.200

KYOCERA MITA (UK) LTD
8 Beacontree Plaza
Gillette Way Reading Berks RG2 OBS,
U.K.
Phone: +44.1189.311.500

KYOCERA MITA ITALIA S.p.A.
Via G. Verdi, 89 / 91, 20063 Cernusco s/N
Milano, Italy
Phone: +39.02.92179.1

S.A. KYOCERA MITA BELGIUM N.V.
Hermestraat 8A, 1930 Zaventem,
Belgium
Phone: +32.2.720.9270

KYOCERA MITA FRANCE S.A.
Parc Les Algorithmes Saint Aubin
91194 GIF-SUR-YVETTE,
France
Phone: +33.1.6985.2600

KYOCERA MITA ESPAÑA S.A.
Edificio Kyocera, Avda de Manacor No. 2,
28290 Las Matas (Madrid),
Spain
Phone: +34.91.631.8392

KYOCERA MITA FINLAND OY
Kirvesmiehenkatu 4, 00880 Helsinki,
Finland
Phone: +358.9.4780.5200

KYOCERA MITA (SCHWEIZ)
Hohlstrasse 614, 8048 Zürich
Switzerland
Phone: +41.1.908.4949

KYOCERA MITA DEUTSCHLAND GMBH
Otto-Hahn-Str. 12 D-40670 Meerbusch,
Germany
Phone: +49.2159.918.0

KYOCERA MITA GMBH AUSTRIA
Eduard-Kittenberger-Gasse 95,
1230 Wien,
Austria
Phone: +43.1.86338.210

KYOCERA MITA SVENSKA AB
Esbogatan 16B 164 75 Kista,
Sweden
Phone: +46.8.546.55000

KYOCERA MITA NORGE
Postboks 150 Oppsal, NO 0619 Oslo
Olaf Helsetsvai 6, NO 0694 Oslo,
Norway
Phone: +47.22.62.73.00

KYOCERA MITA DANMARK A/S
Ejby Industrivej 1, DK-2600 Glostrup,
Denmark
Phone: +45.5687.1100

KYOCERA MITA PORTUGAL LDA.
Rua do Centro Cultural, 41 (Alvalade) 1700-106 Lisbon,
Portugal
Phone: +351.21.842.9100

KYOCERA MITA SOUTH AFRICA (PTY) LTD.
527 Kyalami Boulevard,
Kyalami Business Park Midrand,
South Africa
Phone: +27.(0)11.540.2600

KYOCERA MITA AMERICA, INC.

Headquarters:
225 Sand Road,
Fairfield, New Jersey 07004-0008,
U.S.A.
Phone: (973) 808-8444

KYOCERA MITA AUSTRALIA PTY. LTD.
Level 3, 6-10 Talavera Road, North Ryde,
N.S.W. 2113 Australia
Phone: (02) 9888-9999

KYOCERA MITA NEW ZEALAND LTD.
1-3 Parkhead Place, Albany
P.O. Box 302 125 NHPC, Auckland,
New Zealand
Phone: (09) 415-4517

KYOCERA MITA (THAILAND) CORP., LTD.
9/209 Ratchada-Prachachem Road,
Bang Sue, Bangkok 10800, Thailand
Phone: (02) 586-0320

KYOCERA MITA SINGAPORE PTE LTD.
121 Genting Lane, 3rd Level,
Singapore 349572
Phone: 67418733

KYOCERA MITA HONG KONG LIMITED
11/F., Mita Centre,
552-566, Castle Peak Road,
Tsuen Wan, New Territories,
Hong Kong
Phone: 24297422

KYOCERA MITA TAIWAN Corporation.
7F-1~2, No.41, Lane 221, Gangchi Rd.
Neihu District, Taipei, Taiwan, 114. R.O.C.
Phone: (02) 87511560

KYOCERA MITA Corporation

2-28, 1-chome, Tamatsukuri, Chuo-ku
Osaka 540-8585, Japan
Phone: (06) 6764-3555
<http://www.kyoceramita.com>

KYOCERA MITA AMERICA, INC.

Headquarters:

225 Sand Road,
Fairfield, New Jersey 07004-0008
TEL : (973) 808-8444
FAX : (973) 882-6000

New York Branch:

1410 Broadway 23rd floor
New York, NY 10018
TEL : (917) 286-5400
FAX : (917) 286-5402

Northeastern Region:

225 Sand Road,
Fairfield, New Jersey 07004-0008
TEL : (973) 808-8444
FAX : (973) 882-4401

Midwestern Region:

201 Hansen Court Suite 119
Wood Dale, Illinois 60191
TEL : (630) 238-9982
FAX : (630) 238-9487

Western Region:

14101 Alton Parkway,
Irvine, California 92618-7006
TEL : (949) 457-9000
FAX : (949) 457-9119

Southeastern Region:

1500 Oakbrook Drive,
Norcross, Georgia 30093
TEL : (770) 729-9786
FAX : (770) 729-9873

Southwestern Region:

2825 West Story Road,
Irving, Texas 75038-5299
TEL : (972) 550-8987
FAX : (972) 252-9786

National Operation Center & National Training Center:

2825 West Story Road,
Irving, Texas 75038-5299
TEL : (972) 659-0055
FAX : (972) 570-5816

Latin America Division:

8240 N.W. 52nd. Terrace Dawson Building,
Suite 108 Miami, Florida 33166
TEL : (305) 421-6640
FAX : (305) 421-6666

KYOCERA MITA CANADA, LTD.

6120 Kestrel Road, Mississauga,
Ontario L5T 1S8, Canada
TEL : (905) 670-4425
FAX : (905) 670-8116

KYOCERA MITA MEXICO, S.A. DE C.V.

Av. 16 de Septiembre #407
Col. Santa Inés,
Azcapotzalco México,
D.F. 02130, México
TEL : (55) 5383-2741
FAX : (55) 5383-7804