

SAMSUNG

LASER PRINTER


ML-3050 Series

ML-3051N/XAA

Basic Model : ML-3050

SERVICE *Manual*

LASER PRINTER



The keynote of Product

- Speed: Up to 28ppm (Ltr. 30ppm),
1200x1200dpi Effective output
- Paper Path: MPF Type Cassette
- Emulation: PCL6, PS3
- CPU: SPGPv3
- Memory: 16~64MB Standard
- Cassette: 250 sheet Cassette
- MP: 50 sheet MP
- Lan: 10/100 Base TX (ML-3051N, ML-3051ND)
- I/O: USB 2.0, IEEE1284
- Toner: 8K Toner (4K initial)
- Option: 802.11b/g Wireless N/W,
250 sheet Opt. SCF
- Duplex: Built in Duplex
(ML-3051ND)

TONER

www.tonerplus.com.ua





* This service manual is a property of Samsung Electronics Co., Ltd.
Any unauthorized use of Manual can be punished under applicable
international and/or domestic law.

* This service manual is also provided on the web, the ITSELF
system Samsung Electronics Co., Ltd.

<http://itself.sec.samsung.co.kr>

© Samsung Electronics Co., Ltd. February, 2006
Printed in Korea.

VERSION NO. : 1.01

CODE : JC-0161C



Contents

1. Precautions

1.1 Safety Warning	1-1
1.2 Safety Caution	1-2
1.3 ESD Precautions	1-4

2. Product Specification

2.1 Product Overview	2-1
2.2 Specifications	2-2

3. System Overview

3.1 System Construction	3-1
3.2 Mechanical Parts Specifications	3-6
3.3 Engine H/W Specifications	3-15
3.4 S/W Descriptions	3-31

4. Alignment and Adjustments

4.1 Sample Pattern	4-1
4.2 Control Panel	4-2
4.3 Consumables and Replacement Parts	4-7
4.4 LED Status Error Message	4-7
4.5 Abnormal Image Printing and Defective Roller	4-10
4.6 How to use DCU	4-11
4.7 Paper Path	4-16
4.8 Download & Reset F/W	4-28

Continued

5. Disassembly and Reassembly

- 5.1 General Precautions on Disassembly 5-1
- 5.2 Disassembly and Reassembly 5-2

6. Troubleshooting

- 6.1 The cause and solution of Bad image 6-1
- 6.2 The cause and solution of the bad discharge 6-8
- 6.3 The cause and solution of the malfunction 6-13
- 6.4 Toner Cartridge Service 6-19
- 6.5 The cause and solutions of bad environment of the software . . 6-27

7. Exploded Views & Parts List

- 7.1 Main 7-2
- 7.2 Cover Ass'y 7-4
- 7.3 Front Cover Ass'y 7-6
- 7.4 Rear Cover Ass'y 7-8
- 7.5 OPE Cover Ass'y 7-9
- 7.6 Frame 7-10
- 7.7 MP Ass'y 7-14
- 7.8 Main Drive Ass'y 7-16
- 7.9 Fuser Drive Ass'y 7-18
- 7.10 Duplex Unit (Optional) 7-19
- 7.11 Fuser Unit 7-21
- 7.12 Cassette Unit 7-23

8. Block diagram

- 8.1 System Block Diagram 8-1
- 8.2 System Timing Chart 8-2

Continued

9. Connection Diagram

9.1 Connection Diagram	9-1
----------------------------------	-----

10. Schematic Diagram

10.1 Main Board	10-1
10.2 OPE LCD	10-14
10.3 OPE LED	10-15
10.4 SMPS 110V	10-16
SMPS 220V	10-17
10.5 HVPS	10-18

11. Reference Information

11.1 Troubleshooting Tools	11-1
11.2 Acronyms and Abbreviations	11-2
11.3 Selecting printer locations	11-4
11.4 Sample Tests Patterns	11-5

12. Series model solution(ML-3050 and SCX-5530FN)

