

SAMSUNG

DIGITAL LASER MFP

SCX-6122FN/XAX

Basic Model : SCX-6322DN

SERVICE *Manual*

DIGITAL LASER MFP



The keynote of Product

[Key Features]

1. General Spec
 - CPU : 240 MHz Chorus-M
 - Memory : 64MB SDRAM
 - USB2.0, IEEE1284, Ethernet 10/100 base TX
 - Toner: 8K (Std.) / Drum : 20K
 - 50sh DADF (SCX-6322DN), 40sh ADF (SCX-6122FN)
 - 550sh x 1 Tray (Max.550sh x 2 Tray), 100sh MP Tray
 - Machine Life : 300K pages
2. Copying
 - 20cpm/Ltr. (SCX-6322DN),
17cpm/Ltr. (SCX-6122FN)
 - 600 x 600dpi, 25-400% Zoom Copy
3. Printing
 - 23ppm /Ltr., 1200dpi Effective output Quality
 - PCL6, PS3, Duplex Standard
4. Scan
 - Scan to Email/SMB/FTP, 20 Sec.(Gray) Scan speed
 - JPEG, TIFF, PDF
5. FAX
 - 33.6Kbps, PC-FAX
 - Send from Local/Remote PC
 - Fax forward to Folder
6. Options
 - 2nd Tray (550sh)

www.tonerplus.com.ua





ELECTRONICS

* This service manual is a property of Samsung Electronics Co., Ltd.
Any unauthorized use of Manual can be punished under applicable
international and/or domestic law.

© Samsung Electronics Co., Ltd. August. 2006
Printed in Korea.
VERSION NO. : 1.00 CODE : JC-0174L

www.tonerplus.com.ua



Contents

1. Precautions

1.1 Safety Warning	1-1
1.2 Caution for safety	1-2
1.3 ESD Precautions	1-5
1.4 Super Capacitor or Lithium Battery Precautions	1-5

2. Product Specification

2.1 Product Overview	2-1
2.2 Product Specification	2-1
2.3 Model Comparison Table	2-8

3. System Overview

3.1 System Construction	3-1
3.2 Engine H/W	3-5

4. Alignment and Adjustments

4.1 Paper path	4-1
4.2 Clearing Paper Jams	4-2
4.3 User Mode	4-10
4.4 Tech Mode	4-13
4.5 Flash Upgrade	4-22
4.6 Abnormal Image Printing and Defective Roller	4-24
4.7 Error Messages	4-25

Continued

5. Disassembly and Reassembly

5.1 General Precautions on Disassembly	5-1
5.2 Rear Cover	5-1
5.3 Scanner Ass'y	5-2
5.4 DADF Ass'y	5-7
5.5 OPE Ass'y	5-11
5.6 Side Cover Ass'y	5-12
5.7 Fuser Ass'y	5-14
5.8 Exit Ass'y	5-15
5.9 Cover Paper Exit Ass'y	5-15
5.10 Drive Ass'y	5-16
5.11 SMPS	5-17
5.12 LSU (Laser Scanning Unit)	5-18
5.13 Cover Exit Rear	5-18
5.14 Main Frame Ass'y	5-19
5.15 MP Ass'y	5-20
5.16 Feed Ass'y	5-21
5.17 Pick Up Ass'y	5-22
5.18 Main PBA	5-23

6. Troubleshooting

6.1 Procedure of Checking the Symptoms	6-1
6.2 Solution	6-2

Continued

7. Setting Guide

7.1 Printer overview	7-1
7.2 Understanding the Status LED	7-4
7.3 Finding more information	7-5
7.4 System setup	7-6
7.5 Network setup	7-12

8. Exploded Views & Parts List

8.1 Main	8-2
8.2 Housing Scanner	8-5
8.3 OPE Cover	8-7
8.4 Platen Cover Ass'y	8-9
8.5 ADF Ass'y	8-12
8.6 DADF Ass'y	8-15
8.7 DADF Platen Cover Ass'y	8-17
8.8 DADF SUB Ass'y	8-19
8.9 Side Cover Ass'y	8-22
8.10 Cassette Ass'y	8-24
8.11 Exit Ass'y	8-26
8.12 Feeder Ass'y	8-28
8.13 MP Ass'y	8-30
8.14 Base Frame	8-32
8.15 Pick-up Ass'y	8-34
8.16 Drive Ass'y	8-36
8.17 Main Frame Ass'y	8-38
8.18 FuserAss'y	8-40
8.19 SCF Unit(Optional Cassette)	8-48

Continued

9. Block diagram

9.1 SCX-6122FN Block Diagram	9-1
9.2 SCX-6322DN Block Diagram	9-2

10. Connection Diagram

10.1 SCX-6122FN Connection Diagram	10-1
10.2 SCX-6322DN Connection Diagram	10-2

11. Schematic Diagram

11.1 Main board	11-1
11.2 DADF	11-12
11.3 OPE	11-15
11.4 HVPS	11-17
11.5 Modular board	11-21

12. Reference Information

12.1 Tool for Troubleshooting	12-1
12.2 Acronyms and Abbreviations	12-2
12.3 The Sample Pattern for the Test	12-7
12.4 Wireless LAN	12-8
12.5 Selecting a location	12-9