

Installation Instructions for the Phaser® 3100MFP System Software 2.07t General Release



Release Date: July 26, 2011

dc11cd016

Before Getting Started

1. The Xerox Companion Suite software application must be installed on a PC in able to perform the firmware update.
 - The application can be found on the CD that was included with the product box, or
 - The application can also be found on the Xerox support site by [clicking here](#). The web package contains the Xerox Companion Suite, Windows 7 drivers, and utilities.
2. The firmware .zip file must be extracted to a known location.

Installation Instructions

1. Start the Xerox Companion Suite by selecting
Start → All Programs → Xerox Companion Suite → Phaser 3100 MFP → Companion - Firmware Update
2. At the Firmware Update window select the folder/magnifying glass icon and browse to the location where the .zip file was extracted.
3. Select the file named **firmware_boot_v3_01.fwf**
4. Select the **Start upload** button.
5. Select **OK** at the Information window warning you not to power off the machine during the firmware upload. This will cause the firmware to download and the progress window to appear.
6. When firmware upgrade is complete the machine will cycle with check date on the local display indicating firmware upgrade is complete.
7. Within the Xerox Companion Suite select the folder/magnifying glass icon and browse to the location where the .zip file was extracted.
8. Select the Firmware appropriate to your model.
 - For a model with fax select **firmware_3100x_v2_07t.fwf**
 - For a model with no fax select **firmware_3100s_v2_07t.fwf**
9. Select the **Start upload** button.
10. Select **OK** at the Information window warning you not to power off the machine during the firmware upload. This will cause the firmware to download and the progress window to appear.
11. When firmware upgrade is complete the machine will cycle with check date on the local display indicating firmware upgrade is complete.
12. Select the Versions Information button within he Firmware Update windows to confirm the new software level is at 2.07m.

Scanner Calibration

After a firmware upgrade a scanner calibration needs to be performed.

1. At the device Press the **[Down]** arrow (Menu) button on the Control Panel.
2. Press **[8]**, then **[0]** using the numeric keypad. "**Advanced Fct / Calibration**" will be displayed.
3. Press the **[OK]** button. The machine will automatically perform calibration.

© 2011 Xerox Corporation. All Rights Reserved. XEROX®, XEROX and Design®, and Phaser® are trademarks of Xerox Corporation in the United States and/or other countries.