

PARTS CATALOG

SELPHY CP710



© CANON INC., 2005

CONTENTS

SELPHY CP710

Casing Parts -----	Pg1
Top Cover Section -----	Pg2
Accessories -----	Pg3

CLASS凡例

- A: 使用頻度 高
- B: 使用頻度 中
- C: 使用頻度 低
- D: 安全規格部品
- E: 消耗部品
- F: 標準ネジ、ワッシャー
- S: 供給制限品
- Y: サービス工具


Category of CLASS

- A: Frequency of use: High
- B: Frequency of use: Middle
- C: Frequency of use: Low
- D: Safety-related critical parts
- E: Consumable parts
- F: Standard screws and washers
- S: Supply of the parts is limited
- Y: Service Tools

CAUTION

⚠ がついている部品は安全上重要な部品です。交換時は、必ず指定の部品を使用してください。
Especially critical parts in the power circuit block should not be replaced with other marks.
Critical parts are marked with ⚠ in this parts list


Casing Parts



PARTS LIST

NEW	SYMBOL	PARTS NO.	CLASS	QTY	DESCRIPTION	REMARKS
	1	CY6-3281-000	B	1	SEAL, SCREW HOLE COVER	
*	2	CY6-3286-000	B	1	DOOR, PAPER CASSETTE	
	3	CY6-3283-000	B	1	FPC, MAIN-SW	
*	4	CY7-1340-000	C	1	PCB ASS'Y, SW	
*	5	CY7-1339-000	C	1	PCB ASS'Y, MAIN	
	6	CY6-3279-000	C	1	COVER, USB	
	7	CY6-3278-000	B	1	COVER, I/F	
*	8	CY7-1337-000	B	1	COVER ASS'Y, BOTTOM	
	9	CY6-3280-000	C	1	HOOK, INK CASSETTE DOOR	
*	10	CY7-1338-000	B	1	CASE ASS'Y, BATTERY	
*	11	CY6-3287-000	B	1	COVER, BATTERY CASE	
*	12	CY6-3285-000	B	1	DOOR, INK CASSETTE	
*	13	CY6-3284-000	C	1	LABEL, SERIAL	
	101	CY6-3219-000	C	3	SCREW	
	102	CY6-3220-000	C	2	SCREW	
	103	CY6-3239-000	C	4	SCREW	
	104	CY6-3245-000	C	1	SCREW	

Top Cover Section





P A R T S L I S T


NEW	SYMBOL	PARTS NO.	CLASS	QTY	DESCRIPTION	REMARKS
*	1	CY6-3292-000	C	1	COVER, SHIELD	
*	2	CY6-3288-000	B	1	FPC, OP	
*	3	CY7-1342-000	B	1	LCD UNIT	
*	4	CY6-3282-000	C	1	CUSHION, LCD	
*	5	CY6-3290-000	B	1	BUTTON, PRINT	
*	6	CY6-3291-000	B	1	COVER, BUTTON (PRINT)	
*	7	CY7-1336-000	B	1	COVER ASS'Y, TOP	
*	8	CY6-3289-000	B	1	BUTTON, CROSS	
*	9	CY7-1341-000	B	1	PCB ASS'Y, OP	
	101	CY6-3239-000	C	5	SCREW	

Accessories



Paper Cassette




Cover




AC Cable, Power Adapter



Canon Printer Solution Disk



Cleaning Cassette



N.S : N.S Stand for No Stock

PARTS LIST

NEW	SYMBOL	PARTS NO.	CLASS	QTY	DESCRIPTION	REMARKS
	1	C86-1036-000	B	1	CASSETTE, C-SIZE PAPER	FOR ALL
	2	C86-1034-000	B	1	CASSETTE, L-SIZE PAPER	FOR JAPAN, CHINA
		C86-1035-000	B	1	CASSETTE, P-SIZE PAPER	FOR USA, CANADA, EUROPE, AUSTRALIA, ASIA
*	3	CZ5-6117-000	B	1	COVER	FOR ALL
	4	C86-1049-000	B	1	POWER ADAPTER, CA-CP200	FOR ALL
	5	D82-0641-000	C	1	CABLE, AC, JAPAN	FOR JAPAN
	6	WT3-5063-000	C	1	AC CABLE(N), FOR BC-15N	FOR USA, CANADA
	7	D82-0643-000	C	1	CABLE, AC, EUROPE	FOR EUROPE, ASIA
	8	D82-0644-000	C	1	CABLE, AC, UK	FOR ASIA
	9	D82-0645-001	C	1	CABLE, AC, AUSTRALIA	FOR AUSTRALIA
	10	WT3-5087-000	C	1	CABLE, AC, CHINA	FOR CHINA
	11	CD3-1701-000	E	1	CASSETTE, CLEANING	FOR ALL