

# MX700

## PARTS CATALOG

REVISION 0



2186B002AA	MX700 / 120V(US)
2186B003AA	MX700 / 120V(CA)
2186B004AA	MX700 / 120V-240V(LAM)
2186B006AB	MX700 / 220V-240V(FR)
2186B007AA	MX700 / 220V-240V(EMB)
2186B008AA	MX700 / 220V-240V(GB/NEU)
2186B009AA	MX700 / 220V-240V(CEU)
2186B010AA	MX700 / 220V-240V(WEU)
2186B011AA	MX700 / 220V-240V(AU)
2186B012AA	MX700 / 220V-240V(ASA)
2186B013AA	MX700 / 220V-240V(HK)
2186B014AA	MX700 / 220V-240V(CN)
2186B015AA	MX700 / 100V-120V(TW)
2186B016AA	MX700 / 220V-240V(KR)

AUG. 2007

**QY8-31D7-000**

COPYRIGHT © 2007 CANON INC. CANON MX700 0708 N 0.00-0

---

## **Application**

This manual has been issued by Canon Inc. for qualified person to learn technical theory, installation, maintenance, and repair of products. This manual covers all localities where the products are sold. For this reason, there may be information in this manual that does not apply to your locality.

## **Corrections**

This manual could include technical inaccuracies or typographical errors due to improvements or changes in the products. When changes occur in applicable products or in the content of this manual, Canon will release technical information as the need arises. In the event of major changes in the contents of this manual over a long or short period, Canon will issue a new editions of this manual. The following paragraph does not apply to any countries where such provisions are inconsistent with local law.

## **Trademarks**

The product names and company names described in this manual are the registered trademarks of the individual companies.

## **Copyright**

This manual is copyrighted with all rights reserved. Under the copyright laws, this manual may not be copied, reproduced or translated into another language, in whole or in part, without the written consent of Canon Inc.

Copyright © 2007 by Canon Inc.

CANON INC.

Inkjet Device Quality Assurance Div. 2

451, Tsukagoshi, 3-chome, Saiwai-ku, Kawasaki-shi, Kanagawa 212-8530, Japan

This manual was created under Microsoft® Windows® 2000.

Parts layout pictures were edited using Adobe® Photoshop® 7.0. KEY No. were created using Adobe® Illustrator® 10.

HTML files were created using Microsoft® FrontPage® 2000.

---

## ABOUT THIS MANUAL

### A. ILLUSTRATION INDEX

For illustration index, the parts layout illustrations in this parts catalog are listed in abbreviated form in order of illustration number to identify the pages they appear on. To find an illustration of a part, see the ILLUSTRATION INDEX.

### B. PARTS LAYOUT & PARTS LIST

Parts layout illustration

#### a) Parts search

Find a part from the parts layout illustration and find its key number from the parts list to identify the part number and name. For screws, nuts, washers, lock washers, pins, spacers, see SCREWS & WASHERS LIST.

**Note:** If parts have the same or similar shape but different specifications, their key number is assigned to several part numbers and names in the parts list.

#### b) Parts replacement procedure

To replace parts, the parts layout illustrations have figure numbers according to the disassembly procedure of the product. The parts that require careful work are shown the illustration.

Parts list

#### a) FIGURE & KEY No.

The FIGURE & KEY No. column corresponds to the key numbers assigned to the parts in the parts layout illustration.

#### b) PART NUMBER

The PART NUMBER column gives the part numbers corresponding to the key numbers. To order a part, indicate the part number clearly.

**Note:** Parts marked NPN are not service parts.

#### c) RANK

The service parts with N in the RANK column are order parts.

#### d) QTY

The QTY column gives the number of parts in the corresponding components layout illustration.

#### e) DESCRIPTION

The DESCRIPTION column gives the part names in English.

To order a part, indicate the part name, too.

### C. OPTIONS & CONSUMABLES

These are illustrations and a list of units that can be used as optional consumable equipments.

### D. SCREWS & WASHERS LIST

This is a list of screws, nuts, washers, lock washers, pins, and spacers.

The QTY column does not give the number of parts used.

### E. TOOL LIST

This is a list of tools used for servicing products.

### F. NUMERICAL INDEX

All the parts listed in this parts catalog are arranged in order of part number. You can identify part locations and names from the NUMERICAL INDEX.

# Contents

## A. ILLUSTRATION INDEX ▶

## B. PARTS LAYOUT & PARTS LIST

**FIGURE 1** PRINTER & PRINT HEAD

**FIGURE 2** EXTERNAL COVERS

**FIGURE 3** ADF UNIT & SCANNER UNIT

**FIGURE 4** MAIN CASE UNIT

**FIGURE 5** LOGIC BOARD & CARD BOARD

**FIGURE 6** BOTTOM CASE UNIT & INK ABSORBER

**FIGURE 7** SHEET FEED UNIT

**FIGURE 8** CARRIAGE UNIT & PURGE UNIT

**FIGURE 9** PAPER FEED PART

## C. OPTION & CONSUMABLES ▶

## D. SCREW & WASHER LIST ▶

## E. TOOL ▶

## F. NUMERICAL INDEX ▶

**This page intentionally left blank**

# A. ILLUSTRATION INDEX

Contents NUMERICAL INDEX

FIGURE 1 PRINTER & PRINT HEAD



FIGURE 2 EXTERNAL COVERS




FIGURE 3 ADF UNIT & SCANNER UNIT




FIGURE 4 MAIN CASE UNIT




FIGURE 5 LOGIC BOARD & CARD BOARD




FIGURE 6 BOTTOM CASE UNIT & INK ABSORBER




FIGURE 7 SHEET FEED UNIT




FIGURE 8 CARRIAGE UNIT & PURGE UNIT




FIGURE 9 PAPER FEED PART





FIGURE 10 OPTION & CONSUMABLES



FIGURE 11 TOOL



## B. PARTS LAYOUT & PARTS LIST

[Contents](#)

[ILLUSTRATION INDEX](#)

[NUMERICAL INDEX](#)



**FIGURE 1 PRINTER & PRINT HEAD**

**TONER**  
[www.tonerplus.com.ua](http://www.tonerplus.com.ua)





FIGURE & KEY No.		PART NUMBER	RANK	QTY	DESCRIPTION	REMARKS
1-	1	QY6-0070-000		1	PRINTER HEAD	
	2	QH2-2716-000		1	CORD, POWER	220V-240V(EUM, EMB, ASA, MY)
	2	QH2-2719-000		1	CORD, POWER	100V-120V
	2	QK1-0776-000		1	CORD, POWER	220V-240V(AU)
	2	QK1-2017-000		1	CORD, POWER	100V-120V(TW)
	2	QK1-3048-000		1	CORD, POWER	120V-240V(LAM, CHN)
	2	WT3-5156-000		1	CORD, POWER	220V-240V(GB, HK)
	2	WT3-5160-000		1	CORD, POWER	220V-240V(KR)
	3	QC2-6430-000		1	STICKER, PANEL	CA
	4	QC2-5341-000		1	STICKER, PANEL	EMB, FR, GB/NEU, CEU, WEU

FIGURE 2 EXTERNAL COVERS




FIGURE & KEY No.		PART NUMBER	RANK	QTY	DESCRIPTION	REMARKS
2-	1	QM3-2669-000		1	FRONT TRAY UNIT	
	2	QC1-9024-000		1	EMBLEM	FOR OTHER REGIONS
	2	QC2-4900-000		1	EMBLEM	FOR FRANCE
	3	QC2-6160-000		1	FRONT PANEL L	
	4	QM3-2667-000		1	SIDE COVER L UNIT	
	5	QK1-3928-000		1	CAP, TEL CONNECTOR	
	6	QC2-6416-000		1	CAP, LAN CONNECTOR	
	7	QC2-6157-000		1	FRONT PANEL R	
	8	QM3-2682-000		1	PANEL SUPPORT R UNIT	
	9	QM3-2666-000		1	SIDE COVER R UNIT	
	10	QC2-5615-000		1	COVER, REAR	
	11	QC2-6075-000		1	COVER, ASF UNDER	
	12	QM3-2668-000		1	ASF TRAY UNIT	

FIGURE 3 ADF UNIT & SCANNER UNIT




FIGURE & KEY No.		PART NUMBER	RANK	QTY	DESCRIPTION	REMARKS
3-	1	QC2-4884-000		1	SHEET, DOCUMENT PRESSURE	
	2	QL2-2214-000		1	DF FRONT PANEL ASS'Y	
	3	QC2-6164-000		1	COVER, DF FRONT DECO	
	4	QC2-6167-000		1	COVER, TOP	
	5	QC2-5324-000		1	DF STOP ARM	
	6	QC2-6165-000		1	COVER, REAR	
	7	QM3-2674-000		1	DOCUMENT FEED UNIT	
	8	QC2-6130-000		1	TRAY, DF	
	9	QC2-6168-000		1	COVER, ACCESS	
	10	QC2-5485-000		2	SPRING, DF EJECT BACKUP	
	11	QC2-5484-000		2	ROLLER, DF EJECT BACKUP	
	12	QC2-5498-000	N	1	SHAFT, DF EJECT BACKUP	
	13	QC2-5366-000		1	GUIDE, DF CABLE	
	14	QC2-5430-000		2	ADF HINGE	
	15	QC2-6162-000		1	DF BASE	
	16	QM3-2890-000		1	DAMPER UNIT, SCANNER	
	17	QC2-5363-000		1	GEAR, DAMPER RACK	
	18	QC2-6171-000		1	STAY, SCANNER	
	19	QC2-5509-000		1	SPRING, SCANNER STAY	
	20	QC2-6174-000		1	COVER, PANEL R	US, CA, AU, ASA
	20	QC2-6423-000		1	COVER, PANEL R	LAM, FR, EMB, GB/NEU, CEU, WEU
	20	QC2-6425-000		1	COVER, PANEL R	HK, TW
	20	QC2-6427-000		1	COVER, PANEL R	CN
	20	QC2-6429-000		1	COVER, PANEL R	KR
	21	QC2-6173-000		1	COVER, PANEL L	US, CA, AU, ASA
	21	QC2-6422-000		1	COVER, PANEL L	LAM, FR, EMB, GB/NEU, CEU, WEU
	21	QC2-6424-000		1	COVER, PANEL L	HK, TW
	21	QC2-6426-000		1	COVER, PANEL L	CN
	21	QC2-6428-000		1	COVER, PANEL L	KR
	22	QM3-2670-000		1	OPERATION PANEL UNIT	
	23	QC2-6186-000		1	UPPER COVER, LCD	
	24	QC2-6190-000		1	WINDOW, LCD	
	25	QM3-2671-000		1	LCD UNIT	
	26	QM3-2672-000		1	SCANNER UNIT	

FIGURE 4 MAIN CASE UNIT




FIGURE & KEY No.		PART NUMBER	RANK	QTY	DESCRIPTION	REMARKS
4-	1	QC2-6172-000		1	SHEET, SCANNER	
	2	QL2-2213-000		1	MIDDLE FRAME ASS'Y	
	3	QM3-2833-000		1	COVER SW HARNESS UNIT	
	4	QC2-5716-000		1	TRAY, OUTPUT	
	5	QM3-4291-000		1	DAMPER UNIT, FRONT	
	6	QC2-6412-000		1	GEAR, FRONT DAMPER	



**FIGURE 5 LOGIC BOARD & CARD BOARD**







FIGURE & KEY No.		PART NUMBER	RANK	QTY	DESCRIPTION	REMARKS
5-	1	QK1-3520-000		1	AC ADAPTER: 100V-240V 50/60HZ	
	2	QM3-2824-000		1	DC HARNESS UNIT	
	3	QC2-5689-000		1	GUIDE, FFC	
	4	QK1-3807-000		1	FFC, MAIN CARD	
	5	QK1-3945-000		1	PICTBRIDGE HARNESS UNIT	
	6	QC2-5772-000		1	PLATE, CARD FACE	
	7	QM3-2835-000		1	CARD BOARD ASS'Y	
	8	QC2-6143-000		1	COVER, NCU	
	9	QM3-2834-000		1	LOGIC BOARD ASS'Y	
	10	QM3-2571-000		1	PE SENSOR BOARD ASS'Y	
	11	QC2-6142-000		1	COVER, MODULAR JACK	
	12	QM3-2811-000		1	MODULAR PCB UNIT	
	13	QC2-6146-000		1	HOLDER, SPEAKER	
	14	QM3-2828-000		1	SPEAKER HARNESS UNIT	
	15	QM3-2572-000		1	TIMING SENSOR ASS'Y	
	16	QM3-2820-000		1	SPEAKER RELAY HARNESS	
	17	QM3-2818-000		1	MODULAR HARNESS UNIT	
	18	QM3-2577-000		1	LF PE SENSOR HARNESS	
	19	QM3-2813-000		1	ADF SENSOR HARNESS	
	20	QM3-2821-000		1	ADF MOTOR HARNESS UNIT	

**FIGURE 6 BOTTOM CASE UNIT & INK ABSORBER**




**S4**  
 8mm  
 Metal  
 M3  
 (Self Tap)

FIGURE & KEY No.		PART NUMBER	RANK	QTY	DESCRIPTION	REMARKS
6-	1	QC2-5614-000		1	COVER, ABSORBER	
	2	QY5-0192-000		1	ABSORBER KIT	Including in Key No. 9-5.
	3	QM3-2665-000		1	BASE CASE UNIT	

**FIGURE 7 SHEET FEED UNIT**




FIGURE & KEY No.		PART NUMBER	RANK	QTY	DESCRIPTION	REMARKS
7-	1	QM3-2677-000		1	SHEET FEED UNIT	
	2	QM3-2576-000		1	ASF-PG ENC HARNESS	

**FIGURE 8 CARRIAGE UNIT & PURGE UNIT**






FIGURE & KEY No.		PART NUMBER	RANK	QTY	DESCRIPTION	REMARKS
8-	1	QM3-2664-000		1	SPUR BASE UNIT	
	2	QC1-9614-000		1	SPRING, EARTH	
	3	QL2-2209-000		1	IDLER PURRY ASS'Y	
	4	QC2-3234-000		1	SPRING, COIL	
	5	QC2-5688-000		1	SPRING, LEAF	
	6	QC2-5687-000		1	FILM, TIMING SLIT STRIP	
	7	QC2-5675-000		1	RAIL, CARRIAGE	
	8	QM3-2650-000		1	CARRIAGE UNIT	
	9	WE8-5973-000		1	CORE	
	10	QM3-2651-000		1	PURGE UNIT	
	11	QK1-1500-000		1	MOTOR, CARRIAGE	
	12	QM3-2589-000		1	CR-PG MOTOR HARNESS	
	13	QC2-5691-000		1	LEVER, AP-PG ARM	
	14	QC2-5692-000		1	SPRING, AP-PG ARM	

FIGURE 9 PAPER FEED PART



**S6**  
 3mm  
 Metal  
 M2.6  
 (Self tap)








FIGURE & KEY No.		PART NUMBER	RANK	QTY	DESCRIPTION	REMARKS
9 -	1	QK1-3849-000		1	MOTOR, PAPER FEED	
	2	QM3-2826-000		1	LF MOTOR HARNESS UNIT	
	3	QL2-2205-000		1	EJECT ROLLER ASS'Y	
	4	QC2-5665-000		1	PLATEN	
	5	NPN		1	ABSORBER, INK	Included in Key No. 6-2.
	6	QC2-6103-000		2	SPRING, PLATEN	
	7	QL2-2206-000		1	PAPER FEED ROLLER ASS'Y	
	8	QC1-9598-000		1	BELT, PAPER FEED	
	9	QC1-9612-000		1	FLANGE, LF PULLEY	
	10	QC1-9597-000		1	FILM, TIMING SLIT DISK	
	11	QC2-5664-000		1	BUSHING, PAPER FEED ROLLER R	
	12	QM3-2649-000		1	PRESSURE ROLLER ASS'Y	
	13	QC1-9600-000		5	SPRING, TORSION	
	14	QC1-9613-000		1	GEAR, EJECT IDLER	



FIGURE 10 OPTION & CONSUMABLES



FIGURE & KEY No.		PART NUMBER	RANK	QTY	DESCRIPTION	REMARKS
10-	1	NPN		1	BLACK INK TANK PGI-5BK	CONSUMABLES
		NPN		1	YELLOW INK TANK CLI-8Y	CONSUMABLES
		NPN		1	MAGENTA INK TANK CLI-8M	CONSUMABLES
		NPN		1	CYAN INK TANK CLI-8C	CONSUMABLES

## D. SCREW & WASHER LIST

[Contents](#)
[NUMERICAL INDEX](#)

FIGURE & KEY No.		PART NUMBER	RANK	QTY	DESCRIPTION	REMARKS
S-	1	XB4-7300-805			SCREW, TP, BH3X8	
	2	XB4-7300-809			SCREW, TAP, BINDING HEAD, M3X8	
	3	XB1-2300-405			SCREW, MACH.BH, M3X4	
	4	XA9-1756-000			SCREW, TP, M3X8	
	5	XB4-7300-605			SCREW, BH M3X6	
	6	XB1-2260-305			SCREW, MACH. TRUSS HEAD, M2.6X3	
	7	XA9-1646-000			SCREW, TP, M3X4	
	8	XA9-1755-000			SCREW, B-TIGHT M1.7X10	
	9	XB4-7401-005			SCREW,TAPPIG,TRUSS HEAD,M4X10	
	10	XB4-7301-009			SCREW, B-TIGHT: M3 X 10 MM	
	11	XB6-7300-605			SCREW, MACHINE, TP, M3X6	

**This page intentionally left blank**

FIGURE 11 TOOL




FIGURE & KEY No.		PART NUMBER	RANK	QTY	DESCRIPTION	REMARKS
T-	1	QY9-0057-000		1	LUBE, FLOIL KG107A, OIL	
	2	CK-8006-000		1	LUBE, ELECTRICITY GREASE IF-20	
	3	CK-0562-000		1	GREASE, MOLYKOTE PG-641	

# F. NUMERICAL INDEX

Contents ILLUSTRATION INDEX

PART NUMBER	FIGURE & KEY No.	DESCRIPTION	PART NUMBER	FIGURE & KEY No.	DESCRIPTION
CK-0562-000	T- 3	GREASE, MOLYKOTE PG-641	QK1-0776-000	1- 2	CORD, POWER
CK-8006-000	T- 2	LUBE, ELECTRICITY GREASE IF-20	QK1-1500-000	8- 11	MOTOR, CARRIAGE
QC1-9024-000	2- 2	EMBLEM	QK1-2017-000	1- 2	CORD, POWER
QC1-9597-000	9- 10	FILM, TIMING SLIT DISK	QK1-3048-000	1- 2	CORD, POWER
QC1-9598-000	9- 8	BELT, PAPER FEED	QK1-3520-000	5- 1	AC ADAPTER: 100V-240V 50/60HZ
QC1-9600-000	9- 13	SPRING, TORSION	QK1-3807-000	5- 4	FFC, MAIN CARD
QC1-9612-000	9- 9	FLANGE, LF PULLEY	QK1-3849-000	9- 1	MOTOR, PAPER FEED
QC1-9613-000	9- 14	GEAR, EJECT IDLER	QK1-3928-000	2- 5	CAP, TEL CONNECTOR
QC1-9614-000	8- 2	SPRING, EARTH	QK1-3945-000	5- 5	PICTBRIDGE HARNESS UNIT
QC2-3234-000	8- 4	SPRING, COIL	QL2-2205-000	9- 3	EJECT ROLLER ASS'Y
QC2-4884-000	3- 1	SHEET, DOCUMENT PRESSURE	QL2-2206-000	9- 7	PAPER FEED ROLLER ASS'Y
QC2-4900-000	2- 2	EMBLEM	QL2-2209-000	8- 3	IDLER PURRY ASS'Y
QC2-5324-000	3- 5	DF STOP ARM	QL2-2213-000	4- 2	MIDDLE FRAME ASS'Y
QC2-5341-000	1- 4	STICKER, PANEL	QL2-2214-000	3- 2	DF FRONT PANEL ASS'Y
QC2-5363-000	3- 17	GEAR, DAMPER RACK	QM3-2571-000	5- 10	PE SENSOR BOARD ASS'Y
QC2-5366-000	3- 13	GUIDE, DF CABLE	QM3-2572-000	5- 15	TIMING SENSOR ASS'Y
QC2-5430-000	3- 14	ADF HINGE	QM3-2576-000	7- 2	ASF-PG ENC HARNESS
QC2-5484-000	3- 11	ROLLER, DF EJECT BACKUP	QM3-2577-000	5- 18	LF PE SENSOR HARNESS
QC2-5485-000	3- 10	SPRING, DF EJECT BACKUP	QM3-2589-000	8- 12	CR-PG MOTOR HARNESS
QC2-5498-000	3- 12	SHAFT, DF EJECT BACKUP	QM3-2649-000	9- 12	PRESSURE ROLLER ASS'Y
QC2-5509-000	3- 19	SPRING, SCANNER STAY	QM3-2650-000	8- 8	CARRIAGE UNIT
QC2-5614-000	6- 1	COVER, ABSORBER	QM3-2651-000	8- 10	PURGE UNIT
QC2-5615-000	2- 10	COVER, REAR	QM3-2664-000	8- 1	SPUR BASE UNIT
QC2-5664-000	9- 11	BUSHING, PAPER FEED ROLLER R	QM3-2665-000	6- 3	BASE CASE UNIT
QC2-5665-000	9- 4	PLATEN	QM3-2666-000	2- 9	SIDE COVER R UNIT
QC2-5675-000	8- 7	RAIL, CARRIAGE	QM3-2667-000	2- 4	SIDE COVER L UNIT
QC2-5687-000	8- 6	FILM, TIMING SLIT STRIP	QM3-2668-000	2- 12	ASF TRAY UNIT
QC2-5688-000	8- 5	SPRING, LEAF	QM3-2669-000	2- 1	FRONT TRAY UNIT
QC2-5689-000	5- 3	GUIDE, FFC	QM3-2670-000	3- 22	OPERATION PANEL UNIT
QC2-5691-000	8- 13	LEVER, AP-PG ARM	QM3-2671-000	3- 25	LCD UNIT
QC2-5692-000	8- 14	SPRING, AP-PG ARM	QM3-2672-000	3- 26	SCANNER UNIT
QC2-5716-000	4- 4	TRAY, OUTPUT	QM3-2674-000	3- 7	DOCUMENT FEED UNIT
QC2-5772-000	5- 6	PLATE, CARD FACE	QM3-2677-000	7- 1	SHEET FEED UNIT
QC2-6075-000	2- 11	COVER, ASF UNDER	QM3-2682-000	2- 8	PANEL SUPPORT R UNIT
QC2-6103-000	9- 6	SPRING, PLATEN	QM3-2811-000	5- 12	MODULAR PCB UNIT
QC2-6130-000	3- 8	TRAY, DF	QM3-2813-000	5- 19	ADF SENSOR HARNESS
QC2-6142-000	5- 11	COVER, MODULAR JACK	QM3-2818-000	5- 17	MODULAR HARNESS UNIT
QC2-6143-000	5- 8	COVER, NCU	QM3-2820-000	5- 16	SPEAKER RELAY HARNESS
QC2-6146-000	5- 13	HOLDER, SPEAKER	QM3-2821-000	5- 20	ADF MOTOR HARNESS UNIT
QC2-6157-000	2- 7	FRONT PANEL R	QM3-2824-000	5- 2	DC HARNESS UNIT
QC2-6160-000	2- 3	FRONT PANEL L	QM3-2826-000	9- 2	LF MOTOR HARNESS UNIT
QC2-6162-000	3- 15	DF BASE	QM3-2828-000	5- 14	SPEAKER HARNESS UNIT
QC2-6164-000	3- 3	COVER, DF FRONT DECO	QM3-2833-000	4- 3	COVER SW HARNESS UNIT
QC2-6165-000	3- 6	COVER, REAR	QM3-2834-000	5- 9	LOGIC BOARD ASS'Y
QC2-6167-000	3- 4	COVER, TOP	QM3-2835-000	5- 7	CARD BOARD ASS'Y
QC2-6168-000	3- 9	COVER, ACCESS	QM3-2890-000	3- 16	DAMPER UNIT, SCANNER
QC2-6171-000	3- 18	STAY, SCANNER	QM3-4291-000	4- 5	DAMPER UNIT, FRONT
QC2-6172-000	4- 1	SHEET, SCANNER	QY6-0192-000	6- 2	ABSORBER KIT
QC2-6173-000	3- 21	COVER, PANEL L	QY6-0070-000	1- 1	PRINTER HEAD
QC2-6174-000	3- 20	COVER, PANEL R	QY9-0057-000	T- 1	LUBE, FLOIL KG107A, OIL
QC2-6186-000	3- 23	UPPER COVER, LCD	WE8-5973-000	8- 9	CORE
QC2-6190-000	3- 24	WINDOW, LCD	WT3-5156-000	1- 2	CORD, POWER
QC2-6412-000	4- 6	GEAR, FRONT DAMPER	WT3-5160-000	1- 2	CORD, POWER
QC2-6416-000	2- 6	CAP, LAN CONNECTOR	XA9-1646-000	S- 7	SCREW, TP, M3X4
QC2-6422-000	3- 21	COVER, PANEL L	XA9-1755-000	S- 8	SCREW, B-TIGHT M1.7X10
QC2-6423-000	3- 20	COVER, PANEL R	XA9-1756-000	S- 4	SCREW, TP, M3X8
QC2-6424-000	3- 21	COVER, PANEL L	XB1-2260-305	S- 6	SCREW, MACH. TRUSS HEAD, M2.6X3
QC2-6425-000	3- 20	COVER, PANEL R	XB1-2300-405	S- 3	SCREW, MACH.BH, M3X4
QC2-6426-000	3- 21	COVER, PANEL L	XB4-7300-605	S- 5	SCREW, BH M3X6
QC2-6427-000	3- 20	COVER, PANEL R	XB4-7300-805	S- 1	SCREW, TP, BH3X8
QC2-6428-000	3- 21	COVER, PANEL L	XB4-7300-809	S- 2	SCREW, TAP, BINDING HEAD, M3X8
QC2-6429-000	3- 20	COVER, PANEL R	XB4-7301-009	S- 10	SCREW, B-TIGHT: M3 X 10 MM
QC2-6430-000	1- 3	STICKER, PANEL	XB4-7401-005	S- 9	SCREW,TAPPIG,TRUSS HEAD,M4X10
QH2-2716-000	1- 2	CORD, POWER	XB6-7300-605	S- 11	SCREW, MACHINE, TP, M3X6
QH2-2719-000	1- 2	CORD, POWER			