



---

# KM-1500



## PARTS LIST

Published in Feb.'03  
842DC120

## NOTE

1. Indicate parts number and machine model when placing an order.

eg.	Parts Number	Parts Name	Machine Model	Cycle	Quantity
	2DC04030	COVER REAR	KM-1500	50Hz	1

2. Service calls and freight will be charged separately.

3. Symbols in the "Parts Number" column.

- Parts with "●" indicates the spare parts and the parts without "●" can not be supplied.
- Parts with "•" are component parts or sub-assemblies of the assembly appearing immediately above them.

eg.	Parts Number	Parts Name	Parts Number	Parts Name
	2DC93100	PARTS,MPF COVER SP	•2A806730	TRAY MPF A
			•2A806740	TRAY MPF B

4. See the last page of this parts list for the classification of the screws in the illustrations.

# Parts List

**KM-1500**

## — CONTENTS —

FIG.1	EXTERIOR COVERS .....	2
FIG.2	FRAMES & PAPER FEED SECTION I .....	4
FIG.3	PAPER FEED SECTION II & LSU .....	8
FIG.4	DRIVING SECTION .....	10
FIG.5	PROCESS UNIT .....	12
FIG.6	FUSER UNIT .....	14
FIG.7	CASSETTE .....	16
FIG.8	OPTICAL SECTION .....	18
FIG.9	OPERATION UNIT & ORIGINAL HOLDER .....	20
FIG.10	TOOLS & SUPPLIED PARTS .....	22
• INDEX .....		24



FIG. 1 EXTERIOR COVERS

2DC




FIG. 1 EXTERIOR COVERS

SP	Ref. No.	Part. No.	KYOCERA Part Number	Description	Quantity		
					120V	230V	240V
● ● ● ● ● ● ●	1	2A804080	5MVX422DN005	HINGE FRONT L	1	1	1
	2	2A804090	5MVX422DN006	HINGE FRONT R	1	1	1
	3	2DC04010		COVER FRONT (1/2)	1	1	1
	4	2DC04020		COVER LEFT (1/2)	1	1	1
	5	2DC04030		COVER REAR	1	1	1
	6	2DC04050		COVER DIMM	1	1	1
	7	2DC04060		COVER RIGHT (1/2)	1	1	1
	8	2DD04020		LID TOP	1		1
	8	2DC04100		LID TOP B		1	
	9	2DC04080		COVER TOP (1/3)	1	1	1
	10	2DC04090		PLATE SHIELD	1	1	1
	11	2A802520	5MMT263SN012	SCREW OP	1	1	1

• Parts with "●" are component parts or sub-assemblies of the assembly appearing immediately above them.  
• Parts with "●" indicates the spare parts.

• Parts with "●●" are component parts or sub-assembly with "●" appearing immediately above them.

FIG. 2 FRAMES & PAPER FEED SECTION I

2DC




FIG. 2 FRAMES &amp; PAPER FEED SECTION I

SP	Ref. No.	Part. No.	KYOCERA Part Number	Description	Quantity		
					120V	230V	240V
	1	2A802030	5MVB874CH002	COVER PWB	1	1	1
	2	2A802040	5MVX721DN001	LEVER INTERLOCK	1	1	1
	3	2A802050	5MVT653DW001	PIN CASSETTE	1	1	1
	4	2A802060	5MMW351LD006	SPRING INTERLOCK	1	1	1
	5	2A802070	5MMW341LD005	SPRING PIN CASSETTE	1	1	1
	6	2A806020	5MMT766SN007	SHAFT FEED	1	1	1
	7	2A806030	5MVM176DN026	BUSH FEED	2	2	2
●	8	2A806040	5MMT876SN073	ROLLER REGIST LOW	1	1	1
●	9	2A806050	5MMT865SN010	ROLLER REGIST UP	1	1	1
●	10	2A806090	5MVX432DB009	ACTUATOR REGIST	1	1	1
●	11	2A806100	5MVX542DB003	ACTUATOR PE	1	1	1
●	12	2A806120	5AAVCLTCH016	CLUTCH REGIST	1	1	1
	13	2A806170	5MVS441KF008	SHEET REGIST SW	1	1	1
	14	2A806210	5MMX532LD005	CONTACT EARTH REG	1	1	1
●	15	2A806220	5MVT676DB002	PULLEY FEED	1	1	1
●	16	2A806230	5MVG127DB047	GEAR REGIST Z20	1	1	1
●	17	2A806240	5MVG126DB025	GEAR REGIST Z13	1	1	1
●	18	2A806250	5MVX111DN003	RING STOPPER	4	4	4
	19	2A806260	5MVM161DW001	BUSH PULLEY FEED	2	2	2
	20	2A806410	5MMW261LD023	SPRING REGIST R	2	2	2
	21	2A806420	5MVX221DB019	BUSH REGIST LEFT	1	1	1
	22	2A806430	5MVX221DW006	BUSH REGIST RIGHT	1	1	1
●	23	2A806580	5AAVCLTCH017	CLUTCH MPF	1	1	1
	24	2A815010	5MMW361LD015	SPRING PIN BIAS	1	1	1
	25	2A815020	5MMT365SN003	PIN CONTACT BIAS	1	1	1
●	26	2A816020	5MVX221DB023	BUSH TC L	1	1	1
●	27	2A816030	5MVX221DW008	BUSH TC R	1	1	1
	28	2A816040	5MMW251LD043	SPRING TC L	1	1	1
	29	2DC16040		SPRING TC R	1	1	1
●	30	2A816060	5MVG127DB048	GEAR TC Z18	1	1	1
●	31	2A820090	5MMT874SN007	ROLLER EXIT UP	1	1	1
●	32	2A820290	5MVG137DN030	GEAR EXIT Z23 UP	1	1	1
	33	2A820300	5MVX322SB020	ACTUATOR FUSER B	1	1	1
	34	2A821010	5MVM176DW001	BUSH EXIT	1	1	1
●	35	2A822080	5MVG148DN045	GEAR Z38H	1	1	1
●	36	2A822090	5MVG148DN046	GEAR FREE Z40H	1	1	1
●	37	2A822100	5MVG138DN041	GEAR FREE Z25S	1	1	1
●	38	2A822110	5MVG148DN047	GEAR Z34S	1	1	1
●	39	2A822120	5MVG148DN048	GEAR Z40S	1	1	1
●	40	2A822130	5MMT364SN003	PIN DRIVE	3	3	3

- Parts with "●" are component parts or sub-assemblies of the assembly appearing immediately above them.
- Parts with "●●" indicates the spare parts.


2DC

SP	Ref. No.	Part. No.	KYOCERA Part Number	Description	Quantity		
					120V	230V	240V
●	41	2A822140	5MMW271LD010	SPRING FREE	1	1	1
●	42	2A822160	5MVG148DN049	GEAR Z37S	1	1	1
	43	2A822200	5MVB663SB048	COVER CORD	1	1	1
	44	2A827010	5MMS775SL001	PLATE CONTROLLER	1	1	1
	45	2A827030	5MMX773SL001	PLATE SW REG	1	1	1
	46	2A827060	5MVS765KF001	SHEET SW REG	1	1	1
●	47	2DC06030		ROLLER FEED ASSY	1	1	1
	48	2BY02010	5MMX632LD008	CONTACT MAIN MR	1	1	1
	49	2BY06040	5MMW261LD057	SPRING ACTUATOR REG	1	1	1
	50	2BY06050	5MVS622KF011	SHEET REGIST R	1	1	1
	51	2BY06060	5MVS622KF012	SHEET REGIST L	1	1	1
●	52	2DC68120		P.W.BOARD ASSY(SP)	1	1	1
●	53	2DC68110		P.W.BOARD ASSY(SP)	1	1	1
●	54	2DC01060		P.W.BOARD ASSY	1	1	1
	55	2DC02010		FRAME BASE (1/8)	1	1	1
	56	2DC02020		STAY SCANNER LEFT	1	1	1
	57	2DC02030		STAY SCANNER RIGHT	1	1	1
	58	2DC02040		FRAME MIDDLE (1/3)	1	1	1
	59	2DC02050		MOUNT SCANNER PCB	1	1	1
	60	2DC02060		PLATE EARTH STAY L	1	1	1
●	61	2DC06010		CLUTCH FEED	1	1	1
●	62	2DC16010		ROLLER TRANSFER,(C)		1	1
●	62	2DC16020		ROLLER TRANSFER,(I)	1		
	63	2DC16030		PLATE EARTH BRUSH A	1	1	1
●	64	2DC23010		FAN COOLING	1	1	1
	65	2DC26010		SHIELD CONTROLLER (1/3)	1	1	1
	66	2DC26080		GROUND PLATE SR	1	1	1
	67	2DC26100		CONTACT TRANSFER	1	1	1
	68	2DC27010		CONN.CORD ASSY ENGINE-MAIN	1	1	1
	69	2DC27020		CONN.CORD ASSY ENGINE-SCANNER1	1	1	1
	70	2DC27030		CONN.CORD ASSY ENGINE-SCANNER2	1	1	1
	71	2DC27110		CONN.CORD ASSY ENGINE-MMOT	1	1	1
	72	2DC27120		CONN.CORD ASSY ENGINE-BIASH	1	1	1
	73	2DC27130		CONN.CORD ASSY ENGINE-BIASY	1	1	1
●	74	2DC28080		TRANS ASSY	1	1	1
	75	2A868610	5AAY3010E+31	EARTH GUIDE ASSY	1	1	1
	76	2DC02090		PLATE EARTH STAY L2	1	1	1
	77	2DC02100		FILM PS LOW	1	1	1
	78	2DC26130		FILM MAIN PWB	1	1	1
●	79	2DC28070		PRINTED W.BOARD PS100	1		

- Parts with "●●" are component parts or sub-assembly with "●" appearing immediately above them.

FIG. 2 FRAMES & PAPER FEED SECTION I

2DC



2DC

- Parts with "●" are component parts or sub-assemblies of the assembly appearing immediately above them.
- Parts with "●" indicates the spare parts.

- 7 -



FIG. 3 PAPER FEED SECTION II & LSU

2DC




FIG. 3 PAPER FEED SECTION II &amp; LSU

SP	Ref. No.	Part. No.	KYOCERA Part Number	Description	Quantity		
					120V	230V	240V
●	1	2DC68090		TE SENSOR ASSY	1	1	1
●	2	2DC68100		FULL SENSOR ASSY	1	1	1
	3	2A802500	5MVS228RB019	FOOT	4	4	4
	4	2A805010	5MVVL661WN34	LABEL LASER CAUTION	1	1	1
	5	2A806030	5MVM176DN026	BUSH FEED	2	2	2
●	6	2A806250	5MVX111DN003	RING STOPPER	4	4	4
	7	2A806480	5MVS312KF011	SHEET GUIDE	4	4	4
●	8	2A806510	5AAVROLL*045	ROLLER MPF ASSY	1	1	1
	9	2A806520	5MVX854SH002	HOLDER MP FEED	1	1	1
	10	2A806530	5MMT766SN008	SHAFT MPF	1	1	1
	11	2A806550	5MVX522DB004	SEPARATOR MPF	1	1	1
	12	2A806560	5MVS416XN001	PAD SEPARATOR MPF	1	1	1
	13	2A806570	5MMW261LD038	SPRING SEPA MPF	1	1	1
	14	2A806600	5MVX432DB010	ACTUATOR MPF	1	1	1
	15	2A806620	5MVX221DN014	CAM MPF R	1	1	1
	16	2A806660	5MVB872SH019	BASE MPF	1	1	1
	17	2A806670	5MVX852CB003	BOTTOM PLATE MPF	1	1	1
	18	2A806680	5MVS616XN002	PAD BOTTOM MPF	1	1	1
	19	2A806690	5MMW271SZ005	SPRING BOTTOM MPF	1	1	1
	20	2A806700	5MVX752SH002	GUIDE MPF R	1	1	1
	21	2A806710	5MVX752SH003	GUIDE MPF L	1	1	1
	22	2A806720	5MVG137DN032	GEAR MPF	1	1	1
	23	2A806760	5MVS431TX001	TAPE SEPARATOR	1	1	1
	24	2A813030	5MMX221LD024	SPRING MIRROR	2	2	2
	25	2A813050	5MMW341LD006	SPRING SHUTTER LSU	1	1	1
	26	2A814570	5MMW261LD036	SPRING TE SENSOR	1	1	1
●	27	2A827110	5ENXGPIA73A*01	PT SENSOR	1	1	1
	28	2A827580	5AACCNRM0GEA	CONN.CORD ASSY	1	1	1
●	29	2DC01170		P.W.BOARD ASSY	1	1	1
●	30	2A868700	5AAY3010E+58	COVER REAR ASSY	1	1	1
	31	*B8023060		BINDING TAP-TITE B SCREW M3X6	2	2	2
●	32	*2A820100	5MVM273DB005	PULLEY EXIT	2	2	2
	33	*2A820340	5MMX322LD022	PLATE TRAY	2	2	2
	34	*2A820850	5MMX332LD021	BKT PULLEY FD	2	2	2
●	35	*2A820950	5MVB874SH018	COVER REAR	1	1	1
	36	*2A820961	5MVB874SH019	TRAY EXIT FU	1	1	1
	37	*2A820970	5MVS222KN006	SHEET REAR	2	2	2
	38	*2A820980	5MVS222KW001	SHEET REAR B	2	2	2
	39	2DC06020		GUIDE TURN A	1	1	1
●	40	2DC93070		LK-100 PARTS LASER SCANNER	1	1	1

- Parts with "•" are component parts or sub-assemblies of the assembly appearing immediately above them.
- Parts with "●" indicates the spare parts.

2DC

SP	Ref. No.	Part. No.	KYOCERA Part Number	Description	Quantity		
					120V	230V	240V
	41	2DC13020		SHUTTER LSU	1	1	1
	42	2DC13030		MIRROR LSU	1	1	1
	43	2DC13040		SPRING FULL SENSOR	1	1	1
	44	2DC26070		SHIELD LSU	1	1	1
	45	2DC26110		PLATE EARTH LSU	1	1	1
	46	2DC27070		WIRE MAIN-LSU	1	1	1
	47	2DC27140		WIRE ENGINE-LSU	1	1	1
●	48	2DC93100		PARTS.MPF COVER SP	1	1	1
	49	*2A806730	5MVX861SH004	TRAY MPF A	1	1	1
●	50	*2A806740	5MVX751SH001	TRAY MPF B	1	1	1
	51	*2DC04040		COVER MPF	1	1	1
	52	2A627940		CORE 10-20X10	1	1	1

- Parts with "••" are component parts or sub-assembly with "•" appearing immediately above them.



FIG. 4 DRIVING SECTION

2DC




FIG. 4 DRIVING SECTION

2DC

SP	Ref. No.	Part. No.	KYOCERA Part Number	Description	Quantity		
					120V	230V	240V
●	1	2DC93080		DR-100PARTS DRIVE UNIT	1	1	1
●	2	•2A806141	5EZA2402410401	SOLENOID REGIST	1	1	1
	3	•2A806280	5MVS217SN002	PAD SOLENOID	1	1	1
●	4	•2A806590	5EZA2402410501	SOLENOID MPF	1	1	1
●	5	•2A822030	5MVG168DN017	GEAR Z68H-Z21H	1	1	1
●	6	•2A822050	5MVG148DN044	GEAR Z40H	1	1	1
●	7	•2A822060	5MVG169DN032	GEAR Z95H-Z21H	1	1	1
●	8	•2A822070	5MVG169DN033	GEAR Z53H	1	1	1
	9	•2A822150	5MMX521LD005	PLATE EARTH DRUM	1	1	1
●	10	•2A822170	5MVG138DN042	GEAR Z24H	1	1	1
●	11	•2A822180	5MVG137DN029	GEAR Z21H	1	1	1
●	12	•2A822190	5MVG148DN050	GEAR Z36H-Z21H	1	1	1
	13	•2A827590	5AACCNRM1GEA	CONN.CORD ASSY	1	1	1
●	14	•2DC22010		MOTOR MAIN	1	1	1
	15	•2DC22020		MOUNT MACHINE DRIVE	1	1	1
	16	•2DC22030		GEAR 48/21	1	1	1
●	17	2A806130	5EZA2402410301	SOLENOID FEED	1	1	1
	18	2A806750	5MMX332LD013	PLATE EARTH MPF	1	1	1

- Parts with "•" are component parts or sub-assemblies of the assembly appearing immediately above them.
- Parts with "●" indicates the spare parts.

- Parts with "••" are component parts or sub-assembly with "•" appearing immediately above them.

FIG. 5 PROCESS UNIT

2DC




FIG. 5 PROCESS UNIT

2DC

SP	Ref. No.	Part. No.	KYOCERA Part Number	Description	Quantity		
					120V	230V	240V
●		2DC93030		PU-100 PARTS PROCESS UNIT SP		1	1
●		2DC93040		PU-101 PARTS PROCESS UNIT (U) SP	1		
●	1	•2A814190	5MVG127DN067	GEAR MIXER Z20 A	1	1	1
●	2	•2A814230	5MVG127DN068	GEAR Z14-Z18	1	1	1
●	3	•2A814240	5MVG148DN056	GEAR Z40	1	1	1
●	4	•2A814470	5MVG127DN069	GEAR MIXER Z20 B	1	1	1
●	5	•2A818080	5MVT865SB002	ROLLER SWEEP	1	1	1
●	6	•2A818220	5MVG127DN0065	GEAR SWEEP Z13	1	1	1
●	7	•2A818230	5MVG127DN0066	GEAR IDLE Z18H	1	1	1
●	8	•2BZ14610	5MVM187DB009	PULLEY DLP	2	2	2
●	9	•2DC14100		GEAR DLP 20	1	1	1
●	10	•2DC14110		GEAR DLP 24	1	1	1
●	11	•2DC14120		GEAR DLP 14/26/30	1	1	1
●	12	•2DC14140		GEAR DLP 18/44	1	1	1
●	13	•2DC14150		GEAR DLP 18/40	1	1	1
●	14	•2A893062	5PLPXU5AEKX	MC-40 MCH ASSY	1	1	1

- Parts with "•" are component parts or sub-assemblies of the assembly appearing immediately above them.
- Parts with "●" indicates the spare parts.

- Parts with "••" are component parts or sub-assembly with "•" appearing immediately above them.

FIG. 6 FUSER UNIT

2DC




FIG. 6 FUSER UNIT

2DC

SP	Ref. No.	Part. No.	KYOCERA Part Number	Description	Quantity		
					120V	230V	240V
●		2DC93050		FK-100(E) PARTS FUSER UNIT		1	1
●		2DC93060		FK-100(U) PARTS FUSER UNIT	1		
	1	•2A805020	5MVL731WN14	LABEL FUSER CAUTION	1	1	1
	2	•2A820022	5MVB863KB003	FRAME FUSER UP	1	1	1
●	3	•2A820080	5MMT774SN001	ROLLER EXIT LOW	1	1	1
●	4	•2A820100	5MVM273DB005	PULLEY EXIT	2	2	2
	5	•2A820110	5MVX211DB016	BUSH EXIT	1	1	1
	6	•2A820120	5MVM188XN015	BUSH HEAT R	1	1	1
	7	•2A820131	5MVM188XN016	BUSH HEAT L	1	1	1
●	8	•2A820160	5MVG148XN008	GEAR HEAT Z33	1	1	1
●	9	•2A820170	5MVG137DN031	GEAR EXIT Z23	1	1	1
●	10	•2A820180	5MVG148XN009	GEAR IDLE Z34	1	1	1
●	11	•2A820190	5MVG127DN070	GEAR IDLE Z18	1	1	1
	12	•2A820200	5MVX731CB002	ACTUATOR FUSER A	1	1	1
	13	•2A820220	5MML211RD002	HOLDER LAMP B	1	1	1
	14	•2A820260	5MMW601LD011	SPRING PULLEY	2	2	2
	15	•2A820280	5MMX665LD004	PLATE EARTH FUSER	1	1	1
	16	•2A820350	5MMW261LD055	SPRING SEPARATOR	4	4	4
	17	•2A820360	5AAVSEPR015	SEPARATOR ASSY	4	4	4
	18	•2A820520	5MMW261LD017	SPRING ACTUATOR	1	1	1
●	19	•2BY20010	5MMT876AX002	ROLLER HEAT	1	1	1
●	20	•2BY20020	5EYFFQ16001++01	THERMOSTAT 250V 160	1	1	1
	21	•2BY20050	5MMS111SL002	NUT FUSER A	2	2	2
	22	•2BY20060	5MML531CG001	HOLDER LAMP A	1	1	1
	23	•2BY20070	5MVX221XN004	BUSH PRESS	2	2	2
	24	•2BY27560	5AACCNH3GGEA	CONN.CORD ASSY S02774		1	1
	24	•2BY27570	5AACCNH4GGEA	CONN.CORD ASSY S02775	1		
	25	•2DC20010		SPRING PRESS ROLLER	2	2	2
●	26	•2DC20020		HEATER 230 FIXING		1	1
●	26	•2DC20030		HEATER 120 FIXING	1		
	27	•2DC20040		FRAME FUSER LOW (1/2)	1	1	1
●	28	•2DC20050		THERMISTOR FUSER	1	1	1
	29	•2DC20060		ROLLER PRESS	1	1	1

- Parts with "•" are component parts or sub-assemblies of the assembly appearing immediately above them.
- Parts with "●" indicates the spare parts.

- Parts with "••" are component parts or sub-assembly with "•" appearing immediately above them.

FIG. 7 CASSETTE

2DC




FIG. 7 CASSETTE

2DC

SP	Ref. No.	Part. No.	KYOCERA Part Number	Description	Quantity		
					120V	230V	240V
●		2DC93090		PARTS,CASSETTE SP	1	1	1
	1	•2A807010	5MVB886SH063	BASE CASSETTE	1	1	1
	2	•2A807020	5MVX765SH002	GUIDE SIDE R	1	1	1
	3	•2A807030	5MVX765SH003	GUIDE SIDE L	1	1	1
●	4	•2A807050	5MVG127DN071	GEAR CASSETTE	1	1	1
	5	•2A807060	5MVX882SH002	BOTTOM CASSETTE	1	1	1
	6	•2A807080	5MVS616XN001	PAD BOTTOM	1	1	1
	7	•2A807110	5MMW251LD047	SPRING SEPARATOR C	1	1	1
	8	•2A807121	5MVX431DW001	LOCK CASSETTE R	1	1	1
	9	•2A807131	5MVX431DW002	LOCK CASSETTE L	1	1	1
	10	•2A807140	5MMW251LD045	SPRING LOCK	2	2	2
	11	•2A807161	5MVX541DG003	LEVER SIDE	1	1	1
	12	•2A807170	5MMS856SL001	PLATE BOTTOM	1	1	1
	13	•2A807191	5MVX541DG002	LEVER REAR	1	1	1
	14	•2A807510	5MMP141LD002	PLATE SIDE GUIDE	1	1	1
	15	•2A807520	5MMP141LD003	PLATE STOPPER	1	1	1
●	16	•2A807530	5MMW171LD006	SPRING STOPPER	1	1	1
	17	•2DC07030		SPRING CASSETTE	2	2	2
	18	•2A807550	5MVL311KF003	SHEET CASSETTE	2	2	2
	19	•2A807910	5MVS315CN001	SPACER CASSETTE	2	2	2
	20	•2BX68340	5AAVSEPR016	SEPARATOR KIT	1	1	1
●	21	•2DC07010		STOPPER PAPER	1	1	1
●	22	•2DC07020		POSITIONING FOLIO PAPER	1	1	1

- Parts with "•" are component parts or sub-assemblies of the assembly appearing immediately above them.
- Parts with "●" indicates the spare parts.

- Parts with "••" are component parts or sub-assembly with "•" appearing immediately above them.



FIG. 8 OPTICAL SECTION

2DC




FIG. 8 OPTICAL SECTION

SP	Ref. No.	Part. No.	KYOCERA Part Number	Description	Quantity		
					120V	230V	240V
●	1	2DC01020	5MVX111DN003	P.W.BOARD ASSY	1	1	1
	2	2DC05010		LABEL CONTACT GLASS	1	1	1
●	3	2DC12010		UPPER FRAME SCANNER(1/2)	1	1	1
	4	2DC12020		LOWER FRAME SCANNER(1/4)	1	1	1
●	5	2DC12040		SHAFT SCANNER	1	1	1
	6	2DC12050		CONTACT GLASS	1	1	1
●	7	2DC12060		CONTACT GLASS DF	1	1	1
	8	2DC12110		MOUNT SCANNER MOTOR	1	1	1
●	9	2DC12120		GEAR SCANNER 39/22	1	1	1
	10	2DC12130		GEAR SCANNER 45/18	1	1	1
●	11	2DC12140		MOUNT TENSION PULLEY	1	1	1
	12	2DC12150		PULLEY TENSION	1	1	1
●	13	2DC12160		MOTOR SCANNER	1	1	1
	14	2DC12170		SPRING TENSION	1	1	1
●	15	2DC12180		BELT SCANNER	1	1	1
	16	2DC12190		RAIL SCANNER	1	1	1
●	17	2DC12210		STANDARD PLATE SHADING	1	1	1
	18	2DC12280		STOPPER 8	1	1	1
●	19	2DC12300		GROUND PLATE SCANNER	1	1	1
	20	2DC12310		HOLDER FFC	1	1	1
●	21	2DC12330		PLATE EARTH SCANNER A	1	1	1
	22	2DC12340		PLATE EARTH SCANNER B	1	1	1
●	23	2DC12350		PLATE EARTH SCANNER C	1	1	1
	24	2DC12360		TAPE CONTACT GLASS A	2	2	2
●	25	2DC12370		TAPE CONTACT GLASS B	2	2	2
	26	2DC12380		TAPE CONTACT GLASS C	1	1	1
●	27	2DC12390		TAPE CONTACT GLASS D	7	7	7
	28	2DC12400		TAPE FFC	2	2	2
●	29	2A806250		RING STOPPER	2	2	2
	30	2DC93010		PARTS,IMAGE SCANNER SP	1	1	1
●	31	•2DC12200		LAMP SCANNER	1	1	1
	32	•2DC27090		CONN.CORD ASSY SCANNER-CCD	1	1	1
●	33	2DC27040		CONN.CORD ASSY SCANNER-MAIN1	1	1	1
	34	2DC27050		CONN.CORD ASSY SCANNER-PANEL	1	1	1
●	35	2DC27080		CONN.CORD ASSY SCANNER-MAIN2	1	1	1
	36	2DC12420		PLATE EARTH SCANNER D	1	1	1
●	37	2DC12430		PLATE EARTH SCANNER E	1	1	1
	38	2DC12440		PLATE EARTH SCANNER F	1	1	1
●	39	2DC12450		PLATE EARTH SCANNER G	1	1	1
	40	2DC27150		CORE FFC1	1	1	1

- Parts with "•" are component parts or sub-assemblies of the assembly appearing immediately above them.
- Parts with "●" indicates the spare parts.

2DC

SP	Ref. No.	Part. No.	KYOCERA Part Number	Description	Quantity		
					120V	230V	240V
	41	2BY26040		FERRITE CORE	1	1	1
	42	33927590		CORE 7-15X18	1	1	1

- Parts with "••" are component parts or sub-assembly with "•" appearing immediately above them.

FIG. 9 OPERATION UNIT & ORIGINAL HOLDER

2DC





FIG. 9 OPERATION UNIT &amp; ORIGINAL HOLDER

SP	Ref. No.	Part. No.	KYOCERA Part Number	Description	Quantity		
					120V	230V	240V
●	1	2DC93110		PARTS, PLATEN COVER SP	1	1	1
●	2	•2DC11010		COVER ORIGINAL HOLDER(1/2)	1	1	1
●	3	•2DC11020		MAT ORIGINAL HOLDER	1	1	1
●	4	•2DC11030		UPPER HINGE	2	2	2
●	5	•2DC11040		LOWER HINGE	2	2	2
●	6	•2DC11050		TAPE ORIGINAL HOLDER	2	2	2
●	7	2DC93020		PARTS, OPERATION PANEL, SP	1	1	1
●	8	•2DC01050		P.W.BOARD ASSY	1	1	1
●	9	•2DC25010		COVER OPERATION	1	1	1
●	10	•2DC25020		SHEET OPERATION	1	1	1
●	11	•2DC25030		SHEET DUST SHIELD	1	1	1
●	12	•2DC25050		KEY PRINT	1	1	1
●	13	•2DC25060		KEY STOP	1	1	1
●	14	•2DC25070		KEY RESET	1	1	1

- Parts with "•" are component parts or sub-assemblies of the assembly appearing immediately above them.
- Parts with "●" indicates the spare parts.

- Parts with "••" are component parts or sub-assembly with "•" appearing immediately above them.

## TOOLS



## SUPPLIED PARTS






FIG. 10 TOOLS & SUPPLIED PARTS

2DC

SP	Ref. No.	Part. No.	KYOCERA Part Number	Description	Quantity		
					120V	230V	240V
●	1	2DC01090		PCB DIMM ASSY	1	1	1
	2	2A802530	5AAMDK5P**01	CLEANING KIT C	1	1	1
	3	2A827810	5AACAC482ULA	AC CORD ASSY	1		
	4	2A827830	5AACAC479EEA	AC CORD ASSY		1	1

- Parts with "•" are component parts or sub-assemblies of the assembly appearing immediately above them.
- Parts with "●" indicates the spare parts.

- Parts with "••" are component parts or sub-assembly with "•" appearing immediately above them.

## INDEX

SP	Part. No.	KYOCERA Part Number	Description	Quantity			Fig. No.
				120V	230V	240V	
	2A627940		CORE 10-20X10	1	1	1	3
	2A802030	5MVB874CH002	COVER PWB	1	1	1	2
	2A802040	5MVX721DN001	LEVER INTERLOCK	1	1	1	2
	2A802050	5MVT653DW001	PIN CASSETTE	1	1	1	2
	2A802060	5MMW351LD006	SPRING INTERLOCK	1	1	1	2
	2A802070	5MMW341LD005	SPRING PIN CASSETTE	1	1	1	2
	2A802500	5MVS228RB019	FOOT	4	4	4	3
	2A802520	5MMT263SN012	SCREW OP	1	1	1	1
	2A802530	5AAMDK5P*01	CLEANING KIT C	1	1	1	10
	2A804080	5MVX422DN005	HINGE FRONT L	1	1	1	1
	2A804090	5MVX422DN006	HINGE FRONT R	1	1	1	1
	2A805010	5MVVL661VN34	LABEL LASER CAUTION	1	1	1	3
	2A805020	5MVVL731VN14	LABEL FUSER CAUTION	1	1	1	6
	2A806020	5MMT766SN007	SHAFT FEED	1	1	1	2
	2A806030	5MVM176DN026	BUSH FEED	4	4	4	2,3
●	2A806040	5MMT876SN073	ROLLER REGIST LOW	1	1	1	2
●	2A806050	5MMT865SN010	ROLLER REGIST UP	1	1	1	2
●	2A806090	5MVX432DB009	ACTUATOR REGIST	1	1	1	2
●	2A806100	5MVX542DB003	ACTUATOR PE	1	1	1	2
●	2A806120	5AAVCLTCH016	CLUTCH REGIST	1	1	1	2
●	2A806130	5EZSA2402410301	SOLENOID FEED	1	1	1	4
●	2A806141	5EZSA2402410401	SOLENOID REGIST	1	1	1	4
	2A806170	5MVS441KF008	SHEET REGIST SW	1	1	1	2
	2A806210	5MMX532LD005	CONTACT EARTH REG	1	1	1	2
●	2A806220	5MVT676DB002	PULLEY FEED	1	1	1	2
●	2A806230	5MVG127DB047	GEAR REGIST Z20	1	1	1	2
●	2A806240	5MVG126DB025	GEAR REGIST Z13	1	1	1	2
●	2A806250	5MVX111DN003	RING STOPPER	10	10	10	2,3,8
	2A806260	5MVM161DW001	BUSH PULLEY FEED	2	2	2	2
	2A806280	5MVS217SN002	PAD SOLENOID	1	1	1	4
	2A806410	5MMW261LD023	SPRING REGIST R	2	2	2	2
	2A806420	5MVX221DB019	BUSH REGIST LEFT	1	1	1	2
	2A806430	5MVX221DW006	BUSH REGIST RIGHT	1	1	1	2
	2A806480	5MVS312KF011	SHEET GUIDE	4	4	4	3
●	2A806510	5AAVROLL*045	ROLLER MPF ASSY	1	1	1	3
	2A806520	5MVX854SH002	HOLDER MP FEED	1	1	1	3
	2A806530	5MMT766SN008	SHAFT MPF	1	1	1	3
	2A806550	5MVX522DB004	SEPARATOR MPF	1	1	1	3
	2A806560	5MVS416XN001	PAD SEPARATOR MPF	1	1	1	3
	2A806570	5MMW261LD038	SPRING SEPA MPF	1	1	1	3

## 2DC

SP	Part. No.	KYOCERA Part Number	Description	Quantity			Fig. No.
				120V	230V	240V	
●	2A806580	5AAVCLTCH017	CLUTCH MPF	1	1	1	2
●	2A806590	5EZSA2402410501	SOLENOID MPF	1	1	1	4
	2A806600	5MVX432DB010	ACTUATOR MPF	1	1	1	3
	2A806620	5MVX221DN014	CAM MPF R	1	1	1	3
	2A806660	5MVB872SH019	BASE MPF	1	1	1	3
	2A806670	5MVX852CB003	BOTTOM PLATE MPF	1	1	1	3
	2A806680	5MVS616XN002	PAD BOTTOM MPF	1	1	1	3
	2A806690	5MMW271SZ005	SPRING BOTTOM MPF	1	1	1	3
	2A806700	5MVX752SH002	GUIDE MPF R	1	1	1	3
	2A806710	5MVX752SH003	GUIDE MPF L	1	1	1	3
	2A806720	5MVG137DN032	GEAR MPF	1	1	1	3
	2A806730	5MVX861SH004	TRAY MPF A	1	1	1	3
	2A806740	5MVX751SH001	TRAY MPF B	1	1	1	3
	2A806750	5MMX332LD013	PLATE EARTH MPF	1	1	1	4
	2A806760	5MVS431TX001	TAPE SEPARATOR	1	1	1	3
	2A807010	5MVB886SH063	BASE CASSETTE	1	1	1	7
	2A807020	5MVX765SH002	GUIDE SIDE R	1	1	1	7
	2A807030	5MVX765SH003	GUIDE SIDE L	1	1	1	7
●	2A807050	5MVG127DN071	GEAR CASSETTE	1	1	1	7
	2A807060	5MVX882SH002	BOTTOM CASSETTE	1	1	1	7
	2A807080	5MVS616XN001	PAD BOTTOM	1	1	1	7
	2A807110	5MMW251LD047	SPRING SEPARATOR C	1	1	1	7
	2A807121	5MVX431DW001	LOCK CASSETTE R	1	1	1	7
	2A807131	5MVX431DW002	LOCK CASSETTE L	1	1	1	7
	2A807140	5MMW251LD045	SPRING LOCK	2	2	2	7
	2A807161	5MVX541DG003	LEVER SIDE	1	1	1	7
	2A807170	5MMS856SL001	PLATE BOTTOM	1	1	1	7
	2A807191	5MVX541DG002	LEVER REAR	1	1	1	7
	2A807510	5MMP141LD002	PLATE SIDE GUIDE	1	1	1	7
	2A807520	5MMP141LD003	PLATE STOPPER	1	1	1	7
●	2A807530	5MMW171LD006	SPRING STOPPER	1	1	1	7
	2A807550	5MVL311KF003	SHEET CASSETTE	2	2	2	7
	2A807910	5MVS315CN001	SPACER CASSETTE	2	2	2	7
	2A813030	5MMX221LD024	SPRING MIRROR	2	2	2	3
	2A813050	5MMW341LD006	SPRING SHUTTER LSU	1	1	1	3
●	2A814190	5MVG127DN067	GEAR MIXER Z20 A	1	1	1	5
●	2A814230	5MVG127DN068	GEAR Z14-Z18	1	1	1	5
●	2A814240	5MVG148DN056	GEAR Z40	1	1	1	5
●	2A814470	5MVG127DN069	GEAR MIXER Z20 B	1	1	1	5
	2A814570	5MMW261LD036	SPRING TE SENSOR	1	1	1	3

• Parts with "●" indicates the spare parts.

## 2DC

SP	Part. No.	KYOCERA Part Number	Description	Quantity			Fig. No.
				120V	230V	240V	
●	2A815010	5MMW361LD015	SPRING PIN BIAS	1	1	1	2
●	2A815020	5MMT365SN003	PIN CONTACT BIAS	1	1	1	2
●	2A816020	5MVX221DB023	BUSH TC L	1	1	1	2
●	2A816030	5MVX221DW008	BUSH TC R	1	1	1	2
●	2A816040	5MMW251LD043	SPRING TC L	1	1	1	2
●	2A816060	5MVG127DB048	GEAR TC Z18	1	1	1	2
●	2A818080	5MVT865SB002	ROLLER SWEEP	1	1	1	5
●	2A818220	5MVG127DN0065	GEAR SWEEP Z13	1	1	1	5
●	2A818230	5MVG127DN0066	GEAR IDLE Z18H	1	1	1	5
●	2A820022	5MVB863KB003	FRAME FUSER UP	1	1	1	6
●	2A820080	5MMT774SN001	ROLLER EXIT LOW	1	1	1	6
●	2A820090	5MMT874SN007	ROLLER EXIT UP	1	1	1	2
●	2A820100	5MVM273DB005	PULLEY EXIT	4	4	4	3,6
●	2A820110	5MVX211DB016	BUSH EXIT	1	1	1	6
●	2A820120	5MVM188XN015	BUSH HEAT R	1	1	1	6
●	2A820131	5MVM188XN016	BUSH HEAT L	1	1	1	6
●	2A820160	5MVG148XN008	GEAR HEAT Z33	1	1	1	6
●	2A820170	5MVG137DN031	GEAR EXIT Z23	1	1	1	6
●	2A820180	5MVG148XN009	GEAR IDLE Z34	1	1	1	6
●	2A820190	5MVG127DN070	GEAR IDLE Z18	1	1	1	6
●	2A820200	5MVX731CB002	ACTUATOR FUSER A	1	1	1	6
●	2A820220	5MML211RD002	HOLDER LAMP B	1	1	1	6
●	2A820260	5MMW601LD011	SPRING PULLEY	2	2	2	6
●	2A820280	5MMX665LD004	PLATE EARTH FUSER	1	1	1	6
●	2A820290	5MVG137DN030	GEAR EXIT Z23 UP	1	1	1	2
●	2A820300	5MVX322SB020	ACTUATOR FUSER B	1	1	1	2
●	2A820340	5MMX322LD022	PLATE TRAY	2	2	2	3
●	2A820350	5MMW261LD055	SPRING SEPARATOR	4	4	4	6
●	2A820360	5AAVSEPR015	SEPARATOR ASSY	4	4	4	6
●	2A820520	5MMW261LD017	SPRING ACTUATOR	1	1	1	6
●	2A820850	5MMX332LD021	BKT PULLEY FD	2	2	2	3
●	2A820950	5MVB874SH018	COVER REAR	1	1	1	3
●	2A820961	5MVB874SH019	TRAY EXIT FU	1	1	1	3
●	2A820970	5MVS222KN006	SHEET REAR	2	2	2	3
●	2A820980	5MVS222KW001	SHEET REAR B	2	2	2	3
●	2A821010	5MVM176DW001	BUSH EXIT	1	1	1	2
●	2A822030	5MVG168DN017	GEAR Z68H-Z21H	1	1	1	4
●	2A822050	5MVG148DN044	GEAR Z40H	1	1	1	4
●	2A822060	5MVG169DN032	GEAR Z95H-Z21H	1	1	1	4
●	2A822070	5MVG169DN033	GEAR Z53H	1	1	1	4

SP	Part. No.	KYOCERA Part Number	Description	Quantity			Fig. No.
				120V	230V	240V	
●	2A822080	5MVG148DN045	GEAR Z38H	1	1	1	2
●	2A822090	5MVG148DN046	GEAR FREE Z40H	1	1	1	2
●	2A822100	5MVG138DN041	GEAR FREE Z25S	1	1	1	2
●	2A822110	5MVG148DN047	GEAR Z34S	1	1	1	2
●	2A822120	5MVG148DN048	GEAR Z40S	1	1	1	2
●	2A822130	5MMT364SN003	PIN DRIVE	3	3	3	2
●	2A822140	5MMW271LD010	SPRING FREE	1	1	1	2
●	2A822150	5MMX521LD005	PLATE EARTH DRUM	1	1	1	4
●	2A822160	5MVG148DN049	GEAR Z37S	1	1	1	2
●	2A822170	5MVG138DN042	GEAR Z24H	1	1	1	4
●	2A822180	5MVG137DN029	GEAR Z21H	1	1	1	4
●	2A822190	5MVG148DN050	GEAR Z36H-Z21H	1	1	1	4
●	2A822200	5MVB663SB048	COVER CORD	1	1	1	2
●	2A827010	5MMS775SL001	PLATE CONTROLLER	1	1	1	2
●	2A827030	5MMX773SL001	PLATE SW REG	1	1	1	2
●	2A827060	5MVS765KF001	SHEET SW REG	1	1	1	2
●	2A827110	5ENXGP1A73A*01	PT SENSOR	1	1	1	3
●	2A827580	5AACCNRM0GEA	CONN.CORD ASSY	1	1	1	3
●	2A827590	5AACCNRM1GEA	CONN.CORD ASSY	1	1	1	4
●	2A827810	5AACAC482ULA	AC CORD ASSY	1			10
●	2A827830	5AACAC479EEA	AC CORD ASSY		1	1	10
●	2A868610	5AAY3010E+31	EARTH GUIDE ASSY	1	1	1	2
●	2A868700	5AAY3010E+58	COVER REAR ASSY	1	1	1	3
●	2A893062	5PLPXU5AEKX	MC-40 MCH ASSY	1	1	1	5
●	2BX68340	5AAVSEPR016	SEPARATOR KIT	1	1	1	7
●	2BY02010	5MMX632LD008	CONTACT MAIN MR	1	1	1	2
●	2BY06040	5MMW261LD057	SPRING ACTUATOR REG	1	1	1	2
●	2BY06050	5MVS622KF011	SHEET REGIST R	1	1	1	2
●	2BY06060	5MVS622KF012	SHEET REGIST L	1	1	1	2
●	2BY20010	5MMT876AX002	ROLLER HEAT	1	1	1	6
●	2BY20020	5EYFFQ16001+01	THERMOSTAT 250V 160	1	1	1	6
●	2BY20050	5MMS111SL002	NUT FUSER A	2	2	2	6
●	2BY20060	5MML531CG001	HOLDER LAMP A	1	1	1	6
●	2BY20070	5MVX221XN004	BUSH PRESS	2	2	2	6
●	2BY26040		FERRITE CORE	1	1	1	8
●	2BY27560	5AACNSH3GEA	CONN.CORD ASSY S02774		1	1	6
●	2BY27570	5AACNSH4GEA	CONN.CORD ASSY S02775	1			6
●	2BZ14610	5MVM187DB009	PULLEY DLP	2	2	2	5
●	2DC01020		P.W.BOARD ASSY	1	1	1	8

• Parts with "●" indicates the spare parts.



SP	Part. No.	KYOCERA Part Number	Description	Quantity			Fig. No.
				120V	230V	240V	
●	2DC01050		P.W.BOARD ASSY	1	1	1	9
●	2DC01060		P.W.BOARD ASSY	1	1	1	2
●	2DC01090		PCB DIMM ASSY	1	1	1	10
●	2DC01170		P.W.BOARD ASSY	1	1	1	3
	2DC02010		FRAME BASE (1/8)	1	1	1	2
	2DC02020		STAY SCANNER LEFT	1	1	1	2
	2DC02030		STAY SCANNER RIGHT	1	1	1	2
	2DC02040		FRAME MIDDLE (1/3)	1	1	1	2
	2DC02050		MOUNT SCANNER PCB	1	1	1	2
	2DC02060		PLATE EARTH STAY L	1	1	1	2
	2DC02090		PLATE EARTH STAY L2	1	1	1	2
	2DC02100		FILM PS LOW	1	1	1	2
●	2DC04010		COVER FRONT (1/2)	1	1	1	1
●	2DC04020		COVER LEFT (1/2)	1	1	1	1
	2DC04030		COVER REAR	1	1	1	1
●	2DC04040		COVER MPF	1	1	1	3
●	2DC04050		COVER DIMM	1	1	1	1
●	2DC04060		COVER RIGHT (1/2)	1	1	1	1
●	2DC04080		COVER TOP (1/3)	1	1	1	1
	2DC04090		PLATE SHIELD	1	1	1	1
●	2DC04100		LID TOP B		1		1
	2DC05010		LABEL CONTACT GLASS	1	1	1	8
●	2DC06010		CLUTCH FEED	1	1	1	2
	2DC06020		GUIDE TURN A	1	1	1	3
●	2DC06030		ROLLER FEED ASSY	1	1	1	2
●	2DC07010		STOPPER PAPER	1	1	1	7
●	2DC07020		POSITIONING FOLIO PAPER	1	1	1	7
	2DC07030		SPRING CASSETTE	2	2	2	7
●	2DC11010		COVER ORIGINAL HOLDER(1/2)	1	1	1	9
●	2DC11020		MAT ORIGINAL HOLDER	1	1	1	9
●	2DC11030		UPPER HINGE	2	2	2	9
●	2DC11040		LOWER HINGE	2	2	2	9
	2DC11050		TAPE ORIGINAL HOLDER	2	2	2	9
	2DC12010		UPPER FRAME SCANNER(1/2)	1	1	1	8
	2DC12020		LOWER FRAME SCANNER(1/4)	1	1	1	8
	2DC12040		SHAFT SCANNER	1	1	1	8
●	2DC12050		CONTACT GLASS	1	1	1	8
●	2DC12060		CONTACT GLASS DF	1	1	1	8
	2DC12110		MOUNT SCANNER MOTOR	1	1	1	8

SP	Part. No.	KYOCERA Part Number	Description	Quantity			Fig. No.
				120V	230V	240V	
●	2DC12120		GEAR SCANNER 39/22	1	1	1	8
●	2DC12130		GEAR SCANNER 45/18	1	1	1	8
	2DC12140		MOUNT TENSION PULLEY	1	1	1	8
●	2DC12150		PULLEY TENSION	1	1	1	8
●	2DC12160		MOTOR SCANNER	1	1	1	8
	2DC12170		SPRING TENSION	1	1	1	8
●	2DC12180		BELT SCANNER	1	1	1	8
	2DC12190		RAIL SCANNER	1	1	1	8
●	2DC12200		LAMP SCANNER	1	1	1	8
	2DC12210		STANDARD PLATE SHADING	1	1	1	8
●	2DC12280		STOPPER 8	1	1	1	8
	2DC12300		GROUND PLATE SCANNER	1	1	1	8
	2DC12310		HOLDER FFC	1	1	1	8
	2DC12330		PLATE EARTH SCANNER A	1	1	1	8
	2DC12340		PLATE EARTH SCANNER B	1	1	1	8
	2DC12350		PLATE EARTH SCANNER C	1	1	1	8
	2DC12360		TAPE CONTACT GLASS A	2	2	2	8
	2DC12370		TAPE CONTACT GLASS B	2	2	2	8
	2DC12380		TAPE CONTACT GLASS C	1	1	1	8
	2DC12390		TAPE CONTACT GLASS D	7	7	7	8
	2DC12400		TAPE FFC	2	2	2	8
	2DC12420		PLATE EARTH SCANNER D	1	1	1	8
	2DC12430		PLATE EARTH SCANNER E	1	1	1	8
	2DC12440		PLATE EARTH SCANNER F	1	1	1	8
	2DC12450		PLATE EARTH SCANNER G	1	1	1	8
	2DC13020		SHUTTER LSU	1	1	1	3
	2DC13030		MIRROR LSU	1	1	1	3
	2DC13040		SPRING FULL SENSOR	1	1	1	3
●	2DC14100		GEAR DLP 20	1	1	1	5
●	2DC14110		GEAR DLP 24	1	1	1	5
●	2DC14120		GEAR DLP 14/26/30	1	1	1	5
●	2DC14140		GEAR DLP 18/44	1	1	1	5
●	2DC14150		GEAR DLP 18/40	1	1	1	5
●	2DC16010		ROLLER TRANSFER,(C)		1	1	2
●	2DC16020		ROLLER TRANSFER,(I)	1			2
	2DC16030		PLATE EARTH BRUSH A	1	1	1	2
	2DC16040		SPRING TC R	1	1	1	2
	2DC20010		SPRING PRESS ROLLER	2	2	2	6
●	2DC20020		HEATER 230 FIXING		1	1	6
●	2DC20030		HEATER 120 FIXING	1			6

• Parts with "●" indicates the spare parts.

2DC

SP	Part. No.	KYOCERA Part Number	Description	Quantity			Fig. No.
				120V	230V	240V	
●	2DC20040		FRAME FUSER LOW (1/2)	1	1	1	6
●	2DC20050		THERMISTOR FUSER	1	1	1	6
●	2DC20060		ROLLER PRESS	1	1	1	6
●	2DC22010		MOTOR MAIN	1	1	1	4
●	2DC22020		MOUNT MACHINE DRIVE	1	1	1	4
●	2DC22030		GEAR 48/21	1	1	1	4
●	2DC23010		FAN COOLING	1	1	1	2
●	2DC25010		COVER OPERATION	1	1	1	9
●	2DC25020		SHEET OPERATION	1	1	1	9
●	2DC25030		SHEET DUST SHIELD	1	1	1	9
●	2DC25050		KEY PRINT	1	1	1	9
●	2DC25060		KEY STOP	1	1	1	9
●	2DC25070		KEY RESET	1	1	1	9
	2DC26010		SHIELD CONTROLLER (1/3)	1	1	1	2
	2DC26070		SHIELD LSU	1	1	1	3
	2DC26080		GROUND PLATE SR	1	1	1	2
	2DC26100		CONTACT TRANSFER	1	1	1	2
	2DC26110		PLATE EARTH LSU	1	1	1	3
	2DC26120		TAPE FFC M/S	1	1	1	2
	2DC26130		FILM MAIN PWB	1	1	1	2
	2DC27010		CONN.CORD ASSY ENGINE-MAIN	1	1	1	2
	2DC27020		CONN.CORD ASSY ENGINE-SCANNER1	1	1	1	2
	2DC27030		CONN.CORD ASSY ENGINE-SCANNER2	1	1	1	2
	2DC27040		CONN.CORD ASSY SCANNER-MAIN1	1	1	1	8
	2DC27050		CONN.CORD ASSY SCANNER-PANEL	1	1	1	8
	2DC27070		WIRE MAIN-LSU	1	1	1	3
	2DC27080		CONN.CORD ASSY SCANNER-MAIN2	1	1	1	8
	2DC27090		CONN.CORD ASSY SCANNER-CCD	1	1	1	8
	2DC27110		CONN.CORD ASSY ENGINE-MMOT	1	1	1	2
	2DC27120		CONN.CORD ASSY ENGINE-BIASH	1	1	1	2
	2DC27130		CONN.CORD ASSY ENGINE-BIASY	1	1	1	2
	2DC27140		WIRE ENGINE-LSU	1	1	1	3
	2DC27150		CORE FFC1	1	1	1	8
	2DC27160		CORE FFC2	1	1	1	2
●	2DC28070		PRINTED W.BOARD PS100	1			2
●	2DC28080		TRANS ASSY	1	1	1	2
●	2DC28100		PRINTED W.BOARD PS200		1	1	2
●	2DC68090		TE SENSOR ASSY	1	1	1	3
●	2DC68100		FULL SENSOR ASSY	1	1	1	3
●	2DC68110		P.W.BOARD ASSY(SP)	1	1	1	2

SP	Part. No.	KYOCERA Part Number	Description	Quantity			Fig. No.
				120V	230V	240V	
●	2DC68120		P.W.BOARD ASSY(SP)	1	1	1	2
●	2DC93010		PARTS,IMAGE SCANNER SP	1	1	1	8
●	2DC93020		PARTS,OPERATION PANEL,SP	1	1	1	9
●	2DC93030		PU-100 PARTS PROCESS UNIT SP		1	1	5
●	2DC93040		PU-101 PARTS PROCESS UNIT (U) SP	1			5
●	2DC93050		FK-100(E) PARTS FUSER UNIT		1	1	6
●	2DC93060		FK-100(U) PARTS FUSER UNIT	1			6
●	2DC93070		LK-100 PARTS LASER SCANNER	1	1	1	3
●	2DC93080		DR-100PARTS DRIVE UNIT	1	1	1	4
●	2DC93090		PARTS,CASSETTE SP	1	1	1	7
●	2DC93100		PARTS,MPF COVER SP	1	1	1	3
●	2DC93110		PARTS,PLATEN COVER SP	1	1	1	9
●	2DD04020		LID TOP	1		1	1
	33927590		CORE 7-15X18	1	1	1	8
	B8023060		BINDING TAP-TITE B SCREW M3X6	2	2	2	3

• Parts with "●" indicates the spare parts.

## CLASSIFICATION OF THE SCREWS IN ILLUSTRATION

<u>REF.</u>	<u>ITEM #</u>	<u>DESCRIPTION</u>
ANG	B4073080	TRIPLE TAP-TITE B SCREW M3X8
ANJ	B8023120	BINDING TAP-TITE B SCREW M3X12
BHA	B3023060	BINDING TAP TITE S SCREW M3X6
BHE	B3023050	BINDING TAP-TITE S SCREW M3X5
BUD	B8204100	BINDING TAP-TITE B SCREW M4X10
BUL	B8023060	BINDING TAP-TITE B SCREW M3X6
EMQ	B3204060	BINDING TAP-TITE S SCREW M4X6
E03	D1000300	STOP RING (E-3)
E05	D1000500	STOP RING (E-5)
HCM	B4213080	TRIPLE SCREW M3X8(UNICRO)
HCN	B8023080	BINDING TAP-TITE B SCREW M3X8
HCP	B4003060	TRIPLE SEREW M3X6
HCX	B8023100	BINDING TAP-TITE B SCREW M3X10
HDL	B4073050	TRIPLE TAP-TITE B SCREW M3X5
HEB	B4094100	PEDESTALHEAD TAP-TITE B SCREW(CHROMATING)M4X10

<u>REF.</u>	<u>ITEM #</u>	<u>DESCRIPTION</u>
HEC	B4090060	PEDESTALHEAD TAP-TIGHT B SCREW M3X6
KAK	E0020080	SPRING PIN 2X8
KDE	E1120100	SPRING PIN M2 X 10 SUS-DP XX
NAB	C1003000	NUT NM3
NAD	C1004000	NUT NM4
NCZ	B4213100	TRIPLE SCREW M3X10(UNICRO)
NGL	C2806130	POLY SLIDER M6.2X 13X.25T PA
RDD	D4000400	STOP RING CSTW-4
TGB	C4204000	CROWN WASHER TWM4
WPM	C2891100	POLY-SLIDER WASHER 4.1X10X0.3T
WPP	C2891080	POLY CUT WASHER 5.2X8X0.25T
XBE	C2894650	SHIM 4.1X0.25T
XCC	C2892950	SHIM 6.2X9.5X0.5T
XEJ	C3790080	WAVE WASHER SUS WW4.3X8X0.2T

**KYOCERA MITA EUROPE B.V.**

Hoeksteen 40, 2132 MS Hoofddorp,  
The Netherlands  
Phone: +31.(0)20.654.000  
Home page: <http://www.kyoceramita-europe.com>  
Email: [info@kyoceramita-europe.com](mailto:info@kyoceramita-europe.com)

**KYOCERA MITA NEDERLAND B.V.**

Hoeksteen 40 2132 MS Hoofddorp  
The Netherlands  
Phone: +31.(0)20.587.7200

**KYOCERA MITA (UK) LTD.**

8 Beacontree Plaza  
Gillette Way,  
Reading Berks RG2 0BS, UK  
Phone: +44.(0)118.931.1500

**KYOCERA MITA ITALIA S.P.A.**

Via Verdi 89 / 91 20063 Cernusco sul Naviglio,  
Italy  
Phone: +39.02.92179.1

**S.A. KYOCERA MITA BELGIUM N.V.**

Hermesstraat 8A 1930 Zaventem Belgium  
Phone: +32.(0)2.720.9270

**KYOCERA MITA FRANCE S.A.**

Parc Les Algorithmes  
Saint Aubin  
91194 GIF-SUR-YVETTE  
France  
Phone: +33.(0)1.6985.2600

**KYOCERA MITA ESPAÑA S.A.**

Edificio Kyocera, Avda de Manacor N. 2,  
Urb. Parque Rozas 28290 Las Rozas,  
Madrid, Spain  
Phone: +34.(0)91.631.8392

**KYOCERA MITA FINLAND OY**

Kirvesmiehenkatu 4 00810 Helsinki,  
Finland  
Phone: +358.(0)9.4780.5200

**KYOCERA MITA (SCHWEIZ) AG**

Holzliwisen Industriestrasse 28  
8604 Volketswil, Switzerland  
Phone: +41.(0)1.908.4949

**KYOCERA MITA DEUTSCHLAND GMBH**

Mollsfield 12 D-40670 Meerbusch,  
Germany  
Phone: +49.(0)2159.918.0

**KYOCERA MITA GMBH AUSTRIA**

Eduard-Kittenberger Gasse 95  
1230 Wien, Austria  
Phone: +43.(0)1.86338.0

**KYOCERA MITA SVENSKA AB**

Box 1402 171 27 Solna, Sweden  
Phone: +46.(0)8.546.550.00

**KYOCERA MITA NORGE**

Postboks 150 Oppsal, NO 0619 Oslo  
Olaf Helsetsvet 6, NO 0694 Oslo  
Phone: +47.(0)22.62.73.00

**KYOCERA MITA DANMARK A/S**

Hovedkontor: Slotsmarken 11,  
DK-2970 Hørsholm, Denmark  
Phone: +45.(70)22.3880

**KYOCERA MITA PORTUGAL LDA.**

Rua de Campolide 55-5° Dt° 1070-029  
Lisboa, Portugal  
Phone: +351.(0)21.032.0900

**KYOCERA MITA SOUTH AFRICA (PTY) LTD.**

527 Kyalami Boulevard,  
Kyalami Business Park 1685 Midrand South  
Phone: +27.(0)11.466.3290

**KYOCERA MITA AMERICA, INC.****Headquarters:**

225 Sand Road, P.O. Box 40008,  
Fairfield, New Jersey 07004-0008,  
U.S.A.  
Phone: (973) 808-8444

**KYOCERA MITA AUSTRALIA PTY. LTD.**

Level 3, 6-10 Talavera Road, North Ryde,  
N.S.W. 2113 Australia  
Phone: (02) 9888-9999

**KYOCERA MITA NEW ZEALAND LTD.**

1-3 Parkhead Place, Albany  
P.O. Box 302 125 NHPC, Auckland,  
New Zealand  
Phone: (09) 415-4517

**KYOCERA MITA (THAILAND) CORP., LTD.**

9/209 Ratchada-Prachachem Road,  
Bang Sue, Bangkok 10800, Thailand  
Phone: (02) 586-0320

**KYOCERA MITA SINGAPORE PTE LTD.**

121 Genting Lane, 3rd Level,  
Singapore 349572  
Phone: 67418733

**KYOCERA MITA HONG KONG LIMITED**

11/F., Mita Centre,  
552-566, Castle Peak Road,  
Tsuen Wan, New Territories,  
Hong Kong  
Phone: 24297422

**KYOCERA MITA TAIWAN CORPORATION**

7F-1~2, No.41, Lane 221, Gangchi Rd.  
Neihu District, Taipei, Taiwan, 114. R.O.C.  
Phone: (02) 87511560

**KYOCERA MITA CORPORATION**

2-28, 1-chome, Tamatsukuri, Chuo-ku  
Osaka 540-8585, Japan  
Phone: (06) 6764-3555  
<http://www.kyoceramita.com>

© 2003 KYOCERA MITA CORPORATION

 **KYOCERA** is a trademark of Kyocera Corporation

**mita** is a registered trademark of KYOCERA MITA CORPORATION



Printed in Holland