

# PIXUS MP800 / PIXMA MP800

## PIXMA MP800R

# PARTS CATALOG

REVISION 1



0581B001AA	PIXUS MP800/ 100V(JP)	0582B002AA	PIXMA MP800R/ 120V(US)
0581B002AA	PIXMA MP800/ 120V(US)	0582B005AA	PIXMA MP800R/ 220V-240V(EUM)
0581B003AA	PIXMA MP800/ 120V(CA)	0582B007AA	PIXMA MP800R/ 220V-240V(GB/EU)
0581B004AA	PIXMA MP800/ 220V-240V(EUM)	0582B008AA	PIXMA MP800R/ 220V-240V(AU)
0581B006AA	PIXMA MP800/ 220V-240V(EMB)	0582B009AA	PIXMA MP800R/ 220V-240V(ASA)
0581B007AA	PIXMA MP800/ 220V-240V(GB)		
0581B008AA	PIXMA MP800/ 220V-240V(AU)		
0581B009AA	PIXMA MP800/ 220V-240V(EUM)		

FEB. 2006

**QY8-31CK-010**

COPYRIGHT © 2006 CANON INC. CANON PIXUS MP800/PIXMA MP800/PIXMA MP800R 0206 0.00-1

## **Application**

This manual has been issued by Canon Inc. for qualified person to learn technical theory, installation, maintenance, and repair of products. This manual covers all localities where the products are sold. For this reason, there may be information in this manual that does not apply to your locality.

## **Corrections**

This manual could include technical inaccuracies or typographical errors due to improvements or changes in the products. When changes occur in applicable products or in the content of this manual, Canon will release technical information as the need arises. In the event of major changes in the contents of this manual over a long or short period. Canon will issue a new editions of this manual. The following paragraph does not apply to any countries where such provisions are inconsistent with local law.

## **Trademarks**

The product names and company names described in this manual are the registered trademarks of the individual companies.

## **Copyright**

This manual is copyrighted with all rights reserved. Under the copyright laws, this manual may not be copied, reproduced or translated into another language, in whole or in part, without the written consent of Canon Inc.

Copyright © 2006 by Canon Inc.

CANON INC.

Inkjet Device Quality Assurance Div. 2

451, Tsukagoshi, 3-chome, Saiwai-ku, Kawasaki-shi, Kanagawa 212-8530, Japan

This manual was created under Microsoft® Windows® 2000.

Parts layout pictures were edited using Adobe® Photoshop® 7.0. KEY No. were created using Adobe® Illustrator® 10.

HTML files were created using Microsoft® FrontPage® 2000.

## ABOUT THIS MANUAL

### A. ILLUSTRATION INDEX

For illustration index, the parts layout illustrations in this parts catalog are listed in abbreviated form in order of illustration number to identify the pages they appear on. To find an illustration of a part, see the ILLUSTRATION INDEX.

### B. PARTS LAYOUT & PARTS LIST

Parts layout illustration

#### a) Parts search

Find a part from the parts layout illustration and find its key number from the parts list to identify the part number and name. For screws, nuts, washers, lock washers, pins, spacers, see SCREWS & WASHERS LIST.

Note: If parts have the same or similar shape but different specifications, their key number is assigned to several part numbers and names in the parts list.

#### b) Parts replacement procedure

To replace parts, the parts layout illustrations have figure numbers according to the disassembly procedure of the product. The parts that require careful work are shown the illustration.

Parts list

#### a) FIGURE & KEY No.

The FIGURE & KEY No. column corresponds to the key numbers assigned to the parts in the parts layout illustration.

#### b) PART NUMBER

The PART NUMBER column gives the part numbers corresponding to the key numbers. To order a part, indicate the part number clearly.

Note: Parts marked NPN are not service parts.

#### c) RANK

The service parts with N in the RANK column are order parts.

#### d) QTY

The QTY column gives the number of parts in the corresponding components layout illustration.

#### e) DESCRIPTION

The DESCRIPTION column gives the part names in English.

To order a part, indicate the part name, too.

### C. OPTIONS & CONSUMABLES

These are illustrations and a list of units that can be used as optional consumable equipments.

### D. SCREWS & WASHERS LIST

This is a list of screws, nuts, washers, lock washers, pins, and spacers.

The QTY column does not give the number of parts used.

### E. TOOL LIST

This is a list of tools used for servicing products.

### F. NUMERICAL INDEX

All the parts listed in this parts catalog are arranged in order of part number. You can identify part locations and names from the NUMERICAL INDEX.

# Contents

## A. ILLUSTRATION INDEX ▶

## B. PARTS LAYOUT & PARTS LIST

**FIGURE 1** PACING CONTENTS & PRINT HEAD

**FIGURE 2** AC ADAPTER

**FIGURE 3** EXTERNAL COVERS

**FIGURE 4** DOCUMENT PRESSURE PLATE UNIT

**FIGURE 5** SCANNER UNIT & OPERATION PANEL UNIT

**FIGURE 6** MAIN CASE UNIT

**FIGURE 7** NIC BOARD UNIT (MP800R)

**FIGURE 8** CARD BOARD ASS'Y & IRDA BOARD ASS'Y

**FIGURE 9** LOGIC BOARD ASS'Y

**FIGURE 10** BOTTOM CASE UNIT & INK ABSORBER

**FIGURE 11** SHEET FEED UNIT

**FIGURE 12** CARRIAGE UNIT

**FIGURE 13** PLATEN UNIT

**FIGURE 14** PURGE UNIT

**FIGURE 15** PAPER FEED & CARRIAGE LIFT PART

## C. OPTION & CONSUMABLES ▶

## D. SCREW & WASHER LIST ▶

## E. TOOL ▶

## F. NUMERICAL INDEX ▶

FIGURE 1 PACKING CONTENTS & PRINT HEAD



FIGURE 2 AC ADAPTER



FIGURE 3 EXTERNAL COVERS




FIGURE 4 DOCUMENT PRESSURE PLATE UNIT




FIGURE 5 SCANNER UNIT & OPERATION PALNE UNIT







FIGURE 6 MAIN CASE UNIT




**FIGURE 7** NIC BOARD UNIT(MP800R)




**FIGURE 8** CARD BOARD ASS'Y & IRDA BOARD ASS'Y




**FIGURE 9** LOGIC BOARD ASS'Y



**FIGURE 10** BOTTOM CASE UNIT & INK ABSORBER



**FIGURE 11** SHEET FEED UNIT



**FIGURE 12** CARRIAGE UNIT




FIGURE 13 PLATEN UNIT




FIGURE 14 PURGE UNIT




FIGURE 15 PAPER FEED & CARRIAGE LIFT PART




FIGURE 16 OPTION & CONSUMABLES



FIGURE 17 TOOL





## B. PARTS LAYOUT & PARTS LIST

[Contents](#) [ILLUSTRATION INDEX](#) [NUMERICAL INDEX](#) 

**FIGURE 1 PACKING CONTENTS & PRINT HEAD**





FIGURE & KEY No.		PART NUMBER	RANK	QTY	DESCRIPTION	REMARKS
1 -	1	QA4-1117-000		1	TRAY, CD SUB	W/ CDR PRINTING
	2	QL2-1203-000		1	CDR TRAY ASS'Y	W/ CDR PRINTING
	3	QY6-0061-000		1	PRINT HEAD	
	4	QK1-0278-000		1	CORD, POWER	100V-120V
		QK1-0279-000		1	CORD, POWER	220V-240V
		QK1-0286-000		1	CORD, POWER	100V-120V(JP) FOR MP800
		QK1-1061-000		1	CORD, POWER	220V-240V(AU)
		WT3-5156-000		1	CORD, POWER	220V-240V(GB, HK)
	5	QC1-8513-000		1	LABEL, PANEL	EUM, EMB



**FIGURE 2 AC ADAPTER**



FIGURE & KEY No.		PART NUMBER	RANK	QTY	DESCRIPTION	REMARKS
2 -	1	QK1-1728-000		1	AC ADAPTER: 100V-240V 50/60HZ	

FIGURE 3 EXTERNAL COVERS




FIGURE & KEY No.		PART NUMBER	RANK	QTY	DESCRIPTION	REMARKS
3 -	1	QC1-7981-000		1	EMBLEM, PIXMA	
		QC1-8015-000		1	EMBLEM, PIXUS	FOR MP800
	2	QM2-3008-000		1	PAPER SUPPORT UNIT	
	3	QC1-8422-000		1	COVER, CABLE	
	4	QC1-8446-000		1	DOOR, CARD	
	5	QC1-8444-000		1	COVER, FRONT R	
	6	QC1-8449-000		1	WINDOW, IRDA	
	7	QC1-8423-000		1	GUIDE, CARD LED	
	8	QC1-8442-000		1	COVER, SIDE R	FOR MP800
		QC1-8494-000		1	COVER, SIDE R	FOR MP800R
	9	QC1-8443-000		1	COVER, FRONT L	
	10	QL2-1237-000		1	LEFT SIDE COVER UNIT	
	11	QC1-6573-000		1	DAMPER, DOOR	
	12	QM2-3007-000		1	FRONT DOOR UNIT	
	13	QM2-3031-000		1	SCANNER STOP ARM UNIT	
	14	QM2-3021-000		2	SHOCK ABSORBER UNIT	
	15	QM2-3011-000		1	CASSETTE UNIT	
	16	QC1-8445-000		1	PANEL, CASSETTE FRONT	
	17	QC1-8448-000		1	COVER, CASSETTE	

FIGURE 4 DOCUMENT PRESSURE PLATE UNIT




FIGURE & KEY No.		PART NUMBER	RANK	QTY	DESCRIPTION	REMARKS
4 -	1	QM2-3013-000		1	DOCUMENT PRESSURE PLATE UNIT	
	2	QC1-8457-000		1	COVER, DOCUMENT PRESSURE PLATE R	
	3	QC1-8456-000		1	COVER, DOCUMENT PRESSURE PLATE L	
	4	QC1-8416-000		1	SHEET, DOCUMENT PRESSURE	
	5	QC1-8452-000		1	FRAME, DOCUMENT PRESSURE SHEET	
	6	QM2-3030-000		1	DOCUMENT PRESSURE PLATE COVER UNIT	
	7	QM2-3028-000		1	FILM GUIDE SLEEVE UNIT	
	8	QC1-8455-000		1	GUIDE, MOUNT FILM	



FIGURE 5 SCANNER UNIT & OPERATION PANEL UNIT




FIGURE & KEY No.		PART NUMBER	RANK	QTY	DESCRIPTION	REMARKS
5 -	1	QC1-8434-000		1	PANEL, LCD, PIXUS	FOR MP800
		QC1-8500-000		1	PANEL, LCD, PIXMA	FOR MP800
		QC1-8532-000		1	PANEL, LCD	FOR MP800R
	2	QC1-8425-000		1	PANEL, OPERATION R	JP FOR MP800
		QC1-8499-000		1	PANEL, OPERATION R	UA, CA, AU, ASA
		QC1-8502-000		1	PANEL, OPERATION R	EUM, EMB, GB
	3	QC1-8424-000		1	PANEL, OPERATION L	JP FOR MP800
		QC1-8498-000		1	PANEL, OPERATION L	UA, CA, AU, ASA
		QC1-8501-000		1	PANEL, OPERATION L	EUM, EMB, GB
	4	QM2-3015-000		1	OPERATION PANEL UNIT	
	5	QC1-8435-000		1	WINDOW, LCD	
	6	QM2-3029-000		1	LCD VIEWER UNIT	
	7	WE8-5266-000		2	CORE	MP800-QTY 1, MP800R-QTY 2
	8	QK1-1708-000		1	SCANNER UNIT	
	9	QC1-8404-000		1	LOCK, ARM	
	10	QC1-8478-000		1	COVER, MIST	
	11	QC1-8465-000		1	HOLDER, MIST COVER	
	12	WE8-5071-000		1	CORE	

FIGURE 6 MAIN CASE UNIT




FIGURE & KEY No.		PART NUMBER	RANK	QTY	DESCRIPTION	REMARKS
6 -	1	QM2-3115-000		1	SOLENOID RELAY HARNESS ASS'Y	FOR MP800
		QM2-3706-000		1	SOLENOID RELAY HARNESS ASS'Y	FOR MP800R
	2	VS1-7165-002		2	CONNECTOR, CABLE	MP800-QTY 1, MP800R-QTY 2
	3	QM2-3117-000		1	SCANNER OPEN SENSOR UNIT	FOR MP800
		QM2-3469-000		1	SCANNER OPEN SENSOR UNIT	FOR MP800R
	4	QM2-3006-020		1	MAIN CASE UNIT	
	5	QK1-1726-000		1	SOLENOID	
	6	QC1-8447-000		1	BUTTON, OPEN	
	7	QM2-3467-000		1	SCANNER OPEN RELAY HARNESS ASS'Y	FOR MP800R
	8	QC1-8537-000		1	INSTRUCTION LABEL	

FIGURE 7 NIC BOARD UNIT(MP800R)




FIGURE & KEY No.		PART NUMBER	RANK	QTY	DESCRIPTION	REMARKS
7 -	1	QM2-3468-000		1	GROUND HARNESS	FOR MP800R
	2	WE8-5881-000		1	CORE, RING	FOR MP800R
	3	QM2-3466-000		1	NIC SUB HARNESS ASS'Y	FOR MP800R
	4	QM2-3125-000		1	SUB INTERFACE BOARD ASS'Y	FOR MP800R
	5	QM2-3465-000		1	NIC HARNESS ASS'Y	FOR MP800R
	6	QM2-3039-000		1	NIC BOARD ASS'Y	FOR MP800R

FIGURE 8 CARD BOARD ASS'Y & IRDA BOARD ASS'Y






FIGURE & KEY No.		PART NUMBER	RANK	QTY	DESCRIPTION	REMARKS
8 -	1	QM2-3111-000		1	PICT BRIDGE HARNESS ASS'Y	FOR MP800
		QM2-3705-000		1	PICT BRIDGE HARNESS ASS'Y	FOR MP800R
	2	QM2-3113-000		1	MEMORY CARD HARNESS ASS'Y	FOR MP800
		QM2-3704-000		1	MEMORY CARD HARNESS ASS'Y	FOR MP800R
	3	QM2-3110-000		1	IRDA BOARD UNIT	
	4	QC1-8421-000		1	PLATE, CARD SLOT	
	5	QM2-2853-000		1	CARD BOARD ASS'Y	
	6	QC1-6199-000		1	COVER, CDR TRAY BASE	W/O CDR PRINTING
	7	QM2-3017-000		1	CDR TRAY BASE UNIT	
	8	QC1-7454-000		2	ARM, RELEASE	

FIGURE 9 LOGIC BOARD ASS'Y




FIGURE & KEY No.		PART NUMBER	RANK	QTY	DESCRIPTION	REMARKS
9 -	1	QM2-3116-000		1	SCANNER MOTOR RELAY HARNESS ASS'Y	FOR MP800
		QM2-3708-000		1	SCANNER MOTOR RELAY HARNESS ASS'Y	FOR MP800R
	2	VS1-7165-004		1	CONNECTOR, CABLE	
	3	QM2-3022-000		1	LOGIC BOARD ASS'Y	FOR MP800
		QM2-3035-000		1	LOGIC BOARD ASS'Y	FOR MP800R

**FIGURE 10 BOTTOM CASE UNIT & INK ABSORBER**




FIGURE & KEY No.		PART NUMBER	RANK	QTY	DESCRIPTION	REMARKS
10 -	1	QY5-0153-000		1	ABSORBER KIT	
	2	QM2-3009-000		1	BOTTOM CASE UNIT	FOR MP800
		QM2-3034-000		1	BOTTOM CASE UNIT	FOR MP800R
	3	QC1-8533-000		1	SPONGE, MIST TRAP	
	4	QC1-8525-000		1	SHEET, MIST COVER	

FIGURE 11 SHEET FEED UNIT




FIGURE & KEY No.		PART NUMBER	RANK	QTY	DESCRIPTION	REMARKS
11 -	1	QM2-3114-000		1	DC CONNECTOR ASS'Y	
	2	QM2-3119-000		1	MOTOR MULTI HARNESS ASS'Y	
	3	QM2-3124-000		1	SENSOR MULTI HARNESS ASS'Y	FOR MP800
		QM2-3707-000		1	SENSOR MULTI HARNESS ASS'Y	FOR MP800R
	4	WE8-5881-000		1	CORE, RING	
	5	QC1-8013-000		1	COVER, PAPER FEED GUIDE	
	6	QM2-3016-000		1	SHEET FEED UNIT	



FIGURE 12 CARRIAGE UNIT




FIGURE & KEY No.		PART NUMBER	RANK	QTY	DESCRIPTION	REMARKS
12 -	1	QC1-6526-000		1	FILM, TIMING SLIT STRIP	
	2	QC1-6201-000		1	SPRING, LEAF	
	3	QC1-6207-000		1	CLIP, SHAFT R	
	4	QC1-6306-000		1	RING, CARRIAGE SHAFT	
	5	QC1-6209-000		1	CAM, CARRIAGE SHAFT R	
	6	QC1-6206-000		1	CLIP, SHAFT L	
	7	QK1-1500-000		1	MOTOR, CARRIAGE	
	8	QC1-6208-000		1	CAM, CARRIAGE SHAFT L	
	9	WE8-5266-000		1	CORE	
	10	QM2-3025-020		1	CARRIAGE UNIT	
	11	QC1-6523-000	N	1	SHAFT, CARRIAGE	
	12	QL2-0938-000		1	IDLER PULLEY ASS'Y	
	13	QC1-6202-000		1	SPRING, COIL	
	14	WE8-6323-000		1	CORE, RING	FOR MP800R

FIGURE 13 PLATEN UNIT




FIGURE & KEY No.		PART NUMBER	RANK	QTY	DESCRIPTION	REMARKS
13 -	1	QC1-6619-000		1	SPRING, TORSION	
	2	QC1-6272-000		1	ABSORBER, INK	
	3	QM2-3026-000		1	PLATEN UNIT	

FIGURE 14 PURGE UNIT




FIGURE & KEY No.		PART NUMBER	RANK	QTY	DESCRIPTION	REMARKS
14 -	1	QM2-3032-000		1	PURGE UNIT	
	2	QC1-6499-000		1	COVER, WASTE INK TUBE	
	3	QC1-6458-000		1	TUBE, WASTE INK	
	4	QC1-6460-000		1	HOLDER, WASTE INK TUBE	

FIGURE 15 PAPER FEED & CARRIAGE LIFT PART






FIGURE & KEY No.		PART NUMBER	RANK	QTY	DESCRIPTION	REMARKS
15 -	1	QC1-6216-000		1	CAM, SWING ARM LOCK	
	2	QL2-0936-000		1	PR LIFT SHAFT ASS'Y	
	3	QC1-6232-000		2	SPRING, TENSION	
	4	QM2-2265-000		1	PAPER GUIDE UNIT	
	5	QC1-6226-000		4	SPRING, TORSION	
	6	QM2-2201-000		1	PRESSURE ROLLER ASS'Y	
	7	QM2-3092-000		1	CARRIAGE LIFT SENSOR UNIT	
	8	QC1-6213-000		1	GEAR, INPUT CARRIAGE LIFT	
	9	QM2-2232-000		1	CARRIAGE LIFT GEAR BASE UNIT	
	10	QC1-6471-000		1	SPRING, TENSION	
	11	QC1-6217-000		1	LEVER, SWING ARM LOCK	
	12	QM2-2677-000		1	PE SENSOR UNIT	
	13	QK1-1502-000		1	MOTOR, PAPER FEED	
	14	QC1-6227-000		1	BUSHING	
	15	QC1-6229-000		1	FILM, TIMING SLIT DISK	
	16	QC1-6230-000		1	BELT, PAPER FEED	
	17	QL2-0950-000		1	FEED ROLLER ASS'Y	
	18	QC1-6225-000		1	GEAR, EJECT	
	19	QM2-2683-000		1	TIMING SENSOR UNIT	



FIGURE 16 OPTION & CONSUMABLES




FIGURE & KEY No.		PART NUMBER	RANK	QTY	DESCRIPTION	REMARKS
16 -	1	QY5-0155-000	N	1	BLUETOOTH UNIT, BU-20	
	2	QY5-0156-000	N	1	CAP, BU-20	
	3	NPN		1	BLACK INK TANK BCI-9BK	CONSUMABLES
		NPN		1	BLACK INK TANK BCI-7eBK	CONSUMABLES
		NPN		1	YELLOW INK TANK BCI7eY	CONSUMABLES
		NPN		1	MAGENTA INK TANK BCI-7eM	CONSUMABLES
		NPN		1	CYAN INK TANK BCI-7eC	CONSUMABLES
	4	NPN		1	BLACK INK TANK PGI-5BK	CONSUMABLES
		NPN		1	BLACK INK TANK CLI-8BK	CONSUMABLES
		NPN		1	YELLOW INK TANK CLI-8Y	CONSUMABLES
		NPN		1	MAGENTA INK TANK CLI-8M	CONSUMABLES
		NPN		1	CYAN INK TANK CLI-8C	CONSUMABLES

## D. SCREW & WASHER LIST

[Contents](#)
[NUMERICAL INDEX](#)

FIGURE & KEY No.		PART NUMBER	RANK	QTY	DESCRIPTION	REMARKS
S -	1	XB4-7300-805			SCREW, TP, BH3X8	
	2	XB4-7301-005			SCREW, M3x10	
	3	XB2-7300-605			SCREW, W/WASHER, M3X6	
	4	XB4-7300-809			SCREW, B-TIGHT: M3 X 8 MM	
	5	XA4-9170-605			SCREW, TAPING PAN HEAD, M1.7X6	
	6	XB6-7300-605			SCREW, MACHINE, WASHER HEAD, M3x6	
	7	XB2-4300-805			SCREW, M3	
	8	XB1-2300-405			SCREW, MACH.BH, M3X4	
	9	XA9-1258-000			SCREW, TAP, WASHER HEAD, M3X12	
	10	XB2-4300-605			SCREW, W/WASHER, M3X6	
	11	XB4-7300-605			SCREW, BH M3X6	
	12	XA9-1437-000			SCREW, BIND, M2.6X4(RED)	
	13	XB1-2200-505			SCREW, MACH, TRUSS HEAD, M2X5	

**This page intentionally left blank**

FIGURE 16 TOOL



FIGURE & KEY No.		PART NUMBER	RANK	QTY	DESCRIPTION	REMARKS
T -	1	QY9-0057-000		1	LUBE, FLOIL KG107A, OIL	

# F. NUMERICAL INDEX

Contents ILLUSTRATION INDEX

PART NUMBER	FIGURE & KEY No.	DESCRIPTION	PART NUMBER	FIGURE & KEY No.	DESCRIPTION
QA4-1117-000	1 - 1	TRAY, CD SUB	QC1-8513-000	1 - 5	LABEL, PANEL
QC1-6199-000	8 - 6	COVER, CDR TRAY BASE	QC1-8525-000	10 - 4	SHEET, MIST COVER
QC1-6201-000	12 - 2	SPRING, LEAF	QC1-8532-000	5 - 1	PANEL, LCD
QC1-6202-000	12 - 13	SPRING, COIL	QC1-8533-000	10 - 3	SPONGE, MIST TRAP
QC1-6206-000	12 - 6	CLIP, SHAFT L	QC1-8537-000	6 - 8	INSTRUCTION LABEL
QC1-6207-000	12 - 3	CLIP, SHAFT R	QK1-0278-000	1 - 4	CORD, POWER
QC1-6208-000	12 - 8	CAM, CARRIAGE SHAFT L	QK1-0279-000	1 - 4	CORD, POWER
QC1-6209-000	12 - 5	CAM, CARRIAGE SHAFT R	QK1-0286-000	1 - 4	CORD, POWER
QC1-6213-000	15 - 8	GEAR, INPUT CARRIAGE LIFT	QK1-1061-000	1 - 4	CORD, POWER
QC1-6216-000	15 - 1	CAM, SWING ARM LOCK	QK1-1500-000	12 - 7	MOTOR, CARRIAGE
QC1-6217-000	15 - 11	LEVER, SWING ARM LOCK	QK1-1502-000	15 - 13	MOTOR, PAPER FEED
QC1-6225-000	15 - 18	GEAR, EJECT	QK1-1708-000	5 - 8	SCANNER UNIT
QC1-6226-000	15 - 5	SPRING, TORSION	QK1-1726-000	6 - 5	SOLENOID
QC1-6227-000	15 - 14	BUSHING	QK1-1728-000	2 - 1	AC ADAPTER: 100V-240V 50/60HZ
QC1-6229-000	15 - 15	FILM, TIMING SLIT DISK	QL2-0936-000	15 - 2	PR LIFT SHAFT ASS'Y
QC1-6230-000	15 - 16	BELT, PAPER FEED	QL2-0938-000	12 - 12	IDLER PULLEY ASS'Y
QC1-6232-000	15 - 3	SPRING, TENSION	QL2-0950-000	15 - 17	FEED ROLLER ASS'Y
QC1-6272-000	13 - 2	ABSORBER, INK	QL2-1203-000	1 - 2	CDR TRAY ASS'Y
QC1-6306-000	12 - 4	RING, CARRIAGE SHAFT	QL2-1237-000	3 - 10	LEFT SIDE COVER UNIT
QC1-6458-000	14 - 3	TUBE, WASTE INK	QM2-2201-000	15 - 6	PRESSURE ROLLER ASS'Y
QC1-6460-000	14 - 4	HOLDER, WASTE INK TUBE	QM2-2232-000	15 - 9	CARRIAGE LIFT GEAR BASE UNIT
QC1-6471-000	15 - 10	SPRING, TENSION	QM2-2265-000	15 - 4	PAPER GUIDE UNIT
QC1-6499-000	14 - 2	COVER, WASTE INK TUBE	QM2-2677-000	15 - 12	PE SENSOR UNIT
QC1-6523-000	12 - 11	SHAFT, CARRIAGE	QM2-2683-000	15 - 19	TIMING SENSOR UNIT
QC1-6526-000	12 - 1	FILM, TIMING SLIT STRIP	QM2-2853-000	8 - 5	CARD BOARD ASS'Y
QC1-6573-000	3 - 11	DAMPER, DOOR	QM2-3006-020	6 - 4	MAIN CASE UNIT
QC1-6619-000	13 - 1	SPRING, TORSION	QM2-3007-000	3 - 12	FRONT DOOR UNIT
QC1-7454-000	8 - 8	ARM, RELEASE	QM2-3008-000	3 - 2	PAPER SUPPORT UNIT
QC1-7981-000	3 - 1	EMBLEM, PIXMA	QM2-3009-000	10 - 2	BOTTOM CASE UNIT
QC1-8013-000	11 - 5	COVER, PAPER FEED GUIDE	QM2-3011-000	3 - 15	CASSETTE UNIT
QC1-8015-000	3 - 1	EMBLEM, PIXUS	QM2-3013-000	4 - 1	DOCUMENT PRESSURE PLATE UNIT
QC1-8404-000	5 - 9	LOCK, ARM	QM2-3015-000	5 - 4	OPERATION PANEL UNIT
QC1-8416-000	4 - 4	SHEET, DOCUMENT PRESSURE	QM2-3016-000	11 - 6	SHEET FEED UNIT
QC1-8421-000	8 - 4	PLATE, CARD SLOT	QM2-3017-000	8 - 7	CDR TRAY BASE UNIT
QC1-8422-000	3 - 3	COVER, CABLE	QM2-3021-000	3 - 14	SHOCK ABSORBER UNIT
QC1-8423-000	3 - 7	GUIDE, CARD LED	QM2-3022-000	9 - 3	LOGIC BOARD ASS'Y
QC1-8424-000	5 - 3	PANEL, OPERATION L	QM2-3025-020	12 - 10	CARRIAGE UNIT
QC1-8425-000	5 - 2	PANEL, OPERATION R	QM2-3026-000	13 - 3	PLATEN UNIT
QC1-8434-000	5 - 1	PANEL, LCD, PIXUS	QM2-3028-000	4 - 7	FILM GUIDE SLEEVE UNIT
QC1-8435-000	5 - 5	WINDOW, LCD	QM2-3029-000	5 - 6	LCD VIEWER UNIT
QC1-8442-000	3 - 8	COVER, SIDE R	QM2-3030-000	4 - 6	DOCUMENT PRESSURE PLATE COVER UNIT
QC1-8443-000	3 - 9	COVER, FRONT L	QM2-3031-000	3 - 13	SCANNER STOP ARM UNIT
QC1-8444-000	3 - 5	COVER, FRONT R	QM2-3032-000	14 - 1	PURGE UNIT
QC1-8445-000	3 - 16	PANEL, CASSETTE FRONT	QM2-3034-000	10 - 2	BOTTOM CASE UNIT
QC1-8446-000	3 - 4	DOOR, CARD	QM2-3035-000	9 - 3	LOGIC BOARD ASS'Y
QC1-8447-000	6 - 6	BUTTON, OPEN	QM2-3039-000	7 - 6	NIC BOARD ASS'Y
QC1-8448-000	3 - 17	COVER, CASSETTE	QM2-3092-000	15 - 7	CARRIAGE LIFT SENSOR UNIT
QC1-8449-000	3 - 6	WINDOW, IRDA	QM2-3110-000	8 - 3	IRDA BOARD UNIT
QC1-8452-000	4 - 5	FRAME, DOCUMENT PRESSURE SHEET	QM2-3111-000	8 - 1	PICT BRIDGE HARNESS ASS'Y
QC1-8455-000	4 - 8	GUIDE, MOUNT FILM	QM2-3113-000	8 - 2	MEMORY CARD HARNESS ASS'Y
QC1-8456-000	4 - 3	COVER, DOCUMENT PRESSURE PLATE L	QM2-3114-000	11 - 1	DC CONNECTOR ASS'Y
QC1-8457-000	4 - 2	COVER, DOCUMENT PRESSURE PLATE R	QM2-3115-000	6 - 1	SOLENOID RELAY HARNESS ASS'Y
QC1-8465-000	5 - 11	HOLDER, MIST COVER	QM2-3116-000	9 - 1	SCANNER MOTOR RELAY HARNESS ASS'Y
QC1-8478-000	5 - 10	COVER, MIST	QM2-3117-000	6 - 3	SCANNER OPEN SENSOR UNIT
QC1-8494-000	3 - 8	COVER, SIDE R	QM2-3119-000	11 - 2	MOTOR MULTI HARNESS ASS'Y
QC1-8498-000	5 - 3	PANEL, OPERATION L	QM2-3124-000	11 - 3	SENSOR MULTI HARNESS ASS'Y
QC1-8499-000	5 - 2	PANEL, OPERATION R	QM2-3125-000	7 - 4	SUB INTERFACE BOARD ASS'Y
QC1-8500-000	5 - 1	PANEL, LCD, PIXMA	QM2-3465-000	7 - 5	NIC HARNESS ASS'Y
QC1-8501-000	5 - 3	PANEL, OPERATION L	QM2-3466-000	7 - 3	NIC SUB HARNESS ASS'Y
QC1-8502-000	5 - 2	PANEL, OPERATION R	QM2-3467-000	6 - 7	SCANNER OPEN RELAY HARNESS



PART NUMBER	FIGURE & KEY No.		DESCRIPTION
QM2-3468-000	7 -	1	GROUND HARNESS
QM2-3469-000	6 -	3	SCANNER OPEN SENSOR UNIT
QM2-3704-000	8 -	2	MEMORY CARD HARNESS ASS'Y
QM2-3705-000	8 -	1	PICT BRIDGE HARNESS ASS'Y
QM2-3706-000	6 -	1	SOLENOID RELAY HARNESS ASS'Y
QM2-3707-000	11 -	3	SENSOR MULTI HARNESS ASS'Y
QM2-3708-000	9 -	1	SCANNER MOTOR RELAY HARNESS ASS'Y
QY5-0153-000	10 -	1	ABSORBER KIT
QY5-0155-000	16 -	1	BLUETOOTH UNIT, BU-20
QY5-0156-000	16 -	2	CAP, BU-20
QY6-0061-000	1 -	3	PRINT HEAD
QY9-0057-000	T -	1	LUBE, FLOIL KG107A, OIL
VS1-7165-002	6 -	2	CONNECTOR, CABLE
VS1-7165-004	9 -	2	CONNECTOR, CABLE
WE8-5071-000	5 -	12	CORE
WE8-5266-000	5 -	7	CORE
	12 -	9	
WE8-5881-000	7 -	2	CORE, RING
	11 -	4	
WE8-6323-000	12 -	14	CORE, RING
WT3-5156-000	1 -	4	CORD, POWER
XA4-9170-605	S -	5	SCREW, TAPING PAN HEAD, M1.7X6
XA9-1258-000	S -	9	SCREW, TAP, WASHER HEAD, M3X12
XA9-1437-000	S -	12	SCREW, BIND, M2.6X4(RED)
XB1-2200-505	S -	13	SCREW, MACH, TRUSS HEAD, M2X5
XB1-2300-405	S -	8	SCREW, MACH.BH, M3X4
XB2-4300-605	S -	10	SCREW, W/WASHER, M3X6
XB2-4300-805	S -	7	SCREW, M3
XB2-7300-605	S -	3	SCREW, W/WASHER, M3X6
XB4-7300-605	S -	11	SCREW, BH M3X6
XB4-7300-805	S -	1	SCREW, TP, BH3X8
XB4-7300-809	S -	4	SCREW, B-TIGHT: M3 X 8 MM
XB4-7301-005	S -	2	SCREW, M3x10
XB6-7300-605	S -	6	SCREW, MACHINE, WASHER HEAD, M3x6